



Configuring Cisco G.SHDSL HWICs in Cisco Access Routers

First Published: December 23, 2006 OL-11079-01

Last Updated: December 15, 2006

This document describes how to configure Cisco G.SHDSL high-speed WAN interface cards (HWICs). Cisco G.SHDSL HWICs connect Cisco access routers with central office digital subscriber line access multiplexer (DSLAMs) and provide as many as four lines of G.SHDSL (ITU-T 991.2) connectivity.

Finding Support Information for Platforms and Cisco IOS Software Images

Use Cisco Feature Navigator to find information about platform support and Cisco IOS software image support. Access Cisco Feature Navigator at <http://www.cisco.com/go/fn>. You must have an account on Cisco.com. If you do not have an account or have forgotten your username or password, click **Cancel** at the login dialog box and follow the instructions that appear.

Contents

- [Prerequisites for Cisco G.SHDSL HWICs, page 2](#)
- [Information About Cisco G.SHDSL HWICs, page 2](#)
- [Connecting Cisco G.SHDSL HWICs to the Network, page 4](#)
- [Configuring Cisco G.SHDSL HWICs, page 6](#)
- [Troubleshooting Cisco G.SHDSL HWICs, page 12](#)
- [Command Reference, page 22](#)
- [Additional References, page 43](#)

Prerequisites for Cisco G.SHDSL HWICs

- Ensure that you have the appropriate Cisco access router to serve as the host router. The following Cisco access routers support Cisco G.SHDSL HWICs.
 - Cisco 1841
 - Cisco 2800 series
 - Cisco 3800 series
- Use the **show version** command to ensure that the router is running Cisco IOS Release 12.4(11) XJ or a later release.



Note When minimum release requirements are met, you can change images on the router without affecting performance.

- Install the Cisco G.SHDSL HWIC on the router, using the directions provided in the *Cisco Interface Cards Hardware Installation Guide* and *Cisco Network Modules and Interface Cards Regulatory Compliance and Safety Information*.

Information About Cisco G.SHDSL HWICs

Cisco G.SHDSL HWICs support up to four pairs of digital subscriber lines (DSL): two inverse multiplexing over ATM (IMA) lines, and two ATM segmentation and reassembly (SAR) lines. The four DSL pairs are bundled in groups and configured in the Cisco IOS command-line interface (CLI) by using the **dsl-group** command.

G.SHDSL HWICs support the following DSL groups:

- Inverse Multiplexing over ATM (IMA) groups—1- 4 DSL pairs
- Multi-Pair Operation (M-Pair) groups—2 or more DSL pairs
- 2-Pair groups—2 DSL pairs
- 1-Pair groups—1 DSL pair


See the “[Command Reference](#)” section on page 22 for more information about commands used with Cisco G.SHDSL HWICs.

Cisco G.SHDSL HWICs

Cisco G.SHDSL HWICs are available in two variations:


- The Cisco HWIC-2SHDSL (Figure 1) provides two lines of connectivity through one *RJ-11* connector. It supports *1-Pair* groups or *2-Pair* groups.

Figure 1 Cisco HWIC-2SHDSL Faceplate



- The Cisco HWIC-4SHDSL (Figure 2) provides four lines of connectivity through one *RJ-45* connector. It combines four lines of data into one line or two lines with either inverse multiplexing over ATM (IMA) groups or *M-pair* groups, and it supports *1-Pair* groups or *2-Pair* groups.

Figure 2 Cisco HWIC-4SHDSL Faceplate



The Cisco HWIC-2SHDSL provides support for the Dying Gasp feature; however, the Cisco HWIC-4SHDSL does not provide support for this feature. The term *dying gasp* refers to power status as defined in ITU-T standard G.991.2, section 7.1.2.5.3.

EN	Status of the system: Green—Operating system is running. Amber—Interface card is resetting. Blinking—System is initializing.
L0, L1, L2, L3	Status of link: On—Link is active. Off—Link is inactive (disabled). Blinking—Link is training / Link alarm

What to do next

See the “[Connecting Cisco G.SHDSL HWICs to the Network](#)” section on page 4 for cable information.

Connecting Cisco G.SHDSL HWICs to the Network

Connect Cisco G.SHDSL HWICs as described next:

- Cisco HWIC-2SHDSL—Use a standard *RJ-11* straight-through cable to establish connection between the HWIC and a network device.
- Cisco HWIC-4SHDSL—Use a standard *RJ-45* straight-through cable to establish connection between the HWIC and a network device.

[Figure 3](#) shows the *RJ-45* pin assignment. [Table 1](#) identifies the *RJ-45* signal assignment by pin.



Caution Inserting an *RJ-11* connector into the Cisco HWIC-4SHDSL port may deform pins 1 and 8, which may prevent solid contact between the connector and the plug in subsequent connections. If solid contact is prevented, line -1 tip and line -3 ring will not work properly.

Figure 3 *RJ-45 Pin Assignment*




Table 1 *RJ-45 Signal Assignment by Pin*

Pin	Signal
1	Line 1 tip
2	Line 1 ring
3	Line 2 tip
4	Line 0 tip
5	Line 0 ring
6	Line 2 ring
7	Line 3 tip
8	Line 3 ring

To connect the Cisco HWIC-4SHDSL with a DSLAM that supports two or four *RJ-11* connections, modify the standard *RJ-45* cable, using one of the following diagrams as applicable:

- [Figure 4](#) shows how to modify the cable and connect the Cisco HWIC-4SHDSL with a DSLAM that supports four *RJ-11* cable connections.
- [Figure 5](#) shows how to modify the cable and connect the Cisco HWIC-4SHDSL with a DSLAM that supports two *RJ-11* cable connections.

Figure 4 Standard *RJ-45* Connector to Four Standard *RJ-11* Connectors





Figure 5 Standard *RJ-45* Connector to Two Standard *RJ-11* Connectors



What to Do Next

See the “[Configuring Cisco G.SHDSL HWICs](#)” section on page 6 for information about configuring DSL groups.

Configuring Cisco G.SHDSL HWICs

Configure DSL groups on the Cisco G.SHDSL HWIC, using the Cisco IOS CLI on the router in privileged configuration mode.

- [Configuring IMA Groups, page 6](#)
- [Configuring M-Pair Groups, page 8](#)
- [Configuring 1-Pair Groups and 2-Pair Groups, page 9](#)

Configuring IMA Groups

Use the Cisco IOS CLI on the router in global configuration mode to configure an *IMA* group on the Cisco HWIC-4SHDSL.

SUMMARY STEPS

1. `controller shdsl`
2. `dsl-group`
3. `ima link add`
4. `ima group minimum-links`
5. `ima group clock-mode`
6. `shdsl annex`
7. `shdsl rate`
8. `exit`
9. `exit`

DETAILED STEPS

	Command	Purpose
Step 1	<code>controller shdsl slot number/subslot number/0</code>	Selects the controller and enters config-controller mode. Example: Router (config)# <code>controller shdsl 0/2/0</code> Router (config-controller)#
Step 2	<code>dsl-group number pairs link number [ima m-pair]</code>	Creates a DSL group and enters config-controller-dsl-group mode. Example: Router (config-controller)# <code>dsl-group 0 pairs 0-3 ima</code>
Step 3	<code>ima link {add delete shutdown}number</code>	Modifies links in an IMA group. Example: Router (config-controller-dsl-group)# <code>ima link add 2</code>
Step 4	<code>ima group {shutdown minimum-links number clock-mode}</code>	Modifies IMA group behavior. Example: Router (config-controller-dsl-group)# <code>ima group minimum-links 2</code>

	Command	Purpose
Step 5	ima group clock-mode {ctc itc} Example: Router (config-controller-dsl-group)# ima group clock-mode ctc	Defines the clock mode for an IMA group. See the “ ima group clock-mode ” section on page 31 for more information.
Step 6	shdsl annex {standard} Example: Router (config-controller-dsl-group)# shdsl annex A	Defines the SHDSL annex. See the “ shdsl annex ” section on page 36 for more information.
Step 7	shdsl rate {number auto} Example: Router (config-controller-dsl-group)# shdsl rate auto	Defines the SHDSL rate. See the “ shdsl rate ” section on page 38 for more information.
Step 8	exit Example: Router (config-controller-dsl-group)# exit	Exits config-controller-dsl-group mode.
Step 9	exit Example: Router (config-controller)# exit	Exits config-controller mode.

Examples

The following example use the G.SHDSL commands to configure an IMA group on a HWIC- 4SHDSL.

```

Router(config)# controller shdsl 0/2/0
Router(config-controller)# dsl-group 1 pairs 1 ima
Router(config-controller-dsl-group)#?

dsl-group configuration sub commands:

    default      Set a command to its defaults
    exit         Exit dsl-group sub commands
    ima          IMA sub commands
    no           Negate a command or set its defaults
    shdsl        Symmetric g.shdsl configuration
    shutdown     Shutdown this dsl-group

Router(config-controller-dsl-group)# ima link add 2
Router(config-controller-dsl-group)# ima group minimum-links 2
Router(config-controller-dsl-group)# ima group clock-mode ?

    ctc  Common Transmit Clock configuration
    itc  Independent Transmit Clock configuration

Router(config-controller-dsl-group)# ima group clock-mode ctc ?
Router(config-controller-dsl-group)# shdsl annex a
Router(config-controller-dsl-group)# shdsl rate auto
Router(config-controller-dsl-group)# exit
Router(config-controller)# exit

```

Configuring M-Pair Groups

Use the Cisco IOS CLI on the router in global configuration mode to configure an M-Pair group on the Cisco HWIC-4SHDSL.


Note

To ensure a successful *M-Pair* group configuration, confirm that the central office (CO) network equipment that is connected with the Cisco HWIC-4SHDSL supports *M-Pair* bonding.

SUMMARY STEPS

1. **controller shdsl**
2. **dsl-group**
3. **shdsl annex**
4. **shdsl rate**
5. **exit**
6. **exit**

DETAILED STEPS

	Command	Purpose
Step 1	controller shdsl slot number/subslot number/0	Selects the controller and enters config-controller mode. Example: Router (config)# controller shdsl 0/2/0 Router (config-controller)#
Step 2	dsl-group number pairs link number [ima m-pair]	Creates a DSL group and enters config-controller-dsl-group mode. Example: Router (config-controller)# dsl-group 0 pairs 0-1 m-pair
Step 3	shdsl annex {standard}	Defines the SHDSL annex. Example: Router (config-controller-dsl-group)# shdsl annex A-B
Step 4	shdsl rate {number auto}	Defines the SHDSL rate. Example: Router (config-controller)# shdsl rate 2048
Step 5	exit	Exits config-controller-dsl-group mode. Example: Router (config-controller-dsl-group)# exit
Step 6	exit	Exits config-controller mode. Example: Router (config-controller)# exit

Examples

The following example use the G.SHDSL commands to configure an M-Pair group on a HWIC-4SHDSL.

```

Router(config)#
Router(config)# controller shdsl 0/2/0
Router(config-controller)# dsl-group 1 pairs 0-1 m-pair
Router(config-controller-dsl-group)#

Sep 27 14:16:00.167: %HWIC_SHDSL-5-DSLGROUP_UPDOWN: SHDSL 0/2/0 dsl-group(1) state changed
to down.
Sep 27 14:16:02.167: %LINK-3-UPDOWN: Interface ATM0/2/1, changed state to down
Sep 27 14:16:03.167: %LINEPROTO-5-UPDOWN: Line protocol on Interface ATM0/2/1, changed
state to down

Router(config-controller-dsl-group)# shdsl annex a-b
Router(config-controller-dsl-group)# shdsl rate 2048
Router(config-controller-dsl-group)# exit
Router(config-controller)# exit
Router(config)#

```

Configuring 1-Pair Groups and 2-Pair Groups

To configure a 1-Pair group or 2-Pair group on a Cisco HWIC-4SHDSL or HWIC-2SHDSL, use the Cisco IOS CLI on the router in global configuration mode.

SUMMARY STEPS

1. **controller shdsl**
2. **dsl-group**
3. **shdsl 4-wire mode**
(For 2-Pair groups only)
4. **shdsl annex**
5. **shdsl rate**
6. **exit**
7. **exit**

DETAILED STEPS

	Command	Purpose
Step 1	controller shdsl slot number/subslot number/0 Example: Router (config)# controller shdsl 0/2/0 Router (config-controller)#+	Selects the controller and enters config-controller mode. See the “ controller shdsl ” section on page 23 for more information.
Step 2	dsl-group number pairs link number Example(1-pair group): Router (config-controller)# dsl-group 0 pairs 0 Example(2-pair group): Router (config-controller)# dsl-group 0 pairs 0-1	Creates a DSL group and enters config-controller-dsl-group mode. See the “ dsl-group ” section on page 25 for more information.

Command	Purpose
Step 3 <code>shdsl 4-wire mode enhanced</code> Example: Router (config-controller)# shdsl 4-wire mode enhanced	Defines a 2-pair group as enhanced. See the “ shdsl 4-wire mode ” section on page 35 for more information.
Step 4 <code>shdsl annex {standard}</code> Example: Router (config-controller-dsl-group)# shdsl annex A-B	Defines the SHDSL annex. See the “ shdsl annex ” section on page 36 for more information.
Step 5 <code>shdsl rate {number auto}</code> Example: Router (config-controller)# shdsl rate 2048	Defines the SHDSL rate. See the “ shdsl rate ” section on page 38 for more information.
Step 6 <code>exit</code> Example: Router (config-controller-dsl-group)# exit	Exits config-controller-dsl-group mode.
Step 7 <code>exit</code> Example: Router (config-controller)# exit	Exits config-controller mode.

Examples

The following example use the G.SHDSL commands to configure a 1-Pair group and 2-Pair group on a HWIC-4SHDSL and HWIC-2SHDSL.

1-Pair Group Configuration

```
Router(config)# controller shdsl 0/2/0
Router(config-controller)# dsl-group 0 pairs 0
Router(config-controller-dsl-group)#
Oct  4 14:30:48.863: %HWIC_SHDSL-5-DSLGROUP_UPDOWN: SHDSL 0/2/0 dsl-group(0) state changed to down.
Oct  4 14:30:50.863: %LINK-3-UPDOWN: Interface ATM0/2/0, changed state to down
Oct  4 14:30:51.863: %LINEPROTO-5-UPDOWN: Line protocol on Interface ATM0/2/0, changed state to down

Router(config-controller-dsl-group)# shdsl annex ?
A      Annex A of G.991.2 standard
A-B    Annex A/B of G.991.2 standard
B      Annex B of G.991.2 standard
F      Annex F of G.991.2 standard
F-G    Annex F/G of G.991.2 standard
G      Annex G of G.991.2 standard

Router(config-controller-dsl-group)# shdsl annex A-B
Router(config-controller-dsl-group)# shdsl rate ?

<192-2304>  DSL Rate in kbps(line will train at the rate + 16kbps overhead)
auto          auto rate mode

Router(config-controller-dsl-group)# shdsl rate 2048
Router(config-controller-dsl-group)# exit
Router(config-controller)# exit
Router(config)#

```

2-Pair Group Configuration

```
Router(config)# controller shdsl 0/2/0
Router(config-controller)# dsl-group 0 pairs 0-1
Router(config-controller-dsl-group)#

Oct  4 14:37:01.027: %HWIC_SHDSL-5-DSLGROUP_UPDOWN: SHDSL 0/2/0 dsl-group(0) state changed
to down.
Oct  4 14:37:03.027: %LINK-3-UPDOWN: Interface ATM0/2/0, changed state to down
Oct  4 14:37:04.027: %LINEPROTO-5-UPDOWN: Line protocol on Interface ATM0/2/0, changed
state to down

Router(config-controller-dsl-group)# shdsl ?
4-wire  Symmetric g.shdsl 4-wire mode configuration
annex   Symmetric g.shdsl Annex configuration
rate    DSL line rate configuration

Router(config-controller-dsl-group)# shdsl 4-wire mode ?
enhanced 4-wire mode start up on both pairs

Router(config-controller-dsl-group)# shdsl 4-wire mode enhanced
Router(config-controller-dsl-group)# shdsl ?
4-wire  Symmetric g.shdsl 4-wire mode configuration
annex   Symmetric g.shdsl Annex configuration
rate    DSL line rate configuration

Router(config-controller-dsl-group)# shdsl annex ?
A      Annex A of G.991.2 standard
A-B    Annex A/B of G.991.2 standard
B      Annex B of G.991.2 standard
F      Annex F of G.991.2 standard
F-G    Annex F/G of G.991.2 standard
G      Annex G of G.991.2 standard

Router(config-controller-dsl-group)# shdsl annex A-B
Router (config-controller-dsl-group)# shdsl rate ?
<384-4608>  DSL Rate in kbps(line will train at the rate + 16kbps overhead)
auto       auto rate mode

Router(config-controller-dsl-group)# shdsl rate 2048
Router(config-controller-dsl-group)# exit
Router(config-controller)# exit
```

Troubleshooting Cisco G.SHDSL HWICs

To troubleshoot Cisco G.SHDSL HWICs, use the following new and published Cisco IOS commands. All other Cisco IOS software commands used with G.SHDSL HWICs are documented in the Cisco IOS Release 12.4(11) XJ command reference publication at Cisco.com:

http://www.cisco.com/en/US/products/ps6441/tsd_products_support_series_home.html

SUMMARY STEPS

1. **show controllers shdsl**
(new command)
2. **show controllers atm**
3. **show ima interface**
4. **show ima interface atm**
5. **show atm pvc**

DETAILED STEPS

	Command	Purpose
Step 1	show controllers shdsl slot number/subslot number/0 [detailed brief] Example: Router# show controllers shdsl 0/2/0 detailed	Displays the status of SHDSL controllers. See the “ show controllers shdsl ” section on page 40 for more information.
Step 2	show controllers atm [slot/subslot number/imagroup-number] Example: Router# show controllers atm 0/1/ima0	Displays information about the IMA group.
Step 3	show ima interface Example: Router# show ima interface	Displays information about the IMA interface.
Step 4	show ima interface atm [slot/subslot number/imagroup-number] [detailed] Example: Router# show ima interface atm 0/1/ima0	Displays detailed information about the IMA interface.
Step 5	show atm pvc Example: Router# show atm pvc	Displays information about ATM permanent virtual connections (PVCs) and traffic information.

Examples

The following example uses the **show controllers shdsl** command to display the controller status on a HWIC-4SHDSL.

```
show controllers shdsl
Router# show controllers shdsl 0/2/0 detailed
Controller SHDSL 0/2/0 is UP
```

```

Hardware is HWIC-4SHDSL, rev 2 on slot 0, hwic slot 2
Capabilities: IMA, M-pair, 2/4 wire, Annex A, B, F & G, CPE termination
cdb=0x43D8E90C, plugin=0x43CC44D0, ds=0x43D75284 base=0xB8000000
FPGA Version is REL.3.4.0, NIOSII FW:Ver 2.6, status Running
SDC-16i HW:Rev 1.2, status UP, FW:Ver 1.2-1.1.3_57, status Running
SDFE-4 HW:Rev 1.2, status UP, FW:Ver 1.1-1.5.2_001 , status Running
NIOSII Firmware image: System
SDC16i Firmware image: System
SDFE4 Firmware image: System
Number of pairs 4, number of groups configured 1
Ignored CLI cmd(0), Event buffer: in use(0), failed(0)
Group (0) info:
    Type: 2-wire g.shdsl, status: Configure Firmware
    Interface: ATM0/2/0, hwidb: 0x43D8EA54, UTOPIA phy 0
    Configured/active num links: 1/0, bit map: 0x1/0x0
    Line termination: CPE, line mode: 2-wire, Annex-B, PMMS disabled
    Line coding: 16-TCPAM, configured/actual rate: 2304/0 kbps
    SHDSL wire-pair (0) is in DSL DOWN state
        Termination: CPE, line mode: 2-wire, Annex-B
        Line coding: 16-TCPAM, configured/actual rate: 2304/0 kbps
        CONNECT state: MAIN_PRE_ACT, cond: NONE, reason: ERR_NONE
        Power back off: 0dB, FE power back off: 0dB
        LoopAttn: 0dB, SnrMargin: 0dB, Status noDefect
        Current 15 minute statistics (Time Elapsed 608 seconds):
            ES: 0, SES: 0, CRC: 0, LOSWS: 0, UAS: 0
        Previous 15 minute statistics:
            ES: 0, SES: 0, CRC: 0, LOSWS: 0, UAS: 0
        Current 24 hr statistics:
            ES: 0, SES: 0, CRC: 0, LOSWS: 0, UAS: 0
        Previous 24 hr statistics:
            ES: 0, SES: 0, CRC: 0, LOSWS: 0, UAS: 0
        ATM-TC Tx: data cells: 0, Idle/Unassigned: 0
        ATM-TC Rx: data cells: 0, uncorr HEC: 0, corr HEC: 0
        ATM-TC Rx: OCD: 0, LCD start: 0, LCD end: 0
    Group (1) is Not configured.
***** Firmware Status Information Start *****

ticks: 537140002, heapmem used: 223744 bytes

Utopia information:
    ints: 1, last intr status: 0x00000000
    utopia_tx_stuck_count: 1, utopia_rx_stuck_count: 1
    sar0_rcv_parity_errs: 0, sar0_rcv_errs: 0
    sar1_rcv_parity_errs: 0, sar1_rcv_errs: 0

IPC information:
    tx_polling: false
    Tx ok 538289, poll 0, fails qfull 0, noinit 0, dma 0
    Rx ok 53867, fails nobufs 0, noapp 0

DMA information:
    Write req 538294, complete 538294, underruns 0, overruns 0

VOS:
    write fail1: 0, fail2: 0, fail3: 0

App Group information:
    grp 0, tsnid 9, linkmap 0x1, flags 0x00, imacmd 0, realMWWMaster 0
    grp 1, tsnid 0, linkmap 0x0, flags 0x00, imacmd 0, realMWWMaster 0

App information:
    ch 0, pre_st 6, cur_st 6, tr 2, flags 0x210
    ch 1, pre_st 8, cur_st 8, tr 3, flags 0x000
    ch 2, pre_st 1, cur_st 5, tr 3, flags 0x000

```

```

ch 3, pre_st 1, cur_st 5, tr 3, flags 0x000

Chip information:
ch 0, state 1, cond 0, reason 0, prims 0xff, fbits 0x0f, vendFe 0
sa 1 crca 1 sd 1 loswd 1 snrmd 1 lad 1 loswf 1 trr 1 pwr status 1
ch 1, state 0, cond 0, reason 0, prims 0xffff, fbits 0x0f, vendFe 0
sa 1 crca 1 sd 1 loswd 1 snrmd 1 lad 1 loswf 1 trr 1 pwr status 1
ch 2, state 0, cond 0, reason 0, prims 0xffff, fbits 0x0f, vendFe 0
sa 1 crca 1 sd 1 loswd 1 snrmd 1 lad 1 loswf 1 trr 1 pwr status 1
ch 3, state 0, cond 0, reason 0, prims 0xffff, fbits 0x0f, vendFe 0
sa 1 crca 1 sd 1 loswd 1 snrmd 1 lad 1 loswf 1 trr 1 pwr status 1

Global information:
DSL wait 0, flags 0x7, cctmsgs 0, ipcmsgs 0
DSL rate mismatch 0, cct write fails 0, ipc write fails 0
DSL cmd sent: line_cfg 9, start_data 9
stop_data 8, rel_conn 8
IMA cmd sent: addgrp 0, delgrp 0, addlink 0
dellink 0, set_param 0
IMA fails addgrp 0, delgrp 0, addlink 0 dellink 0
/pipe/dsl_ipc_norm, mqp 0x3f66f0, nmsgs 32, msgsize 4
magic 0xbeefbacc, p_start 0x3f6720, p_end 0x3f68a0, memsize 384
free mhead 0x3f6780 mtail 0x3f6774 numfree 32
read qhead 0x0 qtail 0x0 qcount 0

CC information:
global state 4, restart 0, AppWrite fails 0
fatalError 0, selectErr 0
rxEctEvtNoMsgs 0, rxMctEvtNoMsgs 0, rxAppEvtNo Msgs 0
dciMsg2MctFails 0, ctrlMsg2MctFails 0, ectSendFails 0
sciMsg2MctFails 0, sciAuxMsg2MctFails 0, sciRsMsg2MctFails 0

Channel cfg:
ch 0, state 5, substate 12, conntype 1, mwire 0, realMwMaster 0
ch 1, state 4, substate 0, conntype 1, mwire 1, realMwMaster 0
ch 2, state 4, substate 0, conntype 1, mwire 0, realMwMaster 0
ch 3, state 4, substate 0, conntype 1, mwire 0, realMwMaster 0

Channel var:
ch 0, state 5, atmsync 0, atm_tcenable 0, delayMt 0, delay 0
ch 1, state 1, atmsync 0, atm_tcenable 0, delayMt 0, delay 0
ch 2, state 1, atmsync 0, atm_tcenable 0, delayMt 0, delay 0
ch 3, state 1, atmsync 0, atm_tcenable 0, delayMt 0, delay 0

IMA group info:
idx 0, state 0, rate 0, id 0, GrpId 255, mod 0, mismatch 0
idx 1, state 0, rate 0, id 0, GrpId 255, mod 0, mismatch 0
idx 2, state 0, rate 0, id 0, GrpId 255, mod 0, mismatch 0
idx 3, state 0, rate 0, id 0, GrpId 255, mod 0, mismatch 0

IMA link info:
idx 0, imaGrp 255, linkId 255, rate 0, mismatch 0
idx 1, imaGrp 255, linkId 255, rate 0, mismatch 0
idx 2, imaGrp 255, linkId 255, rate 0, mismatch 0
idx 3, imaGrp 255, linkId 255, rate 0, mismatch 0

MC information:
state 5, nDciInUse 0, fatalerr 0

DciInUse >= 10 msgs err:
dsDci 0, dsSci 0, dsSciAux 0, dsSciRs 0, rxCCT 0 rxEct 0

Other Stats:
dsDciWrFails1 0, dsDciWrFails2 0, dsSciAckLost 0

```

```

dsSciWrFails1 0, dsSciWrFails2 0, dsSciAuxWrFails1 0
dsSciAuxWrFails2 0, dsSciRsWrFails1 0, dsSciRsWrFails2 0
usSciInvalidLen 0, usSciUnexpectedAck 0, usSciMsgFw2EctFails 0
usSciMsgFw2CctFails 0, usSciAuxInvalidLen 0, usSciSendFails 0
usDciSendFails 0, sciBlocking 0, dciBlocking 0

EC information:
mctMsgsRx 0, mctMsgsTxFails 0, mctMsgsTxOks 0

VOS Pipes:
/pipe/CCT_FROM_APP_0, mqp 0x3c0c78, nmsgs 32, msgsize 400
magic 0xbeefbacc, p_start 0x3c0ca8, p_end 0x3c3fa8, memsize 13056
free mhead 0x3c3e10 mtail 0x3c3c78 numfree 32
read qhead 0x0 qtail 0x0 qcount 0

/pipe/CCT_TO_APP_0, mqp 0x3c4018, nmsgs 64, msgsize 400
magic 0xbeefbacc, p_start 0x3c4048, p_end 0x3ca648, memsize 26112
free mhead 0x3c6e80 mtail 0x3c6ce8 numfree 64
read qhead 0x0 qtail 0x0 qcount 0

/pipe/CCT_FROM_MCT_0, mqp 0x3ca6b8, nmsgs 96, msgsize 400
magic 0xbeefbacc, p_start 0x3ca6e8, p_end 0x3d3fe8, memsize 39168
free mhead 0x3cab0 mtail 0x3caa18 numfree 96
read qhead 0x0 qtail 0x0 qcount 0

/pipe/CCT_FROM_ECT_0, mqp 0x3d4058, nmsgs 32, msgsize 400
magic 0xbeefbacc, p_start 0x3d4088, p_end 0x3d7388, memsize 13056
free mhead 0x3d4088 mtail 0x3d71f0 numfree 32
read qhead 0x0 qtail 0x0 qcount 0

/pipe/MCT_TO_ECT_0, mqp 0x3d73f8, nmsgs 64, msgsize 400
magic 0xbeefbacc, p_start 0x3d7428, p_end 0x3dda28, memsize 26112
free mhead 0x3d7428 mtail 0x3dd890 numfree 64
read qhead 0x0 qtail 0x0 qcount 0

/pipe/CCT_TO_ECT_0, mqp 0x3dda98, nmsgs 32, msgsize 400
magic 0xbeefbacc, p_start 0x3ddac8, p_end 0x3e0dc8, memsize 13056
free mhead 0x3e0a98 mtail 0x3e0900 numfree 32
read qhead 0x0 qtail 0x0 qcount 0

/pipe/CCT_TO_MCT_0, mqp 0x3e36e8, nmsgs 96, msgsize 400
magic 0xbeefbacc, p_start 0x3e3718, p_end 0x3ed018, memsize 39168
free mhead 0x3ead08 mtail 0x3eab70 numfree 96
read qhead 0x0 qtail 0x0 qcount 0

/pipe/MCT_FROM_ECT_0, mqp 0x3ed088, nmsgs 64, msgsize 400
magic 0xbeefbacc, p_start 0x3ed0b8, p_end 0x3f36b8, memsize 26112
free mhead 0x3ed0b8 mtail 0x3f3520 numfree 64
read qhead 0x0 qtail 0x0 qcount 0

```

Tasks:

```

tIPC delay 00000 flags 0x002 schedcnt 106899104
tMCT_0 delay 00000 flags 0x000 schedcnt 21379921
tCCT delay 00011 flags 0x000 schedcnt 10743684
sCCT delay 00236 flags 0x000 schedcnt 537184
tECT delay 00460 flags 0x000 schedcnt 537195
tDMT delay 00010 flags 0x000 schedcnt 11280188

```

***** Firmware Status Information End *****

IPC Info:	host_base=0xF59B040,	sram_base=0xB81E0000			
CmdType	Tx	TxErr	Rx	RxFailed	RxUnknown

■ Troubleshooting Cisco G.SHDSL HWICs

```

    GEN      6      0      8      0      0
    DBG      0      0      0      0      0
    DSL     34      0   536537      0      0
    IMA      0      0      0      0      0
    EOC      0      0      0      0      0
***** HWIC Common Registers at B8000000 *****
HWIC ID:      0x1
HWIC Revision: 0x4
HWIC Status: 0x0
HWIC DDR TXCRC:0x0
HWIC Control: 0x8040
    DDR Enable      1      Software Reset      0
    Interrupt Module Reset 0      GDF Module Reset      0
    DMA Module Reset 0      Flow Control Reset      0
    IRQ2 Global Int Mask 0      IRQ1 Global Int Mask 1
    DDR TXCRC Int Mask 0      DDR TXClk Loss Int Mask 0
    TX Fifo Overrun Int Mask 0
HWIC Interrupt Event: 0x0
    DDR TXCRC Int      0      DDR TXClk Loss Int      0
    TX Fifo Overrun Int 0
HWIC Diag 1: 0x0
HWIC Diag 2: 0x1EOF

***** HWIC Host Registers at B8A00000 *****
Status (0x00):
    Card Present Low      0      Graceful Stop Tx Complete 0
Config (0x00000806):
    Hwic Reset      0      Hwic Host Reset      0
    Hwic IRQ2 Type Err      Hwic IRQ1 Type      Net
    Rx Queue Watermark Enable 0      Auto XOFF When Full 0
    Rx Int On Last      0      Graceful Stop Tx      0
    Generic Rx Enable 0      Generic Tx Enable 1
    DDR Enable      1      Loopback      0
Error Interrupt Enable (0x37EFF):
    Rx Done Error Int      1      Card Present Change Int 1
    Hwic Int Frame Error Int 0x07      Tx First Last Error Int 1
    Tx Done Error Int      1      IRQ2 Int      1
    IRQ1 Int      0      Host Specific Error Int 1
    Rx Overrun Int      1      DDR RxClk Missing Int 1
    Reg RW Timeout Int 1      Reg RW Error Int 1
    Rx CRC Int      1      Rx Format Error Int 1
    DMA Error Int      1
Management Interrupt Enable (0xA000):
    Hwic Int Frame Mgmt Int 0x0A
    IRQ2 Int      0
    IRQ1 Int      0      Graceful Stop Tx Int 0
Network Interrupt Enable (0x003F):
    Rx Frame Drop Int      0      Generic Frame Tx Int 0
    Generic Frame Rx Int 0      DMA Write Int 0
    IRQ2 Int      0      IRQ1 Int 0
    Int Frame Network Int 0x3F
Error Interrupt Event (0x0000):
    Rx Done Error Event      0      Card Present Change Event 0
    Hwic Int Frame Error Event 0x00      Tx First Last Error Event 0
    Tx Done Error Event      0      IRQ2 Event 0
    IRQ1 Event      0      Host Specific Error Event 0
    Rx Overrun Event      0      DDR RxClk Missing Event 0
    Reg RW Timeout Event 0      Reg RW Error Event 0
    Rx CRC Event      0      Rx Format Error Event 0
    DMA Error Event      0
Management Interrupt Event (0x0000):
    Hwic Int Frame Mgmt Event 0x00
    IRQ2 Int      0
    IRQ1 Int      0      Graceful Stop Tx Event 0

```

Network Interrupt Event (0x1000):			
Rx Frame Drop Event	0	Generic Frame Tx Event	1
Generic Frame Rx Event	0	DMA Write Event	0
IRQ2 Event	0	IRQ1 Event	0
Int Frame Network Event	0x00		
HWICRegisterOffset	0x0000	HWICRegisterErrorAddress	0x00000000
HWICRegisterTimeout	0x0000C350		
TxControlFrameCounter	0x2B4F3F	RxControlFrameCounter	0x264A19
TxDataFrameCounter	0x00D271	RxDataFrameCounter	0x0836E6
RegisterRWErroredCounter	0x0000	RxOverrunErrorCounter	0x0000
RxCRCErrorCounter	0x0000	RxFrameDropCounter	0x0000
TxBUFFERExtension	0x00	RxBUFFERExtension	0x00
HWICQueueBaseExtension	0x00	HWICQueueBase	0x0F59
TXQueueTailBase Register	0xC088		
TxQueueBase	0x18	TxQueueTail	0x11
TxQueueSize	0x20	TxQueueHead	0x11
RxQueueHeadBase Register	0x0000		
RxQueueBase	0x00	RxQueueHead	0x00
RxQueueSize	0x00	RxQueueTail	0x00
RxBUFFERSize	0x0000	RxQueueHighWaterMark	0x00
RxQueueLowWaterMark	0x00	DMAOffsetExtension	0x00
DMAOffset	0x0000	DMAWindow	0x0000

The following example uses the **show controllers atm** command to display information about an IMA group.

show controllers atm

```
Router#show controllers atm 0/1/ima0
DSL SAR Info
Interface: ATM0/1/IMA0 Hardware: DSLSAR WITH IMA State: up
IDB: 0x4358A1F8 Instance: 0x435B70C8 dpi: 0x435D3C90
PHY bw: 4608 kbps Cell tick: 0x00121ECA Current TST: 1
NetIO enable: 0x003F Int status: 0x0000, sram_base(h): 0xB0240000
SAR reg base: 0xB0202400 Host reg base: 0xB0A00400
SAR config: 0x200D0A20 SAR status: 0x00000000
RPQ head: 0xF394330 RPQ tail:0xF394330
RCQ head: 0xF390D40 RCQ tail:0xF390D40
FBQ head: 0x000198DC FBQ tail:0x00019CBC
TBQ head: 0xF392260 TBQ tail:0xF392260
RCT base: 0x0001A000 RCID base:0x00030000
Tx ints: 0x00005842 Rx pkt ints: 0x00005495
Rx cell ints: 0x000003E9 Rx pkts: 0x00005118
Tx pkts: 0x00005119 Tx OAM cells: 0x000003C0
Rx raw cells: 0x000003C0
Utopia Tx cells: 0x0009D5C2 Utopia Rx cells: 0x0009D5C2
Utopia Tx rate: 10742.43 cps, 4554790 bps
Tx idle rate: 0.00 cps, 0 bps
Utopia Rx rate: 10742.43 cps, 4554790 bps
Bad tbd_ids: 0x00000000, Tx error: 0x00000000
oam_nobuf: 0x00000000 no_tbd_id: 0x00000000 shaping_defer: 0x00000000
bad_oam_rx: 0x00000000 delayed_rpqe: 0x00000000 delayed_tbqe: 0x00000000
DSL SAR Info
Unknown vpi/vci: 0x00000000, Inv cells: 0x00000000
TCD[0]: 0x00000000 TCD[1]: 0x00000040
TST[0]: 0x00000240 TST[1]: 0x0000CB6C
Boot jump: 0x00019498 RCTE[0]: 0x0001A000 FBQ: 0x00019800
lp_tcq[0][0]: 0x0001B000 lp_tcq[0][1]: 0x0001B010
lp_tcq[1][0]: 0x0001C000 lp_tcq[1][1]: 0x0001C010
hp_tcq[0][0]: 0x00024000 hp_tcq[0][1]: 0x00024010
hp_tcq[1][0]: 0x00025000 hp_tcq[1][1]: 0x00025010
rx_conn_id[0]: 0x00030000 rcte[0]: 0x0001A000
```

```

Configured vcs:
    VCD   VPI   VCI   QoS(c)   QoS(a)   BW(c)   BW(a)   RCTE   rd(min/max/var)
    1     1     11    5        5        0       4608   0x000A220B  3370/22859/19489
    2     1     12    5        5        0       4608   0x000A221C  4035/23100/19064
    3     1     13    5        5        0       4608   0x000A2211  3197/22446/19248
    4     1     14    5        5        0       4608   0x000A2203  3607/21524/17917
    5     1     15    5        5        0       4608   0x000A0000  4022/29498/25476
    6     1     16    5        5        0       4608   0x000A2209  20/12401/12381
    7     1     17    5        5        0       4608   0x000A0000  --
    8     1     18    5        5        0       4608   0x000A0000  5651/19762/14110

VC Tx stats:
    VCD      Tx(hp)      Tx(lp)      ring(p/b)  pkts(h/l)  bufs(h/l)  td(min/max/var)
    0  0x00000440  0x00000000  30/30      0/0        0/0        7176/7916/739
    1  0x00000B81  0x00000000  30/30      30/0      30/0      15160/15402/241

DSL SAR Info
    2  0x00000B81  0x00000000  30/30      30/0      30/0      15160/15402/241
    3  0x00000B9E  0x00000000  30/30      30/0      30/0      15160/15415/255
    4  0x00000B9E  0x00000000  30/30      30/0      30/0      15160/15415/255
    5  0x00000B9F  0x00000000  30/30      30/0      30/0      15160/15402/241
    6  0x00000B9E  0x00000000  30/30      30/0      30/0      15160/15456/295
    7  0x00000B9E  0x00000000  30/30      30/0      30/0      15160/15469/309
    8  0x00000B9E  0x00000000  30/30      30/0      30/0      15160/15415/255

Unreserved TBDIDs: 512

OAM table(0x0000CB6C):
    0
    0x6000CB6C 0x00100274 0x001018BC 0x001018E4 0x0010190C 0x00801934
    0x00000240 0x00000274 0x0000195C 0x000045E0 0x00007264

CBR table(0x0000CBA0):
    *
    EOT(0x0000CBA0) -- entries: 1

VBR1 poll table (0x0000E1E8):
    EOT(0x0000E1E8) -- entries: 0
    VBR1 redirect table (0x0000E288):
        *
        DSL SAR Info
        EOT(0x0000E288) -- entries: 1

VBR2 poll table (0x0000E210):
    EOT(0x0000E210) -- entries: 0
    VBR2 redirect table (0x00010F0C):
        *
        EOT(0x00010F0C) -- entries: 1

VBR3 poll table (0x0000E238):
    EOT(0x0000E238) -- entries: 0
    VBR3 redirect table (0x00013B90):
        *
        EOT(0x00013B90) -- entries: 1

VBR4 poll table (0x0000E260):
    1 2 3 4 5 6 7 8
    EOT(0x0000E260) -- entries: 8
    VBR4 redirect table (0x00016814):
        1 2 3 4 5 6 7 8
        1 2 3 4 5 6 7 8
        1 2 3 4 5 6 7 8
    DSL SAR Info
    1 2 3 4 5 6 7 8

```


The following example uses the **show ima interface** command to display information about an IMA interface.

show ima interface

```
Router#show ima interface
Interface ATM0/2/IMA0 is down
    Group index is 0, group ifIndex is 11
    Ne state is startUp, failure status is noFailure
    Active links bitmap 0x0
IMA Group Current Configuration:
    Tx/Rx configured links bitmap 0x3/0x3
    Tx/Rx minimum required links 1/1
    Maximum allowed diff delay is 25ms, Tx frame length 128
    Ne Tx clock mode CTC, configured timing reference link Pair 0
    Test pattern procedure is disabled
IMA Group Current Counters (time elapsed 0 seconds):
    0 Ne Failures, 0 Fe Failures, 0 Unavail Secs
IMA Group Total Counters (last 0 15 minute intervals):
    0 Ne Failures, 0 Fe Failures, 0 Unavail Secs
IMA link Information:
    Link      Physical Status      NearEnd Rx Status      Test Status
    -----      -----           -----           -----
    Pair 0    down                notInGroup        disabled
    Pair 1    down                notInGroup        disabled
Router#
```

The following example uses the **show ima interface detail** command to display detailed information about an IMA interface.

show ima interface detail

```
Router#show ima interface atm 0/2/ima0 detailed
Interface ATM0/2/IMA0 is down
    Group index is 0, group ifIndex is 11
    Ne state is startUp, failure status is noFailure
    Active links bitmap 0x0
IMA Group Current Configuration:
    Tx/Rx configured links bitmap 0x3/0x3
    Tx/Rx minimum required links 1/1
    Maximum allowed diff delay is 25ms, Tx frame length 128
    Ne Tx clock mode CTC, configured timing reference link Pair 0
    Test pattern procedure is disabled
Detailed group Information:
    Ne IMA version in operation IMA Version 1.1
    Fe IMA version in operation IMA Version 1.1
    Tx/Rx Ima_id 0x0/0xFFFFFFFF, symmetry symmetricOperation
    Number of Tx/Rx configured links 2/2
    Number of Tx/Rx active links 0/0
    Fe Tx clock mode CTC, Rx frame length 128
    Tx/Rx timing reference link 0/-1
    Maximum observed diff delay 0ms, least delayed link -1
    Running seconds 0
    GTSM last changed 16:06:16 UTC Wed Oct 4 2006
IMA Group Current Counters (time elapsed 0 seconds):
    0 Ne Failures, 0 Fe Failures, 0 Unavail Secs
IMA Group Total Counters (last 0 15 minute intervals):
    0 Ne Failures, 0 Fe Failures, 0 Unavail Secs
Detailed IMA link Information:

Link Pair 0 is down
    ifIndex 12, Group ifIndex 11, Row Status is active
    Tx/Rx Lid -1/-1, relative delay 0ms
```

```

Ne Tx/Rx state notInGroup/notInGroup
Fe Tx/Rx state notInGroup/notInGroup
Ne Rx failure status is noFailure
Fe Rx failure status is noFailure
Rx test pattern 0x0, test procedure disabled
IMA Link Current Counters (time elapsed 0 seconds):
 0 Ima Violations, 0 Oif Anomalies
 0 Ne Severely Err Secs, 0 Fe Severely Err Secs
 0 Ne Unavail Secs, 0 Fe Unavail Secs
 0 Ne Tx Unusable Secs, 0 Ne Rx Unusable Secs
 0 Fe Tx Unusable Secs, 0 Fe Rx Unusable Secs
 0 Ne Tx Failures, 0 Ne Rx Failures
 0 Fe Tx Failures, 0 Fe Rx Failures
IMA Link Total Counters (last 0 15 minute intervals):
 0 Ima Violations, 0 Oif Anomalies
 0 Ne Severely Err Secs, 0 Fe Severely Err Secs
 0 Ne Unavail Secs, 0 Fe Unavail Secs
 0 Ne Tx Unusable Secs, 0 Ne Rx Unusable Secs
 0 Fe Tx Unusable Secs, 0 Fe Rx Unusable Secs
 0 Ne Tx Failures, 0 Ne Rx Failures
 0 Fe Tx Failures, 0 Fe Rx Failures

Link Pair 1 is down
  ifIndex 13, Group ifIndex 11, Row Status is active
  Tx/Rx Lid -1/-1, relative delay 0ms
  Ne Tx/Rx state notInGroup/notInGroup
  Fe Tx/Rx state notInGroup/notInGroup
  Ne Rx failure status is noFailure
  Fe Rx failure status is noFailure
  Rx test pattern 0x0, test procedure disabled
IMA Link Current Counters (time elapsed 0 seconds):
 0 Ima Violations, 0 Oif Anomalies
 0 Ne Severely Err Secs, 0 Fe Severely Err Secs
 0 Ne Unavail Secs, 0 Fe Unavail Secs
 0 Ne Tx Unusable Secs, 0 Ne Rx Unusable Secs
 0 Fe Tx Unusable Secs, 0 Fe Rx Unusable Secs
 0 Ne Tx Failures, 0 Ne Rx Failures
 0 Fe Tx Failures, 0 Fe Rx Failures
IMA Link Total Counters (last 0 15 minute intervals):
 0 Ima Violations, 0 Oif Anomalies
 0 Ne Severely Err Secs, 0 Fe Severely Err Secs
 0 Ne Unavail Secs, 0 Fe Unavail Secs
 0 Ne Tx Unusable Secs, 0 Ne Rx Unusable Secs
 0 Fe Tx Unusable Secs, 0 Fe Rx Unusable Secs
 0 Ne Tx Failures, 0 Ne Rx Failures
 0 Fe Tx Failures, 0 Fe Rx Failures

```

The following example uses the **show atm pvc** command to display information about permanent virtual connections (PVCs) and traffic information.

show atm pvc

```

Router# show atm pvc
          VCD /
Interface Name      VPI    VCI  Type   Encaps     SC   Peak   Avg/Min Burst
          0/0/0    1        1    66  PVC      SNAP     UBR   4608
          0/0/0    2        1    77  PVC      SNAP     UBR   4608
          0/0/0    3        1    88  PVC      SNAP     UBR   4608
          0/1/0    1        1    44  PVC      SNAP     UBR   4608
Router#

```

Command Reference

This section documents the following new and modified Cisco IOS commands. All other Cisco IOS software commands used with this HWIC are documented in the Cisco IOS Release 12.4(11) XJ command reference publication at Cisco.com:

http://www.cisco.com/en/US/products/ps6441/tsd_products_support_series_home.html

New Commands

- [dsl-group](#), page 25
- [ima group clock-mode](#), page 31
- [ima link](#), page 33
- [shdsl 4-wire mode](#), page 35
- [shdsl annex](#), page 36
- [shdsl rate](#), page 38

Modified Commands

- [controller shdsl](#), page 23
- [ima-group](#), page 28
- [show controllers shdsl](#), page 40

controller shdsl

To configure a controller for single-pair high-bit-rate digital subscriber line (SHDSL) mode, use the **controller shdsl** command in global or controller configuration mode.

Cisco HWIC-4SHDSL and HWIC-2SHDSL

controller shdsl slot number/subslot number/port number

Cisco IAD2420 Series

controller shdsl number

Syntax Description	<table border="0"> <tr> <td><i>number</i></td><td>Controller number. The valid controller number is 0.</td></tr> <tr> <td><i>slot number</i></td><td>Defines the slot on the router in which the high-speed WAN interface cards (HWIC) is installed.</td></tr> <tr> <td><i>subslot number</i></td><td>Defines the subslot on the router in which the HWIC is installed.</td></tr> <tr> <td><i>port number</i></td><td>Defines the port on the router in which the HWIC is installed. By default, Cisco HWIC-4SHDSL and HWIC-2SHDSL use port number 0.</td></tr> </table>	<i>number</i>	Controller number. The valid controller number is 0.	<i>slot number</i>	Defines the slot on the router in which the high-speed WAN interface cards (HWIC) is installed.	<i>subslot number</i>	Defines the subslot on the router in which the HWIC is installed.	<i>port number</i>	Defines the port on the router in which the HWIC is installed. By default, Cisco HWIC-4SHDSL and HWIC-2SHDSL use port number 0.
<i>number</i>	Controller number. The valid controller number is 0.								
<i>slot number</i>	Defines the slot on the router in which the high-speed WAN interface cards (HWIC) is installed.								
<i>subslot number</i>	Defines the subslot on the router in which the HWIC is installed.								
<i>port number</i>	Defines the port on the router in which the HWIC is installed. By default, Cisco HWIC-4SHDSL and HWIC-2SHDSL use port number 0.								

Command Defaults	Controller number: 0
-------------------------	----------------------

Command Modes	Cisco HWIC-4SHDSL and HWIC-2SHDSL Global configuration Controller configuration
----------------------	---

Cisco IAD2420 Series
Global configuration

Command History	Release	Modification
	11.3(5)AAA	This command was introduced.
	12.2(8)T	This command was implemented on Cisco IAD2420 series IADs.
	12.4(15)T	This command was introduced for the Cisco HWIC-4SHDSL and HWIC-2SHDSL running on the Cisco 1841 router, and on the Cisco 2800 and 3800 series access routers.

Usage Guidelines	This command is used to configure the controller mode and the controller number.
-------------------------	--

```
■ controller shdsl
```

Examples**Cisco HWIC-4SHDSL and HWIC-2SHDSL**

The following example uses the **controller shdsl** command to configure a Cisco HWIC-4SHDSL installed in a Cisco access router, controller number 0, subslot 2, port number 0); the example enters controller configuration mode:

```
Router(config)# controller shdsl 0/2/0
Router(config-controller)#

```

Cisco IAD2420 Series

The following example uses the **controller shdsl** command to enter SHDSL controller mode on controller number 0; the example also configures ATM mode:

```
Router# controller shdsl 0
Router# mode atm

```

Related Commands

Command	Description
show controller shdsl	Displays the controller status and statistics.

dsl-group

To create a digital subscriber line (DSL) group and enter config-controller-dsl-group mode, use the **dsl-group** command in config-controller mode. To disable the DSL group, use the **no** form of this command.

dsl-group number pairs link number [ima| m-pair]

no dsl-group number pairs link number

Syntax Description		
	<i>number</i>	Defines the dsl-group number. The dsl-group number can be one of the following numbers: <ul style="list-style-type: none"> • 0 • 1
	pairs	Defines the DSL wire pairs.
	<i>link number</i>	Designates the pair's link number. Link number options are limited to one of the following choices, based on the hardware interface and the desired DSL group.
HWIC-4SHDSL		
IMA DSL Group		
<ul style="list-style-type: none"> • 0 • 1 • 2 • 3 • Any combination of the numbers 0,1,2,3 		
M-Pair DSL Group		
<ul style="list-style-type: none"> • 0-1 • 0-2 • 0-3 		
2-Pair DSL Group		
<ul style="list-style-type: none"> • 0-1 • 2-3 		
1-Pair DSL Group		
<ul style="list-style-type: none"> • 0 • 1 • 2 • 3 		

HWIC-2SHDSL	
DSL Group 0	
• 0	
• 1	
• 0-1	
DSL Group 1	
• 1	
ima	Defines a DSL group as an inverse multiplexing over ATM (IMA) group.
m-pair	Defines a DSL group as an M-pair group.

Command Default No DSL group is defined.

Command Modes Config controller

Command History	Release	Modification
	12.4(15)T	This command was introduced for the Cisco HWIC-4SHDSL and HWIC-2SHDSL running on the Cisco 1841 router and the Cisco 2800 and 3800 series access routers.

Usage Guidelines From config-controller mode, use the **dsl-group** command to define the DSL group and enter config-controller-dsl-group mode.

Examples The following example uses the **dsl-group** command to create an IMA-DSL group and enter config-controller-dsl-group mode:

```
Router(config-controller)# dsl-group 1 pairs 0-1 ima
Router(config-controller-dsl-group)#
Sep 14 13:15:40.285:%HWIC_SHDSL-5-DSLGROUP_UPDOWN: SHDSL 0/2/0 dsl-group(1) state changed to down.
Sep 14 13:15:42.285:%LINK-3-UPDOWN: Interface ATM0/2/IMA1, changed state to down
Sep 14 13:15:43.285:%LINEPROTO-5-UPDOWN: Line protocol on Interface ATM0/2/IMA1, changed state to down
```

Related Commands	Command	Description
	controller shdsl	Configures a controller for SHDSL mode and enters config-controller mode.
	ima group	Defines physical links as IMA group members.
	ima group clock-mode	Sets the clock mode for an IMA group.
	ima link	Defines physical links in an IMA group.

Command	Description
shdsl 4-wire mode enhanced	Defines the SHDSL to use enhanced mode in a 2-pair DSL group.
shdsl annex	Defines the SHDSL G.991.2 standard.
shdsl rate	Defines the SHDSL rate.
show controller shdsl	Displays the status of the controller that is configured for SHDSL mode.

ima-group

ima-group

To define inverse multiplexing over ATM (IMA) groups, use the **ima-group** command in interface configuration mode for Cisco 7100, 7200, and 7500 series routers; use the command in config controller mode for the Cisco HWIC-4SHDSL. To remove the group, use the **no** form of this command.

Cisco HWIC-4SHDSL

```
ima-group [shutdown | minimum-links number | clock-mode]
```

Cisco 7100, 7200, and 7500 series routers

```
ima-group group-number
```

```
no ima-group group-number
```

Syntax Description	clock-mode	Sets the clock mode for an IMA group
	<i>group-number</i>	Specifies an IMA group number from 0 to 3. IMA groups can span multiple ports on a port adapter but cannot span port adapters.
	minimum-links <i>number</i>	Defines the number of minimum links that must remain in operation for an IMA group to remain in service.
	shutdown	Shuts down physical links in an IMA group.

Command Defaults No IMA groups are defined.

Command Modes Cisco HWIC-4SHDSL
Config controller
Config controller DSL group

Cisco 7100, 7200, and 7500 series routers

Interface configuration

Command History	Release	Modification
	12.0(5)XK	This command was introduced on Cisco 2600 and 3600 series routers.
	12.0(5)T	This command was integrated into Cisco IOS Release 12.0(5)T.
	12.0(5)XE	Support for Cisco 7200 and 7500 series routers was added.
	12.0(7)XE1	Support for Cisco 7100 series routers was added.
	12.1(5)T	Support for Cisco 7100, 7200, and 7500 series routers was added
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

12.4 (11)XJ	This command was integrated into Cisco IOS Release 12.4 (11)XJ.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

For usage guidelines for using the **clock-mode** keyword, see the command reference page for the **ima group clock-mode** command.

Cisco HWIC-4SHDSL

Use the **dsl-group** command with the optional keyword **ima** to create an IMA DSL group and to enter config-controller-dsl-group mode. Use the **ima group** command to define the links as IMA group members.

Cisco 7100, 7200, and 7500 series routers

When the configuration is first performed or when the group number is changed, the interface is automatically disabled, moved to the new group, and then enabled.

Examples**Cisco HWIC-4SHDSL**

The following example uses the **dsl-group** command to create an IMA group and enter config-controller-dsl-group mode on the Cisco HWIC-4SHDSL in a Cisco access router:

```
Router(config-controller)# dsl-group 1 pairs 0-1 ima
Router(config-controller-dsl-group)#
Sep 26 11:43:55.798: %HWIC_SHDSL-5-DSLGROUP_UPDOWN: SHDSL 0/2/0 dsl-group(1) state changed to down.
Sep 26 11:43:57.798: %LINK-3-UPDOWN: Interface ATM0/2/IMA1, changed state to down
Sep 26 11:43:58.798: %LINEPROTO-5-UPDOWN: Line protocol on Interface ATM0/2/IMA1, changed state to down

Router (config-controller-dsl-group)#
dsl-group configuration sub commands:
  default   Set a command to its defaults
  exit      Exit dsl-group sub commands
  ima       IMA sub commands
  no        Negate a command or set its defaults
  shdsl    Symmetric g.shdsl configuration
  shutdown  Shutdown this dsl-group

Router (config-controller-dsl-group)#
group  IMA group configuration
link   IMA link configuration

Router (config-controller-dsl-group)#
clock-mode      IMA group clock mode configuration
minimum-links  Minimum number of active links for group UP
shutdown        IMA group shutdown
```

ima-group**Cisco 7100, 7200, and 7500 series routers**

The following example assigns interface 1 on the ATM module in slot 0 to a member of IMA group 2:

```
interface atm0/1
  ima-group 2
```

Related Commands	Command	Description
	ima group clock-mode	Sets the clock mode for an IMA group.
	ima link	Defines physical links for an IMA group.
	interface atm	Configures an ATM interface.
	interface atm ima	Configures an ATM IMA group.
	show ima interface atm	Provides information about all configured IMA groups or a specific IMA group.
	shutdown (interface)	Disables an interface.

ima group clock-mode

To set the clock mode for an inverse multiplexing over ATM (IMA) group, use the **ima group clock-mode** command in config controller DSL group mode. To disable the current configuration, use the **no** form of this command.

ima group clock-mode {ctc | itc}

no ima group clock-mode

Syntax Description	ctc Sets the transmit clocks for all the links in the IMA group to be derived from the same source. itc Sets the transmit clock source for at least one link in the IMA group to be different from the clock source used by the other links.
---------------------------	---

Command Defaults	ctc mode
-------------------------	----------

Command Modes	Config controller DSL group
----------------------	-----------------------------

Command History	Release	Modification
	12.4(15)T	This command was introduced for the Cisco HWIC-4SHDSL and HWIC-2SHDSL running on the Cisco 1841 router, and Cisco 2800 and 3800 series access routers.

Usage Guidelines	<p>This command controls the clock for the IMA group as a whole. If all the links in the group share a clock source, use the ctc keyword. If all the links use different clock sources, use the itc keyword.</p> <p>When the ctc keyword is set, the clock source ATM interface configuration command for the common link determines clocking for all the links in the group. When the itc keyword is set, the clock source ATM interface configuration command is used under each interface to determine clocking individually.</p> <p>Because the system automatically chooses a replacement for the common link when it fails, any link in an IMA group can potentially provide the recovered transmit clock. For this reason, even when the common keyword is set with a specific link stipulated by the port value, you should use the ATM interface configuration clock source command to make sure that the clock source is configured correctly on each interface in the IMA group.</p>
-------------------------	--

Examples	The following example uses the ima group clock-mode command to configure the clock source for an IMA group:
-----------------	--

```
Router(config-controller-dsl-group)# ima group clock-mode ?
      ctc  Common Transmit Clock configuration
      itc  Independent Transmit Clock configuration
```

■ **ima group clock-mode**

```
Router(config-controller-dsl-group)# ima group clock-mode ctc ?
```

```
<cr>
```

Related Commands

Command	Description
clock source	Configures the clock source of a DS1 link.
interface atm ima	Configures an ATM IMA group.
show ima interface atm	Provides information about all configured IMA groups or a specific IMA group.

ima link

To modify an inverse multiplexing over ATM (IMA) group link, use the **ima link** command in config controller DSL group mode.

ima link {add | delete | shutdown} number

Syntax Description

add	Adds a link to an IMA group.
delete	Deletes a link from an IMA group. The last link cannot be deleted from an IMA group.
shutdown	Shuts down a link in an IMA group.
number	Defines the IMA link number.

Command Defaults

The default value is a minimum of 1 link.

Command Modes

Config controller DSL group

Command History

Release	Modification
12.4(15)T	This command was introduced for the Cisco HWIC-4SHDSL running on the Cisco 1841 router and on the Cisco 2800 and 3800 series access routers.

Usage Guidelines

Use the **dsl-group** command with the optional keyword, **ima**, to create an IMA DSL group. Then, use the **ima link** command to define the links in the IMA group.

Examples

The following example uses the **ima link** command to modify an IMA DSL group on a Cisco HWIC-4SHDSL that is installed on a Cisco access router:

```
Router(config-controller-dsl-group)# ima link ?
add      Add a link to the IMA group
delete   Delete a link from the IMA group
shutdown Shutdown a link in the IMA group

Router(config-controller-dsl-group)# ima link add ?
<0-3>  Link pair number

Router(config-controller-dsl-group)# ima link add 2 ?
<cr>
```

■ [ima link](#)

Related Commands	Command	Description
	interface atm ima	Configures an ATM IMA group.
	show ima interface atm	Provides information about all configured IMA groups or a specific IMA group.
	shutdown (interface)	Disables an interface.

shdsl 4-wire mode

To define the single-pair high-bit-rate digital subscriber line (SHDSL) to use enhanced mode in a 2-pair digital subscriber line (DSL) group, use the **shdsl 4-wire mode** command in config controller DSL group mode. To disable **shdsl 4-wire mode**, use the **no** form of this command.

shdsl 4-wire mode enhanced

no shdsl 4-wire mode enhanced

Syntax Description	enhanced	Specifies both pairs in a <i>2-Pair</i> DSL group to operate in a symmetric 4-wire configuration.
Command Default		Standard mode is the default setting.
Command Modes		Config controller DSL group
Command History	Release	Modification
	12.4(15)T	This command was introduced for the Cisco HWIC-4SHDSL and HWIC-2SHDSL running on the Cisco 1841 router and on the Cisco 2800 and 3800 series access routers.
Usage Guidelines		Use the dsl-group command to create a <i>2-Pair</i> DSL group and enter config controller DSL group mode. Use the shdsl 4-wire mode enhanced command to define both pairs to operate in a symmetric 4-wire configuration.
Examples		The following example uses the shdsl 4-wire mode enhanced command to configure both pairs in a <i>2-Pair</i> DSL group to operate in enhanced mode on the Cisco HWIC-4SHDSL: <pre>Router (config-controller-dsl-group)# shdsl 4-wire mode ? enhanced 4-wire mode start up on both pairs Router (config-controller-dsl-group)# shdsl 4-wire mode enhanced ? <cr></pre>
Related Commands	Command	Description
	dsl-group	Creates a DSL group and enters config controller DSL group mode.
	shdsl annex	Defines the G.991.2 standard for a DSL group.
	shdsl rate	Defines the SHDSL rate.

shdsl annex

To define the single-pair high-bit-rate digital subscriber line (SHDSL) G.991.2 standard, use the **shdsl annex** command in config controller DSL group mode.

shdsl annex {standard}

Syntax Description	standard	Defines the standard for the selected type of DSL group.				
		<p>IMA Group</p> <ul style="list-style-type: none"> • A • A-B • B <p>M-PAIR Group</p> <ul style="list-style-type: none"> • A • A-B • B • F {coding 16 / 32} • F-G {coding 16 / 32} • G {coding 16 / 32} <p>1-PAIR and 2-PAIR Group</p> <ul style="list-style-type: none"> • A • A-B • B • F {coding 16 / 32} • F-G {coding 16 / 32} • G {coding 16 / 32} 				
Command Default	SHDSL annex B					
Command Modes	Config controller DSL group					
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>12.4(15)T</td> <td>This command was introduced for the Cisco HWIC-4SHDSL and HWIC-2SHDSL running on the Cisco 1841 router and on the Cisco 2800 and 3800 series access routers.</td> </tr> </tbody> </table>		Release	Modification	12.4(15)T	This command was introduced for the Cisco HWIC-4SHDSL and HWIC-2SHDSL running on the Cisco 1841 router and on the Cisco 2800 and 3800 series access routers.
Release	Modification					
12.4(15)T	This command was introduced for the Cisco HWIC-4SHDSL and HWIC-2SHDSL running on the Cisco 1841 router and on the Cisco 2800 and 3800 series access routers.					

Usage Guidelines Use the **dsl-group** command to create a DSL group, and then use the **shdsl annex** command to define the G.991.2 standard for the DSL group.

Examples The following example uses the **shdsl annex** command to define the annex standard for a 2-Pair DSL group on a Cisco HWIC-4SHDSL:

```
Router(config-controller-dsl-group)# shdsl annex ?

A Annex A of G.991.2 standard
A-B Annex A/B of G.991.2 standard
B Annex B of G.991.2 standard
F Annex F of G.991.2 standard
F-G Annex F/G of G.991.2 standard
G Annex G of G.991.2 standard

Router(config-controller-dsl-group)# shdsl annex g ?

coding 16-TCPAM or 32-TCPAM line coding

Router(config-controller-dsl-group)# shdsl annex g coding ?

16-TCPAM 16-TCPAM line coding
32-TCPAM 32-TCPAM line coding

Router(config-controller-dsl-group)# shdsl annex g coding 16 ?

<cr>
```

Related Commands	Command	Description
	dsl-group	Creates a DSL group and enters config controller DSL group mode.
	shdsl rate	Defines the SHDSL rate.

shdsl rate

To define the single-pair high-bit-rate digital subscriber line (SHDSL) rate, use the **shdsl rate** command in config-controller-dsl-group mode.

shdsl rate {number | auto}

Syntax Description	<i>number</i>	Defines the SHDSL rate for the digital subscriber line (DSL) group.
--------------------	---------------	---

DSL Group with 1 Pair

Annex A & B—192-2304 kbps

Annex F & G (32 TC-PAM)—768-5696 kbps

Annex F & G (16 TC-PAM)—2304-3840 kbps

DSL Group with 2 Pairs

Annex A & B—384-4608 kbps

Annex F & G (32 TC-PAM)—1536-11392 kbps

Annex F & G (16 TC-PAM)— 4608-7680 kbps

DSL Group with 3 Pairs

Annex A & B—576-6912 kbps

Annex F & G (32 TC-PAM)—2304-12288 kbps

Annex F & G (16 TC-PAM)— 6912-11520 kbps

DSL Group with 4 Pairs

Annex A & B—768-9216 kbps

Annex F & G (32 TC-PAM)—3072-16384 kbps

Annex F & G (16 TC-PAM)— 9216-15360 kbps

auto	Sets this SHDSL rate to automatic mode.
-------------	---

Command Default	The command default is the maximum annex rate for the selected DSL group.
-----------------	---

Command Modes	Config controller DSL group
---------------	-----------------------------

Command History	Release	Modification
	12.4(15)T	This command was introduced for the Cisco HWIC-4SHDSL and HWIC-2SHDSL running on the Cisco 1841 router and on the Cisco 2800 and 3800 series access routers.

Usage Guidelines

Use the **dsl-group** command to create a DSL group, and then use the **shdsl annex** command to define the G.991.2 standard for the newly created DSL group. Define the SHDSL line rate with the **shdsl rate** command.

Examples

The following example defines the SHDSL line rate for DSL group 1, pairs 0-1 (2 pairs) on a Cisco HWIC-4SHDSL:

```
Router(config-controller)# dsl-group 1 pairs 0-1 ima

Router(config-controller-dsl-group)#
Sep 22 14:53:46.481: %HWIC_SHDSL-5-DSLGROUP_UPDOWN: SHDSL 0/2/0 dsl-group(1) state changed to down.
Sep 22 14:53:48.481: %LINK-3-UPDOWN: Interface ATM0/2/IMA1, changed state to down
Sep 22 14:53:49.481: %LINEPROTO-5-UPDOWN: Line protocol on Interface ATM0/2/IMA1, changed state to down

Router(config-controller-dsl-group)# shdsl annex ?

A      Annex A of G.991.2 standard
A-B    Annex A/B of G.991.2 standard
B      Annex B of G.991.2 standard

Router(config-controller-dsl-group)# shdsl annex b ?

<cr>
Router(config-controller-dsl-group)# shdsl rate auto

<384-4608>  DSL Rate in kbps(line will train at the rate + 16kbps overhead)
auto          auto rate mode
```

Related Commands

Command	Description
dsl-group	Creates a DSL group and enters config controller DSL group mode.
shdsl annex	Defines the G.991.2 standard for a DSL group.

 show controllers shdsl

show controllers shdsl

To display the status of the controller configured for single-pair high-bit-rate digital subscriber line (SHDSL) mode, use the **show controllers shdsl** command in privileged EXEC mode.

Cisco HWIC-4SHDSL and HWIC-2SHDSL

```
show controllers shdsl slot number/subslot number/port number {brief | detailed}
```

Cisco IAD2420

```
show controller shdsl number
```

Syntax Description	brief Provides a summary of the controller's status. detailed Provides a detailed report of the controller's status. number SHDSL controller number. The valid controller number for SHDSL mode is 0. slot number Identifies the slot on the router in which the HWIC is installed. subslot number Identifies the subslot on the router in which the HWIC is installed. port number Identifies the port on the router in which the HWIC is installed. By default, the Cisco HWIC-4SHDSL and HWIC-2SHDSL use port number 0.
---------------------------	---

Command Defaults Controller number

Command Modes Privileged EXEC

Command History	Release	Modification
	12.4(15)T	This command was updated for the Cisco HWIC-4SHDSL and HWIC-2SHDSL running on the Cisco 1841 router and on the Cisco 2800 and 3800 series access routers.
	12.2(8)T	This command was introduced on Cisco IAD2420 series.

Usage Guidelines This command is used to display the controller mode, the controller number, and associated statistics.

Examples **Cisco HWIC-4SHDSL and HWIC-2SHDSL**

The following example displays the status of a Cisco HWIC-4SHDSL controller in slot 0, subslot 2, port 0 on a Cisco access router:

```
Router# show controllers shdsl 0/2/0 brief
Controller SHDSL 0/2/0 is UP
  Hardware is HWIC-4SHDSL, rev 2 on slot 0, hwic slot 2
```

```

Capabilities: IMA, M-pair, 2/4 wire, Annex A, B, F & G, CPE termination
cdb=0x43EB384C, plugin=0x43DE9410, ds=0x43E9A1C4 base=0xB8000000
FPGA Version is REL.3.4.0, NIOSII FW:Ver 2.6, status Running
SDC16i HW:Rev 1.2, status UP, FW:Ver 1.2-1.1.3_57, status Running
SDFE4 HW:Rev 1.2, status UP, FW:Ver 1.1-1.5.2_001 , status Running
NIOSII Firmware image: System
SDC16i Firmware image: System
SDFE4 Firmware image: System
Number of pairs 4, number of groups configured 1
Ignored CLI cmd(0), Event buffer: in use(0), failed(0)
Group (0) is Not configured.
Group (1) info:
    Type: M-pair over g.shdsl, status: Configure Firmware
    Interface: ATM0/2/1, hwidb: 0x43F04EA0, UTOPIA phy 1
    Configured/active num links: 2/0, bit map: 0x3/0x0
    Line termination: CPE, line mode: M-pair, Annex-B, PMMS disabled
    Line coding: 16-TCPAM, configured/actual rate: 4608/0 kbps
    SHDSL wire-pair (0) is in DSL DOWN state
    SHDSL wire-pair (1) is in DSL config state
Router#

```

Cisco IAD2420 Series

The following example displays the status of the controller that is configured for SHDSL mode on a Cisco IAD2420 series IAD:

```
Router# show controller shdsl 0
```

```

SHDSL 0 controller UP
SLOT 3: Globespan xDSL controller chipset
Frame mode: Serial ATM
Configured Line rate: 1160Kbps
Line Re-activated 0 times after system bootup
LOSW Defect alarm: None
CRC per second alarm: None
Line termination: CPE
FPGA Revision: 9

```

Related Commands

Command	Description
controller shdsl 0	Configures the controller status and the controller number.

Additional References

The following references provide links to related topics, such as the Cisco IOS software resource center, interface card documentation, and additional hardware documentation.

Related Documents

Related Topic	Document Title
Cisco IOS software	<i>Cisco IOS Software</i> http://www.cisco.com/en/US/products/sw/iosswrel/tsd_products_support_category_home.html
Interface Cards	<i>Cisco Interface Cards Hardware Installation Guide</i> http://www.cisco.com/en/US/products/hw/modules/ps2641/products_module_installation_guide_book09186a0080692b21.html <i>Cisco Network Modules and Interface Cards Regulatory Compliance and Safety Information</i> http://www.cisco.com/en/US/products/hw/modules/ps2797/products_regulatory_approvals_and_compliance09186a0080183b96.html
Technical documentation, including feedback and assistance	<i>What's New in Cisco Product Documentation</i> (including monthly listings of new and revised documents) at http://www.cisco.com/univercd/cc/td/doc/abtuniced/136957.htm

Standards

Standard	Title
• ITU G.991.2	<ul style="list-style-type: none"> – Annex A – Annex B – Annex F – Annex G
• af-phy-0086.001	<ul style="list-style-type: none"> – Inverse Multiplexing over ATM version 1.1

■ Additional References

MIBs

MIB	MIBs Link
<ul style="list-style-type: none"> • Entity MIB • Chassis MIB • Interface MIB • AToM MIB • ILMI MIB • IMA MIB • HDSL2-SHDSL-LINE MIB 	<p>To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL:</p> <p>http://www.cisco.com/go/mibs</p>

RFCs

RFC	Title
<ul style="list-style-type: none"> • G.SHDSL— RFC# 3276 	<ul style="list-style-type: none"> • HDSL2-SHDSL-LINE MIB

Technical Assistance

Description	Link
<p>The Cisco Technical Support & Documentation website contains thousands of pages of searchable technical content, including links to products, technologies, solutions, technical tips, and tools. Registered Cisco.com users can log in from this page to access even more content.</p>	<p>http://www.cisco.com/techsupport</p>

CCVP, the Cisco Logo, and the Cisco Square Bridge logo are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn is a service mark of Cisco Systems, Inc.; and Access Registrar, Aironet, BPX, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Fast Step, Follow Me Browsing, FormShare, GigaDrive, GigaStack, HomeLink, Internet Quotient, IOS, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, iQuick Study, LightStream, Linksys, MeetingPlace, MGX, Networking Academy, Network Registrar, *Packet*, PIX, ProConnect, RateMUX, ScriptShare, SlideCast, SMARTnet, StackWise, The Fastest Way to Increase Your Internet Quotient, and TransPath are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0609R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

© 2006 Cisco Systems, Inc. All rights reserved.