



Cisco H.323 Signaling Interface User Guide

Cisco HSI Release 2.21
February 2004

Corporate Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 526-4100

Customer Order Number:
Text Part Number: OL-2156-04 Rev A1



THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

CCIP, the Cisco Arrow logo, the Cisco *Powered* Network mark, the Cisco Systems Verified logo, Cisco Unity, Follow Me Browsing, FormShare, iQ Breakthrough, iQ Expertise, iQ FastTrack, the iQ Logo, iQ Net Readiness Scorecard, Networking Academy, ScriptShare, SMARTnet, TransPath, and Voice LAN are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn, Discover All That's Possible, The Fastest Way to Increase Your Internet Quotient, and iQuick Study are service marks of Cisco Systems, Inc.; and Aironet, ASIST, BPX, Catalyst, CCDA, CCDP, CCIE, CCNA, CCNP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, the Cisco IOS logo, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Empowering the Internet Generation, Enterprise/Solver, EtherChannel, EtherSwitch, Fast Step, GigaStack, Internet Quotient, IOS, IP/TV, LightStream, MGX, MICA, the Networkers logo, Network Registrar, *Packet*, PIX, Post-Routing, Pre-Routing, RateMUX, Registrar, SlideCast, StrataView Plus, Stratm, SwitchProbe, TeleRouter, and VCO are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and certain other countries.

All other trademarks mentioned in this document or Web site are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0208R)

Cisco H.323 Signaling Interface User Guide
Copyright © 2004, Cisco Systems, Inc.
All rights reserved.



Preface xi

Document Objectives	xi
Audience	xi
System Administrator	xi
System Operator	xii
System Technician	xii
Document Organization	xii
Document Conventions	xiii
Related Documentation	xiv
Release Notes	xiv
Hardware Documentation	xiv
Software Documentation	xv
Related Documentation	xv
Obtaining Documentation	xv
World Wide Web	xv
Documentation CD-ROM	xv
Ordering Documentation	xvi
Documentation Feedback	xvi
Obtaining Technical Assistance	xvi
Cisco.com	xvi
Technical Assistance Center	xvii
Cisco TAC Web Site	xvii
Cisco TAC Escalation Center	xviii

CHAPTER 1

Cisco H.323 Signaling Interface Overview 1-1

Introduction	1-1
Cisco HSI Overview	1-1
PGW 2200	1-2
IP Network	1-2
Cisco HSI System Description	1-2
OAM Subsystem	1-3
Call Control Subsystem	1-3
RUDP	1-4
RADVision H.323	1-4

- E-ISUP 1-4
- New Features Introduced in HSI Release 2.21 1-4
 - Asymmetric Codec Treatment 1-4
 - Empty Capability Set 1-4
 - H.323 Hairpin 1-4
 - T38 Fax 1-5
- Operational Environment 1-5
 - Hardware Requirements 1-5
 - Software Requirements 1-5
 - Security 1-5
- Cisco HSI Recovery 1-5
- Cisco HSI System Limitations 1-5

CHAPTER 2

Installing and Configuring Cisco HSI Software 2-1

- Introduction 2-1
- Hardware and Software Requirements 2-1
- Installing the Sun Solaris 8 Operating System 2-1
- Installing the Cisco HSI 2-2
 - Before You Start 2-2
 - Configuring Groups and Users 2-2
 - Cisco HSI Installation Information 2-3
 - Installing the Cisco HSI 2-5
 - Installing a Dual Cisco HSI for a Redundant PGW 2200 Configuration 2-9
- Starting the Cisco HSI 2-10
- Stopping the Cisco HSI 2-10
- Configuring the Cisco HSI 2-10
- Upgrading the Cisco HSI 2-10
- Removing the Cisco HSI 2-11

CHAPTER 3

Provisioning the Cisco HSI 3-1

- Introduction 3-1
- Cisco HSI Configuration 3-1
 - MML Configuration Commands 3-2
 - System Configuration Data 3-3
 - Static System Data 3-3
 - Dynamic System Data 3-5
- H.323 Stack Configuration 3-8
 - Nonprovisionable Data 3-8

MML Provisionable Data	3-9
H.323 System Parameters	3-9
Q.931 Parameters	3-9
RAS Parameters	3-10
H.245 Parameters	3-13
Configuring HSI Release 2.21 Features	3-16
Asymmetric Codec Treatment	3-16
Empty Capability Set	3-16
H.323 Hairpin	3-16
T.38 Fax	3-17
Configuring T.38 Fax on the Cisco PSTN Gateway	3-17
Configuring T.38 Fax on a Cisco IOS H.323 Gateway	3-17
Configuring T.38 Fax on a Cisco IOS MGCP Gateway	3-17

CHAPTER 4**Managing the Cisco HSI 4-1**

Introduction	4-1
Restarting the Cisco HSI Application	4-1
Stopping Call Processing	4-1
Starting Call Processing	4-2
Stopping the Call Processing Application	4-2
Starting the Call Processing Application	4-2
Reporting the Cisco HSI Status	4-2
Measurements	4-2
System-Related Measurements	4-2
Call-Related Measurements	4-3
Resetting Measurements	4-6
Retrieving Counters	4-6
Overload	4-6
Overload Level 1	4-7
Overload Level 2	4-7
Overload Level 3	4-7
Setting Overload Data	4-7
Retrieving Overload Data	4-8
Logging	4-8
Rotating Log Files	4-8
Convention for Naming Convention the Log File	4-9
Log File Location	4-9
Log Messages	4-9

- Log Message Packages 4-10
- Logging Levels 4-10
 - Setting Logging Levels 4-10
- RADVision Logging 4-11
- Gapping 4-11
 - Setting Gapping 4-11
 - Retrieving Call Gapping Data 4-12

CHAPTER 5

Troubleshooting Cisco HSI Alarms 5-1

- Introduction 5-1
- Alarms Overview 5-1
 - Debounce 5-1
 - Alarm Severity Levels 5-1
 - Retrieving and Reporting Alarms 5-2
 - Informational Event Requirements 5-2
 - SNMP Trap Types 5-2
- Retrieving Alarm Messages 5-3
 - Noncontinuous Mode 5-3
 - Continuous Mode 5-3
- Acknowledging and Clearing Alarms 5-4
- Alarms List 5-5
- Troubleshooting 5-6
 - H323_STACK_FAILURE 5-6
 - Description 5-6
 - Severity Level and Trap Type 5-6
 - Cause 5-6
 - Troubleshooting 5-6
 - CONFIGURATION_FAILURE 5-6
 - Description 5-6
 - Severity Level and Trap Type 5-6
 - Cause 5-7
 - Troubleshooting 5-7
 - EISUP_PATH_FAILURE 5-7
 - Description 5-7
 - Severity Level and Trap Type 5-7
 - Cause 5-7
 - Troubleshooting 5-7
 - GATEKEEPER_INTERFACE_FAILURE 5-8
 - GENERAL_PROCESS_FAILURE 5-8

Description	5-8
Severity Level and Trap Type	5-8
Cause	5-8
Troubleshooting	5-8
IP_LINK_FAILURE	5-8
Description	5-8
Severity Level and Trap Type	5-8
Cause	5-8
Troubleshooting	5-9
LOW_DISK_SPACE	5-9
Description	5-9
Severity Level and Trap Type	5-9
Cause	5-9
Troubleshooting	5-9
OVERLOAD_LEVEL3	5-9
Description	5-9
Severity Level and Trap Type	5-9
Cause	5-10
Troubleshooting	5-10
VSC_FAILURE	5-10
Description	5-10
Severity Level and Trap Type	5-10
Cause	5-10
Troubleshooting	5-10
OVERLOAD_LEVEL2	5-11
Description	5-11
Severity Level and Trap Type	5-11
Cause	5-11
Troubleshooting	5-11
CONFIG_CHANGE	5-11
Description	5-11
Severity Level and Trap Type	5-11
Cause	5-11
Troubleshooting	5-11
ENDPOINT_CALL_CONTROL_INTERFACE_FAILURE	5-12
Description	5-12
Severity Level and Trap Type	5-12
Cause	5-12
Troubleshooting	5-12
ENDPOINT_CHANNEL_INTERFACE_FAILURE	5-12

Description	5-12
Severity Level and Trap Type	5-12
Cause	5-12
Troubleshooting	5-12
GAPPED_CALL_NORMAL	5-13
Description	5-13
Severity Level and Trap Type	5-13
Cause	5-13
Troubleshooting	5-13
GAPPED_CALL_PRIORITY	5-13
Description	5-13
Severity Level and Trap Type	5-13
Cause	5-13
Troubleshooting	5-14
OVERLOAD_LEVEL1	5-14
Description	5-14
Severity Level and Trap Type	5-14
Cause	5-14
Troubleshooting	5-14
PROVISIONING_INACTIVITY_TIMEOUT	5-14
Description	5-14
Severity Level and Trap Type	5-14
Cause	5-15
Troubleshooting	5-15
PROVISIONING_SESSION_TIMEOUT	5-15
Description	5-15
Severity Level and Trap Type	5-15
Cause	5-15
Troubleshooting	5-15
STOP_CALL_PROCESSING	5-15
Description	5-15
Severity Level and Trap Type	5-15
Cause	5-15
Troubleshooting	5-16
Detailed Logging	5-16

APPENDIX A MML User Interface and Command Reference A-1

Introduction	A-1
Starting an MML Command Session in the Cisco HSI	A-1

MML Commands	A-2
MML Command Syntax	A-2
MML Command Conventions	A-2
Case Sensitivity	A-3
Starting an MML Session	A-3
Batch Files	A-3
Creating a Batch File	A-4
Starting a Batch File	A-4
MML Responses	A-5
Status Messages	A-5
Error Messages	A-5
MML Help	A-6
Quitting an MML Session	A-6
MML Command Reference	A-6
ack-alm	A-8
clr-alm	A-8
clr-meas	A-9
diaglog	A-10
h	A-10
help	A-11
prov-add	A-12
prov-cpy	A-13
prov-dlt	A-14
prov-ed	A-15
prov-exp	A-16
prov-rtrv	A-17
prov-sta	A-19
prov-stp	A-20
quit	A-21
radlog	A-22
restart-softw	A-23
rtrv-alms	A-24
rtrv-calls	A-24
rtrv-ctr	A-25
rtrv-dest	A-25
rtrv-gapping	A-26

rtrv-log **A-27**
 rtrv-mml **A-28**
 rtrv-ne **A-28**
 rtrv-ne-health **A-29**
 rtrv-overload **A-29**
 rtrv-softw **A-30**
 set-dest-state **A-31**
 set-gapping **A-32**
 set-log **A-32**
 set-overload **A-33**
 sta-callproc **A-34**
 sta-softw **A-35**
 sta-trc **A-35**
 stp-call **A-37**
 stp-callproc **A-37**
 stp-softw **A-38**
 stp-trc **A-38**

APPENDIX B **Skeleton Configuration File** **B-1**

APPENDIX C **Example of an HSI Configuration File** **C-1**

APPENDIX D **E-ISUP Name-to-Cause Value Lookup** **D-1**

APPENDIX E **E-ISUP Cause Value-to-Name Lookup** **E-1**

APPENDIX F **H.323 Name-to-Cause Value Lookup** **F-1**

APPENDIX G **H.323 Cause Value-to-Name Lookup** **G-1**

INDEX



Preface

This preface describes the objectives, audience, organization, and conventions of the *Cisco H.323 Signaling Interface User Guide*, and explains how to find additional information on related products and services. It contains the following sections:

- Document Objectives, page xi
- Audience, page xi
- Document Organization, page xii
- Document Conventions, page xiii
- Related Documentation, page xiv
- Obtaining Documentation, page xv
- Obtaining Technical Assistance, page xvi

Document Objectives

This guide contains installation, configuration, system management, troubleshooting, and Man-Machine Language (MML) command information for the Cisco H.323 Signaling Interface (HSI).

This version of the *Cisco H.323 Signaling Interface User Guide* documents the Cisco H.323 Signaling Interface (HSI) software, Release 2.21. Cisco HSI, Release 2.21 is associated with the Cisco Media Gateway Controller Software, Release 9.3(2).

Audience

The intended audience is the system administrator, the system operator, and the system technician.

System Administrator

The system administrator is required to manage the host administrative functions, including:

- Configuring and maintaining system parameters
- Granting group and user IDs
- Managing all Cisco Public Switched Telephone Network (PSTN) Gateway (PGW 2200) files and directories

The system administrator should have an in-depth knowledge of UNIX and a basic knowledge of data and telecommunications networking.

System Operator

The system operator is assumed to have knowledge of the following:

- Telecommunications protocols
- Basic computer software operations
- Computer terminology and concepts
- Hierarchical file systems
- Common UNIX shell commands

System Technician

The system technician is assumed to have knowledge of the following:

- Telecommunications protocols
- Basic computer software operations
- Computer terminology and concepts
- Hierarchical file systems
- Common UNIX shell commands
- Log files
- Configuration of telephony switching systems
- Use of electrical and electronic telephony test equipment
- Basic troubleshooting techniques

Document Organization

This document is organized as follows:

- Preface
- Chapter 1, “Cisco H.323 Signaling Interface Overview.”
- Chapter 2, “Installing and Configuring Cisco HSI Software”
- Chapter 3, “Provisioning the Cisco HSI”
- Chapter 4, “Managing the Cisco HSI”
- Chapter 5, “Troubleshooting Cisco HSI Alarms”
- Appendix A, “MML User Interface and Command Reference”
- Appendix B, “Skeleton Configuration File”
- Appendix C, “Example HSI Configuration File”
- Appendix D, “E-ISUP Name-to-Cause Value Lookup”

- Appendix E, “E-ISUP Cause Value-to-Name Lookup”
- Appendix F, “H.323 Name-to-Cause Value Lookup”
- Appendix G, “H.323 Cause Value-to-Name Lookup”

Document Conventions

This manual uses the document conventions listed in this section.

Table 1 Document Conventions

Convention	Meaning	Comments and Examples
Boldface	Commands and keywords you enter literally as shown	prov-sta
<i>Italics</i>	Variables for which you supply values	command <i>interface type</i> You replace the variable with the type of interface.
Courier	Font used for screen displays, prompts, and scripts.	Are you ready to continue? [Y]
Courier bold	Font used to indicate what the user enters in examples of command environments.	Login: root Password: <password>
Square brackets ([])	Optional elements	command [abc] abc is optional (not required), but you can choose it.
Vertical bars ()	Separated alternative elements	command [abc def] You can choose either abc or def, or neither, but not both.
Braces ({ })	Required choices	command {abc def} You must use either abc or def, but not both.
Braces with vertical bars within square brackets ([{ }])	A required choice within an optional element	command [abc{ def ghi}] You have three options: <ul style="list-style-type: none"> • No entry • abc def • abc ghi
A string	A nonquoted set of characters	For example, when setting an SNMP community string to public, do not use quotation marks around the string; otherwise, the string will include the quotation marks.

Table 1 Document Conventions (continued)

Convention	Meaning	Comments and Examples
System prompt	Denotes interactive sessions; indicates that the user enters commands at the prompt	The system prompt indicates the current command mode. For example, the prompt <code>Router (config)#</code> indicates global configuration mode.
Exclamation point (!) at the beginning of a line	A comment line	Comments are sometimes displayed.

**Note**

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.

**Tip**

Means *the following information will help you solve a problem*. The tip information might not be troubleshooting or even an action, but could be useful information, similar to a Timesaver.

**Caution**

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

Related Documentation

The following sections provide the titles of documents related to the *Cisco H.323 Signaling Interface User Guide*.

Release Notes

For information regarding subsequent releases of the Cisco H.323 signaling interface, refer to:

- *Release Notes for Cisco H.323 Signaling Interface, Release 2.21.*

Hardware Documentation

- *Cisco Media Gateway Controller Hardware Installation Guide*
- *Regulatory Compliance and Safety Information for Cisco Media Gateway Controller*
- *Cisco Media Gateway Hardware Installation Guide*

Software Documentation

- *Cisco Media Gateway Controller Software Release 9 Installation and Configuration Guide*
- *Cisco Media Gateway Controller Software Release 9 Provisioning Guide*
- *Cisco Media Gateway Controller Software Release 9 MML Command Reference Guide*
- *Cisco Media Gateway Controller Software Release 9 Messages Reference Guide*
- *Cisco Media Gateway Controller Software Release 9 Billing Interface Guide*
- *Cisco Media Gateway Controller Software Release 9 Operations, Maintenance, and Troubleshooting Guide*
- *Cisco Media Gateway Controller Software Release 9 Management Information Base Guide*
- *Cisco Media Gateway Controller Node Manager User's Guide 2.0*
- *Cisco Signaling Link Terminal*
- *Cisco Media Gateway Controller Online Documentation Notice*
- *Cisco Media Gateway Controller SLT Documentation Notice*

Related Documentation

- *ITU Recommendation H.323, 1999*
- *ITU Recommendation H.225, 1998*
- *ITU Recommendation H.245, 1998*
- *ITU Recommendation H.246 Annex C*

Obtaining Documentation

These sections explain how to obtain documentation from Cisco Systems.

World Wide Web

You can access the most current Cisco documentation on the World Wide Web at this URL:

<http://www.cisco.com>

Translated documentation is available at this URL:

http://www.cisco.com/public/countries_languages.shtml

Documentation CD-ROM

Cisco documentation and additional literature are available in a Cisco Documentation CD-ROM package, which is shipped with your product. The Documentation CD-ROM is updated monthly and may be more current than printed documentation. The CD-ROM package is available as a single unit or through an annual subscription.

Ordering Documentation

You can order Cisco documentation in these ways:

- Registered Cisco.com users (Cisco direct customers) can order Cisco product documentation from the Networking Products MarketPlace:
http://www.cisco.com/cgi-bin/order/order_root.pl
- Registered Cisco.com users can order the Documentation CD-ROM through the online Subscription Store:
<http://www.cisco.com/go/subscription>
- Nonregistered Cisco.com users can order documentation through a local account representative by calling Cisco Systems Corporate Headquarters (California, U.S.A.) at 408 526-7208 or, elsewhere in North America, by calling 800 553-NETS (6387).

Documentation Feedback

You can submit comments electronically on Cisco.com. In the Cisco Documentation home page, click the **Fax** or **Email** option in the “Leave Feedback” section at the bottom of the page.

You can e-mail your comments to bug-doc@cisco.com.

You can submit your comments by mail by using the response card behind the front cover of your document or by writing to the following address:

Cisco Systems
Attn: Document Resource Connection
170 West Tasman Drive
San Jose, CA 95134-9883

We appreciate your comments.

Obtaining Technical Assistance

Cisco provides Cisco.com as a starting point for all technical assistance. Customers and partners can obtain online documentation, troubleshooting tips, and sample configurations from online tools by using the Cisco Technical Assistance Center (TAC) Web Site. Cisco.com registered users have complete access to the technical support resources on the Cisco TAC Web Site.

Cisco.com

Cisco.com is the foundation of a suite of interactive, networked services that provides immediate, open access to Cisco information, networking solutions, services, programs, and resources at any time, from anywhere in the world.

Cisco.com is a highly integrated Internet application and a powerful, easy-to-use tool that provides a broad range of features and services to help you with these tasks:

- Streamline business processes and improve productivity
- Resolve technical issues with online support
- Download and test software packages

- Order Cisco learning materials and merchandise
- Register for online skill assessment, training, and certification programs

If you want to obtain customized information and service, you can self-register on Cisco.com. To access Cisco.com, go to this URL:

<http://www.cisco.com>

Technical Assistance Center

The Cisco Technical Assistance Center (TAC) is available to all customers who need technical assistance with a Cisco product, technology, or solution. Two levels of support are available: the Cisco TAC Web Site and the Cisco TAC Escalation Center.

Cisco TAC inquiries are categorized according to the urgency of the issue:

- Priority level 4 (P4)—You need information or assistance concerning Cisco product capabilities, product installation, or basic product configuration.
- Priority level 3 (P3)—Your network performance is degraded. Network functionality is noticeably impaired, but most business operations continue.
- Priority level 2 (P2)—Your production network is severely degraded, affecting significant aspects of business operations. No workaround is available.
- Priority level 1 (P1)—Your production network is down, and a critical impact to business operations will occur if service is not restored quickly. No workaround is available.

The Cisco TAC resource that you choose is based on the priority of the problem and the conditions of service contracts, when applicable.

Cisco TAC Web Site

You can use the Cisco TAC Web Site to resolve P3 and P4 issues yourself, saving both cost and time. The site provides around-the-clock access to online tools, knowledge bases, and software. To access the Cisco TAC Web Site, go to this URL:

<http://www.cisco.com/tac>

All customers, partners, and resellers who have a valid Cisco service contract have complete access to the technical support resources on the Cisco TAC Web Site. The Cisco TAC Web Site requires a Cisco.com login ID and password. If you have a valid service contract but do not have a login ID or password, go to this URL to register:

<http://www.cisco.com/register/>

If you are a Cisco.com registered user, and you cannot resolve your technical issues by using the Cisco TAC Web Site, you can open a case online by using the TAC Case Open tool at this URL:

<http://www.cisco.com/tac/caseopen>

If you have Internet access, we recommend that you open P3 and P4 cases through the Cisco TAC Web Site.

Cisco TAC Escalation Center

The Cisco TAC Escalation Center addresses priority level 1 or priority level 2 issues. These classifications are assigned when severe network degradation significantly impacts business operations. When you contact the TAC Escalation Center with a P1 or P2 problem, a Cisco TAC engineer automatically opens a case.

To obtain a directory of toll-free Cisco TAC telephone numbers for your country, go to this URL:

<http://www.cisco.com/warp/public/687/Directory/DirTAC.shtml>

Before calling, please check with your network operations center to determine the level of Cisco support services to which your company is entitled: for example, SMARTnet, SMARTnet Onsite, or Network Supported Accounts (NSA). When you call the center, please have available your service agreement number and your product serial number.



Cisco H.323 Signaling Interface Overview

Introduction

This chapter provides an overview of the Cisco H.323 Signaling Interface (HSI) system and subsystems and contains the following sections:

- Cisco HSI Overview, page 1-1
- Cisco HSI System Description, page 1-2
- Operational Environment, page 1-5
- Cisco HSI Recovery, page 1-5
- Cisco HSI System Limitations, page 1-5

Cisco HSI Overview


The Cisco HSI adds an H.323 interface to the Cisco Public Switched Telephone Network (PSTN) Gateway (PGW 2200). This interface allows calls to be established between the PSTN and an H.323 network (see Figure 1-1).

The Cisco HSI provides the following services:

- Translation of signaling protocols for establishing, controlling, and releasing calls
- Administration of network parameters and protocol capabilities
- System and call-related statistics
- Fault reporting
- Overload management
- Event logging
- Simple Network Management Protocol (SNMP) interface

The Cisco HSI does not operate in an active/standby configuration and, therefore, does not provide the same level of redundancy as the PGW 2200, which is configured as active/standby. We therefore recommend that you use enough HSI nodes to support the number of simultaneous calls plus one. This ensures (Trunk Group Caveats dependant) that, if one HSI fails, the calls are still adequately supported by the remaining active HSI's.

Figure 1-1 Cisco HSI System Overview



PGW 2200

The PGW 2200 consists of the hardware and software that perform the signaling and call control tasks (such as digit analysis, routing, and circuit selection) and seamlessly switch calls from the PSTN through to the IP network.

IP Network


The purpose of the Cisco HSI is to enable the PGW 2200 to interoperate with the H.323 network.

Cisco HSI System Description

The Cisco HSI system has two subsystems (see Figure 1-2):

- Operations, Administration, and Maintenance (OAM) subsystem
- Call control subsystem

Figure 1-2 Cisco HSI Subsystems



OAM Subsystem

The OAM subsystem provides the following services:

- Man-Machine Language (MML) interface that enables you to retrieve operational parameters and modify configuration values through direct input or through batch files
- SNMP interface that allows statistics and alarm retrieval
- Management to provide automatic restart of the Cisco HSI application and control over the running of the process
- Statistics, events, call trace, and alarm output to files
- Alarm events output to the MML interface
- Overload control

Call Control Subsystem

The call control subsystem provides the following services:

- Manages the Reliable User Data Protocol (RUDP) and H.323 stacks
- Implements Enhanced ISDN User Part (E-ISUP)
- Manages H.323 call control
- Performs the conversion of calls between H.323 and E-ISUP call control messages
- Provides call management and overload reduction actions

RUDP

RUDP transports the E-ISUP messages between the PGW 2200 and the Cisco HSI.

RUDP is a Cisco proprietary, connection-oriented, packet-based transport protocol.

RADVision H.323

The Cisco HSI uses the RADVision H.323 stack. The system uses the H.225 (Q.931 and registration, admission, and status [RAS] protocol) and H.245 protocols to implement the H.323 endpoint signaling function.

RADVision H.323 enables the creation of real-time voice H.323 calls over IP networks.

E-ISUP

E-ISUP is a proprietary Cisco protocol based on ISUP. E-ISUP is used for inter-PGW 2200 call control. E-ISUP uses a subset of ISUP messages. The main differences between ISUP and E-ISUP are as follows:

- E-ISUP is for the control of packet voice connection. It does not have circuit management messages such as circuit reset and blocking.
- E-ISUP is transported over RUDP in an IP network.
- E-ISUP enables PGW 2200s to transport Session Description Protocol (SDP) information (such as endpoint IP address and codec specifications) for call endpoints.

The Cisco HSI provides a conversion between the E-ISUP call control protocol originating from the PGW 2200 and the H.323 call control protocol originating from the IP network (see Figure 1-1).

New Features Introduced in HSI Release 2.21

The following four features are introduced in Cisci HSI, Release 2.21.

Asymmetric Codec Treatment

The Asymmetric Codec Treatment feature averts the potential for inconsistencies in codec selection, which might otherwise result when endpoints attempt to use different codecs for the transmission path.

Empty Capability Set

Empty Capability Set support enables the HSI to close opened logical channels, without releasing the call. Subsequently, the HSI can open a new logical channel, potentially to a different endpoint, or use a different codec.

H.323 Hairpin

The H.323 Hairpin feature can be used to connect a call between two H.323 endpoints without using resources on the media gateway. For example, the PGW can respond to the dialled number in an incoming H.323 call by routing the call to another HSI (perhaps the same HSI) rather than routing the

call to the PSTN. In this case, the originating and terminating HSI s establish the call normally but pass the H.245 address of the H.323 endpoints. This enables the two endpoints to use H.245 to negotiate media channels with each other directly, independent of the HSI.

T38 Fax

The T.38 Fax feature enables the HSI to alter a call, initially established for voice, to support a fax transmission.

When a fax call is initiated, a voice call is established. When the terminating gateway detects the fax tone generated by the terminating fax machine, the gateway initiates a T.38 mode request using H.245 procedures from the terminating gateway. If the opposite end of the call acknowledges the T.38 mode request, the initial audio channel is closed and a T.38 fax relay channel is opened.

Operational Environment

This section provides operational environment requirements for the Cisco HSI.

Hardware Requirements

The Cisco HSI is targeted to run on a Sun Netra T1 100/105 platform with an 18-GB hard disk drive, a Sun Netra 120 platform with a 36-GB hard disk drive, or a Sun Fire V120 platform with a 36-GB hard disk drive. These platforms run on the Sun Solaris 8 operating system.

Software Requirements

The Sun Netra T1 100/105 platform, Sun Netra 120 platform, and Sun Fire V120 platform run on the Solaris 8 operating system.

Security

The application does not directly provide security features. All security must be implemented at the UNIX level.

Cisco HSI Recovery

The Cisco HSI automatically restarts the main application process if that process terminates.

Cisco HSI System Limitations

The Cisco HSI does not implement security features.



Installing and Configuring Cisco HSI Software

Introduction

This chapter contains instructions for the system administrator on how to install and configure the Cisco H.323 Signaling Interface (HSI). This chapter contains the following sections:

- Hardware and Software Requirements, page 2-1
- Installing the Sun Solaris 8 Operating System, page 2-1
- Installing the Cisco HSI, page 2-2
- Starting the Cisco HSI, page 2-10
- Stopping the Cisco HSI, page 2-10
- Configuring the Cisco HSI, page 2-10
- Upgrading the Cisco HSI, page 2-10
- Removing the Cisco HSI, page 2-11

Hardware and Software Requirements

The Cisco HSI is targeted to run on a Sun Netra T1 100/105 platform with an 18-GB hard disk drive, a Sun Netra 120 platform with a 36-GB hard disk drive, or a Sun Fire V120 platform with a 36-GB hard disk drive. These platforms run on the Sun Solaris 8 operating system.

Installing the Sun Solaris 8 Operating System

The Sun Solaris 8 operating system must be installed before you install the Cisco HSI. Instructions for installing Solaris 8 on the Sun Netra T1 100/105, Sun Netra 120, and Sun Fire V120 are in the *Cisco Media Gateway Controller Software Release 9 Installation and Configuration Guide*, located at the following URL:

<http://www.cisco.com/univercd/cc/td/doc/product/access/sc/re19/swinstll/index.htm>

After completing the Solaris 8 operating system installation, return to this document for Cisco HSI installation procedures.

Installing the Cisco HSI

This section provides step-by-step instructions for installing the Cisco HSI.

Before You Start

Complete the preinstallation tasks listed in Table 2-1 before installing the Cisco HSI. Use the checklist to ensure that each task is completed. Detailed instructions for completing some tasks follow the checklist.

Table 2-1 Preinstallation Tasks Checklist

Check	Preinstallation Task
	Ensure that Solaris 8 is installed on the Sun Netra T1 100/105, Sun Netra 120, or Sun Fire V120 platform, as described in the “Installing the Sun Solaris 8 Operating System” section on page 2-1. Note The default platform for the Cisco HSI is the Sun Fire V120.
	Configure group and user names, as described in the “Configuring Groups and Users” section on page 2-2.
	Gather the information listed in Table 2-2 and note it in the table for reference during the installation.
	Have your company internal support information and Cisco support contact information readily available so you can get help with the installation if needed. If you have questions or need assistance, see the “Obtaining Technical Assistance” section on page xvi.

Configuring Groups and Users

You must configure groups and users for the Cisco HSI on each host server. A user must be a member of the “mgcgrp” group to use certain Cisco HSI functions, such as Man-Machine Language (MML).

To configure groups and users, complete the following steps:

-
- Step 1** Log in as root.
- Step 2** At the # prompt, enter the following commands:
- ```
mkdir -p /export/home/users/mgcusr
mkdir /export/BUILDS
mkdir /export/PATCHES
cd /export/home/users
groupadd -g 20000 mgcgrp
useradd -u 20001 -g 20000 -d /export/home/users/mgcusr -s /bin/csh mgcusr
chown mgcusr:mgcgrp mgcusr
passwd mgcusr <type password twice>
```
- (Enter and confirm password)
- Step 3** Log out, then log in as user **mgcusr**, using the password you applied in Step 2.

- Step 4** Verify that you are in directory /export/home/users/mgcur by entering the following command:  
# **pwd**
- Step 5** Enter the following command:  
# **vi .cshrc**
- Step 6** Enter the vi insert mode by entering the following command:  
# **i** (enter insert mode)
- Step 7** Enter the following text on the first line:  
**source /opt/GoldWing/currentPM/local/setup.gw.csh**
- Step 8** Save the file and quit vi by entering the following commands:  
[Esc] (exit insert mode)  
**:wq** (write file and quit)
- Step 9** Enter the following command:  
# **chmod 777 .cshrc**

## Cisco HSI Installation Information

Gather the information listed in Table 2-2 before you begin the Cisco HSI installation. Use the Notes column in this table to record the information. Several steps in the installation procedure require you to provide this information. Refer to this table as you proceed through the Cisco HSI installation steps.

**Table 2-2 Cisco HSI Installation Information**

| Required Information                                                                                                                        | Notes                                                                                                                          |
|---------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
| Base directory path                                                                                                                         | <b>Note</b> We strongly recommend that you accept the default base directory path.                                             |
| Cisco HSI user name                                                                                                                         | Default: mgcur                                                                                                                 |
| Cisco HSI group name                                                                                                                        | Default: mggrp                                                                                                                 |
| Gatekeeper IP address                                                                                                                       |                                                                                                                                |
| Gatekeeper port                                                                                                                             | Default: 1719                                                                                                                  |
| Gateway prefix                                                                                                                              |                                                                                                                                |
| Terminal alias                                                                                                                              |                                                                                                                                |
| Gatekeeper ID                                                                                                                               | <b>Note</b> This ID must match the entry configured in the gatekeeper.                                                         |
| E-ISUP host port                                                                                                                            | <b>Note</b> Typically 8003, but this entry must match the peer port setting of the IPLNK object in the PGW 2200 configuration. |
| VSC1 <sup>1</sup> name (either the DNS <sup>2</sup> host name, if DNS is configured, or the IP address of the Cisco PGW 2200 <sup>3</sup> ) |                                                                                                                                |

**Table 2-2 Cisco HSI Installation Information (continued)**

| Required Information  | Notes                                                                                                                          |
|-----------------------|--------------------------------------------------------------------------------------------------------------------------------|
| VSC1 port             | <b>Note</b> Typically 8003, but this entry must match the peer port setting of the IPLNK object in the PGW 2200 configuration. |
| Installation node ID  |                                                                                                                                |
| Hardware platform     | Sun Netra T1<br>Sun Netra 120<br>Sun Fire V120 (Default)                                                                       |
| Installation location |                                                                                                                                |

1. VSC = virtual switch controller
2. DNS = domain name system
3. PGW = PSTN Gateway

The Cisco HSI application software is distributed in the OTTgw000.pkg file, which is in a Sun Packaging Stream file format.

The Cisco HSI application software is distributed as a tar file with a name format GoldWing-xxxx.tar, where xxxx is the version ID: for example, GoldWing-2.21.tar.

The default installation directory is /opt/GoldWing. You can specify a different directory. More than one version of the software can exist. The parent directory is in /opt/GoldWing/2.21.

Links point to the current active version of the Cisco HSI application, as follows:

- currentPM points to the current version to use for all software except the call processing application.
- currentGW points to the version that may not be the latest version of the call processing application. (GWmain)

Table 2-3 shows the subdirectories of the /opt/GoldWing/currentPM directory.

**Table 2-3 CurrentPM Subdirectories**

| Subdirectory | Contents                                                |
|--------------|---------------------------------------------------------|
| ./bin        | All compiled executables.                               |
| ./local      | All scripts.                                            |
| ./etc        | Base configuration files.                               |
| ./lib        | Shared libraries required by executables.               |
| ./toolkit    | Toolkit files.                                          |
| ./var        | Volatile directory that contains file locks and so on.  |
| ./var/log    | Default log directory.                                  |
| ./var/prov   | Provision system writes provisioning config files here. |
| ./var/trace  | Trace logs are written here.                            |

Exported provisioning files are stored in /opt/GoldWing/export.

## Installing the Cisco HSI

This section provides step-by-step instructions for installing a single Cisco HSI for use with a simplex PGW 2200 configuration (a configuration with one Cisco PGW 2200 host). To install a dual Cisco HSI for use with a redundant PGW 2200 configuration (a configuration with two Cisco PGW 2200 hosts), complete the steps in this section and then proceed to the “Installing a Dual Cisco HSI for a Redundant PGW 2200 Configuration” section on page 2-9.



### Note

In the following installation procedure, the package name is OTTgw000 and the version of the software is 2.21; the /export/BUILDS directory is used to install the system software.

To install the Cisco HSI, complete the following steps:

- Step 1** Verify that the Sun Solaris 8 operating system is installed. See the “Installing the Sun Solaris 8 Operating System” section on page 2-1 for more information.
- Step 2** Insert the Cisco HSI software CD in the CD-ROM drive.
- Step 3** Log in as root and enter the following commands at the # prompt:

```
cd /export/BUILDS
tar xvf /mnt/cdrom/GoldWing-2.21.tar
```

The following text displays:

```
x ./2.21/APPLICATIONS, 0 bytes, 0 tape blocks
x ./2.21/APPLICATIONS/OTTgw000.pkg, 38954496 bytes, 76083 tape blocks
x ./2.21/install.sh, 5223 bytes, 11 tape blocks
x ./2.21/uninstall.sh, 3053 bytes, 6 tape blocks
```

- Step 4** At the # prompt, enter the following commands:

```
cd /export/BUILDS/2.21
./install.sh
```

The following text displays:

```
Processing package instance <OTTgw000> from
</export/BUILDS/2.21/APPLICATIONS/OTTgw000.pkg>
GoldWing H323 Adjunct Processor V0.1.6
(sparc) 2.21
Copyright (c) 2001 Cisco Systems, Ltd.
All Rights Reserved
This product is protected by copyright and distributed under
licenses restricting copying, distribution and decompilation.
Enter GoldWing base directory path (default /opt/GoldWing) [?,q]
```

- Step 5** Press **Enter** to select the default HSI base directory path.



### Caution

We strongly recommend that you select the default base directory path. Operational issues might arise if other directories are used.

The following text displays:

```
Enter base directory path (default /opt/GoldWing/2.21) [?,q]
```

- Step 6** Press **Enter** to select the default base directory path. The following text displays:

Enter GoldWing user name

- Step 7** Type the Cisco HSI user name **mgcusr** and press **Enter** (the default user name is cisco). The following text displays:

Enter GoldWing group name

- Step 8** Type the Cisco HSI group name **mgcgrp** and press **Enter** (the default user group name is sysadmin). The following text displays:

Enter GateKeeper IP Address

- Step 9** Type the gatekeeper IP address (see Table 2-2) and press **Enter**. The following text displays:

Enter GateKeeper Port

- Step 10** Type the gatekeeper port (see Table 2-2) and press **Enter** (the default port is 1719). The following text displays:

Enter GateWay Prefix

- Step 11** Type the gateway prefix (see Table 2-2) and press **Enter**.



**Note** The gateway prefix is the prefix that, when dialed from the H.323 network, causes the Cisco HSI to route the call over E-ISUP to the PGW 2200.

The following text displays:

Enter Terminal Alias

- Step 12** Type the terminal alias (see Table 2-2) and press **Enter**. The following text displays:

Enter GateKeeper Id

- Step 13** Type the gatekeeper ID (see Table 2-2) and press **Enter**.



**Note** The gatekeeper ID must match the entry configured in the gatekeeper.

The following text displays:

Enter E-ISUP Host Port

- Step 14** Type the E-ISUP host port (see Table 2-2) and press **Enter**.



**Note** The E-ISUP host port is typically 8003, but it must match the peer port setting of the IPLNK object in the PGW 2200 configuration.

The following text displays:

Enter VSC1 Name

- Step 15** Type the VSC1 name and press **Enter**.



**Note** The VSCI name is either the DNS host name (if DNS is configured) or the IP address of the PGW 2200.

The following text displays:

```
Enter VSC1 Port
```

- Step 16** Type the VSC1 port number (see Table 2-2) and press **Enter**.



**Note** The VSC1 port is typically 8003, but it must match the port setting of the IPLNK object in the PGW 2200 configuration.

The following text displays:

```
Enter Installation NodeId
```

- Step 17** Type the installation node ID (see Table 2-2) and press **Enter**.



**Note** The installation node ID is a text field typically used by network designers for identification purposes. Entering a value in this field does not affect functionality.

The following text displays:

```
Enter Hardware Platform
```

- Step 18** Type the hardware platform name (see Table 2-2) and press **Enter** (typically, accept the default platform name). The following text displays:

```
Enter Installation Location
```

- Step 19** Type the installation location (see Table 2-2) and press **Enter**.



**Note** The installation location field is a text field typically used by network designers for identification purposes. Entering a value in this field does not affect functionality.

The following is an example of the screen that displays:

```
Executing checkinstall script.
Modified Environment is:

BASEDIR=/opt/GoldWing/2.21
GWHOME=/opt/GoldWing
GWUSR=mgcusr
GWGRP=mgcgrp
GWCONF_IP="10.70.54.53"
GWCONF_PORT="1719"
GWCONF_PREFIX="0208"
GWCONF_ALIAS="cisco@OuterLondonDomain.com"
GWCONF_GKID="OuterLondon"
GWCONF_HOST_PORT=8003
GWCONF_VSC1_NAME=goliath
GWCONF_VSC1_PORT=8003
GWCONF_NODEID="H323-GW1"
GWCONF_HARDWARE="Sun Netra T1"
GWCONF_LOCATION="H323 - GW1"

The selected base directory </opt/GoldWing/2.21> must exist before installation is
attempted.
Do you want this directory created now [y,n,?,q]
```

- Step 20** Type **y** to create the version directory. The following text displays:

```

Using </opt/GoldWing/2.21> as the package base directory.
Processing package information.
Processing system information.
Verifying disk space requirements.
Checking for conflicts with packages already installed.
Checking for setuid/setgid programs.
This package contains scripts which will be executed with super-user
permission during the process of installing this package.
Do you want to continue with the installation of <OTTgw000> [y,n,?]

```

**Step 21** Review the output before you continue the installation. Type **y** to continue. The files are installed. The following text displays:

```

Installing GoldWing H323 Adjunct Processor V0.1.6 as <OTTgw000>
Installing part 1 of 1.
/etc/init.d/CiscoGW
/etc/rc3.d/S95CiscoGW <symbolic link>
/opt/GoldWing/2.21/bin/GWmain
/opt/GoldWing/2.21/bin/PMmain
/opt/GoldWing/2.21/bin/mml
/opt/GoldWing/2.21/bin/msg.conf
/opt/GoldWing/2.21/bin/parse
/opt/GoldWing/2.21/etc/GWmain.base.conf
/opt/GoldWing/2.21/etc/GWmain.default.conf
/opt/GoldWing/2.21/etc/GWmain.static.conf
/opt/GoldWing/2.21/etc/H323SkeletonFileSimple.dat
/opt/GoldWing/2.21/etc/parse.exclude.list
/opt/GoldWing/2.21/etc/parse.list
/opt/GoldWing/2.21/lib/libgwMib_shlib.so
/opt/GoldWing/2.21/var/prov/active_config <symbolic link>
[verifying class <none>]
[verifying class <script>]
Executing postinstall script.
Installed package instance is: OTTgw000
Installation of <OTTgw000> was successful.
Installed package instance environment variables are:

PKGINST=OTTgw000
VERSION=2.21
BASEDIR=/opt/GoldWing/2.21
GWHOME=/opt/GoldWing
MGCUSR=mgcusr
MGCGRP=mgcgrp

Setting link /opt/GoldWing/currentPM.
Setting link /opt/GoldWing/currentGW.

```

Installation of the Cisco HSI is now complete. The directory /opt/GoldWing now displays as follows:

```

drwxr-xr-x 7 cisco sysadmin 512 Jan 9 18:31 2.21
lrwxrwxrwx 1 cisco sysadmin 19 Jan 9 18:31 currentGW -> /opt/GoldWing/2.21
lrwxrwxrwx 1 cisco sysadmin 19 Jan 9 18:31 currentPM -> /opt/GoldWing/2.21
-rwxrwxr-x 1 root other 3053 Jan 9 18:31 uninstall.sh

```



**Note**

The links currentPM and currentGW point to the currently active version of the Cisco HSI. The uninstall script has been copied here for convenience, but it can be run only by root user.

To check the Cisco HSI installation, enter **pkgchk OTTgw000**.



**Note**

The package name is OTTgw000. If more than one instance of the package is installed, the package name has a suffix (for example, OTTgw000.2, OTTgw000.3, and so on).

Outside of the /opt/GoldWing directory, the start/stop script CiscoGW is copied to the /etc/init.d directory, and the link /etc/rc3.d/S95CiscoGW is created to facilitate automatic startup of the Cisco HSI on system reboot.

When the installation is complete, a file named PKINST is written to the base directory on the installed software.


**Caution**

Do not modify the PKINST file. It contains information derived from the installation, and the uninstall script uses the PKINST file in the version directory to determine which package name to remove if more than one instance of the package is installed.

## Installing a Dual Cisco HSI for a Redundant PGW 2200 Configuration

A dual Cisco HSI can be installed and configured for use with a redundant Cisco PGW 2200 configuration (see Figure 2-1).

**Figure 2-1 Dual Cisco HSI with a Redundant PGW 2200 Configuration**

**Caution**

To ensure the successful installation of a dual Cisco HSI, after Step 21 of the “Installing the Cisco HSI” section on page 2-5, make sure that you provision the software for the active host first before proceeding to Step 1 below. See “Configuring the Cisco HSI” section on page 2-10 for configuration information.

Only one active provisioning session is permitted, and provisioning is permitted only on the active Cisco HSI.

Exit the provisioning session on the active host and continue to Step 1 below. If software is not provisioned after it is installed on the active host, the standby host is not synchronized with the active host. As a result, a forced switchover might fail.

To install a dual Cisco HSI for a redundant PGW 2200 configuration (a configuration with two Cisco PGW 2200 hosts), complete the following steps:

- 
- Step 1** Continuing from Step 21 of the “Installing the Cisco HSI” section on page 2-5, exit server 1.
  - Step 2** Log in to server 2 as root and go to the # prompt.
  - Step 3** Insert the Cisco HSI CD in the CD-ROM drive.
  - Step 4** Follow the installation instructions found in Step 3 through Step 21 of the “Installing the Cisco HSI” section on page 2-5.
- 

Installation of the dual Cisco HSI for a redundant PGW 2200 configuration is now complete.

## Starting the Cisco HSI

To start the Cisco HSI, execute the start script as the root user and enter the following command:

```
/etc/init.d/CiscoGW start
```



### Note

The application runs as root user because this is a requirement of a Simple Network Management Protocol (SNMP) subagent application. If you do not run this script as the root user, the SNMP subagent fails to connect to the master agent.

---

## Stopping the Cisco HSI

To stop the Cisco HSI, log in as root user and enter the following command:

```
/etc/init.d/CiscoGW stop
```

## Configuring the Cisco HSI

To configure the Cisco HSI, you must first access the user interface. Use the **mml** command (see Appendix A, “MML User Interface and Command Reference” for more information). If the `setup.gw` file has been sourced, it is in the user path. Use the provisioning commands to configure the Cisco HSI as required (see Chapter 3, “Provisioning the Cisco HSI” and Appendix A, “MML User Interface and Command Reference” for more information).

## Upgrading the Cisco HSI

Before removing an old version of the Cisco HSI, install the new version of the software. A provisioning session can be exported to a flat file in a format that can be used as input to another provisioning session (see `prov-exp` in Appendix A, “MML User Interface and Command Reference,” for more information).

When you upgrade the Cisco HSI version, the following conditions apply:

- The Cisco HSI must first be stopped before installation is allowed to proceed.
- The installation of the software overwrites the existing installed version of the software.

- The installation of a new version results in a new version directory being created in the /opt/GoldWing parent directory. The links currentPM and currentGW are updated to point to this new version.



**Note** To revert to a previous version of the software, manually modify the currentPM and currentGW links in the /opt/GoldWing parent directory to point to the previous version.

The uninstall.sh script uses the PKINST file in the version directory to determine which package name to remove.

## Removing the Cisco HSI

To remove the Cisco HSI, complete the following steps:

**Step 1** Log in as root.

**Step 2** Enter the following command to stop the Cisco HSI:

```
/etc/init.d/CiscoGW stop
```

**Step 3** Enter the following commands:

```
cd /opt/GoldWing
```

```
ls -l
```

The following is an example of the screen that displays:

```
drwxr-xr-x 7 cisco sysadmin 512 Jan 9 18:31 2.21
lrwxrwxrwx 1 cisco sysadmin 19 Jan 9 18:31 currentGW -> /opt/GoldWing/2.21
lrwxrwxrwx 1 cisco sysadmin 19 Jan 9 18:31 currentPM -> /opt/GoldWing/2.21
-rwxrwxr-x 1 root other 3053 Jan 9 18:31 uninstall.sh
```

**Step 4** Enter the **uninstall** command and specify the version of the software that you want to uninstall; for example:

```
./uninstall.sh 2.21
```

The following text displays:

```
Warning: This script will remove the package OTTgw000
Do you wish to proceed? [n] [y,n,?,q]
```

**Step 5** Type **y** and press **Enter**. The following text displays:

```
Deleting generated files in /opt/GoldWing/2.21
The following package is currently installed:
OTTgw000 GoldWing H323 Adjunct Processor V0.1.6
(sparc) 2.21
Do you want to remove this package?
```

**Step 6** Type **y** and press **Enter**. The following text displays:

```
Removing installed package instance <OTTgw000>
This package contains scripts which will be executed with super-user
permission during the process of removing this package.
Do you want to continue with the removal of this package [y,n,?,q]
```

**Step 7** Type **y** and press **Enter**. The following text displays:

```
Verifying package dependencies.
```

```
Processing package information.
Executing preremove script.
Removing pathnames in class <script>
/opt/GoldWing/2.21/local/setup.gw
/opt/GoldWing/2.21/local/pmStart.sh
/opt/GoldWing/2.21/local/gwhalt
/opt/GoldWing/2.21/local/CiscoGW
Removing pathnames in class <none>
/opt/GoldWing/2.21/local
/opt/GoldWing/2.21/lib/libgwMib_shlib.so
/opt/GoldWing/2.21/lib
/opt/GoldWing/2.21/etc/parse.list
/opt/GoldWing/2.21/etc/parse.exclude.list
/opt/GoldWing/2.21/etc/H323SkeletonFileSimple.dat
/opt/GoldWing/2.21/etc/GWmain.static.conf
/opt/GoldWing/2.21/etc/GWmain.request.conf
/opt/GoldWing/2.21/etc/GWmain.default.conf
/opt/GoldWing/2.21/etc/GWmain.conf
/opt/GoldWing/2.21/etc/GWmain.base.conf
/opt/GoldWing/2.21/etc
/opt/GoldWing/2.21/bin/parse
/opt/GoldWing/2.21/bin/msg.conf
/opt/GoldWing/2.21/bin/mml
/opt/GoldWing/2.21/bin/PMmain
/opt/GoldWing/2.21/bin/GWmain
/opt/GoldWing/2.21/bin
/opt/GoldWing/2.21/PKGINST
/etc/rc3.d/S95CiscoGW
/etc/rc3.d <shared pathname not removed>
/etc/init.d/CiscoGW
/etc/init.d <shared pathname not removed>
/etc <shared pathname not removed>
Executing postremove script.
Updating system information.

Removal of <OTTgw000> was successful.
```

---



# Provisioning the Cisco HSI

## Introduction

This chapter describes the data that must be provisioned for the Cisco H.323 Signaling Interface (HSI). The data is divided into two areas: system configuration and H.323 stack data. This chapter contains the following sections:

- Cisco HSI Configuration, page 3-1
- H.323 Stack Configuration, page 3-8

## Cisco HSI Configuration

All configuration data is contained within configuration files. Cisco HSI starts with an initial configuration file in `$BASEDIR/currentGW/etc/GWmain.conf`. This file is created during installation of the software.

The configuration data within the file is defined as dynamic, static, or constant:

- Dynamic data can be modified by a provisioning session (see Appendix A, “MML User Interface and Command Reference”). It can be activated on the currently running Cisco HSI.
- Static data can be modified by a provisioning session but cannot be activated on a running Cisco HSI. Changes to dynamic and static data can be written to a separate provisioning file (in `$BASEDIR/currentGW/var/prov/configname/session.dat`) that can be used during subsequent restarts of the Cisco HSI.
- Constant configuration data is contained within the configuration file and cannot be modified by provisioning sessions. Constant configuration data can be modified only by system technicians or administrators who use UNIX editing tools. This data is replicated from the initial configuration file into the provisioning files, and is included in subsequent provisioning sessions.

Examples of the use of constant data are given in Appendixes D, E, F, and G. These appendixes determine the mapping of cause values for incoming and outgoing H.323 and Enhanced ISDN User Part (E-ISUP) messages. System technicians can modify these values in the initial configuration file to explicitly choose the mappings for their system.

When a provisioning session creates a new configuration file, it also verifies that provisioned data is within allowable ranges and indicates this in the start of the file. It checksums the configuration file and writes the checksum as `$BASEDIR/currentGW/var/prov/configname/checksum.dat`. When the Cisco HSI starts up, it attempts to read the active configuration, checks that the configuration has been verified, and ensures that the checksum matches. If the active configuration is not verified or if the checksum is faulty, the configuration reverts to using the `$BASEDIR/currentGW/etc/GWmain.conf` file.

All configuration data that can be set in the system is defined in the Skeleton Configuration file (see Appendix B, “Skeleton Configuration File”). The Skeleton Configuration file defines the data names and types (strings or numbers), and defines whether the data is dynamic, static, or constant.

## MML Configuration Commands

There are three types of MML configuration command:

- Configuration session commands that work with entire provisioning data files (see Table 3-1)
- Configuration component or parameter commands that perform actions on components or parameters affecting a specific data file (see Table 3-2)
- Configuration export commands

For more information about MML configuration commands, see Appendix A, “MML User Interface and Command Reference.”



### Note

Parameter names used in MML commands are not case sensitive.

**Table 3-1 Configuration Session Commands**

| Command         | Description                                                                                     |
|-----------------|-------------------------------------------------------------------------------------------------|
| <b>prov-sta</b> | Starts a provisioning session to create a new configuration or modify an existing configuration |
| <b>prov-cpy</b> | Activates the configuration settings in the current provisioning session                        |
| <b>prov-stp</b> | Terminates the provisioning session and saves the configuration                                 |

**Table 3-2 Configuration Component or Parameter Commands**

| Command          | Description                                                  |
|------------------|--------------------------------------------------------------|
| <b>prov-add</b>  | Adds a component to the Cisco HSI                            |
| <b>prov-dlt</b>  | Deletes a provisioned component                              |
| <b>prov-ed</b>   | Modifies a provisioned component                             |
| <b>prov-rtrv</b> | Retrieves information about an existing provisioning session |

The configuration export command is **prov-exp**, which exports the currently provisioned configuration of the Cisco HSI to a file.

## System Configuration Data

System configuration data can be static or dynamic. Static data can be activated only at startup. Dynamic data can be activated during system run time.

### Static System Data

To modify the static system data parameters in Table 3-3, use the **sys\_config\_static** MML name variable for the **prov-add**, **prov-dlt**, and **prov-ed** commands. Halt and restart the application for the changes to take effect.

In the following example, the **prov-add** command adds the static system data parameter VSCA\_PORT\_NUMBER1 to a static configuration file. The **prov-ed** command modifies the value of the VSCA\_PORT\_NUMBER1 parameter. The **prov-dlt** command deletes the VSCA\_PORT\_NUMBER1 parameter from the static configuration file.

#### Example

```
prov-add:name=sys_config_static,vsca_port_number1=8003
prov-ed:name=sys_config_static,vsca_port_number1=8002
prov-dlt:name=sys_config_static,vsca_port_number1
```

The parameters in Table 3-3 are written to a static configuration file or to a section within a file.

**Table 3-3** Static System Data Parameters

| Parameter         | Type      | Description                                                                                                                                                                                    |
|-------------------|-----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| HOST_PORT_NUMBER1 | [0-65535] | The first port number to be used by the Cisco HSI. The default value is 0.<br><b>Note</b> This value must match the peer port setting on the PGW <sup>1</sup> 2200 E-ISUP IPLNK object.        |
| HOST_PORT_NUMBER2 | [0-65535] | The second port number to be used by the Cisco HSI. The default value is 0.<br><b>Note</b> This value should always be set to 0.                                                               |
| VSCA_IPADDR1      | STRING    | The primary IP address of the primary PGW 2200.                                                                                                                                                |
| VSCA_IPADDR2      | STRING    | The secondary IP address of the primary PGW 2200.<br><b>Note</b> This value must match that of VSCA_IPADDR1.                                                                                   |
| VSCB_IPADDR1      | STRING    | The primary IP address of the secondary PGW 2200.<br><b>Note</b> This parameter is not used in a standalone PGW configuration.                                                                 |
| VSCB_IPADDR2      | STRING    | The secondary IP address of the secondary PGW 2200.<br><b>Note</b> This value of this parameter must match that of VSCB_IPADDR1. This parameter is not used in a standalone PGW configuration. |
| VSCA_PORT_NUMBER1 | [0-65535] | The first port number of the primary PGW 2200.                                                                                                                                                 |
| VSCA_PORT_NUMBER2 | [0-65535] | The second port number of the primary PGW 2200.<br><b>Note</b> This value must match that of VSCA_PORT_NUMBER1.                                                                                |
| VSCB_PORT_NUMBER1 | [0-65535] | The first port number of the secondary PGW 2200.<br><b>Note</b> This parameter is not used in a standalone PGW configuration.                                                                  |

Table 3-3 Static System Data Parameters (continued)

| Parameter              | Type      | Description                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|------------------------|-----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| VSCB_PORT_NUMBER2      | [0-65535] | The second port number of the secondary PGW 2200.<br><b>Note</b> This value of this parameter must match that of VSCA_PORT_NUMBER2. This parameter is not used in a standalone PGW configuration.                                                                                                                                                                                                                                                        |
| ClipClirSupported      | STRING    | CLI Presentation or restriction is enabled if this parameter is present and set to anything other than "". For example, to enable CLIP/CLIR support, set this parameter explicitly to "Enabled."                                                                                                                                                                                                                                                         |
| RaiSupported           | STRING    | RAI support is enabled if this parameter is present and set to anything other than "". For example, to enable RAI support, set this parameter to "Enabled."                                                                                                                                                                                                                                                                                              |
| DtmfSupportedDirection | STRING    | This is set to "both", "tx," or "rx". If this parameter is not present or is set to any value other than "both," "tx," or "rx," the DTMF Relay feature is disabled.                                                                                                                                                                                                                                                                                      |
| DtmfSupportedType      | STRING    | This is set to "dtmf" or "basicString." If this parameter is not present or set to any other value, the DTMF Relay feature is disabled.                                                                                                                                                                                                                                                                                                                  |
| H225PavoSupported      | STRING    | Pavo support is enabled if this parameter is present and set to anything other than "". For example, set it to "Enabled."                                                                                                                                                                                                                                                                                                                                |
| PavoRedirScreeningInd  | [0-3]     | The value of the Pavo redirecting number screening indicator. (If this parameter is not provisioned, the default is Q.931 zero—user provided, not screened.)                                                                                                                                                                                                                                                                                             |
| PavoRedirReason        | [0-15]    | The value of the Pavo redirecting number reason field. This parameter has no default. If unprovisioned, the redirecting number parameter will not contain the Reason for Redirection field (octet 3b).                                                                                                                                                                                                                                                   |
| PavoRedirPresInd       | [0-3]     | The value of the Pavo redirecting number presentation indicator. (If this parameter is not provisioned, the default is Q.931 zero—no indication.)                                                                                                                                                                                                                                                                                                        |
| CliInDisplaySupported  | STRING    | If this parameter is present and set to anything other than "", the Calling Number is also sent in the DISPLAY IE. The NetMeeting endpoint retrieves the calling party number from the DISPLAY IE in the H.225 setup message. To enable this parameter, set it to "Enabled."                                                                                                                                                                             |
| T38MaxVal              | STRING    | This T.38 FaxT38MaxVal parameter has the following optional attributes that can be assigned values in a specific range.<br><b>Note</b> Values for the following attributes must be expressed in hexadecimal format. <ul style="list-style-type: none"> <li>MaxBit—[0x0—0xFFFFFFFF]. The default value is 0x90.</li> <li>FxMaxBuf—[0x0—0xFFFFFFFF]. The default value is 0xc8.</li> <li>FxMaxData—[0x0—0xFFFFFFFF]. The default value is 0x48.</li> </ul> |
| T38Options             | STRING    | This T.38 Fax parameter is assigned one of the following optional values: <ul style="list-style-type: none"> <li>FxFillBit—[0 or 1] The default value is 0.</li> <li>FxTransMMR—[0 or 1] The default value is 0.</li> <li>FxRateTransJBIG—[0 or 1] The default value is 0.</li> <li>FXRate—[Local or Trans] The default value is Trans.</li> <li>FxUdpEC—[Red or FEC] The default value is Red.</li> </ul>                                               |



**Table 3-3 Static System Data Parameters (continued)**

| Parameter                   | Type   | Description                                                                                                                                                                                                                                                                                                                                                                                                 |
|-----------------------------|--------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| AsymmetricHandlingSupported | STRING | Asymmetric Codec Treatment support is enabled if this parameter is present and set to anything other than "". To enable Asymmetric Codec Treatment, set this parameter to "Enabled."                                                                                                                                                                                                                        |
| UseConfID                   | STRING | Use this parameter to specify the precedence of extracting the Global Call ID from the Conference ID or the GUID in the H.225 Setup message. The provisioning of this property to a value other than "" gives precedence to the Conference ID. For example, set it to "Enabled." To set the precedence to the GUID field, the crafts person can either delete the property from the config or set it to "". |
| DualCLISupported            | STRING | To enable Dual CLI support (see H.246 Annex C), set this parameter to anything other than "". For example, to explicitly enable Dual CLI support, set this parameter to "Enabled."                                                                                                                                                                                                                          |

1. PGW = Public Switched Telephone Network (PSTN) Gateway

## Dynamic System Data

To modify the dynamic system data parameters in Table 3-4, use the `sys_config_dynamic` MML name variable for the **prov-add**, **prov-dlt**, and **prov-ed** commands. You need not halt and restart call processing for the changes to take effect.

In the following example, the **prov-add** command adds the dynamic system data parameter `OVLLEVEL1PERCENT` to a dynamic configuration file. The **prov-ed** command modifies the value of the `OVLLEVEL1PERCENT` parameter. The **prov-dlt** command deletes the `OVLLEVEL1PERCENT` parameter from the dynamic configuration file.

### Example

```
prov-add:name=sys_config_dynamic,OVLLEVEL1PERCENT=20
prov-ed:name=sys_config_dynamic,OVLLEVEL1PERCENT=25
prov-dlt:name=sys_config_dynamic,OVLLEVEL1PERCENT
```

The MML commands write the parameters in Table 3-4 to a dynamic configuration file or to a section within a file.

**Table 3-4 Dynamic System Data Parameters**

| Parameter         | Description                                                                                                                                                                                                                                       | Default      |
|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------|
| LOGDIRECTORY      | Specifies the directory used when the active log file is created, and also specifies the directory where the rotated log file is stored.                                                                                                          | /var/log/    |
| LOGFILENAMEPREFIX | Specifies the filename prefix used when the log files are created or rotated. The .log postfix is appended to the end of the prefix to establish the name of the active log file.                                                                 | platform.log |
| LOGPRIO           | Defines the initial logging levels. By default it is set to TRACE. When the system initializes and is running, the levels set for individual packages (0x0000 to 0xFFFF) determine the log levels. See the "Logging Levels" section on page 4-10. | TRACE        |

Table 3-4 Dynamic System Data Parameters (continued)

| Parameter                  | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Default                               |
|----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------|
| LOGFILEROTATESIZE          | Triggers a log file rotation based on the size of the active file. The application regularly checks the current size of the file to determine whether a rotation is required. If a file rotation is triggered by this parameter, the rotated file might be slightly larger than the size specified by this parameter. A file rotation is triggered by this parameter causes the timer associated with the LOGFILEROTATEINTERVAL parameter to be reset as well.                                              | 10 Mb                                 |
| LOGFILEROTATEINTERVAL      | Triggers a log file rotation based on the time elapsed since the previous rotation. This timer is reset after any rotation occurs, regardless of the cause or trigger of the rotation.                                                                                                                                                                                                                                                                                                                      | 1440 minutes<br>(24 hours)            |
| IPADDRNMS                  | Defines the IP address of the network management system.                                                                                                                                                                                                                                                                                                                                                                                                                                                    | —                                     |
| OVLDSAMPLERATE             | Defines the frequency of CPU sampling and threshold checking.                                                                                                                                                                                                                                                                                                                                                                                                                                               | 3000 millisecond<br>(ms) polling rate |
| OVLLEVEL1PERCENT           | Indicates what percentage of calls should be rejected when an overload condition occurs. This parameter is used in conjunction with the OVLLEVEL1FILTER parameter. The overload level 1 value is the lowest level of overload and must be less than or equal to the provisioned values for OVLLEVEL2PERCENT and OVLLEVEL3PERCENT.<br><br><b>Note</b> If this value is set to zero, no overload level 1 treatment occurs.                                                                                    | 20                                    |
| OVLLEVEL1FILTER            | Indicates what call types should be gapped if an overload level 1 condition occurs. The possible values are: <ul style="list-style-type: none"> <li>Normal—Emergency or priority calls are not gapped.</li> <li>All—All calls are gapped, regardless of type.</li> </ul> <b>Note</b> If the overload percentage is set to 100, all calls are gapped irrespective of this setting.                                                                                                                           | Normal                                |
| OVLLEVEL1THRESHLOWER CALLS | Determines the number of active calls below which the application load must fall in order for the overload level 1 condition to be removed.                                                                                                                                                                                                                                                                                                                                                                 | 1800                                  |
| OVLLEVEL1THRESHUPPER CALLS | Determines how many simultaneous active calls trigger an overload level 1 condition.                                                                                                                                                                                                                                                                                                                                                                                                                        | 1900                                  |
| OVLLEVEL1THRESHLOWER CPU   | Determines the CPU utilization level below which the application must fall in order for the overload level 1 condition to be removed.                                                                                                                                                                                                                                                                                                                                                                       | 60                                    |
| OVLLEVEL1THRESHUPPER CPU   | Determines the level of CPU utilization that triggers an overload level 1 condition.                                                                                                                                                                                                                                                                                                                                                                                                                        | 65                                    |
| OVLLEVEL2PERCENT           | Indicates what percentage of calls should be rejected when an overload condition occurs. The parameter is used in conjunction with the OVLLEVEL2FILTER parameter. This is the second level of overload and must be less than or equal to the provisioned value of OVLLEVEL3PERCENT and greater than or equal to the provisioned value of OVLLEVEL1PERCENT.<br><br><b>Note</b> If this value is set to zero, no overload level 1 or 2 treatment occurs (by definition, the level 1 value must also be zero). | 75                                    |

Table 3-4 Dynamic System Data Parameters (continued)

| Parameter                  | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                     | Default |
|----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| OVLLEVEL2FILTER            | Indicates what call types should be gapped if an overload level 2 condition occurs (see OVLLEVEL1FILTER).                                                                                                                                                                                                                                                                                                                                                       | Normal  |
| OVLLEVEL2THRESHLOWER CALLS | Determines the number of active calls below which the application load must fall in order for the overload level 2 condition to be removed.                                                                                                                                                                                                                                                                                                                     | 2000    |
| OVLLEVEL2THRESHUPPER CALLS | Determines how many simultaneous active calls trigger an overload level 2 condition.                                                                                                                                                                                                                                                                                                                                                                            | 2200    |
| OVLLEVEL2THRESHLOWER CPU   | Determines the level of CPU utilization below which the application must fall in order for the overload level 2 condition to be removed.                                                                                                                                                                                                                                                                                                                        | 70      |
| OVLLEVEL2THRESHUPPER CPU   | Determines the level of CPU utilization that triggers an overload level 2 condition.                                                                                                                                                                                                                                                                                                                                                                            | 80      |
| OVLLEVEL3PERCENT           | Indicates what percentage of calls should be rejected when an overload condition occurs. The parameter is used in conjunction with the OVLLEVEL3FILTER parameter. This is the highest level of overload and must be greater than or equal to the provisioned values for OVLLEVEL1PERCENT and OVLLEVEL2PERCENT.<br><br><b>Note</b> If this value is set to zero, no overload treatment occurs (by definition, the level 1 and level 2 values must also be zero). | 90      |
| OVLLEVEL3FILTER            | Indicates what call types should be gapped if an overload level 3 condition occurs (see OVLLEVEL1FILTER).                                                                                                                                                                                                                                                                                                                                                       | Normal  |
| OVLLEVEL3THRESHLOWER CALLS | Determines the number of active calls below which the application load must fall in order for the overload level 3 condition to be removed.                                                                                                                                                                                                                                                                                                                     | 2300    |
| OVLLEVEL3THRESHUPPER CALLS | Determines how many simultaneous active calls trigger an overload level 3 condition.                                                                                                                                                                                                                                                                                                                                                                            | 2400    |
| OVLLEVEL3THRESHLOWER CPU   | Determines the level of CPU utilization below which the application must fall in order for the overload level 3 condition to be removed.                                                                                                                                                                                                                                                                                                                        | 85      |
| OVLLEVEL3THRESHUPPER CPU   | Determines the level of CPU utilization that triggers an overload level 3 condition.                                                                                                                                                                                                                                                                                                                                                                            | 95      |
| CIAGENTSCANPERIOD          | Specifies the frequency with which the CIagent polls the CPU utilization.                                                                                                                                                                                                                                                                                                                                                                                       | —       |
| ALARMDEBOUNCETIME          | Specifies the length of time that an alarm condition must persist before being reported, and any associated action taken.                                                                                                                                                                                                                                                                                                                                       | 0       |
| CALLREFERENCEUSAGE         | Determines which call reference identity is passed on to the PGW 2200 (call reference field or Conference ID).                                                                                                                                                                                                                                                                                                                                                  | —       |

Table 3-4 Dynamic System Data Parameters (continued)

| Parameter              | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | Default |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| DISKUSAGELIMIT         | <p>Represents a percentage of disk occupancy.</p> <p>The application continually polls the system for disk occupancy, and if the percentage rises above the limit set by DISKUSAGELIMIT, the LOW_DISK_SPACE alarm is raised.</p> <p>DISKUSAGELIMIT has a default value of 95 percent. The value range is 0–100, inclusive. When dynamically provisioned, the parameter DISKUSAGELIMIT, if not set within that range, is set to the default value (95) and the CONFIGURATION_FAILURE alarm is raised.</p> | 95      |
| RegFailureReleaseCause | <p>This parameter specifies the Q.850 release cause, which the HSI uses after the HSI fails three times to register to a gatekeeper.</p> <p>This parameter is assigned a value in the range 1–127</p>                                                                                                                                                                                                                                                                                                    | —       |

## H.323 Stack Configuration

Refer to the *RADVision H.323 Protocol Stack Programmer's Guide* for definitions of each of the RADVision parameters.

The parameter name is based on the ASN.1 paths, but in some cases the parameter name has been shortened for convenience. For example, “capabilities” has been shortened to “caps.”

The case of the parameter name reflects exactly the ASN.1 definitions, but case is not important to MML configuration.

## Nonprovisionable Data

The parameters in Table 3-5 cannot be altered through MML commands.

Table 3-5 Nonprovisionable Data Parameters

| H323_SYS                          | Description     |
|-----------------------------------|-----------------|
| system.manualstart                | Present         |
| system.pdlname                    | Absent          |
| system.delimiter                  | #FF             |
| ras.gatekeeper                    | Absent          |
| ras.rasmulticastaddress           | 224.0.1.41.1718 |
| h245.capabilities.manualoperation | Present         |
| h245.masterslave.manualoperation  | Present         |
| q931.manualaccept                 | Present         |
| q931.earlyH245                    | Present         |
| q931.autoanswer                   | Present         |

**Table 3-5 Nonprovisionable Data Parameters (continued)**

| H323_SYS                  | Description |
|---------------------------|-------------|
| q931.manualcallprocessing | Present     |
| q931.h245tunneling        | Present     |

## MML Provisionable Data

### H.323 System Parameters

The parameters in Table 3-6 are required for H.323 stack initialization. To modify the parameters in Table 3-6, use the h323\_sys MML name variable for the **prov-add**, **prov-dlt**, and **prov-ed** commands. Halt and restart the application for these changes to take effect.


**Note**

The asterisk (\*) after a parameter name in the first column of Table 3-6 denotes a mandatory RADVision parameter that has an inbuilt default value if a value is not set in provisioning.

**Table 3-6 H.323 System Initialization Parameters**

| Parameter    | Description                                   | Type              | Example |
|--------------|-----------------------------------------------|-------------------|---------|
| maxCalls*    | Maximum number of concurrent calls allowed    | INTEGER(0, 65535) | 2500    |
| maxChannels* | Maximum number of concurrent channels allowed | INTEGER(0, 65535) | 2       |

### Q.931 Parameters

To modify the parameters listed in Table 3-7, use the q931 MML name variable for the **prov-add**, **prov-dlt**, and **prov-ed** commands.

In the following example, the **prov-add** command sets the Q.931 parameter maxCalls to the value 2000.

**Example**

```
prov-add:name=q931,maxCalls=2000
```

The Update Type column in Table 3-7 shows when the change to a parameter takes effect once a change is made:

- Immediate means that the effect of the change is immediate.
- Start means that the application needs to be restarted for the change to take effect.
- Next Call means that the next call has the new parameter set.


**Note**

Immediate and Next Call update types refer to dynamic system data.


**Note**

The asterisk (\*) after a parameter name in the first column of Table 3-7 denotes a mandatory RADVision parameter with an inbuilt default value that will be used if the value is not set in provisioning.

Table 3-7 Q.931 Parameters

| Parameter Name      | Description                                                                                                                                                                | Type             | Example     | Update Type |
|---------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|-------------|-------------|
| responseTimeOut*    | The maximum time (in seconds) permitted to receive the first response to a call. If this parameter expires, the call is disconnected.                                      | INTEGER(1,200)   | 20          | Immediate   |
| connectTimeOut*     | The maximum time (in seconds) the stack waits for call establishment after the first response is received. If this parameter expires, the call is disconnected.            | INTEGER(1,20000) | 180         | Immediate   |
| callSignalingPort*  | The number of the port receiving the calls destined for the PGW 2200.                                                                                                      | INTEGER(0,65535) | 1720        | Start       |
| maxCalls*           | The maximum number of simultaneous calls permitted. If this parameter is exceeded, the next call attempt returns busy.                                                     | INTEGER(0,65535) | 2500        | Next Call   |
| notEstablishControl | The stack does not allow the switching of control from the Q.931 to the H.245 stack.                                                                                       | NULL             | Not present | Next Call   |
| overlappedSending   | Because the Q.931 configuration flag indicates that both parties support overlap sending, this state notifies the other party that it can send an overlap sending message. | NULL             | Present     | Immediate   |

**Note**

The Q.931 parameter overlappedSending has been combined with the RAS overlappedSending parameter. If you set the Q.931 overlappedSending parameter, you also set the RAS overlappedSending parameter.

## RAS Parameters

The parameters in Table 3-8 are required for RAS stack initialization. To modify the RAS parameters, use the ras MML name variable for the **prov-add**, **prov-dlt**, and **prov-ed** commands.

In the following example, the **prov-add** command sets the RAS parameter maxfail to the value 3.

**Example**

```
prov-add:name=ras,maxfail=3
```

The array index [i] in some of the parameter names in the first column of Table 3-8 must be replaced with a valid braced index from 1 to 20, and must be continuous and unique (that is, it must contain no duplicates).

The Update Type column in Table 3-8 shows when the change to a parameter takes effect after it is modified:

- Immediate means that the effect of the change is immediate.
- Start means that the application needs to be restarted for the change to take effect.
- Next Call means that the next call has the new parameter set.



**Note** Immediate and next call update types are dynamic system data.



**Note** The RAS parameter overlappedSending is not available here because it has been combined with the Q.931 overlappedSending parameter. If you set the Q.931 overlappedSending parameter, you also set the the RAS overlappedSending parameter.



**Note** The asterisk (\*) after a parameter name in the first column of Table 3-8 denotes a mandatory RADVision parameter with an inbuilt default value that will be used if the value is not set in provisioning.

**Table 3-8 RAS Parameters**

| Parameter Name       | Description                                                                                                                                       | Type              | Example     | Update Type |
|----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|-------------|-------------|
| manualRAS            | If this parameter is present, the stack does not perform automatic RAS procedures (it waits to be driven by the application).                     | NULL              | —           | Start       |
| responseTimeOut*     | The time (in seconds) that the stack waits until it notifies the application that the called party has failed to respond to a transaction.        | INTEGER(1, 200)   | 10          | Immediate   |
| maxFail*             | Maximum number of retry gatekeeper registration attempts.                                                                                         | INTEGER(1, 200)   | 3           | Immediate   |
| allowCallsWhenNonReg | If this parameter is present, it allows calls to proceed even if gatekeeper registration has not been done for the PGW 2200.                      | NULL              | Not present | Immediate   |
| manualRegistration   | If this parameter is present, the stack does not perform automatic gatekeeper registration procedures (it waits to be driven by the application). | NULL              | Not present | Stop/Start  |
| timeToLive           | The maximum time (in seconds) the registration of the PGW 2200 with a gatekeeper remains valid. The stack reregisters periodically.               | INTEGER(1, 65535) | 400         | Immediate   |

Table 3-8 RAS Parameters (continued)

| Parameter Name            | Description                                                                                                                                                                                                                                     | Type              | Example      | Update Type |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|--------------|-------------|
| rasPort*                  | The number of the port receiving all RAS transactions for the current endpoint. Set this parameter to 0 to allow the software to look for the available port.                                                                                   | INTEGER(0, 65535) | 0            | Start       |
| compare15bitRasCrv        | If this parameter is present, it causes the stack to ignore the call reference value (CRV) MSBit in RAS messages.                                                                                                                               | NULL              | —            | Immediate   |
| maxRetries*               | Maximum number of RAS retransmissions.                                                                                                                                                                                                          | INTEGER(1, 200)   | 3            | Immediate   |
| maxMulticastTTL           | Maximum number of multicast time to live (TTL).                                                                                                                                                                                                 | INTEGER(0, 200)   | 3            | Start       |
| preGrantedArqUse          | Choice of direct or routed. If direct, the pregranted Admission Request (ARQ) feature is used for both direct and routed calls. If routed, the pregranted ARQ feature is used only for routed calls. If absent, the pregranted ARQ is not used. | STRING            | direct       | Next Call   |
| manualDiscovery.ipAddress | The IP address of a known gatekeeper with which an endpoint might attempt to register.                                                                                                                                                          | STRING            | 10.70.54.53  | Start       |
| manualDiscovery.port      | The port associated with the manualDiscovery.ipAddress, which can, by agreement, be either a well-known port or another port.                                                                                                                   | INTEGER(0, 65535) | 1719         | Start       |
| gateway.prefix[i]         | The gateway registers the telephone prefix specified by this parameter to indicate that it is able to terminate it.                                                                                                                             | STRING            | 0208         | Immediate   |
| gatekeeperId              | Identifies the gatekeeper with which the endpoint is trying to register.                                                                                                                                                                        | STRING            | OuterLondon  | Immediate   |
| terminalAlias[i].e164     | Two variants of the same address for the endpoint; e164 is numeric and h323ID is text.                                                                                                                                                          | STRING            | 0208001000   | Immediate   |
| terminalAlias[i].h323ID   |                                                                                                                                                                                                                                                 | STRING            | GW@ot.com.au | Immediate   |



Table 3-8 RAS Parameters (continued)

| Parameter Name                  | Description                                                 | Type              | Example | Update Type |
|---------------------------------|-------------------------------------------------------------|-------------------|---------|-------------|
| endpointVendor.t35CountryCode   | These parameters identify the manufacturer of the endpoint. | INTEGER(0, 255)   | 11      | Immediate   |
| endpointVendor.t35Extension     |                                                             | INTEGER(0, 255)   | 11      | Immediate   |
| endpointVendor.manufacturerCode |                                                             | INTEGER(0, 65535) | 9       | Immediate   |
| endpointVendor.productId        | Data that the manufacturer assigns to each product.         | STRING            | H323ESP | Immediate   |
| endpointVendor.versionId        | Data that the manufacturer assigns to each version.         | STRING            | R0.2.4  | Immediate   |

## H.245 Parameters

To modify the H.245 parameters listed in Table 3-9, use the h245 MML name variable for the **prov-add**, **prov-dlt** and **prov-ed** commands.

In the following example, the **prov-add** command sets the H.245 parameter masterSlave.timeout to the value 5.

### Example

```
prov-add:name=h245,masterSlave.timeout=5
```

The Update Type column in Table 3-9 shows when a change to an H.245 parameter takes effect after it is modified:

- Immediate means that the effect of the change is immediate.
- Start means that the application needs to be restarted for the change to take effect.
- Next Call means that the next call has the new parameter set.



### Note

Immediate and Next Call update types are dynamic system data.

Table 3-9 H.245 Parameters

| Parameter Name             | Description                                                                                         | Type              | Example | Update Type |
|----------------------------|-----------------------------------------------------------------------------------------------------|-------------------|---------|-------------|
| masterSlave.terminalType   | The terminal type for the PGW 2200.                                                                 | INTEGER(0, 255)   | 60      | Next Call   |
| masterSlave.manualResponse | If this parameter is present, it cancels automatic acknowledgment of master or slave determination. | NULL              | Present | Next Call   |
| masterSlave.timeout        | The maximum time (in seconds) the stack waits before it gives up on the master/slave procedure.     | INTEGER(0, 65535) | 5       | Immediate   |

Table 3-9 H.245 Parameters (continued)

| Parameter Name      | Description                                                                                            | Type              | Example | Update Type |
|---------------------|--------------------------------------------------------------------------------------------------------|-------------------|---------|-------------|
| channelsTimeout     | The time (in seconds) the stack waits for a response to a channel establishment message.               | INTEGER(0, 65535) | 10      | Immediate   |
| roundTripTimeout    | The time (in seconds) the stack waits for round-trip procedure completion.                             | INTEGER(0, 65535) | 5       | Immediate   |
| requestCloseTimeout | The time (in seconds) the stack waits for request close procedure completion.                          | INTEGER(0, 65535) | 5       | Immediate   |
| requestModeTimeout  | The time (in seconds) the stack waits for request mode procedure completion.                           | INTEGER(0, 65535) | 5       | Immediate   |
| caps.timeout        | The maximum time (in seconds) the stack waits before it gives up on the capability exchange procedure. | INTEGER(0, 65535) | 5       | Immediate   |
| caps.maxAudioDelay  | Maximum H.255 multiplex audio delay jitter.                                                            | INTEGER(0, 1023)  | 60      | Immediate   |
| mediaLoopTimeout    | The timeout (in seconds) of the media loop procedure.                                                  | INTEGER(0, 65535) | 5       | Immediate   |

Table 3-10, Table 3-11, and Table 3-12 list the parameters and modes related to the configuring of codecs. The array index [i] must be replaced with a valid braced index from 1 to 20. The braced index must be continuous and unique (that is, there must be no duplicates).

Table 3-10 H.245 Terminal Capability Codec Parameters

| Parameter Name                               | Type              |
|----------------------------------------------|-------------------|
| caps.table[i].entryNo                        | INTEGER(1, 65535) |
| caps.table[i].audio.g711Alaw64k              | INTEGER(1, 256)   |
| caps.table[i].audio.g711Alaw56k              | INTEGER(1, 256)   |
| caps.table[i].audio.g711Ulaw64k              | INTEGER(1, 256)   |
| caps.table[i].audio.g711Ulaw56k              | INTEGER(1, 256)   |
| caps.table[i].audio.g722at64k                | INTEGER(1, 256)   |
| caps.table[i].audio.g722at56k                | INTEGER(1, 256)   |
| caps.table[i].audio.g722at48k                | INTEGER(1, 256)   |
| caps.table[i].audio.g7231.maxAudioFrames     | INTEGER(1, 256)   |
| caps.table[i].audio.g7231.silenceSuppression | INTEGER(0, 1)     |
| caps.table[i].audio.g728                     | INTEGER(1, 256)   |
| caps.table[i].audio.g729                     | INTEGER(1, 256)   |

**Table 3-11 H.245 Channel Codec Parameters**

| Parameter Name                         | Type            |
|----------------------------------------|-----------------|
| chan[i].name                           | STRING          |
| chan[i].audio.g711Alaw64k              | INTEGER(1, 256) |
| chan[i].audio.g711Alaw56k              | INTEGER(1, 256) |
| chan[i].audio.g711Ulaw64k              | INTEGER(1, 256) |
| chan[i].audio.g711Ulaw56k              | INTEGER(1, 256) |
| chan[i].audio.g722at64k                | INTEGER(1, 256) |
| chan[i].audio.g722at56k                | INTEGER(1, 256) |
| chan[i].audio.g722at48k                | INTEGER(1, 256) |
| chan[i].audio.g7231.maxAudioFrames     | INTEGER(1, 256) |
| chan[i].audio.g7231.silenceSuppression | INTEGER(0, 1)   |
| chan[i].audio.g728                     | INTEGER(1, 256) |
| chan[i].audio.g729                     | INTEGER(1, 256) |

**Table 3-12 H.245 Modes**

| Parameter Name             | Type            |
|----------------------------|-----------------|
| modes[i].name              | STRING          |
| modes[i].audio.g711Alaw64k | NULL            |
| modes[i].audio.g711Alaw56k | NULL            |
| modes[i].audio.g711Ulaw64k | NULL            |
| modes[i].audio.g711Ulaw56k | NULL            |
| modes[i].audio.g722at64k   | NULL            |
| modes[i].audio.g722at56k   | NULL            |
| modes[i].audio.g722at48k   | NULL            |
| modes[i].audio.g7231       | INTEGER(1, 256) |
| modes[i].audio.g728        | NULL            |
| modes[i].audio.g729        | NULL            |

# Configuring HSI Release 2.21 Features

This section tells you how to enable the HSI features introduced in HSI Release 2.21. These features are:

- Asymmetric Codec Treatment
- Empty Capability Set
- H.323 Hairpin
- T.38 Fax

## Asymmetric Codec Treatment

The Asymmetric Codec Treatment feature averts the potential for inconsistencies in codec selection, which can result if the open channel requests are sent by each endpoint at nearly the same time, so that neither side has received an open channel request prior to sending one. In practice, such asymmetric conditions occur only for slow start calls. When there is a fast start recipient, both channels agree to use the same codec in unison.

The Asymmetric Codec Treatment support is enabled if this parameter is present and set to anything other than "". For example, support is enabled if the parameter is explicitly set to "Enabled." To enable Asymmetric Codec Treatment, enter the following command:

**Example:**

```
prov-add:name=sys_config_static, asymmetrichandlingsupported = "Enabled"
```

## Empty Capability Set

The Empty Capability Set feature enables an H.323 endpoint to send a TCS message with empty capabilities during a call. The TCS message causes the audio channels to close. This action enables the negotiation and opening of new audio channels.

The Empty Capability Set feature is useful when the H.323 endpoint wishes to change the audio codec during a call or if the endpoint needs to divert the media streams to a different location. Typically, the feature is used to place a call on hold to disable the media stream until the user presses the Resume button.

The Empty Capability Set feature on the HSI requires no provisioning.

## H.323 Hairpin

The H.323 Hairpin feature (also called H.323 Hairpin) can be used to connect a call between two H.323 endpoints without using resources on the media gateway. For example, the PGW can respond to the dialled number in an incoming H.323 call by routing the call to another HSI (perhaps the same HSI) rather than routing the call to the PSTN. In this case, the originating and terminating HSIs establish the call normally but pass the H.245 address of the H.323 endpoints. This enables the two endpoints to use H.245 to negotiate media channels with each other directly, independent of the HSI.

The H.323 Hairpin feature on the HSI requires no provisioning. However, to operate throughout the system, H.323 Hairpin must be enabled on the PGW. On the PGW, you enable H.323 Hairpin through a trunk group property by issuing the following commands:

```
prov-add:trnkgprpprop:name="2000",AllowH323Hairpin="1"
prov-add:trnkgprpprop:name="3000",AllowH323Hairpin="1"
```

**Note**

H.323 Hairpin must be enabled for both the ingress and egress EISUP trunk groups.

Refer to PGW and Cisco IOS documentation at [www.cisco.com](http://www.cisco.com) for further information on these commands.

## T.38 Fax

You enable T.38 Fax for the HSI by specifying static system data parameters. By default, T.38 is provisioned on the HSI by use of the following commands:

```
prov-add:name=sys_config_static,t38maxval="MaxBit 0x90, FxMaxBuf 0xc8, FxMaxData 0x48"
prov-add:name=sys_config_static,t38options="FxFillBit 0, FxTransMMR 0, FxTransJBIG 0,
FxRate Trans, FxUdpEC Red"
```

Table 3-3 describes the T.38 static system data parameters. The T.38 parameters for HSI correspond to T.38 parameters proposed in the ITU T.38 recommendation.

### Configuring T.38 Fax on the Cisco PSTN Gateway

To enable T.38 Fax throughout the system, you must enable T.38 Fax on the Cisco PGW. On the PGW, T.38 is enabled through a trunk group property by use of the following MML command:

```
prov-add:trnkgprpprop:name="2000",FaxSupport="1"
```

### Configuring T.38 Fax on a Cisco IOS H.323 Gateway

Enable T.38 Fax on a Cisco IOS H.323 gateway by issuing the following IOS commands:

```
voice service voip
 fax protocol t38 ls-redundancy 0 hs-redundancy 0 fallback none
```

### Configuring T.38 Fax on a Cisco IOS MGCP Gateway

Enable T.38 fax on a Cisco IOS MGCP gateway by issuing the following IOS commands:

```
voice service voip
 fax protocol t38 ls-redundancy 0 hs-redundancy 0 fallback none
 mgcp package-capability fxr-package
```

Refer to PGW and Cisco IOS documentation at [www.cisco.com](http://www.cisco.com) for further information on these commands.





# Managing the Cisco HSI

## Introduction

This chapter provides information about operation and management tasks for the Cisco H.323 Signaling Interface (HSI) application. This chapter contains the following sections:

- Restarting the Cisco HSI Application, page 4-1
- Stopping Call Processing, page 4-1
- Starting Call Processing, page 4-2
- Stopping the Call Processing Application, page 4-2
- Starting the Call Processing Application, page 4-2
- Reporting the Cisco HSI Status, page 4-2
- Measurements, page 4-2
- Overload, page 4-6
- Logging, page 4-8
- Gapping, page 4-11

## Restarting the Cisco HSI Application

To restart the Cisco HSI at the MML command prompt, use the **restart-softw** MML command. For more information about this command, see Appendix A, “MML User Interface and Command Reference.”

To start the Cisco HSI application, see the “Starting the Cisco HSI” section on page 2-10.

## Stopping Call Processing

To stop call processing, use the **stp-callproc** MML command. This command causes the handling of new call requests to cease immediately, and, if no timeout period is specified, all existing calls are released immediately. If a timeout period is specified, existing calls are released after the specified amount of time has elapsed. For more information about the **stp-callproc** command, see Appendix A, “MML User Interface and Command Reference.”

## Starting Call Processing

To start call processing, use the **sta-callproc** MML command. For more information about this command, see Appendix A, “MML User Interface and Command Reference.”

## Stopping the Call Processing Application

To stop the call processing application, use the **stp-softw** MML command. For more information about this command, see Appendix A, “MML User Interface and Command Reference.”

## Starting the Call Processing Application

To start the call processing application, use the **sta-softw** MML command. For more information about this command, see Appendix A, “MML User Interface and Command Reference.”

## Reporting the Cisco HSI Status

To display the status of the Cisco HSI, use the **rtrv-softw** MML command. For more information about this command, see Appendix A, “MML User Interface and Command Reference.”

## Measurements

The following sections describe two measurement categories:

- System-related measurements
- Call-related measurements

### System-Related Measurements

The CIagent is a Simple Network Management Protocol (SNMP) subagent. It handles the collection and storage of the following system performance measurements:

- CPU occupancy
- RAM occupancy
- Disk occupancy
- TCP usage

Use the CIAGENTSCANPERIOD parameter to define the period that the CIagent polls the CPU for utilization (see Chapter 3, “Provisioning the Cisco HSI”).



## Call-Related Measurements

The Cisco HSI application handles all call-related measurements. An SNMP MIB handles the collection of call-related measurement data.

The call-related measurements are organized into counter groups. The following MML counter groups are required:

- RAS (see Table 4-1 on page 4-3)
- Q.931 (see Table 4-2 on page 4-4)
- H.245 (see Table 4-3 on page 4-5)

The measurements in these groups are written to a file on disk every 30 minutes. The file name includes the date and time that measurements were written to disk.

**Table 4-1 RAS Counter Group**

| Counter Name         | Measurement                           | Type    | Comments                                                                                     |
|----------------------|---------------------------------------|---------|----------------------------------------------------------------------------------------------|
| GK_DISC_ATT_TOT      | Gatekeeper discovery attempts         | Integer | Incremented for every unicast gatekeeper request (GRQ) sent or for every multicast operation |
| GK_REG_ATT_TOT       | Registration request attempts         | Integer | Incremented for every registration request (RRQ) sent                                        |
| GK_REG_SUCC_TOT      | Registration request successes        | Integer | Incremented for every registration confirmation (RCF) received                               |
| GK_RCV_UNR_ATT_TOT   | G- initiated unregistration attempts  | Integer | Incremented for every unregistration request (URQ) received from a gatekeeper (GK)           |
| GK_XMIT_UNR_SUCC_TOT | GK-initiated unregistration successes | Integer | Incremented for every unregistration confirmation (UCF) sent to a GK                         |
| GK_XMIT_UNR_ATT_TOT  | T- initiated unregistration attempts  | Integer | Incremented for every URQ sent to a GK                                                       |
| GK_RCV_UNR_SUCC_TOT  | T- initiated unregistration successes | Integer | Incremented for every UCF received from a GK                                                 |
| GK_RLS_ATT_TOT       | Disengage attempts                    | Integer | Incremented for every disengage request (DRQ) sent to a GK                                   |
| GK_RLS_SUCC_TOT      | Disengage successes                   | Integer | Incremented for every disengage confirmation (DCF) returned by a GK                          |
| GK_INFO_REPORT_TOT   | Information reports                   | Integer | Incremented for every information request (IRQ) sent to the GK                               |

Table 4-2 Q.931 Counter Group

| Counter Name         | Measurement                                | Type    | Comments                                                                                                                                                                        |
|----------------------|--------------------------------------------|---------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FC_INC_CALL_ATT_TOT  | H.225 Incoming Fast Connect Call Attempts  | Integer | Incremented when a setup containing the fastStart element is received.                                                                                                          |
| FC_INC_CALL_SUCC_TOT | H.225 Incoming Fast Connect Call Successes | Integer | Incremented when the Fast Connect procedure is used to establish an incoming H.323 call.                                                                                        |
| FC_OTG_CALL_ATT_TOT  | H.225 Outgoing Fast Connect Call Attempts  | Integer | Incremented when a setup containing the fastStart element is sent to an H.323 endpoint.<br>Decrementd when you revert to Version 1 signaling (another measurement incremented). |
| FC_OTG_CALL_SUCC_TOT | H.225 Outgoing Fast Connect Call Successes | Integer | Incremented when the Fast Connect procedure is used to establish an outgoing H.323 call.                                                                                        |
| V1_INC_CALL_ATT_TOT  | H.225 Incoming Version 1 Call Attempts     | Integer | Incremented when an incoming H.323 Version 1 Setup is received. (That is, no fastStart element or H.245 tunneling.)                                                             |
| V1_INC_CALL_SUCC_TOT | H.225 Incoming Version 1 Call Successes    | Integer | Incremented when an incoming H.323 Version 1 call is established.                                                                                                               |
| V1_OTG_CALL_ATT_TOT  | H.225 Outgoing Version 1 Call Attempts     | Integer | Incremented when an outgoing H.323 call reverts to Version 1 signaling.                                                                                                         |
| V1_OTG_CALL_SUCC_TOT | H.225 Outgoing Version 1 Call Successes    | Integer | Incremented when an outgoing H.323 call using Version 1 is established.                                                                                                         |
| INC_NORM_REL_TOT     | H.225 Incoming Call Normal Releases        | Integer | Incremented when an established incoming H.323 call is taken down due to user on-hook                                                                                           |
| INC_ABNORM_REL_TOT   | H.225 Incoming Call Abnormal Releases      | Integer | Incremented when an established incoming H.323 call is taken down due to anything other than user on-hook                                                                       |
| OTG_NORM_REL_TOT     | H.225 Outgoing Call Normal Releases        | Integer | Incremented when an established outgoing H.323 call is taken down due to user on-hook.                                                                                          |
| OTG_ABNORM_REL_TOT   | H.225 Outgoing Call Abnormal Releases      | Integer | Incremented when an established outgoing H.323 call is taken down due to anything other than user on-hook.                                                                      |
| PGW_T38_FAX_ATT_TOT  | Q931                                       | Integer | Incremented for each T.38 Fax Call request from the PGW. Collection Intervals are provisionable (default is 12 hours).                                                          |
| PGW_T38_FAX_SUCC_TOT | Q931                                       | Integer | Incremented for each T.38 Fax Call request from the PGW that is successfully reconfigured for T.38. Collection Intervals: Provisionable (default 12 hours)                      |
| H323_INTERWORK_SUCC_ | Q931                                       | Integer | Incremented for each successful H.323-H.323 interworking condition. Collection Intervals are provisionable (default is 12 hours).                                               |

Table 4-3 H.245 Counter Group

| Counter Name           | Measurement                                  | Type         | Comments                                                                                                                                                                              |
|------------------------|----------------------------------------------|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| MASTER_SLAVE_ATT_TOT   | H.245 Master Slave Determination Attempts    | Integer      | Incremented whenever either side of the call initiates the master slave determination procedure (using either H.245 tunneling or a separate H.245 signaling path).                    |
| MASTER_SLAVE_SUCC_TOT  | H.245 Master Slave Determination Successes   | Integer      | Incremented whenever a master slave determination procedure is completed.                                                                                                             |
| TERM_CAP_XCHG_ATT_TOT  | H.245 Terminal Capability Exchange Attempts  | Integer      | Incremented whenever either side of the call initiates the capability exchange procedure (using either H.245 tunneling or a separate H.245 signaling path).                           |
| TERM_CAP_XCHG_SUCC_TOT | H.245 Terminal Capability Exchange Successes | Integer      | Incremented whenever a capability exchange procedure is completed.                                                                                                                    |
| OPEN_CH_ATT_TOT        | H.245 Open Logical Channel Attempts          | Integer      | Incremented whenever either side of the call initiates the open logical channel procedure (using either H.245 tunneling or a separate H.245 signaling path).                          |
| OPEN_CH_SUCC_TOT       | H.245 Open Logical Channel Successes         | Integer      | Incremented whenever an open logical channel procedure is completed.                                                                                                                  |
| CLOSE_CH_ATT_TOT       | H.245 Close Logical Channel Attempts         | Integer      | Incremented whenever either side of the call initiates the close logical channel procedure (using either H.245 tunneling or a separate H.245 signaling path).                         |
| CLOSE_CH_SUCC_TOT      | H.245 Close Logical Channel Successes        | Integer      | Incremented whenever a close logical channel procedure is completed.                                                                                                                  |
| AVG_ROUND_TRIP_DELAY   | H.245 Round Trip Delay Determination         | Average (ms) | The average time in milliseconds (ms) for round trip delay measured as a result of successful round trip delay determination procedures.                                              |
| EMPTY_CAP_SET_TOT      | H245                                         | Integer      | Incremented each time an empty cap set request is received from the remote peer. Collection intervals are provisionable (default is 12 hours).                                        |
| H323_T38_FAX_ATT_TOT   | H245                                         | Integer      | Incremented for each T.38 Fax Call request from the remote peer. Collection intervals are provisionable (default is 12 hours)                                                         |
| H323_T38_FAX_SUCC_TOT  | H245                                         | Integer      | Incremented for each T.38 Fax Call request from the remote peer that is successfully reconfigured for T.38 fax working. Collection intervals are provisionable (default is 12 hours). |

Table 4-3 H.245 Counter Group (continued)

| Counter Name   | Measurement | Type    | Comments                                                                                                             |
|----------------|-------------|---------|----------------------------------------------------------------------------------------------------------------------|
| ASYMMETRIC_TOT | H245        | Integer | Incremented for each asymmetric condition encountered. Collection intervals are provisionable (default is 12 hours). |
| DTMF_RELAY_TOT | H245        | Integer | incremented for each call where DTMF relay is used. Collection intervals are provisionable (default is 12 hours).    |

## Resetting Measurements

The **clr-meas** MML command resets the measurement counters. This command resets an individual counter or all counters in a counter group. The following are valid counter groups:

- RAS
- Q.931
- H.245

For more information about the **clr-meas** command, see Appendix A, “MML User Interface and Command Reference.”

## Retrieving Counters

Use the **rtrv-ctr** MML command to retrieve measurement counters. This command displays the measurements for a counter group. Valid counter groups are RAS, Q.931, and H.245. For more information about the **rtrv-ctr** command, see Appendix A, “MML User Interface and Command Reference.”

## Overload

The system continuously checks call totals and CPU utilization. Each of these values is compared to predefined limits. Three call total limits are available. Each limit has a hysteresis value and an alarm associated with it. When the call total reaches the limit, an alarm is raised. When the call total falls below the limit minus the hysteresis value, the alarm is cleared after the appropriate recovery action is taken.

Cisco HSI supports the following three levels of overload:

- Overload level 1
- Overload level 2
- Overload level 3

The following factors can trigger any one of the overload levels:

- CPU usage (the OVLDSAMPLERATE parameter defines the frequency of CPU sampling and threshold checking)
- Maximum calls allowed

Disk usage can trigger a LOW\_DISK\_SPACE alarm. For more information about this alarm, see Chapter 5, “Troubleshooting Cisco HSI Alarms.”

## Overload Level 1

Use the following configuration parameters for overload level 1 (see Chapter 3, “Provisioning the Cisco HSI”):

- OVLDLEVEL1PERCENT
- OVLDLEVEL1FILTER
- OVLDLEVEL1THRESHLOWERCALLS
- OVLDLEVEL1THRESHUPPERCALLS
- OVLDLEVEL1THRESHLOWERCPU
- OVLDLEVEL1THRESHUPPERCPU

## Overload Level 2

Use the following configuration parameters for overload level 2 (see Chapter 3, “Provisioning the Cisco HSI”):

- OVLDLEVEL2PERCENT
- OVLDLEVEL2FILTER
- OVLDLEVEL2THRESHLOWERCALLS
- OVLDLEVEL2THRESHUPPERCALLS
- OVLDLEVEL2THRESHLOWERCPU
- OVLDLEVEL2THRESHUPPERCPU

## Overload Level 3

Use the following configuration parameters for overload level 3 (see Chapter 3, “Provisioning the Cisco HSI”):

- OVLDLEVEL3PERCENT
- OVLDLEVEL3FILTER
- OVLDLEVEL3THRESHLOWERCALLS
- OVLDLEVEL3THRESHUPPERCALLS
- OVLDLEVEL3THRESHLOWERCPU
- OVLDLEVEL3THRESHUPPERCPU

## Setting Overload Data

The following MML commands set overload data:

```
set-overload:level1|level2|level3:cpu, lower=number, upper=number
```

**set-overload:level1|level2|level3:calls, lower=*number*, upper=*number***

**set-overload:level1|level2|level3:gap, filter=*normal|all*, percent=*number***

The upper parameter specifies the threshold for overload detection, and the lower parameter specifies the hysteresis point at which the overload condition is removed.

The lower value should be greater than the upper value of the next lower severity level.

For example:

**set-overload:level1:cpu, lower=45, upper=50**

**set-overload:level1:gap, filter=normal, percent=50**

**set-overload:level2:cpu, lower=63, upper=70**

**set-overload:level2:gap, filter=normal, percent=75**

**set-overload:level3:cpu, lower=81, upper=90**

**set-overload:level3:gap, filter=normal, percent=95**

These values mean that:

- At less than 50 percent CPU usage, no call is gapped.
- From 50 percent to 70 percent CPU usage, 50 percent of calls are gapped.
- From 70 percent to 90 percent CPU usage, 75 percent of calls are gapped.
- At more than 90 percent CPU usage, 95 percent of calls are gapped.
- Before the overload level returns from level 3 to level 2, the CPU usage must fall to less than 81 percent.

## Retrieving Overload Data

Use the **rtrv-overload** MML command to display the overload status and related overload data. For information about this command, see Appendix A, “MML User Interface and Command Reference.”

## Logging

The logging level of one or more service packages is set using the **set-log** MML command. For more information about this command, see Appendix A, “MML User Interface and Command Reference.”

## Rotating Log Files

Log files are rotated at system startup or when either of the following conditions occurs:

- The size limit for the corresponding file is reached. The size of the corresponding log file is equal to or greater than the value that the LOGFILEROTATESIZE configuration parameter specifies. The default value for this parameter is 10 Mb (see Chapter 3, “Provisioning the Cisco HSI”).
- The age limit for the corresponding file is reached. The corresponding log file is equal to or older than the interval that the LOGFILEROTATEINTERVAL parameter specifies. The default value for this parameter is 1440 minutes (24 hours). See Chapter 3, “Provisioning the Cisco HSI,” for more information about this parameter.

## Convention for Naming Convention the Log File

Log rotation occurs when the system ceases to write to the current log file and commences to write to a new log file. The LOGFILENAMEPREFIX parameter defines the name of the active log file (see Chapter 3, “Provisioning the Cisco HSI”). The default is platform.log.

When log rotation is triggered, the existing file (for example, platform.log) is renamed with the format *platform\_yyyymmddhhmmss.log* (see Table 4-4). For example, a platform error file rotated on September 30, 1999 at 12:36:24 is renamed platform\_19990930123624.

**Table 4-4 Log Filename Format**

| Format            | Definition                                     |
|-------------------|------------------------------------------------|
| LOGFILENAMEPREFIX | Provisioned filename (default is platform.log) |
| yyyy              | Year                                           |
| mm                | Month                                          |
| dd                | Day                                            |
| hh                | Hour                                           |
| mm                | Minute                                         |
| ss                | Second                                         |



**Note**

The time stamp is the coordinated universal time (CUT) from the machine at the time of rotation.

## Log File Location

The LOGDIRECTORY parameter defines the directory for active log files and rotated log files (see Chapter 3, “Provisioning the Cisco HSI”). The default is \$GWHOME/var/log/.

## Log Messages

Log messages have the following format:

*Date and timestamp, Package Name, <log level>, LogID:<text of the message>.*

The following are examples of log messages:

```
Thu Dec 7 03:55:32:837 2000, Infrastructure, <DEBUG>, 205: GWModule Registration -
shutdownList() - NbOfItems 10 - Item 8
Thu Dec 7 03:55:32:837 2000, Infrastructure, <DEBUG>, 206 : GWModuleRegistration -
shutdownList() - NbOfItems 10 - Item 9
Thu Dec 7 03:55:32:838 2000, Infrastructure, <DEBUG>, 207 : GWReactor::thdId() returns 6.
Thu Dec 7 03:55:32:838 2000, Infrastructure, <DEBUG>, 208 : GWReactorModule::shutdown() -
Thread has joined.
```

## Log Message Packages

The following service packages can log messages:

- Application
- CallControl
- Connection
- DataManager
- Eisup
- FaultManager
- Gapping
- H323
- Infrastructure
- Overload
- ProcessManager
- Provisioning
- Signal
- Snmp
- SnmpSubagent
- Statistics
- Trace
- UserInterface

## Logging Levels

Logging levels determine how much debug information is stored in the platform.log file for each package. Levels are set through use of a hexadecimal number between 0x0000 and 0xFFFF. 0x0000 is the lowest level, and switches off logging for a particular package. 0xFFFF is the highest logging level.

**Note**

---

We strongly recommend that you set all packages to log level 0x0000 in a live network. Set them to higher levels only when you debug on an offline network.

---

## Setting Logging Levels

The **set-log** MML command dynamically alters the log level setting during the execution of the system. However, the **set-log** MML command does not affect the logging level of any current MML processes. For more information about the **set-log** command, see Appendix A, “MML User Interface and Command Reference.”

**Note**

---

The enabling of logging severely impacts HSI performance. We recommend the HSI be running at less than 2 calls per second when you enable logging. Logging will be automatically disabled when the HSI enters overload level 3. You can reenabling logging when the HSI exits overload.

---



## RADVision Logging

The Cisco HSI application provides the capability (through MML) to initiate RADVision logging. The contents of the resultant log file are not under the control of the Cisco HSI application.

Use the **radlog** MML command to start and stop RADVision logging. RADVision logging can be directed to a file or into the standard logging output. For information about this command, see Appendix A, “MML User Interface and Command Reference.”

## Gapping

The gapping level can be set from 0 to 100 percent. From 0 to 99 percent, the call type (normal or priority) is checked against the gapping level call status type. At 100 percent gapping, all calls are gapped regardless of call type.

## Setting Gapping

To activate call gapping, complete the following steps:

- 
- Step 1** Determine the direction of the call to be gapped:
- Incoming (inc) for calls originating from the H.323 network
  - Outgoing (otg) for calls originating from the PSTN Gateway (PGW 2200)
  - Both (both) for calls originating from either side
- Step 2** Determine what type of calls are to be gapped:
- Normal calls (nonpriority calls)
  - All calls
- Step 3** Determine the percentage of calls to be gapped. The percentage can range from 0 to 100 percent. If 100 percent is selected, all calls are gapped, regardless of the type of call.
- Step 4** Enter the **set-gapping** MML command. For example, to gap 60 percent of all calls for both directions, enter:
- ```
set-gapping:both:calltype=all,percent=60
```
-

Retrieving Call Gapping Data

To retrieve the current levels of call gapping for all gapping clients, enter the **rtrv-gapping** command. The command displays text similar to the following:

Client Name	Direction	Level	Call Type	Active
Overload	Outgoing	10	Normal	No
Overload	Incoming	10	Normal	No
MML	Outgoing	20	All	Yes
MML	Incoming	30	All	Yes

The output shows the gapping levels set by the overload function and the MML command **set-gapping**. The highest gapping level is used as the level to gap calls, which is indicated as Yes in the column titled Active. In this example, the MML levels for outgoing and incoming calls are active.



Troubleshooting Cisco HSI Alarms

Introduction

This chapter contains information about Cisco H.323 Signaling Interface (HSI) alarms, troubleshooting procedures for these alarms, and information about detailed logging. This chapter contains the following sections:

- Alarms Overview, page 5-1
- Retrieving Alarm Messages, page 5-3
- Acknowledging and Clearing Alarms, page 5-4
- Troubleshooting, page 5-6
- Detailed Logging, page 5-16

Alarms Overview

An alarm can be in one of the following states:

- Raised, when a persistent fault occurs in the system
- Cleared, when the fault is fixed

Debounce

The alarms have a timeout (debounce) period. The debounce period is the time that elapses before an alarm condition is accepted. Use the `ALARMDEBOUNCETIME` parameter to set the debounce period (see Chapter 3, “Provisioning the Cisco HSI”). The default debounce period is 0.

Alarm Severity Levels

The Cisco HSI generates autonomous messages, or events, to notify you of problems or atypical network conditions. Depending on the event severity level, events are considered alarms or informational events. Table 5-1 lists the severity levels and the required responses.

Table 5-1 Alarm Severity Levels

Severity Level	Description
Critical	A serious problem exists in the network. Clear critical alarms immediately. A critical alarm should force an automatic restart of the application.
Major	A disruption of service has occurred. Clear this alarm immediately.
Minor	No disruption of service has occurred, but clear this alarm as soon as possible.
Informational	An abnormal condition has occurred. It is transient and does not require corrective action. (An invalid protocol call state transition is an example of an event that prompts such an alarm.) No corrective action is required by the management center to fix the problem.

Retrieving and Reporting Alarms

Events with a severity level of critical, major, or minor are classified as alarms and can be retrieved through the Man-Machine Language (MML) interface and a Simple Network Management Protocol (SNMP) manager.

An alarm must be reported when an alarm state changes (assuming the alarm does not have an unreported severity).

Informational Event Requirements

Informational events do not require state changes. An informational event is a warning that an abnormal condition that does not require corrective action has occurred. An invalid protocol call state transition is an example of an informational event. The informational event needs to be reported, but it is transient. No corrective action is required by the management center to fix the problem.

An informational event is reported once, upon occurrence, through the MML and SNMP interfaces. The MML interface must be in the `rtrv-alm:cont` mode for the event to be displayed. The event is not displayed in subsequent `rtrv-alm` commands.

SNMP Trap Types

Alarms have SNMP trap types associated with them. Table 6-2 identifies the trap types.

Table 5-2 SNMP Trap Types

Trap Type	Trap Description
0	No error
1	Communication alarm
2	Quality of service
3	Processing error
4	Equipment error
5	Environment error

Retrieving Alarm Messages

Alarms can be displayed in noncontinuous mode or in continuous mode.

Noncontinuous Mode

To display all current alarms, use the **rtrv-alm**s MML command.

Figure 5-1 shows an example of an alarm message displayed with the **rtrv-alm**s MML command (noncontinuous mode). For more information about the **rtrv-alm**s MML command, see Appendix A, “MML User Interface and Command Reference.”

Figure 5-1 Sample Alarm Message

Node ID	Alarm Category	Severity Level	Displayed only if state=cleared
"H323-GW1:ALM=	"VSC FAILURE"	,SEV=MJ	STATE=CLEARED

The example in Figure 5-1 shows a Cisco Public Switched Telephone Network (PSTN) Gateway (PGW 2200) communication failure on the Cisco HSI that has the node ID H323-GW1. The resulting message is an alarm with a *major* severity level.

Continuous Mode

To display the names of active alarms and new alarm events, use the **rtrv-alm**s:cont MML command.

Table 5-3 defines the message components that are displayed when the **rtrv-alm**s:cont MML command is used. The following is sample output from this command. For more information about the **rtrv-alm**s:cont MML command, see Appendix A, “MML User Interface and Command Reference.”

```

GW Signaling Gateway      2000-12-05 14:19:22
M  RTRV
"H323-GW1: 2000-11-27 11:25:12.259, ** ALM=\"VSC FAILURE\", SEV=MJ"
"H323-GW1: 2000-11-27 11:25:13.259, ALM=\"VSC FAILURE\", SEV=MJ" STATE=CLEARED
"H323-GW1: 2000-11-27 11:25:13.260, ** ALM=\"CONFIGURATION FAILURE\", SEV=MJ"
"H323-GW1: 2000-11-27 11:25:14.011, A^ ALM=\"ENDPOINT CHANNEL INTERFACE FAILURE\", SEV=IF"
"H323-GW1: 2000-11-27 11:25:14.012, A^ ALM=\"ENDPOINT CHANNEL INTERFACE FAILURE\", SEV=IF"

/* Listening for alarm events... (Ctrl-C to stop) */

"H323-GW1: 2000-11-27 11:25:13.259, ** ALM=\"VSC FAILURE\", SEV=MJ"

/* Ctrl-C pressed */

```

Table 5-3 Elements of Continuous Mode Messages

Element	Description
systemId	The name of your device and its identifier.
YYYY-MM-DD	The year, month, and day that the alarm or information event occurred.
hh-mm-ss-ms	The hour, minute, second, and millisecond that the alarm or information event occurred.
severity	<p>The severity level of the alarm or information event. Severity is represented by a two-character indicator with the following meanings:</p> <ul style="list-style-type: none"> • *C—Critical alarm. A critical alarm indicates that a serious problem exists in the network. It causes a restart or reboot of the Cisco HSI. Clear critical alarms immediately. • **—Major alarm. A major alarm indicates the existence of a problem that disrupts service. Clear major alarms immediately. Major alarms differ from critical alarms in that they do not initiate automatic recovery processes. • *^—Minor alarm. A minor alarm indicates the presence of a problem that does not disrupt service. Note and clear minor alarms as soon as possible. • A^—Informational event. An informational event indicates the presence of an atypical network condition, such as a timer expiration, a value that has exceeded preset thresholds, or unexpected response from an end point to a signaling messages sent by the Cisco HSI. • — (Empty spaces in two leftmost columns). The alarm or event has been cleared. “STATE=CLEARED” is displayed.
almCat	<p>Alarm category. A text string that indicates whether the message is an alarm or an informational event and the MML alarm or event message. See Table 5-4 for a list of alarm categories.</p> <p>Note Despite its name, the alarm category field is used for both alarms and informational events.</p>
Acknowledgement	Indicates whether the alarm has been acknowledged.

Acknowledging and Clearing Alarms

To acknowledge that an alarm is recognized but not cleared, use the **ack-alm** MML command. See Appendix A, “MML User Interface and Command Reference,” for more information.

To clear an alarm, use the **clr-alm** MML command. See Appendix A, “MML User Interface and Command Reference,” for more information.

Alarms List

Table 5-4 lists alarms and information events. Troubleshooting information for each of the alarms and information events can be found in the “Troubleshooting” section on page 5-6.

Table 5-4 Alarms and Informational Events

Alarm Event and Reference	Severity Level
H323_STACK_FAILURE, page 5-6	Critical
CONFIGURATION_FAILURE, page 5-6	Major
EISUP_PATH_FAILURE, page 5-7	Major
GATEKEEPER_INTERFACE_FAILURE, page 5-8	—
GENERAL_PROCESS_FAILURE, page 5-8	Major
IP_LINK_FAILURE, page 5-8	Major
LOW_DISK_SPACE, page 5-9	Major
OVERLOAD_LEVEL3, page 5-9	Major
VSC_FAILURE, page 5-10	Major
OVERLOAD_LEVEL2, page 5-11	Minor
CONFIG_CHANGE, page 5-11	Information
ENDPOINT_CALL_CONTROL_INTERFACE_FAILURE, page 5-12	Information
ENDPOINT_CHANNEL_INTERFACE_FAILURE, page 5-12	Information
GAPPED_CALL_NORMAL, page 5-13	Information
GAPPED_CALL_PRIORITY, page 5-13	Information
OVERLOAD_LEVEL1, page 5-14	Information
PROVISIONING_INACTIVITY_TIMEOUT, page 5-14	Information
PROVISIONING_SESSION_TIMEOUT, page 5-15	Information
STOP_CALL_PROCESSING, page 5-15	Information

Troubleshooting

This section provides troubleshooting procedures for the alarms listed in Table 5-4.

H323_STACK_FAILURE

Description

Irrecoverable failure in the RADVision stack. This alarm is reported to the management interface and can be obtained with SNMP.

Severity Level and Trap Type

The severity level is critical. The trap type is 4.

Cause

The H.323 RADVision stack has failed to correctly initialize on an application startup. An automatic application restart is initiated, and the application reverts to the base configuration data.

Troubleshooting

To clear the H.323 stack failure alarm, complete the following steps:

-
- Step 1** Allow the application to restart and revert back to the base configuration data that is known to be reliable.
 - Step 2** Review the H323_SYS parameters in a provisioning session, ensuring that the values are correct and within the memory limits of the machine.
 - Step 3** Use the **prov-cpy** MML command to recommit the new H323_SYS parameters.
 - Step 4** Use the **restart-softw** MML command to initiate a software restart.
 - Step 5** Use the **rtrv-alm**s MML command to check the alarm list to see if the H.323 stack correctly initializes.
-

CONFIGURATION_FAILURE

Description

The configuration has failed. This alarm is reported to the management interface and can be obtained with SNMP.

Severity Level and Trap Type

The severity level is major. The trap type is 4.

Cause

A major error has occurred in the configuration of the software packages. This is a potentially nonrecoverable situation that requires an application restart.

Troubleshooting

To clear the CONFIGURATION_FAILURE alarm, complete the following steps:

-
- Step 1** Use the **restart-softw:init** command to restart the application and revert to the base configuration.
 - Step 2** Review the modified parameters and ensure that the values are correct.
 - Step 3** Use the **prov-cpy** MML command to recommit the new parameters.
 - Step 4** Use the **restart-softw** MML command to initiate a software restart.
 - Step 5** Use the **rtrv-alm**s MML command to check the alarm list to see if the problem has been resolved.
-

EISUP_PATH_FAILURE

Description

A failure of the RUDP layer has occurred. This alarm is reported to the management interface and can be obtained with SNMP.

Severity Level and Trap Type

The severity level is major. The trap type is 4.

Cause

Both IP links A and B to a single Cisco PGW 2200 have gone down.

Troubleshooting

To clear the EISUP_Path_Failure alarm, complete the following steps:

-
- Step 1** Use the **rtrv-dest** command to assess which Cisco PGW 2200 (standby or active) has been lost.
 - Step 2** Check the network connections, cables, and routers for that system.
 - Step 3** Use the **clr-alm**s MML command to attempt to clear the alarm.
-

GATEKEEPER_INTERFACE_FAILURE

This alarm has not been implemented.

GENERAL_PROCESS_FAILURE

Description

A general process failure has occurred. This alarm is reported to the management interface and can be obtained with SNMP.

Severity Level and Trap Type

The severity level is major. The trap type is 4.

Cause

The Cisco HSI (GWmain program) quit unexpectedly (that is, there were no requests to stop or restart the application). The process manager (PMmain) raises the GENERAL_PROCESS_FAILURE alarm so that a trap is sent to the Rambler.

The process manager clears the GENERAL_PROCESS_FAILURE alarm when it restarts the Cisco HSI (GWmain).

Troubleshooting

To trace the problem, look at either the core file or the log files.

IP_LINK_FAILURE

Description

A failure of the IP link has occurred. This alarm is reported to the management interface and can be obtained with SNMP.

Severity Level and Trap Type

The severity level is major. The trap type is 4.

Cause

One of the two links to a single Cisco PGW 2200 has failed.

Troubleshooting

To clear the IP link failure alarm, complete the following steps:

-
- Step 1** Use the **rtrv-dest** command to assess which PGW 2200 (standby or active) has been lost.
 - Step 2** Check the network connections, cables, and routers for that system.
 - Step 3** Use the **clr-alm** MML command to attempt to clear the alarm.
-

LOW_DISK_SPACE

Description

The disk space is low. This alarm is reported to the management interface and can be obtained with SNMP. The alarm automatically clears when the disk usage decreases below the alarm limit.

Severity Level and Trap Type

The severity level is major. The trap type is 4.

Cause

The percentage of disk usage is greater than the alarm limit.

Troubleshooting

To obtain more disk space, remove old versions of installed software that are no longer required, or archive log files from the \$GWHOME/var/log directory, for example.

OVERLOAD_LEVEL3

Description

An overload level 3 condition exists. This alarm is reported to the management interface and can be obtained with SNMP. This alarm automatically clears when the CPU occupancy or the number of active calls drops below the lower limits set in the overload configuration for level 3.

Severity Level and Trap Type

The severity level is major. The trap type is 4.

Cause

The OVERLOAD_LEVEL3 alarm is triggered when the CPU occupancy or the number of active calls rises above the upper limits set in the overload configuration for level 3. Gapping is then initiated.

Troubleshooting

To clear the OVERLOAD_LEVEL3 alarm, complete the following steps:

-
- Step 1** Wait for the number of calls to drop.
 - Step 2** If CPU occupancy remains high, request assistance from the system administrator.
-

VSC_FAILURE

Description

This alarm is derived by the Cisco HSI application from RUDP/SM events. This alarm is reported to the management interface and can be obtained with SNMP.

Severity Level and Trap Type

The severity level is major. The trap type is 5.

Cause

Links to both (active and standby) Cisco PGW 2200s have gone down.

Troubleshooting

To clear the VSC_FAILURE alarm, complete the following steps:

-
- Step 1** Use the **rtrv-dest** command to confirm that links to the Cisco PGW 2200s have gone down.
 - Step 2** Check the network connections, cables, and routers.
 - Step 3** Refer to the *Cisco Media Gateway Controller Software Release 9 Operations, Maintenance, and Troubleshooting Guide* for detailed information about this alarm.
 - Step 4** Use the **clr-alm** command to attempt to clear the alarm.
-

OVERLOAD_LEVEL2

Description

An overload level 2 condition exists. This alarm is reported to the management interface and can be obtained with SNMP. This alarm automatically clears when the CPU occupancy or the number of active calls drops below the lower limits set in the overload configuration for level 2.

Severity Level and Trap Type

The severity level is minor. The trap type is 4.

Cause

The OVERLOAD_LEVEL2 alarm is triggered when the CPU occupancy or the number of active calls rises above the upper limits set in the overload configuration for level 2. Gapping is then initiated.

Troubleshooting

To clear the OVERLOAD_LEVEL2 alarm, complete the following steps:

-
- | | |
|---------------|--|
| Step 1 | Wait for the number of calls to drop. |
| Step 2 | If CPU occupancy remains high, request assistance from the system administrator. |
-

CONFIG_CHANGE

Description

The running configuration has been modified.

Severity Level and Trap Type

The severity level is information. The trap type is 0.

Cause

A new configuration has been activated within a provisioning session.

Troubleshooting

This is an informational event.

ENDPOINT_CALL_CONTROL_INTERFACE_FAILURE

Description

An individual call failure has occurred. This informational event is reported to the management interface and can be obtained with SNMP.

Severity Level and Trap Type

The severity level is information. The trap type is 3.

Cause

The RADVision stack reports this alarm.

Troubleshooting

This is an informational event.

ENDPOINT_CHANNEL_INTERFACE_FAILURE

Description

An individual call failure has occurred. This informational event is reported to the management interface and can be obtained with SNMP.

Severity Level and Trap Type

The severity level is information. The trap type is 3.

Cause

The RADVision stack reports this alarm.

Troubleshooting

This is an informational event.

GAPPED_CALL_NORMAL

Description

A normal call has been rejected due to call gapping. This informational event is reported to the management interface and can be obtained with SNMP.

Severity Level and Trap Type

The severity level is information. The trap type is 2.

Cause

The GAPPED_CALL_NORMAL alarm is triggered when gapping levels cause a normal call to be rejected.

Troubleshooting

To clear the GAPPED_CALL_NORMAL informational event, complete the following steps:

-
- Step 1** Use the **rtrv-gapping** MML command to retrieve gapping information.
 - Step 2** If the MML-specific gap levels are active, use the **set-gapping** MML command to modify them.
 - Step 3** If the overload-specific gap levels are active, either modify the provisioned overload gapping percent levels or reduce the cause of the overload (see OVERLOAD_LEVEL1, page 5-14, OVERLOAD_LEVEL2, page 5-11, and OVERLOAD_LEVEL3, page 5-9).
-

GAPPED_CALL_PRIORITY

Description

A priority or emergency call has been rejected due to call gapping. This informational event is reported to the management interface and can be obtained with SNMP.

Severity Level and Trap Type

The severity level is information. The trap type is 2.

Cause

The GAPPED_CALL_NORMAL alarm is triggered when gapping levels cause a priority or emergency call to be rejected.

Troubleshooting

To clear the GAPPED_CALL_PRIORITY informational event, complete the following steps:

-
- Step 1** Change the MML gapping levels to less than 100 percent and change the call type to normal.
 - Step 2** Change the provisioned overload call filter type to normal.
-

OVERLOAD_LEVEL1

Description

An overload level 1 condition exists. This informational event is reported to the management interface and can be obtained with SNMP.

Severity Level and Trap Type

The severity level is information. The trap type is 4.

Cause

The OVERLOAD_LEVEL1 alarm is triggered when the CPU occupancy or the number of active calls rises above the upper limits set in the overload configuration for level 1. Gapping is then initiated.

Troubleshooting

To clear the OVERLOAD_LEVEL1 informational event, complete the following steps:

-
- Step 1** Wait for the number of calls to drop.
 - Step 2** If CPU occupancy remains high, request assistance from the system administrator.
-

PROVISIONING_INACTIVITY_TIMEOUT

Description

A provisioning session has been inactive for 20 minutes. The text of the output is:

```
"H323-GW1:2001-01-30 11:12:57.421,A^ ALM=\ "PROVISIONING INACTIVITY TIMEOUT\ ",SEV=IF"
```

Severity Level and Trap Type

The severity level is information. The trap type is 3.

Cause

The provisioning session has been inactive for 20 minutes. The provisioning session will be closed if there is no activity within the next 5 minutes.

Troubleshooting

Ensure that activity in the provisioning session occurs at least every 20 minutes.

PROVISIONING_SESSION_TIMEOUT

Description

The current session has been terminated. The text of the output is:

```
"H323-GW1:2001-01-30 11:17:57.422,A^ ALM=\ "PROVISIONING_SESSION_TIMEOUT\ ",SEV=IF"
```

Severity Level and Trap Type

The severity level is information. The trap type is 3.

Cause

The provisioning session has been inactive for longer than the time allowed.

Troubleshooting

Ensure that activity within the provisioning session occurs at least every 20 minutes.

STOP_CALL_PROCESSING

Description

A stop call processing request has been entered through the MML.

Severity Level and Trap Type

The severity level is information. The trap type is 4.

Cause

A user has entered the **stp-callproc** command through the MML.

Troubleshooting

This is an informational event.

Detailed Logging

Logging occurs on 16 different levels for each package, and the logging mask (which is a 16-bit number from 0x0000 to 0xFFFF) allows each specific log level to be turned on and off. The most-significant-bit positions correspond to higher (that is, more processor intensive) levels of debugging.

We recommend that you set the logging level of all packages to 0x0000 in a live network. For debugging a single call in an off-line network, the recommended level of debug is:

- Set Eisup, CallControl, and H323 package log levels to 0xFFFF.
- Set all other package log levels to 0x0000.
- Turn radlog on by entering the MML command **radlog::start**.

Once the test call has been made, remember to set all the logging levels back to 0x0000 and to turn radlog off by entering the MML command **radlog::stop**.



MML User Interface and Command Reference

Introduction

This chapter provides information about Man-Machine Language (MML) command syntax and conventions, batch files, and procedures for starting and stopping MML sessions in the Cisco H.323 Signaling Interface (HSI) application. The chapter contains the following sections:

- Starting an MML Command Session in the Cisco HSI, page A-1
- MML Commands, page A-2
- Starting an MML Session, page A-3
- Batch Files, page A-3
- MML Responses, page A-5
- MML Help, page A-6
- Quitting an MML Session, page A-6

Starting an MML Command Session in the Cisco HSI

To start an MML command session within the HSI environment, complete the following steps:

-
- Step 1** Log in to Cisco HSI as mgusr.
 - Step 2** Become superuser by typing `su <root password>`.
 - Step 3** To start the software, enter the following command:
`/etc/init.d/CiscoGW start`
 - Step 4** Exit out of superuser.
 - Step 5** Type `mml` to start the MML command-line interpreter.



Tip

Press the **Tab** key twice to see a list of MML commands.

MML Commands

To execute MML commands, log in to Cisco HSI and perform one of the following tasks:

- Start the MML session (see the “Starting an MML Session” section on page A-3) and enter a command.
- Type a batch file command to start an MML session (see the “Starting a Batch File” section on page A-4).

MML Command Syntax

MML commands use the following syntax:

```
command_name:target:[Parameter_List][;comments]
```

Parameter_List consists of a parameter name, an equal sign, and a value for the parameter.

The keywords and the value strings need not be enclosed in quotation marks. Anything you enter after a semicolon (;) is treated as a comment. Use only one MML command on each line.

The “MML Command Reference” section on page A-6 contains detailed information about the individual MML commands.



Tip

- Use the **Up Arrow** key to scroll through all previous MML commands in turn.
- Use the **Down Arrow** key to move forward in the command buffer.
- Use the **Left** and **Right Arrow** keys to move along the command line.
- Use the **Backspace**, **Delete**, and alphanumeric keys to edit an MML command.

MML Command Conventions

The MML commands use the conventions shown in Table A-1.

Table A-1 MML Command Conventions

Convention	Meaning	Comments and Examples
Square brackets ([])	Optional elements	command [abc] abc is optional (not required), but you can choose it.
Vertical bars ()	Separated alternative elements	command [abc def] You can choose either abc or def, or neither, but not both.
Braces ({ })	Required choice of alternative elements	command {abc def} You must use either abc or def, but not both.
Angle brackets (< >)	Symbol specifier	—

The MML commands can be interpreted and monitored through a network Transaction Language 1 (TL1) interface. The TL1 symbols shown in Table A-2 are used in MML

Table A-2 TL1 Symbols Used in MML

Symbol	Description
:	A parameter separator.
::	An empty parameter block.
&	Arguments are grouped together so that one parameter can convey several arguments.
;	End of command (optional). Anything on the same line after this symbol is treated as a comment.

Case Sensitivity

Command names and parameter names are not case sensitive. You can enter commands and parameters in either upper- or lowercase. Filenames *are* case sensitive when they are used as arguments in MML commands.

Starting an MML Session

To start an MML session, complete the following steps:

-
- Step 1** Log in to Cisco HSI.
- Step 2** Type one of the following commands at the prompt:
- **mml**
 - **mml -b batchfile** (see the “Starting a Batch File” section on page A-4)
-

The following example shows the start of an MML session:

```
user@host> mml

Welcome to the Cisco H.323 Signaling Interface.

gw mml>
```

Batch Files

The Cisco HSI application supports the use of batch files. You can create an ASCII file of MML provisioning commands for use as a batch file. You can also use a script file. When the commands are read, the Cisco HSI executes them sequentially.

The following is an example of an MML provisioning batch file:

```
prov-sta::srcver="new",dstver="first"
prov-add:name="sys_config",nodeid="H323-GW1"
prov-add:name="h323_sys",messages=30000,channels=5000
```

```
prov-add:name="ras",responsetimeout=10,allowcallswhennonreg=1
prov-add:name="ras",terminaltype="gateway",timetolive=900
prov-add:name="q931",reponsetimeout=20,connecttimeout=20,maxcalls=5000
prov-cpy
```

The **prov-sta** command establishes a provisioning session. The **prov-cpy** command copies configuration settings from the current provisioning session to the Cisco HSI and activates the configuration. If the command is successful, it also terminates the current provisioning session. If you are not ready to commit a session, use the **prov-stp** command to save and stop the provisioning session.

The application provides a log function (**diaglog** command) that records the MML commands and responses in a log file.

In the MML batch file, you can place a **diaglog** command at the beginning to start logging and a **diaglog** command at the end to stop logging. For more information about the **diaglog** command, see the “MML Command Reference” section on page A-6

For commands executed in both the process manager and the application, the application logs the user ID, the login date and time, and the name of each command that is executed in batch mode to the `mml_batch_log` file.

**Note**

Batch files can be defined for complete systems or to modify parts of an existing system.

Creating a Batch File

To create a batch file, use an ASCII text editor program to create a new file. Each command should be on a separate line.

Starting a Batch File

To start executing a batch file, type **mml -b *batchfilename*** at the UNIX prompt.

After you enter the batch file command, the application displays the result of each MML command as it is executed. Each command and its results are saved in the `mml.log` file. When the batch file is completed, the MML session is ready to accept user commands.

The following example shows the start of a batch file named `nolog.bat` with these contents:

```
prov-sta:srcver=active,dstver=nolog
prov-ed:name=logging,eisup=0x0000
prov-cpy
```

and this output:

```
gp-capetown-16-> mml -b nolog.bat
Starting in batch mode.
Connecting to port 10129 on host gp-capetown
```

```
Welcome to the Cisco H.323 Signaling Interface.
gw mml> gw mml> prov-sta:srcver=active,dstver=nolog
H323 Signaling Interface Tue Jan 22 05:57:12 2002
M SUCC
Successfully started provisioning session "nolog" from "active".Note: This provisioning
session has not been verified.
gw mml> prov-ed:name=logging,eisup=0x0000
H323 Signaling Interface Tue Jan 22 05:57:12 2002
M SUCC
```

```

Successfully edited provisioning element(s):
MML Name : logging.
Parameter: EISUP.
Value : 0x0000.
gw mml> prov-cpy
H323 Signalling Gateway Tue Jan 22 05:57:13 2002
M SUCC
Successfully activated provisioning session nolog.
gw mml>

```

MML Responses

The following sections describe the two types of response messages that are displayed by the MML user interface:

- Status messages
- Error messages

Status Messages

Table A-3 lists the MML status messages and their descriptions.

Table A-3 MML Status Messages and Descriptions

Status	Message	Description
RTRV	Retrieve	Retrieve and display the contents of the specified file
SUCC	Successful	Successful completion

Error Messages

If an MML command does not perform, an error message is displayed. Table A-4 lists the MML error messages and their descriptions.

Table A-4 MML Error Messages and Descriptions

Error Message	Definition	Description
DENY	Command denied	The system recognizes the command but does not perform the requested function.
ICNV	Input command not valid	The system does not recognize the MML command.
IDNV	Input data not valid	An unknown parameter was entered.
IISP	Input syntax error	Incorrect syntax was entered.
IITA	Invalid target	The system cannot perform the requested operation on the specified component, or the component does not exist.
IPRM	Input parameter missing	An expected parameter was not entered.

Table A-4 MML Error Messages and Descriptions (continued)

Error Message	Definition	Description
SABT	Status abort	The requested operation did not complete within the allotted time.
SNVS	Component not in valid state	The requested operation failed because the component is either not configured to accept the operation or the component is already in the desired state.
SNSP	State not supported	The operation is not supported by the component.
SROF	Status requested operation failed	The requested operation failed.

MML Help

MML has an online help feature. The MML **help** command displays a list of valid system commands and an explanation of each command's use. To display the online help, start an MML session and type **help** at the command line prompt. See the "help" section on page A-11.

Quitting an MML Session

To quit an MML session, type **quit** at the prompt.

MML Command Reference

This section describes the following MML commands:

- **ack-alm**
- **clr-alm**
- **clr-meas**
- **diaglog**
- **h**
- **help**
- **prov-add**
- **prov-cpy**
- **prov-dlt**
- **prov-ed**
- **prov-exp**
- **prov-rtrv**
- **prov-sta**
- **prov-stp**

- **quit**
- **radlog**
- **restart-softw**
- **rtrv-alms**
- **rtrv-calls**
- **rtrv-ctr**
- **rtrv-dest**
- **rtrv-gapping**
- **rtrv-log**
- **rtrv-mml**
- **rtrv-ne**
- **rtrv-ne-health**
- **rtrv-overload**
- **rtrv-softw**
- **set-dest-state**
- **set-gapping**
- **set-log**
- **set-overload**
- **sta-callproc**
- **sta-softw**
- **sta-trc**
- **stp-call**
- **stp-callproc**
- **stp-softw**
- **stp-trc**

ack-alm

The **ack-alm** command acknowledges that an alarm event is recognized but does not clear the alarm.

ack-alm:event=alarm event

Syntax Description

<i>alarm event</i>	The alarm category or the text that appears in the body of the alarm. Alarm event names are defined in Chapter 5, “Troubleshooting Cisco HSI Alarms.”
--------------------	---

Usage Guidelines

The format of the alarm category name must be the same as the format of the alarm category name that the **rtrv-arms** command displays. It is case sensitive.

Examples

This example recognizes the **VSC_FAILURE** alarm event is recognized, but the alarm is not cleared:

```
gw mml> ack-alm:event=VSC_FAILURE

GW Signaling Interface    2000-12-05 14:19:22
M   SUCC

mml>
```

Related Commands

Command	Description
clr-alm	Clears an alarm event
rtrv-arms	Displays all active alarms

clr-alm

The **clr-alm** command clears an alarm event.

clr-alm:event=alarm event

Syntax Description

<i>alarm event</i>	The alarm event name or the text that appears in the body of the alarm. Alarm names are defined in Chapter 5, “Troubleshooting Cisco HSI Alarms.”
--------------------	---

Usage Guidelines

The alarm category must match the format shown in the alarm when the **rtrv-arms** command displays it. It is case sensitive.

Examples

This example clears the alarm event **VSC_FAILURE**.

```
gw mml> clr-alm:event=VSC_FAILURE
```

```
GW Signaling Interface    2000-12-05 14:19:22
M    SUCC

mml>
```

Related Commands	Command	Description
	ack-alm	Acknowledges that an alarm event is recognized but does not clear the alarm.
	rtrv-alms	Displays all active alarms

clr-meas

The **clr-meas** command resets a measurement counter.

clr-meas:counter group:name=measurement name

clr-meas:counter group

Syntax Description	counter group	Description
		Valid counter groups are: <ul style="list-style-type: none"> • RAS • Q931 • H245
	<i>measurement name</i>	For a list of measurement names, see Table 4-1, Table 4-2, and Table 4-3.

Examples

In this example, a measurement counter, GK_DISC_ATT_TOT (Gatekeeper Discovery Attempts), is reset in the counter group RAS:

```
gw mml> clr-meas:RAS

GW Signaling Interface    2000-12-05 14:19:22
M    SUCC
mml>

mml> clr-meas:RAS:name=GK_DISC_ATT_TOT

GW Signaling Interface    2000-12-05 14:19:22
M    SUCC
```

Related Commands	Command	Description
	rtrv-ctr	Displays the measurements for a counter group.

diaglog

The **diaglog** command starts and stops event logging into a diagnostics log.

diaglog:*file name*:start | stop

Syntax Description

<i>file name</i>	The user-defined name of the log file. The actual file name has a .log suffix applied. The file is located in the logging directory defined in the configuration data (see Chapter 3, "Provisioning the Cisco HSI").
------------------	--

Examples

In this example, event logging is started in a diagnostics log named **test5**.

```
gw mml> diaglog:test5:start
test5_davek15823_20010130053323.log
```

In the preceding example, davek is the user who runs the command, and 15823 is the process ID of the MML process from which the command is run.

Related Commands

Command	Description
radlog	Starts and stops RADVision logging into a specified log file.
rtrv-log	Displays the logging level of a package or all packages.
set-log	Sets the logging level of a package or all packages.

h

The **h** command redisplay a command or a series of commands. Items displayed depend on a specified number or range. If no number is specified, only the last command is displayed.

h[::start=*number*[,end=*number*]]

Syntax Description

start	Entered as a number; specifies the first command to redisplay.
end	Entered as a number; specifies the end of the range of commands to redisplay.

Examples

The MML command in the following example displays the last successful command entered:

```
mml> h
VSC H-323 Signaling Interface - H323-GW1 2000-06-20 10:04:28
M RTRV
  "rtrv-log:all"
/* command 1 */
```

The MML command in the following example displays the third from the last successful command entered:

```
mml> h::3
VSC H-323 Signaling Interface - H323-GW1 2000-06-20 10:04:28
M RTRV
  "rtrv-ne"
  /* command 3 */
```

The MML command in the following example displays the last and second to last commands entered.

```
mml> h::start=1,end=2
VSC H-323 Signaling Interface - H323-GW1 2000-06-20 10:04:28
M RTRV
  "rtrv-log:all"
  /* command 1 */
  "rtrv-ne"
  /* command 2 */
```

help

The **help** command displays a list of valid system commands and an explanation of their use. If you do not enter a command name as a parameter, the **help** command provides a list of MML commands, descriptions, and values. If you enter a command name as a parameter, a description of that command displays.

help[:*command name*]

Syntax Description

<i>command name</i>	The name of the MML command.
---------------------	------------------------------

Examples

The command shown in the following example displays help for a specific command:

```
mml> help:rtrv-ctr
H323 Signalling Gateway   Tue Feb 12 19:09:58 2002
M SUCC

          RTRV-CTR -- Display the measurements for a counter group
          -----

Purpose:   This MML command displays a measurement counter for a counter group

Format:    rtrv-ctr:<counter group>

Description: * counter group -- The name of an MML counter group (RAS, Q931 or H245)

Example:   The MML command shown in the following example displays measurement
          counters for the counter group RAS.
          mml> rtrv-ctr:ras;
          GW Signalling GateWay 2000-12--5 14:19:32
          M RTRV
          "H323-GW1:GROUP=RAS,NAME=\"GK_DISC_ATT_TOT\",VAL=1000"
          "H323-GW1:GROUP=RAS,NAME=\"GK_REG_ATT_TOT\",VAL=1000"
          "H323-GW1:GROUP=RAS,NAME=\"GK_REG_SUCC_TOT\",VAL=1000"

          mml>
```

If you enter the **help** command without a parameter, the help file displays information about all available commands. The following example shows a portion of the help file that displays if you do not enter a parameter:

```

mml> help

VSC H323 signaling interface - H323-GW1 2000-06-20 10:04:28
M RTRV
Available commands (in alphabetical order):
ack-alm:"<alm cat>" Acknowledges an alarm category on a component
clr-alm:"<alm cat>" Clears an alarm category on a component
clr-meas:"<meas cat>" Resets a measurement category on a component
diaglog:<file name>:START|STOP Starts/stops diagnostics log
h[::<number>[,<number>]] Displays a history of commands for a specified backward number or
range; the last command by default
help[:<command name>] Displays the list of MML commands or the help information on a
specified command
prov-add:name=<MML name>,<param name>=<param value>,... Adds the component
prov-cpy Commits provisioning data
prov-dlt:name=<MML name> Deletes the component

```

prov-add

The **prov-add** command adds a component to the Cisco HSI.

prov-add:name=MML name,param name=param value,...

Syntax Description	MML name	MML name for the element you are adding. Valid MML names are:
		<ul style="list-style-type: none"> • sys_config_static • sys_config_dynamic • h323_sys • ras • h245 • q931
	<i>param name</i>	The name of a valid configuration parameter for the specified name.
	<i>param value</i>	The value you want to assign to the parameter.

Usage Guidelines

To define more than one parameter, enter additional *param name=param value* descriptions on the command line. See Chapter 3, "Provisioning the Cisco HSI," for the list of MML names, parameter names, and their associated values.

Examples

The command shown in the following example adds a provisioning element with the MML name *ras*, parameter name *maxFail*, and value 3:

```

gw mml> prov-add:name=ras,maxfail=3
H323 Signaling Interface Sun Jan 7 15:15:02 2001
M SUCC
Successfully added provisioning element(s):
MML Name : ras.
Parameter: maxFail.
Value : 3.

```

Related Commands	Command	Description
	prov-cpy	Activates the configuration settings in the current provisioning session.
	prov-dlt	Deletes a provisioned component.
	prov-ed	Modifies a provisioned component.
	prov-exp	Exports the current configuration of the Cisco HSI in MML command form to a file or files.
	prov-rtrv	Retrieves information about an existing provisioning session.
	prov-sta	Establishes a provisioning session.
	prov-stp	Terminates either a specified provisioning session or the current provisioning session.

prov-cpy

The **prov-cpy** command copies configuration settings from the current provisioning session to the Cisco HSI to activate the configuration. If this command is successful, it terminates the current provisioning session. If this command fails, there is no active provisioning session. If any client level parsing fails during the data session, a **confirm** is needed for the data to be activated.

prov-cpy[:confirm]

Syntax Description	confirm	If any client level parsing fails during the data session, a confirm is needed for the data to be activated.

Examples

The command shown in the following example copies the configuration changes from the current session to the Cisco HSI:

```
gw mml> prov-cpy
H323 Signaling Interface Sun Jan 7 13:53:42 2001
M SUCC
Successfully activated the provisioning session.
```

Usage Guidelines

See Chapter 3, “Provisioning the Cisco HSI,” for a list of MML names, parameter names, and their associated values.

Related Commands	Command	Description
	prov-add	Adds a component.
	prov-dlt	Deletes a provisioned component.
	prov-ed	Modifies a provisioned component.
	prov-exp	Exports the current configuration of the Cisco HSI in MML command form to a file or files.
	prov-rtrv	Retrieves information about an existing provisioning session.

Command	Description
prov-sta	Establishes a provisioning session.
prov-stp	Terminates either a specified provisioning session or the current provisioning session.

prov-dlt

The **prov-dlt** command deletes a provisioned component. It allows you to delete a parameter rather than deleting the MML group.

prov-dlt:name=MML name

prov-dlt:name=MML name,param=param name

prov-dlt:name=MML name param name

Syntax Description

<i>MML name</i>	MML name for the element you are deleting. Valid MML names are: <ul style="list-style-type: none"> • sys_config_static • sys_config_dynamic • h323_sys • ras • h245 • q931
<i>param name</i>	The name of a valid configuration parameter for the specified name.

Usage Guidelines

See Chapter 3, “Provisioning the Cisco HSI,” for a list of MML names, parameter names, and their associated values.

Examples

The MML command in the following example deletes the ras element:

```
gw mml> prov-dlt:name=ras
H323 Signaling Interface Sun Jan 7 14:13:05 2001
M SUCC
Successfully deleted provisioning data for ras
```

The MML command in the following examples delete the maxCalls parameter of the ras element:

```
gw mml> prov-dlt:name=ras,param=maxCalls
gw mml> prov-dlt:name=ras,maxCalls
H323 Signaling Interface Sun Jan 7 14:46:01 2001
M SUCC
Successfully deleted provisioning data for ras:maxCalls
```


Related Commands	Command	Description
	prov-add	Adds a component.
	prov-cpy	Activates the configuration settings in the current provisioning session.
	prov-ed	Modifies a provisioned component.
	prov-exp	Exports the current configuration of the Cisco HSI in MML command form to a file or files.
	prov-rtrv	Retrieves information about an existing provisioning session.
	prov-sta	Establishes a provisioning session.
	prov-stp	Terminates either a specified provisioning session or the current provisioning session.

prov-ed

The **prov-ed** command modifies a provisioned component.

prov-ed:name=MML name,param name=param value,...



Note Enter only those parameters that must be modified.

Syntax Description	<i>MML name</i>	MML name for the element you are modifying. Valid MML names are:
		<ul style="list-style-type: none"> • sys_config_static • sys_config_dynamic • h323_sys • ras • h245 • q931
	<i>param name</i>	The name of a valid configuration parameter for the specified name.
	<i>param value</i>	The value you want to assign to the parameter.

Usage Guidelines

To change more than one parameter, enter additional *param name=value* descriptions on the command line. See Chapter 3, “Provisioning the Cisco HSI,” for a list of MML names, parameter names, and their associated values.

Examples

Use the MML command shown in the following example to edit a provisioning element with the MML name *ras*, parameter name *maxFail*, and value *7*:

```
gw mml> prov-ed:name=ras,maxfail=7
H323 Signaling Interface Sun Jan 7 15:22:02 2001
M SUCC
Successfully edited provisioning element(s):
```

MML Name : ras.
 Parameter: maxFail.
 Value : 7.

Related Commands	Command	Description
	prov-add	Adds a component.
	prov-cpy	Activates the configuration settings in the current provisioning session.
	prov-dlt	Deletes a provisioned component.
	prov-exp	Exports the current configuration of the Cisco HSI in MML command form to a file or files.
	prov-rtrv	Retrieves information about an existing provisioning session.
	prov-sta	Establishes a provisioning session.
	prov-stp	Terminates either a specified provisioning session or the current provisioning session.

prov-exp

The **prov-exp** command exports the current provisioned configuration of the Cisco HSI in MML command form to a file. With this configuration file, you can prime a system with a cloned configuration from an existing system. It also enables you to restore a baseline configuration to a system. You can use the MML batch feature to import the exported data.

Start a dummy provisioning session with the **prov-sta** command before you use the **prov-exp** command.

```
prov-sta:srcver=active, dstver=dummy1
```

```
prov-exp:dirname=export directory name
```

```
prov-stp
```

Syntax Description

<i>export directory name</i>	Name of the directory to which the data is exported. This directory is a subdirectory within the /opt/GoldWing/export directory established at installation.
------------------------------	--

Examples

The MML command shown in the following example saves the active file as config.mml to the export/uk9/ directory:

```
gw mml> prov-exp:dirname=uk9
H323 Signaling Interface Sun Jan 7 14:29:11 2001
M SUCC
Successfully exported "active" to export/uk9/config.mml
```

The UNIX command shown in the following example executes MML in batch mode and imports the configuration file that was exported in the previous example:

```
mml> -b /opt/GoldWing/currentGW/export/uk9/config.mml
```

Related Commands	Command	Description
	prov-add	Adds a component.
	prov-cpy	Activates the configuration settings in the current provisioning session.
	prov-dlt	Deletes a provisioned component.
	prov-ed	Modifies a provisioned component.
	prov-rtrv	Retrieves information about an existing provisioning session.
	prov-sta	Establishes a provisioning session.
	prov-stp	Terminates either a specified provisioning session or the current provisioning session.

prov-rtrv

The **prov-rtrv** command retrieves information about an existing provisioning session.

prov-rtrv:name=MML name

prov-rtrv:all

prov-rtrv:session

prov-rtrv:list



Note

The **prov-rtrv:list** command is the only **prov-rtrv** command that can be executed outside of a provisioning session. Use the **prov-sta** command to start a provisioning command.

Syntax Description	name	The MML name for the elements that you want to display.
	<i>MML name</i>	The MML component name for the component you want to display. Valid MML names are: <ul style="list-style-type: none"> • sys_config_static • sys_config_dynamic • h323_sys • ras • h245 • q931
	all	Displays all components that have been provisioned.
	session	Displays information about the provisioning session.
	list	Provides a list of possible session names that you can use as the srver parameter to prov-sta:srcver=uk9,dstver=uk10.

Usage Guidelines

See Chapter 3, “Provisioning the Cisco HSI,” for a list of MML names, parameter names and their associated values.

Examples

The **prov-rtrv** command shown in the following example displays information about the MML name ras:

```
gw mml> prov-rtrv:name=ras
H323 Signaling Interface Sun Jan 7 14:46:01 2001
M SUCC
MML Name : ras.
Parameter: maxFail.
Value : 33.
```

The MML command shown in the following example displays information about the MML session:

```
gw mml> prov-rtrv:session
H323 Signaling Interface Sun Jan 7 14:46:01 2001
M RTRV
Session ID = mml 6 | davek
SRCVER = uk9
DSTVER = inter
```

```
gw mml> prov-rtrv:list
H323 Signaling Interface Sun Jan 7 14:46:01 2001
M RTRV
```

The following provisioning sessions are available:
uk9 matt inter
gw mml>

Related Commands

Command	Description
prov-add	Adds a component.
prov-cpy	Activates the configuration settings in the current provisioning session.
prov-dlt	Deletes a provisioned component.
prov-ed	Modifies a provisioned component.
prov-exp	Exports the current configuration of the Cisco HSI in MML command form to a file or files.
prov-sta	Establishes a provisioning session.
prov-stp	Terminates either a specified provisioning session or the current provisioning session.

prov-sta

The **prov-sta** command establishes a provisioning session. The data files are copied from the source version to the destination version.

prov-sta::srcver=version,dstver=version

Syntax Description

srcver=version	Selects a specific configuration version as the source for configuration changes. The srcver variable represents a directory that exists in \$GWBASE/var/prov/. In place of the configuration version, you can also enter: <ul style="list-style-type: none"> new—Specifies a new default session configuration; no existing source configuration is used. active—Selects the active configuration as the source for configuration changes.
dstver=version	Specifies the output version directory for the configuration session results. The dstver variable represents a directory stored in \$GWBASE/var/prov/.

Usage Guidelines

If the source and destination filenames are the same, the new configuration overwrites the old configuration. It is a good practice to copy an existing configuration instead of overwriting it so that you can return to a known configuration if there are problems with the new one.

If the source provisioning session has not been verified, the message “Note: This provisioning session has not been verified” is displayed, but the session starts normally.

If you try to start with a provisioning session that does not exist, an error is displayed, along with a list of available sessions.

Examples

The MML command in the following example starts a provisioning session named **nowt** and creates a new configuration named **blah**:

```
gw mml> prov-sta::srcver=nowt,dstver=blah
H323 Signaling Interface Sun Jan 7 13:32:07 2000
M DENY
The provisioning session called "nowt" does not exist.
The following configurations are available:
sanfran2 uk9 final
telco mgcpvia miki
transit dave matt
```

The MML command in the following example starts a provisioning session and creates a new configuration named **ver1**:

```
gw mml> PROV-STA::SRCVER="new", DSTVER="ver1"
H323 Signaling Interface Sun Jan 7 13:32:07 2001
M SUCC
Successfully started provisioning session "ver1" from "new".
```

The MML command in the following example starts a provisioning session, opens the existing configuration named **ver1**, and overwrites that configuration:

```
gw mml> PROV-STA::SRCVER="ver1", DSTVER="ver1"
```

The MML command shown in the following example starts a provisioning session, opens the existing configuration named **ver1**, and saves the updated configuration as **ver2**:

```
gw mml> PROV-STA::SRCVER="ver1", DSTVER="ver2"
```

Related Commands

Command	Description
prov-add	Adds a component.
prov-cpy	Activates the configuration settings in the current provisioning session.
prov-dlt	Deletes a provisioned component.
prov-ed	Modifies a provisioned component.
prov-exp	Exports the current configuration of the Cisco HSI in MML command form to a file or files.
prov-rtrv	Retrieves information about an existing provisioning session.
prov-stp	Terminates either a specified provisioning session or the current provisioning session.

prov-stp

The **prov-stp** command terminates the provisioning session and saves the configuration.

prov-stp:confirm

prov-stp:session name:confirm

Syntax Description

session name	Use the rtrv-mml command to retrieve the MML name given to the MML process that started the provisioning session.
confirm	If no confirm option is entered, the command is rejected and a message notifies you of the potential performance impact of this command.

Usage Guidelines

You can use the name given to an MML session to stop a provisioning session. Each MML session (not Telnet) gets an MML name: for example, mml1 or mml2. The maximum number of allowable MML sessions is 12.

If you log in to the Cisco HSI from an MML session and start a provisioning session (for example, gw mml> **prov-sta:srcver=new,dstver=uk9**), you can use the MML name (for example, mml2) to stop the session with **prov-stp** (for example, **prov-stp:mml2:confirm**).

Use the **rtrv-mml** command to display all active MML sessions (see **rtrv-mml**, page A-28).

Examples

The MML command in the following example terminates the current provisioning session:

```
gw mml> prov-stp:confirm
H323 Signaling Interface Sun Jan 7 14:46:01 2001
M SUCC
Successfully stopped provisioning session "ver1"
```

The MML command in the following example terminates the uk9 provisioning session:

```
gw mml> prov-stp:uk9:confirm
H323 Signaling Interface Day Mon 1 hh:mm:ss YYYY
M SUCC
Successfully stopped provisioning session "uk9"
gw mml>
```

If the previous session starts from an MML process assigned the name mml2, you can use the following MML command:

```
gw mml> prov-stp:mml2:confirm
H323 Signaling Interface Day Mon 1 hh:mm:ss YYYY
M SUCC
Successfully stopped provisioning session "uk9"
gw mml>
```

Related Commands

Command	Description
prov-add	Adds a component.
prov-cpy	Activates the configuration settings in the current provisioning session.
prov-dlt	Deletes a provisioned component.
prov-ed	Modifies a provisioned component.
prov-exp	Exports the current configuration of the Cisco HSI in MML command form to a file or files.
prov-rtrv	Retrieves information about an existing provisioning session.
prov-sta	Establishes a provisioning session.

quit

The **quit** command ends an MML session.

quit

Syntax Description

This command has no arguments or keywords.

Examples

The command in the following example ends an MML session.

```
gw mml> quit
```

radlog

The **radlog** command starts or stops RADVision logging into a specified log file.

radlog:*[file name]:start | stop*



Caution

This command is processor intensive and results in very large log files. Use this command only to retrieve information for single test calls, and do not use it on a live network that is processing numerous calls.

Syntax Description.

<i>file name</i>	The user-defined name of the log file. The actual filename has a <i>.log</i> suffix. The file is located in the logging directory defined in the configuration data (see Chapter 3, “Provisioning the Cisco HSI”).
------------------	--

Examples

The command in the following example starts logging into a diagnostics log named file1:

```
gw mml> radlog:file1:start
H323 Signaling Interface Day Mon 1 hh:mm:ss YYYY
M SUCC
RADLogging requested to start
```

The following command logs RADVision to the standard log file:

```
gw mml> radlog::start
H323 Signaling Interface Day Mon 1 hh:mm:ss YYYY
M SUCC
RADLogging to standard log file
```

Related Commands

Command	Description
diaglog	Starts or stops event logging into a diagnostics log.
rtrv-log	Displays the logging level of a package or all packages.
set-log	Sets the logging level of a package or all packages.

restart-softw

The **restart-softw** command restarts the call processing application. It applies the provisioning data specified in the *configVersion* (if present) that overrides the existing active provisioning data.

```
restart-softw[:configVersion][:confirm]
```

Syntax Description

<i>configVersion</i>	In <i>configVersion</i> , init is a keyword, and this command restarts the call processing application applying the etc/GWmain.conf configuration file as the provisioning data. If <i>configVersion</i> is an unverified provisioning session, the command fails.
<i>confirm</i>	If there are active calls, a notification is sent to the craft, and the command must be reentered with the <i>confirm</i> parameter to take effect.

Examples

In the following example, the call processing application restarts using the etc/GWmain.conf configuration files as the provisioning data:

```
gw mml> restart-softw:init
H323 Signaling Interface Day Mon 1 hh:mm:ss YYYY
M SUCC
```

```
Application is now restarting using the default provisioning session.
There are no active calls.
New call requests are rejected.
Call Processing now stopped.
Application will restart in 60 seconds
```

In the following example, the application would restart using the active provisioning session. There are no active calls, new call requests are rejected, and call processing is now stopped. The application is set to restart in 12 seconds.

```
gw mml> restart-softw
H323 Signaling Interface Day Mon 1 hh:mm:ss YYYY
M SUCC
```

In the following example, a restart passes an unverified provisioning session. The command fails. You cannot use an unverified provisioning session.

```
gw mml> restart-softw:config2
H323 Signaling Interface Day Mon 1 hh:mm:ss YYYY
M DENY
```

In the following example, a restart uses a specified verified provisioning session. The application restarts by using original as the provisioning session. There are no active calls, new call requests are rejected, and call processing is now stopped. The application is set to restart in 12 seconds.

```
gw mml> restart-softw:original
H323 Signaling Interface Day Mon 1 hh:mm:ss YYYY
M SUCC
```

rtrv-alms

The **rtrv-alms** command retrieves all active alarms.

rtrv-alms

rtrv-alms:cont

Syntax Description

cont	This parameter displays alarm events until you press Ctrl-C . All active alarms are displayed, and then a message appears (for example: “/* Listening for alarm events . . . (Ctrl-C to stop) */”).
-------------	--

Examples

In the following example, the output contains the standard alarm definition and also a NACK or an ACK for noninformational alarms. NACK and ACK indicate the acknowledgement status of the alarm.

```
gw mml> rtrv-alms
GW Signaling Interface    2000-12-05 14:19:22
M   RTRV
"H323-GW1: 2000-11-27 11:25:12.259, ** ALM=\"VSC FAILURE\",SEV=MJ" NACK
"H323-GW1: 2000-11-27 11:25:13.260, ** ALM=\"CONFIGURATION FAILURE\",SEV=MJ" ACK
"H323-GW1: 2000-11-27 11:25:14.011, A^ ALM=\"ENDPOINT CHANNEL INTERFACE FAILURE\",SEV=IF"
"H323-GW1: 2000-11-27 11:25:14.012, A^ ALM=\"ENDPOINT CHANNEL INTERFACE FAILURE\",SEV=IF"
```

In the following example, the output displays alarm events until you press **Ctrl-C**:

```
gw mml> rtrv-alms:cont
GW Signaling Interface    2000-12-05 14:19:22
M   RTRV
"H323-GW1: 2000-11-27 11:25:12.259, ** ALM=\"VSC FAILURE\",SEV=MJ"
"H323-GW1: 2000-11-27 11:25:13.259,     ALM=\"VSC FAILURE\",SEV=MJ" STATE=CLEARED
"H323-GW1: 2000-11-27 11:25:13.260, ** ALM=\"CONFIGURATION FAILURE\",SEV=MJ"
"H323-GW1: 2000-11-27 11:25:14.011, A^ ALM=\"ENDPOINT CHANNEL INTERFACE FAILURE\",SEV=IF"
"H323-GW1: 2000-11-27 11:25:14.012, A^ ALM=\"ENDPOINT CHANNEL INTERFACE FAILURE\",SEV=IF"

/* Listening for alarm events... (Ctrl-C to stop) */

"H323-GW1: 2000-11-27 11:25:13.259, ** ALM=\"VSC FAILURE\",SEV=MJ"

/* Ctrl-C pressed */
```

Related Commands

Command	Description
ack-alm	Acknowledges that an alarm event is recognized but does not clear the alarm.
clr-alm	Clears an alarm event.

rtrv-calls

The **rtrv-calls** command displays all actively connected calls. If the *time elapsed* parameter is provided (in units of minutes), calls display only if they exceed the specified time. The output includes the call direction, time connected, calling and called address, and call reference.

rtrv-calls*[:time elapsed]*

Syntax Description	<i>time elapsed</i>	If the time elapsed parameter is provided (in units of minutes), calls display only if they have exceeded the specified time.
---------------------------	---------------------	---

Examples

In the following example, the command displays all actively connected calls:

```
gw mml> rtrv-calls
H323 Signaling Interface Day Mon 1 hh:mm:ss YYYY
M SUCC

CallId SrcAddr DestAddr StartTime
124 04161234567 0299598125 2000-11-27 11:25:13.259
```

rtrv-ctr

The **rtrv-ctr** command displays the measurements for a counter group.

rtrv-ctr*:counter group*

Syntax Description	<i>counter group</i>	The name of an MML counter group (RAS, Q931, or H245).
---------------------------	----------------------	--

Examples

In the following example, the command displays the measurements for the **RAS** counter group:

```
gw mml> rtrv-ctr:RAS
GW Signaling Interface      2000-12-05 14:19:22
M   RTRV
"H323-GW1:GROUP=\"RAS\",NAME=\"GK DISC ATT TOT\",VAL=10"
"H323-GW1:GROUP=\"RAS\",NAME=\"GK REG ATT TOT\",VAL=0"
"H323-GW1:GROUP=\"RAS\",NAME=\"GK REG SUCC TOT\",VAL=12"
"H323-GW1:GROUP=\"RAS\",NAME=\"GK RCV UNR ATT TOT\",VAL=100"
"H323-GW1:GROUP=\"RAS\",NAME=\"GK XMIT UNR SUCC TOT \",VAL=2000"
"H323-GW1:GROUP=\"RAS\",NAME=\"GK XMIT UNR ATT TOT\",VAL=20"
"H323-GW1:GROUP=\"RAS\",NAME=\"GK RCV UNR SUCC TOT\",VAL=10"
"H323-GW1:GROUP=\"RAS\",NAME=\"GK RLS ATT TOT\",VAL=20"
"H323-GW1:GROUP=\"RAS\",NAME=\"GK RLS SUCC TOT\",VAL=30"
"H323-GW1:GROUP=\"RAS\",NAME=\"GK INFO REPORT TOT\",VAL=40"
```

Related Commands

Command	Description
clr-meas	Resets a measurement counter.

rtrv-dest

The **rtrv-dest** command retrieves status information about the IP links and E-ISUP signaling path to the PGW 2200.

rtrv-dest:*point code*

rtrv-dest:*sig path*

rtrv-dest:**all**

Syntax Description		
	<i>point code</i>	The MML component name of a point code component.
	<i>sig path</i>	The MML name of the logical signaling channel for which you want to display information. This path should be made up of sig path DSS IP or sig path NAS entities. Use the help:prov-add command to obtain a description of sig path components.
	all	Displays information about all external point codes and signal paths.

Examples

The MML command in the following example retrieves the destination of point code dpcl:

```
gw mml> rtrv-dest:dpcl
MGC-01 Media Gateway Controller 2000-01-12 15:19:51
M RTRV
^dpcl:PKG=SS7-ANSI,ASSOC=UNK,PST=IS
```

Related Commands

Command	Description
set-dest-state	Changes the service state of an IP link or E-ISUP signaling path to in service (IS) or out of service (OOS).

rtrv-gapping

The **rtrv-gapping** command retrieves information about overload-triggered call gapping.

The following information displays:

- The active/inactive status of call gapping
- The percentage of calls that are gapped
- The type of calls to which gapping is applied

rtrv-gapping

Syntax Description

This command has no arguments or keywords

Examples

The following MML command retrieves the current levels of call gapping for all gapping clients:

```
gw mml> rtrv-gapping
```

Client Name	Direction	Level	Call Type	Active
Overload	Outgoing	10	Normal	No
Overload	Incoming	10	Normal	No
MML	Outgoing	20	All	Yes
MML	Incoming	30	All	Yes

Related Commands

Command	Description
set-gapping	Sets the type of calls to be gapped.

rtrv-log

The **rtrv-log** command displays the logging level of a package or all packages.

rtrv-log:package=x

rtrv-log:all

Syntax Description

package=x	Displays the logging level for the various packages that make up the Cisco HSI. For package names, see the “Log Message Packages” section on page 4-10.
all	Displays the logging levels of all packages.

Examples

In the following example, the command displays the logging levels of all packages:

```
gw mml> rtrv-log:all
H323 Signaling Interface Thu Dec 14 16:28:44 2000
M RTRV

Logging levels:
Application.....0x0000
CallControl.....0xFFFF
Connection.....0x0000
DataManager.....0x0000
Eisup.....0xFFFF
FaultManager.....0x0000
Gapping.....0x0000
H323.....0xFFFF
Infrastructure....0x0000
OverLoad.....0x0000
ProcessManager....0x0000
Provisioning.....0x0000
Signal.....0x0000
Snmp.....0x0000
SnmpSubagent.....0x0000
```

```

Statistics.....0x0000
Trace.....0x0000
UserInterface.....0x0000

```

Related Commands	Command	Description
	diaglog	Starts and stops event logging into a diagnostics log.
	radlog	Starts and stops RADVision logging into a specified log file.
	set-log	Sets the logging level of a package or all packages.

rtrv-mml

The **rtrv-mml** command displays the following information:

- All active MML sessions
- Session numbers of all active MML sessions
- User IDs of the session originators

rtrv-mml

Syntax Description

This command has no arguments or keywords.

Examples

In the following example, the command displays all active MML sessions, their sessions numbers, and the user IDs of the session originators.

```
gw mml> rtrv-mml
```

```

VSC H-323 Signaling Interface - H323-GW1 2000-06-20 10:04:28
M RTRV
mml1:matthew1
mml2:davek

```

rtrv-ne

The **rtrv-ne** command displays the type, hardware platform, vendor, location, version, and status of the Cisco HSI.

rtrv-ne

Syntax Description

This command has no arguments or keywords.

Examples

In the following example, the command displays the type, hardware platform, vendor, location, version, and status of the Cisco HSI.

```
gw mml> rtrv-ne
```

```

H323 Signaling Interface Thu Dec 14 16:29:19 2000
M RTRV

Type: H323 Signaling Interface
Hardware platform: Sun netra t1
Vendor: Cisco Systems, Inc.
Location: H323 - GW1
Version: R1_1_0
Platform Status:
Signaling interface: Active
Call processing: Running

```

rtrv-ne-health

The **rtrv-ne-health** command displays the following information about the Cisco HSI status:

- CPU load
- Disk space
- Number of currently connected calls
- Number of calls in setup

rtrv-ne-health

Syntax Description

This command has no arguments or keywords.

Examples

In the following example, the command displays information about the Cisco HSI status:

```

gw mml> rtrv-ne-health

VSC H-323 Signaling Interface - H323-GW1 2000-06-20 10:04:28
M RTRV

CPU Load:                23%
Disk space:              123456
Number of connected calls: 23
Number of calls in setup: 12

```

rtrv-overload

The **rtrv-overload** command displays overload status information and value settings for the three provisionable levels of overload.

rtrv-overload

Syntax Description

This command has no arguments or keywords.

Examples

In the following example, the command displays overload status information:

```
gw mml> rtrv-overload
H323 Signaling Interface Tue Jan 30 11:21:45 2001
M SUCC
Overload/Gapping Information
NumCalls : 0 | CPU : 7% | DiskUsage : 27%
Status : Not in Ovld
Overload Configuration
DiskUsageLimit : 29%
OvldSampleRate : 3000ms
OvldLevel1Percent : 65%
OvldLevel1Filter : NORMAL
OvldLevel1ThreshLowerCpu : 30%
OvldLevel1ThreshUpperCpu : 35%
OvldLevel1ThreshLowerCalls : 800
OvldLevel1ThreshUpperCalls : 1000
OvldLevel2Percent : 75%
OvldLevel2Filter : ALL
OvldLevel2ThreshLowerCpu : 45%
OvldLevel2ThreshUpperCpu : 50%
OvldLevel2ThreshLowerCalls : 1100
OvldLevel2ThreshUpperCalls : 1400
OvldLevel3Percent : 90%
OvldLevel3Filter : NORMAL
OvldLevel3ThreshLowerCpu : 55%
OvldLevel3ThreshUpperCpu : 65%
OvldLevel3ThreshLowerCalls : 1400
OvldLevel3ThreshUpperCalls : 1600
```

Related Commands

Command	Description
set-overload	Defines the overload handling criteria and behavior.

rtrv-softw

The **rtrv-softw** command displays the status of the Cisco HSI and call processing activity. The following software states can be displayed for the Cisco HSI:

- Not running
- Starting
- Active
- Restart pending
- Halt pending
- Reboot pending

The following software states can be displayed for call processing:

- Running
- Idle pending
- Idle

rtrv-softw

**Note**

When the Cisco HSI is in the restart pending, halt pending, or reboot pending software state, the **sta-callproc** command cancels the pending state.

Syntax Description

This command has no arguments or keywords.

Examples

In the following example, the command displays the status of the Cisco HSI and call processing activity:

```
gw mml> rtrv-softw
VSC H-323 Signaling Interface - H323-GW1 2000-06-20 10:04:28
M RTRV
Platform Status:
Signaling interface: Active
Call processing:      Running
```

set-dest-state

The **set-dest-state** command changes the service state of an IP link or E-ISUP signaling path to IS (in service) or OOS (out of service).

set-dest-state:ipLink1toVscA:IS|OOS

set-dest-state:ipLink2toVscA:IS|OOS

set-dest-state:ipLink1toVscB:IS|OOS

set-dest-state:ipLink2toVscB:IS|OOS

set-dest-state:EisupPath:IS|OOS

set-dest-state:ipLinkNms:IS|OOS

Syntax Description

IS	In service.
OOS	Out of service.

Examples

In the following example, the command changes the service state of an IP link signaling path to IS:

```
gw mml> set-dest-state:ipLink1toVscA:state=IS
H323 Signaling Interface Day Mon 1 hh:mm:ss YYYY
M SUCC

Initiating state change of ipLink1toVscA to IS
gw mml> set-dest-state:ipLink1toVscA:state=OOS
H323 Signaling Interface Day Mon 1 hh:mm:ss YYYY
M SUCC

Initiating state change of ipLink1toVscA to OOS
```

Related Commands	Command	Description
	rtrv-dest	Retrieves status information about the IP links and E-ISUP signaling path to the PGW 2200.

set-gapping

The **set-gapping** command sets the type of calls to be gapped.

set-gapping: inc | otg | both : calltype=normal | all, percent=number

Syntax Description	Parameter	Description
	inc	Gaps calls from the H.323 network.
	otg	Gaps calls from the PSTN over E-ISUP.
	both	Gaps calls originating from either side.
	normal	Gaps all calls except priority and emergency calls.
	all	Gaps calls of all types.
	number	Specifies the percentage of calls rejected due to call gapping.

Usage Guidelines

If call gapping is set to 100 percent, all calls are gapped irrespective of the normal or all parameter setting.

If the overload condition is active and call gapping is active, the higher of the two percentage values determines whether new call attempts are accepted or rejected.

Examples

In the following example, the command sets all calls to be gapped and specifies that 50 percent of the calls be rejected due to call gapping:

```
gw mm1> set-gapping:both:calltype=all,percent=50
H323 Signaling Interface Day Mon 1 hh:mm:ss YYYY
M SUCC
Successfully set gapping for target 'both', calltype 'all', and percentage 50
```

Related Commands	Command	Description
	rtrv-gapping	Retrieves information about overload-triggered call gapping.

set-log

The **set-log** command sets the logging level of a package or all packages.

set-log:package:level=level, [confirm]

set-log:all:level=level, [confirm]

Syntax Description	package	One of the packages in the Cisco HSI. For a list of package names, see the “Log Message Packages” section on page 4-10.
	level	Logging levels are set through the use of hexadecimal numbers between 0x0000 and 0xFFFF. The higher the number, the higher the level of debug.
	confirm	If any client level parsing fails on the data session, a confirm is needed for the data to be activated.

Usage Guidelines Logging at any level implies that upper levels are included. When you are setting logging with the level DEBUG, a confirmation is required because the amount of data logged affects service. For a list of the packages that can log messages, see the “Log Message Packages” section on page 4-10.

Examples In the following example, the command sets the logging level of the package gapping to 0xFFE0:

```
gw mml> set-log:gapping:0xFFE0
M SUCC
logging level for package gapping set to 0xFFE0
```

Related Commands	Command	Description
	diaglog	Starts and stops event logging into a diagnostics log.
	radlog	Starts and stops RADVision logging into a specified log file.
	rtrv-log	Displays the logging level of a package or all packages.

set-overload

The **set-overload** command defines the overload handling criteria and behavior.

set-overload: level1|level2|level3:cpu,lower=number, upper=number

set-overload: level1|level2|level3:calls,lower=number, upper=number

set-overload: level1|level2|level3:gap,normalall : number

Syntax Description	level 1 level 2 level 3	Overload behavior can be provisioned at three separate levels: 1, 2, and 3 (rising in severity).
	lower=number	The lower threshold for overload detection and restoration of normal call handling service.
	upper=number	The upper threshold for overload detection and restoration of normal call handling service.

Usage Guidelines

The **set-overload** command defines the upper and lower thresholds for overload detection and restoration of normal call handling service. The percentage of calls to be gapped and the type of calls to be gapped can also be configured. Any changes made become active immediately.

The lower value must always be less than the upper value. If the call gap percentage is set to 0, the system takes no recovery action when overload is encountered, but the appropriate alarm is raised.

Inconsistent threshold settings for different levels can destabilize call processing. For successful execution of this command, ensure that threshold settings are consistent, as follows:

- The number of calls gapped at level 2 must be greater than or equal to the number of calls gapped at level 1.
- The number of calls gapped at level 3 must be greater than or equal to the number of calls gapped at levels 1 and 2.
- The lower level value of CPU occupancy must always be less than the upper level value.
- The lower level value of CPU occupancy and the number of calls for level 2 must be greater than or equal to the corresponding values for level 1.
- The lower level value of CPU occupancy and the number of calls for level 3 must be greater than or equal to the corresponding values for levels 1 and 2.

Examples

In the following example, the command sets the overload handling criteria and behavior at level 1, sets the cpu to the lower threshold of 10, and sets the upper threshold to 14.

```
gw mml> set-overload:level1:cpu, lower =10, upper = 14
H323 Signaling Interface Day Mon 1 11:21:28 2001
M SUCC
Successfully added that configuration item.
```

Related Commands

Command	Retrieve
rtrv-overload	Displays the overload status and the data values for the three provisionable levels of overload

sta-callproc

The **sta-callproc** command starts call processing.

sta-callproc

Syntax Description

This command has no arguments or keywords.

Examples

In the following example, the command starts call processing:

```
gw mml> sta-softw
gw mml> sta-callproc
```

```
H323 Signaling Interface Thu Dec 14 16:31:09 2000
M SUCC
```

Starting call processing.

Related Commands	Command	Description
	sta-softw	Starts the call processing application.

sta-softw

The **sta-softw** command starts the call processing application.

```
sta-softw
```

Syntax Description	Description
	This command has no arguments or keywords.

Examples

In the following example, the command starts the call processing application:

```
gw mml> sta-softw
```

```
H323 Signaling Interface Day Mon 1 hh:mm:ss YYYY
M SUCC
```

The Call Processing Application is starting.

Related Commands	Command	Description
	sta-callproc	Starts call processing

sta-trc

The **sta-trc** command starts the call processing tracing function.

```
sta-trc:Calltype=calltype,TraceLevel=trace level[,CdAddress=address]  
[,CgAddress=address],log=filename[,prd=n]
```

Syntax Description	Calltype=calltype	This parameter defines the type of call to be traced. The possible values are: <ul style="list-style-type: none"> inc—For H.323-originated calls otg—For E-ISUP-originated calls both—For calls originating from either side
	TraceLevel=trace level	This parameter defines the level of detail that is recorded in the call trace. The possible values are: <ul style="list-style-type: none"> terse—Traces only incoming/outgoing message names and RADvision API calls. brief—In addition to terse, traces internal interfaces, and call state changes. verbose—Traces all messages and their contents, RADvision API calls and their contents, internal interfaces, and call state changes.
	CdAddress=address	A filter used to trace calls using only the specified leading digits within the called address. A match is performed on these digits and the initial called address digits contained within the E-ISUP IAM message or the H225 SETUP message.
	CgAddress=address	A filter used to trace calls using only the specified leading digits within the calling address. A match is performed on these digits and the initial calling address digits contained within the E-ISUP IAM message or the H.225 SETUP message.
	log=filename	The filename for the trace output.
	prd=n	The trace period (in seconds). At expiration of this period, the trace log is closed. If no value is specified, the period defaults to 1800 seconds (30 minutes).

Defaults

The default trace for all calls is 30 minutes.

Usage Guidelines

Only one trace command at a time can be active. If an additional request is issued, the command is rejected with a call trace already active indication.

Examples

In the following example, the command starts the call processing tracing function:

```
gw mm1> sta-trc:Calltype=both, TraceLevel=terse, dAddress=012,CgAddress=013, log=tlog.txt,
prd=10
```

```
H323 Signaling Interface Day Mon 1 hh:mm:ss YYYY
M SUCC
```

Related Commands

Command	Description
stp-trc	Halts the tracing currently active and closes the trace file.

stp-call

The **stp-call** command terminates a currently active call by forcing a release of the call. Disconnect/release messages are sent in both directions.

stp-call:callref=x

stp-call:all

Syntax Description

callref	Refers to a positive integer.
all	Stops all calls.

Examples

In the following example, the command terminates a currently active call by forcing a release of the call with a callref of 33.

```
gw mml> stp-call:callref=33
```

```
H323 Signaling Interface Thu Dec 14 16:43:54 2000
M SUCC
```

```
Stopped call 33
```

Related Commands

Command	Description
rtrv-calls	Displays all actively connected calls.

stp-callproc

The **stp-callproc** command stops further call processing by immediately terminating the handling of new call requests.

stp-callproc[:timeout=T]

Syntax Description

timeout	If no timeout period is provided, existing calls are released immediately. If a timeout period is provided, existing calls are released after the specified amount of time has elapsed. When all calls have been released, a notification message is sent to the craft terminal.
T	T is in seconds.

Examples

In the following example, the command stops further call processing by immediately terminating the handling of new call requests:

```
gw mml> stp-callproc
```

```
H323 Signaling Interface Thu Dec 14 16:27:07 2000
M SUCC
```

Stopped accepting new calls. Existing calls will be released in 5 seconds.

Stopping Call Processing.

stp-softw

The **stp-softw** command stops the call processing application. This command causes the Cisco HSI to terminate.

stp-softw[:confirm]

Syntax Description

confirm	Description
confirm	If there are active calls, a notification is sent to the craft. In order for the command to take effect, it must be reentered with the confirm parameter.

Examples

In the following example, the command stops the call processing application:

```
gw mml> stp-softw
```

```
H323 Signaling Interface Thu Dec 14 16:27:36 2000
M SUCC
```

```
There are no active calls.
Application is now stopping
```

stp-trc

The **stp-trc** command halts the currently active tracing and closes the trace file.

stp-trc

Syntax Description

This command has no arguments or keywords

Examples

In the following example, the command halts the currently active tracing and closes the trace file:

```
gw mml> stp-trc
```

```
H323 Signaling Interface Day Mon 1 hh:mm:ss YYYY
M SUCC
Tracing deactivated.
```

Related Commands

Command	Description
sta-trc	Starts the call processing tracing function.



Skeleton Configuration File

Provisionable and configurable data elements within the Cisco H.323 Signaling Interface (HSI) are grouped as dynamic, static, or constant data. You can modify dynamic and static data through the provisioning MML commands.

At startup, the Cisco HSI reads a skeleton file, which contains information for every configurable item within the system. It determines which group the item is in and what its possible ranges are. The format for each item is:

PackageName	ItemName	GroupValueRange
-------------	----------	-----------------

The package name is an MML name for dynamic and static data, and service package names (determined within the detailed design) for constant data.

The item name is as specified in the detailed design (that is, all constant data).

The group is one of the following:

- S = Static data
- D = Dynamic data
- C = Constant data

The ValueRange is one of the following:

- [] = Number: No range
- [x-y] = Number: Acceptable range x to y
- STRING = String value
- NULL = No associated value

An example of an MML command follows:

```
RASmaxFailD[1-200]
```

In the preceding example, the PackageName is RAS, and the ItemName is maxFail. It is a dynamic configuration item, and it is a numerical data type with an acceptable range of 1 to 200.

The skeleton file allows the system technician to specify whether data is provisionable and whether provisionable data is static or dynamic.



Note

The skeleton configuration file should be modified only by authorized personnel.

The following is an example of a skeleton file:

```

***** sys_config_static *****
#Static
SYS_CONFIG_STATIC      Nodeid                S          STRING
SYS_CONFIG_STATIC      HOST_PORT_NUMBER1    S          [0-65535]
SYS_CONFIG_STATIC      HOST_PORT_NUMBER2    S          [0-65535]
SYS_CONFIG_STATIC      HOST_IPADDR1         S          STRING
SYS_CONFIG_STATIC      HOST_IPADDR2         S          STRING
SYS_CONFIG_STATIC      VSCA_IPADDR1         S          STRING
SYS_CONFIG_STATIC      VSCA_IPADDR2         S          STRING
SYS_CONFIG_STATIC      VSCB_IPADDR1         S          STRING
SYS_CONFIG_STATIC      VSCB_IPADDR2         S          STRING
SYS_CONFIG_STATIC      VSCA_PORT_NUMBER1    S          [0-65535]
SYS_CONFIG_STATIC      VSCA_PORT_NUMBER2    S          [0-65535]
SYS_CONFIG_STATIC      VSCB_PORT_NUMBER1    S          [0-65535]
SYS_CONFIG_STATIC      VSCB_PORT_NUMBER2    S          [0-65535]

SYS_CONFIG_STATIC      ClipClirSupported    S          STRING
SYS_CONFIG_STATIC      DualCLISupported     S          STRING
SYS_CONFIG_STATIC      RaiSupported          S          STRING
SYS_CONFIG_STATIC      DtmfSupportedDirection S          STRING
SYS_CONFIG_STATIC      DtmfSupportedType    S          STRING
SYS_CONFIG_STATIC      NetchatSupported     S          STRING
SYS_CONFIG_STATIC      H225PavoSupported    S          STRING
SYS_CONFIG_STATIC      PavoRedirScreeningInd S          [0-3]
SYS_CONFIG_STATIC      PavoRedirReason      S          [0-15]
SYS_CONFIG_STATIC      PavoRedirPresInd     S          [0-3]
SYS_CONFIG_STATIC      CliInDisplaySupported S          STRING
SYS_CONFIG_STATIC      T38MaxVal            S          STRING
SYS_CONFIG_STATIC      T38Options           S          STRING
SYS_CONFIG_STATIC      AsymmetricHandlingSupported S          STRING
SYS_CONFIG_STATIC      UseConfID            S          STRING

SYS_CONFIG_STATIC      CC_EC_DEFAULT        S          STRING
SYS_CONFIG_STATIC      CC_HC_DEFAULT        S          STRING
SYS_CONFIG_STATIC      CC_EC_AccessBarred   S          STRING
SYS_CONFIG_STATIC      CC_EC_Acknowledgement S          STRING
SYS_CONFIG_STATIC      CC_EC_AddressIncomplete S          STRING
SYS_CONFIG_STATIC      CC_EC_AnonymousCallRejection S          STRING

```

SYS_CONFIG_STATIC	CC_EC_BlacklistBNumberMatched	S	STRING
SYS_CONFIG_STATIC	CC_EC_BlacklistCliLengthInvalid	S	STRING
SYS_CONFIG_STATIC	CC_EC_BlacklistCliMatched	S	STRING
SYS_CONFIG_STATIC	CC_EC_BlacklistCpcRestricted	S	STRING
SYS_CONFIG_STATIC	CC_EC_BlacklistNoCli	S	STRING
SYS_CONFIG_STATIC	CC_EC_BlacklistNoaRestricted	S	STRING
SYS_CONFIG_STATIC	CC_EC_Busy	S	STRING
SYS_CONFIG_STATIC	CC_EC_CallRejectCallGapping	S	STRING
SYS_CONFIG_STATIC	CC_EC_CallTerminated	S	STRING
SYS_CONFIG_STATIC	CC_EC_CallTypeIncompatible	S	STRING
SYS_CONFIG_STATIC	CC_EC_CallingDroppedWhileOnHold	S	STRING
SYS_CONFIG_STATIC	CC_EC_CallingPartyOffHold	S	STRING
SYS_CONFIG_STATIC	CC_EC_ChannelOutOfService	S	STRING
SYS_CONFIG_STATIC	CC_EC_Congestion	S	STRING
SYS_CONFIG_STATIC	CC_EC_CotFailure	S	STRING
SYS_CONFIG_STATIC	CC_EC_CugAccessBarred	S	STRING
SYS_CONFIG_STATIC	CC_EC_DteControlledNotReady	S	STRING
SYS_CONFIG_STATIC	CC_EC_DteUncontrolledNotReady	S	STRING
SYS_CONFIG_STATIC	CC_EC_ExcessiveDigCallProceeding	S	STRING
SYS_CONFIG_STATIC	CC_EC_FacilityNotRegistered	S	STRING
SYS_CONFIG_STATIC	CC_EC_FlowControlledCongestion	S	STRING
SYS_CONFIG_STATIC	CC_EC_GroupRestrictions	S	STRING
SYS_CONFIG_STATIC	CC_EC_IncomingCallsBarred	S	STRING
SYS_CONFIG_STATIC	CC_EC_InterceptedSubscriber	S	STRING
SYS_CONFIG_STATIC	CC_EC_InterworkUnspec	S	STRING
SYS_CONFIG_STATIC	CC_EC_InvalidCallRef	S	STRING
SYS_CONFIG_STATIC	CC_EC_MesgWithUnrecElemDiscarded	S	STRING
SYS_CONFIG_STATIC	CC_EC_MessageNotUnderstood	S	STRING
SYS_CONFIG_STATIC	CC_EC_MisroutedCallPortedNumber	S	STRING
SYS_CONFIG_STATIC	CC_EC_NetworkAddressExtensionError	S	STRING
SYS_CONFIG_STATIC	CC_EC_NetworkTermination	S	STRING
SYS_CONFIG_STATIC	CC_EC_NewDestination	S	STRING
SYS_CONFIG_STATIC	CC_EC_NumberUnobtainable	S	STRING
SYS_CONFIG_STATIC	CC_EC_OperatorPriorityAccess	S	STRING
SYS_CONFIG_STATIC	CC_EC_OutOfCatchmentArea	S	STRING
SYS_CONFIG_STATIC	CC_EC_OutgoingCallsBarred	S	STRING
SYS_CONFIG_STATIC	CC_EC_PermanentIcb	S	STRING
SYS_CONFIG_STATIC	CC_EC_PortedNumber	S	STRING

SYS_CONFIG_STATIC	CC_EC_PreemptionCctUnavailable	S	STRING
SYS_CONFIG_STATIC	CC_EC_Prefix0DialledInError	S	STRING
SYS_CONFIG_STATIC	CC_EC_Prefix1DialledInError	S	STRING
SYS_CONFIG_STATIC	CC_EC_Prefix1NotDialled	S	STRING
SYS_CONFIG_STATIC	CC_EC_PriorityForcedRelease	S	STRING
SYS_CONFIG_STATIC	CC_EC_Proprietary	S	STRING
SYS_CONFIG_STATIC	CC_EC_ProtErrThresholdExceeded	S	STRING
SYS_CONFIG_STATIC	CC_EC_ProtocolErrorUnspec	S	STRING
SYS_CONFIG_STATIC	CC_EC_Reject	S	STRING
SYS_CONFIG_STATIC	CC_EC_RejectedDivertedCall	S	STRING
SYS_CONFIG_STATIC	CC_EC_RemoteProcError	S	STRING
SYS_CONFIG_STATIC	CC_EC_RepeatAttempt	S	STRING
SYS_CONFIG_STATIC	CC_EC_RouteOutOfService	S	STRING
SYS_CONFIG_STATIC	CC_EC_SelectiveCallBarring	S	STRING
SYS_CONFIG_STATIC	CC_EC_ServiceIncompatible	S	STRING
SYS_CONFIG_STATIC	CC_EC_ServiceTemporarilyUnavailable	S	STRING
SYS_CONFIG_STATIC	CC_EC_ServiceUnavailable	S	STRING
SYS_CONFIG_STATIC	CC_EC_SignalNotUnderstood	S	STRING
SYS_CONFIG_STATIC	CC_EC_SignalNotValid	S	STRING
SYS_CONFIG_STATIC	CC_EC_SignallingSystemIncompatible	S	STRING
SYS_CONFIG_STATIC	CC_EC_SubControlledIcb	S	STRING
SYS_CONFIG_STATIC	CC_EC_SubNotFoundDle	S	STRING
SYS_CONFIG_STATIC	CC_EC_SubscriberCallTerminate	S	STRING
SYS_CONFIG_STATIC	CC_EC_SubscriberIncompatible	S	STRING
SYS_CONFIG_STATIC	CC_EC_SubscriberMoved	S	STRING
SYS_CONFIG_STATIC	CC_EC_SubscriberOutOfService	S	STRING
SYS_CONFIG_STATIC	CC_EC_TemporaryOos	S	STRING
SYS_CONFIG_STATIC	CC_EC_TerminalCongestion	S	STRING
SYS_CONFIG_STATIC	CC_EC_Transferred	S	STRING
SYS_CONFIG_STATIC	CC_EC_TranslationOos	S	STRING
SYS_CONFIG_STATIC	CC_EC_UnallocatedDestNumber	S	STRING
SYS_CONFIG_STATIC	CC_EC_UndefinedBg	S	STRING
SYS_CONFIG_STATIC	CC_EC_Unknown	S	STRING
SYS_CONFIG_STATIC	CC_EC_UnrecElemPassedOn	S	STRING
SYS_CONFIG_STATIC	CC_EC_VacantCode	S	STRING
SYS_CONFIG_STATIC	CC_EC_WhitelistCliNotMatched	S	STRING

system

#Static

H323_SYS	cidAssociate	S	NULL
H323_SYS	vtNodeCount	S	[0-65535]
H323_SYS	channels	S	[0-65535]
H323_SYS	messages	S	[0-65535]
H323_SYS	pktChans	S	[0-65535]
H323_SYS	protocols	S	[0-65535]
H323_SYS	maxProcs	S	[0-65535]
H323_SYS	maxBuffSize	S	[0-65535]
H323_SYS	maxCalls	S	[0-5000]
H323_SYS	maxChannels	S	[0-65535]

sys_config_dynamic#####

#Dynamic

SYS_CONFIG_DYNAMIC	AlternateGatekeeperIp	D	STRING
SYS_CONFIG_DYNAMIC	AlternateGatekeeperPort	D	[0-65535]
SYS_CONFIG_DYNAMIC	AlternateGatekeeperId	D	STRING
SYS_CONFIG_DYNAMIC	Logdirectory	D	STRING
SYS_CONFIG_DYNAMIC	LogFilenamePrefix	D	STRING
SYS_CONFIG_DYNAMIC	LogPrio	D	STRING
SYS_CONFIG_DYNAMIC	LogFileRotateSize	D	[1000-65535]
SYS_CONFIG_DYNAMIC	LogFileRotateInterval	D	[0-65535]
SYS_CONFIG_DYNAMIC	IPAddrRNMS	D	STRING
SYS_CONFIG_DYNAMIC	DiskUsageLimit	D	[20-100]
SYS_CONFIG_DYNAMIC	OvldSampleRate	D	[500-10000]
SYS_CONFIG_DYNAMIC	OvldLevel1Percent	D	[0-100]
SYS_CONFIG_DYNAMIC	OvldLevel1Filter	D	STRING
SYS_CONFIG_DYNAMIC	OvldLevel1ThreshLowerCalls	D	[1-5000]
SYS_CONFIG_DYNAMIC	OvldLevel1ThreshUpperCalls	D	[1-5000]
SYS_CONFIG_DYNAMIC	OvldLevel1ThreshLowerCPU	D	[0-100]
SYS_CONFIG_DYNAMIC	OvldLevel1ThreshUpperCPU	D	[0-100]
SYS_CONFIG_DYNAMIC	OvldLevel2Percent	D	[0-100]
SYS_CONFIG_DYNAMIC	OvldLevel2Filter	D	STRING
SYS_CONFIG_DYNAMIC	OvldLevel2ThreshLowerCalls	D	[1-5000]
SYS_CONFIG_DYNAMIC	OvldLevel2ThreshUpperCalls	D	[1-5000]
SYS_CONFIG_DYNAMIC	OvldLevel2ThreshLowerCPU	D	[0-100]

SYS_CONFIG_DYNAMIC	OvldLevel2ThreshUpperCPU	D	[0-100]
SYS_CONFIG_DYNAMIC	OvldLevel3Percent	D	[0-100]
SYS_CONFIG_DYNAMIC	OvldLevel3Filter	D	STRING
SYS_CONFIG_DYNAMIC	OvldLevel3ThreshLowerCalls	D	[1-5000]
SYS_CONFIG_DYNAMIC	OvldLevel3ThreshUpperCalls	D	[1-5000]
SYS_CONFIG_DYNAMIC	OvldLevel3ThreshLowerCPU	D	[0-100]
SYS_CONFIG_DYNAMIC	OvldLevel3ThreshUpperCPU	D	[0-100]
SYS_CONFIG_DYNAMIC	CiAgentScanPeriod	D	[]
SYS_CONFIG_DYNAMIC	AlarmDebounceTime	D	[0-60000]
SYS_CONFIG_DYNAMIC	RegFailureReleaseCause	D	[1-127]

```
##### ras #####
```

```
#Static
```

RAS	manualRAS	S	NULL
-----	-----------	---	------

```
##### ras #####
```

```
#Dynamic
```

RAS	responseTimeOut	D	[1-200]
RAS	maxFail	D	[1-200]
RAS	allowCallsWhenNonReg	D	NULL
RAS	manualRegistration	D	NULL
RAS	timeToLive	D	[1-65535]
RAS	rasPort	D	[0-65535]
RAS	compare15bitRasCrv	D	NULL
RAS	maxRetries	D	[1-200]
RAS	maxMulticastTTL	D	[0-200]
RAS	preGrantedArqUse	D	STRING
RAS	manualDiscovery.ipAddress	D	STRING
RAS	manualDiscovery.port	D	[0-65535]
RAS	gateway.prefix[i]	D	STRING
RAS	gatekeeperId	D	STRING
RAS	terminalAlias[i].e164	D	STRING
RAS	terminalAlias[i].h323ID	D	STRING
RAS	endpointVendor.t35CountryCode	D	[0-255]
RAS	endpointVendor.t35Extension	D	[0-255]
RAS	endpointVendor.manufacturerCode	D	[0-65535]
RAS	endpointVendor.productId	D	STRING
RAS	endpointVendor.versionId	C	STRING

***** q931 *****

#Dynamic

Q931	responseTimeOut	D	[1-200]
Q931	connectTimeOut	D	[1-20000]
Q931	callSignalingPort	D	[0-65535]
Q931	maxCalls	D	[0-5000]
Q931	notEstablishControl	D	NULL
Q931	overlappedSending	C	NULL
Q931	earlyH245	C	NULL
Q931	h245tunneling	C	NULL

***** h245 *****

#Dynamic

H245	masterSlave.terminalType	D	[0-255]
H245	masterSlave.manualResponse	D	NULL
H245	masterSlave.timeout	D	[0-65535]
H245	masterSlave.manualOperation	D	NULL
H245	channelsTimeout	D	[0-65535]
H245	roundTripTimeout	D	[0-65535]
H245	requestCloseTimeout	D	[0-65535]
H245	requestModeTimeout	D	[0-65535]
H245	mediaLoopTimeout	D	[0-65535]
H245	caps.manualOperation	D	NULL
H245	caps.timeout	D	[0-65535]
H245	caps.maxAudioDelay	D	[0-1023]
H245	caps.table[i].entryNo	D	[1-65535]
H245	caps.table[i].audio.g711Alaw64k	D	[1-256]
H245	caps.table[i].audio.g711Alaw56k	D	[1-256]
H245	caps.table[i].audio.g711Ulaw64k	D	[1-256]
H245	caps.table[i].audio.g711Ulaw56k	D	[1-256]
H245	caps.table[i].audio.g722at64k	D	[1-256]
H245	caps.table[i].audio.g722at56k	D	[1-256]
H245	caps.table[i].audio.g722at48k	D	[1-256]
H245	caps.table[i].audio.g728	D	[1-256]
H245	caps.table[i].audio.g729	D	[1-256]
H245	caps.table[i].audio.g729.echo[i]22k	D	[1-256]

H245	caps.table[i].audio.g7231.maxAudioFrames	D	[1-256]
H245	caps.table[i].audio.g7231.silenceSuppression	D	[1-256]
H245	chan[i].name	D	STRING
H245	chan[i].audio.g711Alaw64k	D	[1-256]
H245	chan[i].audio.g711Alaw56k	D	[1-256]
H245	chan[i].audio.g711Ulaw64k	D	[1-256]
H245	chan[i].audio.g711Ulaw56k	D	[1-256]
H245	chan[i].audio.g722at64k	D	[1-256]
H245	chan[i].audio.g722at56k	D	[1-256]
H245	chan[i].audio.g722at48k	D	[1-256]
H245	chan[i].audio.g728	D	[1-256]
H245	chan[i].audio.g729	D	[1-256]
H245	chan[i].audio.g7231.maxAudioFrames	D	[1-256]
H245	chan[i].audio.g7231.silenceSuppression	D	[1-256]
H245	modes[i].name	D	STRING
H245	modes[i].audio.g711Alaw64k	D	NULL
H245	modes[i].audio.g711Alaw56k	D	NULL
H245	modes[i].audio.g711Ulaw64k	D	NULL
H245	modes[i].audio.g711Ulaw56k	D	NULL
H245	modes[i].audio.g722at64k	D	NULL
H245	modes[i].audio.g722at56k	D	NULL
H245	modes[i].audio.g722at48k	D	NULL
H245	modes[i].audio.g728	D	NULL
H245	modes[i].audio.g729	D	NULL
H245	modes[i].audio.g7231	D	NULL

***** From GWmain.static.conf *****

#Logging

#Const

Logging	Application	D	[0-65535]
Logging	CallControl	D	[0-65535]
Logging	CC	D	[0-65535]
Logging	Connection	D	[0-65535]
Logging	DataManager	D	[0-65535]
Logging	Eisup	D	[0-65535]


```

Logging    FaultManager    D    [0-65535]
Logging    Gapping            D    [0-65535]
Logging    H323              D    [0-65535]
Logging    Infrastructure      D    [0-65535]
Logging    Overload           D    [0-65535]
Logging    ProcessManager     D    [0-65535]
Logging    Provisioning       D    [0-65535]
Logging    Signal             D    [0-65535]
Logging    Snmp               D    [0-65535]
Logging    SnmpSubagent      D    [0-65535]
Logging    Statistics         D    [0-65535]
Logging    Trace              D    [0-65535]
Logging    UserInterface     D    [0-65535]
Logging    Configuration      D    [0-65535]
Logging    Timer              D    [0-65535]
Logging    EISUP             D    [0-65535]
Logging    OTLogging         D    STRING

```

##

Call Control Package

##

```

CCPackage    Hash                C                STRING
CCPackage    Pound               C                STRING
CCPackage    Star                C                STRING
CCPackage    StopDigit          C                STRING

```

```

CCPackage    A_CC_ChargeInd      D                []
CCPackage    A_CC_tEndToEndMethod C                []
CCPackage    A_CC_tLineUser      D                []
CCPackage    A_CC_tLineStatus    C                []
CCPackage    A_CC_MLC_Action     C                []
CCPackage    A_CC_tSCCPMethod    C                []
CCPackage    A_CC_Interworking   D                []
CCPackage    A_CC_tEndToEndInfAvail C                []
CCPackage    A_CC_tIsdnAllTheWay D                []
CCPackage    A_CC_tEchoCancIr    C                []
CCPackage    A_CC_tLineAccess    D                []

```

CCPackage	A_CC_BNumDataNOA	D	[]
CCPackage	A_CC_BNumDataNPI	C	[]
CCPackage	A_CC_BNumDataINN	D	[]
CCPackage	A_CC_ANumDataNOA	D	[]
CCPackage	A_CC_Clr	D	[]
CCPackage	A_CC_ANumDataSI	D	[]
CCPackage	A_CC_ANumDataNPI	C	[]
CCPackage	A_CC_A_Cli	C	[]
CCPackage	A_CC_AddANumDataNOA	C	[]
CCPackage	A_CC_AddANumDataSI	D	[]
CCPackage	A_CC_AddANumDataNPI	C	[]
CCPackage	A_CC_AddANumDataCLIR	D	[]
CCPackage	A_CC_oLinecall	D	[]
CCPackage	A_CC_Location	D	[]
CCPackage	A_CC_CodeStandard	C	[]
CCPackage	A_CC_ProgressRestrict	C	[]
CCPackage	A_CC_oIsdnPref	C	[]
CCPackage	A_CC_oIsdnAllTheWay	C	[]
CCPackage	A_CC_oEndToEndInfAvail	C	[]
CCPackage	A_CC_oNatInd	C	[]
CCPackage	A_CC_oLSPP	C	[]
CCPackage	A_CC_oNBit	C	[]
CCPackage	A_CC_oPORC	C	[]
CCPackage	A_CC_oPBit	C	[]
CCPackage	A_CC_oEndToEndMethod	C	[]
CCPackage	A_CC_CollectCallInd	C	[]
CCPackage	A_CC_oSCCPMethod	C	[]
CCPackage	A_CC_GDES	C	[]
CCPackage	A_CC_GDTD	C	[]
CCPackage	A_CC_NOCI_VC	C	[]
CCPackage	A_CC_NOCI_ECIDI	C	[]
CCPackage	A_CC_NOCI_CCI	C	[]
CCPackage	A_CC_NOCI_SI	C	[]
CCPackage	A_CC_TMR	C	[]
CCPackage	A_CC_INFO_CFN	C	[]
CCPackage	A_CC_GAPPEDCALLCAUSE	C	[]
CCPackage	A_CC_WAIT_CONFIRM	C	[]
CCPackage	A_CC_WAIT_ANSWER	C	[]

CCPackage	A_CC_NUM_REL_RETRIES	C	[]
CCPackage	A_CC_WAIT_REL_RETRY	C	[]
CCPackage	A_CC_WAIT_RLC_FAIL	C	[]
# Cause code map			
CCPackage	CC_EC_UnallocatedNumber	C	STRING
CCPackage	CC_EC_NoRouteToTns	C	STRING
CCPackage	CC_EC_NoRouteToDest	C	STRING
CCPackage	CC_EC_SpecialInformationTone	C	STRING
CCPackage	CC_EC_MisdialledTkPrefix	C	STRING
CCPackage	CC_EC_ChUnacceptable	C	STRING
CCPackage	CC_EC_CallAwardedDeliveredEstCh	C	STRING
CCPackage	CC_EC_Preemption	C	STRING
CCPackage	CC_EC_PreemptionCctRes	C	STRING
CCPackage	CC_EC_NormalClearing	C	STRING
CCPackage	CC_EC_UserBusy	C	STRING
CCPackage	CC_EC_NoUserResponding	C	STRING
CCPackage	CC_EC_NoAnswerAlertedUser	C	STRING
CCPackage	CC_EC_SubAbscent	C	STRING
CCPackage	CC_EC_CallRejected	C	STRING
CCPackage	CC_EC_NumberChanged	C	STRING
CCPackage	CC_EC_RedirectionToNewDest	C	STRING
CCPackage	CC_EC_RoutingError	C	STRING
CCPackage	CC_EC_NonSelectedUserClearing	C	STRING
CCPackage	CC_EC_DestOutOfOrder	C	STRING
CCPackage	CC_EC_InvalidNumberFormat	C	STRING
CCPackage	CC_EC_FacilityRejected	C	STRING
CCPackage	CC_EC_ResponseToStatusEnquiry	C	STRING
CCPackage	CC_EC_NormalUnspecified	C	STRING
CCPackage	CC_EC_NoCircuitAvailable	C	STRING
CCPackage	CC_EC_NetworkOutOfOrder	C	STRING
CCPackage	CC_EC_PermanentFrameModeOos	C	STRING
CCPackage	CC_EC_PermanentFrameModeOperational	C	STRING
CCPackage	CC_EC_TemporaryFailure	C	STRING
CCPackage	CC_EC_SwitchingEquipCongestion	C	STRING
CCPackage	CC_EC_AccessInfoDiscarded	C	STRING
CCPackage	CC_EC_ReqCircuitUnavail	C	STRING

CCPackage	CC_EC_PrecedenceBlocked	C	STRING
CCPackage	CC_EC_ResourcesUnavailUnspec	C	STRING
CCPackage	CC_EC_QualityUnavail	C	STRING
CCPackage	CC_EC_ReqFacilityNotSubscr	C	STRING
CCPackage	CC_EC_OutgoingCallsBarredInCug	C	STRING
CCPackage	CC_EC_IncomingCallsBarredInCug	C	STRING
CCPackage	CC_EC_BearcapNotAuthorized	C	STRING
CCPackage	CC_EC_BaercapNotAvail	C	STRING
CCPackage	CC_EC_InconOutgoingAccAndSubClass	C	STRING
CCPackage	CC_EC_ServiceOrOptionNotAvail	C	STRING
CCPackage	CC_EC_BearcapNotImp	C	STRING
CCPackage	CC_EC_ChTypeNotImp	C	STRING
CCPackage	CC_EC_ReqFacilityNotImp	C	STRING
CCPackage	CC_EC_OnlyRestrictDigInfoBearer	C	STRING
CCPackage	CC_EC_ServiceOrOptionNotImpUnspec	C	STRING
CCPackage	CC_EC_InvalidCallReferenceValue	C	STRING
CCPackage	CC_EC_ChIdNotExist	C	STRING
CCPackage	CC_EC_SuspendExistButNotThisId	C	STRING
CCPackage	CC_EC_CallIdInUse	C	STRING
CCPackage	CC_EC_NoCallSuspended	C	STRING
CCPackage	CC_EC_CallIdHasBeenCleared	C	STRING
CCPackage	CC_EC_UserNotMemberOfCug	C	STRING
CCPackage	CC_EC_IncompatibleDest	C	STRING
CCPackage	CC_EC_NonExistentCug	C	STRING
CCPackage	CC_EC_InvalidTns	C	STRING
CCPackage	CC_EC_InvalidMsgUnspec	C	STRING
CCPackage	CC_EC_MandatoryElementMissing	C	STRING
CCPackage	CC_EC_MsgTypeNotImp	C	STRING
CCPackage	CC_EC_MsgTypeNotImpOrWrongState	C	STRING
CCPackage	CC_EC_ElemTypeNotImp	C	STRING
CCPackage	CC_EC_InvalidElemContents	C	STRING
CCPackage	CC_EC_MsgInWrongState	C	STRING
CCPackage	CC_EC_RecoveryOnTimerExpiry	C	STRING
CCPackage	CC_EC_ParamUnrecPassed	C	STRING
CCPackage	CC_HC_UnallocatedNumber	C	STRING
CCPackage	CC_HC_NoRouteToSpecifiedTransitNetwork	C	STRING
CCPackage	CC_HC_NoRouteToDestination	C	STRING
CCPackage	CC_HC_SendSpecialInformationTone	C	STRING

CCPackage	CC_HC_MisdialedTrunkPrefix	C	STRING
CCPackage	CC_HC_ChannelUnacceptable	C	STRING
CCPackage	CC_HC_CallAwardedEstablishedChannel	C	STRING
CCPackage	CC_HC_Preemption	C	STRING
CCPackage	CC_HC_PreemptionCircuitReservedForReuse	C	STRING
CCPackage	CC_HC_NormalCallClearing	C	STRING
CCPackage	CC_HC_UserBusy	C	STRING
CCPackage	CC_HC_NoUserresponding	C	STRING
CCPackage	CC_HC_NoAnswerFromAlertedUser	C	STRING
CCPackage	CC_HC_SubscriberAbsent	C	STRING
CCPackage	CC_HC_CallRejected	C	STRING
CCPackage	CC_HC_NumberChanged	C	STRING
CCPackage	CC_HC_RedirectionToNewDestination	C	STRING
CCPackage	CC_HC_ExchangeRouteError	C	STRING
CCPackage	CC_HC_NonSelectedUserClearing	C	STRING
CCPackage	CC_HC_DestinationOutOfOrder	C	STRING
CCPackage	CC_HC_InvalidNumberFormat	C	STRING
CCPackage	CC_HC_FacilityRejected	C	STRING
CCPackage	CC_HC_ResponseToStatusEnquiry	C	STRING
CCPackage	CC_HC_NormalUnspecified	C	STRING
CCPackage	CC_HC_NoCircuitChannelAvailable	C	STRING
CCPackage	CC_HC_NetworkOutOfOrder	C	STRING
CCPackage	CC_HC_PermanentFrameModeConnectionOutOfService	C	STRING
CCPackage	CC_HC_PermanentFrameModeConnectionOperational	C	STRING
CCPackage	CC_HC_TemporaryFailure	C	STRING
CCPackage	CC_HC_SwitchingEquipmentCongestion	C	STRING
CCPackage	CC_HC_AccessInformationDiscarded	C	STRING
CCPackage	CC_HC_RequestedCircuitChannelNotAvailable	C	STRING
CCPackage	CC_HC_PrecedenceCallBlocked	C	STRING
CCPackage	CC_HC_ResourceUnavailable	C	STRING
CCPackage	CC_HC_QualityOfServiceNotAvailable	C	STRING
CCPackage	CC_HC_RequestedFacilityNotSubscribed	C	STRING
CCPackage	CC_HC_OutgoingCallsBaredWithinCUG	C	STRING
CCPackage	CC_HC_IncomingCallsBaredWithinCUG	C	STRING
CCPackage	CC_HC_BearerCapabilityNotAuthorized	C	STRING
CCPackage	CC_HC_BearerCapabilityNotPresentlyAvailable	C	STRING
CCPackage	CC_HC_InconsistencyAccessInfoSubscriberClass	C	STRING
CCPackage	CC_HC_ServiceOrOptionUnavailable	C	STRING

CCPackage	CC_HC_BearerCapabilityNotImplemented	C	STRING
CCPackage	CC_HC_ChannelTypeNotImplemented	C	STRING
CCPackage	CC_HC_RequestedFacilityNotImplemented	C	STRING
CCPackage	CC_HC_OnlyRestrictedDigitalBearerInfoCapability	C	STRING
CCPackage	CC_HC_ServiceOrOptionNotImplemented	C	STRING
CCPackage	CC_HC_InvalidCallreferenceValue	C	STRING
CCPackage	CC_HC_IdentifiedChannelDoesNotExist	C	STRING
CCPackage	CC_HC_ASuspendedCallExistsThisCallIdDoesNot	C	STRING
CCPackage	CC_HC_CallIdentityInUse	C	STRING
CCPackage	CC_HC_NoCallSuspended	C	STRING
CCPackage	CC_HC_CallHavingTheRequestedCallIdHasBeenCleared	C	STRING
CCPackage	CC_HC_UserNotMemberOfCUG	C	STRING
CCPackage	CC_HC_IncompatibleDestination	C	STRING
CCPackage	CC_HC_NonExistantCUG	C	STRING
CCPackage	CC_HC_InvalidTransitNetworkSelection	C	STRING
CCPackage	CC_HC_InvalidMessage	C	STRING
CCPackage	CC_HC_MandatoryInformationElementIsMissing	C	STRING
CCPackage	CC_HC_MessageTypeNonExistantOrNotImplemented	C	STRING
CCPackage	CC_HC_MessageTypeNotCompatibleWithStateOrNonExistantOrNotImplemented	C	STRING
CCPackage	CC_HC_InformationElementParameterNonExistantOrNotImplemented	C	STRING
CCPackage	CC_HC_InvalidInformationElementContents	C	STRING
CCPackage	CC_HC_MessageNotCompatibleWithCallState	C	STRING
CCPackage	CC_HC_RecoveryOnTimerExpiry	C	STRING
CCPackage	CC_HC_ParameterNonExistantOrNotImplementedPassedOn	C	STRING

```
#
# Package Gapping
# Set the gapping percentage level for each side. A level of 0
# indicates no gapping
# A level of 100 indicates gap all calls (except priority calls -
# see treatment below)
#
```

Gapping	H323level	C	[]
Gapping	EISUPlevel	C	[]

```
#
# Priority treatment determines the treatment of priority calls
# during gapping.
# GapAlways indicates priority calls are treated as normal calls
# GapNever indicate priority calls are never to be gapped
# GapOn100PercentGapping indicates priority calls are only gapped
# when 100 percent gapping is applied.
#
```

```
Gapping          PriorityCallTreatment    C          STRING
```

```
#
# Configuration for trace package
# There are five trace trigger locations. Each location can hold one type of
# six trigger types as follows:
#
# EISUP CallingPartyNumber (E.164 address)
# EISUP CalledPartyNumber (E.164 address)
# H323 CallingPartyNumber (E.164 address)
# H323 CalledPartyNumber (E.164 address)
# H323 OriginatingIPAddress and H323 OriginatingIPMask (dotted notation)
# H323 TerminatingIPAddress and TerminatingIPMask (dotted notation)
#
```

```
Trace  TraceOutputFilename                C          STRING
Trace  Trigger1.eisup.CallingPartyNumber    C          []
Trace  Trigger1.eisup.CalledPartyNumber     C          []
Trace  Trigger1.h323.CallingPartyNumber     C          []
Trace  Trigger1.h323.CalledPartyNumber      C          []
Trace  Trigger1.h323.OriginatingIPAddress   C          []
Trace  Trigger1.h323.OriginatingIPMask     C          []
Trace  Trigger1.h323.TerminatingIPAddress   C          []
Trace  Trigger1.h323.TerminatingIPMask     C          []

Trace  Trigger2.eisup.CallingPartyNumber    C          []
Trace  Trigger2.eisup.CalledPartyNumber     C          []
Trace  Trigger2.h323.CallingPartyNumber     C          []
```

Trace	Trigger2.h323.CalledPartyNumber	C	STRING
Trace	Trigger2.h323.OriginatingIPAddress	C	STRING
Trace	Trigger2.h323.OriginatingIPMask	C	STRING
Trace	Trigger2.h323.TerminatingIPAddress	C	STRING
Trace	Trigger2.h323.TerminatingIPMask	C	STRING
Trace	Trigger3.eisup.CallingPartyNumber	C	[]
Trace	Trigger3.eisup.CalledPartyNumber	C	[]
Trace	Trigger3.h323.CallingPartyNumber	C	[]
Trace	Trigger3.h323.CalledPartyNumber	C	[]
Trace	Trigger3.h323.OriginatingIPAddress	C	[]
Trace	Trigger3.h323.OriginatingIPMask	C	[]
Trace	Trigger3.h323.TerminatingIPAddress	C	[]
Trace	Trigger3.h323.TerminatingIPMask	C	[]
Trace	Trigger4.eisup.CallingPartyNumber	C	[]
Trace	Trigger4.eisup.CalledPartyNumber	C	[]
Trace	Trigger4.h323.CallingPartyNumber	C	[]
Trace	Trigger4.h323.CalledPartyNumber	C	[]
Trace	Trigger4.h323.OriginatingIPAddress	C	[]
Trace	Trigger4.h323.OriginatingIPMask	C	[]
Trace	Trigger4.h323.TerminatingIPAddress	C	[]
Trace	Trigger4.h323.TerminatingIPMask	C	[]
Trace	Trigger5.eisup.CallingPartyNumber	C	[]
Trace	Trigger5.eisup.CalledPartyNumber	C	[]
Trace	Trigger5.h323.CallingPartyNumber	C	[]
Trace	Trigger5.h323.CalledPartyNumber	C	[]
Trace	Trigger5.h323.OriginatingIPAddress	C	STRING
Trace	Trigger5.h323.OriginatingIPMask	C	STRING
Trace	Trigger5.h323.TerminatingIPAddress	C	STRING
Trace	Trigger5.h323.TerminatingIPMask	C	STRING
#			
#	TraceTriggerSwitch(for CLI/SNMP application)		
#	This gates the output of the trigger data for each location		
#			
Trace	TriggerGate1	C	STRING


```
Trace TriggerGate2 C STRING
Trace TriggerGate3 C STRING
Trace TriggerGate4 C STRING
Trace TriggerGate5 C STRING
```

```
##
```

```
## Package EISUP
```

```
##
```

```
#
```

```
#The period for CISCO's RUDP timer manager in milli seconds
```

```
#
```

```
EISUP RUDP_TIMER_CHECK_PERIOD_MSEC C []
```

```
#The time to wait before failing over to another vsc.
```

```
EISUP WAIT_TIME_BEFORE_FAIL_OVER_MILLI_SEC C []
```

```
##
```

```
## Package Application
```

```
##
```

```
Application DefaultCallProcessingStatus C STRING
```

```
Application WaitBeforeCallReleaseTimer C []
```

```
Application RestartPendingTimer C []
```

```
Application HaltPendingTimer C []
```

```
Application RebootPendingTimer C []
```

```
#
```

```
#Information required by the rtrv-ne-health MML command
```

```
#
```

```
Application Hardware C STRING
```

```
Application Location C STRING
```

```
##
```

```
## Package H323
```

```

##
H323    maxTimers          C          []
H323    tickPeriod        C          []
H323    defaultSDPt       C          STRING
H323    overrideConfig    S          [0-1]
H323    defaultRadLog     S          [0-4]

##
## Statistics
##
Statistics  StatLogFileName  D          STRING
Statistics  StatOutputTime    D          [0-65535]

#
# Test entries for provisioning tests.
#

RAS    NumberNoRangeConst  C          []
RAS    NumberRangeDynamic2_4  D          [2-4]

H245   NumberNoRangeConst  C          []
H245   NumberRangeStatic1_4  S          [1-4]

Q931   QuotedDynamic        D          STRING
Q931   NonQuotedConst       C          STRING
Q931   ConnectTimeoutConst  C          STRING

```



Example of an HSI Configuration File

This appendix presents an example of an HSI configuration file.



Note

The configuration file does not contain a complete list of all configurable items.

```
#verified
#
# $Id: GWmain.base.conf,v 1.6 2002/09/09 15:27:10 syousaf Exp $
#

# This is the base configuration file that is concatenated to
# a file derived from questions at install time, to generate the GWmain.conf
# file, which is used by the Application GWmain.

#####
##
# LOGGING PACKAGE
#
# The Logging package determines the logging level for all defined packages.
# This is a bit mask which controls the 16 debug levels
#
Package = Logging
#
OTLogging      = "ON"           #Choice {ON, OFF}. Default: "OFF"

Application    = 0x0000
#CallControl   = 0xFF00
CallControl    = 0x0000
```

```

Connection          = 0x0000
#Connection         = 0xFF00
DataManager         = 0x0000
#Eisup              = 0xFF00
Eisup               = 0x0000
FaultManager        = 0x0000
Gapping             = 0x0000
H323                 = 0x0000
Infrastructure       = 0x0000
Overload            = 0x0000
ProcessManager      = 0x0000
Provisioning         = 0x0000
Signal              = 0x0000
Snmp                 = 0x0000
SnmpSubagent        = 0x0000
Statistics           = 0x0000
Trace                = 0x0000
UserInterface       = 0x0000

```

```

#####
##
# H323 Service Package
#
# Not modifiable at runtime (Static Provisionable Data)
#
Package = H323
#
maxTimers = 20
tickPeriod = 1000
defaultSDPt = "v=0\r\no=\r\ns=\r\nnt=0 0\r\nnc=IN IP4 0.0.0.0\r\nnm=audio 0 RTP/AVP 0 8\r\n"
overrideConfig = 0 # Set to 1 to use the override_config.val file instead of RVConfig
defaultRadLog = 0 # Set to 3(or any rad log level) to start radvision logging at startup.

#####
##
# H323 RADVision SYSTEM Package
#

```

```
# Not modifiable at runtime (Static Provisionable Data)
```

```
#
```

```
Package = H323_SYS
```

```
#
```

```
maxCalls = 2500
```

```
maxChannels = 2
```

```
#####  
##
```

```
# Q931 RADVIsion PACKAGE
```

```
#
```

```
Package = Q931
```

```
#
```

```
responseTimeOut = 60
```

```
connectTimeOut = 180
```

```
callSignalingPort = 1720
```

```
maxCalls = 2500
```

```
#notEstablishControl =
```

```
overlappedSending =
```

```
earlyH245 =
```

```
h245Tunneling =
```

```
#####  
###
```

```
# H323 RADVIsion RAS Package
```

```
#
```

```
# Modifiable at runtime (Dynamic Provisionable Data) except for manualRAS
```

```
#
```

```
Package = RAS
```

```
#
```

```
responseTimeOut = 30
```

```
#manualRAS =
```

```
maxFail = 3
```

```
#allowCallsWhenNonReg =
```

```
#manualRegistration =
endpointVendor.productID = "GoldWing"
endpointVendor.t35CountryCode = 11
endpointVendor.t35Extension = 11
endpointVendor.manufacturerCode = 9
timeToLive = 600
rasPort = 0
#compare15bitRasCrv =
maxRetries = 3
maxMulticastTTL = 3
preGrantedArqUse = direct
```

```
#####
####
# H245 RADVision PACKAGE
#
# Dynamically Provisionable except for manualOperation(s)
Package = H245
#
channelsTimeout = 30
#roundTripTimeout = 5
#requestCloseTimeout = 5
#requestModeTimeout = 5
#mediaLoopTimeout = 5
## MasterSlave Determination
masterSlave.terminalType = 60
masterSlave.manualOperation =
masterSlave.manualResponse =
masterSlave.timeout = 30
caps.manualOperation =
caps.timeout = 30
caps.maxAudioDelay = 60
caps.table[1].entryNo = 7111
caps.table[1].audio.g711Ulaw64k = 20
caps.table[2].entryNo = 7110
caps.table[2].audio.g711Alaw64k = 20
```

```

caps.table[3].entryNo = 728
caps.table[3].audio.g728 = 20
chan[1].name = g711Alaw64k
chan[1].audio.g711Alaw64k = 20
chan[2].name = g711Ulaw64k
chan[2].audio.g711Ulaw64k = 20
chan[3].name = g728
chan[3].audio.g728 = 20
modes[1].name = g711Alaw64k
modes[1].audio.g711Alaw64k =
modes[2].name = g711Ulaw64k
modes[2].audio.g711Ulaw64k =
#modes[3].name = g728
#modes[3].audio.g728 =

```

```

#####
##

```

```

# CALL CONTROL PACKAGE

```

```

#

```

```

##

```

```

Package = CCPackage

```

```

#

```

```

Hash = A

```

```

Pound = A

```

```

Star = B

```

```

StopDigit = "#"

```

```

A_CC_ChargeInd = # BCI

```

```

A_CC_tEndToEndMethod =

```

```

A_CC_tLineUser =

```

```

A_CC_tLineStatus =

```

```

A_CC_MLC_Action =

```

```

A_CC_tSCCPMethod =

```

```

A_CC_Interworking =

```

```

A_CC_tEndToEndInfAvail =

```

```

A_CC_tIsdnAllTheWay =

```

```

A_CC_tEchoCancIr =
A_CC_tLineAccess =
A_CC_BNumDataNOA =      # CalledPN
A_CC_BNumDataNPI =
A_CC_BNumDataINN =
A_CC_ANumDataNOA =      # CallingPN
A_CC_Clr =
A_CC_ANumDataSI =
A_CC_ANumDataNPI =
A_CC_A_Cli =
A_CC_oLinecall = # CallingPC
A_CC_Location = # CauseInd
A_CC_CodeStandard =
A_CC_ProgressRestrict = # Event Info
A_CC_oIsdnPref = # FCI
A_CC_oIsdnAllTheWay =
A_CC_oEndToEndInfAvail =
A_CC_oNatInd =
A_CC_oLSP =
A_CC_oNBit =
A_CC_oPORC =
A_CC_oPBit =
A_CC_oEndToEndMethod =
A_CC_CollectCallInd =
A_CC_oSCCPMethod =
A_CC_GDES = # GenericDigits
A_CC_GDTD =
A_CC_NOCI_VC = # NatureOfConnection
A_CC_NOCI_ECDI =
A_CC_NOCI_CCI =
A_CC_NOCI_SI =
A_CC_TMR = # TransmissionMediumRequired
A_CC_INFO_CFN = # confusion code on INFO receipt
A_CC_GAPPEDCALLCAUSE = 60 # congestion cause for releasing on gapping
A_CC_WAIT_CONFIRM = 30 #20..30 seconds (default is 30), from q764
A_CC_WAIT_ANSWER = 180 #90..180 seconds (default is 180), from q118, refd in

# ----- Cause Codes -----

```


CC: Call Control, EC: EISUP Cause, HC: H323 Cause

For the EISUP cause code values see CISCO: EISUP Protocol Specification ENG-46168 version 19

For the H323 cause code values see ITU-T: Q.850

The mappings below are considered constant and not provisionable.

They can be made provisionable by moving them from the CCPackage

to the SYS_CONFIG_STATIC package.

The following is the EISUP to H323 cause code map.

When the EISUP cause on the left is received from EISUP,

the H323 cause on right is sent to H323.

Note: the reverse is not true, this is a one way mapping.

The H323 to EISUP cause map is defined in further down.

CC_EC_UnallocatedNumber	= CC_HC_UnallocatedNumber
CC_EC_NoRouteToTns	= CC_HC_NoRouteToSpecifiedTransitNetwork
CC_EC_NoRouteToDest	= CC_HC_NoRouteToDestination
CC_EC_SpecialInformationTone	= CC_HC_SendSpecialInformationTone
CC_EC_MisdialledTkPrefix	= CC_HC_MisdialledTrunkPrefix
CC_EC_ChUnacceptable	= CC_HC_ChannelUnacceptable
CC_EC_CallAwardedDeliveredEstCh	= CC_HC_CallAwardedEstablishedChannel
CC_EC_Preemption	= CC_HC_Preemption
CC_EC_PreemptionCctRes	= CC_HC_PreemptionCircuitReservedForReuse
CC_EC_NormalClearing	= CC_HC_NormalCallClearing
CC_EC_UserBusy	= CC_HC_UserBusy
CC_EC_NoUserResponding	= CC_HC_NoUserresponding
CC_EC_NoAnswerAlertedUser	= CC_HC_NoAnswerFromAlertedUser
CC_EC_SubAbsent	= CC_HC_SubscriberAbsent
CC_EC_CallRejected	= CC_HC_CallRejected
CC_EC_NumberChanged	= CC_HC_NumberChanged
CC_EC_RedirectionToNewDest	= CC_HC_RedirectionToNewDestination
CC_EC_RoutingError	= CC_HC_ExchangeRouteError
CC_EC_NonSelectedUserClearing	= CC_HC_NonSelectedUserClearing
CC_EC_DestOutOfOrder	= CC_HC_DestinationOutOfOrder
CC_EC_InvalidNumberFormat	= CC_HC_InvalidNumberFormat
CC_EC_FacilityRejected	= CC_HC_FacilityRejected

CC_EC_ResponseToStatusEnquiry	=	CC_HC_ResponseToStatusEnquiry
CC_EC_NormalUnspecified	=	CC_HC_NormalUnspecified
CC_EC_NoCircuitAvailable	=	CC_HC_NoCircuitChannelAvailable
CC_EC_NetworkOutOfOrder	=	CC_HC_NetworkOutOfOrder
CC_EC_PermanentFrameModeOos	=	CC_HC_PermanentFrameModeConnectionOutOfService
CC_EC_PermanentFrameModeOperational	=	CC_HC_PermanentFrameModeConnectionOperational
CC_EC_TemporaryFailure	=	CC_HC_TemporaryFailure
CC_EC_SwitchingEquipCongestion	=	CC_HC_SwitchingEquipmentCongestion
CC_EC_AccessInfoDiscarded	=	CC_HC_AccessInformationDiscarded
CC_EC_ReqCircuitUnavail	=	CC_HC_RequestedCircuitChannelNotAvailable
CC_EC_PrecedenceBlocked	=	CC_HC_PrecedenceCallBlocked
CC_EC_ResourcesUnavailUnspec	=	CC_HC_ResourceUnavailable
CC_EC_QualityUnavail	=	CC_HC_QualityOfServiceNotAvailable
CC_EC_ReqFacilityNotSubscr	=	CC_HC_RequestedFacilityNotSubscribed
CC_EC_OutgoingCallsBarredInCug	=	CC_HC_OutgoingCallsBaredWithinCUG
CC_EC_IncomingCallsBarredInCug	=	CC_HC_IncomingCallsBaredWithinCUG
CC_EC_BearcapNotAuthorized	=	CC_HC_BearerCapabilityNotAuthorized
CC_EC_BaercapNotAvail	=	CC_HC_BearerCapabilityNotPresentlyAvailable
CC_EC_InconOutgoingAccAndSubClass	=	CC_HC_InconsistencyAccessInfoSubscriberClass
CC_EC_ServiceOrOptionNotAvail	=	CC_HC_ServiceOrOptionUnavailable
CC_EC_BearcapNotImp	=	CC_HC_BearerCapabilityNotImplemented
CC_EC_ChTypeNotImp	=	CC_HC_ChannelTypeNotImplemented
CC_EC_ReqFacilityNotImp	=	CC_HC_RequestedFacilityNotImplemented
CC_EC_OnlyRestrictDigInfoBearer	=	CC_HC_OnlyRestrictedDigitalBearerInfoCapability
CC_EC_ServiceOrOptionNotImpUnspec	=	CC_HC_ServiceOrOptionNotImplemented
CC_EC_InvalidCallReferenceValue	=	CC_HC_InvalidCallreferenceValue
CC_EC_ChIdNotExist	=	CC_HC_IdentifiedChannelDoesNotExist
CC_EC_SuspendExistButNotThisId	=	CC_HC_ASuspendedCallExistsThisCallIdDoesNot
CC_EC_CallIdInUse	=	CC_HC_CallIdentityInUse
CC_EC_NoCallSuspended	=	CC_HC_NoCallSuspended
CC_EC_CallIdHasBeenCleared	=	CC_HC_CallHavingTheRequestedCallIdHasBeenCleared
CC_EC_UserNotMemberOfCug	=	CC_HC_UserNotMemberOfCUG
CC_EC_IncompatibleDest	=	CC_HC_IncompatibleDestination
CC_EC_NonExistentCug	=	CC_HC_NonExistantCUG
CC_EC_InvalidTns	=	CC_HC_InvalidTransitNetworkSelection
CC_EC_InvalidMsgUnspec	=	CC_HC_InvalidMessage
CC_EC_MandatoryElementMissing	=	CC_HC_MandatoryInformationElementIsMissing
CC_EC_MsgTypeNotImp	=	CC_HC_MessageTypeNonExistantOrNotImplemented

```

CC_EC_MsgTypeNotImpOrWrongState =
CC_HC_MessageTypeNotCompatibleWithStateOrNonExistantOrNotImplemented
CC_EC_ElemTypeNotImp = CC_HC_InformationElementParameterNonExistantOrNotImplemented
CC_EC_InvalidElemContents          = CC_HC_InvalidInformationElementContents
CC_EC_MsgInWrongState              = CC_HC_MessageNotCompatibleWithCallState
CC_EC_RecoveryOnTimerExpiry        = CC_HC_RecoveryOnTimerExpiry
CC_EC_ParamUnrecPassed              = CC_HC_ParameterNonExistantOrNotImplementedPassedOn

```

```

# When the H323 cause on the left is received from H323,
# the Eisup cause on the right is sent to Eisup.
# Note: the reverse is not true, this is a one way mapping.
#   The Eisup to H323 cause map is defined in above.

```

```

CC_HC_UnallocatedNumber            = CC_EC_UnallocatedNumber
CC_HC_NoRouteToSpecifiedTransitNetwork = CC_EC_NoRouteToTns
CC_HC_NoRouteToDestination          = CC_EC_NoRouteToDest
CC_HC_SendSpecialInformationTone     = CC_EC_SpecialInformationTone
CC_HC_MisdialedTrunkPrefix           = CC_EC_MisdialledTkPrefix
CC_HC_ChannelUnacceptable            = CC_EC_ChUnacceptable
CC_HC_CallAwardedEstablishedChannel = CC_EC_CallAwardedDeliveredEstCh
CC_HC_Preemption                     = CC_EC_Preemption
CC_HC_PreemptionCircuitReservedForReuse = CC_EC_PreemptionCctRes
CC_HC_NormalCallClearing              = CC_EC_NormalClearing
CC_HC_UserBusy                        = CC_EC_UserBusy
CC_HC_NoUserresponding                = CC_EC_NoUserResponding
CC_HC_NoAnswerFromAlertedUser        = CC_EC_NoAnswerAlertedUser
CC_HC_SubscriberAbsent                = CC_EC_SubAbsent
CC_HC_CallRejected                    = CC_EC_CallRejected
CC_HC_NumberChanged                  = CC_EC_NumberChanged
CC_HC_RedirectionToNewDestination     = CC_EC_RedirectionToNewDest
CC_HC_ExchangeRouteError              = CC_EC_RoutingError
CC_HC_NonSelectedUserClearing         = CC_EC_NonSelectedUserClearing
CC_HC_DestinationOutOfOrder           = CC_EC_DestOutOfOrder
CC_HC_InvalidNumberFormat             = CC_EC_InvalidNumberFormat
CC_HC_FacilityRejected                = CC_EC_FacilityRejected
CC_HC_ResponceToStatusEnquiry         = CC_EC_ResponseToStatusEnquiry
CC_HC_NormalUnspecified               = CC_EC_NormalUnspecified

```

CC_HC_NoCircuitChannelAvailable = CC_EC_NoCircuitAvailable
 CC_HC_NetworkOutOfOrder = CC_EC_NetworkOutOfOrder
 CC_HC_PermanentFrameModeConnectionOutOfService = CC_EC_PermanentFrameModeOos
 CC_HC_PermanentFrameModeConnectionOperational = CC_EC_PermanentFrameModeOperational
 CC_HC_TemporaryFailure = CC_EC_TemporaryFailure
 CC_HC_SwitchingEquipmentCongestion = CC_EC_SwitchingEquipCongestion
 CC_HC_AccessInformationDiscarded = CC_EC_AccessInfoDiscarded
 CC_HC_RequestedCircuitChannelNotAvailable = CC_EC_ReqCircuitUnavail
 CC_HC_PrecedenceCallBlocked = CC_EC_PrecedenceBlocked
 CC_HC_ResourceUnavailable = CC_EC_ResourcesUnavailUnspec
 CC_HC_QualityOfServiceNotAvailable = CC_EC_QualityUnavail
 CC_HC_RequestedFacilityNotSubscribed = CC_EC_ReqFacilityNotSubscr
 CC_HC_OutgoingCallsBaredWithinCUG = CC_EC_OutgoingCallsBarredInCug
 CC_HC_IncomingCallsBaredWithinCUG = CC_EC_IncomingCallsBarredInCug
 CC_HC_BearerCapabilityNotAuthorized = CC_EC_BearcapNotAuthorized
 CC_HC_BearerCapabilityNotPresentlyAvailable = CC_EC_BaercapNotAvail
 CC_HC_InconsistencyAccessInfoSubscriberClass = CC_EC_InconOutgoingAccAndSubClass
 CC_HC_ServiceOrOptionUnavailable = CC_EC_ServiceOrOptionNotAvail
 CC_HC_BearerCapabilityNotImplemented = CC_EC_BearcapNotImp
 CC_HC_ChannelTypeNotImplemented = CC_EC_ChTypeNotImp
 CC_HC_RequestedFacilityNotImplemented = CC_EC_ReqFacilityNotImp
 CC_HC_OnlyRestrictedDigitalBearerInfoCapability = CC_EC_OnlyRestrictDigInfoBearer
 CC_HC_ServiceOrOptionNotImplemented = CC_EC_ServiceOrOptionNotImpUnspec
 CC_HC_InvalidCallreferenceValue = CC_EC_InvalidCallReferenceValue
 CC_HC_IdentifiedChannelDoesNotExist = CC_EC_ChIdNotExist
 CC_HC_ASuspendedCallExistsThisCallIdDoesNot = CC_EC_SuspendExistButNotThisId
 CC_HC_CallIdentityInUse = CC_EC_CallIdInUse
 CC_HC_NoCallSuspended = CC_EC_NoCallSuspended
 CC_HC_CallHavingTheRequestedCallIdHasBeenCleared = CC_EC_CallIdHasBeenCleared
 CC_HC_UserNotMemberOfCUG = CC_EC_UserNotMemberOfCug
 CC_HC_IncompatibleDestination = CC_EC_IncompatibleDest
 CC_HC_NonExistantCUG = CC_EC_NonExistentCug
 CC_HC_InvalidTransitNetworkSelection = CC_EC_InvalidTns
 CC_HC_InvalidMessage = CC_EC_InvalidMsgUnspec
 CC_HC_MandatoryInformationElementIsMissing = CC_EC_MandatoryElementMissing
 CC_HC_MessageTypeNonExistantOrNotImplemented = CC_EC_MsgTypeNotImp
 CC_HC_MessageTypeNotCompatibleWithStateOrNonExistantOrNotImplemented =
 CC_EC_MsgTypeNotImpOrWrongState

```

CC_HC_InformationElementParameterNonExistantOrNotImplemented = CC_EC_ElemTypeNotImp
CC_HC_InvalidInformationElementContents                    = CC_EC_InvalidElemContents
CC_HC_MessageNotCompatibleWithCallState                  = CC_EC_MsgInWrongState
CC_HC_RecoveryOnTimerExpiry                              = CC_EC_RecoveryOnTimerExpiry
CC_HC_ParameterNonExistantOrNotImplementedPassedOn = CC_EC_ParamUnrecPassed

```

```
# -----
```

```
#####
##
```

```
# FAULTMANAGEMENT PACKAGE
```

```
#
```

```
Package = FaultManagement
```

```
#
```

```
FMRaiseRecoveryAction = "ON"
```

```
FMClearRecoveryAction = "ON"
```

```
#####
##
```

```
# GAPPING PACKAGE
```

```
#
```

```
# Set the gapping percentage level for each side. A level of 0 indicates no gapping
```

```
# A level of 100 indicates gap all calls (except priority calls - see treatment below)
```

```
#
```

```
Package = Gapping
```

```
#
```

```
H323level = 0
```

```
EISUPlevel = 0
```

```
#
```

```
# Priority treatment determines the treatment of priority calls during gapping.
```

```
# GapAlways indicates priority calls are treated as normal calls
```

```
# GapNever indicate priority calls are never to be gapped
```

```
# GapOn100PercentGapping indicates priority calls are only gapped when 100 percent
# gapping is applied.
#
```

```
#PriorityCallTreatment = GapOn100PercentGapping
#PriorityCallTreatment = GapNever
PriorityCallTreatment = GapAlways
```

```
#####
##
```

```
# TRACE PACKAGE
```

```
#
```

```
# There are five trace trigger locations. Each location can hold one type of
# six trigger types as follows:
```

```
#
```

```
# EISUP CallingPartyNumber (E.164 address)
```

```
# EISUP CalledPartyNumber (E.164 address)
```

```
# H323 CallingPartyNumber (E.164 address)
```

```
# H323 CalledPartyNumber (E.164 address)
```

```
# H323 OriginatingIPAddress and H323 OriginatingIPMask (dotted notation)
```

```
# H323 TerminatingIPAddress and TerminatingIPMask (dotted notation)
```

```
#
```

```
Package = Trace
```

```
#
```

```
TraceOutputFilename = GWtrace.txt
```

```
Trigger1.eisup.CallingPartyNumber=1800
```

```
#Trigger1.eisup.CalledPartyNumber=1900
```

```
#Trigger1.h323.CallingPartyNumber=0299
```

```
#Trigger1.h323.CalledPartyNumber=0388
```

```
#Trigger1.h323.OriginatingIPAddress=203.188.2.3
```

```
#Trigger1.h323.OriginatingIPMask=255.255.0.0
```

```
#Trigger1.h323.TerminatingIPAddress=203.155.7.9
```

```
#Trigger1.h323.TerminatingIPMask=255.255.0.0
```

```
#Trigger2.eisup.CallingPartyNumber=1800
```

```
Trigger2.eisup.CalledPartyNumber=1900
#Trigger2.h323.CallingPartyNumber=0299
#Trigger2.h323.CalledPartyNumber=0388
#Trigger2.h323.OriginatingIPAddress=203.188.2.3
#Trigger2.h323.OriginatingIPMask=255.255.0.0
#Trigger2.h323.TerminatingIPAddress=203.155.7.9
#Trigger2.h323.TerminatingIPMask=255.255.0.0

#Trigger3.eisup.CallingPartyNumber=1800
#Trigger3.eisup.CalledPartyNumber=1900
#Trigger3.h323.CallingPartyNumber=0299
#Trigger3.h323.CalledPartyNumber=0388
Trigger3.h323.OriginatingIPAddress=203.188.2.3
Trigger3.h323.OriginatingIPMask=255.255.0.0
#Trigger3.h323.TerminatingIPAddress=203.155.7.9
#Trigger3.h323.TerminatingIPMask=255.255.0.0

#Trigger4.eisup.CallingPartyNumber=1800
#Trigger4.eisup.CalledPartyNumber=1900
#Trigger4.h323.CallingPartyNumber=0299
Trigger4.h323.CalledPartyNumber=0388
#Trigger4.h323.OriginatingIPAddress=203.188.2.3
#Trigger4.h323.OriginatingIPMask=255.255.0.0
#Trigger4.h323.TerminatingIPAddress=203.155.7.9
#Trigger4.h323.TerminatingIPMask=255.255.0.0

#Trigger5.eisup.CallingPartyNumber=1800
#Trigger5.eisup.CalledPartyNumber=1900
#Trigger5.h323.CallingPartyNumber=0299
#Trigger5.h323.CalledPartyNumber=0388
#Trigger5.h323.OriginatingIPAddress=203.188.2.3
#Trigger5.h323.OriginatingIPMask=255.255.0.0
Trigger5.h323.TerminatingIPAddress=203.155.7.9
Trigger5.h323.TerminatingIPMask=255.255.0.0

#
# TraceTriggerSwitch(for CLI/SNMP application)
# This gates the output of the trigger data for each location
```

```

#
TriggerGate1=ON
TriggerGate2=ON
TriggerGate3=ON
TriggerGate4=ON
TriggerGate5=ON

#####
##
# EISUP PACKAGE
#
#
Package = EISUP
#
#The period for CISCO's RUDP timer manage, in milli seconds
#RUDP_TIMER_CHECK_PERIOD_MSEC=20

#The time to wait before failing over to another VSC.
WAIT_TIME_BEFORE_FAIL_OVER_MILLI_SEC=1000

#####
##
# APPLICATION PACKAGE
#
#
Package = Application
#
DefaultCallProcessingStatus = "UP" #Choice {"UP", "DOWN"}

WaitBeforeCallReleaseTimer = 20 #Default is 60
RestartPendingTimer        = 20 #Default is 60
HaltPendingTimer           = 20 #Default is 60
RebootPendingTimer         = 20 #Default is 60

```



```
#####
##
# DYNAMIC SYSTEM DATA
#
#
Package = SYS_CONFIG_DYNAMIC

#
# Alternate Gatekeeper
ALTERNATEGATEKEEPERIP = "" #Leave blank if you don't want to provision an alternate
gatekeeper, otherwise insert IP address e.g. 10.70.54.55
ALTERNATEGATEKEEPERPORT = 1719
ALTERNATEGATEKEEPERID = "OuterLondonAlt"

# Logging
#
LOGDIRECTORY = "var/log/" #Default: "var/log/"
LOGFILENAMEPREFIX = "platform" #Default: "platform.log"
LOGPRIO = "TRACE" #Choice {DEBUG, TRACE, INFO, WARN, ERR,
CRIT}. Default: "WARN"
LOGFILEROTATESIZE = 10240 #Default: 10240 bytes (10Mb)
LOGFILEROTATEINTERVAL = 1440 #Default: 1440 min (24hrs)

# Overload
#
DISKUSAGELIMIT = 98 #Default: 95% Disk Usage
OVLDSAMPLERATE = 3000 #Default: 3000 msec polling rate

OVLDDLEVEL1PERCENT = 20 #Default: 0
OVLDDLEVEL1FILTER = "NORMAL" #Choice {"NORMAL", "ALL"}. Default:
"NORMAL"
OVLDDLEVEL1THRESHUPPERCPU = 65 #Default: 100
OVLDDLEVEL1THRESHLOWERCPU = 60 #Default: 100
OVLDDLEVEL1THRESHUPPERCALLS = 1900 #Default: 1000
OVLDDLEVEL1THRESHLOWERCALLS = 1800 #Default: 1000

OVLDDLEVEL2PERCENT = 75 #Default: 0
```

```

OVLLEVEL2FILTER                = "NORMAL" #Choice {"NORMAL", "ALL"}. Default:
"NORMAL"
OVLLEVEL2THRESHUPPERCPU        = 80      #Default: 100
OVLLEVEL2THRESHLOWERCPU        = 70      #Default: 100
OVLLEVEL2THRESHUPPERCALLS      = 2200   #Default: 1000
OVLLEVEL2THRESHLOWERCALLS      = 2000   #Default: 1000

OVLLEVEL3PERCENT                = 90      #Default: 0
OVLLEVEL3FILTER                = "NORMAL" #Choice {"NORMAL", "ALL"}.
Default: "NORMAL"
OVLLEVEL3THRESHUPPERCPU        = 95      #Default: 100
OVLLEVEL3THRESHLOWERCPU        = 85      #Default: 100
OVLLEVEL3THRESHUPPERCALLS      = 2400   #Default: 1000
OVLLEVEL3THRESHLOWERCALLS      = 2300   #Default: 1000

#####
##
#
Package = SYS_CONFIG_STATIC

#
# Call Control
# For the Eisup cause code values see CISCO: EISUP Protocol Specification ENG-46168 version 19
# For the H323 cause code values see ITU-T: Q.850
# The default cause codes, used when there is no map entry for a received cause

CC_EC_DEFAULT                   = CC_EC_NormalUnspecified
CC_HC_DEFAULT                   = CC_HC_NormalUnspecified

#
# Unassigned Eisup cause codes
#

CC_EC_AccessBarred              = CC_HC_DEFAULT
CC_EC_Acknowledgement           = CC_HC_DEFAULT
CC_EC_AddressIncomplete         = CC_HC_DEFAULT

```

CC_EC_AnonymousCallRejection	= CC_HC_DEFAULT
CC_EC_BlacklistBNumberMatched	= CC_HC_DEFAULT
CC_EC_BlacklistCliLengthInvalid	= CC_HC_DEFAULT
CC_EC_BlacklistCliMatched	= CC_HC_DEFAULT
CC_EC_BlacklistCpcRestricted	= CC_HC_DEFAULT
CC_EC_BlacklistNoCli	= CC_HC_DEFAULT
CC_EC_BlacklistNoaRestricted	= CC_HC_DEFAULT
CC_EC_Busy	= CC_HC_DEFAULT
CC_EC_CallRejectCallGapping	= CC_HC_DEFAULT
CC_EC_CallTerminated	= CC_HC_DEFAULT
CC_EC_CallTypeIncompatible	= CC_HC_DEFAULT
CC_EC_CallingDroppedWhileOnHold	= CC_HC_DEFAULT
CC_EC_CallingPartyOffHold	= CC_HC_DEFAULT
CC_EC_ChannelOutOfService	= CC_HC_DEFAULT
CC_EC_Congestion	= CC_HC_DEFAULT
CC_EC_CotFailure	= CC_HC_DEFAULT
CC_EC_CugAccessBarred	= CC_HC_DEFAULT
CC_EC_DteControlledNotReady	= CC_HC_DEFAULT
CC_EC_DteUncontrolledNotReady	= CC_HC_DEFAULT
CC_EC_ExcessiveDigCallProceeding	= CC_HC_DEFAULT
CC_EC_FacilityNotRegistered	= CC_HC_DEFAULT
CC_EC_FlowControlledCongestion	= CC_HC_DEFAULT
CC_EC_GroupRestrictions	= CC_HC_DEFAULT
CC_EC_IncomingCallsBarred	= CC_HC_DEFAULT
CC_EC_InterceptedSubscriber	= CC_HC_DEFAULT
CC_EC_InterworkUnspec	= CC_HC_DEFAULT
CC_EC_InvalidCallRef	= CC_HC_DEFAULT
CC_EC_MesgWithUnrecElemDiscarded	= CC_HC_DEFAULT
CC_EC_MessageNotUnderstood	= CC_HC_DEFAULT
CC_EC_MisroutedCallPortedNumber	= CC_HC_DEFAULT
CC_EC_NetworkAddressExtensionError	= CC_HC_DEFAULT
CC_EC_NetworkTermination	= CC_HC_DEFAULT
CC_EC_NewDestination	= CC_HC_DEFAULT
CC_EC_NumberUnobtainable	= CC_HC_DEFAULT
CC_EC_OperatorPriorityAccess	= CC_HC_DEFAULT
CC_EC_OutOfCatchmentArea	= CC_HC_DEFAULT
CC_EC_OutgoingCallsBarred	= CC_HC_DEFAULT
CC_EC_PermanentIcb	= CC_HC_DEFAULT

CC_EC_PortedNumber	= CC_HC_DEFAULT
CC_EC_PreemptionCctUnavailable	= CC_HC_DEFAULT
CC_EC_Prefix0DialledInError	= CC_HC_DEFAULT
CC_EC_Prefix1DialledInError	= CC_HC_DEFAULT
CC_EC_Prefix1NotDialled	= CC_HC_DEFAULT
CC_EC_PriorityForcedRelease	= CC_HC_DEFAULT
CC_EC_Proprietary	= CC_HC_DEFAULT
CC_EC_ProtErrThresholdExceeded	= CC_HC_DEFAULT
CC_EC_ProtocolErrorUnspec	= CC_HC_DEFAULT
CC_EC_Reject	= CC_HC_DEFAULT
CC_EC_RejectedDivertedCall	= CC_HC_DEFAULT
CC_EC_RemoteProcError	= CC_HC_DEFAULT
CC_EC_RepeatAttempt	= CC_HC_DEFAULT
CC_EC_RouteOutOfService	= CC_HC_DEFAULT
CC_EC_SelectiveCallBarring	= CC_HC_DEFAULT
CC_EC_ServiceIncompatible	= CC_HC_DEFAULT
CC_EC_ServiceTemporarilyUnavailable	= CC_HC_DEFAULT
CC_EC_ServiceUnavailable	= CC_HC_DEFAULT
CC_EC_SignalNotUnderstood	= CC_HC_DEFAULT
CC_EC_SignalNotValid	= CC_HC_DEFAULT
CC_EC_SignallingSystemIncompatible	= CC_HC_DEFAULT
CC_EC_SubControlledIcb	= CC_HC_DEFAULT
CC_EC_SubNotFoundIcb	= CC_HC_DEFAULT
CC_EC_SubscriberCallTerminate	= CC_HC_DEFAULT
CC_EC_SubscriberIncompatible	= CC_HC_DEFAULT
CC_EC_SubscriberMoved	= CC_HC_DEFAULT
CC_EC_SubscriberOutOfService	= CC_HC_DEFAULT
CC_EC_TemporaryOos	= CC_HC_DEFAULT
CC_EC_TerminalCongestion	= CC_HC_DEFAULT
CC_EC_Transferred	= CC_HC_DEFAULT
CC_EC_TranslationOos	= CC_HC_DEFAULT
CC_EC_UnallocatedDestNumber	= CC_HC_DEFAULT
CC_EC_UndefinedBg	= CC_HC_DEFAULT
CC_EC_Unknown	= CC_HC_DEFAULT
CC_EC_UnrecElemPassedOn	= CC_HC_DEFAULT
CC_EC_VacantCode	= CC_HC_DEFAULT
CC_EC_WhitelistCliNotMatched	= CC_HC_DEFAULT

```
#
# T38 Fax default configuration
#
T38MaxVal = "MaxBit 0x90, FxMaxBuf 0xc8, FxMaxData 0x48"
T38Options = "FxFillBit 0, FxTransMMR 0, FxTransJBIG 0, FxRate Trans, FxUdpEC Red"

#
#
# EISUP Settings for GoldWing to look at EISUP Test Tool
# Point GWmain to look at the test tool HOST_PORT instead of the VSC's
#VSCA_IPADDR1=samson
#VSCA_PORT_NUMBER1=18613
#VSCB_IPADDR1=stonehenge
#VSCB_PORT_NUMBER1=18613
```




E-ISUP Name-to-Cause Value Lookup

This appendix lists the Cisco E-ISUP protocol names and their associated cause values.

Name	Value
-----	-----
CC_EC_AccessBarred	54
CC_EC_AccessInfoDiscarded	1
CC_EC_Acknowledgement	55
CC_EC_AddressIncomplete	56
CC_EC_AnonymousCallRejection	116
CC_EC_BaercapNotAvail	3
CC_EC_BearcapNotAuthorized	2
CC_EC_BearcapNotImp	4
CC_EC_BlacklistBNumberMatched	137
CC_EC_BlacklistCliLengthInvalid	133
CC_EC_BlacklistCliMatched	134
CC_EC_BlacklistCpcRestricted	135
CC_EC_BlacklistNoCli	132
CC_EC_BlacklistNoaRestricted	136
CC_EC_Busy	57
CC_EC_CallAwardedDeliveredEstCh	5
CC_EC_CallIdHasBeenCleared	6
CC_EC_CallIdInUse	7
CC_EC_CallRejectCallGapping	102
CC_EC_CallRejected	8
CC_EC_CallTerminated	61
CC_EC_CallTypeIncompatible	95
CC_EC_CallingDroppedWhileOnHold	98
CC_EC_CallingPartyOffHold	97
CC_EC_ChIdNotExist	9
CC_EC_ChTypeNotImp	10
CC_EC_ChUnacceptable	11
CC_EC_ChannelOutOfService	58
CC_EC_Congestion	60
CC_EC_CotFailure	141
CC_EC_CugAccessBarred	108
CC_EC_DEFAULT	32
CC_EC_DestOutOfOrder	12
CC_EC_DteControlledNotReady	59
CC_EC_DteUncontrolledNotReady	79
CC_EC_ElemTypeNotImp	13
CC_EC_ExcessiveDigCallProceeding	123
CC_EC_FacilityNotRegistered	62
CC_EC_FacilityRejected	14
CC_EC_FlowControlledCongestion	110
CC_EC_GroupRestrictions	96

CC_EC_IncomingCallsBarred	63
CC_EC_IncomingCallsBarredInCug	81
CC_EC_IncompatibleDest	15
CC_EC_InconOutgoingAccAndSubClass	126
CC_EC_InterceptedSubscriber	53
CC_EC_InterworkUnspec	16
CC_EC_InvalidCallRef	143
CC_EC_InvalidCallReferenceValue	17
CC_EC_InvalidElemContents	18
CC_EC_InvalidMsgUnspec	19
CC_EC_InvalidNumberFormat	20
CC_EC_InvalidTns	21
CC_EC_MandatoryElementMissing	22
CC_EC_MesgWithUnrecElemDiscarded	128
CC_EC_MessageNotUnderstood	65
CC_EC_MisdialledTkPrefix	84
CC_EC_MisroutedCallPortedNumber	142
CC_EC_MsgInWrongState	23
CC_EC_MsgTypeNotImp	24
CC_EC_MsgTypeNotImpOrWrongState	25
CC_EC_NetworkAddressExtensionError	66
CC_EC_NetworkOutOfOrder	26
CC_EC_NetworkTermination	67
CC_EC_NewDestination	99
CC_EC_NoAnswerAlertedUser	28
CC_EC_NoCallSuspended	27
CC_EC_NoCircuitAvailable	29
CC_EC_NoRouteToDest	33
CC_EC_NoRouteToTns	34
CC_EC_NoUserResponding	35
CC_EC_NonExistentCug	127
CC_EC_NonSelectedUserClearing	30
CC_EC_NormalClearing	31
CC_EC_NormalUnspecified	32
CC_EC_NumberChanged	36
CC_EC_NumberUnobtainable	68
CC_EC_OnlyRestrictDigInfoBearer	37
CC_EC_OperatorPriorityAccess	107
CC_EC_OutOfCatchmentArea	111
CC_EC_OutgoingCallsBarred	100
CC_EC_OutgoingCallsBarredInCug	125
CC_EC_ParamUnrecPassed	85
CC_EC_PermanentFrameModeOos	130
CC_EC_PermanentFrameModeOperational	131
CC_EC_PermanentIcb	113
CC_EC_PortedNumber	139
CC_EC_PrecedenceBlocked	94
CC_EC_Preemption	87
CC_EC_PreemptionCctRes	129
CC_EC_PreemptionCctUnavailable	88
CC_EC_Prefix0DialledInError	120
CC_EC_Prefix1DialledInError	121
CC_EC_Prefix1NotDialled	122
CC_EC_PriorityForcedRelease	69
CC_EC_Proprietary	86
CC_EC_ProtErrThresholdExceeded	124
CC_EC_ProtocolErrorUnspec	38
CC_EC_QualityUnavail	39
CC_EC_RecoveryOnTimerExpiry	40
CC_EC_RedirectionToNewDest	140
CC_EC_Reject	70
CC_EC_RejectedDivertedCall	103
CC_EC_RemoteProcError	105
CC_EC_RepeatAttempt	118

CC_EC_ReqCircuitUnavail	41
CC_EC_ReqFacilityNotImp	42
CC_EC_ReqFacilityNotSubscr	43
CC_EC_ResourcesUnavailUnspec	44
CC_EC_ResponseToStatusEnquiry	45
CC_EC_RouteOutOfService	71
CC_EC_RoutingError	93
CC_EC_SelectiveCallBarring	104
CC_EC_ServiceIncompatible	64
CC_EC_ServiceOrOptionNotAvail	47
CC_EC_ServiceOrOptionNotImpUnspec	46
CC_EC_ServiceTemporarilyUnavailable	77
CC_EC_ServiceUnavailable	78
CC_EC_SignalNotUnderstood	73
CC_EC_SignalNotValid	74
CC_EC_SignallingSystemIncompatible	76
CC_EC_SpecialInformationTone	82
CC_EC_SubAbsent	91
CC_EC_SubControlledIcb	101
CC_EC_SubNotFoundDle	115
CC_EC_SubscriberCallTerminate	109
CC_EC_SubscriberIncompatible	72
CC_EC_SubscriberMoved	114
CC_EC_SubscriberOutOfService	75
CC_EC_SuspendExistButNotThisId	48
CC_EC_SwitchingEquipCongestion	49
CC_EC_TemporaryFailure	50
CC_EC_TemporaryOos	106
CC_EC_TerminalCongestion	117
CC_EC_Transferred	80
CC_EC_TranslationOos	112
CC_EC_UnallocatedDestNumber	89
CC_EC_UnallocatedNumber	51
CC_EC_UndefinedBg	92
CC_EC_Unknown	144
CC_EC_UnrecElemPassedOn	90
CC_EC_UserBusy	52
CC_EC_UserNotMemberOfCug	83
CC_EC_VacentCode	119
CC_EC_WhitelistCliNotMatched	138



E-ISUP Cause Value-to-Name Lookup

This appendix lists the Cisco E-ISUP cause values and their associated names.

Value	Name
1	CC_EC_AccessInfoDiscarded
2	CC_EC_BearcapNotAuthorized
3	CC_EC_BaercapNotAvail
4	CC_EC_BearcapNotImp
5	CC_EC_CallAwardedDeliveredEstCh
6	CC_EC_CallIdHasBeenCleared
7	CC_EC_CallIdInUse
8	CC_EC_CallRejected
9	CC_EC_ChIdNotExist
10	CC_EC_ChTypeNotImp
11	CC_EC_ChUnacceptable
12	CC_EC_DestOutOfOrder
13	CC_EC_ElemTypeNotImp
14	CC_EC_FacilityRejected
15	CC_EC_IncompatibleDest
16	CC_EC_InterworkUnspec
17	CC_EC_InvalidCallReferenceValue
18	CC_EC_InvalidElemContents
19	CC_EC_InvalidMsgUnspec
20	CC_EC_InvalidNumberFormat
21	CC_EC_InvalidTns
22	CC_EC_MandatoryElementMissing
23	CC_EC_MsgInWrongState
24	CC_EC_MsgTypeNotImp
25	CC_EC_MsgTypeNotImpOrWrongState
26	CC_EC_NetworkOutOfOrder
27	CC_EC_NoCallSuspended
28	CC_EC_NoAnswerAlertedUser
29	CC_EC_NoCircuitAvailable
30	CC_EC_NonSelectedUserClearing
31	CC_EC_NormalClearing
32	CC_EC_DEFAULT
32	CC_EC_NormalUnspecified
33	CC_EC_NoRouteToDest
34	CC_EC_NoRouteToTns
35	CC_EC_NoUserResponding
36	CC_EC_NumberChanged
37	CC_EC_OnlyRestrictDigInfoBearer
38	CC_EC_ProtocolErrorUnspec
39	CC_EC_QualityUnavail
40	CC_EC_RecoveryOnTimerExpiry
41	CC_EC_ReqCircuitUnavail

42	CC_EC_ReqFacilityNotImp
43	CC_EC_ReqFacilityNotSubscr
44	CC_EC_ResourcesUnavailUnspec
45	CC_EC_ResponseToStatusEnquiry
46	CC_EC_ServiceOrOptionNotImpUnspec
47	CC_EC_ServiceOrOptionNotAvail
48	CC_EC_SuspendExistButNotThisId
49	CC_EC_SwitchingEquipCongestion
50	CC_EC_TemporaryFailure
51	CC_EC_UnallocatedNumber
52	CC_EC_UserBusy
53	CC_EC_InterceptedSubscriber
54	CC_EC_AccessBarred
55	CC_EC_Acknowledgement
56	CC_EC_AddressIncomplete
57	CC_EC_Busy
58	CC_EC_ChannelOutOfService
59	CC_EC_DteControlledNotReady
60	CC_EC_Congestion
61	CC_EC_CallTerminated
62	CC_EC_FacilityNotRegistered
63	CC_EC_IncomingCallsBarred
64	CC_EC_ServiceIncompatible
65	CC_EC_MessageNotUnderstood
66	CC_EC_NetworkAddressExtensionError
67	CC_EC_NetworkTermination
68	CC_EC_NumberUnobtainable
69	CC_EC_PriorityForcedRelease
70	CC_EC_Reject
71	CC_EC_RouteOutOfService
72	CC_EC_SubscriberIncompatible
73	CC_EC_SignalNotUnderstood
74	CC_EC_SignalNotValid
75	CC_EC_SubscriberOutOfService
76	CC_EC_SignallingSystemIncompatible
77	CC_EC_ServiceTemporarilyUnavailable
78	CC_EC_ServiceUnavailable
79	CC_EC_DteUncontrolledNotReady
80	CC_EC_Transferred
81	CC_EC_IncomingCallsBarredInCug
82	CC_EC_SpecialInformationTone
83	CC_EC_UserNotMemberOfCug
84	CC_EC_MisdialledTkPrefix
85	CC_EC_ParamUnrecPassed
86	CC_EC_Proprietary
87	CC_EC_Preemption
88	CC_EC_PreemptionCctUnavailable
89	CC_EC_UnallocatedDestNumber
90	CC_EC_UnrecElemPassedOn
91	CC_EC_SubAbsent
92	CC_EC_UndefinedBg
93	CC_EC_RoutingError
94	CC_EC_PrecedenceBlocked
95	CC_EC_CallTypeIncompatible
96	CC_EC_GroupRestrictions
97	CC_EC_CallingPartyOffHold
98	CC_EC_CallingDroppedWhileOnHold
99	CC_EC_NewDestination
100	CC_EC_OutgoingCallsBarred
101	CC_EC_SubControlledIcb
102	CC_EC_CallRejectCallGapping
103	CC_EC_RejectedDivertedCall
104	CC_EC_SelectiveCallBarring
105	CC_EC_RemoteProcError

106	CC_EC_TemporaryOos
107	CC_EC_OperatorPriorityAccess
108	CC_EC_CugAccessBarred
109	CC_EC_SubscriberCallTerminate
110	CC_EC_FlowControlledCongestion
111	CC_EC_OutOfCatchmentArea
112	CC_EC_TranslationOos
113	CC_EC_PermanentIcb
114	CC_EC_SubscriberMoved
115	CC_EC_SubNotFoundDle
116	CC_EC_AnonymousCallRejection
117	CC_EC_TerminalCongestion
118	CC_EC_RepeatAttempt
119	CC_EC_VacentCode
120	CC_EC_Prefix0DialledInError
121	CC_EC_Prefix1DialledInError
122	CC_EC_Prefix1NotDialled
123	CC_EC_ExcessiveDigCallProceeding
124	CC_EC_ProtErrThresholdExceeded
125	CC_EC_OutgoingCallsBarredInCug
126	CC_EC_InconOutgoingAccAndSubClass
127	CC_EC_NonExistentCug
128	CC_EC_MesgWithUnrecElemDiscarded
129	CC_EC_PreemptionCctRes
130	CC_EC_PermanentFrameModeOos
131	CC_EC_PermanentFrameModeOperational
132	CC_EC_BlacklistNoCli
133	CC_EC_BlacklistCliLengthInvalid
134	CC_EC_BlacklistCliMatched
135	CC_EC_BlacklistCpcRestricted
136	CC_EC_BlacklistNoaRestricted
137	CC_EC_BlacklistBNumberMatched
138	CC_EC_WhitelistCliNotMatched
139	CC_EC_PortedNumber
140	CC_EC_RedirectionToNewDest
141	CC_EC_CotFailure
142	CC_EC_MisroutedCallPortedNumber
143	CC_EC_InvalidCallRef
144	CC_EC_Unknown



H.323 Name-to-Cause Value Lookup

This appendix lists the H.323 names and their associated cause values.

Name	Value
----	-----
CC_HC_ASuspendedCallExistsThisCallIdDoesNot	83
CC_HC_AccessInformationDiscarded	43
CC_HC_BearerCapabilityNotAuthorized	57
CC_HC_BearerCapabilityNotImplemented	65
CC_HC_BearerCapabilityNotPresentlyAvailable	58
CC_HC_CallAwardedEstablishedChannel	7
CC_HC_CallHavingTheRequestedCallIdHasBeenCleared	86
CC_HC_CallIdentityInUse	84
CC_HC_CallRejected	21
CC_HC_ChannelTypeNotImplemented	66
CC_HC_ChannelUnacceptable	6
CC_HC_DEFAULT	31
CC_HC_DestinationOutOfOrder	27
CC_HC_ExchangeRouteError	25
CC_HC_FacilityRejected	29
CC_HC_IdentifierChannelDoesNotExist	82
CC_HC_IncomingCallsBaredWithinCUG	55
CC_HC_IncompatibleDestination	88
CC_HC_InconsistencyAccessInfoSubscriberClass	62
CC_HC_InformationElementParameterNonExistantOrNotImplemented	99
CC_HC_InvalidCallreferenceValue	81
CC_HC_InvalidInformationElementContents	100
CC_HC_InvalidMessage	95
CC_HC_InvalidNumberFormat	28
CC_HC_InvalidTransitNetworkSelection	91
CC_HC_MandatoryInformationElementIsMissing	96
CC_HC_MessageNotCompatibleWithCallState	101
CC_HC_MessageTypeNonExistantOrNotImplemented	97
CC_HC_MessageTypeNotCompatibleWithStateOrNonExistantOrNotImplemented	98
CC_HC_MisdialedTrunkPrefix	5
CC_HC_NetworkOutOfOrder	38
CC_HC_NoAnswerFromAlertedUser	19
CC_HC_NoCallSuspended	85
CC_HC_NoCircuitChannelAvailable	34
CC_HC_NoRouteToDestination	3
CC_HC_NoRouteToSpecifiedTransitNetwork	2
CC_HC_NoUserresponding	18
CC_HC_NonExistantCUG	90
CC_HC_NonSelectedUserClearing	26
CC_HC_NormalCallClearing	16
CC_HC_NormalUnspecified	31

CC_HC_NumberChanged	22
CC_HC_OnlyRestrictedDigitalBearerInfoCapability	70
CC_HC_OutgoingCallsBaredWithinCUG	53
CC_HC_ParameterNonExistantOrNotImplementedPassedOn	103
CC_HCPermanentFrameModeConnectionOperational	40
CC_HCPermanentFrameModeConnectionOutOfService	39
CC_HCPrecedenceCallBlocked	46
CC_HCPreemption	8
CC_HCPreemptionCircuitReservedForReuse	9
CC_HCQualityOfServiceNotAvailable	49
CC_HCRecoveryOnTimerExpiry	102
CC_HCRedirectionToNewDestination	23
CC_HCRequestedCircuitChannelNotAvailable	44
CC_HCRequestedFacilityNotImplemented	69
CC_HCRequestedFacilityNotSubscribed	50
CC_HCResourceUnavailable	47
CC_HCResponceToStatusEnquiry	30
CC_HC_SendSpecialInformationTone	4
CC_HC_ServiceOrOptionNotImplemented	79
CC_HC_ServiceOrOptionUnavailable	63
CC_HC_SubscriberAbsent	20
CC_HC_SwitchingEquipmentCongestion	42
CC_HC_TemporaryFailure	41
CC_HC_UnallocatedNumber	1
CC_HC_UserBusy	17
CC_HC_UserNotMemberOfCUG	87



H.323 Cause Value-to-Name Lookup

This appendix lists the H.323 cause values and their associated names.

Value	Name
1	CC_HC_UnallocatedNumber
2	CC_HC_NoRouteToSpecifiedTransitNetwork
3	CC_HC_NoRouteToDestination
4	CC_HC_SendSpecialInformationTone
5	CC_HC_MisdialedTrunkPrefix
6	CC_HC_ChannelUnacceptable
7	CC_HC_CallAwardedEstablishedChannel
8	CC_HC_Preemption
9	CC_HC_PreemptionCircuitReservedForReuse
16	CC_HC_NormalCallClearing
17	CC_HC_UserBusy
18	CC_HC_NoUserresponding
19	CC_HC_NoAnswerFromAlertedUser
20	CC_HC_SubscriberAbsent
21	CC_HC_CallRejected
22	CC_HC_NumberChanged
23	CC_HC_RedirectionToNewDestination
25	CC_HC_ExchangeRouteError
26	CC_HC_NonSelectedUserClearing
27	CC_HC_DestinationOutOfOrder
28	CC_HC_InvalidNumberFormat
29	CC_HC_FacilityRejected
30	CC_HC_ResponseToStatusEnquiry
31	CC_HC_DEFAULT
31	CC_HC_NormalUnspecified
34	CC_HC_NoCircuitChannelAvailable
38	CC_HC_NetworkOutOfOrder
39	CC_HC_PermanentFrameModeConnectionOutOfService
40	CC_HC_PermanentFrameModeConnectionOperational
41	CC_HC_TemporaryFailure
42	CC_HC_SwitchingEquipmentCongestion
43	CC_HC_AccessInformationDiscarded
44	CC_HC_RequestedCircuitChannelNotAvailable
46	CC_HC_PrecedenceCallBlocked
47	CC_HC_ResourceUnavailable
49	CC_HC_QualityOfServiceNotAvailable
50	CC_HC_RequestedFacilityNotSubscribed
53	CC_HC_OutgoingCallsBaredWithinCUG
55	CC_HC_IncomingCallsBaredWithinCUG
57	CC_HC_BearerCapabilityNotAuthorized
58	CC_HC_BearerCapabilityNotPresentlyAvailable
62	CC_HC_InconsistencyAccessInfoSubscriberClass

63	CC_HC_ServiceOrOptionUnavailable
65	CC_HC_BearerCapabilityNotImplemented
66	CC_HC_ChannelTypeNotImplemented
69	CC_HC_RequestedFacilityNotImplemented
70	CC_HC_OnlyRestrictedDigitalBearerInfoCapability
79	CC_HC_ServiceOrOptionNotImplemented
81	CC_HC_InvalidCallreferenceValue
82	CC_HC_IdentifiedChannelDoesNotExist
83	CC_HC_ASuspendedCallExistsThisCallIdDoesNot
84	CC_HC_CallIdentityInUse
85	CC_HC_NoCallSuspended
86	CC_HC_CallHavingTheRequestedCallIdHasBeenCleared
87	CC_HC_UserNotMemberOfCUG
88	CC_HC_IncompatibleDestination
90	CC_HC_NonExistantCUG
91	CC_HC_InvalidTransitNetworkSelection
95	CC_HC_InvalidMessage
96	CC_HC_MandatoryInformationElementIsMissing
97	CC_HC_MessageTypeNonExistantOrNotImplemented
98	CC_HC_MessageTypeNotCompatibleWithStateOrNonExistantOrNotImplemented
99	CC_HC_InformationElementParameterNonExistantOrNotImplemented
100	CC_HC_InvalidInformationElementContents
101	CC_HC_MessageNotCompatibleWithCallState
102	CC_HC_RecoveryOnTimerExpiry
103	CC_HC_ParameterNonExistantOrNotImplementedPassedOn



A

ack-alm command **A-8**
acknowledging alarms **5-4**
active log file **4-9**
ALARMDEBOUNCETIME parameter **5-1**
alarm messages
 continuous mode **5-3**
 noncontinuous mode **5-3**
alarms
 acknowledging **5-4**
 cleared state **5-4**
 clearing **5-4**
 CONFIG_CHANGE **5-11**
 CONFIGURATION_FAILURE **5-6**
 debounce period **5-1**
 EISUP_PATH_FAILURE **5-7**
 ENDPOINT_CALL_CONTROL_INTERFACE_FAILURE **5-12**
 ENDPOINT_CHANNEL_INTERFACE_FAILURE **5-12**
 GAPPED_CALL_NORMAL **5-13**
 GAPPED_CALL_PRIORITY **5-13**
 GATEKEEPER_INTERFACE_FAILURE **5-8**
 GENERAL_PROCESS_FAILURE **5-8**
 H323_STACK_FAILURE **5-6**
 IP_LINK_FAILURE **5-8**
 list **5-5**
 LOW_DISK_SPACE **5-9**
 OVERLOAD_LEVEL1 **5-14**
 OVERLOAD_LEVEL2 **5-11**
 OVERLOAD_LEVEL3 **5-9**
 PROVISIONING_INACTIVITY_TIMEOUT **5-14**
 retrieving **5-3**

severity level
 critical **5-2, 5-4**
 informational **5-2, 5-4**
 major **5-2, 5-4**
 minor **5-2, 5-4**
SNMP manager **5-2**
STOP_CALL_PROCESSING **5-15**
trap types **5-2**
troubleshooting **5-6**
VSC_FAILURE **5-10**
array index **3-10**
Asymmetric **1-4**
asymmetric codec treatment **3-16**

B

batch files
 creating **A-4**
 description **A-3**
 logging to **A-4**
 starting **A-4**

C

call control subsystem **1-3**
call processing
 starting **4-2**
 stopping **4-1**
call processing application
 starting **4-2**
 stopping **4-2**
call-related measurements **4-3**
checksum **3-1**

- CIAGENT 4-2
 - CIAGENTSCANPERIOD parameter 4-2
 - Cisco HSI
 - See HSI
 - clearing alarms 5-4
 - clr-alm command 5-4, A-8
 - clr-meas command 4-6, A-9
 - codec parameters 3-14
 - commands
 - ack-alm A-8
 - clr-alm 5-4, A-8
 - clr-meas 4-6, A-9
 - diaglog A-4, A-10
 - h A-10
 - help A-6, A-11
 - MML configuration 3-2
 - prov-add 3-3, 3-5, 3-9, A-12
 - prov-cpy A-13
 - prov-dlt 3-3, 3-5, 3-9, A-14
 - prov-ed 3-3, 3-5, 3-9, A-15
 - prov-exp A-16
 - prov-rtrv A-17
 - prov-sta A-4, A-19
 - prov-stp A-4, A-20
 - quit A-6, A-21
 - radlog 4-11, A-22
 - restart-softw 4-1, A-23
 - rtrv-alm 5-2, 5-3, A-24
 - rtrv-alm:cont 5-2, 5-3
 - rtrv-calls A-24
 - rtrv-ctr 4-6, A-25
 - rtrv-dest A-25
 - rtrv-gapping 4-12, A-26
 - rtrv-log A-27
 - rtrv-mml A-28
 - rtrv-ne A-28
 - rtrv-ne-health A-29
 - rtrv-overload 4-8, A-29
 - rtrv-softw 4-2, A-30
 - set-dest-state A-31
 - set-gapping 4-11, 4-12, A-32
 - set-log 4-8, 4-10, A-32
 - set-overload A-33
 - sta-callproc 4-2, A-34
 - sta-softw 4-2, A-35
 - sta-trc A-35
 - stp-call A-37
 - stp-callproc 4-1, A-37
 - stp-softw 4-2, A-38
 - stp-trc A-38
 - CONFIG_CHANGE alarm 5-11
 - configuration
 - commands parameter 3-2
 - data
 - constant 3-1
 - dynamic 3-1
 - static 3-1
 - CONFIGURATION_FAILURE alarm 5-6
 - configuring
 - Cisco HSI 2-10
 - group and user names 2-2
 - H.323 stack 3-8
 - MML sessions A-1
 - constant configuration data 3-1
 - continous mode alarm messages 5-3
 - conventions
 - document xiii
 - MML commands A-2
 - counter groups
 - H.245 4-3
 - RAS 4-3
 - counters, retrieving 4-6
 - critical severity level 5-2, 5-4
-
- D**
- data
 - configurable B-1

- constant **B-1**
- dynamic **B-1**
- provisionable **B-1**
- static **B-1**

debounce **5-1**

default active log file **4-9**

detailed logging **5-16**

diaglog command **A-4, A-10**

documentation

- related **xiv**

document conventions **xiii**

dual Cisco HSI **2-9**

dynamic

- configuration data **3-1**
- system data parameters **3-5**

E

E-ISUP

- overview **1-4**
- protocol **1-4**

EISUP_PATH_FAILURE alarm **5-7**

empty capability set **1-4, 3-16**

ENDPOINT_CALL_CONTROL_INTERFACE_FAILURE
E alarm **5-12**

ENDPOINT_CHANNEL_INTERFACE_FAILURE
alarm **5-12**

Enhanced ISDN User Part

- See E-ISUP

G

GAPPED_CALL_NORMAL alarm **5-13**

GAPPED_CALL_PRIORITY alarm **5-13**

gapping

- call type **4-11**
- description **4-11**
- level **4-11**
- retrieving data **4-12**

- setting **4-11**

GATEKEEPER_INTERFACE_FAILURE alarm **5-8**

GENERAL_PROCESS_FAILURE alarm **5-8**

group names, configuring **2-2**

H

H.225 protocol **1-4**

H.245

- codec parameters **3-14**
- counter groups **4-3**
- parameters **3-13**

H.323

- IP network **1-2**
- network **1-1**
- stack

 - configuration **3-8**
 - system parameters **3-9**

H.323 Hairpin **1-4, 3-16**

H.323 Signaling Interface

- See HSI

H323_STACK_FAILURE alarm **5-6**

hardware requirements **1-5**

h command **A-10**

help command **A-6, A-11**

HSI

- asymmetric codec treatment **3-16**
- base directory path **2-3**
- configuration

 - data **3-1**
 - file **3-1**
 - overview **3-1**

- configuring **2-10**
- default

 - base directory path **2-5**
 - gatekeeper port **2-3**
 - group name **2-3**
 - user name **2-3**

- dual **2-9**

- empty capability set **1-4, 3-16**
- H.323 Hairpin **1-4, 3-16**
- hardware requirements **1-5, 2-1**
- installing
 - previous version **2-11**
 - procedures **2-2**
 - required information **2-3**
 - subdirectories **2-4**
- MML sessions, configuring **A-1**
- overview **1-1**
- performance and sizing **1-5**
- preinstallation tasks **2-2**
- recovery **1-5**
- removing **2-11**
- restarting **4-1**
- security **1-5**
- services **1-1**
- software requirements **1-5, 2-1**
- starting **2-10**
- status **4-2**
- stopping **2-10**
- subsystems **1-2**
- system limitations **1-5**
- T.38 Fax **1-5, 3-17**
- uninstalling **2-11**
- upgrading **2-10**

I

- informational
 - events **5-2**
 - severity level **5-2, 5-4**
- installation procedures
 - Cisco HSI **2-2**
 - Solaris 8 operating system **2-1**
- IP_LINK_FAILURE alarm **5-8**
- IP network
 - H.323 network **1-2**
 - PSTN **1-2**

L

- LOGDIRECTORY parameter **4-9**
- LOGFILEROTATEINTERVAL parameter **4-8**
- LOGFILEROTATESIZE parameter **4-8**
- log files
 - active **4-9**
 - format **4-9**
 - location **4-9**
 - naming convention **4-9**
 - rotating **4-8**
- logging
 - batch files **A-4**
 - description **4-8**
 - detailed **5-16**
 - RADVision **4-11**
- log levels, setting **4-10**
- log messages
 - format **4-9**
 - packages **4-10**
- LOW_DISK_SPACE alarm **5-9**

M

- major severity level **5-2, 5-4**
- man-machine language
 - See MML
- measurements
 - call-related **4-3**
 - resetting **4-6**
 - system-related **4-2**
- messages, log **4-9**
- minor severity level **5-2, 5-4**
- MML commands
 - case sensitivity **A-3**
 - conventions **A-2**
 - syntax **A-2**
- MML configuration commands
 - component **3-2**

export 3-2
 session 3-2
 MML response messages
 error A-5
 status A-5
 MML sessions
 configuring A-1
 help A-6
 quitting A-6
 starting A-3

N

noncontinuous mode alarm messages 5-3
 nonprovisionable data parameters 3-8

O

OAM subsystem 1-3
 overlappedSending parameter 3-11
 overload
 data
 retrieving 4-8
 setting 4-7
 description 4-6
 level 1 4-7
 level 2 4-7
 level 3 4-7
 OVERLOAD_LEVEL1 alarm 5-14
 OVERLOAD_LEVEL2 alarm 5-11
 OVERLOAD_LEVEL3 alarm 5-9
 OVLLEVEL1FILTER parameter 4-7
 OVLLEVEL1PERCENT parameter 4-7
 OVLLEVEL1THRESHLOWERCALLS parameter 4-7
 OVLLEVEL1THRESHLOWERCPU parameter 4-7
 OVLLEVEL1THRESHUPPERCALLS parameter 4-7
 OVLLEVEL1THRESHUPPERCPU parameter 4-7
 OVLLEVEL2FILTER parameter 4-7

OVLLEVEL2PERCENT parameter 4-7
 OVLLEVEL2THRESHLOWERCALLS parameter 4-7
 OVLLEVEL2THRESHLOWERCPU parameter 4-7
 OVLLEVEL2THRESHUPPERCALLS parameter 4-7
 OVLLEVEL2THRESHUPPERCPU parameter 4-7
 OVLLEVEL3PERCENT parameter 4-7
 OVLLEVEL3THRESHLOWERCPU parameter 4-7
 OVLLEVEL3THRESHUPPERCALLS parameter 4-7
 OVLLEVEL3THRESHUPPERCPU parameter 4-7

P

parameters
 ALARMDEBOUNCETIME 5-1
 CIAGENTSCANPERIOD 4-2
 codec 3-14
 dynamic system data 3-5
 H.245 3-13
 H.323 system 3-9
 LOGDIRECTORY 4-9
 LOGFILEROOTATEINTERVAL 4-8
 LOGFILEROOTATESIZE 4-8
 nonprovisionable data 3-8
 overlappedSending 3-11
 OVLLEVEL1FILTER 4-7
 OVLLEVEL1PERCENT 4-7
 OVLLEVEL1THRESHLOWERCALLS 4-7
 OVLLEVEL1THRESHLOWERCPU 4-7
 OVLLEVEL1THRESHUPPERCALLS 4-7
 OVLLEVEL1THRESHUPPERCPU 4-7
 OVLLEVEL2FILTER 4-7
 OVLLEVEL2PERCENT 4-7
 OVLLEVEL2THRESHLOWERCALLS 4-7
 OVLLEVEL2THRESHLOWERCPU 4-7
 OVLLEVEL2THRESHUPPERCALLS 4-7
 OVLLEVEL2THRESHUPPERCPU 4-7
 OVLLEVEL3PERCENT 4-7
 OVLLEVEL3THRESHLOWERCPU 4-7
 OVLLEVEL3THRESHUPPERCALLS 4-7

OVLLEVEL3THRESHUPPERCPU 4-7
 Q.931 3-9
 RAS 3-10
 PGW 2200
 description 1-2
 redundant configuration 2-9
 PKINST file 2-9, 2-11
 protocols
 E-ISUP 1-4
 H.225 1-4
 Q.931 1-4
 RUDP 1-4
 prov-add command 3-3, 3-5, 3-9, A-12
 prov-cpy command A-13
 prov-dlt command 3-3, 3-5, 3-9, A-14
 prov-ed command 3-3, 3-5, 3-9, A-15
 prov-exp command A-16
 PROVISIONING_INACTIVITY_TIMEOUT alarm 5-14
 prov-rtrv command A-17
 prov-sta command A-4, A-19
 prov-stp command A-4, A-20

Q

Q.931 4-3
 parameters 3-9
 protocol 1-4
 quit command A-6, A-21

R

radlog command 4-11, A-22
 RADVision
 H.323 overview 1-4
 logging 4-11
 RAS
 counter groups 4-3
 parameters 3-10

redundant PGW 2200 configuration 2-9
 related documentation xiv
 Reliable User Datagram Protocol
 See RUDP
 resetting measurements 4-6
 restarting the Cisco HSI 4-1
 restart-softw command 4-1, A-23
 retrieving
 counters 4-6
 gapping data 4-12
 overload data 4-8
 rotating log files 4-8
 rtrv-alm:cont command 5-2, 5-3
 rtrv-alm command 5-2, 5-3, A-24
 rtrv-calls command A-24
 rtrv-ctr command 4-6, A-25
 rtrv-dest command A-25
 rtrv-gapping command 4-12, A-26
 rtrv-log command A-27
 rtrv-mml command A-28
 rtrv-ne command A-28
 rtrv-ne-health command A-29
 rtrv-overload command 4-8, A-29
 rtrv-softw command 4-2, A-30
 RUDP
 overview 1-4
 protocol 1-4

S

security features 1-5
 set-dest-state command A-31
 set-gapping command 4-11, 4-12, A-32
 set-log command 4-8, 4-10, A-32
 set-overload command A-33
 setting
 gapping 4-11
 overload data 4-7
 signaling interface

- See HSI
- Simple Network Management Protocol
 - See SNMP
- skeleton configuration file **3-2**
- SNMP
 - manager **5-2**
 - MIB **4-3**
 - subagent **2-10, 4-2**
 - trap types **5-2**
- software requirements **1-5**
- Solaris 8 operating system
 - installation **2-1**
 - platform requirements **2-1**
- sta-callproc command **4-2, A-34**
- starting
 - batch files **A-4**
 - call processing **4-2**
 - call processing application **4-2**
 - Cisco HSI **2-10**
 - MML sessions **A-3**
- sta-softw command **4-2, A-35**
- static
 - configuration data **3-1**
- sta-trc command **A-35**
- STOP_CALL_PROCESSING alarms **5-15**
- stopping
 - call processing **4-1**
 - call processing application **4-2**
 - Cisco HSI **2-10**
- stp-call command **A-37**
- stp-callproc command **4-1, A-37**
- stp-softw command **4-2, A-38**
- stp-trc command **A-38**
- system configuration data
 - dynamic **3-5**
 - static **3-3**
- system-related measurements **4-2**

T

- T.38 Fax **1-5, 3-17**
- trap types **5-2**
- troubleshooting alarms **5-6**

U

- uninstalling Cisco HSI **2-11**
- update types **3-9, 3-10, 3-13**
- user names, configuring **2-2**

V

- VSC_FAILURE alarm **5-10**

