



Cisco ONS 15454 Troubleshooting and Maintenance Guide

Product and Documentation Release 3.1
November 2001

Corporate Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 526-4100

Customer Order Number: DOC-7813454=
Text Part Number: 78-13454-01

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The following information is for FCC compliance of Class A devices: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to correct the interference at their own expense.

The following information is for FCC compliance of Class B devices: The equipment described in this manual generates and may radiate radio-frequency energy. If it is not installed in accordance with Cisco's installation instructions, it may cause interference with radio and television reception. This equipment has been tested and found to comply with the limits for a Class B digital device in accordance with the specifications in part 15 of the FCC rules. These specifications are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation.

Modifying the equipment without Cisco's written authorization may result in the equipment no longer complying with FCC requirements for Class A or Class B digital devices. In that event, your right to use the equipment may be limited by FCC regulations, and you may be required to correct any interference to radio or television communications at your own expense.

You can determine whether your equipment is causing interference by turning it off. If the interference stops, it was probably caused by the Cisco equipment or one of its peripheral devices. If the equipment causes interference to radio or television reception, try to correct the interference by using one or more of the following measures:

- Turn the television or radio antenna until the interference stops.
- Move the equipment to one side or the other of the television or radio.
- Move the equipment farther away from the television or radio.
- Plug the equipment into an outlet that is on a different circuit from the television or radio. (That is, make certain the equipment and the television or radio are on circuits controlled by different circuit breakers or fuses.)

Modifications to this product not authorized by Cisco Systems, Inc. could void the FCC approval and negate your authority to operate the product.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.


IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

AccessPath, AtmDirector, Browse with Me, CCIP, CCSI, CD-PAC, *CiscoLink*, the Cisco *Powered* Network logo, Cisco Systems Networking Academy, the Cisco Systems Networking Academy logo, Cisco Unity, Fast Step, Follow Me Browsing, FormShare, FrameShare, IGX, Internet Quotient, IP/VC, iQ Breakthrough, iQ Expertise, iQ FastTrack, the iQ Logo, iQ Net Readiness Scorecard, MGX, the Networkers logo, ScriptBuilder, ScriptShare, SMARTnet, TransPath, Voice LAN, Wavelength Router, and WebViewer are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn, and Discover All That's Possible are service marks of Cisco Systems, Inc.; and Aironet, ASIST, BPX, Catalyst, CCDA, CCDP, CCIE, CCNA, CCNP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, the Cisco IOS logo, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Empowering the Internet Generation, Enterprise/Solver, EtherChannel, EtherSwitch, FastHub, FastSwitch, GigaStack, IOS, IP/TV, LightStream, MICA, Network Registrar, *Packet*, PIX, Post-Routing, Pre-Routing, RateMUX, Registrar, SlideCast, StrataView Plus, Stratm, SwitchProbe, TeleRouter, and VCO are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and certain other countries.

All other trademarks mentioned in this document or Web site are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0110R)

Cisco ONS 15454 Troubleshooting and Maintenance Guide, Release 3.1

Copyright © 2001, Cisco Systems, Inc.
All rights reserved.



About This Manual	xxix
Procedure: Cisco TAC Web Site	xxxiii
Procedure: Cisco TAC Escalation Center	xxxiii

CHAPTER 1

Alarm Troubleshooting	1-1
1.1 Alarm Index	1-1
1.2 Trouble Notifications	1-3
1.2.1 Conditions	1-3
1.2.2 Severities	1-3
1.3 Alarm Procedures	1-4
1.3.1 AIS	1-4
Procedure: Clear the AIS Condition	1-4
1.3.2 AIS-L	1-4
Procedure: Clear the AIS-L Condition	1-4
1.3.3 AIS-P	1-5
Procedure: Clear the AIS-P Condition	1-5
1.3.4 AIS-V	1-5
Procedure: Clear the AIS-V Condition on the DS-1/DS3XM-6 Card	1-6
1.3.5 APSB	1-6
Procedure: Clear the APSB Alarm on an OC-N Card	1-6
1.3.6 APSCDFLTk	1-6
Procedure: Clear the APSCDFLTk Alarm	1-6
1.3.7 APSC-IMP	1-7
Procedure: Clear the APSC-IMP Alarm	1-7
1.3.8 APSCINCON	1-8
Procedure: Clear the APSCINCON Alarm on an OC-N Card in a BLSR	1-8
1.3.9 APSCM	1-8
Procedure: Clear the APSCM Alarm on an OC-N Card in 1+1 Mode	1-9
1.3.10 APSCNMIS	1-9
Procedure: Clear the APSCNMIS Alarm	1-9
1.3.11 APSCONNL	1-10
Procedure: Clear the APSCONNL Alarm on an OC-N Card in a BLSR	1-10
1.3.12 APSMM	1-11
Procedure: Clear the APSMM Alarm in 1+1 Mode	1-11
1.3.13 AUTOLSROFF	1-11

Procedure: Clear the AUTOLSROFF Alarm	1-12
1.3.14 AUTORESET	1-12
Procedure: Clear the AUTORESET Alarm	1-12
1.3.15 AUTOSW-AIS	1-12
1.3.16 AUTOSW-LOP	1-13
1.3.17 AUTOSW-PDI	1-13
1.3.18 AUTOSW-SDBER	1-13
1.3.19 AUTOSW-SFBER	1-13
1.3.20 AUTOSW-UNEQ	1-13
1.3.21 BKUPMEMP	1-13
Procedure: Clear the BKUPMEMP Alarm	1-14
1.3.22 BLSROSYNC	1-14
Procedure: Clear the BLSROSYNC Alarm	1-15
1.3.23 CARLOSS	1-15
Procedure: Clear the CARLOSS Alarm	1-16
1.3.24 CONCAT	1-16
Procedure: Clear the CONCAT Alarm	1-17
1.3.25 CONNLOS	1-17
Procedure: Clear the CONNLOS Alarm	1-17
1.3.26 CONTBUS-A-X	1-18
Procedure: Clear the CONTBUS-A-X Alarm for Slots 1 Through 17	1-18
1.3.27 CONTBUS-A-18	1-19
Procedure: Clear the CONTBUS-A-18 Alarm	1-19
1.3.28 CONTBUS-B-X	1-20
Procedure: Clear the CONTBUS-B-X Alarm for Slots 1 Through 17	1-20
1.3.29 CONTBUS-B-18	1-21
Procedure: Clear the CONTBUS-B-18 Alarm on the TCC+ Card	1-21
1.3.30 CTNEQPT-PB1PROT	1-21
Procedure: Clear the CTNEQPT-PB1PROT Alarm	1-22
1.3.31 CTNEQPT-PB1WORK	1-23
Procedure: Clear the CTNEQPT-PB1WORK Alarm	1-23
1.3.32 CTNEQPT-PBXPROT	1-24
Procedure: Clear the CTNEQPT-PBXPROT Alarm	1-24
1.3.33 CTNEQPT-PBXWORK	1-25
Procedure: Clear the CTNEQPT-PBXWORK Alarm	1-26
1.3.34 DATAFLT	1-27
1.3.35 DISCONNECTED	1-27
Procedure: Clear the DISCONNECTED Alarm	1-28
1.3.36 EOC	1-28
Procedure: Clear the EOC Alarm on an OC-N Card	1-28

- 1.3.37 EQPT **1-30**
 - Procedure: Clear the EQPT Alarm **1-30**
- 1.3.38 E-W-MISMATCH **1-30**
 - Procedure: Clear the E-W-MISMATCH Alarm with a Physical Switch **1-31**
 - Procedure: Clear the E-W-MISMATCH Alarm with the CTC **1-31**
- 1.3.39 EXCCOL **1-32**
 - Procedure: Clear the EXCCOL Alarm **1-32**
- 1.3.40 EXERCISE-SPAN-FAIL **1-32**
- 1.3.41 EXERCISE-RING-FAIL **1-32**
- 1.3.42 EXT **1-32**
 - Procedure: Clear the EXT Alarm **1-33**
- 1.3.43 FAILTOSW **1-33**
 - Procedure: Clear the FAILTOSW Alarm **1-33**
- 1.3.44 FAILTOSW-PATH **1-33**
 - Procedure: Clear the FAILTOSW-PATH Alarm on a UPSR Configuration **1-34**
- 1.3.45 FAILTOSWR **1-35**
 - Procedure: Clear the FAILTOSWR Alarm on a Four-Fiber BLSR Configuration **1-35**
- 1.3.46 FAILTOSWS **1-36**
- 1.3.47 FAN **1-37**
 - Procedure: Clear the FAN Alarm **1-37**
- 1.3.48 FE-AIS **1-37**
 - Procedure: Clear the FE-AIS Condition on the DS3XM-6 or DS3E Cards in C-bit Format **1-37**
- 1.3.49 FE-DS1-MULTLOS **1-38**
 - Procedure: Clear the FE-DS1-MULTLOS Condition on the DS3XM-6 **1-38**
- 1.3.50 FE-DS1-SNGLLOS **1-38**
 - Procedure: Clear the FE-DS1-SNGLLOS Condition on the DS3XM-6 **1-38**
- 1.3.51 FE-EQPT-FAIL-SA **1-38**
 - Procedure: Clear the FE-EQPT-FAIL-SA Condition on the DS3XM-6 or DS3E Cards in C-bit Format **1-39**
- 1.3.52 FE-EQPT-NSA **1-39**
 - Procedure: Clear the FE-EQPT-NSA Condition on the DS3XM-6 or DS3E Cards in C-bit Format **1-39**
- 1.3.53 FE-IDLE **1-39**
 - Procedure: Clear the FE-IDLE Condition on the DS3XM-6 or DS3E Cards in C-bit Format **1-40**
- 1.3.54 FE-LOCKOUT **1-40**
 - Procedure: Clear the FE-LOCKOUT Alarm on a BLSR **1-40**
- 1.3.55 FE-LOF **1-40**
 - Procedure: Clear the FE-LOF Condition on the DS3XM-6 or DS-3E Cards in C-bit Format **1-40**
- 1.3.56 FE-LOS **1-41**
 - Procedure: Clear the FE-LOS Condition on the DS3XM-6 or DS-3E Cards in C-bit Format **1-41**

1.3.57	FEPRLF	1-41	
	Procedure: Clear the FEPRLF Alarm on a Four-Fiber BLSR	1-41	
1.3.58	FORCED-REQ	1-41	
	Procedure: Clear the FORCED-REQ Alarm on an OC-N Card	1-42	
1.3.59	FRNGSYNC	1-42	
	Procedure: Clear the FRNGSYNC Alarm	1-42	
1.3.60	FSTSYNC	1-42	
1.3.61	HITEMP	1-42	
	Procedure: Clear the HITEMP Alarm	1-43	
1.3.62	HLDOVERSYNC	1-43	
	Procedure: Clear the HLDOVERSYNC Alarm	1-43	
1.3.63	IMPROPRMVL	1-44	
	Procedure: Clear the IMPROPRMVL Alarm	1-44	
1.3.64	INCOMPATIBLE-SW	1-45	
	Procedure: Clear the INCOMPATIBLE-SW Alarm	1-45	
1.3.65	INVMACADR	1-45	
	Procedure: Clear the INVMACADDR Alarm	1-46	
1.3.66	LOCKOUT-REQ	1-46	
	Procedure: Clear the Lockout Switch Request and the LOCKOUT-REQ Condition on an OC-N Card	1-46	
1.3.67	LOF (DS-1)	1-46	
	Procedure: Clear the LOF Condition on the DS-1 Card	1-46	
1.3.68	LOF (DS3XM-6)	1-47	
	Procedure: Clear the LOF Condition on the DS3XM-6 or DS-3E Cards in C-bit Format	1-47	
1.3.69	LOF (BITS)	1-48	
	Procedure: Clear the LOF Alarm on the TCC+ Card	1-48	
1.3.70	LOF (EC-1)	1-49	
	Procedure: Clear the LOF Alarm on the EC-1 Card	1-49	
1.3.71	LOF (OC-N)	1-50	
	Procedure: Clear the LOF Alarm on an OC-N Card	1-50	
1.3.72	LOP-P	1-50	
	Procedure: Clear the LOP Alarm on a Line Card	1-51	
1.3.73	LOP-V	1-52	
	Procedure: Clear the LOP-V Alarm on the DS3XM-6 or DS-1 Card	1-52	
1.3.74	LOS (DS-N)	1-53	
	Procedure: Clear the LOS Alarm on the DS-3, DS3XM-6, or DS-1 Card	1-53	
1.3.75	LOS (BITS)	1-54	
	Procedure: Clear the LOS Alarm	1-54	
1.3.76	LOS (OC-N)	1-54	
	Procedure: Clear the LOS Alarm on an OC-N Card	1-54	

- 1.3.77 LOS (EC-1) **1-55**
 - Procedure: Clear the LOS Alarm on the EC-1 Card **1-55**
- 1.3.78 LPBKDS1FEAC **1-56**
- 1.3.79 LPBKDS3FEAC **1-56**
- 1.3.80 LPBKFACILITY (DS-N) **1-56**
 - Procedure: Clear the LBFACILITY Alarm on the DS-3, DS-3E, DS3XM-6 or DS-1 Card **1-57**
- 1.3.81 LPBKFACILITY (OC-N) **1-57**
 - Procedure: Clear the LBFACILITY Condition on the OC-N Card **1-57**
- 1.3.82 LPBKTERMINAL (DS-N) **1-57**
 - Procedure: Clear the LPBKTERMINAL Condition on a DS-N Card **1-58**
- 1.3.83 LPBKTERMINAL (OC-N) **1-58**
 - Procedure: Clear the LBKTERMINAL Condition on an OC-N Card **1-58**
- 1.3.84 MANRESET **1-59**
- 1.3.85 MANUAL-REQ **1-59**
 - Procedure: Clear the Manual Switch and the MANUAL-REQ Condition on an OC-N Card **1-59**
- 1.3.86 MEA **1-59**
 - Procedure: Clear the MEA Alarm on a Cross-Connect or Line Card **1-59**
- 1.3.87 MEM-GONE **1-60**
- 1.3.88 MEM-LOW **1-60**
- 1.3.89 MFGMEM **1-61**
 - Procedure: Clear the MFGMEM Alarm on the AIP, Fan Tray, or Backplane. **1-61**
- 1.3.90 NOT-AUTHENTICATED **1-62**
 - Procedure: Clear the NOT-AUTHENTICATED Alarm on the TCC+ Card **1-62**
- 1.3.91 PDI-P **1-63**
 - Procedure: Clear the PDI-P Alarm Reported on the DS-3, DS-3E, DS3XM-6 or DS-1 Card **1-63**
- 1.3.92 PEER-NORESPONSE **1-64**
 - Procedure: Clear the PEER-NORESPONSE Alarm Reported on DS-N, OC-N or EC1 Card **1-64**
- 1.3.93 PLM-P **1-64**
 - Procedure: Clear the PLM-P Alarm Reported on the DS-N Card **1-65**
- 1.3.94 PLM-V **1-65**
 - Procedure: Clear the PLM-V Alarm on the DS-1 or DS3XM-6 Card **1-65**
- 1.3.95 PRC-DUPID **1-66**
 - Procedure: Clear the PRC-DUPID Alarm on an OC-N Card in a BLSR **1-66**
- 1.3.96 PWRRESTART **1-66**
 - Procedure: Clear the PWRRESTART Condition **1-66**
- 1.3.97 RAI **1-67**
 - Procedure: Clear the RAI Condition on DS3XM-6 or DS3E Cards in C-bit Format **1-67**
- 1.3.98 RCVR-MISS **1-67**
 - Procedure: Clear the RCVR-MISS Alarm on the DS-1 Port **1-67**
- 1.3.99 RFI-L **1-67**

	Procedure: Clear the RFI-L Condition on the OC-N or EC-1 Card	1-68
1.3.100	RFI-P	1-68
	Procedure: Clear the RFI-P Condition on the DS-N or Ethernet Card	1-68
1.3.101	RFI-V	1-68
	Procedure: Clear the RFI-V Condition on the DS3XM-6 or DS-1 Card	1-69
1.3.102	RING-MISMATCH	1-69
	Procedure: Clear the RING-MISMATCH Alarm	1-69
1.3.103	SD-L	1-70
	Procedure: Clear the SD-L Condition on an OC-N Card	1-70
1.3.104	SD-P	1-70
	Procedure: Clear the SD-P Condition on an OC-N Card	1-71
1.3.105	SF-L	1-71
	Procedure: Clear the SF-L Condition on an OC-N Card	1-72
1.3.106	SF-P	1-72
	Procedure: Clear the SF-P Condition on an OC-N Card	1-73
1.3.107	SFTWDOWN	1-73
1.3.108	SFTWDOWN-FAIL	1-73
	Procedure: Clear the SFTWDOWN-FAIL Alarm on the TCC+ Card	1-73
1.3.109	SQUELCH	1-74
	Procedure: Clear the SQUELCH Condition	1-74
1.3.110	SSM-FAIL	1-75
	Procedure: Clear the SSM-FAIL Alarm	1-75
1.3.111	STU	1-75
	Procedure: Clear the STU Condition	1-75
1.3.112	SWTOPRI	1-75
1.3.113	SWTOSEC	1-76
	Procedure: Clear the SWTOSEC Alarm	1-76
1.3.114	SWTOTHIRD	1-76
	Procedure: Clear the SWTOTHIRD Alarm	1-76
1.3.115	SYNCPRI	1-76
	Procedure: Clear the SYNCPRI Alarm on the TCC+ Card	1-76
1.3.116	SYNCSEC	1-77
	Procedure: Clear the SYNCSEC Alarm on the TCC+ Card	1-77
1.3.117	SYNCTHIRD	1-77
	Procedure: Clear the SYNCTHIRD Alarm on the TCC+ Card	1-77
1.3.118	SYSBOOT	1-78
1.3.119	TIM-P	1-78
	Procedure: Clear the TIM-P Alarm	1-78
1.3.120	TRMT	1-79
	Procedure: Clear the TRMT Alarm on the DS-1 Card	1-79

- 1.3.121 TRMT-MISS **1-79**
 - Procedure: Clear the TRMT-MISS Alarm **1-79**
- 1.3.122 UNEQ-P **1-80**
 - Procedure: Clear the UNEQ-P Alarm on the Line Card **1-80**
- 1.3.123 UNEQ-V **1-81**
 - Procedure: Clear the UNEQ-V Alarm on the DS-1 and DS3XM-6 Card **1-81**
- 1.4 DS3E Line Alarms **1-82**

CHAPTER 2**General Troubleshooting 2-1**

- 2.1 Problem List **2-1**
- 2.2 Network Tests **2-3**
 - 2.2.1 Network Test Types **2-3**
 - 2.2.2 Network Test Procedures **2-4**
 - Procedure: Perform a Facility Loopback on a Source DS-N Card **2-4**
 - Procedure: Perform a Terminal Loopback on a Destination DS-N Card **2-6**
 - Procedure: Perform a Hairpin on a Source Node **2-8**
 - Procedure: Perform a Hairpin on a Destination Node **2-10**
 - Procedure: Perform a Facility Loopback on a Destination DS-N Card **2-13**
 - 2.2.3 Using the DS3XM-6 Card FEAC (Loopback) Functions **2-16**
 - 2.2.3.1 FEAC Send Code **2-16**
 - 2.2.3.2 FEAC Inhibit Loopback **2-17**
 - 2.2.3.3 FEAC Alarms **2-17**
- 2.3 CTC Operation and Connectivity **2-17**
 - 2.3.1 Browser Stalls When Downloading jar File From TCC+ **2-17**
 - Procedure: Disable the VirusScan Download Scan **2-17**
 - 2.3.2 Browser Cache Points to an Invalid Directory **2-18**
 - Procedure: Redirect the Netscape Cache to a Valid Directory **2-18**
 - 2.3.3 Clear the CTC Cache File **2-18**
 - Procedure: Delete the CTC Cache File Automatically **2-18**
 - Procedure: Delete the CTC Cache File Manually **2-19**
 - 2.3.4 Node Icon is Grey on CTC Network View **2-19**
 - 2.3.5 CTC Cannot Launch Due to Applet Security Restrictions **2-20**
 - 2.3.6 Java Runtime Environment Incompatible **2-20**
 - 2.3.7 Different CTC Releases Do Not Recognize Each Other **2-21**
 - Procedure: Launch CTC to Correct the Core Version Build **2-21**
 - 2.3.8 Username or Password Do Not Match **2-21**
 - Procedure: Verify Correct Username and Password **2-22**
 - 2.3.9 No IP Connectivity Exists Between Nodes **2-22**
 - 2.3.10 DCC Connection Lost **2-22**

- 2.3.11 Browser Login Does not Launch Java **2-22**
- 2.3.12 Verify PC Connection to ONS 15454 (ping) **2-23**
 - Procedure: Ping the ONS 15454 **2-23**
- 2.3.13 Calculate and Design IP Subnets **2-24**
- 2.3.14 Ethernet Connections **2-24**
 - Procedure: Verify Ethernet Connections **2-24**
- 2.3.15 VLAN Cannot Connect to Network Device from Untag Port **2-25**
 - Procedure: Change VLAN Port Tag and Untagged Settings **2-26**
- 2.4 Circuits and Timing **2-27**
 - 2.4.1 AIS-V on DS3XM-6 Unused VT Circuits **2-27**
 - Procedure: Clear AIS-V on DS3XM-6 Unused VT Circuits **2-27**
 - 2.4.2 Circuit Creation Error with VT1.5 Circuit **2-27**
 - 2.4.3 Unable to Create Circuit From DS-3 Card to DS3XM-6 Card **2-28**
 - 2.4.4 DS3 Card Does Not Report AIS-P From External Equipment **2-28**
 - 2.4.5 OC-3 and DCC Limitations **2-28**
 - 2.4.6 ONS 15454 Switches Timing Reference **2-28**
 - 2.4.7 Holdover Synchronization Alarm **2-29**
 - 2.4.8 Free-Running Synchronization Mode **2-29**
 - 2.4.9 Daisy-Chained BITS Not Functioning **2-29**
- 2.5 Fiber and Cabling **2-29**
 - 2.5.1 Bit Errors Appear for a Line Card **2-29**
 - 2.5.2 Faulty Fiber-Optic Connections **2-29**
 - Procedure: Verify Fiber-Optic Connections **2-30**
 - Procedure: Replace Faulty Gigabit Interface Converters **2-31**
 - 2.5.3 Create CAT-5 Cables **2-33**
 - 2.5.4 Optical Card Transmit and Receive Levels **2-35**
- 2.6 Power and LED Tests **2-36**
 - 2.6.1 Power Supply Problems **2-36**
 - Procedure: Isolate the Cause of Power Supply Problems **2-36**
 - 2.6.2 Power Consumption for Node and Cards **2-37**
 - 2.6.3 Lamp Test for Card LEDs **2-37**
 - Procedure: Verify Card LED Operation **2-37**

CHAPTER 3

Maintenance 3-1

- 3.1 Air Filter Inspection and Replacement **3-1**
 - 3.1.1 Reusable Air Filter **3-2**
 - Procedure: Inspect and Clean the Reusable Air Filter **3-2**
 - 3.1.2 Disposable Air Filter **3-3**
 - Procedure: Inspect and Replace the Disposable Air Filter **3-3**

- 3.2 Fan-Tray Assembly Replacement **3-5**
 - Procedure: Replace the Fan-Tray Assembly **3-6**
- 3.3 Alarm Interface Panel Replacement **3-7**
 - Procedure: Replace the Alarm Interface Panel **3-8**
- 3.4 System Reset **3-8**
 - Procedure: Perform a Software-Initiated Reset **3-8**
 - Procedure: Perform a Card Pull **3-9**
- 3.5 Database Backup and Restore **3-10**
 - Procedure: Back up the Database **3-10**
 - Procedure: Restore the Database **3-11**
- 3.6 Reverting to an Earlier Software Load **3-12**
 - Procedure: Revert to an Earlier Software Load **3-13**
- 3.7 Card Replacement **3-14**
 - Procedure: Switch Traffic and Replace an In-Service Cross-Connect Card **3-14**
- 3.8 TCC Card to TCC+ Card Upgrade **3-15**
 - Procedure: Upgrade the TCC Card to the TCC+ Card **3-16**
- 3.9 XC Card to XCVT Card Upgrade **3-17**
 - Procedure: Upgrade the XC Card to the XCVT Card **3-17**
- 3.10 XC/XCVT Card to XC10G Card Upgrade **3-18**
 - Procedure: Upgrade the XC/XCVT Card to the XC10G Card **3-19**
- 3.11 DS3/DS3N Card to DS3E/DS3EN Card Upgrade **3-20**
 - Procedure: Upgrade the DS3 Card to the DS3E Card (or the DS3N Card to the DS3EN Card) **3-20**
 - Procedure: Downgrade a DS3 or DS3N Card **3-21**
- 3.12 Span Upgrades **3-22**
 - 3.12.1 Span Upgrade Wizard **3-23**
 - Procedure: Perform a Span Upgrade Using the Span Upgrade Wizard **3-23**
 - 3.12.2 Manual Span Upgrades **3-25**
 - Procedure: Perform a Manual Span Upgrade on a Two-Fiber BLSR **3-25**
 - Procedure: Perform a Manual Span Upgrade on a Four-Fiber BLSR **3-26**
 - Procedure: Perform a Manual Span Upgrade on a UPSR **3-27**
 - Procedure: Perform a Manual Span Upgrade on a 1+1 Protection Group **3-28**
- 3.13 Protection Group Switching **3-29**
 - Procedure: Apply a Lock On **3-29**
 - Procedure: Apply a Lock Out **3-30**
 - Procedure: Clear a Lock On or Lock Out **3-30**
- 3.14 Electrical Interface Assembly Replacement **3-31**
 - 3.14.1 EIA Types **3-31**
 - 3.14.2 EIA Replacement Procedures **3-32**

- Procedure: Remove the Backplane Cover or EIA 3-32
- Procedure: Install the EIAs 3-32
- 3.15 Fiber Cleaning 3-33
- 3.16 Powering Down a Node 3-33
 - Procedure: Power Down a Node 3-34

CHAPTER 4

Card Reference 4-1

- 4.1 Card Overview 4-1
 - 4.1.1 Common Control Cards 4-1
 - 4.1.2 Electrical Cards 4-2
 - 4.1.3 Optical Cards 4-3
 - 4.1.4 Ethernet Cards 4-4
 - 4.1.5 Card and Fan-Tray Assembly Power Requirements 4-5
 - 4.1.6 Card Temperature Ranges 4-6
 - 4.1.7 Card Compatibility 4-9
- 4.2 Electrical Card Protection 4-12
 - 4.2.1 Protection, 1:1 4-12
 - 4.2.2 Protection, 1:N 4-12
 - 4.2.2.1 Revertive Switching 4-13
 - 4.2.2.2 Protection Guidelines, 1:N 4-13
- 4.3 Electrical Card Protection and the Backplane 4-14
 - 4.3.1 Standard BNC Protection 4-14
 - 4.3.2 High-Density BNC Protection 4-14
 - 4.3.3 SMB Protection 4-14
 - 4.3.4 AMP Champ Protection 4-15
- 4.4 Optical Card Protection 4-15
- 4.5 Unprotected Cards 4-16
- 4.6 Timing Communication and Control (TCC+) Card 4-17
 - 4.6.1 TCC+ Card-Level Indicators 4-18
 - 4.6.2 Network-Level Indicators 4-18
 - 4.6.3 TCC+ Specifications 4-19
- 4.7 XC Cross-Connect Card 4-20
 - 4.7.1 XC Card-Level Indicators 4-21
 - 4.7.2 XC Specifications 4-22
- 4.8 XCVT Cross-Connect Card 4-23
 - 4.8.1 VT Mapping 4-24
 - 4.8.2 XCVT Hosting DS3XM-6 4-25
 - 4.8.3 XCVT Card-Level Indicators 4-25

4.8.4	XC/XCVT Compatibility	4-26
4.8.5	XCVT Card Specifications	4-26
4.9	XC10G Cross-Connect Card	4-27
4.9.1	VT Mapping	4-28
4.9.2	XC10G Hosting DS3XM-6	4-29
4.9.3	XC10G Card-Level Indicators	4-29
4.9.4	XC/XCVT/XC10G Compatibility	4-29
4.9.5	XC10G Card Specifications	4-30
4.10	Alarm Interface Controller Card	4-31
4.10.1	User-Defined Alarms	4-31
4.10.2	Orderwire	4-32
4.10.3	AIC Specifications	4-33
4.11	EC1-12 Card	4-35
4.11.1	EC1-12 Hosted by XCVT	4-36
4.11.2	EC1-12 Card-Level Indicators	4-36
4.11.3	EC1-12 Port-Level Indicators	4-36
4.11.4	EC1-12 Specifications	4-36
4.12	DS1-14 Card	4-38
4.12.1	DS1-14 Hosted by XCVT	4-39
4.12.2	DS1-14 Card-Level Indicators	4-39
4.12.3	DS1-14 Port-Level Indicators	4-39
4.12.4	DS1-14 Specifications	4-39
4.13	DS1N-14 Card	4-41
4.13.1	DS1N-14 Hosted by XCVT	4-42
4.13.2	DS1N-14 Card-Level Indicators	4-42
4.13.3	DS1N-14 Port-Level Indicators	4-42
4.13.4	DS1N-14 Specifications	4-42
4.14	DS3-12 Card	4-44
4.14.1	DS3-12 Card-Level Indicators	4-45
4.14.2	DS3-12 Port-Level Indicators	4-45
4.14.3	DS3-12 Specifications	4-45
4.15	DS3N-12 Card	4-47
4.15.1	DS3N-12 Card-Level Indicators	4-48
4.15.2	DS3N-12 Port-Level Indicators	4-48
4.15.3	DS3N-12 Card Specifications	4-48
4.16	DS3-12E Card	4-50
4.16.1	DS3-12E Card-Level Indicators	4-51
4.16.2	DS3-12E Port-Level Indicators	4-51
4.16.3	DS3-12E Compatibility	4-51

4.16.4	DS3-12E Card Specifications	4-51
4.17	DS3N-12E Card	4-53
4.17.1	DS3N-12E Card-Level Indicators	4-54
4.17.2	DS3N-12E Port-Level Indicators	4-54
4.17.3	DS3N-12E Compatibility	4-54
4.17.4	DS3N-12E Card Specifications	4-54
4.18	DS3XM-6 Card	4-56
4.18.1	DS3XM-6 Hosted By XCVT	4-57
4.18.2	DS3XM-6 Card-Level Indicators	4-57
4.18.3	DS3XM-6 Port-Level Indicators	4-57
4.18.4	DS3XM-6 Card Specifications	4-57
4.19	OC3 IR 4/STM1 SH 1310 Card	4-59
4.19.1	OC3 IR 4/STM1 SH 1310 Card-Level Indicators	4-60
4.19.2	OC3 IR 4/STM1 SH 1310 Port-Level Indicators	4-60
4.19.3	OC3 IR 4/STM1 SH 1310 Card Specifications	4-60
4.20	OC12 IR/STM4 SH 1310 Card	4-62
4.20.1	OC12 IR/STM4 SH 1310 Card-Level Indicators	4-63
4.20.2	OC12 IR/STM4 SH 1310 Port-Level Indicators	4-63
4.20.3	OC12 IR/STM4 SH 1310 Card Specifications	4-63
4.21	OC12 LR/STM4 LH 1310 Card	4-65
4.21.1	OC12 LR/STM4 LH 1310 Card-Level Indicators	4-66
4.21.2	OC12 LR/STM4 LH 1310 Port-Level Indicators	4-66
4.21.3	OC12 LR/STM4 LH 1310 Card Specifications	4-66
4.22	OC12 LR/STM4 LH 1550 Card	4-68
4.22.1	OC12 LR/STM4 LH 1550 Card-Level Indicators	4-69
4.22.2	OC12 LR/STM4 LH 1550 Port-Level Indicators	4-69
4.22.3	OC12 LR/STM4 LH 1550 Card Specifications	4-69
4.23	OC48 IR 1310 Card	4-71
4.23.1	OC48 IR 1310 Card-Level Indicators	4-72
4.23.2	OC48 IR 1310 Port-Level Indicators	4-72
4.23.3	OC48 IR 1310 Card Specifications	4-72
4.24	OC48 LR 1550 Card	4-74
4.24.1	OC48 LR 1550 Card-Level Indicators	4-75
4.24.2	OC48 LR 1550 Port-Level Indicators	4-75
4.24.3	OC48 LR 1550 Card Specifications	4-75
4.25	OC48 IR/STM16 SH AS 1310 Card	4-77
4.25.1	OC48 IR/STM16 SH AS 1310 Card-Level Indicators	4-78
4.25.2	OC48 IR/STM16 SH AS 1310 Port-Level Indicators	4-78
4.25.3	OC48 IR/STM16 SH AS 1310 Compatibility	4-78


4.25.4	OC48 IR/STM16 SH AS 1310 Card Specifications	4-78
4.26	OC48 LR/STM16 LH AS 1550 Card	4-80
4.26.1	OC48 LR/STM16 LH AS 1550 Card-Level Indicators	4-81
4.26.2	OC48 LR/STM16 LH AS 1550 Port-Level Indicators	4-81
4.26.3	OC48 LR/STM16 LH AS 1550 Compatibility	4-81
4.26.4	OC48 LR/STM16 LH AS 1550 Card Specifications	4-81
4.27	OC48 ELR/STM16 EH 100 GHz Cards	4-83
4.27.1	OC48 ELR 100 GHz Card-Level Indicators	4-84
4.27.2	OC48 ELR 100 GHz Port-Level Indicators	4-84
4.27.3	OC48 ELR 100 GHz Compatibility	4-85
4.27.4	OC48 ELR 100 GHz Card Specifications	4-85
4.28	OC48 ELR 200 GHz Cards	4-86
4.28.1	OC48 ELR 200 GHz Card-Level Indicators	4-87
4.28.2	OC48 ELR 200 GHz Port-Level Indicators	4-87
4.28.3	OC48 ELR 200 GHz Compatibility	4-88
4.28.4	OC48 ELR 200 GHz Card Specifications	4-88
4.29	OC192 LR/STM64 LH 1550 Card	4-89
4.29.1	OC192 LR/STM64 LH 1550 Card-Level Indicators	4-91
4.29.2	OC192 LR/STM64 LH 1550 Port-Level Indicators	4-91
4.29.3	OC192 LR/STM64 LH 1550 Compatibility	4-91
4.29.4	OC192 LR/STM64 LH 1550 Card Specifications	4-91
4.30	E100T-G Card	4-93
4.30.1	E100T-G Card-Level Indicators	4-94
4.30.2	E100T-G Port-Level Indicators	4-94
4.30.3	E100T-G Compatibility	4-95
4.30.4	E100T-G Card Specifications	4-95
4.31	E1000-2-G Card	4-96
4.31.1	E1000-2-G Card-Level Indicators	4-97
4.31.2	E1000-2-G Port-Level Indicators	4-97
4.31.3	E1000-2-G Compatibility	4-98
4.31.4	E1000-2-G Card Specifications	4-98
4.32	E100T-12 Card	4-99
4.32.1	E100T-12 Card-Level Indicators	4-100
4.32.2	E100T-12 Port-Level Indicators	4-100
4.32.3	E100T-12 Compatibility	4-100
4.32.4	E100T-12 Card Specifications	4-101
4.33	E1000-2 Card	4-102
4.33.1	E1000-2 Card-Level Indicators	4-103
4.33.2	E1000-2 Port-Level Indicators	4-103

4.33.3 E1000-2 Compatibility **4-104**
4.33.4 E1000-2 Card Specifications **4-104**

ACRONYMS

GLOSSARY

INDEX



<i>Figure 2-1</i>	The facility loopback process on a DS-N card	2-3
<i>Figure 2-2</i>	The terminal loopback process on an OC-N card	2-3
<i>Figure 2-3</i>	The hairpin circuit process on an OC-N card	2-4
<i>Figure 2-4</i>	Facility loopback on a source DS-N card	2-4
<i>Figure 2-5</i>	Terminal loopback on a destination DS-N card	2-6
<i>Figure 2-6</i>	Hairpin on a source node	2-8
<i>Figure 2-7</i>	Hairpin on a destination node	2-10
<i>Figure 2-8</i>	Facility loopback on a destination DS-N card	2-14
<i>Figure 2-9</i>	Accessing FEAC functions on the DS3XM-6 card	2-16
<i>Figure 2-10</i>	Diagram of far end action code	2-16
<i>Figure 2-11</i>	Deleting the CTC cache	2-19
<i>Figure 2-12</i>	Ethernet connectivity reference	2-24
<i>Figure 2-13</i>	A VLAN with Ethernet ports at Tagged And Untag	2-25
<i>Figure 2-14</i>	Configuring VLAN membership for individual Ethernet ports	2-26
<i>Figure 2-15</i>	A gigabit interface converter (GBIC)	2-31
<i>Figure 2-16</i>	Installing a GBIC on the E1000-2/E1000-2-G card	2-33
<i>Figure 2-17</i>	RJ-45 pin numbers	2-34
<i>Figure 2-18</i>	A straight-through cable layout	2-34
<i>Figure 2-19</i>	A cross-over cable layout	2-35
<i>Figure 3-1</i>	A reusable fan-tray air filter in an external filter bracket	3-2
<i>Figure 3-2</i>	Inserting or removing the fan-tray assembly	3-4
<i>Figure 3-3</i>	Inserting or removing a disposable fan-tray air filter	3-5
<i>Figure 3-4</i>	Removing or replacing the fan-tray assembly	3-7
<i>Figure 3-5</i>	Performing a software-initiated reset from the TCC+ card pull-down menu	3-9
<i>Figure 3-6</i>	Backing up the TCC+ database	3-10
<i>Figure 3-7</i>	Confirming a database backup	3-11
<i>Figure 3-8</i>	Restoring the TCC+ database	3-11
<i>Figure 3-9</i>	Restoring the database—traffic loss warning	3-12
<i>Figure 3-10</i>	Restoring the database – in-process notification	3-12
<i>Figure 3-11</i>	Initiating a software reset on the TCC card	3-16
<i>Figure 3-12</i>	Span pull-down menu	3-24

<i>Figure 3-13</i>	Beginning the Span Upgrade Wizard	3-24
<i>Figure 3-14</i>	BNC insertion and removal tool	3-33
<i>Figure 4-1</i>	ONS 15454 cards in a 1:1 protection configuration	4-12
<i>Figure 4-2</i>	ONS 15454 cards in a 1:N protection configuration	4-13
<i>Figure 4-3</i>	ONS 15454 in an unprotected configuration	4-16
<i>Figure 4-4</i>	TCC+ faceplate and block diagram	4-17
<i>Figure 4-5</i>	XC card faceplate and block diagram	4-20
<i>Figure 4-6</i>	XC cross-connect matrix	4-21
<i>Figure 4-7</i>	XCVT faceplate and block diagram	4-23
<i>Figure 4-8</i>	XCVT cross-connect matrix	4-24
<i>Figure 4-9</i>	XC10G faceplate and block diagram	4-27
<i>Figure 4-10</i>	XC10G cross-connect matrix	4-28
<i>Figure 4-11</i>	AIC faceplate and block diagram	4-31
<i>Figure 4-12</i>	RJ-11 cable	4-33
<i>Figure 4-13</i>	EC1-12 faceplate and block diagram	4-35
<i>Figure 4-14</i>	DS1-14 faceplate and block diagram	4-38
<i>Figure 4-15</i>	DS1N-14 faceplate and block diagram	4-41
<i>Figure 4-16</i>	DS3-12 faceplate and block diagram	4-44
<i>Figure 4-17</i>	DS3N-12 faceplate and block diagram	4-47
<i>Figure 4-18</i>	DS3-12E faceplate and block diagram	4-50
<i>Figure 4-19</i>	DS3N-12E faceplate and block diagram	4-53
<i>Figure 4-20</i>	DS3XM-6 faceplate and block diagram	4-56
<i>Figure 4-21</i>	OC3 IR 4/STM1 SH 1310 faceplate and block diagram	4-59
<i>Figure 4-22</i>	OC12 IR/STM4 SH 1310 faceplate and block diagram	4-62
<i>Figure 4-23</i>	OC12 LR/STM4 LH 1310 faceplate and block diagram	4-65
<i>Figure 4-24</i>	OC12 LR/STM4 LH 1550 faceplate and block diagram	4-68
<i>Figure 4-25</i>	OC48 IR 1310 faceplate and block diagram	4-71
<i>Figure 4-26</i>	OC48 LR 1550 faceplate and block diagram	4-74
<i>Figure 4-27</i>	OC48 IR/STM16 SH AS 1310 faceplate and block diagram	4-77
<i>Figure 4-28</i>	OC48 LR/STM16 LH AS 1550 faceplate and block diagram	4-80
<i>Figure 4-29</i>	OC48 ELR/STM16 EH 100 GHz faceplate and block diagram	4-83
<i>Figure 4-30</i>	OC48 ELR 200 GHz faceplate and block diagram	4-86
<i>Figure 4-31</i>	OC192 LR/STM64 LH 1550 faceplate and block diagram	4-89
<i>Figure 4-32</i>	Enlarged section of the OC192 LR/STM64 LH 1550 faceplate	4-90
<i>Figure 4-33</i>	E100T-G faceplate and block diagram	4-93

<i>Figure 4-34</i>	E1000-2-G faceplate and block diagram	4-96
<i>Figure 4-35</i>	E100T-12 faceplate and block diagram	4-99
<i>Figure 4-36</i>	E1000-2 faceplate and block diagram	4-102



<i>Table 1-1</i>	Alarm Index	1-1
<i>Table 1-2</i>	DS3E Line Alarms	1-82
<i>Table 2-1</i>	Type of Problem and Solution Location	2-1
<i>Table 2-2</i>	JRE Compatibility	2-20
<i>Table 2-3</i>	Straight-Through Cable for Both Ends and Cross-Over Cable for First End	2-34
<i>Table 2-4</i>	Second End of Cross-over Cable	2-35
<i>Table 2-5</i>	Optical Card Transmit and Receive Levels	2-35
<i>Table 3-1</i>	EIA Configurations	3-31
<i>Table 4-1</i>	Common Control Card Functions	4-1
<i>Table 4-2</i>	Electrical Cards for the ONS 15454	4-2
<i>Table 4-3</i>	Optical Cards for the ONS 15454	4-3
<i>Table 4-4</i>	Ethernet Cards for the ONS 15454	4-4
<i>Table 4-5</i>	Individual Card Power Requirements	4-5
<i>Table 4-6</i>	Fan Tray Assemblies	4-6
<i>Table 4-7</i>	Card Temperature Ranges and Product Names for the ONS 15454	4-6
<i>Table 4-8</i>	TCC+ Card Software and Cross-Connect Card Compatibility for the ONS 15454	4-9
<i>Table 4-9</i>	Cross-Connect Card Software and Hardware Compatibility for the ONS 15454	4-9
<i>Table 4-10</i>	Alarm Interface Controller Card Software and Cross-Connect Card Compatibility for the ONS 15454	4-9
<i>Table 4-11</i>	Electrical Card Software and Cross-Connect Card Compatibility for the ONS 15454	4-9
<i>Table 4-12</i>	Optical Card Software and Cross-Connect Card Compatibility for the ONS 15454	4-10
<i>Table 4-13</i>	Ethernet Card Software and Cross-Connect Card Compatibility for the ONS 15454	4-11
<i>Table 4-14</i>	TCC+ Card-Level Indicators	4-18
<i>Table 4-15</i>	TCC+ System-Level Indicators	4-18
<i>Table 4-16</i>	XC Card-Level Indicators	4-21
<i>Table 4-17</i>	ONS 15454 VT Mapping	4-24
<i>Table 4-18</i>	XCVT Card-Level Indicators	4-25
<i>Table 4-19</i>	ONS 15454 VT Mapping	4-28
<i>Table 4-20</i>	XC10G Card-Level Indicators	4-29
<i>Table 4-21</i>	Orderwire Pin Assignments	4-33
<i>Table 4-22</i>	EC1-12 Card-Level Indicators	4-36
<i>Table 4-23</i>	DS1-14 Card-Level Indicators	4-39

<i>Table 4-24</i>	DS1N-14 Card-Level Indicators	4-42
<i>Table 4-25</i>	DS3-12 Card-Level Indicators	4-45
<i>Table 4-26</i>	DS3N-12 Card-Level Indicators	4-48
<i>Table 4-27</i>	DS3-12E Card-Level Indicators	4-51
<i>Table 4-28</i>	DS3N-12E Card-Level Indicators	4-54
<i>Table 4-29</i>	DS3XM-6 Card-Level Indicators	4-57
<i>Table 4-30</i>	OC3 IR 4/STM1 SH 1310 Card-Level Indicators	4-60
<i>Table 4-31</i>	OC12 IR/STM4 SH 1310 Card-Level Indicators	4-63
<i>Table 4-32</i>	OC12 LR/STM4 LH 1310 Card-Level Indicators	4-66
<i>Table 4-33</i>	OC12 LR/STM4 LH 1550 Card-Level Indicators	4-69
<i>Table 4-34</i>	OC48 IR 1310 Card-Level Indicators	4-72
<i>Table 4-35</i>	OC48 LR 1550 Card-Level Indicators	4-75
<i>Table 4-36</i>	OC48 IR/STM16 SH AS 1310 Card-Level Indicators	4-78
<i>Table 4-37</i>	OC48 LR/STM16 LH AS 1550 Card-Level Indicators	4-81
<i>Table 4-38</i>	OC48 ELR/STM16 EH 100 GHz Card-Level Indicators	4-84
<i>Table 4-39</i>	OC48 ELR 200 GHz Card-Level Indicators	4-87
<i>Table 4-40</i>	OC192 LR/STM64 LH 1550 Card-Level Indicators	4-91
<i>Table 4-41</i>	E100T-G Card-Level Indicators	4-94
<i>Table 4-42</i>	E100T-G Port-Level Indicators	4-94
<i>Table 4-43</i>	E1000-2-G Card-Level Indicators	4-97
<i>Table 4-44</i>	E1000-2-G Port-Level Indicators	4-98
<i>Table 4-45</i>	E100T-12 Card-Level Indicators	4-100
<i>Table 4-46</i>	E100T-12 Port-Level Indicators	4-100
<i>Table 4-47</i>	E1000-2 Card-Level Indicators	4-103
<i>Table 4-48</i>	E1000-2 Port-Level Indicators	4-104



Cisco TAC Web Site **xxxiii**

Cisco TAC Escalation Center **xxxiii**

Alarm Troubleshooting

- Clear the AIS Condition **1-4**
- Clear the AIS-L Condition **1-4**
- Clear the AIS-P Condition **1-5**
- Clear the AIS-V Condition on the DS-1/DS3XM-6 Card **1-6**
- Clear the APSB Alarm on an OC-N Card **1-6**
- Clear the APSCDFLTK Alarm **1-6**
- Clear the APSC-IMP Alarm **1-7**
- Clear the APSCINCON Alarm on an OC-N Card in a BLSR **1-8**
- Clear the APSCM Alarm on an OC-N Card in 1+1 Mode **1-9**
- Clear the APSCNMIS Alarm **1-9**
- Clear the APSCONNL Alarm on an OC-N Card in a BLSR **1-10**
- Clear the APSMM Alarm in 1+1 Mode **1-11**
- Clear the AUTOLSROFF Alarm **1-12**
- Clear the AUTORESET Alarm **1-12**
- Clear the BKUPMEMP Alarm **1-14**
- Clear the BLSROSYNC Alarm **1-15**
- Clear the CARLOSS Alarm **1-16**
- Clear the CONCAT Alarm **1-17**
- Clear the CONNLOS Alarm **1-17**
- Clear the CONTBUS-A-X Alarm for Slots 1 Through 17 **1-18**
- Clear the CONTBUS-A-18 Alarm **1-19**
- Clear the CONTBUS-B-X Alarm for Slots 1 Through 17 **1-20**
- Clear the CONTBUS-B-18 Alarm on the TCC+ Card **1-21**
- Clear the CTNEQPT-PB1PROT Alarm **1-22**
- Clear the CTNEQPT-PB1WORK Alarm **1-23**
- Clear the CTNEQPT-PBXPROT Alarm **1-24**
- Clear the CTNEQPT-PBXWORK Alarm **1-26**
- Clear the DISCONNECTED Alarm **1-28**

- Clear the EOC Alarm on an OC-N Card **1-28**
- Clear the EQPT Alarm **1-30**
- Clear the E-W-MISMATCH Alarm with a Physical Switch **1-31**
- Clear the E-W-MISMATCH Alarm with the CTC **1-31**
- Clear the EXCCOL Alarm **1-32**
- Clear the EXT Alarm **1-33**
- Clear the FAILTOSW Alarm **1-33**
- Clear the FAILTOSW-PATH Alarm on a UPSR Configuration **1-34**
- Clear the FAILTOSWR Alarm on a Four-Fiber BLSR Configuration **1-35**
- Clear the FAN Alarm **1-37**
- Clear the FE-AIS Condition on the DS3XM-6 or DS3E Cards in C-bit Format **1-37**
- Clear the FE-DS1-MULTLOS Condition on the DS3XM-6 **1-38**
- Clear the FE-DS1-SNGLLOS Condition on the DS3XM-6 **1-38**
- Clear the FE-EQPT-FAIL-SA Condition on the DS3XM-6 or DS3E Cards in C-bit Format **1-39**
- Clear the FE-EQPT-NSA Condition on the DS3XM-6 or DS3E Cards in C-bit Format **1-39**
- Clear the FE-IDLE Condition on the DS3XM-6 or DS3E Cards in C-bit Format **1-40**
- Clear the FE-LOCKOUT Alarm on a BLSR **1-40**
- Clear the FE-LOF Condition on the DS3XM-6 or DS-3E Cards in C-bit Format **1-40**
- Clear the FE-LOS Condition on the DS3XM-6 or DS-3E Cards in C-bit Format **1-41**
- Clear the FEPRLF Alarm on a Four-Fiber BLSR **1-41**
- Clear the FORCED-REQ Alarm on an OC-N Card **1-42**
- Clear the FRNGSYNC Alarm **1-42**
- Clear the HITEMP Alarm **1-43**
- Clear the HLDOVERSYNC Alarm **1-43**
- Clear the IMPROPRMVL Alarm **1-44**
- Clear the INCOMPATIBLE-SW Alarm **1-45**
- Clear the INVMACADDR Alarm **1-46**
- Clear the Lockout Switch Request and the LOCKOUT-REQ Condition on an OC-N Card **1-46**
- Clear the LOF Condition on the DS-1 Card **1-46**
- Clear the LOF Condition on the DS3XM-6 or DS-3E Cards in C-bit Format **1-47**
- Clear the LOF Alarm on the TCC+ Card **1-48**
- Clear the LOF Alarm on the EC-1 Card **1-49**
- Clear the LOF Alarm on an OC-N Card **1-50**
- Clear the LOP Alarm on a Line Card **1-51**
- Clear the LOP-V Alarm on the DS3XM-6 or DS-1 Card **1-52**

- Clear the LOS Alarm on the DS-3, DS3XM-6, or DS-1 Card **1-53**
- Clear the LOS Alarm **1-54**
- Clear the LOS Alarm on an OC-N Card **1-54**
- Clear the LOS Alarm on the EC-1 Card **1-55**
- Clear the LBKFACILITY Alarm on the DS-3, DS-3E, DS3XM-6 or DS-1 Card **1-57**
- Clear the LBKFACILITY Condition on the OC-N Card **1-57**
- Clear the LPBKTERMINAL Condition on a DS-N Card **1-58**
- Clear the LBKTERMINAL Condition on an OC-N Card **1-58**
- Clear the Manual Switch and the MANUAL-REQ Condition on an OC-N Card **1-59**
- Clear the MEA Alarm on a Cross-Connect or Line Card **1-59**
- Clear the MFGMEM Alarm on the AIP, Fan Tray, or Backplane. **1-61**
- Clear the NOT-AUTHENTICATED Alarm on the TCC+ Card **1-62**
- Clear the PDI-P Alarm Reported on the DS-3, DS-3E, DS3XM-6 or DS-1 Card **1-63**
- Clear the PEER-NORESPONSE Alarm Reported on DS-N, OC-N or EC1 Card **1-64**
- Clear the PLM-P Alarm Reported on the DS-N Card **1-65**
- Clear the PLM-V Alarm on the DS-1 or DS3XM-6 Card **1-65**
- Clear the PRC-DUPID Alarm on an OC-N Card in a BLSR **1-66**
- Clear the PWRRESTART Condition **1-66**
- Clear the RAI Condition on DS3XM-6 or DS3E Cards in C-bit Format **1-67**
- Clear the RCVR-MISS Alarm on the DS-1 Port **1-67**
- Clear the RFI-L Condition on the OC-N or EC-1 Card **1-68**
- Clear the RFI-P Condition on the DS-N or Ethernet Card **1-68**
- Clear the RFI-V Condition on the DS3XM-6 or DS-1 Card **1-69**
- Clear the RING-MISMATCH Alarm **1-69**
- Clear the SD-L Condition on an OC-N Card **1-70**
- Clear the SD-P Condition on an OC-N Card **1-71**
- Clear the SF-L Condition on an OC-N Card **1-72**
- Clear the SF-P Condition on an OC-N Card **1-73**
- Clear the SFTWDOWN-FAIL Alarm on the TCC+ Card **1-73**
- Clear the SQUELCH Condition **1-74**
- Clear the SSM-FAIL Alarm **1-75**
- Clear the STU Condition **1-75**
- Clear the SWTOSEC Alarm **1-76**
- Clear the SWTOTHIRD Alarm **1-76**
- Clear the SYNCPRI Alarm on the TCC+ Card **1-76**

- Clear the SYNCSEC Alarm on the TCC+ Card **1-77**
- Clear the SYNCTHIRD Alarm on the TCC+ Card **1-77**
- Clear the TIM-P Alarm **1-78**
- Clear the TRMT Alarm on the DS-1 Card **1-79**
- Clear the TRMT-MISS Alarm **1-79**
- Clear the UNEQ-P Alarm on the Line Card **1-80**
- Clear the UNEQ-V Alarm on the DS-1 and DS3XM-6 Card **1-81**

General Troubleshooting


- Perform a Facility Loopback on a Source DS-N Card **2-4**
- Perform a Terminal Loopback on a Destination DS-N Card **2-6**
- Perform a Hairpin on a Source Node **2-8**
- Perform a Hairpin on a Destination Node **2-10**
- Perform a Facility Loopback on a Destination DS-N Card **2-13**
- Disable the VirusScan Download Scan **2-17**
- Redirect the Netscape Cache to a Valid Directory **2-18**
- Delete the CTC Cache File Automatically **2-18**
- Delete the CTC Cache File Manually **2-19**
- Launch CTC to Correct the Core Version Build **2-21**
- Verify Correct Username and Password **2-22**
- Ping the ONS 15454 **2-23**
- Verify Ethernet Connections **2-24**
- Change VLAN Port Tag and Untagged Settings **2-26**
- Clear AIS-V on DS3XM-6 Unused VT Circuits **2-27**
- Verify Fiber-Optic Connections **2-30**
- Replace Faulty Gigabit Interface Converters **2-31**
- Isolate the Cause of Power Supply Problems **2-36**
- Verify Card LED Operation **2-37**

Maintenance

- Inspect and Clean the Reusable Air Filter **3-2**
- Inspect and Replace the Disposable Air Filter **3-3**
- Replace the Fan-Tray Assembly **3-6**
- Replace the Alarm Interface Panel **3-8**
- Perform a Software-Initiated Reset **3-8**
- Perform a Card Pull **3-9**

- Back up the Database **3-10**
- Restore the Database **3-11**
- Revert to an Earlier Software Load **3-13**
- Switch Traffic and Replace an In-Service Cross-Connect Card **3-14**
- Upgrade the TCC Card to the TCC+ Card **3-16**
- Upgrade the XC Card to the XCVT Card **3-17**
- Upgrade the XC/XCVT Card to the XC10G Card **3-19**
- Upgrade the DS3 Card to the DS3E Card (or the DS3N Card to the DS3EN Card) **3-20**
- Downgrade a DS3 or DS3N Card **3-21**
- Perform a Span Upgrade Using the Span Upgrade Wizard **3-23**
- Perform a Manual Span Upgrade on a Two-Fiber BLSR **3-25**
- Perform a Manual Span Upgrade on a Four-Fiber BLSR **3-26**
- Perform a Manual Span Upgrade on a UPSR **3-27**
- Perform a Manual Span Upgrade on a 1+1 Protection Group **3-28**
- Apply a Lock On **3-29**
- Apply a Lock Out **3-30**
- Clear a Lock On or Lock Out **3-30**
- Remove the Backplane Cover or EIA **3-32**
- Install the EIAs **3-32**
- Power Down a Node **3-34**

Card Reference



About This Manual

This section explains who should read the *Cisco ONS 15454 Troubleshooting and Maintenance Guide*, how the document is organized, related documentation, document conventions, how to order print and CD-ROM documentation, and how to obtain technical assistance.

Audience

This guide is for Cisco ONS 15454 users who are responsible for troubleshooting and maintenance. General troubleshooting categories and a comprehensive list of ONS 15454 alarms are provided. These sections include procedures for correcting every troubleshooting issue. All maintenance procedures are included, as well as detailed card reference information.

Users responsible for installing and configuring ONS 15454 nodes should have the companion *Cisco ONS 15454 Installation and Operations Guide*. Users who require TL1 information should consult the *Cisco ONS 15454 TL1 Command Guide*.

Organization

Chapter and Title	Description
Chapter 1, "Alarm Troubleshooting"	Alphabetically lists the alarms generated by the ONS 15454 and provides troubleshooting procedures for each alarm
Chapter 2, "General Troubleshooting"	Explains several common troubleshooting topics and provides their solution procedures
Chapter 3, "Maintenance"	Explains how to perform several routine hardware and software maintenance procedures
Chapter 4, "Card Reference"	Provides a functional description, illustration, block diagram, and the specifications for every ONS 15454 card

Related Documentation

Cisco ONS 15454 Installation and Operations Guide, Release 3.1

Cisco ONS 15454 TL1 Command Guide, Release 3.1

Cisco ONS 15454 Product Overview, Release 3.1

Release Notes for the Cisco ONS 15454, Release 3.1

Cisco Warranty Services for ONG Products

Cisco ONS 15454 Quick Configuration Guide

Cisco ONS 15454 Quick Installation Guide

Cisco ONS 15454 Quick Reference for TL1 Commands, Release 3.1

Related products:

Cisco ONS 15216 EDFA1 Operations Guide

Installing the Cisco ONS 15216 DWDM Filters

Installing Cisco ONS 15216 OADMS

Installing Cisco ONS 15216 Optical Performance Manager Operations Guide

Conventions

The following conventions are used throughout this publication:



Note

Means reader take note. Notes contain helpful suggestions or useful background information.



Caution

Means reader be careful. In this situation, you might do something that could result in equipment damage or loss of data.



Warning

Means reader be careful. In this situation, you might do something that could result in harm to yourself or others.



Tip

Means the information might help you solve a problem.

Convention	Definition
Telcordia	Replaces all instances of Bellcore, the former name of Telcordia Technologies, Inc.
Cisco Transport Controller (CTC)	Replaces all instances of Cerent Management System (CMS)
Bold	Denotes icons, buttons, or tabs that the user must select

>	Used to separate consecutive actions; for example, “click the Maintenance>Protection>Ring tabs”
Procedure:	Precedes all procedures; a horizontal line indicates the end of each procedure

Obtaining Documentation

The following sections provide sources for obtaining documentation from Cisco Systems.

World Wide Web

You can access the most current Cisco documentation on the World Wide Web at the following URL:

<http://www.cisco.com>

Translated documentation is available at the following URL:

http://www.cisco.com/public/countries_languages.shtml

Optical Networking Product Documentation CD-ROM

Optical networking-related documentation, including Release 3.1 of the *Cisco ONS 15454 Troubleshooting and Reference Guide*, *Cisco ONS 15454 Installation and Operations Guide*, and *Cisco ONS 15454 TLI Command Reference Guide* is available in a CD-ROM package that ships with your product. The Optical Networking Product Documentation CD-ROM, a member of the Cisco Connection Family, is updated as required. Therefore, it might be more current than printed documentation. To order additional copies of the Optical Networking Product Documentation CD-ROM, contact your local sales representative or call customer service. The CD-ROM package is available as a single package or as an annual subscription. You can also access Cisco documentation on the World Wide Web at <http://www.cisco.com>, <http://www-china.cisco.com>, or <http://www.europe.cisco.com>.

Ordering Documentation

Cisco documentation is available in the following ways:

- Registered Cisco Direct Customers can order Cisco Product documentation, including the *Optical Networking Product* CD-ROM, from the Networking Products MarketPlace:
http://www.cisco.com/cgi-bin/order/order_root.pl
- Nonregistered Cisco.com users can order documentation through a local account representative by calling Cisco corporate headquarters (California, USA) at 408 526-7208 or, in North America, by calling 800 553-NETS (6387).

Documentation Feedback

If you are reading Cisco product documentation on Cisco.com, you can submit technical comments electronically. Click **Feedback** at the top of the Cisco Documentation home page. After you complete the form, print it out and fax it to Cisco at 408 527-0730.

You can e-mail your comments to bug-doc@cisco.com.

To submit your comments by mail, use the response card behind the front cover of your document, or write to the following address:

Cisco Systems
Attn: Document Resource Connection
170 West Tasman Drive
San Jose, CA 95134-9883

We appreciate your comments.

Obtaining Technical Assistance

Cisco provides [Cisco.com](http://www.cisco.com) as a starting point for all technical assistance. Customers and partners can obtain documentation, troubleshooting tips, and sample configurations from online tools by using the Cisco Technical Assistance Center (TAC) Web Site. [Cisco.com](http://www.cisco.com) registered users have complete access to the technical support resources on the Cisco TAC Web Site.

Cisco.com

[Cisco.com](http://www.cisco.com) is the foundation of a suite of interactive, networked services that provides immediate, open access to Cisco information, networking solutions, services, programs, and resources at any time, from anywhere in the world.

[Cisco.com](http://www.cisco.com) is a highly integrated Internet application and a powerful, easy-to-use tool that provides a broad range of features and services to help you to

- Streamline business processes and improve productivity
- Resolve technical issues with online support
- Download and test software packages
- Order Cisco learning materials and merchandise
- Register for online skill assessment, training, and certification programs

You can self-register on [Cisco.com](http://www.cisco.com) to obtain customized information and service. To access [Cisco.com](http://www.cisco.com), go to the following URL:

<http://www.cisco.com>

Technical Assistance Center

The Cisco TAC is available to all customers who need technical assistance with a Cisco product, technology, or solution. Two types of support are available through the Cisco TAC: the Cisco TAC Web Site and the Cisco TAC Escalation Center.

Inquiries to Cisco TAC are categorized according to the urgency of the issue:

- Priority level 4 (P4)—You need information or assistance concerning Cisco product capabilities, product installation, or basic product configuration.
- Priority level 3 (P3)—Your network performance is degraded. Network functionality is noticeably impaired, but most business operations continue.

- Priority level 2 (P2)—Your production network is severely degraded, affecting significant aspects of business operations. No workaround is available.
- Priority level 1 (P1)—Your production network is down, and a critical impact to business operations will occur if service is not restored quickly. No workaround is available.

Which Cisco TAC resource you choose is based on the priority of the problem and the conditions of service contracts, when applicable.

Cisco TAC Web Site

The Cisco TAC Web Site allows you to resolve P3 and P4 issues yourself, saving both cost and time. The site provides around-the-clock access to online tools, knowledge bases, and software. To access the Cisco TAC Web Site, go to the following URL:

<http://www.cisco.com/tac>

All customers, partners, and resellers who have a valid Cisco services contract have complete access to the technical support resources on the Cisco TAC Web Site. The Cisco TAC Web Site requires a Cisco.com login ID and password. If you have a valid service contract but do not have a login ID or password, go to the following URL to register:

<http://www.cisco.com/register/>

If you cannot resolve your technical issues by using the Cisco TAC Web Site, and you are a Cisco.com registered user, you can open a case online by using the TAC Case Open tool at the following URL:

<http://www.cisco.com/tac/caseopen>

If you have Internet access, it is recommended that you open P3 and P4 cases through the Cisco TAC Web Site.

Cisco TAC Escalation Center

The Cisco TAC Escalation Center addresses issues that are classified as priority level 1 or priority level 2; these classifications are assigned when severe network degradation significantly impacts business operations. When you contact the TAC Escalation Center with a P1 or P2 problem, a Cisco TAC engineer will automatically open a case.

To obtain a directory of toll-free Cisco TAC telephone numbers for your country, go to the following URL:

<http://www.cisco.com/warp/public/687/Directory/DirTAC.shtml>

Before calling, please check with your network operations center to determine the level of Cisco support services to which your company is entitled; for example, SMARTnet, SMARTnet Onsite, or Network Supported Accounts (NSA). In addition, please have available your service agreement number and your product serial number.



Alarm Troubleshooting

This chapter gives an alphabetical list of Cisco Transport Controller (CTC) alarms for the Cisco ONS 15454, including name, severity, and troubleshooting procedure. The procedure to correct an alarm applies to the CTC and TL1 version of that alarm.

All alarm severities listed are the default for the active card, if applicable. The default standby severity for all ONS 15454 alarms is Minor, Non-service affecting, as defined in Telcordia GR-474.

This chapter provides a comprehensive list of alarms (conditions with a severity of Minor, Major or Critical.) It also includes some conditions with severities of non-alarmed (NA) or not reported (NR), which are commonly encountered while troubleshooting major alarms. The default standby severity for conditions with a severity of NA, Non-service affecting (NSA) is NA, NSA. The default standby severity for conditions with a severity of NR, NSA is NR, NSA. For a comprehensive list of all conditions, see the *Cisco ONS 15454 TL1 Command Guide*.

Log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center to report a service-affecting problem (1-877-323-7368).

1.1 Alarm Index

The alarm index gives the name and page number of every alarm in the chapter.

Table 1-1 Alarm Index

AIS, page 1-4	EXT, page 1-32	MANRESET, page 1-59
AIS-L, page 1-4	FAILTOSW, page 1-33	MANUAL-REQ, page 1-59
AIS-P, page 1-5	FAILTOSW-PATH, page 1-33	MEA, page 1-59
AIS-V, page 1-5	FAILTOSWR, page 1-35	MEM-GONE, page 1-60
APSB, page 1-6	FAILTOSWS, page 1-36	MEM-LOW, page 1-60
APSCDFLTK, page 1-6	FAN, page 1-37	MFGMEM, page 1-61
APSC-IMP, page 1-7	FE-AIS, page 1-37	NOT-AUTHENTICATED, page 1-62
APSCINCON, page 1-8	FE-DS1-MULTLOS, page 1-38	PDI-P, page 1-63
APSCM, page 1-8	FE-DS1-SNGLLOS, page 1-38	PEER-NORESPONSE, page 1-64
APSCNMIS, page 1-9	FE-EQPT-FAIL-SA, page 1-38	PLM-P, page 1-64
APSCONNL, page 1-10	FE-EQPT-NSA, page 1-39	PLM-V, page 1-65
APSMM, page 1-11	FE-IDLE, page 1-39	PRC-DUPID, page 1-66

Table 1-1 Alarm Index (continued)

AUTOLSROFF, page 1-11	FE-LOCKOUT, page 1-40	PWRRESTART, page 1-66
AUTORESET, page 1-12	FE-LOF, page 1-40	RAI, page 1-67
AUTOSW-AIS, page 1-12	FE-LOS, page 1-41	RCVR-MISS, page 1-67
AUTOSW-LOP, page 1-13	FEPLRF, page 1-41	RFI-L, page 1-67
AUTOSW-PDI, page 1-13	FORCED-REQ, page 1-41	RFI-P, page 1-68
AUTOSW-SDBER, page 1-13	FRNGSYNC, page 1-42	RFI-V, page 1-68
AUTOSW-SFBER, page 1-13	FSTSYNC, page 1-42	RING-MISMATCH, page 1-69
AUTOSW-UNEQ, page 1-13	HITEMP, page 1-42	SD-L, page 1-70
BKUPMEMP, page 1-13	HLDOVERSYNC, page 1-43	SD-P, page 1-70
BLSROSYNC, page 1-14	IMPROPRMVL, page 1-44	SF-L, page 1-71
CARLOSS, page 1-15	INCOMPATIBLE-SW, page 1-45	SF-P, page 1-72
CONCAT, page 1-16	INVMACADR, page 1-45	SFTWDOWN, page 1-73
CONNLOS, page 1-17	LOCKOUT-REQ, page 1-46	SFTWDOWN-FAIL, page 1-73
CONTBUS-A-X, page 1-18	LOF (DS-1), page 1-46	SQUELCH, page 1-74
CONTBUS-A-18, page 1-19	LOF (DS3XM-6), page 1-47	SSM-FAIL, page 1-75
CONTBUS-B-X, page 1-20	LOF (BITS), page 1-48	STU, page 1-75
CONTBUS-B-18, page 1-21	LOF (OC-N), page 1-50	SWTOPRI, page 1-75
CTNEQPT-PB1PROT, page 1-21	LOP-P, page 1-50	SWTOSEC, page 1-76
CTNEQPT-PB1WORK, page 1-23	LOP-V, page 1-52	SWTOTHIRD, page 1-76
CTNEQPT-PBXPROT, page 1-24	LOS (DS-N), page 1-53	SYNCPRI, page 1-76
CTNEQPT-PBXWORK, page 1-25	LOS (BITS), page 1-54	SYNCSEC, page 1-77
DATAFLT, page 1-27	LOS (OC-N), page 1-54	SYNCTHIRD, page 1-77
DISCONNECTED, page 1-27	LOS (EC-1), page 1-55	SYSBOOT, page 1-78
EOC, page 1-28	LPBKDS1FEAC, page 1-56	TIM-P, page 1-78
EQPT, page 1-30	LPBKDS3FEAC, page 1-56	TRMT, page 1-79
E-W-MISMATCH, page 1-30	LPBKFACILITY (DS-N), page 1-56	TRMT-MISS, page 1-79
EXCCOL, page 1-32	LPBKFACILITY (OC-N), page 1-57	UNEQ-P, page 1-80
EXERCISE-SPAN-FAIL, page 1-32	LPBKTERMINAL (DS-N), page 1-57	UNEQ-V, page 1-81
EXERCISE-RING-FAIL, page 1-32	LPBKTERMINAL (OC-N), page 1-58	

1.2 Trouble Notifications

The ONS 15454 uses standard Telcordia categories to characterize levels of trouble. The ONS 15454 reports both alarmed trouble notifications, under the Alarms tab, and non-alarmed (NA) trouble notifications, under the Conditions tab in CTC. Alarms signify a problem that the user needs to fix, such as a loss of signal (LOS). Conditions notify the user of an event which does not require action, such as a switch to a secondary timing reference (SWTOSEC) or a user-initiated manual reset (MANRESET).

Telcordia further divides alarms into Service-Affecting (SA) and Non-Service-Affecting (NSA) status. An SA failure affects a provided service or the network's ability to provide service. For example, a missing transmitter (TRM-MISS) alarm is characterized as an SA failure. TRM-MISS occurs when the cable connector leading to a port on an active DS1-14 card is removed. This affects a provided service, because traffic switches to the protect card. The high temperature (HITEMP) alarm, which means the ONS 15454 is hotter than 122 degrees Fahrenheit (50 degrees Celsius), is also an SA failure. Although for example a particular DS-1 port may not be affected, a high temperature affects the network's ability to provide service.

1.2.1 Conditions

When an SA failure is detected, the ONS 15454 also sends an alarm indication signal (AIS) downstream. When it receives the AIS, the receiving node sends a remote failure indication (RFI) upstream. AIS and RFI belong in the conditions category and show up on the Conditions screen of the ONS 15454. However, unlike most conditions which are non-alarmed, Telcordia classifies these conditions as not reported (NR).

Both CTC and TL1 report NRs and NAs as conditions when conditions are retrieved. NAs are also reported as autonomous events under TL1 and under the History tab of the CTC. For a comprehensive list of all conditions, see the *Cisco ONS 15454 TL1 Command Guide*.

1.2.2 Severities

The ONS 15454 uses Telcordia-standard severities: Critical (CR), Major (MJ), and Minor (MN). Critical indicates a severe, service-affecting alarm that needs immediate correction. Major is still a serious alarm, but the failure has less of an impact on the network. For example, with a DS-1 LOS, a Major alarm, 24 DS-0 circuits lose protection. But with a OC-192 LOS, a Critical alarm, over a hundred thousand DS-0 circuits lose protection.

Minor alarms, such as Fast Start Synchronization (FSTSYNC), do not have a serious affect on service. FSTSYNC lets you know that the ONS 15454 is choosing a new timing reference because the old reference failed. The loss of the prior timing source is something a user needs to look at, but it should not disrupt service.

Telcordia standard severities are the default settings for the ONS 15454. A user may customize ONS 15454 alarm severities with the alarm profiles feature. For a description of alarm profiles, see the *Cisco ONS 15454 Installation and Operations Guide*.

This chapter lists the default alarm severity for the active reporting card, if applicable. The default severity for alarms reported by standby cards is always Minor, Non-Service-Affecting.

1.3 Alarm Procedures

This section lists alarms alphabetically and includes some conditions commonly encountered when troubleshooting alarms. The severity, description and troubleshooting procedure accompany each alarm and condition.

1.3.1 AIS

- Not Reported (NR)

The ONS 15454 detects an alarm indication signal (AIS) in the SONET overhead. This alarm is secondary to another alarm occurring simultaneously in an upstream node. An incomplete circuit path causes an AIS, for example, when the port on the reporting node is in-service but the OC-N port on a node upstream on the circuit is not in-service. The upstream node often reports a loss of service or has an out-of-service port. The AIS clears when you clear the primary alarm on the upstream node. However, the primary alarm node may not report any alarms that indicate it is at fault.

Procedure: Clear the AIS Condition

-
- | | |
|---------------|---|
| Step 1 | Check upstream nodes and equipment for alarms, especially for LOS and out-of-service ports. |
| Step 2 | Clear the upstream alarms. |
-

1.3.2 AIS-L

- Not Reported (NR)

The ONS 15454 detects an alarm indication signal (AIS) in the SONET overhead. This alarm is secondary to another alarm occurring simultaneously in an upstream node. An incomplete circuit path causes an AIS, for example, when the port on the reporting node is in-service but a node upstream on the circuit does not have its OC-N port in-service. The upstream node often reports an LOS or has an out-of-service port. The AIS-L clears when you clear the primary alarm on the upstream node. However, the primary alarm node may not report any alarms that indicate it is at fault.

An AIS-L occurs at the line layer. The line layer refers to the segment between two SONET devices in the circuit and is also known as a maintenance span. The line layer deals with SONET payload transport, and its functions include multiplexing and synchronization.

Procedure: Clear the AIS-L Condition

-
- | | |
|---------------|---|
| Step 1 | Check upstream nodes and equipment for alarms, especially for LOS and an out-of-service port. |
| Step 2 | Clear the upstream alarms. |
-

1.3.3 AIS-P

- Not Reported (NR) (Condition)

The ONS 15454 detects an alarm indication signal (AIS) in the SONET overhead. This alarm is secondary to another alarm occurring simultaneously in an upstream node. The AIS is caused by an incomplete circuit path, for example, when the port on the reporting node is in-service, but a node upstream on the circuit does not have its port in-service. The upstream node often reports a LOS or has an OC-N port out of service. The AIS-P clears when the primary alarm on the upstream node is cleared. However, the node with the primary alarm may not report any alarms to indicate it is at fault.

AIS-P occurs in each node on the incoming OC-N path. The path layer is the segment between the originating equipment and the terminating equipment. This path segment encompasses several consecutive line segments or segments between two SONET devices. The originating equipment puts bits together into a SONET payload and the terminating equipment breaks the bits apart again. SONET multiplexers, such as the ONS 15454, often perform the origination and termination tasks of the SONET payload.

Procedure: Clear the AIS-P Condition

-
- | | |
|---------------|---|
| Step 1 | Check upstream nodes and equipment for alarms, especially LOS and out-of-service ports. |
| Step 2 | Clear the upstream alarms. |
-

1.3.4 AIS-V

- Not Reported (NR)

The ONS 15454 detects an alarm indication signal (AIS) in the SONET overhead. This alarm is secondary to another alarm occurring simultaneously in an upstream node. An incomplete circuit path causes an AIS, for example, when the port on the reporting node is in-service but a node upstream on the circuit does not have its OC-N port in-service. The upstream node often reports a LOS or has an out-of-service port. The AIS-V clears when the primary alarm is cleared. The node with the out-of-service port may not report any alarms to indicate it is at fault.

An AIS-V indicates that an upstream failure occurred at the virtual tributary (VT) layer. The VT, or electrical layer, is created when the SONET signal is broken down into an electrical signal, for example when an optical signal comes into an ONS 15454 OC-N card. If this optical signal is demultiplexed by the ONS 15454, and one of the channels separated from the optical signal is then cross-connected into the DS-1 ports in the same node, that ONS 15454 reports an AIS-V alarm.

An AIS-V error message on the electrical card is accompanied by an AIS-P error message on the cross-connected OC-N card.



Note

See the “AIS-V on DS3XM-6 Unused VT Circuits” section on page 2-27 for AIS-Vs that occur on DS3XM-6 unused VT circuits.

Procedure: Clear the AIS-V Condition on the DS-1/DS3XM-6 Card

-
- Step 1** Check upstream nodes and equipment for alarms, especially LOS and out-of-service ports.
- Step 2** Correct the upstream alarms.
-

1.3.5 APSB

- Minor, Service affecting

Line terminating equipment detects protection switching byte failure in the incoming automatic protection switching (APS) signal if an inconsistent APS byte or invalid code is detected. Some older, non-Cisco SONET nodes send invalid APS codes if configured in a 1+1 protection scheme with newer SONET nodes, such as the ONS 15454. These invalid codes will raise an APSB on an ONS node.

Procedure: Clear the APSB Alarm on an OC-N Card

-
- Step 1** Examine the incoming SONET overhead with an optical test set to confirm inconsistent or invalid K bytes.
- Step 2** If corrupted K bytes are confirmed and the upstream equipment is functioning properly, the upstream equipment may not interoperate effectively with the ONS 15454. For ONS 15454 protection switching to operate properly, the upstream equipment may need to be replaced.
-

1.3.6 APSCDFLTK

- Minor, Non-service affecting

The Default K Byte Received alarm occurs when a BLSR is not properly configured, for example, when a four-node BLSR has one node configured as UPSR. A node in a UPSR or 1+1 configuration does not send the two valid K1/K2 APS bytes anticipated by a system configured for BLSR. One of the bytes sent is considered invalid by the BLSR configuration. The K1/K2 byte is monitored by receiving equipment for link-recovery information.

The alarm can also be caused when a new node is added but a new ring map has not been accepted. Troubleshooting for DFLTK is often similar to troubleshooting for BLSROSYNC.

Procedure: Clear the APSCDFLTK Alarm

-
- Step 1** Prior to accepting a new mapping table, verify that each node has a unique node ID number.
- Log into a node on the ring.
 - Click the **Provisioning > Ring** tabs.
 - Record the node ID number.
 - Repeat steps a – c for all nodes in the ring.

- e. If two nodes have the same node ID number, change one node's ID number so that each node has a unique node ID.
 - f. Click **Apply**.
- Step 2** Verify correct configuration of east port and west port optical fibers (see the "E-W-MISMATCH" section on page 1-30).
- Step 3** Click **Yes** to accept the Ring Map.
- Step 4** If the alarm does not clear, check the ring map for each ONS 15454 in the network and verify that each node is visible to the other nodes.
- a. At the node (default) view, click the **Provisioning > SONET DCC** tabs.
 - b. Click **Create**.
 - c. Select the OC-N card that links to the adjacent node.
 - d. Click **OK**.
- Step 5** If alarms are raised when the DCCs are turned on, follow the troubleshooting procedure in the "EOC" section on page 1-28.
- Step 6** If the alarm still does not clear, log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center to report a service-affecting problem (1-877-323-7368).

1.3.7 APSC-IMP

- Minor, Non-service affecting

An Improper SONET Automatic Protect Switch code alarm indicates invalid K bytes. This alarm occurs on OC-N cards in a BLSR configuration. The receiving equipment monitors K bytes or K1 and K2 APS bytes for an indication to switch from the working card to the protect card or vice versa. K1/K2 bytes also contain bits that tell the receiving equipment whether the K byte is valid. APSCIMP occurs when these bits indicate a bad or invalid K byte. The alarm clears when the node receives valid K bytes.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the APSC-IMP Alarm

- Step 1** To determine the validity of the K byte signal, examine the received signal. Use an optical test set capable of viewing SONET overhead.
- Step 2** If the K byte is invalid, the problem lies in upstream equipment and not in the reporting ONS 15454. Troubleshoot the appropriate upstream equipment.
- Step 3** If the K byte is valid, verify that each node has a ring ID that matches the other node ring IDs:
- a. Using CTC, log into a node on the ring.
 - b. Click the **Provisioning > Ring** tabs.
 - c. Record the ring ID number.

d. Repeat steps a – c for all nodes in the ring.

Step 4 If a node has a ring ID number that does not match the other nodes, change the ring ID number of that node to match the other nodes in the ring.

Step 5 Click **Apply**.

1.3.8 APSCINCON

- Minor, Service affecting

An inconsistent automatic protection switching (APS) code is present. The SONET overhead contains K1/K2 APS bytes that notify receiving equipment, such as the ONS 15454, to switch the SONET signal from a working to a protect path. An inconsistent APS code occurs when three consecutive frames do not contain identical APS bytes. Inconsistent APS bytes give the receiving equipment conflicting commands about switching.

Procedure: Clear the APSCINCON Alarm on an OC-N Card in a BLSR

Step 1 Look for other alarms, especially LOS, loss of frame (LOF) or AIS. Clearing these alarms clears the APSCINCON alarm.

Step 2 If an APSCINCON alarm occurs with no other alarms, log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center to report a service-affecting problem (1-877-323-7368).

1.3.9 APSCM

- Major, Service affecting

The APS Channel Mismatch alarm occurs when the ONS 15454 expects a working channel but receives a protection channel. In many cases, the working and protection channels are crossed and the protect channel is active. If the fibers are crossed and the working line is active, the alarm will not occur. This alarm occurs in a 1+1 configuration.

The APSCM alarm only occurs on the ONS 15454 when 1+1 bidirectional protection is used on OC-N cards in a 1+1 configuration.



Warning

Invisible laser radiation may be emitted from the aperture ports of the single-mode fiber optic modules when no cable is connected. Avoid exposure and do not stare into open apertures.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the APSCM Alarm on an OC-N Card in 1+1 Mode

-
- Step 1** Verify that the working-card channel fibers connect directly to the adjoining node's working-card channel fibers.
- Step 2** Verify that the protection-card channel fibers connect directly to the adjoining node's protection-card channel fibers.
-

1.3.10 APSCNMIS

- Major, Service affecting

The APSCNMIS alarm raises when the node ID contained in the K byte of the APS channel being received does not match the node ID expected by the receiving node in a BLSR. This alarm may occur and clear when a BLSR is being provisioned. If so the user can disregard the temporary occurrence. If an APSCNMIS raises and stays, the alarm clears when the receiving node receives or matches the expected K-byte.

Procedure: Clear the APSCNMIS Alarm

-
- Step 1** Verify that each node has a unique node ID number.
- Click the **Provisioning > Ring** tabs.
 - Click the BLSR row to highlight.
 - Click **Ring Map**.
 - If the Node ID column contains any two nodes with the same node ID listed, record the repeated node ID.
 - Click **Close** on the Ring Map dialog box.
- Step 2** If two nodes have the same node ID number, change one node's ID number so that each node has a unique node ID:
- Display the network view.
 - Log into one of the nodes that uses the repeated node ID recorded in Step 1.



Note If the node names shown on the network view do not correlate with the node IDs, log into each node and click the **Provisioning > Ring** tabs. This screen displays the node ID of the node you are logged into.

- Click the Node ID table cell to reveal a pull-down menu.
- Select a unique node ID from the pull-down menu and click **Apply**.



Note Locking out and clearing the lockout on a span causes the ONS 15454 to generate a new K byte. The APSCNMIS alarm clears when the node receives a K byte containing the correct node ID.

- Step 3** If the alarm does not clear, lockout a span on the ring and then clear the lockout:
- a. Click the **Ring > Maintenance** tabs.
 - b. Click the table cell under the West Switch heading to reveal the pull-down menu.
 - c. Select **LOCKOUT SPAN** and click **Apply**.
 - d. Click **OK** on the BLSR Operations dialog box.
 - e. Click the same table cell under the West Switch heading to reveal the pull-down menu.
 - f. Select **CLEAR** and click **Apply**.
 - g. Click **OK** on the BLSR Operations dialog box.
-

1.3.11 APSCONNL

- Major, Service affecting

An APS channel connection loss is occurring in the BLSR.

Procedure: Clear the APSCONNL Alarm on an OC-N Card in a BLSR

-
- Step 1** Verify that both TCC+ cards are powered.
- Step 2** Verify that one TCC+ card is active, and one TCC+ card is standby.
-  **Note** The ACT/STBY LED of the active card is green. The ACT/STBY LED of the standby card is amber.
-
- Step 3** Verify that both OC-N ports are powered and in-service.
- Step 4** Reset the active TCC+ card to make the standby TCC+ card active.
- a. In CTC, display the node view.
 - b. Position the cursor over the active TCC+ card slot.
 - c. Right-click and choose **RESET CARD**.
- Step 5** If the alarm clears, do a card pull on the formerly active, now standby TCC+, and reseal it and allow it to boot up completely.
- Step 6** Reset the currently active TCC+ card to make the current standby, originally active TCC+ card active.
- a. In CTC, display the node view.
 - b. Position the cursor over the active TCC+ card slot.
 - c. Right-click and choose **RESET CARD**.
- Step 7** If the alarm reappears after you perform the switch, replace the TCC+ card.



Note When replacing a card with an identical type of card, you do not need to change the CTC database.

1.3.12 APSMM

- Minor, Non-service affecting

An APS Mode Mismatch failure occurs when there is a mismatch of the protection switching schemes at the two ends of the span. If one node is provisioned for bidirectional switching, the node at the other end of the span must also be provisioned for bidirectional switching. If one end is provisioned for bidirectional and the other is provisioned for unidirectional, an APSMM alarm occurs in the ONS node that is provisioned for bidirectional. This alarm occurs in a 1+1 configuration.

Procedure: Clear the APSMM Alarm in 1+1 Mode

-
- Step 1** For the reporting ONS 15454, display the CTC node view and click the **Provisioning > Protection** tabs.
- Step 2** Choose the 1+1 protection group configured for the OC-N cards.
This is the protection group optically connected (with DCC connectivity) to the far end.
- Step 3** Record whether the bidirectional switching box is checked.
- Step 4** Log into the far end node and verify that the OC-N 1+1 protection group is provisioned.
This is the protection group optically connected (with DCC connectivity) to the near end.
- Step 5** Verify that the bidirectional switching box matches the checked or unchecked condition of the box recorded in Step 3. If not, change it to match.
- Step 6** Click **Apply**.
-

1.3.13 AUTOLSROFF

- Critical, Service affecting



Warning

On the OC-192 card, the laser is on when the card is booted and the safety key is in the on position (labeled 1). The port does not have to be in service for the laser to be on. The laser is off when the safety key is off (labeled 0).



Warning

Invisible laser radiation may be emitted from the end of the unterminated fiber cable or connector. Do not stare into the beam directly with optical instruments. Viewing the laser output with certain optical instruments (for example, eye loupes, magnifiers, and microscopes) within a distance of 100 mm may pose an eye hazard. Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.

The alarm raises when the OC-192 card temperature exceeds 90 degrees Centigrade. The internal equipment automatically shuts down the OC-192 laser when the card temperature rises to prevent the card from self-destructing.

Procedure: Clear the AUTOLSROFF Alarm

-
- Step 1** Read the temperature displayed on the ONS 15454 LCD front panel.
- Step 2** If the temperature of the ONS 15454 exceeds 90 degrees Centigrade, complete the “Clear the HITEMP Alarm” procedure on page 1-43.
- Step 3** If the temperature of the ONS 15454 is below 90 degrees Centigrade, replace the OC-192 card.
-  **Note** When replacing a card with an identical type of card, you do not need to change the CTC database.
-
- Step 4** Call the Technical Assistance Center (TAC) at 1-877-323-7368 to discuss the case and if necessary open a returned materials authorization (RMA) on the original OC-192 card.
-

1.3.14 AUTORESET

- Minor, Non-service affecting

The card is performing a warm reboot automatically. An AUTORESET occurs when you change an IP address or perform any other operation that causes an automatic card-level reboot.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the AUTORESET Alarm

-
- Step 1** Check for additional alarms that may have triggered an automatic reset.
- Step 2** If the card automatically resets more than once a week with no apparent cause, replace it with a new card.
-  **Note** When you replace a card with an identical type of card, you do not need to make any changes to the database.
-

1.3.15 AUTOSW-AIS

- Not Alarmed (Condition)

AUTOSW-AIS indicates that automatic UPSR protection switching took place because of an AIS alarm. The UPSR is configured for revertive switching and will switch back to the working path after the fault clears. Troubleshoot with the “AIS” section on page 1-4.

1.3.16 AUTOSW-LOP

- Minor, Non-service affecting

AUTOSW-LOP indicates that automatic UPSR protection switching took place because of an LOP alarm. The UPSR is configured for revertive switching and will switch back to the working path after the fault clears. Troubleshoot with the “LOP-P” section on page 1-50.

1.3.17 AUTOSW-PDI

- Minor, Non-service affecting

AUTOSW-PDI indicates that automatic UPSR protection switching took place because of a PDI alarm. The UPSR is configured for revertive switching and will switch back to the working path after the fault clears. Troubleshoot with the “PDI-P” section on page 1-63.

1.3.18 AUTOSW-SDBER

- Not Alarmed (NA) (Condition)

AUTOSW-SD indicates that automatic UPSR protection switching took place because of an SD alarm. The UPSR is configured for revertive switching and has switched back to the working path. Troubleshoot with the “PWRRESTART” section on page 1-66.

1.3.19 AUTOSW-SFBER

- Not Alarmed (NA) (Condition)

AUTOSW-SF indicates that automatic UPSR protection switching took place because of a SF alarm. The UPSR is configured for revertive switching and will switch back to the working path. Troubleshoot with the “SF-L” section on page 1-71.

1.3.20 AUTOSW-UNEQ

- Minor, Service affecting

AUTOSW-UNEQ indicates that automatic UPSR protection switching took place because of an UNEQ alarm. The UPSR is configured for revertive switching and will switch back to the working path after the fault clears. Troubleshoot with the “UNEQ-P” section on page 1-80.

1.3.21 BKUPMEMP

- Critical, Non-service affecting

The BKUPMEMP alarm refers to a problem with the TCC+ card's flash memory. The alarm occurs when the TCC+ card is in use and has one of four problems: the flash manager fails to format a flash partition, the flash manager fails to write a file to a flash partition, there is a problem at the driver level or the code volume fails cyclic redundancy checking (CRC). CRC is a method to check for errors in data transmitted to the TCC+.

The BKUPMEMP alarm will also raise the EQPT alarm. In this instance, use the following procedure will clear the BKUPMEMP and the EQPT alarm.

Procedure: Clear the BKUPMEMP Alarm

-
- Step 1** Verify that both TCC+ cards are powered and enabled by confirming lighted ACT/STBY LEDs on the TCC+ cards.
- Step 2** Reset the active TCC+ card to make the standby TCC+ card active:
- In CTC, display the node view.
 - Position the cursor over the active TCC+ card slot.
 - Right click and choose **RESET CARD**.
- Step 3** If the alarm clears, reseal the old TCC+ and allow it to boot up completely.
- Step 4** Do a second reset, this time on the newly-active TCC+ card to make the recently-reseated standby TCC+ card active.
- In CTC, display the node view.
 - Position the cursor over the active TCC+ card slot.
 - Right click and choose **RESET CARD**.
- Step 5** If the alarm reappears after you perform the switch, replace the TCC+ card.
- Open the card ejectors.
 - Slide the card out of the slot.
 - Open the ejectors on the replacement card.
 - Slide the replacement card into the slot along the guide rails.
 - Close the ejectors.



Note When replacing a card with an identical type of card, you do not need to change the CTC database.

1.3.22 BLSROSYNC

- Major, Service affecting

The BLSR Out Of Sync alarm occurs when the mapping table needs updating. To clear the alarm, a new ring map must be created and accepted. Before you create a new ring map, complete Steps 1 – 4.

Procedure: Clear the BLSROSYNC Alarm

-
- Step 1** Prior to accepting a new mapping table, verify that each node has a unique node ID number:
- Log into a node on the ring.
 - Click the **Provisioning > Ring** tabs.
 - Record the Node ID number.
 - Repeat steps a – c for all nodes in the ring.
 - If two nodes have the same node ID number, change one node’s ring ID number.
 - Click **Apply**.
- Step 2** Verify that each node has a ring ID that matches the other node ring IDs:
- Log into the next node on the ring.
 - Click the **Provisioning > Ring** tabs.
 - Record the Ring ID number.
 - Repeat steps a – b for all nodes in the ring.
 - If a node has a ring ID number that does not match the other nodes, change one node’s ID.
 - Click **Apply**.
- Step 3** Verify correct configuration of the east port and west port optical fibers (see the “E-W-MISMATCH” section on page 1-30.)
- Step 4** If the east-to-west configuration changes, click **Apply**.
The BLSR Ring Map Change screen appears.
- Step 5** Click **Yes** to accept the Ring Map.
- Step 6** If the alarm does not clear, check the ring map for each ONS 15454 in the network and verify that each node is visible to the other nodes.
- Step 7** If nodes are not visible, ensure that SDCC terminations exist on each node.
- Click the **Provisioning > SONET DCC** tabs.
 - Click **Create**.
 - Click the OC-N card that links to the adjacent node.
 - Click **OK**.
- Step 8** If alarms are raised when the DCCs are turned on, follow the troubleshooting procedure in the “EOC” section on page 1-28.
- Step 9** If the alarm still does not clear, log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center to report a service-affecting problem (1-877-323-7368).
-

1.3.23 CARLOSS

- Major, Service affecting

A carrier loss on the LAN is the data equivalent of an optical LOS. The Ethernet card has lost its link and is not receiving any signal, even an invalid one. The most common causes of this alarm are a disconnected cable or an improperly installed Ethernet card.

CARLOSS also occurs after the restoration of a node's database. In this instance, the alarm will clear in approximately 30 seconds after spanning tree protection reestablishes.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the CARLOSS Alarm

-
- Step 1** Verify that the cable is properly connected and attached to the correct port.
- Step 2** Check that the transmitting device is operational. If not, troubleshoot the device.
- Step 3** Using a test set, determine that a valid signal is coming into the Ethernet port.
- Step 4** If a valid Ethernet signal is not present and the transmitting device is operational, check that the Ethernet wiring is intact and correct.
- Step 5** If a valid Ethernet signal is present, physically reseal the Ethernet card.
- Step 6** If the alarm does not clear, replace the Ethernet card.
- a. Open the card ejectors.
 - b. Slide the card out of the slot.
 - c. Open the ejectors on the replacement card.
 - d. Slide the replacement card into the slot along the guide rails.
 - e. Close the ejectors.



Note

When replacing a card with an identical type of card, you do not need to change the CTC database.

1.3.24 CONCAT

- Critical, Service affecting

The STS Concatenation error alarm occurs when the transmitted STSc circuit is smaller than the provisioned STSc, which causes a mismatch of the circuit type on the concatenation facility. For example, an STS3c or STS1 is sent across a circuit provisioned for STS12c.

Either an incorrect circuit size was provisioned on the reporting node, or the circuit source is delivering the wrong circuit size. If a recently-configured circuit reports this alarm, it is more likely that the provisioned circuit size is incorrect. If a previously configured circuit has been operating correctly for a period and then reports the alarm, it is more likely that a problem occurred with the circuit source.

Procedure: Clear the CONCAT Alarm

-
- Step 1** Check that the provisioned circuit size is correct:
- Click the **Circuits** tab.
 - Find the appropriate row using the Circuit Name and record the size listed in the size column.
 - Determine whether the size listed matches the original network design plan.
- Step 2** If the circuit size listed does not match the original network design plan, delete the circuit:
- Click the circuit row to highlight it and click **Delete**.
 - Click **Yes** at the Delete Circuits dialog box.
 - Recreate the circuit with the correct circuit size.
- Step 3** Check that the size of the circuit source matches the correct circuit size:
- Measuring the source signal with a test set to determine if the circuit size matches the provisioned circuit.
 - If the source circuit signal is a test set, check that the test set settings match the intended circuit size.
-

1.3.25 CONNLOS

- Major, Service affecting

An APS channel connection loss is occurring in the BLSR.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the CONNLOS Alarm

-
- Step 1** Verify that both TCC+ cards are powered and enabled by confirming a lighted green ACT/STBY LED on the TCC+ card.
- Step 2** Verify that both OC-N cards are powered and enabled by confirming a lighted green ACT/STBY LED on the OC-N card.
- Step 3** Reset the active TCC+ card to make the standby TCC+ card active.
- In CTC, display the node view.
 - Position the cursor over the active TCC+ card slot.
 - Right click and choose **RESET CARD**.
- Step 4** If the alarm clears, reseal the old active TCC+ and allow it to boot up completely.
- Step 5** Do a second reset, this time on the newly-active TCC+ card to make the recently- reseated standby TCC+ card active.
- In CTC, display the node view.

- b. Position the cursor over the active TCC+ card slot.
- c. Right click and choose **RESET CARD**.

Step 6 If the alarm reappears after you perform the switch, replace the TCC+ card.

- a. Open the card ejectors.
- b. Slide the card out of the slot.
- c. Open the ejectors on the replacement card.
- d. Slide the replacement card into the slot along the guide rails.
- e. Close the ejectors.



Note When replacing a card with an identical type of card, you do not need to change the CTC database.

1.3.26 CONTBUS-A-X

- Major, Non-service affecting

The TCC+ card in Slot 7 has lost communication with the card in Slot X. Cards require frequent communication with the TCC+ card because the TCC+ performs system initialization, provisioning, alarm reporting, maintenance, diagnostics, IP address detection/resolution, SONET Data Communications Channel (SDCC) termination, system fault detection, and other operations for the ONS 15454. The TCC+ card also ensures that the system maintains Telcordia timing requirements.

The CONTBUS-A-X alarm can appear briefly when the ONS 15454 switches to the standby TCC+ card. In this instance, the alarm clears after the cards establish communication with the new primary TCC+ card. In cases where the alarm persists, the problem lies in the physical path of communication from the TCC+ to the reporting card. The physical path of communication includes the TCC+ card, the card in Slot X and the backplane.



Note

If X equals 18, see the “CONTBUS-A-18” section on page 1-19.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the CONTBUS-A-X Alarm for Slots 1 Through 17

Step 1 Ensure the Slot X card is physically present. Record the card type.

Step 2 Click the **Inventory** tab to reveal the provisioned type.

If the actual card type and the provisioned card type do not match, complete the “Clear the MEA Alarm on a Cross-Connect or Line Card” procedure on page 1-59.

- Step 3** If slot x is the only slot reporting the alarm, perform a software reset of the traffic card:
- a. Display the CTC node view.
 - b. Position the cursor over the slot reporting the alarm (slot X).
 - c. Right-click and choose **RESET CARD**.
- Step 4** If the software reset does not clear the alarm, physically reseal the reporting card.
- Step 5** If all traffic cards report this alarm, perform a software reset of the active TCC+ card.
- a. Display the node view.
 - b. Position the cursor over the active TCC+ card slot.
 - c. Right-click and choose **RESET CARD**.
- Step 6** If the software reset does not clear the alarm, physically reseal the TCC+ card.
- Step 7** If the alarm still does not clear, replace the TCC+ card.



Note When you replace a card with an identical type of card, you do not need to make any changes to the database.

1.3.27 CONTBUS-A-18

- Major, Non-service affecting

The main processor on the TCC+ card in Slot 7 has lost communication with the coprocessor on the second TCC+ card in Slot 11. The problem is with the physical path of communication from the TCC+ card to the reporting card. The physical path of communication includes the two TCC+ cards and the backplane.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the CONTBUS-A-18 Alarm

- Step 1** Position the cursor over the TCC+ card in Slot 7.
- Step 2** Right-click the mouse to reveal a menu.
- Step 3** To clear the alarm, choose **RESET CARD** to make the standby TCC+ in Slot 11 the active TCC+ and clear the alarm.
- Step 4** Wait approximately 2 minutes for the TCC+ in Slot 7 to reset as the standby TCC+.
- Step 5** Position the cursor over the TCC+ card in Slot 11.
- Step 6** Right-click the mouse to reveal a menu.
- Step 7** Choose **RESET CARD** to make the standby TCC+ in Slot 7 the active TCC+.

- Step 8** If the alarm reappears when the TCC+ in Slot 7 reboots as the active TCC+, the TCC+ card in Slot 7 is defective and must be replaced.



Note When you replace a card with an identical type of card, you do not need to make any changes to the database.

1.3.28 CONTBUS-B-X

- Major, Non-service affecting

The TCC+ card in Slot 11 lost communication with the card in Slot X. Cards require frequent communication with the TCC+ card, because the TCC+ card performs system initialization, provisioning, alarm reporting, maintenance, diagnostics, IP address detection/resolution, SONET DCC termination, and system fault detection among other operations for the ONS 15454. The TCC+ card also ensures that the system maintains Telcordia timing requirements.

This alarm may appear briefly when the ONS 15454 switches over to the protect TCC+ card. In this instance, the alarm clears after the other cards establish communication with the new primary TCC+ card. In cases where the alarm persists, the problem lies in the physical path of communication from the TCC+ card to the reporting card. The physical path of communication includes the TCC+ card, the card in Slot X, and the backplane.



Note If X equals 18, then see CONTBUS-B-18 listed below.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the CONTBUS-B-X Alarm for Slots 1 Through 17

- Step 1** Ensure the Slot X card is physically present and that it matches the type of card identified in that slot on CTC.
- Step 2** If this slot is the only one reporting the alarm, perform a software reset of the traffic card:
- Display the CTC node view.
 - Position the cursor over the slot reporting the alarm (Slot X).
 - Right-click the mouse and choose **RESET CARD** to do a software reset.
- Step 3** If the software reset does not clear the alarm, physically reseal the reporting card.
- Step 4** If all cards with the exception of the active TCC+ report this alarm, perform a software reset of the active TCC+:
- Display the CTC node view.
 - Position the cursor over the active TCC+ card slot.
 - Choose **RESET CARD**.

- Step 5** If the software reset does not clear the card, physically reseal the TCC+ card to perform a card pull.
- Step 6** If the alarm still does not clear, replace the TCC+ card.



Note When you replace a card with an identical type of card, you do not need to make any changes to the database.

1.3.29 CONTBUS-B-18

- Major, Non-service affecting

The main processor on the TCC+ card in Slot 11 lost communication with the coprocessor on the TCC+ card in Slot 7. The problem is with the physical path of communication from the TCC+ card to the reporting TCC+ card. The physical path of communication includes the two TCC+ cards and the backplane.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the CONTBUS-B-18 Alarm on the TCC+ Card

- Step 1** Position the cursor over the TCC+ card in Slot 11.
- Step 2** Right-click and choose **RESET CARD** to make the TCC+ in Slot 11 the active TCC+ card.
- Step 3** Wait approximately 2 minutes for the TCC+ in Slot 7 to reset as the standby TCC+ card.
- Step 4** Position the cursor over the TCC+ card in Slot 7.
- Step 5** Right-click and choose **RESET CARD** again to make the TCC+ in Slot 11 the active TCC+ card.
- Step 6** If the alarm reappears when the TCC+ in Slot 11 reboots as the active TCC+, the TCC+ card in Slot 11 is defective and must be replaced.



Note When you replace a card with an identical type of card, you do not need to make any changes to the database.

1.3.30 CTNEQPT-PB1PROT

- Critical, Service affecting

An Interconnection Equipment Failure - Standby Payload Bus alarm occurs when digital traffic is being lost between the cross-connect (XC/XCVT/XC10G) card and the reporting traffic card.

**Caution**

All traffic on the reporting card is lost after this alarm is reported.

**Caution**

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the CTNEQPT-PB1PROT Alarm

-
- Step 1** Ensure that the reporting traffic card is physically present. Record the card type.
- Step 2** Click the **Inventory** tab to reveal the provisioned type.
- If the actual card type and the provisioned card type do not match, complete the “Clear the MEA Alarm on a Cross-Connect or Line Card” procedure on page 1-59.
- Step 3** Perform a software reset of the reporting traffic card:
- a. Display the CTC node view.
 - b. Position the cursor over the slot reporting the alarm.
 - c. Right-click and choose **RESET CARD**.
- Step 4** If the software reset does not clear the alarm, physically reseal the reporting traffic card.
- Step 5** If physically resealing the reporting traffic card does not clear the alarm, replace the reporting traffic card.

**Note**

When you replace a card with an identical type of card, you do not need to make any changes to the database.

- Step 6** If troubleshooting the reporting traffic card did not clear the alarm, perform a switch of the cross-connect card:
- a. Determine the active cross-connect card. The ACT/STBY LED of the active card is green. The ACT/STBY LED of the standby card is amber.

**Note**

You can also place the cursor over the card graphic to display a popup identifying the card as active or standby.

- b. In the node view, select the **Maintenance > XC Cards** tabs.
- c. From the Cross Connect Cards menu, choose **Switch**.
- d. Click **Yes** on the Confirm Switch dialog box.

**Note**

After the active cross-connect goes into standby, the original standby slot becomes active. This causes the ACT/STBY LED to become green on the former standby card.

- Step 7** If the alarm does not clear after the cross-connect side switch, the problem may be located in the backplane. Call the Technical Assistance Center (TAC) at 1-877-323-7368 to discuss the case and possibly open a returned materials authorization (RMA).

1.3.31 CTNEQPT-PB1WORK

- Critical, Service affecting

An Interconnection Equipment Failure - Active Payload Bus alarm occurs when digital traffic is being lost between the cross-connect (XC/XCVT/XC10G) card and the reporting traffic card. The problem lies in the XCVT card, the backplane or both the XCVT card and the backplane.



Caution

All traffic on the reporting card may be lost after this alarm is reported.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the CTNEQPT-PB1WORK Alarm

- Step 1** Ensure that the reporting traffic card is physically present. Record the card type.
- Step 2** Click the **Inventory** tab to reveal the provisioned type.
- If the actual card type and the provisioned card type do not match, complete the “Clear the MEA Alarm on a Cross-Connect or Line Card” procedure on page 1-59.
- Step 3** Perform a software reset of the traffic card:
- Display the CTC node view.
 - Position the cursor over the slot reporting the alarm.
 - Right-click and choose **RESET CARD**.
- Step 4** If the software reset does not clear the alarm, physically reseal the reporting traffic card.
- Step 5** If physically reseating the reporting traffic card does not clear the alarm, replace the card.
-  **Note** When you replace a card with an identical type of card, you do not need to make any changes to the database.
- Step 6** If troubleshooting the reporting traffic card did not clear the alarm, perform a side switch of the cross-connect card.
- Determine the active cross-connect card. The ACT/STBY LED of the active card is green. The ACT/STBY LED of the standby card is amber.



Note You can also place the cursor over the card graphic to display a popup identifying the card as active or standby.

- b. In the node view, select the **Maintenance > XC Cards** tabs.
- c. From the Cross Connect Cards menu, choose **Switch**.
- d. Click **Yes** on the Confirm Switch dialog box.



Note After the active cross-connect goes into standby, the original standby slot becomes active. This causes the ACT/STBY LED to become green on the former standby card.

Step 7 If the alarm does not clear after the cross-connect side switch, the problem may lie in the backplane. Call the Technical Assistance Center (TAC) at 1-877-323-7368 to discuss the case and possibly open a returned materials authorization (RMA).

1.3.32 CTNEQPT-PBXPROT

- Critical, Service affecting

This alarm indicates a failure of the main payload between the protect cross-connect (XC/XCVT/XC10G) card in Slot 10 and the reporting traffic card in Slot X. The cross-connect card and the reporting card are no longer communicating through the backplane. The problem exists in either the cross-connect card, the reporting traffic card, or the backplane.



Note X is equal to the number of the card slot for numbers 1 – 6. If X is 7 or greater, add 5 to X to determine the actual card slot. For example, CTNEQPT-PB7PROT signifies Slot 12, not Slot 7.



Note If all traffic cards show this alarm, physically reseal the standby TCC+ card. If this fails to clear the alarm, replace the standby TCC+ card. Do not physically reseal an active TCC+ card. This disrupts traffic.



Caution Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the CTNEQPT-PBXPROT Alarm

- Step 1** Perform a software reset on the standby cross-connect (XC/XCVT/XC10G) card:
- a. Display the node view.
 - b. Position the cursor over the slot reporting the alarm.
 - c. Right-click and choose **RESET CARD**.

- Step 2** If the alarm persists, physically reseal the standby cross-connect card.
- Step 3** If the alarm persists and the reporting traffic card is the active card in the protection group, do a force switch to move traffic away from the card:
- At the node view, click the **Maintenance > Protection** tabs.
 - Double-click the protection group that contains the reporting card.
 - Click the Protect/Standby card of the selected groups.
 - Click **Force** and **OK**.
- Step 4** Perform a software reset on the reporting card:
- Display the CTC node view.
 - Position the cursor over the slot reporting the alarm.
 - Right-click to choose **RESET CARD**.
- Step 5** If the alarm persists, physically reseal the reporting card.
- Step 6** Clear the force switch:
- At the node view, click the **Maintenance > Protection** tabs.
 - Double-click the protection group that contains the reporting card.
 - Highlight either selected group.
 - Click **Clear** and click **YES** at the confirmation dialog box.
- Step 7** If the reporting traffic card is protect, perform a software reset on the reporting card:
- Display the CTC node view.
 - Position the cursor over the slot reporting the alarm.
 - Right-click and choose **RESET CARD**.
- Step 8** If the alarm persists, physically reseal the reporting card.
- Step 9** If the alarm persists, replace the standby cross-connect card.
-  **Note** When you replace a card with an identical type of card, you do not need to make any changes to the database.
- Step 10** If the alarm persists, replace the reporting traffic card.

1.3.33 CTNEQPT-PBXWORK

- Critical, Service affecting

The main payload bus between the active cross-connect (XC/XCVT/XC10G) card in Slot 8 and the reporting traffic card in Slot *X* failed. The cross-connect card and the reporting card are no longer communicating through the backplane. The problem exists in the cross-connect card, the reporting traffic card, or the backplane.



Note

X is equal to the number of the card slot for numbers 1–6. If *X* is 7 or greater, add 5 to *X* to determine the actual card slot. For example, CTNEQPT-PB7WORK signifies Slot 12, not Slot 7.

**Note**

If all traffic cards show this alarm, do a forced side switch on the active TCC+ card, as shown in Step 1, and physically reseal this TCC+ card. If this fails to clear the alarm, replace the TCC+ card. Do not physically reseal an active TCC+ card; this disrupts traffic.

**Caution**

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the CTNEQPT-PBXWORK Alarm

Step 1 Do a side switch from the active cross-connect (XC/XCVT/XC10G) card to the protect cross-connect card:

- a. Determine the active cross-connect card. The ACT/STBY LED of the active card is green. The ACT/STBY LED of the standby card is yellow.

**Note**

You can also place the cursor over the card graphic to display a popup identifying the card as active or standby.

- b. In the node view, select the **Maintenance > XC Cards** tabs.
- c. Click **Switch**.
- d. Click **Yes** on the Confirm Switch dialog box.

**Note**

After the active cross-connect goes into standby, the original standby slot becomes active. This causes the ACT/STBY LED to become green on the former standby card.

Step 2 Perform a software reset on the reporting card:

- a. From the node view, position the cursor over the slot reporting the alarm.
- b. Right-click to choose **RESET CARD**.

Step 3 If the alarm persists, perform a card pull on the standby cross-connect card.

Step 4 If the alarm persists and the reporting traffic card is the active card in the protection group, do a force switch to move traffic away from the card:

- a. At the node view, click the **Maintenance > Protection** tabs.
- b. Double-click the protection group that contains the reporting card.
- c. Click the Protect/Standby card of the selected groups.
- d. Click **Force** and **OK**.

Step 5 Perform a software reset on the reporting card:

- a. Display the CTC node view.
- b. Position the cursor over the slot reporting the alarm.
- c. Right-click to choose **RESET CARD**.

- Step 6** If the alarm persists, physically reseat the reporting card.
- Step 7** Clear the force switch:
- At the node view, click the **Maintenance > Protection** tabs.
 - Double-click the protection group that contains the reporting card.
 - Highlight either selected group.
- Step 8** Click **Clear** and click **YES** at the confirmation dialog box.
- Step 9** If the reporting traffic card is protect, perform a software reset on the reporting card:
- Display the CTC node view.
 - Position the cursor over the slot reporting the alarm.
 - Right-click to choose **RESET CARD**.
- Step 10** If the alarm persists, physically reseat the reporting card.
- Step 11** If the alarm persists, replace the cross-connect card. First, ensure the card has been side switched from active to standby (Step 1):
-  **Note** When you replace a card with an identical type of card, you do not need to make any changes to the database.
- Step 12** If the alarm persists, replace the reporting traffic card.

1.3.34 DATAFLT

- Minor, Non-service affecting

The database exceeded the capacity of the flash memory on the TCC+.



Caution

When the system reboots, the last configuration entered is not saved.

Log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center to report a service-affecting problem (1-877-323-7368).

1.3.35 DISCONNECTED

- Minor, Non-service affecting

The ONS 15454 and the CTC do not have a TCP/IP connection. The problem is in the connection (usually a LAN problem) and not the CTC or the ONS 15454.

Procedure: Clear the DISCONNECTED Alarm

- Step 1** Verify connectivity by pinging the ONS 15454 that is reporting the alarm:
- If you are using a Microsoft Windows operating system, from the Start Menu choose **Programs > Command Prompt**.
 - If you are using a Sun Solaris operating system, from the Common Desktop Environment (CDE) click the **Personal Application** tab and click **Terminal**.
 - For both the Sun and Microsoft operating systems, at the prompt type:

```
ping [ONS 15454 IP address]
For example, ping 192.1.0.2.
```

If the workstation has connectivity to the ONS 15454, it displays a “reply from [IP Address]” after the ping. If the workstation does not have connectivity, a “Request timed out” message displays.

- Step 2** If the ping is successful, an active TCP/IP connection exists. Restart the CTC.
- Step 3** If you are unable to establish connectivity, perform standard network/LAN diagnostics. For example, trace the IP route, check cables, and check any routers between the node and CTC.

1.3.36 EOC

- Major, Non-service affecting

The ONS 15454 has lost its data communications channel (DCC). The DCC is three bytes, D1 through D3, in the SONET overhead. The bytes convey information about Operation, Administration, Maintenance, and Provisioning (OAM&P.) The ONS 15454 uses the DCC on the SONET section layer (SDCC) to communicate network management information.



Warning

Invisible laser radiation may be emitted from the aperture ports of the single-mode fiber optic modules when no cable is connected. Avoid exposure and do not stare into open apertures.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the EOC Alarm on an OC-N Card

- Step 1** If an LOS alarm is also reported, first resolve the LOS alarm by following the troubleshooting procedure given for that alarm.
- Step 2** On the node reporting the alarm, check the physical connections from the cards to the fiber-optic cables that are configured to carry DCC traffic.
- Step 3** Verify that both ends of the fiber span have in-service ports by checking that the ACT LED on each OC-N card is illuminated.

- Step 4** Verify that the DCC is provisioned for the ports at both ends of the fiber span.
- Under the node view, click the **Provisioning > SONET DCC** tabs.
 - If the slot and port are listed under **SDCC Terminations**, the DCC is provisioned.
 - If the slot and port are not listed under the SDCC Terminations, click **Create**.
 - Click the OC-N card that links to the adjacent node.
 - Click **OK**.
 - Repeat steps (a) – (e) at the adjacent nodes.
- Step 5** Verify that the OC-N port is active and in-service:
- Confirm that the OC-N card shows a green LED by viewing the CTC or viewing the physical card.
A green LED indicates an Active card. A yellow LED indicates a Standby card.
 - To determine whether the OC-N port is in In Service, double-click the card in the CTC to display the card-level view.
 - Click the **Provisioning > Line** tabs.
 - Verify that the Status column lists the port as In Service.
 - If the Status column lists the port as Out of Service, click the column and select **In Service**. Click **Apply**.
- Step 6** With a test set, check for signal failures on fiber terminations.
- 
Caution Using a test set will disrupt service on the OC-N card. It may be necessary to manually switch traffic carrying circuits over to a protection path.
- Step 7** Measure power levels to verify that the budget loss is within the parameters of the receiver. See the “Optical Card Transmit and Receive Levels” section on page 2-35.
- Step 8** Ensure that fiber connectors are securely fastened and properly terminated.
- Step 9** Reset the active TCC+ using the “Card Replacement” section on page 3-14.
Resetting the active TCC+ switches the traffic to the standby TCC+. If the alarm clears when the ONS 15454 switches to the standby TCC+, the user can assume that the original active TCC+ is the cause of the alarm.
- Step 10** Replace the original active TCC+ with a new TCC+ card.
- 
Caution Resetting the active TCC+ results in loss of traffic.
- Step 11** Delete and recreate the problematic SDCC termination:
- Click the **Provisioning > SONET DCC** tabs.
 - Highlight the problematic SDCC termination.
 - Click **Delete**.
 - Click **Yes** at confirmation dialog box.
- Step 12** Verify that both ends of the SDCC have been recreated at the optical ports.

- Step 13** Log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center to report a service-affecting problem (1-877-323-7368).
-

1.3.37 EQPT

- Critical, Service affecting

An equipment failure (EQPT) alarm indicates that a hardware failure has occurred on the reporting card.

If the EQPT alarm occurs with a BKUPMEMP alarm, follow the procedure “Clear the BKUPMEMP Alarm” section on page 1-14. This procedure will also clear the EQPT alarm.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the EQPT Alarm

- Step 1** Perform a software reset on the reporting card.
- Display the CTC node view.
 - Position the CTC cursor over the slot reporting the alarm.
 - Right click **RESET CARD**.
- Step 2** If the software reset fails to clear the alarm, physically reseal the card.
- Step 3** If the physical reseal of the card fails to clear the alarm, replace the card.



Note

When replacing a card with an identical type of card, you do not need to change the CTC database.

1.3.38 E-W-MISMATCH

- Major, Service affecting

A Procedural Error Misconnect East/West Direction alarm occurs when nodes in a ring have an east slot/port misconnected to another east slot/port or a west slot/port misconnected to another west slot/port. In most cases, the user did not hook up the fibers correctly, did not create the circuit as specified in the ring provisioning plan, or the ring provisioning plan was flawed. You can physically reconnect the cable to the correct slot/ports to clear the E-W-MISMATCH alarm. Alternately, you can delete and recreate the span in CTC to change the west line and east line designations. The CTC method will clear the alarm, but may change the traditional east-west node connection pattern of the ring.

**Note**

The E-W-MISMATCH alarm also appears during the initial set up of a ring with its East-West slot/ports configured correctly. In this instance, the alarm clears itself shortly after the ring setup is complete.

**Note**

The lower numbered slot on a node is traditionally labelled as the west slot and the higher numbered slot is labelled as the east slot. For example, Slot 6 is west and Slot 12 is east.

Procedure: Clear the E-W-MISMATCH Alarm with a Physical Switch

- Step 1** Diagram the ring setup, including nodes and spans, on a piece of paper or white board.
- Step 2** Display the CTC network view and label each of the nodes on the diagram with the same name that appears on the screen's network map.
- Step 3** Double-click each span to reveal the node name/slot/port for each end of the span.
- Step 4** Label the span ends on the diagram with the same information. For example, with Node1/Slot12/Port1 - Node2/Slot6/Port1 (2F BLSR OC48, Ring ID=0), label the end of the span that connects Node 1 and Node 2 at the Node 1 end as *Slot 12/Port 1*. Label the Node 2 end of that same span *Slot 6/Port 1*.
- Step 5** Repeat Steps 3 and 4 for each span on your diagram.
- Step 6** Label the highest slot at each node *east* and the lowest slot at each node *west*.
- Step 7** Look at the diagram. You should see a clockwise pattern of west slots connecting to east slots for each span.
- Step 8** If any span has an east-to-west or west-to-west connection, physically switch the fiber connectors from the card that does not fit the pattern to the card that will continue the pattern. This should clear the alarm.

**Note**

The physical fiber connector switch is the recommend method of clearing this alarm. This method reestablishes the logical pattern of connection in the ring. However, you can also use CTC to recreate the span and identify the misconnected slot/ports as east and west. This is useful when the misconnected node is not geographically near the troubleshooter.

Procedure: Clear the E-W-MISMATCH Alarm with the CTC

- Step 1** Log into the misconnected node. This is the node with both ring fibers misconnected; it is in the middle of the two nodes that have one of two ring fibers misconnected.
- Step 2** Click the **Provisioning > Ring** tabs.
- Step 3** From the row of information for the fiber span, write down the Node ID, Ring ID, and the Slot and Port in the east line list and west line list.
- Step 4** Click the row from Step 3 to select it and click **Delete**.
- Step 5** Click **Create**.
- Step 6** Fill in the Ring ID and Node ID from the information collected in Step 3.

- Step 7** Change the West line pull-down menu to the slot/port you recorded for the East line in Step 3.
 - Step 8** Change the East line pull-down menu to the slot/port you recorded for the West line in Step 3.
 - Step 9** Click **OK**.
 - Step 10** Click **Yes** at the Ring Map Change dialog box.
 - Step 11** Click **Accept** at the new Ring Map.
-

1.3.39 EXCCOL

- Minor, Non-service affecting

The Excess Collisions on the LAN alarm indicates that too many collisions are occurring on the network management LAN. The network management LAN is the data network connecting the workstation running the CTC software to the TCC+ card. This problem is external to the ONS 15454.

Procedure: Clear the EXCCOL Alarm

Troubleshoot the network management LAN connected to the TCC+ card for excess collisions. You may need to contact the system administrator of the network management LAN to accomplish the following steps:

- Step 1** Verify that the network device port connected to the TCC+ card has a flow rate set to 10 Mb, half-duplex.
 - Step 2** Troubleshoot the network device connected to the TCC+ card and the network management LAN.
-

1.3.40 EXERCISE-SPAN-FAIL

- Not Alarmed (NA) (Condition)

The Exercise Span command issues span switching of the requested channel without completing the actual bridge and switch. The EXERCISE-SPAN-FAILED alarm is raised if the command was issued but the exercise did not take place.

1.3.41 EXERCISE-RING-FAIL

- Not Alarmed (NA) (Condition)

The Exercise-Ring command issues ring protection switching of the requested channel without completing the actual bridge and switch. The EXERCISE-RING-FAILED alarm is raised if the command was issued but the exercise did not take place.

1.3.42 EXT

- Major, Service affecting

An external facility alarm is detected external to the node because an environmental alarm is present, for example, a door is open or flooding has occurred.

Procedure: Clear the EXT Alarm

-
- Step 1** Open the AIC card maintenance screen to gather further information about this alarm.
- Step 2** Perform your standard operating procedure for this environmental condition.
-

1.3.43 FAILTOSW

- Major, Service affecting

The FAILTOSW alarm is raised when a working DS-N card cannot switch to the protect card in a 1:N protection group, because another working DS-N card, with a higher-priority alarm, is switched over and monopolizing the lone protect card.

Procedure: Clear the FAILTOSW Alarm

-
- Step 1** Lookup and troubleshoot the higher-priority alarm. Clearing this alarm will free up the 1:N card and clear the FAILTOSW.



Note A higher-priority alarm is an alarm raised on the working DS-N card using the 1:N card protection group. This working DS-N card is reporting an alarm, but not reporting a FAILTOSW alarm.

- Step 2** Replace the working DS-N card that is reporting the higher-priority alarm. This card is the working DS-N card using the DS:N card protection and not reporting FAILTOSW.

Replacing the working DS-N card reporting the higher-priority alarm, will allow traffic to revert back to this slot. This frees up the 1:N card, which can then take over traffic from the card reporting the lower-priority alarm and the FAILTOSW alarm.



Note When you replace a card with an identical type of card, you do not need to make any changes to the database.

1.3.44 FAILTOSW-PATH

- Major, Service affecting

The working path did not switch to the protection path on a UPSR. Common causes of this alarm include a missing or defective protection card or a lockout set on one of the UPSR nodes.

**Caution**

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the FAILTOSW-PATH Alarm on a UPSR Configuration

-
- Step 1** Ensure that a lockout is not set on the UPSR:
- a. Display the CTC network view.
 - b. Right-click the span (the line between the nodes).
 - c. Click **Circuits**.
 - d. Under Switch State, confirm that Clear appears.
 - e. If Clear does appear, perform Steps a – d at the next span.
 - f. If Clear still does not appear, click the **Switch all UPSR- circuits away** menu.
 - g. Choose **Clear** and click **Apply**.
 - h. Click **Yes** at the Confirm UPSR Switch Are You Sure? dialog box.
 - i. Click **OK** at the next dialog box.
- Step 2** Check the fiber connections to ensure they are securely fastened and intact.
- Step 3** Ensure the OC-N cards are active and in-service.
- Step 4** Verify that the protect OC-N card paired with the active reporting OC-N card is the same type and in-service.
- Step 5** If the alarm persists and the reporting traffic card is active, do a manual switch to move traffic away from the card:
- a. At the node view, click the **Maintenance > Protection** tabs.
 - b. Double-click the protection group that contains the reporting card.
 - c. Click the Protect/Standby card of the selected groups.
 - d. Click **Manual** and **OK**.
- Step 6** Perform a software reset on the reporting card:
- a. Display the CTC node view.
 - b. Position the cursor over the slot reporting the alarm.
 - c. Right-click to choose **RESET CARD**.
 - d. If the alarm persists, physically reseal the reporting card.
- Step 7** If the traffic does not switch over, right-click on the protect card and click **Reset**.
- Step 8** Attempt another manual switch after the protect cards have booted up completely.
- Step 9** If you are still unable to perform a switch, reseal the protect card.
- Step 10** Attempt another manual switch.
- Step 11** Clear the manual switch:
- a. At the node view, click the **Maintenance > Protection** tabs.
 - b. Double-click the protection group that contains the reporting card.

- c. Highlight either selected group.
- d. Click **Clear** and click **YES** at the confirmation dialog box.

Step 12 If the alarm persists, replace the protect card.



Note When you replace a card with an identical type of card, you do not need to make any changes to the database.

Step 13 Log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center to report a service-affecting problem (1-877-323-7368).

1.3.45 FAILTOSWR

- Major, Service affecting

This alarm signals an automatic protection switching (APS) ring switch failure. FAILTOSWR clears when one of the following actions occurs: a higher priority event, such as a user-switch command occurs, the next ring switch succeeds, or the cause of the APS switch (such as an SF or SD alarm) clears.



Warning

On the OC-192 card, the laser is on when the card is booted and the safety key is in the on position (labeled 1). The port does not have to be in service for the laser to be on. The laser is off when the safety key is off (labeled 0).



Warning

Invisible laser radiation may be emitted from the end of the unterminated fiber cable or connector. Do not stare into the beam directly with optical instruments. Viewing the laser output with certain optical instruments (for example, eye loupes, magnifiers, and microscopes) within a distance of 100 mm may pose an eye hazard. Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.

Procedure: Clear the FAILTOSWR Alarm on a Four-Fiber BLSR Configuration

- Step 1** Check to see that every node expected to be part of the ring is listed in the ring map:
- a. Click the **Provisioning > Ring** tabs.
 - b. Highlight the row of the affected ring.
 - c. Click **Ring Map**.
 - d. Verify that a Node ID appears in the Ring Map for every node expected to be part of the ring.
- Step 2** Display the CTC network view.
- Step 3** Look for alarms on OC-N cards that make up the ring or span and troubleshoot these alarms.
- Step 4** Log into the near-end node and click the **Ring > Provisioning** tabs.
- Step 5** Record the OC-N cards listed under West Line and East Line. Ensure these OC-N cards are active and in-service.
- Step 6** Verify fiber continuity to the ports on the recorded cards.

Step 7 Verify that the correct port is in-service.



Caution Using a test set will disrupt service on the optical card. It may be necessary to manually switch traffic carrying circuits over to a protection path.

Step 8 Use an optical test set to verify that a valid signal exists on the line.

Test the line as close to the receiving card as possible.

Step 9 Clean the fiber:

- a. Clean fiber according to local site practice.
- b. If no local practice exists, use a CLETOP Real-Type or equivalent fiber-optic cleaner and follow the instructions accompanying the product.

Step 10 Verify that the power level of the optical signal is within the OC-N card's receiver specifications. The "Optical Card Transmit and Receive Levels" section on page 2-35 lists these specifications.

Step 11 If there is a valid signal, replace the connector on the backplane.

Step 12 Repeat Steps 1 - 5 for any other ports on the card.

Step 13 Replace the protect standby OC-N card.

Step 14 If the alarm does not clear after the protect standby OC-N card is replaced, replace the working active OC-N card:

- a. Right click the working active card, and click **Reset Card**.
- b. Verify that the standby protect card becomes active. The green active LED will light up on the card on both the CTC screen and on the physical card.
- c. Replace the now working standby OC-N card.



Note When you replace a card with an identical type of card, you do not need to make any changes to the database.

Step 15 If the alarm does not clear after you replace both cards, follow Steps 4 - 14 for each of the nodes in the ring.

Step 16 Log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center to report a service-affecting problem (1-877-323-7368).

1.3.46 FAILTOSWS

- Major, Service affecting

This alarm signals an APS span switch failure. For four-fiber BLSR, a failed span switch initiates a ring switch. If the ring switch occurs, the FAILTOSWS alarm will not appear. If the ring switch does not occur, the FAILTOSWS alarm appears. FAILTOSWS clears when one of the following actions occur: a higher priority event, such as a user-switch command occurs, the next ring switch succeeds, or the cause of the APS switch (such as an SF or SD alarm) clears.

Follow the procedure for "Clear the FAILTOSWR Alarm on a Four-Fiber BLSR Configuration" section on page 1-35.

1.3.47 FAN

- Two or more fan failure: Critical, Service affecting
- One fan failure: Major, Non-service affecting

The fan alarm indicates a problem with the fan-tray assembly. When the fan is not fully functional, the temperature of the ONS 15454 can rise above its normal operating range. The fan tray contains six fans and needs a minimum of five working fans to properly cool the ONS 15454. However, even with five working fans, the fan tray can need replacement because a sixth working fan is required for extra protection against overheating.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the FAN Alarm

-
- Step 1** Check the condition of the air filter to see if it needs replacement.
 - Step 2** If the filter is clean, take the fan-tray assembly out of the ONS 15454.
 - Step 3** Reinsert the fan tray making sure the back of the fan tray connects to the rear of the ONS 15454.



Note

The fan should run immediately when correctly inserted.

- Step 4** If the fan does not run or the alarm persists, replace the fan tray.
 - Step 5** If the replacement fan tray does not operate correctly, log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center to report a service-affecting problem (1-877-323-7368).
-

1.3.48 FE-AIS

- Not Alarmed (NA) (Condition)

The far-end DS-3 node is reporting an alarm indication signal (AIS). The prefix FE in an alarm message means the main alarm is occurring at the far-end node and not at the node reporting this FE-AIS alarm. Troubleshoot the FE alarm by troubleshooting the main alarm at its source. Both the alarms clear when the main alarm clears.

Procedure: Clear the FE-AIS Condition on the DS3XM-6 or DS3E Cards in C-bit Format

-
- Step 1** To troubleshoot an FE alarm, determine which node and card link directly to the card reporting the FE alarm. For example, an FE-AIS alarm from the DS3XM-6 card in Slot 12 of Node 1 may link to the main AIS alarm from an DS3XM-6 card in Slot 6 of Node 2.
 - Step 2** Log into the node that links directly to the card reporting the FE alarm.

Step 3 Clear the main alarm.

1.3.49 FE-DS1-MULTLOS

- Not Alarmed (NA) (Condition)

Multiple inputs detect a loss on the far end. The prefix FE in an alarm message means the main alarm is occurring at the far-end node and not at the node reporting the FE-DS1-MULTLOS alarm. Troubleshoot the FE alarm by troubleshooting the main alarm at its source. Both alarms clear when the main alarm clears.

Procedure: Clear the FE-DS1-MULTLOS Condition on the DS3XM-6

- Step 1** To troubleshoot an FE alarm, determine which node and card link directly to the card reporting the FE alarm. For example, an FE-AIS alarm from the DS3XM-6 card in Slot 12 of Node 1 may link to the main AIS alarm from a DS3XM-6 card in Slot 6 of Node 2.
- Step 2** Log into the node that links directly to the card reporting the FE alarm.
- Step 3** Look up and troubleshoot the main alarm.
-

1.3.50 FE-DS1-SNGLLOS

- Not Alarmed (NA) (Condition)

One of the DS-1 inputs on the far end detects an LOS. The prefix FE in an alarm message means the main alarm is occurring at the far-end node and not at the node reporting this FE-EQPT-FAILSA alarm. Troubleshoot the FE alarm by troubleshooting the main alarm at its source. Both alarms clear when the main alarm clears.

Procedure: Clear the FE-DS1-SNGLLOS Condition on the DS3XM-6

- Step 1** To troubleshoot an FE alarm, determine which node and card link directly to the card reporting the FE alarm. For example, an FE-AIS alarm from the DS3XM-6 card in Slot 12 of node 1 may link to the main AIS alarm from a DS3XM-6 card in Slot 6 of Node 2.
- Step 2** Log into the node that links directly to the card reporting the FE alarm.
- Step 3** Look up and troubleshoot the main alarm.
-

1.3.51 FE-EQPT-FAIL-SA

- Not Alarmed (NA) (Condition)

A far-end DS-3 equipment failure is occurring. The prefix FE in an alarm message means the main alarm is occurring at the far-end node and not at the node reporting the FE alarm. Troubleshoot the FE alarm by troubleshooting the main alarm at its source. Both alarms clear when the main alarm clears.

Procedure: Clear the FE-EQPT-FAIL-SA Condition on the DS3XM-6 or DS3E Cards in C-bit Format

-
- Step 1** To troubleshoot an FE alarm, determine which node and card link directly to the card reporting the FE alarm. For example, an FE-AIS alarm from the DS3XM-6 card in Slot 12 of Node 1 may link to the main AIS alarm from a DS3XM-6 card in Slot 6 of Node 2.
- Step 2** Log into the node that links directly to the card reporting the FE alarm.
- Step 3** Clear the main alarm.
-

1.3.52 FE-EQPT-NSA

- Not Alarmed (NA) (Condition)

A non-service affecting equipment failure is detected in the far-end DS-3. The prefix FE in an alarm message means that the main alarm is occurring at the far-end node, not the node reporting this FE-EQPT-NSA alarm. Troubleshoot the FE alarm by troubleshooting the main alarm at its source. Both alarms clear when the main alarm clears.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the FE-EQPT-NSA Condition on the DS3XM-6 or DS3E Cards in C-bit Format

-
- Step 1** To troubleshoot an FE alarm, determine which node and card link directly to the card reporting the FE alarm. For example, an FE-AIS alarm from the DS3XM-6 card in Slot 12 of Node 1 may link to the main AIS alarm from a DS3XM-6 card in Slot 6 of Node 2.
- Step 2** Log into the node that links directly to the card reporting the FE alarm.
- Step 3** Look up and troubleshoot the main alarm.
-

1.3.53 FE-IDLE

- Not Alarmed (NA) (Condition)

A far-end node detects an idle DS-3 signal. The prefix FE in an alarm message means that the main alarm is occurring at the far-end node, not the node reporting this FE-IDLE alarm. Troubleshoot the FE alarm by troubleshooting the main alarm at its source. Both alarms clear when the main alarm clears.

Procedure: Clear the FE-IDLE Condition on the DS3XM-6 or DS3E Cards in C-bit Format

-
- Step 1** To troubleshoot the FE alarm, determine which node and card link directly to the card reporting the FE alarm. For example, an FE-AIS alarm from the DS3XM-6 card in Slot 12 of Node 1 may link to the main AIS alarm from a DS3XM-6 card in Slot 6 of Node 2.
- Step 2** Log into the node that links directly to the card reporting the FE alarm.
- Step 3** Clear the main alarm.
-

1.3.54 FE-LOCKOUT

- Minor, Non-service affecting

FE-LOCKOUT raises whenever the Lockout Protection Span command is entered from any other node. This alarm indicates the prevention of any ring switch requests. The alarm clears when the lock out is removed.

Procedure: Clear the FE-LOCKOUT Alarm on a BLSR

-
- Step 1** Display CTC network view.
- Step 2** Find the node reporting the LOCKOUT-REQ.
- Step 3** Log into the node reporting the LOCKOUT-REQ.
- Step 4** Follow the “Clear the Lockout Switch Request and the LOCKOUT-REQ Condition on an OC-N Card” procedure on page 1-46.
-

1.3.55 FE-LOF

- Not Alarmed (NA) (Condition)

A far-end node reports a DS-3 loss of frame (LOF). The prefix FE in an alarm message means that the main alarm is occurring at the far-end node, not the node reporting this FE-LOF alarm. Troubleshoot the FE alarm by troubleshooting the main alarm at its source. Both alarms clear when the main alarm clears.

Procedure: Clear the FE-LOF Condition on the DS3XM-6 or DS-3E Cards in C-bit Format

-
- Step 1** To troubleshoot an FE alarm, determine which node and card link directly to the card reporting the FE alarm. For example, an FE-AIS alarm from the DS3XM-6 card in Slot 12 of Node 1 may link to the main AIS alarm from a DS3XM-6 card in Slot 6 of Node 2.
- Step 2** Log into the node that links directly to the card reporting the FE alarm.
- Step 3** Look up and troubleshoot the main alarm.
-

1.3.56 FE-LOS

- Not Alarmed (NA) (Condition)

The far-end node reports a DS-3 loss of signal (LOS). The prefix FE in an alarm message means that the main alarm is occurring at the far-end node, and not at the node reporting this FE-LOS alarm.

Troubleshoot the FE alarm by troubleshooting the main alarm at its source. Both alarms clear when the main alarm clears.

Procedure: Clear the FE-LOS Condition on the DS3XM-6 or DS-3E Cards in C-bit Format

-
- Step 1** To troubleshoot the FE alarm, determine which node and card link directly to the card reporting the FE alarm. For example, an FE-AIS alarm from the DS3XM-6 card in Slot 12 of Node 1 may link to the main AIS alarm from a DS3XM-6 card in Slot 6 of Node 2.
- Step 2** Log into the node that links directly to the card reporting the FE alarm.
- Step 3** Clear the main alarm.
-

1.3.57 FEPRLF

- Minor, Non-service affecting

The Far End Protection Line Failure alarm means that there was an APS switching channel failure on a signal coming into the node.



Note

The FEPRLF alarm only occurs on the ONS 15454 when 1+1 bidirectional protection is used on optical cards in a 1+1 configuration.

Procedure: Clear the FEPRLF Alarm on a Four-Fiber BLSR

-
- Step 1** To troubleshoot the FE alarm, determine which node and card link directly to the card reporting the FE alarm. For example, an FE-AIS alarm from the DS3XM-6 card in Slot 12 of Node 1 may link to the main AIS alarm from a DS3XM-6 card in Slot 6 of Node 2.
- Step 2** Log into the node that links directly to the card reporting the FE alarm.
- Step 3** Look up and troubleshoot the main alarm.
-

1.3.58 FORCED-REQ

- Not Alarmed (NA) (Condition)

A user entered the force command on a span or card to force traffic from a working card or working span to a protection card or protection span or vice versa. You do not need to clear this alarm if you want the force switch to remain in place. To clear this alarm, clear the force command.

Procedure: Clear the FORCED-REQ Alarm on an OC-N Card

-
- Step 1** Click the **Maintenance** tab.
 - Step 2** Click the **Protection** tab for a card or span switch.
 - Step 3** At **Operation**, click the drop-down arrow.
 - Step 4** Choose **Clear** and click **Apply**.
-

1.3.59 FRNGSYNC

- Major, Service affecting

The reporting ONS 15454 is in free run synchronization mode. External timing sources have been disabled and the node is using its internal clock, or the ONS 15454 has lost its designated BITS timing source.

Procedure: Clear the FRNGSYNC Alarm

-
- Step 1** If the ONS 15454 is configured to operate from its own internal clock, disregard this alarm.
 - Step 2** If the ONS 15454 is configured to operate off an external timing source, verify that the BITS timing source is valid. Common problems with a BITS timing source include reversed wiring and bad timing cards.
 - Step 3** Find and troubleshoot alarms related to the failures of the primary and secondary reference sources, such as SYNCPRI and SYNCSEC.
-

1.3.60 FSTSYNC

- Minor, Non-service affecting

A Fast Start Synchronization mode alarm raises when the ONS 15454 is choosing a new timing reference. The previous timing reference has failed. This alarm disappears after approximately 30 seconds.



Note This is an informational alarm.

1.3.61 HITEMP

- Minor, Non-service affecting

The temperature of the ONS 15454 is above 50 degrees Celsius (122 degrees Fahrenheit).

**Caution**

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the HITEMP Alarm

-
- Step 1** Check the temperature of the ONS 15454 on the front panel LCD.
 - Step 2** Check that the temperature of the room is not abnormally high.
 - Step 3** Ensure that nothing prevents the fan-tray assembly from passing air through the ONS 15454.
 - Step 4** Ensure that blank faceplates fill the ONS 15454 empty slots. Blank faceplates help airflow.
 - Step 5** Check the condition of the air filter to see if it needs replacement.
 - Step 6** If the filter is clean, take the fan-tray assembly out of the ONS 15454.
 - Step 7** Reinsert the fan tray, making sure the back of the fan tray connects to the rear of the ONS 15454.

**Note**

The fan should run immediately when correctly inserted.

-
- Step 8** If the fan does not run or the alarm persists, replace the fan tray.
 - Step 9** If the replacement fan tray does not operate correctly, log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center to report a service-affecting problem (1-877-323-7368).
-

1.3.62 HLDOVERSYNC

- Major, Service affecting

Loss of the primary/secondary timing reference raises the Holdover Synchronization alarm. Timing reference loss occurs when line coding on the timing input is different than the configuration on the ONS 15454. It also usually occurs during the selection of a new node reference clock. This alarm indicates that the ONS 15454 has gone into holdover and is using the ONS 15454 internal reference clock, which is a Stratum 3-level timing device. The alarm clears when primary or secondary timing is reestablished.

Procedure: Clear the HLDOVERSYNC Alarm

-
- Step 1** Check for additional alarms that relate to timing.
 - Step 2** Reestablish a primary and secondary timing source according to local site practice.
-

1.3.63 IMPROPRMVL

- Critical, Service-affecting

A card was physically removed from its slot before the card was deleted in CTC. The card does not need to be in-service to cause this alarm, it only needs to be recognized by CTC and the TCC+ card. This alarm does not appear if you delete the card from CTC before you physically remove the card from the node.



Note

CTC gives the user approximately 15 seconds to physically remove the card before the CTC begins a card reboot.



Caution

Do not pull a card during a card reboot. If CTC begins to reboot a card before you remove the card, allow the card to finish rebooting. After the card reboots, delete the card in CTC again and physically remove the card before it begins to reboot.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the IMPROPRMVL Alarm

Step 1 Right-click the card reporting the IMPROPRMVL.

Step 2 Choose **Delete**.



Note

CTC will not allow you to delete this card if the card is in-service, has a circuit mapped to it, is paired in a working protection scheme, has DCC enabled, or is used as a timing reference.

Step 3 If the card is in-service, take the facility out of service:



Caution

Before taking the facility out of service, ensure that no live traffic is present on the facility.

- In CTC, double-click the reporting card to display the card view.
- Click the **Provisioning** tab.
- Click the **Status** of any in-service ports.
- Choose **Out of Service** to take the ports out of service.

Step 4 If a circuit has been mapped to the card, delete the circuit:



Caution

Before deleting the circuit, ensure that the circuit does not carry live traffic.

- At the node view, click the **Circuits** tab.
- Click the applicable circuit, i.e., the circuit that connects to the reporting card.

- c. Click **Delete**.
- Step 5** If the card is paired in a protection scheme, delete the protection group:
- a. Click the **Provisioning > Protection** tabs.
 - b. Click the protection group of the reporting card.
 - c. Click **Delete**.
- Step 6** If the card is provisioned for DCC, delete the DCC provisioning:
- a. Click the **SONET DCC > Provisioning** tabs.
 - b. Click the slots and ports listed in SDCC Terminations.
 - c. Click **Delete** and click **Yes** in the dialog box that appears.
- Step 7** If the card is used as a timing reference, change the timing reference:
- a. Click the **Provisioning > Timing** tabs.
 - b. Click the **Ref-1** menu.
 - c. Change Ref-1 from the listed OC-N card to Internal Clock.
 - d. Click **Apply**.
- Step 8** Right-click the card reporting the IMPROPRMVL and choose **Delete**.
-

1.3.64 INCOMPATIBLE-SW

- Minor, Non-service affecting

The CTC software version loaded on the connecting workstation and the CTC software version loaded on the TCC+ card are incompatible. This occurs when the TCC+ software is upgraded but the PC has not yet upgraded the compatible CTC jar file. INCOMPATIBLE-SW also occurs when CTC logs into a node with compatible software but encounters another node in the network that has a newer version of CTC.

Procedure: Clear the INCOMPATIBLE-SW Alarm

-
- Step 1** Exit the current CTC session and completely close the browser.
 - Step 2** Start the browser.
 - Step 3** Type the ONS 15454 IP address of the node that reported the alarm. This can be the original IP address you logged on with or an IP address other than the original.
 - Step 4** Log into CTC. The browser will download the jar file from CTC.
-

1.3.65 INVMACADR

- Major, Non-service affecting

The ONS 15454 Media Access Control layer address (MAC Address) is invalid. The MAC Address is permanently set into the ONS 15454 chassis when it is manufactured. Do not attempt to troubleshoot an INVMACADDR. Contact the Cisco Technical Assistance Center (TAC) at 1-877-323-7368.

Procedure: Clear the INVMACADDR Alarm

This is not a user-serviceable problem. Log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center to report a service-affecting problem (1-877-323-7368).

1.3.66 LOCKOUT-REQ

- Not Alarmed (NA) (Condition)

The Lockout Switch Request on Facility/Equipment alarm occurs when a user initiates a lockout switch request for an OC-N card or a lockout switch request on a UPSR at the path level. A lockout prevents protection switching from occurring. Clearing the lockout will again allow protection switching to take place. Clearing the lockout switch request clears the LOCKOUT-REQ alarm. This is an informational alarm.

Procedure: Clear the Lockout Switch Request and the LOCKOUT-REQ Condition on an OC-N Card

-
- Step 1** Display the CTC network view.
 - Step 2** Click **Circuits** tab and highlight the circuit.
 - Step 3** Click **Edit** and click the **UPSR** tab.
 - Step 4** From the Switch State menu, highlight **Clear**.
 - Step 5** Click **Apply** and click **Close**.
-

1.3.67 LOF (DS-1)

- Major, Service affecting

Loss of Frame (LOF) indicates that the receiving ONS 15454 has lost frame delineation in the incoming data. If the LOF appears on the DS-1 card, the transmitting equipment may have its framing set to a format that differs from the receiving ONS 15454.

Procedure: Clear the LOF Condition on the DS-1 Card

-
- Step 1** Verify that the line framing and line coding match between the DS-1 port and the signal source.
 - a. In CTC, note the slot and port reporting the alarm.
 - b. Find the coding and framing formats of the signal source for the card reporting the alarm. You may need to contact your network administrator for this information.
 - c. Display the card-level view of the reporting card.
 - d. Click the **Provisioning > Line** tabs.

- e. Verify that the line type of the reporting port matches the line type of the signal source.
- f. If the signal source line type does not match the reporting port, click **Line Type** to reveal a menu. Choose the matching type.
- g. Verify that the reporting Line Coding matches the signal source's Line Type.
- h. If the signal source line coding does not match the reporting port, click **Line Coding** to reveal the menu. Choose the matching type and click **Apply**.



Note On the Line tab, the B8ZS coding field is normally paired with ESF in the Framing field. AMI coding is normally paired with SF (D4) in the Framing field.

- Step 2** If the alarm does not clear when the coding and framing of the ONS 15454 match the coding and framing of the signal source, replace the DS-1 card.



Note When you replace a card with an identical type of card, you do not need to make any changes to the database.

1.3.68 LOF (DS3XM-6)

- Critical, Service affecting

Loss of Frame (LOF) indicates that the receiving ONS 15454 has lost frame delineation in the incoming data. If the LOF appears on the DS3XM-6 card, the framing of the transmitting equipment may be set to a format that differs from the receiving ONS 15454.

Procedure: Clear the LOF Condition on the DS3XM-6 or DS-3E Cards in C-bit Format

- Step 1** Verify that the line framing and line coding match between the DS3XM-6 port and the signal source.
- a. In CTC, note the slot and port reporting the alarm.
 - b. Find the coding and framing formats of the signal source for the card reporting the alarm. Your network administrator has this information.
 - c. Display the card-level view of the reporting card.
 - d. Click the **Provisioning > Line** tabs.
 - e. Verify that the line type of the reporting port matches the line type of the signal source.
 - f. If the signal source line type does not match the reporting port, click **Line Type** to reveal a menu. Choose the matching type.
 - g. Verify that the reporting Line Coding matches the signal source's Line Type.
 - h. If the signal source line coding does not match the reporting port, click **Line Coding** to reveal the menu. Choose the matching type and click **Apply**.



Note On the Line tab, the B8ZS coding field is normally paired with ESF in the Framing field. AMI coding is normally paired with SF (D4) in the Framing field.

Step 2 If the alarm does not clear when the coding and framing of the ONS 15454 match the coding and framing of the signal source, replace the DS3XM-6 card.



Note When you replace a card with an identical type of card, you do not need to make any changes to the database.

1.3.69 LOF (BITS)

- Major, Service affecting

A port on the TCC+ BITS input detects an LOF on the incoming BITS timing reference signal. LOF indicates that the receiving ONS 15454 has lost frame delineation in the incoming data.



Note The procedure assumes that the BITS timing reference signal is functioning properly. It also assumes the alarm is not appearing during node turn-up.



Caution Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the LOF Alarm on the TCC+ Card

- Step 1** Verify that the line framing and line coding match between the BITS input and the TCC+:
- In CTC node view or card view, note the slot and port reporting the alarm.
 - Find the coding and framing formats of the external BITS timing source. This should be in the user documentation for the external BITS timing source or on the timing source itself.
 - Click the **Provisioning > Timing** tabs to display the General Timing screen.
 - Verify that **Coding** matches the coding of the BITS timing source (either B8ZS or AMI).
 - If the coding does not match, click **Coding** to reveal a menu. Choose the appropriate coding.
 - Verify that **Framing** matches the framing of the BITS timing source (either ESF or SF [D4]).
 - If the framing does not match, click **Framing** to reveal the menu. Choose the appropriate framing.



Note On the timing subtab, the B8ZS coding field is normally paired with ESF in the Framing field, and the AMI coding field is normally paired with SF (D4) in the Framing field.

Step 2 If the alarm does not clear when the line framing and line coding match between the BITS input and the TCC+, replace the TCC+ card.

**Note**

When you replace a card with an identical type of card, you do not need to make any changes to the database.

1.3.70 LOF (EC-1)

- Critical, Service affecting

A port on the reporting EC-1 card has a LOF condition. LOF indicates that the receiving ONS 15454 has lost frame delineation in the incoming data. LOF occurs when the SONET overhead loses a valid framing pattern for 3 milliseconds. Receiving two consecutive valid A1/A2 framing patterns clears the alarm.

LOF on an EC-1 card is sometimes an indication that the EC-1 card reporting the alarm expects a specific line rate and the input line rate source does not match the input line rate of the optical receiver.

**Caution**

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the LOF Alarm on the EC-1 Card

- Step 1** The LOF should trigger an automatic protection switch away from the working card that reported the alarm. If it did not, do a manual switch to move traffic away from the reporting card:
- At the node view, click the **Maintenance > Protection** tabs.
 - Double-click the protection group that contains the reporting card.
 - Click the Protect/Standby card of the selected groups.
 - Click **Manual** and **OK**.
- Step 2** Clear the manual switch:
- At the node view, click the **Maintenance > Protection** tabs.
 - Double-click the protection group that contains the reporting card.
 - Highlight either selected group.
 - Click **Clear** and click **YES** at the confirmation dialog box.

**Note**

If you do not have a protect card for the reporting card, create a new circuit on the reporting card to achieve the same effect.

- Step 3** If you still receive the LOF alarm, log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center to report a service-affecting problem (1-877-323-7368).

1.3.71 LOF (OC-N)

- Critical, Service affecting

A port on the reporting OC-N card has an LOF condition. LOF indicates that the receiving ONS 15454 has lost frame delineation in the incoming data. LOF occurs when the SONET overhead loses a valid framing pattern for 3 milliseconds. Receiving two consecutive valid A1/A2 framing patterns clears the alarm.

LOF on an OC-N card is sometimes an indication that the OC-N card reporting the alarm expects a specific line rate and the input line rate source does not match the input line rate of the optical receiver.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the LOF Alarm on an OC-N Card

- Step 1** The LOF should trigger an automatic protection switch away from the working card that reported the alarm. If it did not, do a manual switch to move traffic away from the reporting card:
- At the node view, click the **Maintenance > Protection** tabs.
 - Double-click the protection group that contains the reporting card.
 - Click the Protect/Standby card of the selected groups.
 - Click **Manual** and **OK**.



Note

If you do not have a protect card for the reporting card, create a new circuit on the reporting card to achieve the same effect.

- Step 2** Clear the manual switch:
- At the node view, click the **Maintenance > Protection** tabs.
 - Double-click the protection group that contains the reporting card.
 - Highlight either selected group.
 - Click **Clear** and click **YES** at the confirmation dialog box.
- Step 3** Verify that the OC-N port on the upstream node is in-service.
- Step 4** If you continue to receive the LOF alarm, see the “Faulty Fiber-Optic Connections” section on page 2-29.

1.3.72 LOP-P

- Critical, Service affecting

This alarm indicates a loss of pointer (LOP) condition at the path level. LOP occurs when valid H1/H2 pointer bytes are missing from the SONET overhead. Receiving equipment monitors the H1/H2 pointer bytes to locate the SONET payload. A LOP alarm means that eight, nine, or ten consecutive frames do not have valid pointer values. The alarm clears when three consecutive valid pointers are received.

One of the conditions that can cause this alarm is a transmitted STSc circuit that is smaller than the provisioned STSc. This condition causes a mismatch of the circuit type on the concatenation facility. For example, if an STS-3c or STS-1 is sent across a circuit provisioned for STS-12c, a LOP alarm occurs.


Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the LOP Alarm on a Line Card

-
- Step 1** Verify the cabling and physical connections on the reporting card.
- Step 2** Perform a software reset on the reporting card:
- a. Display the CTC node view.
 - b. Position the cursor over the slot reporting the alarm.
 - c. Right-click to choose **RESET CARD**.
- Step 3** Do a manual switch (side switch) to move traffic away from the card.
- a. At the node view, click the **Maintenance > Protection** tabs.
 - b. Double-click the protection group that contains the reporting card.
 - c. Click the Protect/Standby card of the selected groups.
 - d. Click **Manual** and **OK**.



Note If you do not have a protect card for the reporting card, create a new circuit on the reporting card to achieve the same effect.

- Step 4** Clear the manual switch:
- a. At the node view, click the **Maintenance > Protection** tabs.
 - b. Double-click the protection group that contains the reporting card.
 - c. Highlight either selected group.
 - d. Click **Clear** and click **YES** at the confirmation dialog box.
- Step 5** If the alarm persists, the problem is at the far-end node. Verify the stability of the cabling and physical connections that connect to the far-end card.
- Step 6** Do a soft reset on the far-end card:
- a. Display the CTC node view.
 - b. Position the cursor over the slot reporting the alarm.
 - c. Right-click and choose **RESET CARD**.
- Step 7** Perform a soft reset on the reporting card:
- a. Display the CTC node view.

- b. Position the cursor over the slot reporting the alarm.
- c. Right-click and choose **RESET CARD**.

Step 8 Switch from the far-end working card to the far-end protect card.

Step 9 If the alarm persists, replace the far-end card.



Note When you replace a card with an identical type of card, you do not need to make any changes to the database.

1.3.73 LOP-V

- Major, Service affecting

LOP-V indicates a loss of pointer at the VT level. The VT, or electrical, layer occurs when the SONET signal is broken down into an electrical signal, for example, when an optical signal comes into an ONS 15454. The ONS 15454 demultiplexes this optical signal. One of the channels separated from the optical signal cross connects into a ONS 15454 DS3XM-6 or DS-1 port. The ONS 15454 reports the LOS-V alarm.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the LOP-V Alarm on the DS3XM-6 or DS-1 Card

Step 1 Verify the stability of the cabling and physical connections on the reporting card.

Step 2 Perform a software reset on the reporting card:

- a. Display the CTC node view.
- b. Position the cursor over the slot reporting the alarm.
- c. Right-click and choose **RESET CARD**.

Step 3 Do a manual switch to move traffic away from the card:

- a. At the node view, click the **Maintenance > Protection** tabs.
- b. Double-click the protection group that contains the reporting card.
- c. Click the Protect/Standby card of the selected groups.
- d. Click **Manual** and **OK**.



Note If you do not have a protect card for the reporting card, create a new circuit on the reporting card to achieve the same effect.

Step 4 Clear the manual switch:

- a. At the node view, click the **Maintenance > Protection** tabs.

- b. Double-click the protection group that contains the reporting card.
 - c. Highlight either selected group.
 - d. Click **Clear** and click **YES** at the confirmation dialog box.
- Step 5** If the alarm persists, the problem is at the far-end node. Verify the cabling and physical connections that connect to the far-end card.
- Step 6** Do a soft reset on the far-end card.
- Step 7** Switch from the far-end working card to the far-end protect card.
-

1.3.74 LOS (DS-N)

- Critical, Service affecting

This alarm indicates a loss of signal (LOS) at the card for either a DS-3 port or a DS-1 port. LOS occurs when the port on the card is in-service but no signal is being received. The cabling is not correctly connected to the card, or no signal exists on the line. Possible causes for no signal on the line include upstream equipment failure or a fiber cut.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the LOS Alarm on the DS-3, DS3XM-6, or DS-1 Card

-
- Step 1** Verify cabling continuity to the port.
- Step 2** Verify that the correct port is in-service.
- Step 3** Use a test set to confirm that a valid signal exists on the line. Test the line as close to the receiving card as possible.
- Step 4** Ensure that the transmit and receive outputs from the DSx panel to your equipment are properly connected.
- Step 5** If there is a valid signal, replace the DS-1 or DS-3 cable connector on the ONS 15454.
- Step 6** Repeat Steps 1 - 5 for another port on the card.
- Step 7** Look for another alarm that may identify the source of the problem.
- Step 8** Replace the reporting card.



Note

When you replace a card with an identical type of card, you do not need to make any changes to the database.

1.3.75 LOS (BITS)

- Major, Service affecting

The TCC+ card has a loss of signal (LOS) condition from the BITS timing source. An LOS occurs when a SONET receiver detects an all-zero pattern for 10 microseconds or longer. An LOS (BITS-N) means the BITS clock or the connection to the BITS clock failed.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the LOS Alarm

-
- Step 1** Verify the wiring connection from the ONS 15454 backplane BITS clock pin fields to the timing source.
- Step 2** Check that the BITS clock is operating properly.
-

1.3.76 LOS (OC-N)

- Critical, Service affecting

A port on the reporting OC-N card has a loss of signal (LOS) condition. An LOS occurs when a SONET receiver detects an all-zero pattern for 10 microseconds or longer. An LOS means the upstream transmitter has failed. If an OC-N LOS alarm is not accompanied by additional alarms, a fiber break is usually the cause of the alarm. The condition clears when two consecutive valid frames are received.



Warning

Invisible laser radiation may be emitted from the aperture ports of the single-mode fiber optic modules when no cable is connected. Avoid exposure and do not stare into open apertures.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the LOS Alarm on an OC-N Card

-
- Step 1** Verify fiber continuity to the port.
- Step 2** Verify that the correct port is in-service.
- Step 3** Use an optical test set to verify that a valid signal exists on the line.
Test the line as close to the receiving card as possible.
- Step 4** Clean the fiber:
- a. Clean fiber according to local site practice.

- b. If no local practice exists, use a CLETOP Real-Type or equivalent fiber-optic cleaner and follow the instructions accompanying the product.
- Step 5** Verify that the power level of the optical signal is within the OC-N card's receiver specifications. The "Optical Card Transmit and Receive Levels" section on page 2-35 lists these specifications for each card.
- Step 6** If there is a valid signal, replace the connector on the backplane.
- Step 7** Repeat Steps 1 - 5 for another port on the card.
- Step 8** Replace the OC-N card.
-

1.3.77 LOS (EC-1)

- Critical, Service affecting

A port on the reporting EC-1 card has a loss of signal (LOS) condition. An LOS occurs when a SONET receiver detects an all-zero pattern for 10 microseconds or longer. An LOS means the upstream transmitter has failed. If an EC-1 LOS alarm is not accompanied by additional alarms, a fiber break or cabling problem is usually the cause of the alarm. The condition clears when two consecutive valid frames are received.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the LOS Alarm on the EC-1 Card

-
- Step 1** Verify cabling continuity to the port.
- Step 2** Verify that the correct port is in-service.
- Step 3** Use a test set to confirm that a valid signal exists on the line. Test the line as close to the receiving card as possible.
- Step 4** Ensure that the transmit and receive outputs from the DSx panel to your equipment are properly connected.
- Step 5** If there is a valid signal, replace the cable connector on the ONS 15454.
- Step 6** Repeat Steps 1 - 5 for another port on the card.
- Step 7** Look for another alarm that may identify the source of the problem.
- Step 8** Replace the reporting card.



Note

When you replace a card with an identical type of card, you do not need to make any changes to the database.

1.3.78 LPBKDS1FEAC

- Not Alarmed (NA) (Condition)

A DS-1 loopback signal is received from the far-end node due to a Far-End Alarm and Control (FEAC) command. An FEAC command is often used with loopbacks.

Loopback is a commonly used troubleshooting technique. A signal is sent out on a link or part of the network and returned to the sending device. A troubleshooter can compare the quality of the sent signal and the returned signal to determine the condition of an isolated circuit. By setting up loopbacks on various parts of the network and excluding other parts, a troubleshooter can logically narrow down the source of the problem. For more information about loopbacks, see the “Network Tests” section on page 2-3.



Caution

The CTC permits loopbacks on an in-service circuit. This operation is service affecting.



Note

This is an informational alarm.

1.3.79 LPBKDS3FEAC

- Not Alarmed (NA) (Condition)

A DS-3 loopback signal is received from the far-end node because of a Far-End Alarm and Control (FEAC) command. An FEAC command is often used with loopbacks.

Loopback is a commonly used troubleshooting technique. A signal is sent out on a link or part of the network and returned to the sending device. A troubleshooter can compare the quality of the sent signal and the returned signal to determine the condition of this isolated circuit. By setting up loopbacks on various parts of the network and excluding other parts, a troubleshooter can logically narrow down the source of the problem. For more information about loopbacks, see the “Network Tests” section on page 2-3.



Caution

The CTC permits loopbacks on an in-service circuit. This operation is service affecting.



Note

This is an informational alarm.

1.3.80 LPBKFACILITY (DS-N)

- Not Alarmed (NA) (Condition)

A software facility loopback is active for a port on the reporting card.

Loopback is a commonly used troubleshooting technique. A signal is sent out on a link or part of the network and returned to the sending device. A troubleshooter can compare the quality of the sent signal and the returned signal to determine the condition of this isolated circuit. By setting up loopbacks on various parts of the network and excluding other parts, a troubleshooter can logically narrow down the source of the problem. For more information on loopbacks, see “Network Tests” section on page 2-3.

Two types of loopbacks are available: Facility and Terminal. Facility loopbacks troubleshoot ports only and are generally performed locally or at the near end. Terminal loopbacks test ports and spans and are often used for remote sites or far-end equipment. You can provision loopbacks through CTC.

**Caution**

The CTC permits loopbacks to be performed on an in-service circuit. This operation is service affecting.

Procedure: Clear the LBFACILITY Alarm on the DS-3, DS-3E, DS3XM-6 or DS-1 Card

-
- Step 1** Double-click the reporting card in CTC or right-click the reporting card in CTC and choose **Open** from the menu.
 - Step 2** Click the **Maintenance** tab.
 - Step 3** Choose the Loopback Type column and click **None**.
 - Step 4** Click **Apply**.
-

1.3.81 LPBFACILITY (OC-N)

- Not Alarmed (NA) (Condition)

A software facility loopback is active for a port on the reporting card.

Loopback is a commonly-used troubleshooting technique. A signal is sent out on a link or part of the network and returned to the sending device. A troubleshooter can compare the quality of the sent signal and the returned signal to determine the condition of an isolated circuit. By setting up loopbacks on various parts of the network and excluding other parts, a troubleshooter can logically isolate the source of the problem. For more information on loopbacks, see the “Network Tests” section on page 2-3.

Two types of loopbacks are available: Facility and Terminal. Facility loopbacks troubleshoot ports only and are generally performed locally or at the near end. Terminal loopbacks test ports and spans and are often used for remote sites or far end equipment. You provision loopbacks using CTC.

Procedure: Clear the LBFACILITY Condition on the OC-N Card

-
- Step 1** To remove the loopback alarm, double-click or right-click on the reporting card in the CTC. Choose **Open** from the list of options.
 - Step 2** Click the **Maintenance** tab.
 - Step 3** Click the Loopback Type column and choose **None** from the menu.
 - Step 4** Click **Apply**.
-

1.3.82 LPBKTERRMINAL (DS-N)

- Not Alarmed (NA) (Condition)

A software terminal loopback is active for a port on the reporting card.

Loopback is a commonly used troubleshooting technique. A signal is sent out on a link or part of the network and returned to the sending device. A troubleshooter can compare the quality of the sent signal and the returned signal to determine the condition of an isolated circuit. By setting up loopbacks on various parts of the network and excluding other parts, a troubleshooter logically isolates the source of the problem. For more information on loopbacks, see the “Network Tests” section on page 2-3.

Two types of loopbacks are available: Facility and Terminal. Facility loopbacks troubleshoot ports only and are generally performed locally or at the near end. Terminal loopbacks test ports and spans and are often used for remote sites or far-end equipment. You provision loopbacks using CTC.



Caution

The CTC permits loopbacks on an in-service circuit. This operation is service affecting.

Procedure: Clear the LPBKTERMINAL Condition on a DS-N Card

-
- Step 1** To remove the loopback alarm, double-click or right-click the reporting card in CTC and choose **Open** from the list of options.
 - Step 2** Click the **Maintenance** tab.
 - Step 3** Choose the Loopback Type column and choose **None** from the menu.
 - Step 4** Click **Apply**.
-

1.3.83 LPBKTERMINAL (OC-N)

- Not Alarmed (NA) (Condition)

A software facility loopback is active for a port on the reporting card.

Loopback is a commonly-used troubleshooting technique. A signal is sent out on a link or part of the network and returned to the sending device. A troubleshooter can compare the quality of the sent signal and the returned signal to determine the condition of an isolated circuit. By setting up loopbacks on various parts of the network and excluding other parts, a troubleshooter can logically isolate the source of the problem. For more information on loopbacks, see the “Network Tests” section on page 2-3.

Two types of loopbacks are available: Facility and Terminal. Facility loopbacks troubleshoot ports only and are generally performed locally or at the near end. Terminal loopbacks test ports and spans and are often used for remote sites or far end equipment. You provision loopbacks using CTC.

Procedure: Clear the LBPBKTERMINAL Condition on an OC-N Card

-
- Step 1** To remove the loopback alarm, double-click or right-click on the reporting card in the CTC. Choose **Open** from the list of options.
 - Step 2** Click the **Maintenance** tab.
 - Step 3** Click the Loopback Type column and choose **None** from the menu.
 - Step 4** Click **Apply**.
-

1.3.84 MANRESET

- Not Alarmed (NA) (Condition)

A user performed a manual system reset meaning a user right-clicked a card and chose **Reset**. Resets performed during a software upgrade also prompt the alarm.

1.3.85 MANUAL-REQ

- Not Alarmed (NA) (Condition)

The Manual Switch Request on a Facility/Equipment alarm occurs when a user initiates a manual switch request on an OC-N card or UPSR path. Clearing the manual switch clears the MANUAL-REQ alarm.

Procedure: Clear the Manual Switch and the MANUAL-REQ Condition on an OC-N Card

-
- Step 1** From network view, click the **Circuits** tab.
 - Step 2** Highlight the circuit.
 - Step 3** Click **Edit** and click the **UPSR** tab.
 - Step 4** From the Switch State menu, highlight **Clear**.
 - Step 5** Click **Apply** and click **Close**.
-

1.3.86 MEA

- Critical, Service affecting

The Mismatch Between Entity/Equipment Type and Provisioned Attributes alarm occurs when the physical card inserted in a slot does not match the card type that is provisioned for that slot in CTC. The alarm clears when the provisioned card type and the physical card type match.

Procedure: Clear the MEA Alarm on a Cross-Connect or Line Card

-
- Step 1** Physically verify the type of card that sits in the reported slot.
 - Step 2** Click the **Inventory** tab to reveal the provisioned card type.
 - Step 3** Determine which card CTC identifies in the reported slot.
 - Step 4** If you prefer the card type depicted by CTC, physically insert that type of card (provisioned for that slot).
 - Step 5** If you prefer the card that physically occupies the slot, put the cursor over the provisioned card in CTC and right-click to choose **Delete Card**.

The card that physically occupies the slot reboots, and CTC automatically provisions the card type into that slot.



Note If the card is in-service, has a circuit mapped to it, is paired in a working protection scheme, has DCC communications turned on, or is used as a timing reference, then CTC will not allow you to delete the card.

Step 6 If the card is in-service, take the facility out of service:



Caution Before taking the facility out of service, ensure that no live traffic exists on the facility.

- a. Double-click the reporting card to display the card view.
- b. Click the **Provisioning** tab.
- c. Click the **Status** of any in-service ports.
- d. Choose **Out of Service** to take the ports out of service.

Step 7 If a circuit has been mapped to the card, delete the circuit:



Caution Before deleting the circuit, ensure that no live traffic exists on the facility.

- a. On the node view, click the **Circuits** tab.
- b. Choose the applicable circuit (the one that connects to the reporting card).
- c. Click **Delete**.

Step 8 If the card is paired in a protection scheme, delete the protection group:

- a. Click the **Provisioning > Protection** tabs.
- b. Choose the protection group of the reporting card.
- c. Click **Delete**.

Step 9 Right-click the card reporting the IMPROPRMVL.

Step 10 Choose **Delete**.

1.3.87 MEM-GONE

- Major, Non-service affecting

The Memory Gone alarm occurs when data generated by software operations exceeds the memory capacity of the TCC+ card. CTC will not function properly until this alarm clears. The alarm clears when additional memory becomes available.

Log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center to report a service-affecting problem (1-877-323-7368).

1.3.88 MEM-LOW

- Minor, Non-service affecting

The Memory Low alarm occurs when data generated by software operations is close to exceeding the memory capacity of the TCC+ card. The alarm clears when additional memory becomes available. If additional memory is not made available and the memory capacity of the TCC+ card is exceeded, CTC will cease to function.

Log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center to report a service-affecting problem (1-877-323-7368).

1.3.89 MFGMEM

- Critical, Service Affecting

The MFGMEM or Manufacturing Data Memory Failure alarm raises if the ONS 15454 cannot access the data in the erasable programmable read-only memory (EPROM). Either the memory module on the component failed or the TCC+ lost the ability to read that module. The EPROM stores manufacturing data that is needed for both compatibility and inventory issues. The EPROM on the alarm interface panel (AIP) also stores the MAC address. An inability to read a valid MAC address will disrupt IP connectivity and gray out the ONS 15454 icon on the CTC network view.

Procedure: Clear the MFGMEM Alarm on the AIP, Fan Tray, or Backplane.

-
- Step 1** Do a software-initiated system reset on the TCC+ by referring to the “Perform a Software-Initiated Reset” procedure on page 3-8.
- Step 2** If the alarm does not clear, do a card pull reset on the TCC+ by referring to the “Perform a Card Pull” procedure on page 3-9.
- Step 3** If the alarm does not clear, physically replace the standby TCC+ card on the ONS 15454 with a new TCC+ card.
- Open the TCC+ card ejectors.
 - Slide the card out of the slot. This raises the IMPROPRMVL alarm which will clear when the upgrade is complete.
 - Open the ejectors on the TCC+ card.
 - Slide the TCC+ card into the slot along the guide rails.
 - Close the ejectors.



Note It takes approximately 20 minutes for the active TCC+ to transfer the system software to the newly-installed TCC+. Software transfer occurs in instances where different software versions exist on the two cards. During this operation, the LEDs on the TCC+ flash Fail and then the Active/Standby LED flashes. When the transfer completes, the TCC+ reboots and goes into Standby mode after approximately three minutes.

- Step 4** Right click the active TCC+ card to reveal a pull-down menu.
- Step 5** Click **Reset Card**.
- Wait for the TCC+ to reboot. The ONS 15454 switches the standby TCC+ card to active mode.
- Step 6** Verify that the remaining TCC+ card is now in standby mode (the ACT/STBY LED changes to amber).

Step 7 Physically replace the remaining TCC+ card with the second TCC+ card.

- a. Open the TCC+ card ejectors.
- b. Slide the card out of the slot.
- c. Open the ejectors on the TCC+ card.
- d. Slide the TCC+ card into the slot along the guide rails.
- e. Close the ejectors.

The ONS 15454 boots up the second TCC+ card. The second TCC+ must also copy the system software, which can take up to twenty minutes.

Step 8 If the MFGMEM alarm continues to report after replacing the TCC+ cards, the problem lies in the EPROM.

Step 9 If the MFGMEM is reported from the fan tray, replace the fan tray.

Step 10 If the MFGMEM is reported from the AIP, the backplane, or the alarm persists after the fan tray is replaced, log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center (1-877-323-7368).

1.3.90 NOT-AUTHENTICATED

- Minor, Non-service affecting

This alarm indicates that the username and password entered do not match the information stored in the TCC+. All ONS nodes must have the same username and password created to display every ONS node in the network. You can also be locked out of certain ONS nodes on a network if your username and password were not created on those specific ONS nodes.



Note

For initial log on to the ONS 15454, type the user name `CISCO15` and click **Login** (no password is required).

Procedure: Clear the NOT-AUTHENTICATED Alarm on the TCC+ Card

Step 1 If you have an alternate username and a password available to access the system:

- a. Use the alternate username and password to access the ONS node.
- b. Click the **Provisioning > Security** tabs.
- c. Look under the Users field to find the username that raised the alarm.
- d. If the username that raised the alarm is listed, then highlight the username to reveal the associated password. Record the correct password.
- e. If the username is not listed, then click **Create**.
- f. Fill in the fields on the Create User dialog box with the username and password that raised the alarm then click **OK**.

Step 2 If you do not have an alternate username and password available, call the Cisco Technical Assistance Center at (1-877-323-7368). TAC can issue a new username and password.

1.3.91 PDI-P

- Not Alarmed (NA) (Condition)

A Payload Defect Indication Path alarm indicates a signal label mismatch failure (SLMF). An invalid C2 byte in the SONET path overhead causes an SLMF. The C2 byte is the signal label byte. This byte tells the equipment what the SONET payload envelope contains and how it is constructed. It enables a SONET device to transport multiple types of services.

The ONS 15454 encounters an SLMF when the payload, such as an ATM, does not match what the signal label is reporting. An AIS alarm often accompanies the PDI-P alarm. If the PDI-P is the only alarm reported with the AIS, clear the PDI-P alarm to clear the AIS alarm. PDI-P can also occur during an upgrade, but usually clears itself and is not a valid alarm.



Warning

Invisible laser radiation may be emitted from the aperture ports of the single-mode fiber optic modules when no cable is connected. Avoid exposure and do not stare into open apertures.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the PDI-P Alarm Reported on the DS-3, DS-3E, DS3XM-6 or DS-1 Card

- Step 1** Verify that all circuits terminating in the reporting card are in an active state:
- Click the **Circuits** tab.
 - Verify that the State column lists the port as ACTIVE.
 - If the State column lists the port as INCOMPLETE, wait 10 minutes for the ONS 15454 to fully initialize. If INCOMPLETE does not change after full initialization, log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center to report a service-affecting problem (1-877-323-7368).
- Step 2** After determining that the port is active, verify the signal source to the card reporting the alarm.
- Step 3** If traffic is affected, delete and recreate the circuit.



Caution Deleting a circuit may affect traffic.

- Step 4** Check the far-end OC-N card that provides STS payload to the reporting card.
- Step 5** Confirm the cross-connect between the OC-N card and the reporting card.
- Step 6** Clean the far-end optical fiber:
- Clean the fiber according to local site practice.
 - If no local practice exists, use a CLETOP Real-Type or equivalent fiber-optic cleaner and follow the instructions accompanying the product.
- Step 7** Replace the optical/electrical cards.

**Note**

When you replace a card with an identical type of card, you do not need to make any changes to the database.

1.3.92 PEER-NORESPONSE

- Major, Non-service affecting

The switch agent raises a Peer Card Not Responding alarm if either traffic card in a protection group does not receive a response to the peer status request message. This is a software failure and occurs at the task level, as opposed to a communication failure, which is a hardware failure between peer cards.

Procedure: Clear the PEER-NORESPONSE Alarm Reported on DS-N, OC-N or EC1 Card

-
- Step 1** Right click on the card reporting the alarm.
- Step 2** Click **Reset Card** and **OK** on the confirmation dialog.
- Step 3** Wait for the card to reset.
- Step 4** At reset, the green Act LED on the card will be replaced on the CTC by a white Ldg LED. When the card finishes resetting, the green Act LED will reappear.
- Step 5** Right click on the peer card of the card reporting the alarm.
- Step 6** Click **Reset Card** and **OK** on the confirmation dialog.
-

1.3.93 PLM-P

- Critical, Service affecting

A Payload Label Mismatch Path indicates a Signal Label Mismatch Failure (SLMF). An invalid C2 byte in the SONET path overhead causes an SLMF. The C2 byte is the signal label byte. This byte tells the equipment what the SONET payload envelope contains and how it is constructed. It enables a SONET device to transport multiple types of services.

The ONS 15454 encounters an SLMF when the payload, such as a DS-3 signal, does not match what the signal label is reporting. An AIS alarm often accompanies the PLM-P alarm. If the PLM-P is the only alarm reported with the AIS, clearing the PLM-P alarm clears the AIS alarm.

**Warning**

Invisible laser radiation may be emitted from the aperture ports of the single-mode fiber optic modules when no cable is connected. Avoid exposure and do not stare into open apertures.

**Caution**

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the PLM-P Alarm Reported on the DS-N Card

-
- Step 1** Verify that all circuits terminating in the reporting card are active:
- Click the **Circuits** tab.
 - Verify that the State column lists the port as ACTIVE.
 - If the State column lists the port as INCOMPLETE, wait 10 minutes for the ONS 15454 to fully initialize. If INCOMPLETE does not change after full initialization, log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center to report a service-affecting problem (1-877-323-7368).
- Step 2** After determining the port is active, verify the signal source to the traffic card reporting the alarm.
- Step 3** If traffic is being affected, delete and recreate the circuit.



Caution Deleting a circuit may affect traffic.

- Step 4** Check the far-end OC-N card that provides STS payload to the DS-N card.
- Step 5** Verify the cross-connect between the OC-N card and the DS-N card.
- Step 6** Clean the far-end optical fiber:
- Clean the fiber according to local site practice.
 - If no local practice exists, use a CLETOP Real-Type or equivalent fiber-optic cleaner and follow the instructions accompanying the product.
- Step 7** Replace the OC-N/DS-N cards.



Note When you replace a card with an identical type of card, you do not need to make any changes to the database.

1.3.94 PLM-V

- Minor, Service affecting

A VT Payload Label Mismatch indicates that the content of the V5 byte in the SONET overhead is inconsistent or invalid. This alarm occurs when ONS nodes interoperate with equipment that performs bit-synchronous mapping for DS-1. ONS nodes use asynchronous mapping.

Procedure: Clear the PLM-V Alarm on the DS-1 or DS3XM-6 Card

-
- Step 1** Verify that your signal source matches the signal allowed by the traffic card. For example, the traffic card does not allow VT6 or VT9 mapping.
- Step 2** Verify that the SONET VT path originator is sending the correct VT label value. You can find the SONET VT path originator using circuit provisioning steps.
-

1.3.95 PRC-DUPID

- Major, Service affecting

The PRC-DUPID alarm indicates that two identical node IDs exist in the same ring. The ONS 15454 requires each node in the ring to have a unique node ID.

Procedure: Clear the PRC-DUPID Alarm on an OC-N Card in a BLSR

-
- Step 1** Find the nodes with identical node IDs.
- Log into a node on the ring.
 - Click the **Provisioning > Ring** tabs.
 - Record the Node ID number.
 - Repeat steps a – c for all nodes in the ring.
- Step 2** If two nodes have an identical node ID number, change the node ID number of one node.
- Log into a node that has an identical node ID number.
 - Click the **Provisioning > Ring** tabs.
 - Change the number in the Node ID field to a unique number between 0 and 31.
 - Click **Apply**.
-

1.3.96 PWRRESTART

- Not Alarmed (NA) (Condition)

A Power Fail Restart is a cold boot of the reporting card. This alarm can occur when you physically remove and insert a card, power up an ONS 15454, or replace a card.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the PWRRESTART Condition

-
- Step 1** If the alarm fails to clear after the card reboots, physically reseal the card.
- Step 2** If the alarm still fails to clear, replace the card.



Note

When you replace a card with an identical type of card, you do not need to make any changes to the database.

1.3.97 RAI

- Not Alarmed (NA) (Condition)

Remote Alarm Indication signifies an end-to-end failure. The error condition is sent from one end of the SONET path to the other.

RAI on the DS3XM-6 card indicates that far-end node is receiving a DS-3 AIS.

Procedure: Clear the RAI Condition on DS3XM-6 or DS3E Cards in C-bit Format

Use the AIS procedure to troubleshoot the far-end DS-3 node for RAI.

1.3.98 RCVR-MISS

- Major, Service affecting

A Missing Receiver alarm occurs when facility termination equipment detects a missing receive cable on the DS-1 port or a possible mismatch of backplane equipment, for example, an SMB connector or a BNC connector is connected to a DS-1 card.



Note

DS-1s are four-wire circuits and need a positive (tip) and negative (ring) connection for both transmit and receive.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the RCVR-MISS Alarm on the DS-1 Port

-
- Step 1** Ensure that the device attached to the DS-1 port is operational.
 - Step 2** Verify that the cabling is securely connected.
 - Step 3** Verify that the pinouts are correct.
 - Step 4** Replace the receive cable if Steps 1 – 3 do not clear the alarm.
-

1.3.99 RFI-L

- Not reported

A Remote Fault Indication alarm occurs when the ONS 15454 detects a remote fault indication (RFI) in the SONET overhead because of a fault in another node. Resolving the fault in the adjoining node clears the RFI-L alarm in the reporting node.

RFI-L indicates that the alarm is occurring at the line level. The line layer is the segment between two SONET devices in the circuit and is also known as a maintenance span. The line layer deals with SONET payload transport. The line layer functions include multiplexing and synchronization.

Procedure: Clear the RFI-L Condition on the OC-N or EC-1 Card

-
- Step 1** Log into the far-end node from the reporting ONS 15454.
 - Step 2** Check for alarms in the far-end node, especially LOS.
 - Step 3** Resolve alarms in the far-end node.
-

1.3.100 RFI-P

- Not reported

A Remote Failure Indication Path alarm occurs when the ONS 15454 detects an RFI in the SONET overhead because of a fault in another node. Resolving the fault in the adjoining node clears the RFI-P alarm in the reporting node.

RFI-P occurs in the node that terminates a path. The path layer is the segment between the originating equipment and the terminating equipment. This segment may encompass several consecutive line segments. The originating equipment puts bits together into a SONET payload and the terminating equipment breaks the bits apart again. SONET multiplexers, such as the ONS 15454, often perform the origination and termination tasks of the SONET payload.

An RFI-P error message on the ONS 15454 indicates that the node reporting the RFI-P is the terminating node on that path segment.

Procedure: Clear the RFI-P Condition on the DS-N or Ethernet Card

-
- Step 1** Verify that the ports are enabled and in-service on the reporting ONS 15454.
 - Step 2** To find the path and node failure, verify the integrity of the SONET STS circuit path at each of the intermediate SONET nodes.
 - Step 3** Check for alarms in the node with the failure, especially UNEQ-P or UNEQ-V.
 - Step 4** Resolve alarms in that node.
-

1.3.101 RFI-V

- Not reported

A Remote Fault Indication VT alarm occurs when the ONS 15454 detects an RFI in the SONET overhead because of a fault in another node. Resolving the fault in the adjoining node clears the RFI-V alarm in the reporting node.

RFI-V indicates that an upstream failure has occurred at the VT layer. The VT (electrical) layer is created when the SONET signal is broken down into an electrical signal, for example when an optical signal comes into an ONS 15454. If this optical signal is demultiplexed and one of the channels separated from the optical signal is cross connected into the DS-1 port in the ONS 15454, the ONS 15454 reports an RFI-V alarm.

**Caution**

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the RFI-V Condition on the DS3XM-6 or DS-1 Card

-
- Step 1** Check connectors to ensure they are securely fastened and connected to the correct slot/port.
 - Step 2** Verify that the DS-1 port is active and in-service.
 - Step 3** Check the signal source for errors.
 - Step 4** Log into the far-end node from the reporting ONS 15454.
 - Step 5** Check for alarms in the far-end node, especially UNEQ-P or UNEQ-V.
 - Step 6** Find and troubleshoot the far-end node alarms.
-

1.3.102 RING-MISMATCH

- Major, Service affecting

A Procedural Error Mismatch Ring alarm occurs when the Ring ID of the ONS 15454 that is reporting the alarm does not match the Ring ID of another ONS node in the BLSR. ONS nodes connected in a BLSR must have identical Ring IDs to function.

Procedure: Clear the RING-MISMATCH Alarm

-
- Step 1** Click the **Provisioning > Ring** tabs.
 - Step 2** Note the number in the Ring ID field.
 - Step 3** Log into the next ONS node in the BLSR.
 - Step 4** Verify that the Ring ID number matches the Ring ID number of the reporting node.
 - a. If the Ring ID matches the Ring ID in the reporting ONS node, log into the next ONS node in the BLSR.
 - b. If the Ring ID does not match the Ring ID in the reporting ONS node, change the Ring ID to match the Ring ID of the reporting node and click **Apply**.
 - c. Click **Yes** on the Accept Ring Map Changes dialog box.
 - d. Verify that the ring map is correct.
 - e. Click **Accept** for the new BLSR Ring Map.

Step 5 Repeat Step 4 for all ONS nodes in the BLSR.

1.3.103 SD-L

- Not Alarmed (NA) (Condition)

Signal Degrade occurs when the quality of the signal is so poor that the bit error rate (BER) on the incoming optical line passed the signal degrade (SD) threshold. The ONS 15454 sets the BER threshold for SD from 10^{-9} to 10^{-5} . Signal degrade is defined by Telcordia as a “soft failure” condition. SD and signal fail (SF) both monitor the incoming BER and are similar alarms, but SD is triggered at a lower bit error rate than SF. SD causes the card to switch from working to protect.

SD-L causes a switch from the working card to the protect card at the line (facility) level. A line or facility level SD alarm travels on the B2 byte of the SONET overhead.

The SD alarm clears when the BER level falls to one-tenth of the threshold level that triggered the alarm. A BER increase is sometimes caused by a physical fiber problem, including a poor fiber connection, a bend in the fiber that exceeds the permitted bend radius, or a bad fiber splice.



Warning

Invisible laser radiation may be emitted from the aperture ports of the single-mode fiber optic modules when no cable is connected. Avoid exposure and do not stare into open apertures.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the SD-L Condition on an OC-N Card

- Step 1** With an optical test set, measure the power level of the line to ensure it is within guidelines.
- Step 2** Verify that optical receive levels are within the acceptable range.
- Step 3** Clean the fibers at both ends for a line signal degrade:
- Clean the fiber according to local site practice.
 - If no local practice exists, use a CLETOP Real-Type or equivalent fiber-optic cleaner and follow the instructions accompanying the product.
- Step 4** Verify that single-mode fiber is used.
- Step 5** Verify that a single-mode laser is used at the far end.
- Step 6** If the problem persists, the transmitter at the other end of the optical line may be failing and require replacement.
-

1.3.104 SD-P

- Not Alarmed (NA) (Condition)

The quality of the signal is so poor that the bit error rate (BER) on the incoming optical line passed the signal degrade (SD) threshold. The ONS 15454 sets the BER threshold for SD from 10^{-9} to 10^{-5} . Signal degrade is defined by Telcordia as a “soft failure” condition. SD and signal fail (SF) both monitor the incoming BER and are similar alarms, but SD is triggered at a lower bit error rate than SF. SD causes the card to switch from working to protect.

SD-P causes a switch from the working card to the protect card at the path (STS) level. A path or STS level SD alarm travels on the B3 byte of the SONET overhead. The ONS 15454 detects path SD on the STS level, not the VT level.

The SD alarm clears when the BER level falls to one-tenth of the threshold level that triggered the alarm. A BER increase is sometimes caused by a physical fiber problem, including a poor fiber connection, a bend in the fiber that exceeds the permitted bend radius, or a bad fiber splice.



Warning

Invisible laser radiation may be emitted from the aperture ports of the single-mode fiber optic modules when no cable is connected. Avoid exposure and do not stare into open apertures.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the SD-P Condition on an OC-N Card

-
- Step 1** With an optical test set, measure the power level of the line to ensure it is within guidelines.
 - Step 2** Verify that optical receive levels are within the acceptable range.
 - Step 3** Verify that single-mode fiber is being used.
 - Step 4** Verify that a single-mode laser is being used at the far end.
 - Step 5** If the problem persists, the transmitter at the other end of the optical line may be failing and require replacement.
-

1.3.105 SF-L

- Not Alarmed (NA) (Condition)

A Signal Failure occurs when the quality of the signal is so poor that the BER on the incoming optical line passed the signal failure (SF) threshold. The ONS 15454 sets the BER threshold for SF from 10^{-5} to 10^{-3} . Signal failure is defined by Telcordia as a “hard failure” condition. SD and SF both monitor the incoming BER error rate and are similar alarms, but SF is triggered at a higher BER than SD.

SF-L causes a switch from the working card to the protect card at the line (facility) level. A line or facility level SF alarm travels on the B2 byte of the SONET overhead.

SF causes a card to switch from working to protect at either the path or line level. The SF alarm clears when the BER level falls to one-tenth of the threshold level that triggered the alarm. A BER increase is sometimes caused by a physical fiber problem, including a poor fiber connection, a bend in the fiber that exceeds the permitted bend radius, or a bad fiber splice.

**Warning**

Invisible laser radiation may be emitted from the aperture ports of the single-mode fiber optic modules when no cable is connected. Avoid exposure and do not stare into open apertures.

**Caution**

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the SF-L Condition on an OC-N Card

-
- Step 1** Using an optical test set, measure the power level of the line and ensure it is within the guidelines.
- Step 2** Verify that optical receive levels are within the acceptable range.
- Step 3** Clean the fibers at both ends for a line signal fail:
- a. Clean the fiber according to local site practice.
 - b. If no local practice exists, use a CLETOP Real-Type or equivalent fiber-optic cleaner and follow the instructions accompanying the product.
- Step 4** Verify that single-mode fiber is being used.
- Step 5** Verify that a single-mode laser is being used at the far-end node.
- Step 6** If the problem persists, the transmitter at the other end of the optical line may be failing and need replacement.
-

1.3.106 SF-P

- Not Alarmed (NA) (Condition)

The quality of the signal is so poor that the BER on the incoming optical line passed the signal failure (SF) threshold. The ONS 15454 sets the BER threshold for SF from 10^{-5} to 10^{-3} . Signal failure is defined by Telcordia as a “hard failure” condition. SD and SF both monitor the incoming BER error rate and are similar alarms, but SF is triggered at a higher BER than SD.

SF-P causes a switch from the working card to the protect card at the path (STS) level. A path or STS level SF alarm travels on the B3 byte of the SONET overhead. The ONS 15454 detects path SF on the STS level, not the VT level.

SF causes a card to switch from working to protect at either the path or line level. The SF alarm clears when the BER level falls to one-tenth of the threshold level that triggered the alarm. A BER increase is sometimes caused by a physical fiber problem, including a poor fiber connection, a bend in the fiber that exceeds the permitted bend radius, or a bad fiber splice.

Invisible laser radiation may be emitted from the aperture ports of the single-mode fiber optic modules when no cable is connected. Avoid exposure and do not stare into open apertures.

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the SF-P Condition on an OC-N Card

-
- Step 1** Using an optical test set, measure the power level of the line and ensure it is within the guidelines.
 - Step 2** Verify that optical receive levels are within the acceptable range.
 - Step 3** Verify that single-mode fiber is being used.
 - Step 4** Verify that a single-mode laser is being used at the far-end node.
 - Step 5** If the problem persists, the transmitter at the other end of the optical line may be failing and need replacement.
-

1.3.107 SFTWDOWN

- Minor, Non-service affecting

TCC+ is downloading or transferring software. No action is necessary. Wait for the transfer or the software download to complete.

1.3.108 SFTWDOWN-FAIL

- Minor, Non-service affecting

The software download from the TCC+ card to the ONS 15454 failed. The problem lies in the TCC+ card.

Procedure: Clear the SFTWDOWN-FAIL Alarm on the TCC+ Card

-
- Step 1** Attempt the download again by clicking the **Maintenance > Software** tabs and the **Download** button.
 - Step 2** If the download fails, reset the active TCC+:
 - a. Right-click on the TCC+.
 - b. Select **Reset Card** from the pull-down menu.
 - Step 3** Attempt the download again by clicking the **Maintenance > Software** tabs and the **Download** button.
 - Step 4** If the download is successful, replace the standby TCC+.
 - Step 5** If the download fails again, replace the active TCC+.



Note When you replace a card with an identical type of card, you do not need to make any changes to the database.

- Step 6** Attempt the download again by clicking the **Maintenance > Software** tabs and the **Download** button.
 - Step 7** If the download fails again, log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center to report a service-affecting problem (1-877-323-7368).
-

1.3.109 SQUELCH

- Not Alarmed, Non-service affecting

The Squelch alarm occurs in a BLSR when a node that originates or terminates STS circuits fails or is isolated by multiple fiber cuts. The isolation or failure of the node will disable the circuits that originate or terminate on the failed node. Squelch alarms appear on one or both of the nodes on either side of the isolated/failed node. The AIS-P alarm will also appear on all nodes in the ring, except the isolated node.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.



Warning

Invisible laser radiation may be emitted from the aperture ports of the single-mode fiber optic modules when no cable is connected. Avoid exposure and do not stare into open apertures.



Warning

On the OC-192 card, the laser is on when the card is booted and the safety key is in the on position (labeled 1). The port does not have to be in service for the laser to be on. The laser is off when the safety key is off (labeled 0).



Warning

Invisible laser radiation may be emitted from the end of the unterminated fiber cable or connector. Do not stare into the beam directly with optical instruments. Viewing the laser output with certain optical instruments (for example, eye loupes, magnifiers, and microscopes) within a distance of 100 mm may pose an eye hazard. Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.

Procedure: Clear the SQUELCH Condition

-
- Step 1** Determine the isolated node:
 - a. Display the CTC network view.
 - b. The grayed out node with red spans will be the isolated node.
 - Step 2** Verify fiber continuity to the ports on the isolated node.
 - Step 3** Verify that the proper ports are in service.
 - Step 4** Use an optical test set to verify that a valid signal exists on the line.
Test the line as close to the receiving card as possible.
 - Step 5** Verify that the power level of the optical signal is within the optical card's receiver specifications. Each individual card section in Chapter 4 lists the receiver specifications for that card.
 - Step 6** Ensure that the optical transmits and receives are connected properly.
 - Step 7** Replace the OC-N card.
-

1.3.110 SSM-FAIL

- Minor, Non-service affecting

The SSM-FAIL alarm means the synchronization status messaging (SSM) received by the ONS 15454 failed. The problem is external to ONS 15454. The ONS 15454 is set up to receive SSM, but the timing source is not delivering valid SSM messages.

SSM is a SONET protocol that communicates information about the quality of the timing source. SSM messages are carried on the S1 byte of the SONET line layer. They enable SONET devices to automatically select the highest quality timing reference and to avoid timing loops.

Procedure: Clear the SSM-FAIL Alarm

-
- Step 1** Check that SSM is enabled on the external timing source.
- Step 2** Use a test set to determine that the external timing source is delivering SSM.
-

1.3.111 STU

- Not Alarmed (NA) (Condition)

The Synchronization Traceability Unknown alarm occurs when the reporting node is timed to a reference that does not support synchronization status messaging (SSM), but the ONS 15454 has SSM support enabled. STU can also be raised if the timing source is sending out SSM messages but SSM is not enabled on the ONS 15454.

SSM is a SONET protocol that communicates information about the quality of the timing source. SSM messages are carried on the S1 byte of the SONET line layer. SSM enables SONET devices to automatically choose the highest quality timing reference and to avoid timing loops.

Procedure: Clear the STU Condition

-
- Step 1** Click the **Provisioning > Timing** tabs.
- Step 2** If **Sync Messaging** is checked, uncheck the box.
- Step 3** If **Sync Messaging** is unchecked, check the box.
- Step 4** Click **Apply**.
-

1.3.112 SWTOPRI

- Not Alarmed (NA) (Condition)

The Switch to Primary occurs when the ONS 15454 switches to the primary timing source (reference 1). The ONS 15454 uses three ranked timing references. The timing references are typically two BITS-level or line-level sources and an internal reference.

**Note**

This is a condition and not an alarm. It is for information only and does not require troubleshooting.

1.3.113 SWTOSEC

- Not Alarmed (NA) (Condition)

The Switch to Secondary occurs when the ONS 15454 has switched to the secondary timing source (reference 2). The ONS 15454 uses three ranked timing references. The timing references are typically two BITS-level or line-level sources and an internal reference.

Procedure: Clear the SWTOSEC Alarm

Find and troubleshoot alarms related to failures of the primary source, such as the SYNCPRI alarm.

1.3.114 SWTOTHIRD

- Not Alarmed (NA) (Condition)

The Switch to Third occurs when the ONS 15454 has switched to the third timing source (reference 3). The ONS 15454 uses three ranked timing references. The timing references are typically two BITS-level or line-level sources and an internal reference.

Procedure: Clear the SWTOTHIRD Alarm

Find and troubleshoot alarms related to failures of the primary and secondary reference source, such as the SYNCPRI and SYNCSEC alarms.

1.3.115 SYNCPRI

- Minor, Non-service affecting

A Loss of Timing on Primary Reference alarm occurs when the ONS 15454 loses the primary timing source (reference 1). The ONS 15454 uses three ranking timing references. The timing references are typically two BITS-level or line-level sources and an internal reference. If SYNCPRI occurs, the ONS 15454 should switch to its secondary timing source (reference 2). This switch also triggers the SWTOSEC alarm.

Procedure: Clear the SYNCPRI Alarm on the TCC+ Card

-
- Step 1** From the node view, click the **Provisioning > Timing** tabs.
- Step 2** Check the current configuration for the REF-1 of the NE Reference.
- Step 3** If the primary reference is a BITS input, follow the procedure in the “LOS (BITS)” section on page 1-54.
- Step 4** If the primary reference clock is an incoming port on the ONS 15454, follow the procedure in the “LOS (OC-N)” section on page 1-54.
-

1.3.116 SYNCSEC

- Minor, Non-service affecting

A Loss of Timing on Secondary Reference alarm occurs when the ONS 15454 loses the secondary timing source (reference 2). The ONS 15454 uses three ranked timing references. The timing references are typically two BITS-level or line-level sources and an internal reference. If SYNCSEC occurs, the ONS 15454 should switch to the third timing source (reference 3) to obtain valid timing for the ONS 15454. This switch also triggers the SWTOTHIRD alarm.

Procedure: Clear the SYNCSEC Alarm on the TCC+ Card

-
- Step 1** From the node view, click the **Provisioning > Timing** tabs.
- Step 2** Check the current configuration of the REF-2 for the NE Reference.
- Step 3** If the secondary reference is a BITS input, follow the procedure in the “LOS (BITS)” section on page 1-54.
- Step 4** If the secondary timing source is an incoming port on the ONS 15454, follow the procedure in the “LOS (OC-N)” section on page 1-54.
-

1.3.117 SYNCTHIRD

- Minor, Non-service affecting

A Loss of Timing on Third Reference alarm occurs when the ONS 15454 loses the third timing source (reference 3). The ONS 15454 uses three ranking timing references. The timing references are typically two BITS-level or line-level sources and an internal reference. If SYNCTHIRD occurs and the ONS 15454 uses an internal reference for source three, then the TCC+ card may have failed. The ONS 15454 often reports either FRNGSYNC or HLDOVERSYNC alarms after a SYNCTHIRD alarm.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the SYNCTHIRD Alarm on the TCC+ Card

-
- Step 1** From node view, click the **Provisioning > Timing** tabs.
- Step 2** Check the current configuration of the REF-3 for the NE Reference.
- Step 3** If the third timing source is a BITS input, follow the procedure in the “LOS (BITS)” section on page 1-54.
- Step 4** If the third timing source is an incoming port on the ONS 15454, follow the procedure in the “LOS (OC-N)” section on page 1-54.
- Step 5** If the third timing source uses the internal ONS 15454 timing, perform a software reset on the TCC+ card:
- a. Display the CTC node view.

- b. Position the cursor over the slot reporting the alarm.
- c. Right-click and choose **RESET CARD**.

Step 6 If this fails to clear the alarm, physically reseal the TCC+ card.

Step 7 If the reset fails to clear the alarm, replace the TCC+ card.



Note When you replace a card with an identical type of card, you do not need to make any changes to the database.

1.3.118 SYSBOOT

- Major, Service affecting

This alarm indicates that new software is booting on the TCC+ card. This is an informational alarm. No action is required. The alarm clears when all cards finish rebooting the new software. The reboot takes up to 30 minutes.

1.3.119 TIM-P

- Minor, Service affecting

The STS Path Trace Identifier Mismatch Path alarm occurs when the expected path trace string does not match the received path trace string. Path Trace Mode must be set to manual or Auto for this alarm to occur.

In manual mode at the Path Trace screen, the user types the expected string into the New Expected String field for the receiving port. This string must match the string typed into the New Transmit String field for the sending port. If these fields do not match, the TIM-P alarm will occur. In Auto mode on the receiving port, the card sets the expected string to the value of the received string. If the alarm occurs on a port that has been operating with no alarms, this means the circuit path changed or someone typed and entered a new incorrect value into the New Transmit String field. Follow the procedure below to clear either instance.

This alarm also occurs on a port that has previously been operating without alarms if someone switches or removes the DS-3 cables or optical fibers that connect the ports. This TIM-P occurrence is usually accompanied by other alarms, such as LOS, UNEQ-P, or PLM-P. In this case, reattach or replace the original cables/fibers to clear the alarm.

Procedure: Clear the TIM-P Alarm

-
- Step 1** Log into the circuit source node and select the **Circuits** tab.
 - Step 2** Select the circuit reporting the alarm, then click **Edit**.
 - Step 3** At the bottom of the Edit Circuit window, check the **Show Detailed Map** box.
 - Step 4** On the detailed circuit map, right-click the source circuit port and select **Edit Path Trace** from the shortcut menu.

- Step 5** On the detailed circuit map, right click the drop/destination circuit port and select **Edit Path Trace** from the shortcut menu.
- Step 6** Compare the New Transmit String and the New Expected String entries in the Path Trace Mode dialog box.
- Step 7** If the strings differ, correct the Transmit or Expected strings and click **Apply**.
- Step 8** Click **Close**.
-

1.3.120 TRMT

- Major, Service affecting

A TRANSMIT alarm occurs when there is a transmit failure on the DS-1 card because of an internal hardware failure. The card must be replaced.

Procedure: Clear the TRMT Alarm on the DS-1 Card

- Step 1** Replace the DS-1 card reporting the failure.



Note When you replace a card with an identical type of card, you do not need to make any changes to the database.

- Step 2** Call the Technical Assistance Center (TAC) at 1-877-323-7368 to discuss the failed card and possibly open a returned materials authorization (RMA).
-

1.3.121 TRMT-MISS

- Major, Service affecting

A Transmit Missing alarm occurs when the facility termination equipment detects an incorrect amount of impedance on its backplane connector. This means transmit cable is missing on the DS-1 port or the backplane does not match the inserted card; for example, an SMB connector or a BNC connector connects to a DS-1 card instead of a DS-3 card.



Note DS-1s are four-wire circuits and need a positive and negative connection for both transmit and receive.

Procedure: Clear the TRMT-MISS Alarm

- Step 1** Check that the device attached to the DS-1 port is operational.
- Step 2** Verify that the cabling is securely connected.
- Step 3** Verify that the pinouts are correct.

Step 4 If Steps 1 – 3 do not clear the alarm, replace the transmit cable,.

1.3.122 UNEQ-P

- Major, Service affecting

An Unequipped Path Alarm occurs when the path does not have a valid sender. The UNEQ-P indicator is carried in the C2 signal path byte in the SONET overhead. The source of the problem is the node that is transmitting the signal into the node reporting the UNEQ-P.

UNEQ-P occurs in the node that terminates a path. The path layer is the segment between the originating equipment and the terminating equipment. This segment can encompass several consecutive line segments. The originating equipment puts bits together into a SONET payload and the terminating equipment breaks the bits apart again. SONET multiplexers, such as the ONS 15454, often perform the origination and termination tasks of the SONET payload.

A UNEQ-P error message on the ONS 15454 indicates that the node reporting the RFI-P is the terminating node on that path segment.



Note

If you have created a new circuit but it has no signal, an UNEQ-P alarm is reported on the OC-N cards and an AIS-P alarm is reported on the terminating cards. These alarms clear when the circuit carries a signal.



Caution

Deleting a circuit affects traffic.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the UNEQ-P Alarm on the Line Card

- Step 1** Display the network view and right-click the span reporting SLMF.
- Step 2** Select **Circuits** from the menu.
- Step 3** If the specified circuit is a VT tunnel, check for VTs assigned to the VT tunnel.
- Step 4** If the VT tunnel has no assigned VTs, delete the VT tunnel from the list of circuits.
- Step 5** If you have complete visibility to all nodes, check for incomplete circuits such as stranded bandwidth from circuits that were not deleted completely.
- Step 6** If you find incomplete circuits, verify whether they are working circuits and if they are still passing traffic.
- Step 7** If the incomplete circuits are not needed or are not passing traffic, delete them and log out of CTC. Log back in and check for incomplete circuits again. Recreate any needed circuits.
- Step 8** Verify that all circuits terminating in the reporting card are active:
 - a. Click the **Circuits** tab.

- b. Verify that the State column lists the port as ACTIVE.
 - c. If the State column lists the port as INCOMPLETE. If INCOMPLETE does not change after a full initialization, log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center to report a service-affecting problem (1-877-323-7368).
- Step 9** After you determine that the port is active, verify the signal source received by the card reporting the alarm.
- Step 10** Check the far-end OC-N card that provides STS payload to the card.
- Step 11** Verify the far-end cross-connect between the OC-N card and the DS-N card.
- Step 12** Clean the far-end optical fiber:
- a. Clean the fiber according to local site practice.
 - b. If no local practice exists, use a CLETOP Real-Type or equivalent fiber-optic cleaner and follow the instructions accompanying the product.

1.3.123 UNEQ-V

- Major, Service affecting

An Unequipped VT alarm indicates that the node is receiving SONET path overhead with bits 5, 6, and 7 of the V5 overhead byte all set to zeroes. The source of the problem is the node that is transmitting the VT-level signal into the node reporting the UNEQ-P. The problem node is the next node upstream that processes the signal at the VT level.

The V in UNEQ-V indicates that the failure has occurred at the VT layer. The VT (electrical) layer is created when the SONET signal is broken down into an electrical signal, for example, when an optical signal comes into an ONS 15454, the optical signal is demultiplexed and one of the channels separated from the optical signal is cross connected into an ONS 15454 cross-connect (XC/XCVT/XC10G) card and the corresponding DS-N card.



Warning

Invisible laser radiation may be emitted from the aperture ports of the single-mode fiber optic modules when no cable is connected. Avoid exposure and do not stare into open apertures.



Caution

Always use the supplied electrostatic discharge wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.

Procedure: Clear the UNEQ-V Alarm on the DS-1 and DS3XM-6 Card

- Step 1** Verify that all circuits terminating in the reporting card are active:
- a. Click the **Circuits** tab.
 - b. Verify that the State column lists the port as ACTIVE.
 - c. If the State column lists the port as INCOMPLETE. If INCOMPLETE does not change after full initialization, log on to <http://www.cisco.com/tac> for more information or call the Cisco Technical Assistance Center to report a service-affecting problem (1-877-323-7368).

Step 2 After you determine that the port is active, verify the signal source being received by the DS-N card reporting the alarm.

Step 3 If traffic is being affected, delete and recreate the circuit.



Caution Deleting a circuit can be service affecting.

Step 4 Check the far-end OC-N card that provides STS payload to the DS-N card.

Step 5 Verify the cross-connect between the OC-N card and the DS-N card.

Step 6 Clean the far-end optical fiber:

- a. Clean the fiber according to local site practice.
- b. If no local practice exists, use a CLETOP Real-Type or equivalent fiber-optic cleaner and follow the instructions accompanying the product.

Step 7 Replace OC-N/DS-N cards.



Note When you replace a card with an identical type of card, you do not need to make any changes to the database.

1.4 DS3E Line Alarms

Unlike the standard DS-3 card, which uses the unframed format exclusively, the DS3E card provides three choices: unframed, M23, or C-bit. The choice of framing format affects which line alarms the DS3E card reports. The table below lists the line alarms reported under each format.

The choice of framing format does not affect the reporting of STS alarms. Regardless of format, the DS3E card reports the same STS alarms as the standard DS-3 card.

Table 1-2 DS3E Line Alarms

Alarm	UNFRAMED	M23	CBIT
LOS	◆	◆	◆
AIS	◆	◆	◆
LOF	○	◆	◆
IDLE	○	◆	◆
RAI	○	◆	◆
Terminal Lpbk	◆	◆	◆
Facility Lpbk	◆	◆	◆
FE Lpbk	○	○	◆
FE Common Equipment Failure	○	○	◆
FE Equipment Failure-SA	○	○	◆
FE LOS	○	○	◆

Table 1-2 DS3E Line Alarms (continued)

Alarm	UNFRAMED	M23	CBIT
FE LOF	○	○	◆
FE AIS	○	○	◆
FE IDLE	○	○	◆
FE Equipment Failure-NSA	○	○	◆



General Troubleshooting

This chapter provides solutions for the most common problems encountered when operating a Cisco ONS 15454. To troubleshoot specific ONS 15454 alarms, use Chapter 1, “Alarm Troubleshooting.” The Problem List is an alphabetized list of the chapter’s procedures and their page numbers. The problem areas are grouped by topic; if you cannot find what you are looking for in this chapter or Chapter 1, “Alarm Troubleshooting,” contact the Cisco Technical Assistance Center (TAC) at 1-877-323-7368.

2.1 Problem List

Table 2-1 Type of Problem and Solution Location

Problem Area	Section or Procedure
Network Tests	
	Perform a Facility Loopback on a Source DS-N Card, page 2-4
	Perform a Hairpin on a Source Node, page 2-8
	Perform a Hairpin on a Destination Node, page 2-10
	Perform a Terminal Loopback on a Destination DS-N Card, page 2-6
	Perform a Facility Loopback on a Destination DS-N Card, page 2-13
	Using the DS3XM-6 Card FEAC (Loopback) Functions, page 2-16
CTC Operation and Connectivity	
	Browser Stalls When Downloading jar File From TCC+, page 2-17
	Browser Cache Points to an Invalid Directory, page 2-18
	Clear the CTC Cache File, page 2-18
	Node Icon is Grey on CTC Network View, page 2-19
	CTC Cannot Launch Due to Applet Security Restrictions, page 2-20
	Java Runtime Environment Incompatible, page 2-20

Table 2-1 Type of Problem and Solution Location (continued)

Problem Area	Section or Procedure
	Different CTC Releases Do Not Recognize Each Other, page 2-21
	Username or Password Do Not Match, page 2-21
	No IP Connectivity Exists Between Nodes, page 2-22
	DCC Connection Lost, page 2-22
	Browser Login Does not Launch Java, page 2-22
	Verify PC Connection to ONS 15454 (ping), page 2-23
	Calculate and Design IP Subnets, page 2-24
	Ethernet Connections, page 2-24
	VLAN Cannot Connect to Network Device from Untag Port, page 2-25
Circuits and Timing	
	Circuit Creation Error with VT1.5 Circuit, page 2-27
	Unable to Create Circuit From DS-3 Card to DS3XM-6 Card, page 2-28
	DS3 Card Does Not Report AIS-P From External Equipment, page 2-28
	OC-3 and DCC Limitations, page 2-28
	VLAN Cannot Connect to Network Device from Untag Port, page 2-25
	ONS 15454 Switches Timing Reference, page 2-28
	Holdover Synchronization Alarm, page 2-29
	Free-Running Synchronization Mode, page 2-29
	Daisy-Chain BITs Not Functioning, page 2-29
Fiber and Cabling	
	Bit Errors Appear for a Line Card, page 2-29
	Create CAT-5 Cables, page 2-33
	Faulty Fiber-Optic Connections, page 2-29
	Replace Faulty Gigabit Interface Converters, page 2-31
	Optical Card Transmit and Receive Levels, page 2-35
Power and LED Tests	
	Power Supply Problems, page 2-36
	Power Consumption for Node and Cards, page 2-37
	Lamp Test for Card LEDs, page 2-37


2.2 Network Tests

Use loopbacks and hairpins to test newly-created circuits before adding live traffic or to logically isolate the source of a network failure. All ONS 15454 line (traffic) cards, except Ethernet cards, allow loopbacks and hairpins.

2.2.1 Network Test Types


Facility loopbacks test the line interface unit (LIU) of a card, the EIA (electrical interface assembly), and cabling. You put a facility loopback on a card and use a test set to run traffic over the loopback. A successful facility loopback eliminates the LIU of the card, the EIA, or cabling plant as the cause or potential cause of a network problem. Figure 2-1 shows a facility loopback on a DS-N card.

Figure 2-1 The facility loopback process on a DS-N card



Terminal loopbacks test a circuit path through the cross-connect card and as it loops back from the line card being tested. Figure 2-2 shows a terminal loopback set on an OC-N card. The test set traffic comes in on the DS-N card and goes through the cross-connect card to the OC-N card. The terminal loopback on the OC-N card turns the signal around before it reaches the LIU and sends it through the cross-connect card to the DS-N card. This test verifies that the cross-connect card and circuit paths are valid, but does not test the LIU on the OC-N card. To test the LIU on an OC-N card, connect an optical test set to the OC-N card ports and perform a facility loopback or use a loopback or hairpin on a card that is farther along the circuit path.

Figure 2-2 The terminal loopback process on an OC-N card



Hairpin circuits bring traffic in and out on a DS-N port instead of sending the traffic onto the OC-N. A hairpin loops back only the specific STS or VT circuit and does not cause an entire OC-N port to loop back, which would drop all traffic on the OC-N port. The hairpin allows you to test a circuit on nodes running live traffic.


-
- Step 1** Test the test set with a hard loop.
To perform a hard loop, bridge the test set transmit (Tx) and receive (Rx) terminals with a cable and send traffic across this loop to ensure that the test set works.
- Step 2** Use appropriate cabling to attach the electrical test set transmit (Tx) and receive (Rx) terminals of the test set to the EIA connectors or DSx panel for the port you are testing. Both transmit (Tx) and receive (Rx) connect to the same port. Set up the test set accordingly.
- Step 3** In node view, double-click the card where you will perform the loopback.
- Step 4** Click the **Maintenance > Loopback** tabs.
- Step 5** On the Loopback subtab, select **Facility (Line)** from the Loopback Type column for the port being tested. If this is a multiport card, such as the OC3, make sure to select the appropriate row for the desired port.
- Step 6** Click **Apply**.
- Step 7** On the confirmation dialog box, click **Yes**.
-  **Note** It is normal for an alarm to appear during loopback setup. The alarm clears when you remove the loopback.
-
- Step 8** If the test set is not already sending traffic, send test set traffic on the loopback circuit.
- Step 9** Examine the traffic received by the test set. Look for errors or any other signal information that the test set is capable of indicating.
- Step 10** If the test set indicates a good circuit:
- a. Clear the Facility Loopback:
On the Loopback subtab, select **None** from the Loopback Type column.
Click **Apply**.
 - b. Skip to the “Perform a Hairpin on a Source Node” procedure on page 2-8.
- Step 11** A faulty circuit signifies a problem with the DS-N card, the cabling from the DS-N card to the DSx panel, or the EIA. Test the DS-N cabling, the DS-N card, and then the EIA.
- Step 12** To test the cabling:
- a. Replace the suspect cabling (the cables from the test set to the EIA ports) with a known good cable.
 - b. If a known good cable is not available, test the suspect cable with a test set. Remove the suspect cable from the EIA and connect the cable to the transmit (Tx) and receive (Rx) terminals of the test set. Run traffic to determine whether the cable is good or suspect.
 - c. Resend test set traffic on the loopback circuit with a known good cable installed.
 - d. If the circuit is now good, the problem was probably the defective cable. Replace this cable and skip to the “Perform a Terminal Loopback on a Destination DS-N Card” procedure on page 2-6.
- Step 13** To test the card:
- a. Replace the suspect card with a known good card.
 - b. Resend test set traffic on the loopback circuit with a known good card.
 - c. If the circuit is now good, the problem was probably the defective card. Replace the suspect card and skip to the “Perform a Terminal Loopback on a Destination DS-N Card” procedure on page 2-6.

- d. Return the defective card to Cisco through the returned materials authorization (RMA) process. Call the Cisco Technical Assistance Center (TAC) at 1-877-323-7368 to open an RMA case.
- Step 14** If the loopback test fails with a known good cable and a known good card, then the EIA is suspect. The EIA may not be seated properly; for example, screws may be loose or missing. Remove and reinstall the EIA to ensure a proper seating.
- Remove the lower backplane cover, loosen the five screws that secure it to the ONS 15454 and pull it away from the shelf assembly.
 - Loosen the nine perimeter screws that hold the backplane sheet metal cover(s) in place.
 - Lift the EIA panel by the bottom to remove it from the shelf assembly.
 - Follow the installation procedure for the appropriate EIA. Refer to the “EIA Replacement Procedures” section on page 3-32.
- Step 15** Repeat the facility loopback test for the DS-N card. If the test fails with the reinstalled EIA, call the Cisco Technical Assistance Center (TAC) at 1-877-323-7368 to open an RMA case for the EIA.
- Step 16** Replace the EIA with a new EIA.
- Step 17** Resend test set traffic on the loopback circuit with known good cabling, a known good card, and the replacement EIA.
- Step 18** If the circuit is now good, the problem was probably the defective EIA. Skip to the “Perform a Hairpin on a Source Node” procedure on page 2-8.
- Step 19** Clear any loopback before testing the next segment of the circuit path.

Procedure: Perform a Terminal Loopback on a Destination DS-N Card

This test is a terminal loopback performed on the fourth line card in the circuit; in the following example the DS-N card in the destination node. First create a bidirectional circuit that starts on the source node DS-N port and terminates on the destination node DS-N port, then proceed with the terminal loopback test. Completing a successful terminal loopback to a destination node DS-N card verifies that the circuit is good up to the destination DS-N.

Figure 2-5 Terminal loopback on a destination DS-N card



Caution Performing a loopback on an in-service circuit is service affecting.

- Step 1** Test the test set with a hard loop if you have not already done so.

To perform a hard loop, bridge the test set transmit (Tx) and receive (Rx) terminals with an appropriate cable and send traffic across the loop to ensure the test set works.


- Step 2** If you are starting the current procedure with the electrical test set hooked up to the DS-N card in the source node, leave the test set hooked up.
- Step 3** If you are starting the current procedure without the electrical test set hooked up to the DS-N card in the source node, use appropriate cabling to attach the electrical test set transmit (Tx) and receive (Rx) terminals to the EIA connectors or DSx panel for the port you are testing. Both transmit (Tx) and receive (Rx) cables connect to the same port. Set up the test set accordingly.
- Step 4** Click the **Circuits** tab and click the **Create** button.
- Step 5** Give the circuit an easily-identifiable name, such as DSNtoDSN.
- Step 6** Set Circuit **Type** and **Size** to your normal preferences.
- Step 7** Leave the **Bidirectional** check box checked and click **Next**.
- Step 8** In the Circuit Source dialog box, fill in the same card and port where you performed the first loopback test (the DS-N card in the source node).
- Step 9** Click **Next**.
- Step 10** In the Circuit Destination dialog box, use the DS-N card and port in the destination node.
- Step 11** Click **Finish**.
- Step 12** Confirm that the newly created circuit appears on a Circuits screen row with a direction column that shows a 2-way circuit.
- Step 13** In node view, double-click the card that requires the loopback. In this example, the DS-N card in the destination node.
- Step 14** Click the **Maintenance > Loopback** tabs.
- Step 15** On the Loopback subtab, select **Terminal (Inward)** from the Loopback Type column. If this is a multiport card, such as the OC3 IR 4 1310, make sure to select the row appropriate for the desired port.
- Step 16** Click **Apply**.
- Step 17** On the confirmation dialog box, click **Yes**.
- 
Note Loopbacks operate only on in-service ports.
- 
Note It is normal for an alarm to appear during a loopback setup. The alarm clears when you remove the loopback.
- Step 18** If the test set is not already sending traffic, send test set traffic on the loopback circuit.
- Step 19** Examine the test traffic being received by the test set. Look for errors or any other signal information that the test set is capable of indicating.
- Step 20** If the test set indicates a good circuit, proceed to the “Perform a Hairpin on a Source Node” procedure on page 2-8.
- Step 21** If the test traffic is not received or is poor quality, then test the DS-N card.
- a. Replace the suspect card with a known good card.
 - b. Resend test set traffic on the loopback circuit with a known good card.

- c. If the circuit is now good, the problem was probably the defective card. Replace the suspect card and return the defective card to Cisco. Call the Technical Assistance Center (TAC) at 1-877-323-7368 to open an RMA case.

Procedure: Perform a Hairpin on a Source Node

The second loopback test is a hairpin circuit performed on the first cross-connect card in the circuit. A hairpin circuit uses the same port for both source and destination. Completing a successful hairpin through this card eliminates the possibility that the source cross-connect card is the cause of the faulty circuit.

Figure 2-6 Hairpin on a source node



Note

The ONS 15454 does not support simplex operation on the cross-connect card. Two cross-connect cards of the same type must be installed for each node.

- Step 1** Test the test set with a hard loop if you have not already done so.
To perform a hard loop, bridge the test set transmit (Tx) and receive (Rx) terminals with a cable and send traffic across this loop to make the test set work.
- Step 2** If you just completed the “Perform a Facility Loopback on a Source DS-N Card” procedure on page 2-4, leave the electrical test set hooked up to the DS-N card.
- Step 3** If you are starting the current procedure without the electrical test set hooked up to the DS-N card, use appropriate cabling to attach the electrical test set transmit (Tx) and receive (Rx) terminals to the EIA connectors or DSx panel for the port you are testing. Both transmit (Tx) and receive (Rx) connect to the same port. Set up the test set accordingly.
- Step 4** Click the **Circuits** tab and click the **Create** button.
- Step 5** Give the circuit an easily-identifiable name, such as hairpin1.
- Step 6** Set the Circuit **Type** and **Size** to your normal preferences.
- Step 7** Uncheck the **Bidirectional** check box and click **Next**.
- Step 8** In the Circuit Source dialog box, fill in the same card and port where you performed the first loopback test. The DS-N card in the source node.
- Step 9** Click **Next**.
- Step 10** In the Circuit Destination dialog box, use the same card and port used for the source information.
- Step 11** Click **Finish**.

- Step 12** Confirm that the newly-created circuit appears with a direction column noting that this circuit is 1-way.
- Step 13** If the test set is not already sending traffic, send test set traffic on the loopback circuit.
- Step 14** Examine the test traffic received by the test set. Look for errors or any other signal information that the test set is capable of indicating.
- Step 15** If the test set indicates a good circuit, skip to the “Perform a Hairpin on a Destination Node” procedure on page 2-10.
- Step 16** If the test traffic is not received or is poor quality, there may be a problem with the cross-connect card.



Caution Cross-connect manual switches (side switches) are service-affecting. Any live traffic on any card in the node endures a hit of up to 50 ms.

- Step 17** Perform a software reset on the standby cross-connect card:
- Determine the standby cross-connect card. On both the physical node and the CTC screen, the ACT/STBY LED of the standby cross-connect card is amber, and the ACT/STBY LED of the active cross-connect card is green.
 - Position the cursor over the standby cross-connect card.
 - Right-click to choose **RESET CARD**.
- Step 18** Do a manual switch (side switch) of the cross-connect cards before retesting the circuit:
- Determine the standby cross-connect card. The ACT/STBY LED of the standby cross-connect card is amber, and the ACT/STBY LED of the active cross-connect card is green.



Note Place the cursor on top of the card graphic to display a dialog. This display identifies the card as *XC: Active* or *XC: Standby*.

- In the node view, select the **Maintenance > XC Cards** tabs.
- From the Cross Connect Cards menu, choose **Switch**.
- Click **Yes** on the Confirm Switch dialog box.



Note After the active cross-connect goes into standby, the original standby slot becomes active. This causes the ACT/STBY LED to become green on the former standby card.


- Step 19** Retest the circuit:
- Resend test set traffic on the loopback circuit.
The test set traffic now travels through the alternate cross-connect card.
 - Examine the test traffic received by the test set. Look for errors or any other signal information that the test set is capable of indicating.
 - If the signal received by the test set is still faulty or non-existent, assume the cross-connect card is not causing the problem. Proceed to the “Perform a Hairpin on a Destination Node” procedure on page 2-10.
- Step 20** If the circuit is now good, the problem could be a defective card. To confirm a defective original cross-connect card:
- Redo the manual switch (side switch) procedure to make the original active cross-connect card again the active card.

- b. Resend test set traffic on the loopback circuit.
 - c. If the signal received by the test set is still faulty or non-existent, return the defective card to Cisco. Call the Technical Assistance Center (TAC) at 1-877-323-7368 to open an RMA case.
- Step 21** If the circuit is now good, the cross-connect card may have had a temporary problem that was cleared by the side switch.
- Step 22** Replace the defective cross-connect card.
- Step 23** Click the **Circuits** tab.
- Step 24** Highlight the newly-created hairpin circuit and click **Delete**.
- Step 25** Proceed to the “Perform a Hairpin on a Destination Node” procedure on page 2-10.

Procedure: Perform a Hairpin on a Destination Node

The third test is a hairpin circuit on the cross-connect card in the destination node. To perform this test, you must also create a bidirectional circuit from the source DS-N card to the source OC-N node in the transmit direction. Creating the bidirectional circuit and completing a successful hairpin eliminates the possibility that the source and destination OC-N cards, the source and destination cross-connect card, or the fiber span is responsible for the faulty circuit.

Figure 2-7 Hairpin on a destination node



- Step 1** Test the test set with a hard loop if you have not done so.



Note To perform a hard loop, bridge the test set transmit (Tx) and receive (Rx) terminals with an appropriate cable and send traffic across this loop to ensure the test set works.

- Step 2** If you are starting the current procedure with the electrical test set hooked up to the DS-N card, leave the test set hooked up.
- Step 3** If you are starting the current procedure without the electrical test set hooked up to the DS-N card, use appropriate cabling to attach the electrical test set transmit (Tx) and receive (Rx) terminals to the EIA connectors or DSx panel for the port you are testing. Both transmit (Tx) and receive (Rx) connect to the same port. Set up the test set accordingly.
- Step 4** To create the first circuit, click the **Circuits** tab and click the **Create** button.
- Step 5** Give the circuit an easily-identifiable name, such as bidirectional1.
- Step 6** Select the appropriate circuit type, VT or STS-1.

- Step 7** Leave the **Bidirectional** check box checked and click **Next**.
- Step 8** In the Circuit Source dialog box, fill in the same card and port where you performed the first loopback test (the DS-N card in the source node).
- Step 9** Click **Next**.
- Step 10** In the Circuit Destination dialog box, use the source node OC-N card and port.
- Step 11** Click **Next** and **Finish**.
- Step 12** Confirm that the newly-created circuit appears with a direction column showing a 2-way circuit.
- Step 13** Log into the destination node.
- Step 14** For the second circuit, click the **Circuits** tab and click the **Create** button.
- Step 15** Give the circuit an easily-identifiable name, such as hairpin2.
- Step 16** Set Circuit **Type** and **Size** to your normal preferences.
- Step 17** Uncheck the **Bidirectional** check box and click **Next**.
- Step 18** In the Circuit Source dialog box, fill in the destination OC-N card and port.
- The OC-N card must be the other end of the fiber span originating from the OC-N card in Step 10. For example in a typical east-to-west slot configuration, a slot 6 OC-N card on the source node is one end of the fiber span, and the slot 12 OC-N card on the destination node is the other end. Figure 2-7 illustrates the slot to fiber span relationship.
- Step 19** Click **Next**.
- Step 20** In the Circuit Destination dialog box, use the same card and port from the Circuit Source dialog box.
- Step 21** Click **Finish**.
- Step 22** Confirm that the second newly-created circuit appears with a direction column noting a 1-way circuit.
- Step 23** Double-click the circuit to display the network view.
- Step 24** Verify that the circuits connect to the correct slots. For example, source node/Slot 6 (east slot) to destination node/Slot 12 (west slot). If two east or two west slots are connected, the circuit will not work. Except for the distinct slots, all other circuit information, such as ports, should be identical.
- Step 25** If the test set is not already sending traffic, send test set traffic on the loopback circuit.
- Step 26** Examine the test traffic received by the test set. Look for errors or any other signal information indicated by the test set.
- Step 27** If the test set indicates a good circuit, skip to the “Perform a Terminal Loopback on a Destination DS-N Card” procedure on page 2-6.
- Step 28** If the test traffic is not received or is poor quality, a problem may exist with the destination cross-connect card, the source or destination OC-N card, or the fiber span. Test the destination cross-connect card, then the OC-N cards, and then test the fiber span.



Caution Cross-connect manual switches (side switches) are service-affecting. Any live traffic on any card in the node will endure a hit of up to 50 ms.

- Step 29** Perform a software reset on the standby cross-connect card:
- a. Determine the standby cross-connect card. On both the physical node and the CTC screen, the ACT/STBY LED of the standby cross-connect card is amber, and the ACT/STBY LED of the active cross-connect card is green.
 - b. Position the cursor over the standby cross-connect card.

- c. Right-click to choose **RESET CARD**.

Step 30 Do a manual switch (side switch) of the cross-connect cards before retesting the circuit:

- a. In the node view, select the **Maintenance > XC Cards** tabs.
- b. From the Cross Connect Cards menu, choose **Switch**.
- c. Click **Yes** on the Confirm Switch dialog box.



Note After the active cross-connect goes into standby, the original standby slot becomes active. This causes the ACT/STBY LED to become green on the former standby card.

Step 31 Retest the circuit:

- a. Resend test set traffic on the loopback circuit.
The test set traffic routes through the alternate cross-connect card.
- b. Examine the test traffic received by the test set. Look for errors or any other signal information that the test set is capable of indicating.
- c. If the signal received by the test set is still faulty or non-existent, assume the cross-connect card is not causing the problem. Skip to Step k of this procedure.

Step 32 If the circuit is now good, the problem could be a defective card. To confirm a defective original cross-connect card:

- a. Redo the manual switch (side switch) procedure to make the original active cross-connect card again the active card.
- b. Resend test set traffic on the loopback circuit.
- c. If the signal received by the test set is still faulty or non-existent, return the defective card to Cisco. Call the Technical Assistance Center (TAC) at 1-877-323-7368 to open an RMA case.
- d. Replace the defective cross-connect card.
If the circuit is now good, the cross-connect card may have had a temporary problem that was cleared by the side switch.

Step 33 Click the **Circuits** tab.

Step 34 Resend test set traffic on the loopback circuit.

The test set traffic routes through the alternate cross-connect card rather than the original cross-connect card.

Step 35 Examine the received test set traffic. Look for errors or any other signal information that the test set is capable of indicating.

Step 36 If the signal received by the test set is still faulty or non-existent, assume the problem does not lie in a faulty cross-connect card and skip to Step 39 of this procedure.

Step 37 If the circuit is now good, the problem could be a defective card. To confirm a defective alternate cross-connect card:


- a. Repeat the manual switch (side switch) procedure to make the original active cross-connect card again the active card.
- b. Resend test set traffic on the loopback circuit.
- c. If the signal received by the test set is still faulty or non-existent, return the defective card to Cisco. Call the Technical Assistance Center (TAC) at 1-877-323-7368 to open an RMA case.
- d. Replace the defective cross-connect card.

- e. If the circuit is now good, the cross-connect card may have had a temporary problem that is now cleared by the side switch.
- Step 38** Click **Apply** and click the **Circuits** tab.
- Step 39** To eliminate the possibility of faulty OC-N cards:
- a. Replace the suspect source OC-N card with a known good card.
 - b. Resend test set traffic on the loopback circuit with a known good card.
 - c. If the circuit is now good, the problem was probably the defective card. Return the defective card to Cisco. Call the Technical Assistance Center (TAC) at 1-877-323-7368 to open an RMA case.
 - d. Repeat steps a – b for the suspect destination OC-N card.
 - e. If the circuit is now good, skip to the “Perform a Terminal Loopback on a Destination DS-N Card” procedure on page 2-6.
If the test traffic is not received or is poor quality and the OC-N card is a known good card, then the fiber span is suspect.
- Step 40** To test a suspect fiber span, see the “Faulty Fiber-Optic Connections” section on page 2-29 and return to Step 41.
- Step 41** If you now have a valid fiber span, resend test set traffic on the loopback circuit.
- Step 42** Examine the test traffic being received by the test set. Look for errors or any other signal information that the test set is capable of indicating.
- Step 43** If you do not have a valid test signal or a valid fiber span, try to obtain access to another known good span, hook the source and destination OC-N cards to the known good span, and resend the test signal.
- Step 44** If you do not have a valid signal with a known good span, valid OC-N cards, and a valid cross-connect card, repeat the “Perform a Hairpin on a Destination Node” procedure on page 2-10 to try and determine the problem, or call the Cisco Technical Assistance Center (TAC) at 1-877-323-7368 and explain the situation.
- Step 45** If you have a valid test signal with the known good span, replace or fix the original fiber span to obtain a valid circuit. Next go to “Perform a Hairpin on a Destination Node” procedure on page 2-10.
- Step 46** Highlight the newly-created hairpin circuit.
- Step 47** Click **Delete**.
- Step 48** Proceed to the “Perform a Facility Loopback on a Destination DS-N Card” procedure on page 2-13.
-

Procedure: Perform a Facility Loopback on a Destination DS-N Card

The final test is a facility loopback performed on the last card in the circuit; in this case the DS-N card in the destination node. Completing a successful facility loopback on this card eliminates the possibility that the destination node cabling, DS-N card, LIU, or EIA is responsible for a faulty circuit.

Figure 2-8 Facility loopback on a destination DS-N card



Caution

Performing a loopback on an in-service circuit is allowed but is service affecting.



Note

Loopbacks operate only on in-service ports.

Step 1 Test the test set with a hard loop if you have not already done so.

To perform a hard loop on the test set, bridge the test set transmit (Tx) and receive (Rx) terminals with an appropriate cable and send traffic across this loop to make sure the test set works properly.

Step 2 Use appropriate cabling to attach the electrical test set transmit (Tx) and receive (Rx) terminals to the EIA connectors or DSx panel for the port you are testing. Both transmit (Tx) and receive (Rx) connect to the same port. Set up your test set accordingly.

Step 3 In node view, double-click the card where you will perform the loopback.

Step 4 Click the **Maintenance > Loopback** tabs.



Note Loopbacks operate only on in-service ports.

Step 5 On the Loopback subtab, select **Facility (Line)** from the Loopback Type column for the port being tested. If this is a multiport OC-N card, such as the OC3 IR 4 1310, make sure to select the row appropriate for the desired port.

Step 6 Click **Apply**.

Step 7 On the confirmation dialog box, click **Yes**.



Note It is normal for an alarm to appear during loopback. The alarm clears when you remove the loopback.

Step 8 If the test set is not already sending traffic, send test set traffic on the loopback circuit.

Step 9 Examine the test traffic received by the test set. Look for errors or any other signal information that the test set is capable of indicating.

Step 10 If the test set indicates a clean circuit:

- a. Clear the facility loopback:

On the Loopback subtab, select **None** from the Loopback Type column.

Click **Apply**.

- b. The entire DS-N circuit path has now passed its comprehensive series of loopback tests. This circuit qualifies to carry live traffic.

Step 11 If the test traffic is not received or is poor quality, there is a problem with the DS-N card, the cabling from the DS-N card, or the EIA. Test the DS-N cabling first, the DS-N card next, and the EIA last.

Step 12 To test the cabling:

- a. Replace the suspect cabling (the cables from the test set to the EIA ports) with a known good cable.
- b. If a known good cable is not available, you can test the suspect cable with a test set. Remove the suspect cable from the EIA and connect the cable to the transmit (Tx) and receive (Rx) terminals of the test set. Run traffic to determine whether this is a good cable.
- c. Resend test set traffic on the loopback circuit with a known good cable installed.
- d. If the circuit is now good, the problem was probably the defective cable. Replace this cable.
- e. Skip to Step 18.

Step 13 To test the card:

- a. Replace the suspect card with a known good card.
- b. Resend test set traffic on the loopback circuit with a known good card.
- c. If the circuit is now good, the problem was probably the defective card. Replace the defective card.
- d. Return your defective card to Cisco. Call the Technical Assistance Center (TAC) at 1-877-323-7368 to open an RMA case.

Step 14 If the loopback test fails with a known good cable and a known good card, then the EIA is suspect. The EIA may not be seated properly, for example, screws may be loose or missing. Remove and reinstall the EIA to ensure a proper seating.

- a. Remove the lower backplane cover, loosen the five screws that secure it to the ONS 15454 and pull it away from the shelf assembly.
- b. Loosen the nine perimeter screws that hold the backplane sheet metal cover(s) in place.
- c. Lift the EIA panel by the bottom to remove it from the shelf assembly.
- d. Follow the installation procedure for the appropriate EIA. Refer to the “EIA Replacement Procedures” section on page 3-32.

Step 15 Repeat the facility loopback test for the DS-N card. If the test fails with the reinstalled EIA, call the Cisco Technical Assistance Center (TAC) at 1-877-323-7368 to open an RMA case for the EIA.

Step 16 Replace the EIA.


Step 17 Resend test set traffic on the loopback circuit with known good cabling, a known good card, and the replacement EIA. If the circuit is now good, the problem was probably the defective EIA.

Step 18 The entire DS-N circuit path has now passed its comprehensive series of loopback tests. This circuit qualifies to carry live traffic.

2.2.3 Using the DS3XM-6 Card FEAC (Loopback) Functions


The DS3XM-6 card supports FEAC (Far End Action Code) features that are not available on basic DS-3 cards. Click the Maintenance tab at the DS3XM-6 card-level view to reveal the two additional DS3XM-6 columns. Figure 2-9 shows the DS3 subtab and the additional Send Code and Inhibit Lbk columns.

Figure 2-9 Accessing FEAC functions on the DS3XM-6 card



The far end in FEAC refers to the piece of equipment that is connected to the DS3XM-6 card and not the far end of a circuit. In Figure 2-10 below, if a DS3XM-6 (near-end) port is configured to send a Line Loop Code, the code will be sent to the connected test set, not the DS3XM-6 (far-end) port.

Figure 2-10 Diagram of far end action code



2.2.3.1 FEAC Send Code

The Send Code column on the maintenance tab of a DS3XM-6 port only applies to In-Service ports configured for CBIT framing. The column lets a user select No Code (the default) or Line Loop Code. Selecting Line Loop Code inserts a line loop activate FEAC (Far End Action Code) in the CBIT overhead transmitting to the connected facility. This code initiates a loopback from the facility to the ONS 15454.

Selecting No Code sends a line loop deactivate FEAC code to the connected equipment, which will remove the loopback. You can also insert a FEAC for the 28 individual DS-1 circuits transmuted into a DS-3 circuit.

2.2.3.2 FEAC Inhibit Loopback

The DS3XM-6 ports and transmuted DS-1s initiate loopbacks when they receive FEAC Line Loop codes. If the Inhibit Loopback checkbox is checked for a DS-3 port, then that port will ignore any received FEAC Line Loop codes and will not loop back. The port can still be put into loopback manually using the Loopback Type column even if the Inhibit Loopback box is selected. Only DS-3 ports can be configured to inhibit responding to FEAC loopback commands, individual DS-1 ports cannot.

2.2.3.3 FEAC Alarms

A LPBKDS3FEAC-CMD or LPBKDS1FEAC-CMD alarm on the ONS 15454 port if a DS-3 or DS-1 FEAC loopback code has been sent to the far end.

If the ONS 15454 port is in loopback from having received a loopback activate FEAC code, a LPBKDS3FEAC or LPBKDS1FEAC alarm occurs. The alarm will clear when a loopback deactivate FEAC command is received on that port.

A DS3E card will respond to, and can inhibit, received FEAC DS3 level loopback codes. A DS3E card cannot be configured to send FEAC codes.

2.3 CTC Operation and Connectivity

This section contains troubleshooting procedures for CTC log-in or operation errors and PC and network connectivity. For a list of the procedures in this section, see Table 2-1 on page 2-1.

2.3.1 Browser Stalls When Downloading jar File From TCC+

If the browser stalls or hangs when downloading a jar file from the TCC+ card, VirusScan software may be interfering with the operation. The problem occurs when the VirusScan Download Scan is enabled on McAfee VirusScan 4.5 or later. To correct the problem, disable the Download Scan feature.

Procedure: Disable the VirusScan Download Scan

-
- Step 1** From the Windows start menu, select **Programs > Network Associates > VirusScan Console**.
 - Step 2** Double-click the **VShield** icon listed in the VirusScan Console dialog box.
 - Step 3** Click the **Configure** button on the lower part of the Task Properties window.
 - Step 4** Click the **Download Scan** icon on the left of the System Scan Properties dialog box.
 - Step 5** Uncheck the **Enable Internet download scanning** box.
 - Step 6** Click **Yes** when the warning message appears.
 - Step 7** Click **OK** on the System Scan Properties dialog box.
 - Step 8** Click **OK** on the Task Properties window.

Step 9 Close the McAfee VirusScan window.

2.3.2 Browser Cache Points to an Invalid Directory

When the Netscape cache points to an invalid directory, CTC does not launch. Usually an error message appears before the purple login screen displays.

Procedure: Redirect the Netscape Cache to a Valid Directory

- Step 1** Launch Netscape.
- Step 2** Display the **Edit** menu.
- Step 3** Select **Preferences**.
- Step 4** Under the Category column on the left-hand side, go to **Advanced** and select the **Cache** tab.
- Step 5** Change your Disk Cache folder to point to the cache file location.

The cache file location is usually C:\ProgramFiles\Netscape\Users\<>yourname>\cache. The <yourname> segment of the file location is often the same as your e-mail username, but you can select any other valid location on the hard drive.

2.3.3 Clear the CTC Cache File


If you experience sluggish CTC operation or have problems logging into CTC, clearing the CTC cache file often helps solve these and other problems. This operation forces the ONS 15454 to download a new set of jar files to your computer hard drive.

You can delete the cache automatically with the Delete CTC Cache button or delete them manually. For CTC releases prior to 2.2, automatic deletion is unavailable.

Procedure: Delete the CTC Cache File Automatically

- Step 1** Enter an ONS 15454 IP address into the browser URL field. The initial browser window shows a **Delete CTC Cache** button.
- Step 2** Close all open CTC sessions. The PC operating system will not allow you to delete files that are in use.
- Step 3** Click the **Delete CTC Cache** button on the initial browser window to clear the CTC cache.

Figure 2-11 Deleting the CTC cache



Procedure: Delete the CTC Cache File Manually

- Step 1** To delete the jar files manually, from the Windows start menu select **Find > Files and Folders**.
- Step 2** Enter *.jar in the Named field on the Find dialog box and click **Find Now**.
- Step 3** Click the **Modified** column on the Find dialog box to find the jar files that match the date when you downloaded the files from the TCC+.
- Step 4** Highlight the files and press the keyboard **Delete** key.
- Step 5** Click **Yes** at the Confirm dialog box.

2.3.4 Node Icon is Grey on CTC Network View

Occasionally, the CTC network view shows one or more node icons as grey in color and without a node name. This can be caused by different CTC releases not recognizing each other, the username/password on the gray nodes not matching, no IP connectivity existing between nodes, or a lost DCC connection.

2.3.5 CTC Cannot Launch Due to Applet Security Restrictions

If the error message “Unable to launch CTC due to applet security restrictions” appears after you enter the IP address in the browser window:

Step 1 Verify that you have executed the javapolicyinstall.bat file on the ONS 15454 software CD. This file is installed when you run the CTC Setup Wizard (see the software installation information in the *Cisco ONS 15454 Installation and Operations Guide* for instructions).

Step 2 If you ran the BAT file but still receive the error message, you must manually edit the java.policy file on your computer. Search your computer for this file and open it with a text editor (Notepad or Wordpad). Verify that the end of this file has the following lines:

```
// Insert this into the system-wide or a per-user java.policy file.
// DO NOT OVERWRITE THE SYSTEM-WIDE POLICY FILE--ADD THESE LINES!

grant codeBase "http://*/fs/LAUNCHER.jar" {
permission java.security.AllPermission;
};
```

Step 3 If these five lines are not in the file, enter them manually.

Step 4 Save the file and re-start Netscape.

CTC should now start correctly.

Step 5 If the error message is still reported, save the java.policy file as .java.policy. On Win95/98/2000 PCs, save the file to the C:\Windows folder. On WinNT4.0 PCs, save the file to all of the user folders on that PC, for example, C:\Winnt\profiles\joeuser.

2.3.6 Java Runtime Environment Incompatible

The Java® 2 Runtime Environment (JRE) contains the Java virtual machine, runtime class libraries, and Java application launcher that are necessary to run programs written in the Java programming language.

The ONS 15454 CTC is a Java application. A Java application, unlike an applet, cannot rely completely on a web browser for installation and runtime services. When you run an application written in the Java programming language, you need the correct JRE installed. The correct JRE for each CTC software release is included on the Cisco ONS 15454 software CD and on the Cisco ONS 15454 documentation CD.

If you are running multiple CTC software releases on a network, the JRE installed on the computer must be compatible with the different software releases. Table 2-2 shows JRE compatibility with ONS software releases.

Table 2-2 JRE Compatibility

ONS Software Release	JRE 1.2.2 Compatible	JRE 1.3 Compatible
ONS 15327 Release 1.0	Yes	No
ONS 15454 Release 2.2.1 and earlier	Yes	No
ONS 15454 Release 2.2.2	Yes	Yes

Table 2-2 JRE Compatibility (continued)

ONS Software Release	JRE 1.2.2 Compatible	JRE 1.3 Compatible
ONS 15454 Release 3.0	Yes	Yes
ONS 15454 Release 3.1	Yes	Yes

2.3.7 Different CTC Releases Do Not Recognize Each Other

This situation is often accompanied by the INCOMPATIBLE-SW alarm. The software loaded on the connecting workstation and the software on the TCC+ card are incompatible. This occurs when the TCC+ software is upgraded but the PC has not yet upgraded the compatible CTC jar file. It also occurs on log-in nodes with compatible software that encounter other nodes in the network that have a newer software version.



Note

Remember to always log into the ONS node with the latest CTC core version first. If you initially log into an ONS node running a CTC core version of 2.2 or lower and then attempt to log into another ONS node in the network running a higher CTC core version, the lower version node will not recognize the new node.

Procedure: Launch CTC to Correct the Core Version Build

- Step 1** Exit the current CTC session and completely close the browser.
- Step 2** Start the browser.
- Step 3** Type the ONS 15454 IP address of the node that reported the alarm. This can be the original IP address you logged on with or an IP address other than the original.
- Step 4** Log into CTC. The browser will download the jar file from CTC.



Note

After Release 2.2.2, the single CMS .jar file evolved into core and element files. Core files are common to both the ONS 15454 and ONS 15327, while the element files are unique to the particular product. For example, the ONS 15327 Release 1.0 uses a 2.3 core build and a 1.0 element build. To display the CTC Core Version number, from the CTC menu bar click **Help > About CTC**. This lists the Core and Element builds discovered on the network.

2.3.8 Username or Password Do Not Match

A mismatch often occurs concurrently with a NOT-AUTHENTICATED alarm. The username or password entered do not match the information stored in the TCC+. All ONS nodes must have the same username and password created to display every ONS node in the network. You can also be locked out of certain ONS nodes on a network if your username and password were not created on those specific ONS nodes.

For initial logon to the ONS 15454, type the *CISCO15* user name in capital letters and click **Login** (no password is required). If you are using a CTC software release prior to 3.0 and *CISCO15* does not work, type *cerent454* for the user name.

Procedure: Verify Correct Username and Password

-
- Step 1** Ensure that your keyboard Caps Lock is not turned on and affecting the case-sensitive entry of the username and password.
 - Step 2** Contact your system administrator to verify the username and password.
 - Step 3** Call Cisco TAC at 1-877-323-7368 to have them enter your system and create a new user name and password.
-

2.3.9 No IP Connectivity Exists Between Nodes

See the “Ethernet Connections” section on page 2-24.

2.3.10 DCC Connection Lost

See the “EOC” section on page 1-28.

2.3.11 Browser Login Does not Launch Java

If the message “Loading Java Applet” does not appear and the JRE does not launch during the initial login, you must reconfigure the PC operating system and the browser.

-
- Step 1** From the Windows start menu, click **Programs > Java Plug-in Control Panel**.
 - Step 2** If **Java Plug-in Control Panel** does not appear, the JRE may not be installed on your PC.
 - a. Run the Cisco ONS 15454 software CD.
 - b. Open the CD:\Windows\jre1.2.2_05 folder.
 - c. Double-click the jre-1_2_2_005-win icon to run the JRE installation wizard.
 - d. Follow the JRE installation wizard steps.
 - Step 3** Click **Advanced** on the Java Plug-in Control Panel.
 - Step 4** From the Java Run Time Environment menu, select JRE 1.2 in C:\ProgramFiles\JavaSoft\JRE\1.2.
 - Step 5** Click **Apply**.
 - Step 6** On Netscape Navigator, click **Edit > Preferences**.
 - Step 7** Click **Advanced > Proxies > Direct connection to the Internet > OK**.
 - Step 8** Again on Netscape Navigator, click **Edit > Preferences**.
 - Step 9** Click **Advanced > Cache**.

- Step 10** Confirm that the Disk Cache Folder field shows C:\ProgramFiles\Netscape\Communicator\cache for Windows 95/98/ME
or C:\ProgramFiles\Netscape\

Step 11 If the Disk Cache Folder field is not correct, click **Choose Folder**.

Step 12 Navigate to the file listed in Step 10 and click **OK**.

Step 13 Click **OK** on the Preferences window and exit the browser.

Step 14 Temporarily disable any virus scanning software on the computer. Refer to “Browser Stalls When Downloading jar File From TCC+” section on page 2-17.

Step 15 Verify that the computer does not have two NIC cards installed. If the computer does have two NIC cards, remove one.

Step 16 Restart the browser and log into the ONS 15454.

2.3.12 Verify PC Connection to ONS 15454 (ping)

Use a standard ping command to verify the TCP/IP connection between the PC and the ONS 15454 TCC+ card. A ping command will work if the PC connects directly to the TCC+ card or uses a LAN to access the TCC+ card. If the TCP/IP connection was established and then lost, a DISCONNECTED alarm will appear on CTC.



Note

Software Release 3.0 requires the TCC+ card and does not support the TCC card. Releases 2.2, 2.2.1, and 2.2.2 support the TCC and the TCC+ cards.

Procedure: Ping the ONS 15454

- Step 1** Display the command prompt:
- If you are using a Microsoft Windows operating system, from the Start Menu choose **Programs > Command Prompt**.
 - If you are using a Sun Solaris operating system, from the Common Desktop Environment (CDE) click the **Personal Application tab** and click **Terminal**.
- Step 2** For both the Sun and Microsoft operating systems, at the prompt type:
- ```
ping [ONS 15454 IP address]
For example, ping 192.1.0.2.
```
- Step 3** If the workstation has connectivity to the ONS 15454, the ping is successful and displays a reply from the IP address. If the workstation does not have connectivity, a “Request timed out” message displays.
- Step 4** If the ping is successful, an active TCP/IP connection exists. Restart CTC.


## 2.3.13 Calculate and Design IP Subnets

Cisco provides a free online tool to calculate and design IP subnets. Go to [http://www.cisco.com/techtools/ip\\_addr.html](http://www.cisco.com/techtools/ip_addr.html). For information about ONS 15454 IP capability, refer to the *Cisco ONS 15454 Installation and Operations Guide*.

## 2.3.14 Ethernet Connections

You can fix most connectivity problems in an Ethernet network by following a few guidelines. See Figure 2-12 when consulting the steps in the following procedure.

**Figure 2-12 Ethernet connectivity reference**



### Procedure: Verify Ethernet Connections

- Step 1** Check for SONET alarms on the STS-N that carries the VLAN #1 Ethernet circuit. Clear any alarms by looking them up in the "Alarm Troubleshooting" chapter.
- Step 2** Check for Ethernet-specific alarms. Clear any present alarms by looking up that alarm in the "Alarm Troubleshooting" chapter.
- Step 3** Verify that the ACT LED on the Ethernet card is green.
- Step 4** Verify that Ports 1 and 3 on ONS 15454 #1 and Ports 1 and 2 on ONS 15454 #2 have green link-integrity LEDs.
- Step 5** If no green link-integrity LED exists for any of these ports:
  - a. Verify physical connectivity between the ONS 15454s and the attached device.
  - b. Verify that the ports are enabled on the Ethernet cards.
  - c. Verify that you are using the proper Ethernet cable and that it is wired correctly, or replace the cable with a reliable straight-through Ethernet cable.
  - d. Check the Status LED on the Ethernet card faceplate to ensure the card booted up properly. This LED should be steady green. If necessary, remove and reinsert the card and allow it to reboot.


- e. It is possible that the Ethernet port is functioning properly but the LNK LED itself is broken. Run the procedure in the “Lamp Test for Card LEDs” section on page 2-37.
- Step 6** Verify connectivity between device A and device C by pinging between these locally-attached devices (see the “Verify PC Connection to ONS 15454 (ping)” section on page 2-23). If the ping is unsuccessful:
- a. Verify that device A and device C are on the same IP subnet.
  - b. At the card view in CTC, display the Ethernet card and click the **Provisioning > VLAN** tabs to verify that both Port 1 and Port 3 on the card are assigned to the same VLAN.
  - c. If a port is not assigned to the correct VLAN, click that port column in the VLAN row and set the port to Tagged or Untag. Click **Apply**.
- Step 7** Repeat Step 6 for devices B and D.
- Step 8** Verify that the Ethernet circuit that carries VLAN #1 is provisioned and that ONS 15454 #1 and ONS 15454 #2 are included in circuit VLAN #1.

## 2.3.15 VLAN Cannot Connect to Network Device from Untag Port

Networks that have a VLAN with one ONS 15454 Ethernet card port set to Tagged and one ONS 15454 Ethernet card set to Untag may have difficulty implementing Address Resolution Protocol (ARP) for a network device attached to the Untag port. They may also see a higher than normal runt packets count at the network device attached to the Untag port.

This implementation problem occurs because the port of the ONS 15454 Ethernet card that is set to Tagged adds the 802.1Q tag, which is four bytes long, to a 60-byte packet and sends the packet to the ONS 15454 with the Ethernet card port set to Untag. The second ONS 15454 removes the 4-byte 802.1 Q-tag and does not stuff the packet with four replacement bytes. This 64-byte packet drops in size to 60 bytes, which makes it a runt or illegal Ethernet packet. The NIC of the network device categorizes the packet as a runt and drops the packet.

**Figure 2-13 A VLAN with Ethernet ports at Tagged And Untag**




Dropped packets can occur when ARP attempts to match the IP address of the network device attached to the Untag port with the physical MAC address required by the network access layer. ARP uses broadcast data packets which are often 60 bytes plus an additional 4 bytes of 802.1 Q-tag information. This makes ARP especially vulnerable to the runt problem.

The solution is to set both ports in the VLAN to Tagged (detailed in the following procedure). Setting both ports in the VLAN to Tagged stops the stripping of the 4 bytes from the data packet and prevents the NIC card in the network access device from recognizing the packet as a runt and dropping it. Network devices with 802.1Q-compliant NIC cards will accept the tagged packets. Network devices with non-802.1Q compliant NIC cards will still drop these tagged packets. The solution may require upgrading network devices with non-802.1Q compliant NIC cards to 802.1Q-compliant NIC cards. You can also set both ports in the VLAN to Untag, but you will lose 802.1Q compliance.

## Procedure: Change VLAN Port Tag and Untagged Settings

- Step 1** Display the CTC card view for the Ethernet card involved in the problem VLAN.
- Step 2** Click the **Provisioning > VLAN** tabs (Figure 2-14).

Figure 2-14 Configuring VLAN membership for individual Ethernet ports



- Step 3** If the port is set to **Tagged**, continue to look at other cards and their ports in the VLAN until you find the port that is set to **Untag**.
- Step 4** At the VLAN port set to **Untag**, click the port and choose **Tagged**.



**Note** The attached external devices must recognize IEEE 802.1Q VLANs.

- Step 5** After each port is in the appropriate VLAN, click **Apply**.

## 2.4 Circuits and Timing

This section provides solutions to circuit creation and reporting errors, as well as common timing reference errors and alarms.

### 2.4.1 AIS-V on DS3XM-6 Unused VT Circuits

An incomplete circuit path causes an alarm indications signal (AIS); for example, when the port on the reporting node is in-service but a node upstream on the circuit does not have an OC-N port in-service. An AIS-V indicates that an upstream failure occurred at the virtual tributary (VT) layer. AIS-V alarms also occur on DS3XM-6 VT circuits that are not carrying traffic and on stranded bandwidth.

#### Procedure: Clear AIS-V on DS3XM-6 Unused VT Circuits

- 
- Step 1** Determine the affected port.
  - Step 2** Record the node ID, slot number, port number, or VT number.
  - Step 3** Create a unidirectional VT circuit from the affected port back to itself. For example, Source node/Slot 2/Port 2/VT 13 cross connected to Source node/Slot 2/Port 2/VT 13.
  - Step 4** Uncheck the bidirectional box in the circuit creation window.
  - Step 5** Give the unidirectional VT circuit an easily recognizable name, such as delete me.
  - Step 6** Display the DS3XM-6 card in CTC card view. Click the **Maintenance > DS1** tabs.
  - Step 7** Locate the VT that is reporting the alarm (for example, DS3 #2, DS1 #13).
  - Step 8** From the Loopback Type list, choose **Facility (line)** and click **Apply**.
  - Step 9** Click **Circuits**.
  - Step 10** Find the one-way circuit you created in Step 2. Select the circuit and click **Delete**.
  - Step 11** Click **Yes** in the Delete Confirmation box.
  - Step 12** Display the DS3XM-6 card in CTC card view. Click **Maintenance > DS1**.
  - Step 13** Locate the VT in Facility (line) Loopback.
  - Step 14** From the Loopback Type list, choose **None** and then click **Apply**.
  - Step 15** Click the **Alarm** tab and verify that the AIS-V alarms have cleared.
  - Step 16** Repeat the above steps for all the AIS-V alarms on the DS3XM-6 cards.
- 

### 2.4.2 Circuit Creation Error with VT1.5 Circuit

You might receive an “Error while finishing circuit creation. Unable to provision circuit. Unable to create connection object at <node name>” message when trying to create a VT1.5 circuit in CTC.

You may have run out of bandwidth on the VT cross-connect matrix at the ONS 15454 indicated in the error message. The matrix has a maximum capacity of 336 bidirectional VT1.5 cross-connects. Certain configurations will exhaust VT capacity with less than 336 bidirectional VT1.5s. Refer to the *Cisco ONS 15454 Installation and Operations Guide* for more information.

## 2.4.3 Unable to Create Circuit From DS-3 Card to DS3XM-6 Card

A circuit cannot be created from a DS-3 card to a DS3XM-6 card because the cards have different functions. DS3XM-6 converts each of its six DS-3 interfaces into 28 DS-1s for cross-connection through the network. Thus you can create a circuit from a DS3XM-6 card to a DS-1 card, but not from a DS3XM-6 card to a DS-3 card. These differences are evident in the STS path overhead. The DS-3 card uses asynchronous mapping for DS-3, which is indicated by the C2 byte in the STS path overhead that has a hex code of 04. A DS3XM-6 has a VT payload with a C2 hex value of 02.



### Note

You can find instructions for creating circuits in the *Cisco ONS 15454 Installation and Operations Guide*.

## 2.4.4 DS3 Card Does Not Report AIS-P From External Equipment

A DS3-12/DS3N-12/DS3-12E/DS3N-12E card does not report STS AIS-P from the external equipment/line side. The card is functioning as designed. This card terminates the port signal at the backplane so STS AIS-P is not reported from the external equipment/line side.

DS3-12/DS3N-12E cards do have DS3 header monitoring functionality, which allows you to view performance monitoring (PM) on the DS3 path. Nevertheless, you cannot view AIS-P on the STS path. For more information on the PM capabilities of the DS3-12E/DS3N-12E cards, refer to the *Cisco ONS 15454 Installation and Operations Guide*.

## 2.4.5 OC-3 and DCC Limitations

For an explanation of OC-3 and DCC limitations, see the DCC Tunnels section of the *Cisco ONS 15454 Installation and Operations Guide*.

## 2.4.6 ONS 15454 Switches Timing Reference

Timing references switch when one or more of the following problems occur:

- The optical or BITS input is receiving LOS, LOF, or AIS signals from another node.
- The optical or BITS input is not functioning.
- Sync Status Messaging (SSM) message is set to Don't Use for Sync (DUS).
- SSM indicates a Stratum 3 or lower clock quality.
- The input frequency is off by more than 15 ppm.
- The input clock wanders and has more than three slips in 30 seconds.
- A bad timing reference existed for at least two minutes.

The ONS 15454 internal clock operates at a Stratum 3 level of accuracy. This gives the ONS 15454 a free-running synchronization accuracy of  $\pm 4.6$  ppm and a holdover stability of less than 255 slips in the first 24 hours or  $3.7 \times 10^{-7}$ /day, including temperature.

ONS 15454 free running synchronization relies on the Stratum 3 internal clock. Over an extended time period, using a higher quality Stratum 1 or Stratum 2 timing source results in fewer timing slips than a lower quality Stratum 3 timing source.

## 2.4.7 Holdover Synchronization Alarm

The clock is running at the frequency of the last known good reference input. This alarm is raised when the last reference input fails. See the “HLDOVERSYNC” section on page 1-43 for a detailed description of this alarm.

**Note**

---

The ONS 15454 supports holdover timing per Telcordia standard GR-4436 when provisioned for external (BITS) timing.

---

## 2.4.8 Free-Running Synchronization Mode

The clock is using the internal oscillator as its only frequency reference. This occurs when no reliable, prior timing reference is available. See the “FRNGSYNC” section on page 1-42 for a detailed description of this alarm.

## 2.4.9 Daisy-Chained BITS Not Functioning

Daisy chaining BITS causes additional wander buildup in the network and is therefore not supported. Instead, use a timing signal generator to create multiple copies of the BITS clock and separately link them to each ONS 15454.

# 2.5 Fiber and Cabling

This section explains problems typically caused by cabling connectivity errors. It also includes instructions for creating Cat-5 cable and lists the optical fiber connectivity levels.

## 2.5.1 Bit Errors Appear for a Line Card

Bit errors on line (traffic) cards usually originate from cabling problems or low optical-line levels. The errors can be caused by synchronization problems, especially if PJ (pointer justification) errors are reported. Moving cards into different error-free slots will isolate the cause. Use a test set whenever possible because the cause of the errors could be external cabling, fiber, or external equipment connecting to the ONS 15454. Troubleshoot cabling problems using the “Network Tests” section on page 2-3. Troubleshoot low optical levels using the “Faulty Fiber-Optic Connections” section on page 2-29.

## 2.5.2 Faulty Fiber-Optic Connections

Faulty fiber-optic connections can be the source of SONET alarms and signal errors.

**Warning**

**Follow all directions and warning labels when working with optical fibers. To prevent eye damage, never look directly into a fiber or connector. Class IIIb laser. Danger, laser radiation when open. The OC-192 laser is off when the safety key is off (labeled 0). The laser is on when the card is booted and the safety key is in the on position (labeled 1). The port does not have to be in service for the laser to be on. Avoid direct exposure to the beam. Invisible radiation is emitted from the aperture at the end of the fiber optic cable when connected, but not terminated.**

## Procedure: Verify Fiber-Optic Connections

- 
- Step 1** Ensure that a single-mode fiber connects to the ONS 15454 OC-N card. SM or SM Fiber should be printed on the fiber span. ONS 15454 OC-N cards do not use multimode fiber.
- Step 2** Check that the connector keys on the SC fiber connector are properly aligned and locked.
- Step 3** Check that the single-mode fiber power level is within the specified range:
- a. Remove the receive (Rx) end of the suspect fiber.
  - b. Connect the receive end of the suspect fiber to a fiber-optic power meter, such as a GN Nettest LP-5000.
  - c. Determine the power level of fiber with the fiber-optic power meter.
  - d. Verify that the power level falls within the range specified for the card; see the “Optical Card Transmit and Receive Levels” section on page 2-35.
- Step 4** If the power level falls below the specified range:
- a. Clean or replace the fiber patch cords. If possible, do this for the OC-N card you are working on and the far-end card.
  - b. Clean the optical connectors on the card. If possible, do this for the OC-N card you are working on and the far-end card.
  - c. Ensure that the far-end transmitting card is not an ONS intermediate range (IR) card when an ONS long range (LR) card is appropriate.  
IR cards transmit a lower output power than LR cards.
  - d. Replace the far-end transmitting OC-N card to eliminate the possibility of a degrading transmitter on this OC-N card.
  - e. If the power level still falls below the specified range with the replacement fibers and replacement card, check for one of these three factors that attenuate the power level and affect link loss (LL):
    - Excessive fiber distance; single-mode fiber attenuates at approximately 0.5 dB/km.
    - Excessive number or fiber connectors; connectors take approximately 0.5 dB each.
    - Excessive number of fiber splices; splices take approximately 0.5 dB each.



**Note** These are typical attenuation values. Refer to the specific product documentation for the actual values or use an optical time domain reflectometer (OTDR) to establish precise link loss and budget requirements.

- Step 5** If no power level shows on the fiber, the fiber is bad or the transmitter on the optical card failed.
- Check that the Transmit (Tx) and Receive (Rx) fibers are not reversed. LOS and EOC alarms normally accompany reversed Tx and Rx fibers. Switching reversed Tx and Rx fibers clears the alarms and restores the signal.
  - Clean or replace the fiber patch cords. If possible, do this for the OC-N card you are working on and the far-end card.
  - Retest the fiber power level.
  - If the replacement fiber still shows no power, replace the optical card.

- Step 6** If the power level on the fiber is above the range specified for the card, ensure that an ONS long range (LR) card is not being used when an ONS intermediate range (IR) card is appropriate.

LR cards transmit a higher output power than IR cards. When used with short runs of fiber, an LR transmitter will be too powerful for the receiver on the receiving OC-N card.

Receiver overloads occur when maximum receiver power is exceeded.



**Tip**

To prevent overloading the receiver, use an attenuator on the fiber between the ONS OC-N card transmitter and the receiver. Place the attenuator on the receive transmitter of the ONS OC-N cards. Refer to the attenuator documentation for specific instructions.



**Tip**


Most fiber has text printed on only one of the two fiber strands. This can help clarify which strand is Tx and which is Rx.

## Procedure: Replace Faulty Gigabit Interface Converters

Gigabit interface converters (GBICs) are hot-swappable input/output devices that plug into a Gigabit Ethernet port to link the port with the fiber-optic network. Cisco provides two GBIC models: one for short reach applications, 15454-GBIC-SX, and one for long reach applications, 15454-GBIC-LX. The short reach, or “SX” model, connects to multimode fiber and has a maximum cabling distance of 1804 feet. The long reach, or “LX” model, requires single-mode fiber and has a maximum cabling distance of 32,810 feet.

GBICs are hot-swappable and can therefore be installed or removed while the card and shelf assembly are powered and running. GBIC transmit failure is characterized by a steadily blinking Fail LED on the Gigabit Ethernet (E1000-2/E1000-2-G) card. Figure 2-15 shows a GBIC.

**Figure 2-15** A gigabit interface converter (GBIC)



**Warning****Class 1 laser product****Warning****Invisible laser radiation may be emitted from the aperture ports of single-mode fiber optic modules when a cable is not connected. Avoid exposure and do not stare into open apertures.**

- 
- Step 1** Disconnect the network interface fiber-optic cable from the GBIC SC connector and replace the protective plug.
- Step 2** Release the GBIC from the card-interface by simultaneously squeezing the two plastic tabs (one on each side of the GBIC).
- Step 3** Slide the GBIC out of the Gigabit Ethernet front-panel slot.

**Note**

A flap closes over the GBIC slot to protect the connector on the Gigabit Ethernet (E1000-2/E1000-2-G) card.

- Step 4** Remove the new GBIC from its protective packaging.
- Step 5** Check the part number to verify that the GBIC is the correct type for your network.

**Caution**


Check the label on the GBIC carefully, the two GBIC models look similar.

- Step 6** Grip the sides of the GBIC with your thumb and forefinger and insert the GBIC into the slot on the front panel of the Gigabit Ethernet (E1000-2/E1000-2-G) card.

**Note**

GBICs are keyed to prevent incorrect installation.



**Figure 2-16** Installing a GBIC on the E1000-2/E1000-2-G card



- Step 7** Slide the GBIC through the front flap until you hear a click. The click indicates that the GBIC is locked into the slot.
- Step 8** When you are ready to attach the network interface fiber-optic cable, remove the protective plug from the GBIC and save the plug for future use.

## 2.5.3 Create CAT-5 Cables

You can manufacture your own CAT-5 cables for use with the ONS 15454. Use a cross-over cable when connecting an ONS 15454 to a router, hub, LAN modem, or switch, and use a straight-through cable when connecting an ONS 15454 to a workstation. Use CAT 5 cable RJ-45 T-568B, Color Code (100 Mbps).

**Figure 2-17 RJ-45 pin numbers****Figure 2-18 A straight-through cable layout****Table 2-3 Straight-Through Cable for Both Ends and Cross-Over Cable for First End**

| Pin | Color        | Pair | Name            |
|-----|--------------|------|-----------------|
| 1   | white/orange | 2    | Transmit Data + |
| 2   | orange       | 2    | Transmit Data - |
| 3   | white/green  | 3    | Receive Data +  |
| 4   | blue         | 1    |                 |
| 5   | white/blue   | 1    |                 |
| 6   | green        | 3    | Receive Data -  |
| 7   | white/brown  | 4    |                 |
| 8   | brown        | 4    |                 |

Figure 2-19 A cross-over cable layout




Table 2-4 Second End of Cross-over Cable

| Pin | Color        | Pair | Name       |
|-----|--------------|------|------------|
| 1   | white/green  | 3    | RecvData + |
| 2   | green        | 3    | RecData -  |
| 3   | white/orange | 2    | TxDData +  |
| 4   | blue         | 1    |            |
| 5   | white/blue   | 1    |            |
| 6   | orange       | 2    | TxDData -  |
| 7   | white/brown  | 4    |            |
| 8   | brown        | 4    |            |

**Note**

Odd numbered pins always connect to a white wire with a colored stripe.

## 2.5.4 Optical Card Transmit and Receive Levels

Each OC-N card has a transmit and receive connector on its faceplate.

Table 2-5 Optical Card Transmit and Receive Levels

| Optical card    | Rx            | Tx            |
|-----------------|---------------|---------------|
| OC3 IR 1310     | -8 to -28 dBm | -8 to -15 dBm |
| OC12 IR 1310    | -8 to -28 dBm | -8 to -15 dBm |
| OC12 LR 1310    | -8 to -28 dBm | +2 to -3 dBm  |
| OC12 LR 1550    | -8 to -28 dBm | +2 to -3 dBm  |
| OC48 IR 1310    | 0 to -18 dBm  | 0 to -5 dBm   |
| OC48 LR 1550    | -8 to -28 dBm | +3 to -2 dBm  |
| OC48 AS LR 1550 | -8 to -28 dBm | +3 to -2 dBm  |
| OC48 ELR DWDM   | -8 to -28 dBm | 0 to -2 dBm   |
| OC192 LR 1550   | -9 to -17 dBm | +10 to +7 dBm |

## 2.6 Power and LED Tests

This section provides the “Power Supply Problems” section on page 2-36, the “Power Consumption for Node and Cards” section on page 2-37, and the “Lamp Test for Card LEDs” section on page 2-37.

### 2.6.1 Power Supply Problems

The ONS 15454 requires a constant source of DC power to properly function. Input power is -48 VDC. Power requirements range from -42 VDC to -57 VDC.

A newly installed ONS 15454 that is not properly connected to its power supply will not operate. Power problems can be confined to a specific ONS 15454 or affect several pieces of equipment on the site.

A loss of power or low voltage can result in a loss of traffic and causes the LCD clock on the ONS 15454 to default to January 1, 1970, 00:04:15. For clock reset instructions, refer to the *Cisco ONS 15454 Installation and Operations Guide*.



#### Caution

Operations that interrupt power supply or short the power connections to the ONS 15454 are service affecting.



#### Warning

**When working with live power, always use proper tools and eye protection.**



#### Warning

**Always use the supplied electrostatic discharge (ESD) wristband when working with a powered ONS 15454. Plug the wristband cable into the ESD jack located on the lower-right outside edge of the shelf assembly.**

### Procedure: Isolate the Cause of Power Supply Problems

#### Step 1

If a single ONS 15454 show signs of fluctuating power or power loss:

- a. Check that the -48 VDC #8 power terminals are properly connected to a fuse panel. These power terminals are located on the lower section of the backplane EIA under the clear plastic cover.
- b. Check that the power cable is #12 or #14 AWG and in good condition.
- c. Check for properly crimped power cable connections. Stranded #12 or #14 AWG does not always crimp properly with Staycon type connectors.
- d. Check that 20A fuses are used in the fuse panel.
- e. Check that the fuses are not blown.
- f. Check that a rack ground cable attaches to the frame ground terminal (FGND) on the right side of the ONS 15454 EIA. Connect this cable to the ground terminal according to local site practice.
- g. Check that the DC power source has enough capacity to carry the power load.
- h. If the DC power source is battery based:
  - Check that the output power is high enough. Power requirements range from -42 VDC to -57 VDC.

- Check the age of the batteries. Battery performance decreases with age.
- Check for opens and shorts in batteries, which may affect power output.
- If brownouts occur, the power load and fuses may be too high for the battery plant.

- Step 2** If multiple pieces of site equipment show signs of fluctuating power or power loss:
- a. Check the uninterruptible power supply (UPS) or rectifiers that supply the equipment. Refer to the UPS manufacturer's documentation for specific instructions.
  - b. Check for excessive power drains caused by other equipment, such as generators.
  - c. Check for excessive power demand on backup power systems or batteries when alternate power sources are used.
- 

## 2.6.2 Power Consumption for Node and Cards

Refer to the “Card and Fan-Tray Assembly Power Requirements” section on page 4-5.

## 2.6.3 Lamp Test for Card LEDs

A lamp test verifies that all the card LEDs work. Run this diagnostic test as part of the initial ONS 15454 turn-up, a periodic maintenance routine, or any time you question whether an LED is in working order.

### Procedure: Verify Card LED Operation

- 
- Step 1** Click the **Maintenance > Diagnostic** tabs.
- Step 2** Click **Lamp Test**.
- Step 3** Watch to make sure all the LEDs on the physical cards light up for several seconds.
- Step 4** Click **OK** on the Lamp Test Run dialog box.

If a LED does not light up, the LED is faulty. Call the Cisco Technical Assistance Center (TAC) at 1-877-323-7368 and fill out an RMA to return the card.

---





## Maintenance

---

This chapter describes maintenance information and procedures for Cisco ONS 15454, including:

- Air filter inspection and replacement
- Fan-tray assembly replacement
- Alarm interface panel replacement
- System reset
- Database backup and restore
- Reverting to an earlier software load
- Card replacement
- TCC card to TCC+ card upgrade
- XC card to XCVT card upgrade
- XC/XCVT card to XC10G card upgrade
- DS3/DS3N card to DS3E/DS3EN card upgrade
- Span upgrades
- Protection group switching
- Electrical interface assembly (EIA) replacement
- Fiber cleaning
- Powering down a node

### 3.1 Air Filter Inspection and Replacement

The ONS 15454 contains an air filter that you should remove and visually inspect approximately every 30 days, depending on the cleanliness of the operating environment. NEBS 3E and later versions of the ONS 15454 use a reusable air filter that is installed either beneath the fan-tray assembly or in the optional external filter brackets. Earlier versions of the ONS 15454 use a disposable air filter that is installed beneath the fan-tray assembly only. For more information about filter brackets and air filter installation, see the “Installation” chapter of the *Cisco ONS 15454 Installation and Operations Guide*.



**Warning**

---


**Do not reach into a vacant slot or chassis while you install or remove a module or a fan. Exposed circuitry could constitute an energy hazard.**

---

## 3.1.1 Reusable Air Filter

The reusable filter is made of a gray, open-cell, polyurethane foam that is specially coated to provide fire and fungi resistance. NEBS 3E and later versions of the ONS 15454 use a reusable air filter. Figure 3-1 illustrates a reusable fan-tray air filter in an external filter bracket. When the filter is dirty, remove the filter and clean it by either vacuuming the filter or running water through it. Because the filter material is delicate, only a very low-power vacuum should be used. If you are cleaning with water, make sure the filter is completely dry (dry time is at least eight hours) before replacing it in the fan-tray assembly. Spare filters should be kept in stock.

**Figure 3-1** A reusable fan-tray air filter in an external filter bracket



### Procedure: Inspect and Clean the Reusable Air Filter

- 
- Step 1** If the air filter is installed in the external filter brackets, slide the filter out of the brackets while being careful not to dislodge any dust that may have collected on the filter and proceed to Step 3. If the filter is installed beneath the fan tray and not in the external filter brackets, open the ONS 15454 door and fold out the retractable handles at each outside edge of the fan tray.
  - Step 2** Slide the fan-tray assembly out of the shelf assembly by gently pulling the handles.
  - Step 3** Visually inspect the air filter material for dirt and dust.
  - Step 4** If the reusable air filter contains a concentration of dirt and dust, either vacuum the filter or wash the filter under a faucet with a light detergent.




---

**Note** If possible, cleaning should take place outside the operating environment to avoid releasing dirt and dust near the equipment.

---

- Step 5** If you washed the filter, allow it to completely air dry for at least eight hours and install a spare filter (spare filters should be kept in stock) in its place:



**Warning** Do not put a damp filter back in the ONS 15454.

- a. If the air filter is installed in the external filter brackets, slide the air filter all the way to the back of the brackets to complete the procedure.
- b. If the filter is installed beneath the fan-tray assembly, slide the air filter into the recessed compartment at the bottom of the shelf assembly. Put the front edge of the air filter flush against the front edge of the recessed compartment.

- Step 6** Push the fan tray back into the shelf assembly.



**Caution** If the fan tray does not slide all the way to the back of the shelf assembly, pull the fan tray out and readjust the position of the reusable filter until the fan tray fits correctly.



**Note** On a powered-up ONS 15454, the fans start immediately after the fan-tray assembly is correctly inserted.

- Step 7** Rotate the retractable handles back into their compartments and close the ONS 15454 front door.

## 3.1.2 Disposable Air Filter

Versions prior to the NEBS 3E version of the ONS 15454 use a disposable air filter. The disposable filter is made of spun white polyester that is flame retardant. This disposable filter is not designed to be cleaned. You can order air filter replacements from Cisco (Cisco P/N 47-01-00001) or from Universal Air Filter, model PE-5 (Universal Air Filter Co., 1624 Sauget Ind. Parkway, Sauget, IL 62206).




**Note** The disposable air filter is installed beneath the fan-tray assembly, so you must remove the fan-tray assembly to inspect and replace the disposable air filter.

### Procedure: Inspect and Replace the Disposable Air Filter

- Step 1** Remove the front door of the shelf assembly.
- Step 2** Open the front covers of the fiber management area.
- Step 3** Lower the hinged panels in front of the cable management tray.
- Step 4** Slide the fan-tray assembly out of the shelf assembly (see Figure 3-2).


**Figure 3-2** Inserting or removing the fan-tray assembly



- Step 5** Carefully slide the air filter out of the shelf assembly (see Figure 3-3). Be careful not to dislodge any dust that may have collected on the filter.
- Step 6** Visually inspect the white filter material for dirt and dust.
- Step 7** If the air filter shows a heavy concentration of dirt and dust, replace it with a new filter:
- a. Slide the filter into the bottom of the shelf assembly, making sure that the front of the filter is flush with the front of the shelf assembly.
 

To be sure you are installing the air filter correctly, make sure the air flow indicators on the filter point upwards.

**Figure 3-3** Inserting or removing a disposable fan-tray air filter



- Step 8** Slide the fan-tray assembly into the shelf assembly until the electrical plug at the rear of the tray plugs into the corresponding receptacle on the backplane.
- Step 9** To verify that the tray is plugged into the backplane, ensure that the LCD on the front of the fan-tray assembly is activated.
- Step 10** Close the cable management tray.
- Step 11** Raise the hinged panel at the front of the cable management tray.
- Step 12** Close the front covers of the fiber management area.
- Step 13** Replace the front door of the shelf assembly.

## 3.2 Fan-Tray Assembly Replacement

If one or more fans fail on the fan-tray assembly, replace the entire assembly. You cannot replace individual fans. The red Fan Fail LED on the front of the fan tray illuminates when one or more fans fail. The red Fan Fail LED clears after you install a working fan tray.



### Caution

The 15454-FTA3 fan-tray assembly can only be installed in ONS 15454 Release 3.1 shelf assemblies (15454-SA-ANSI, P/N: 800-19857). It includes a pin that does not allow it to be installed in ONS 15454 shelf assemblies released before ONS 15454 Release 3.1 (15454-SA-NEBS3E, 15454-SA-NEBS3, and 15454-SA-R1, P/N: 800-07149). Equipment damage can result from attempting to install the 15454-FTA3 in a non-compatible shelf assembly.

**Note**

The 10-Gbps compatible shelf assembly (15454-SA-ANSI) and fan-tray assembly (15454-FTA3) are required with the ONS 15454 XC-10G, OC-192, and OC-48 any slot (AS) cards.

## Procedure: Replace the Fan-Tray Assembly

To replace the fan-tray assembly, it is not necessary to move any of the cable management facilities. You can remove the fan-tray assembly using the retractable handles and replace it by pushing until it plugs into the receptacle on the back panel.

**Caution**

Do not force a fan-tray assembly into place. Doing so can damage the connectors on the fan tray and/or the connectors on the back panel of the shelf assembly.


- Step 1** Remove the front door of the shelf assembly.
- Step 2** Fold out the retractable handles at the outside edges of the fan tray.
- Step 3** Slide the fan tray out of the shelf assembly by gently pulling on the handles. Figure 3-4 shows the location of the fan tray.
- Step 4** If you are replacing the fan-tray air filter and it is installed beneath the fan-tray assembly, slide the existing air filter out of the shelf assembly and replace it before replacing the fan-tray assembly.  
If you are replacing the fan-tray air filter and it is installed in the external bottom bracket, you can slide the existing air filter out of the bracket and replace it at anytime.

**Note**

The air filter will function with either side facing up but Cisco recommends that you install the filter with the metal bracing facing up against the fan tray.

For more information on the fan-tray air filter, see the “Air Filter Inspection and Replacement” section on page 3-1.

- Step 5** Slide the fan tray into the shelf assembly until the electrical plug at the rear of the tray plugs into the corresponding receptacle on the backplane.
- Step 6** To verify that the tray has plugged into the backplane, check that the LCD on the front of the fan tray is activated.

**Figure 3-4** Removing or replacing the fan-tray assembly

## 3.3 Alarm Interface Panel Replacement

If the alarm interface panel (AIP) fails, a MAC Fail alarm displays on the CTC Alarms menu and/or the LCD display on the fan tray will go blank.

**Note**

A blown fuse on the AIP board can cause the LCD display to go blank.

To return a failed AIP, you must follow the standard Return Material Authorizations (RMA) procedures; call (800) 553-NETS (6387) if you do not have an RMA number. Call Cisco Technical Assistance Center (TAC) at 877-323-7368 for assistance in replacing the AIP and maintaining the original MAC address. For more information on the AIP, see Chapter 1 in the *Cisco ONS 15454 Installations and Operations Guide*.

**Caution**

Do not perform this procedure on a node with live traffic. Hot-swapping the alarm interface panel (AIP) can affect traffic and result in a loss of data. For assistance with AIP replacement contact Cisco Technical Assistance Center (TAC) at 877-323-7368.

## Procedure: Replace the Alarm Interface Panel

- 
- Step 1** Remove the clear plastic cover from the AIP.
  - Step 2** Unscrew the two screws that hold the AIP in place.
  - Step 3** Grip the panel on each side.
  - Step 4** Gently remove the panel from the backplane.
  - Step 5** Remove the fan-tray assembly power cable.
  - Step 6** Attach the fan-tray assembly power cable to the new AIP.
  - Step 7** Place the new AIP on the backplane by plugging the panel into the backplane using the DIN connector.
  - Step 8** Replace the screws that secure the pane to the backplane.
  - Step 9** Reset both TCC+s, one at a time.
- 

## 3.4 System Reset

You can reset the ONS 15454 TCC+ cards by using the Cisco Transport Controller (CTC) software, or by physically reseating a TCC+ card (card pull). A software-initiated reset reboots the TCC+ and reloads the operating system and the application software. Additionally, a card pull reset temporarily removes power from the TCC+ and clears all buffer memory.

You can apply a software-initiated reset to either an active or standby TCC+ without affecting traffic, but you should only perform a card pull on a standby TCC+. If you need to perform a card pull on an active TCC+, put the TCC+ into standby mode first by performing a software-initiated reset on the card.

**Note**

---

When a software-initiated reset is performed on an active TCC card or TCC+, the AIC card goes through an initialization process and also resets. The AIC card reset is normal and will happen each time an active TCC card goes through a software-initiated reset.

---

**Warning**

---


**Do not reach into a vacant slot or chassis while you install or remove a module or a fan. Exposed circuitry could constitute an energy hazard.**

---

## Procedure: Perform a Software-Initiated Reset

- 
- Step 1** Log into CTC.
  - Step 2** Right click on the TCC+ card to reveal a pull-down menu.
  - Step 3** Click **Reset Card** (see Figure 3-5).
  - Step 4** Click **Yes** when the “Are You Sure?” dialog box appears.
  - Step 5** Click **OK** when the “Lost connection to node, changing to Network View” dialog box appears.
  - Step 6** Confirm that the TCC+ is in standby mode after the reset.

Figure 3-5 Performing a software-initiated reset from the TCC+ card pull-down menu



61335

## Procedure: Perform a Card Pull



### Note

To determine whether you have an active or standby TCC+, position the cursor over the TCC+ card graphic to display the status.

- Step 1** If you need to perform a card pull on an active TCC+ card, first perform a software-initiated reset on the active TCC+ (see the “Perform a Software-Initiated Reset” procedure on page 3-8).
- Step 2** When the TCC+ is in standby mode, unlatch both the top and bottom ejector levers on the TCC+ card.
- Step 3** Physically pull the card at least partly out of the slot until the lighted LEDs turn off.
- Step 4** Wait 30 seconds. Reinsert the card and close the ejector levers.



### Note

The TCC+ will take several minutes to reboot and will display the amber standby LED after rebooting.

## 3.5 Database Backup and Restore

When dual TCC+ cards are installed in the ONS 15454, each TCC+ card hosts a separate database; therefore, the protect card's database is available if the database on the working TCC+ fails. You can also store a back-up version of the database on the workstation running CTC. This operation should be part of a regular ONS 15454 maintenance program at approximately weekly intervals, and should also be completed when preparing an ONS 15454 for a pending natural disaster, such as a flood or fire.



### Caution

E1000-2 cards lose traffic for approximately 90 seconds when an ONS 15454 database is restored. Traffic is lost during the period of spanning tree reconvergence. The CARLOSS alarm will appear and clear during this period.




### Caution

If you are restoring the database on multiple nodes, wait five minutes between each database restore.

### Procedure: Back up the Database

- Step 1** Log into CTC.
- Step 2** Click the **Maintenance > Database** tabs.

**Figure 3-6** Backing up the TCC+ database



- Step 3** Click **Backup**.
- Step 4** Save the database on the workstation's hard drive or on network storage. Use an appropriate file name with the .db file extension, for example, database.db.

**Step 5** Click **Save**.

**Figure 3-7** Confirming a database backup




**Step 6** Click **OK** in the confirmation dialog box.

## Procedure: Restore the Database

**Step 1** Log into CTC.

**Step 2** Click the **Maintenance > Database** tabs.

**Figure 3-8** Restoring the TCC+ database




**Step 3** Click **Restore**.

**Step 4** Locate the database file stored on the workstation's hard drive or on network storage.

**Step 5** Click the database file to highlight it.

**Step 6** Click **Open**.

The DB Restore dialog box appears. A restore from another node will affect traffic.

**Figure 3-9 Restoring the database—traffic loss warning**

**Step 7** Click **Yes**.

The Restore Database dialog box monitors the file transfer.

**Figure 3-10 Restoring the database – in-process notification**

**Step 8** Wait for the file to complete the transfer to the TCC+.

**Step 9** Click **OK** when the “Lost connection to node, changing to Network View” dialog box appears. Wait for the node to reconnect.

## 3.6 Reverting to an Earlier Software Load

Prior to Release 2.2.1, the ONS 15454 could not revert to an earlier software database without deleting the current database and losing both cross-connect and DCC connectivity. The revert would result in a loss of traffic until the user manually restored the previous database or recreated the existing circuits and provisioning.

Reverting to a 2.2.1 or later load will switch to the older software load and its attendant database without affecting traffic or DCC connectivity. This feature requires dual TCC+ cards and CTC software Release 2.2.1 or later as the protect version.

When you click the Activate button after a software upgrade, the TCC+ copies the current working database and saves it in a reserved location in the TCC+ flash memory. If you later need to revert to the original working software load from the protect software load, the saved database installs automatically. You do not need to restore the database manually or recreate circuits.



### Tip

The revert feature is useful if a maintenance window closes while you are upgrading CTC software. You can revert to the standby software load without losing traffic. When the next maintenance window opens, complete the upgrade and activate the new software load.

**Note**

A revert to a maintenance release software load does not restore the database and no provisioning is lost. All other reverts do restore the database. (A maintenance release has a three-digit release number, e.g. 2.2.2).

**Note**

Circuits created and provisioning performed after a software load is activated will not reinstate with a revert. The database configuration at the time of activation is reinstated after a revert. This note does not apply to maintenance reverts (e.g. 2.2.2 to 2.2.1).

## Procedure: Revert to an Earlier Software Load

- 
- Step 1** Log into CTC.
- Step 2** Record the IP address of that node.
- Step 3** Display the CTC node view.
- Step 4** Right click the standby TCC+ card to reveal a pull-down menu.
- Step 5** Click **Reset Card**.
- Step 6** Click **Yes** when the “Are You Sure?” dialog box appears.
- Step 7** Click **OK** when the “Lost connection to node, changing to Network View” dialog box appears.
- Step 8** Confirm that the TCC+ is in standby mode after the reset.
- Step 9** Click the **Maintenance > Software** tabs.
- Step 10** Verify that the protect software is Version 2.2.0 or later.
- Step 11** Click **Revert**.
- The Revert button activates the protect software load. The ONS 15454 reboots and loses the connection to CTC.
- Step 12** Wait until the software upgrade finishes.
- This may take as long as 30 minutes.
- Step 13** Completely close the browser.
- Step 14** Restart the browser and log back into the node using the IP address recorded in Step 2.
- The browser downloads the CTC applet for the standby software load.
-

## 3.7 Card Replacement

To replace an ONS 15454 card with another card of the same type, you do not need to make any changes to the database; remove the old card and replace it with a new card. To replace a card with a card of a different type, physically remove the card and replace it with the new card, then delete the original card from CTC. Follow the “Switch Traffic and Replace an In-Service Cross-Connect Card” procedure on page 3-14 to replace an XC/XCVT card.



### Caution

Removing any active card from the ONS 15454 can result in traffic interruption. Use caution when replacing cards and verify that only inactive or standby cards are being replaced. If the active card needs to be replaced, switch it to standby prior to removing the card from the node.



### Note

An improper removal (IMPROPRMVL) alarm is raised whenever a card pull is performed, unless the card is deleted in CTC first. The alarm will clear after the card replacement is complete.



### Note

In a UPSR, pulling the active XC/XCVT/XC10G without a lockout will cause UPSR circuits to switch.



### Warning

**Do not reach into a vacant slot or chassis while you install or remove a module or a fan. Exposed circuitry could constitute an energy hazard.**

To upgrade cards, refer to the specific upgrade procedure you need:

- “TCC Card to TCC+ Card Upgrade” section on page 3-15
- “XC Card to XCVT Card Upgrade” section on page 3-17
- “XC/XCVT Card to XC10G Card Upgrade” section on page 3-18
- “DS3/DS3N Card to DS3E/DS3EN Card Upgrade” section on page 3-20

For more information on cards and card compatibility see Chapter 4, “Card Reference.”

### Procedure: Switch Traffic and Replace an In-Service Cross-Connect Card



### Caution

Removing any active card from the ONS 15454 can result in traffic interruption. Use caution when replacing cards and verify that only inactive or standby cards are being replaced. If the active card needs to be replaced, follow the steps below to switch the XC/XCVT card to standby prior to removing the card from the node.

An XC/XCVT reset can cause a linear 1+1 OC-N protection switch or a BLSR protection switch.

### Step 1

Take the following precautions before performing an XC/XCVT reset to avoid causing a linear 1+1 or BLSR protection switch:

- a. Ensure the working span is active on both the local and remote nodes.
- b. Ensure the working span is carrying error-free traffic (no SD or SF alarms present).

- c. Lockout the protection span prior to initiating an XC/XCVT reset.

In a BLSR, place a lockout on the East and West cards of the nodes adjacent to the XC/XCVT switch node; for example, to switch the XC/XCVT on Node B, place the lockout on the West card of Node A and on the East card of Node C. No lockout is necessary on Node B. Before the lockout is set, verify that the BLSR is not switched. If a lockout is set while the BLSR is switched, traffic can be lost.

<-----East [Node A] West-----East [Node B] West-----East [Node C] West----->

In a 1+1 protection scheme, place a lockout on the protect card and verify that the traffic is traveling over the working span before setting the lockout.

- Step 2** Determine the active XC/XCVT card. The ACT/STBY LED of the active card is green. The ACT/STBY LED of the standby card is amber.



**Note** You can also place the cursor over the card graphic to display a pop-up identifying the card as active or standby.

- Step 3** Switch the active XC/XCVT card to standby:
- a. In the node view, click the **Maintenance > XC Cards** tabs.
  - b. Under Cross Connect Cards, choose **Switch**.
  - c. Click **Yes** on the Confirm Switch dialog box.



**Note** After the active XC/XCVT goes into standby, the original standby slot becomes active. This causes the ACT/STBY LED to become green on the former standby card.

- Step 4** Physically remove the new standby XC/XCVT card from the ONS 15454.
- Step 5** Insert the replacement XC/XCVT card into the empty slot.  
The replacement card boots up and becomes ready for service after approximately one minute.
- Step 6** Release the protection lockout(s).

## 3.8 TCC Card to TCC+ Card Upgrade



### Caution

The ONS 15454 Release 3.1 must operate with a matching pair of TCC+ cards.

The TCC card supports ONS 15454 Release 2.2.2 and earlier software versions. The TCC+ card supports ONS 15454 Release 2.2.0 and later software versions.

Verify that the ONS 15454 is running Release 2.2.0 software before you begin the upgrade procedure. The TCC to TCC+ upgrade process requires Release 2.2.0 to support the TCC/TCC+ mismatch that occurs briefly during the TCC to TCC+ upgrade process.

The ACT/STBY LED on the faceplate of the TCC/TCC+ card indicates whether the card is in active or standby mode. A green ACT/STBY LED indicates an active card and an amber light indicates a standby card. See Chapter 5 for more information about the TCC/TCC+ card.

## Procedure: Upgrade the TCC Card to the TCC+ Card

- Step 1** Physically replace the standby TCC card on the ONS 15454 with a TCC+ card.
- Open the TCC card ejectors.
  - Slide the card out of the slot. This raises the IMPROPRMVL alarm which will clear when the upgrade is complete.
  - Open the ejectors on the TCC+ card.
  - Slide the TCC+ card into the slot along the guide rails.
  - Close the ejectors.



**Note** The MEA (card mismatch) alarm appears because CTC recognizes a mismatch between TCC card types. Disregard this alarm; it clears by the end of the procedure.




**Note** It takes approximately 20 or 30 minutes for the active TCC to transfer the system software to the newly-installed TCC+. Software transfer occurs in instances where different software versions exist on the two cards. During this operation, the LEDs on the TCC+ flash Fail and then the active/standby LED flashes. When the transfer completes, the TCC+ reboots and goes into standby mode after approximately three minutes.

- Step 2** Right click the active TCC card to reveal a pull-down menu.

- Step 3** Click **Reset Card** (Figure 3-11).

**Figure 3-11** Initiating a software reset on the TCC card



Wait for the TCC to reboot. The ONS 15454 switches the standby TCC+ card to active mode.

**Step 4** Verify that the remaining TCC card is now in standby mode (the ACT/STBY LED changes to amber).

**Step 5** Physically replace the remaining TCC card with the second TCC+ card.

- a. Open the TCC card ejectors.
- b. Slide the card out of the slot.
- c. Open the ejectors on the TCC+ card.
- d. Slide the TCC+ card into the slot along the guide rails.
- e. Close the ejectors.

The ONS 15454 boots up the second TCC+ card. The second TCC+ must also copy the system software, which can take up to 20 or 30 minutes. The MEA alarm clears when the ONS 15454 recognizes the matching TCC+s.

## 3.9 XC Card to XCVT Card Upgrade

This section explains how to replace dual XC cards with dual XCVT cards in an ONS 15454 with live traffic. The procedure is non-service affecting, that is, the upgrade will cause a switch less than 50 ms in duration.



**Note**

The UNEQ-P alarm might be raised during a cross-connect card upgrade if you have E100/E1000 cards in the system. The alarm will appear and clear within a few seconds.

### Procedure: Upgrade the XC Card to the XCVT Card

Upgrading XC cards to XCVT requires that the ONS 15454 is running CTC Release 2.0 or later. Two XC cards must be installed in the ONS 15454, and two XCVT cards must be available for installation. An XC switch can cause a linear 1+1 OC-N protection switch or a BLSR protection switch.

**Step 1** Take the following precautions before performing an XC switch to avoid causing a linear 1+1 or BLSR protection switch:

- a. Ensure the working span is active on both the local and remote nodes.
- b. Ensure the working span is carrying error-free traffic (no SD or SF alarms present).
- c. Lockout the protection span prior to initiating an XC reset.

In a BLSR, place a lockout on the East and West cards of the nodes adjacent to the XC switch node; for example, to switch the XC on Node B, place the lockout on the West card of Node A and on the East card of Node C. No lockout is necessary on Node B. Before the lockout is set, verify that the BLSR is not switched. If a lockout is set while the BLSR is switched, traffic can be lost.

<-----East [Node A] West-----East [Node B] West-----East [Node C] West----->

In a 1+1 protection scheme, place a lockout on the protect card and verify that the traffic is traveling over the working span before setting the lockout.

**Step 2** Determine the standby XC card. The ACT/STBY LED of the standby XC card is amber, while the ACT/STBY LED of the active XC card is green.




---

**Note** You can also place the cursor on the card graphic in CTC to display a dialog. This display identifies the card as XC: Active or XC: Standby.

---

- Step 3** Physically replace the standby XC card on the ONS 15454 with an XCVT card:
- Open the XC card ejectors.
  - Slide the card out of the slot. This raises the IMPROPRMVL alarm, which will clear when the upgrade is complete.
  - Open the ejectors on the XCVT card.
  - Slide the XCVT card into the slot along the guide rails.  
The fail LED above the ACT/STBY LED becomes red, blinks for several seconds, and turns off. The ACT/STBY LED turns amber and stays lit.
  - Close the ejectors.
- Step 4** In node view, choose the **Maintenance > XC Cards** tabs.
- Step 5** From the Cross Connect Cards menu, choose **Switch**.
- Step 6** Click **Yes** on the Confirm Switch dialog box.




---

**Note** After the active XC disengages, the standby slot or first XCVT card becomes active. This causes the ACT/STBY LED on the first XCVT card to change from amber to green.

---

- Step 7** Physically remove the now standby XC card from the ONS 15454 and insert the second XCVT card into the empty XC slot:
- Open the XC card ejectors.
  - Slide the card out of the slot.
  - Open the ejectors on the XCVT.
  - Slide the XCVT card into the slot along the guide rails.
  - Close the ejectors.
- The upgrade is complete when the second XCVT card boots up and becomes the standby XCVT.
- Step 8** Release the protection lockout.
- 

## 3.10 XC/XCVT Card to XC10G Card Upgrade




---

**Note** This procedure only applies to XC/XCVT cards that are installed in the 15454-SA-ANSI (Release 3.1). You cannot perform this upgrade from shelves released prior to 3.1. The XC10G requires the 15454-SA-ANSI.

---




---

**Note** The UNEQ-P alarm might be raised during a cross-connect card upgrade if you have E100/E1000 cards in the system. The alarm will appear and clear within a few seconds.

---

This section explains how to upgrade dual XC/XCVT cards with dual XC10G cards in the ONS 15454-SA-ANSI with live traffic. The procedure is non-service affecting, that is, the upgrade will cause a switch less than 50 ms in duration.

## Procedure: Upgrade the XC/XCVT Card to the XC10G Card

Upgrading XC/XCVT cards to XC10G requires that the ONS 15454 is running CTC Release 3.1 or later. Two XC/XCVT cards must be installed in the ONS 15454-SA-ANSI, and two XC10G cards must be available for installation. An XC/XCVT switch can cause a linear 1+1 OC-N protection switch or a BLSR protection switch.

**Step 1** Take the following precautions before performing an XC/XCVT switch to avoid causing a linear 1+1 or BLSR protection switch:

- a. Ensure the working span is active on both the local and remote nodes.
- b. Ensure the working span is carrying error-free traffic (no SD or SF alarms present).
- c. Lockout the protection span prior to initiating an XC/XCVT reset.

In a BLSR, place a lockout on the East and West cards of the nodes adjacent to the XC/XCVT switch node; for example, to switch the XC/XCVT on Node B, place the lockout on the West card of Node A and on the East card of Node C. No lockout is necessary on Node B. Before the lockout is set, verify that the BLSR is not switched. If a lockout is set while the BLSR is switched, traffic can be lost.

<-----East [Node A] West-----East [Node B] West-----East [Node C] West----->

In a 1+1 protection scheme, place a lockout on the protect card and verify that the traffic is traveling over the working span before setting the lockout.

**Step 2** Determine the standby XC/XCVT card. The ACT/STBY LED of the standby XC/XCVT card is amber, while the ACT/STBY LED of the active XC/XCVT card is green.



**Note** You can also place the cursor on the card graphic in CTC to display a dialog. This display identifies the card as XC/XCVT: Active or XC/XCVT: Standby.

**Step 3** Physically replace the standby XC/XCVT card on the ONS 15454 with an XC10G card:

- a. Open the XC/XCVT card ejectors.
- b. Slide the card out of the slot. This raises the IMPROPRMVL alarm, which will clear when the upgrade is complete.
- c. Open the ejectors on the XC10G card.
- d. Slide the X10G card into the slot along the guide rails.
 

The fail LED above the ACT/STBY LED becomes red, blinks for several seconds, and turns off. The ACT/STBY LED turns amber and stays lit.
- e. Close the ejectors.

**Step 4** In node view, choose the **Maintenance > XC Cards** tabs.

**Step 5** From the Cross Connect Cards menu, choose **Switch**.

**Step 6** Click **Yes** on the Confirm Switch dialog box.




---

**Note** After the active XC/XCVT disengages, the standby slot or first XC10G card becomes active. This causes the ACT/STBY LED on the first XC10G card to change from amber to green.

---

- Step 7** Physically remove the now standby XC/XCVT card from the ONS 15454 and insert the second XC10G card into the empty XC/XCVT slot:
- a. Open the XC/XCVT card ejectors.
  - b. Slide the card out of the slot.
  - c. Open the ejectors on the XC10G.
  - d. Slide the XC10G card into the slot along the guide rails.
  - e. Close the ejectors.

The upgrade is complete when the second XC10G card boots up and becomes the standby XC10G.

- Step 8** Release the protection lockout.
- 

## 3.11 DS3/DS3N Card to DS3E/DS3EN Card Upgrade

You can perform in-service DS3E upgrades for the following ONS 15454 cards:

- DS3 to a DS3E
- DS3N to a DS3EN

### Procedure: Upgrade the DS3 Card to the DS3E Card (or the DS3N Card to the DS3EN Card)

Upgrading to DS3E or DS3EN cards requires that the ONS 15454 is running CTC Release 3.1 or later. Upgrades must be performed between two N-type cards or two non-N-type cards. You cannot upgrade between an N-type card and a non-N-type card. When physically replacing the card, the new card must be in same slot as the old card. The DS3E card upgrade supports 1:1 and 1:N protection schemes. The procedure is non-service affecting, that is, the upgrade will cause a switch less than 50 ms in duration.




---

**Note** This procedure can also be used to bring forth the capabilities of a DS3E card that was installed in a chassis prior to having the Release 3.1 software load.

---




---

**Note** Protect cards must be upgraded before working cards because working cards cannot have more capabilities than their protect card.

---




---

**Note** During the upgrade some minor alarms and conditions will be raised and will clear on their own; however, there should be no Service-Affecting (SA, Major, or Critical) alarms. If any Service-Affecting alarms occur, Cisco recommends backing out of the procedure.

---

- Step 1** If the card you are upgrading is unprotected, skip to Step 2. If the card you are upgrading is protected, first lockout the protect card:



---

**Note** Traffic will be lost during an upgrade on an unprotected card.

---

- a. In node view, click the **Maintenance > Protection** tabs.
  - b. Under Protection Groups, click on the 1:1 or 1:N protection group (that is, the group supporting the 1:1 or 1:N span cards).
  - c. Under Selected Group, click on the protect card.
  - d. From Inhibit Switching, click **Lock Out**.
  - e. Click **Yes** on the confirmation dialog box.
- Step 2** Physically remove the protect DS3 or the protect DS3N card:
- a. Open the DS3/DS3N card ejectors.
  - b. Slide the card out of the slot. This raises the IMPROPRMVL alarm, which will clear when the upgrade is complete.
- Step 3** Right click on the protect slot and choose **Change Card** from the pull-down menu.
- Step 4** Choose the new card (DS3E or DS3NE) from the Change to: pull-down menu.
- Step 5** Click **OK**.
- Step 6** Insert the new DS3E or DS3NE card into the protect slot:
- a. Open the ejectors on the DS3E/DS3NE card.
  - b. Slide the DS3E/DS3NE card into the slot along the guide rails.
- Step 7** Close the ejectors.  
Wait for the IMPROPRMVL alarm to clear and the card to become standby.
- Step 8** Remove the lockout on the protect card:
- a. In node view, click the **Maintenance > Protection** tabs.
  - b. Under Protection Groups, click on the 1:1 or 1:N protection group (that is, the group supporting the 1:1 or 1:N span cards).
  - c. Under Selected Group, click on the protect card.
  - d. From Inhibit Switching, click **Unlock**.
  - e. Click **Yes** on the confirmation dialog box.
- Step 9** Repeat the steps above for the working card.
- 

## Procedure: Downgrade a DS3 or DS3N Card

Downgrading can be performed to back out of an upgrade. All ports must be provisioned as UNFRAMED and not have the Path Trace enabled.



---

**Note** Working cards must be downgraded before protect cards.

---

The procedure for downgrading is the same as upgrading except you choose DS3 or DS3N from the Change Card pull-down menu. To begin the downgrade, right click on the slot to be downgraded and choose **Change Card** from the pull-down menu as instructed above in Step 4 of the upgrade. Follow the remaining steps of the upgrade until the downgrade is complete.

## 3.12 Span Upgrades

A span is the optical fiber connection between two ONS 15454 nodes. In a span upgrade, the transmission rate of a span is upgraded from a lower to a higher OC-N signal but all other span configuration attributes remain unchanged. With multiple nodes, a span upgrade is a coordinated series of upgrades on all nodes in the ring or protection group in which traffic carried at a lower OC-N rate is transferred to a higher OC-N. You can perform in-service span upgrades for the following ONS 15454 cards:

- OC-12 to OC-48
- OC-12 to OC-192
- OC-48 to OC-192

Use the XC10G card, the TCC+ card, Software R3.1 or higher and the new 15454-SA-ANSI shelf assembly to enable the OC48 IR/STM16 SH AS 1310, OC48 LR/STM16 LH AS 1550, and the OC192 LR/STM64 LH 1550 cards. See Chapter 4, “Card Reference,” for more information on card compatibility.

To perform a span upgrade, the higher-rate optical card must replace the lower-rate card in the same slot. If the upgrade is conducted on spans residing in a BLSR, all spans in the ring must be upgraded. The protection configuration of the original lower-rate optical card (two-fiber BLSR, four-fiber BLSR, UPSR, and 1+1) is retained for the higher-rate optical card.

When performing span upgrades on a large number of nodes, Cisco recommends that you upgrade all spans in a ring consecutively and in the same maintenance window. Until all spans are upgraded, mismatched card types will be present.

Cisco recommends using the Span Upgrade Wizard to perform span upgrades. Although you can also use the manual span upgrade procedures, the manual procedures are mainly provided as error recovery for the wizard. The Span Upgrade Wizard and the Manual Span Upgrade procedures require at least two technicians (one at each end of the span) who can communicate with each other during the upgrade. Upgrading a span is non-service affecting and will cause no more than three switches, each of which is less than 50 ms in duration.



### Note

Do not perform any other maintenance operations or add any circuits during a span upgrade.



### Note

Span upgrades do not upgrade SONET topologies, for example, a 1+1 group to a two-fiber BLSR. See the *Cisco ONS 15454 Installation and Operations Guide* for topology upgrade procedures.



### Warning

**Do not reach into a vacant slot or chassis while you install or remove a module or a fan. Exposed circuitry could constitute an energy hazard.**

## 3.12.1 Span Upgrade Wizard

The Span Upgrade Wizard automates all steps in the manual span upgrade procedure (BLSR, UPSR, and 1+1). The wizard can upgrade both lines on one side of a four-fiber BLSR or both lines of a 1+1 group; the wizard upgrades UPSRs and two-fiber BLSRs one line at a time. The Span Upgrade Wizard requires that spans have DCC enabled.

The Span Upgrade Wizard provides no way to back out of an upgrade. In the case of an abnormal error, you must exit the wizard and initiate the manual procedure to either continue with the upgrade or back out of it. To continue with the manual procedure, examine the standing conditions and alarms to identify the stage in which the wizard failure occurred.

**Note**

The Span Upgrade Wizard only supports OC-N span upgrades. It does not support DS-3 upgrades.

**Note**

During the upgrade some minor alarms and conditions will be raised and will clear automatically. There should be no service-affecting (SA, Major, or Critical) alarms. If any service-affecting alarms occur, Cisco recommends backing out of the procedure. BLSR Out of Sync alarms will be raised during span upgrades and will clear when the upgrade of all nodes is complete; a four-node BLSR can take up to five minutes to clear all of the Out of Sync alarms. Allow extra time for a large BLSR to clear all of the Out of Sync alarms.

**Note**


If any of the cross connect cards reboot during the span upgrade, you must manually reset the card once the span upgrade procedure is completed on all the nodes in the ring.

### Procedure: Perform a Span Upgrade Using the Span Upgrade Wizard

The following procedure shows the Span Upgrade Wizard upgrading the first line of a two-fiber BLSR from OC-48 to OC-192.


- Step 1** Ensure that no alarms or abnormal conditions (regardless of severity), including LOS, LOF, AIS-L, SF, SD, and FORCED-REQ-RING are present:
- In network view, click on the **Alarms** tab to view a list of current alarms.
  - In network view, click on the **Conditions** tab and click the **Retrieve Conditions** button to view a list of current conditions.
- An unresolved alarm or abnormal condition is the most probable reason for upgrade failure.
- Step 2** In network view, right-click the span you want to upgrade.
- Step 3** Choose Span Upgrade from the pull-down menu (Figure 3-12).

Figure 3-12 Span pull-down menu



The first Span Upgrade Dialog box appears (Figure 3-13). Follow the instructions on the dialog box and the wizard will lead you through the rest of the span upgrade. The <Back button is only enabled on Step 2 of the wizard; because you cannot back out of an upgrade via the wizard, exit the wizard and initiate the manual procedure if you need to back out of the upgrade at any point beyond Step 2.

Figure 3-13 Beginning the Span Upgrade Wizard



**Note** Remember to attach the fiber after installing the OC-N cards.

## 3.12.2 Manual Span Upgrades

Manual Span Upgrades are mainly provided as error recovery for the Span Upgrade Wizard, but they can be used to perform span upgrades. Downgrading can be performed to back out of a span upgrade. The procedure for downgrading is the same as upgrading except that you choose a lower-rate card type. You cannot downgrade if circuits exist on the STSs that will be removed (the higher STSs).

Choose from four manual span upgrade options:

- “Perform a Manual Span Upgrade on a Two-Fiber BLSR” procedure on page 3-25
- “Perform a Manual Span Upgrade on a Four-Fiber BLSR” procedure on page 3-26
- “Perform a Manual Span Upgrade on a UPSR” procedure on page 3-27
- “Perform a Manual Span Upgrade on a 1+1 Protection Group” procedure on page 3-28



### Note

During the upgrade some minor alarms and conditions will be raised and will clear automatically. There should be no service-affecting (SA, Major, or Critical) alarms. If any service-affecting alarms occur, Cisco recommends backing out of the procedure.

BLSR Out of Sync alarms will be raised during span upgrades and will clear when the upgrade of all nodes is complete. Allow extra time for a large BLSR to clear all of the Out of Sync alarms.



### Note

If any of the cross connect cards reboot during the span upgrade, you must manually reset the card once the span upgrade procedure is completed on all the nodes in the ring.

### Procedure: Perform a Manual Span Upgrade on a Two-Fiber BLSR

All spans connecting the nodes in a BLSR must be upgraded before the added bandwidth is available.

- Step 1** Ensure that no alarms or abnormal conditions (regardless of severity), including LOS, LOF, AIS-L, SF, SD, and FORCED-REQ-RING are present on the BLSR that you will upgrade:
- In network view, click the **Alarms** tab to view a list of current alarms.
  - In network view, click the **Conditions** tab and click the **Retrieve Conditions** button to view a list of current conditions.
- An unresolved alarm or abnormal condition is the most probable reason for upgrade failure.
- Step 2** Apply a force switch on the span that you will upgrade first:
- In node view, click the **Maintenance > Ring** tabs.
  - Click either the West Switch or the East Switch field and choose **FORCE RING** from the menu.
  - Click **Apply**.
- Step 3** Remove the fiber from both span endpoints (nodes) and ensure that traffic is still running.
- Step 4** Remove the OC-N cards from both endpoints.
- Step 5** From both endpoints, in node view, right-click on each OC-N slot and choose **Change Card**.
- Step 6** In the Change Card dialog box, choose the new OC-N type.
- Step 7** Click **OK**.
- Step 8** Install the new OC-N cards in both endpoints and attach the fiber to the cards.

Wait for the IMPROPRMVL alarm to clear and the cards to become active.

- Step 9** When cards in both endpoint nodes have been successfully upgraded and all the facility alarms (LOS, SD or SF) are cleared, remove the forced switch:
- In node view, click the **Maintenance > Ring** tabs.
  - Click either the West Switch or the East Switch field and choose **CLEAR** from the menu.
  - Click **Apply**.

The forced switch clears and traffic is running. If you have lost traffic, perform a downgrade. The procedure for downgrading is the same as upgrading except that you choose a lower-rate card.



**Note** You cannot downgrade if circuits exist on the STSs that you will remove (the higher STSs).

- Step 10** Repeat these steps for each span in the BLSR.  
When all spans in the BLSR have been upgraded, the span upgrade is complete.

## Procedure: Perform a Manual Span Upgrade on a Four-Fiber BLSR

When upgrading a four-fiber BLSR, you can upgrade both working and protect lines with a single force command. All spans in a BLSR must be upgraded before added bandwidth will be available.

- Step 1** Ensure that no alarms or abnormal conditions (regardless of severity), including LOS, LOF, AIS-L, SF, SD, and FORCED-REQ-RING are present on the BLSR that you will upgrade:
- In network view, click on the **Alarms** tab to view a list of current alarms.
  - In network view, click on the **Conditions** tab and click the **Retrieve Conditions** button to view a list of current conditions.
- An unresolved alarm or abnormal condition is the most probable reason for upgrade failure.
- Step 2** Apply a force switch on the lines that you will upgrade:
- In node view, click the **Maintenance > Ring** tabs.
  - Click either the West Switch or the East Switch field and choose **FORCE RING** from the menu.
  - Click **Apply**.
- Step 3** Remove the fiber from both working and protect cards at both span endpoints (nodes) and ensure that traffic is still running.
- Step 4** Remove the OC-N cards from both end points.
- Step 5** For both ends of the span endpoints, in node view, right-click on each OC-N slot and choose **Change Card**.
- Step 6** In the Change Card dialog box, choose the new OC-N type.
- Step 7** Click **OK**.
- Step 8** When you have finished Steps 5 through 7 for both nodes, install the new OC-N cards in both endpoints and attach the fiber to the cards.

Wait for the IMPROPRMVL alarm to clear and the cards to become active.

- Step 9** When cards on each side of the span have been successfully upgraded and all the facility alarms (LOS, SD, or SF) are cleared, remove the forced switch:
- In node view, click the **Maintenance > Ring** tabs.
  - Click either the West Switch or the East Switch field and choose **CLEAR** from the menu.
  - Click **Apply**.

The forced switch clears and traffic is running. If you have lost traffic, perform a downgrade. The procedure for downgrading is the same as upgrading except that you choose a lower-rate card.



**Note** You cannot downgrade if circuits exist on the STSs that you will remove (the higher STSs).

- Step 10** Repeat these steps for each span in the BLSR.
- When all spans in the BLSR have been upgraded, the span upgrade is complete.

## Procedure: Perform a Manual Span Upgrade on a UPSR

- Step 1** Ensure that no alarms or abnormal conditions (regardless of severity), including LOS, LOF, AIS-L, SF, SD, and FORCED-REQ-RING are present on the span that you will upgrade:
- In node view, click on the **Alarms** tab to view a list of current alarms.
  - In node view, click on the **Conditions** tab and click the **Retrieve Conditions** button to view a list of current conditions.
- An unresolved alarm or abnormal condition is the most probable reason for upgrade failure.
- Step 2** Apply a force switch on the span that you will upgrade:
- In network view, right-click the span and choose **Circuits**.
  - From the Circuits on Span dialog box in the Switch All UPSR Circuits Away field, choose **FORCE**.
  - Click **Apply**.
- Step 3** Remove the fiber from both endpoint nodes in the span and ensure that traffic is still running.
- Step 4** Remove the OC-N cards from both span endpoints.
- Step 5** For both ends of the span, in node view, right-click on each OC-N slot and choose **Change Card**.
- Step 6** In the Change Card dialog box, choose the new OC-N type.
- Step 7** Click **OK**.
- Step 8** When you have finished Steps 5 through 7 for both nodes, install the new OC-N cards in both endpoints and attach the fiber to the cards.
- Wait for the IMPROPRMVL alarm to clear and the cards to become active.
- Step 9** When cards on each side of the span have been successfully upgraded and all the facility alarms (LOS, SD or SF) are cleared, remove the forced switch:
- In network view, right-click the span and choose **Circuits**.
  - From the Circuits on Span dialog box in the Switch All UPSR Circuits Away field choose **CLEAR**.
  - Click **Apply**.

The forced switch clears and traffic is running. If you have lost traffic, perform a downgrade. The procedure for downgrading is the same as upgrading except that you choose a lower-rate card.



**Note** You cannot downgrade if circuits exist on the STSs that you will remove (the higher STSs).

**Step 10** The span upgrade is complete.

## Procedure: Perform a Manual Span Upgrade on a 1+1 Protection Group

When upgrading a 1+1 group, upgrade the protect line first regardless of which line is active. Both lines in a 1+1 group must be upgraded before the added bandwidth will be available.



**Note** If the switching mode is bidirectional in the 1+1 protection group, apply the Force command to only one end of the span, not both. The Clear command will apply to the end the Force was applied to. If the Force command is applied to both ends when the switching mode is bidirectional, it will cause a switch of more than 50 ms in duration.

**Step 1** Ensure that no alarms or abnormal conditions (regardless of severity), including LOS, LOF, AIS-L, SF, SD, and FORCED-REQ-RING are present on the span that you will upgrade:

- a. In node view, click on the **Alarms** tab to view a list of current alarms.
- b. In node view, click on the **Conditions** tab and click the **Retrieve Conditions** button to view a list of current conditions.

An unresolved alarm or abnormal condition is the most probable reason for upgrade failure.

**Step 2** Apply a force switch on the ports that you will upgrade, beginning with the protect port:

- a. In node view, click the **Maintenance > Protection** tabs.
- b. Under Protection Groups, choose the 1+1 protection group.
- c. Under Selected Group, choose the protect port (regardless if it is active or standby).
- d. From Switch Commands, click **Force**.
- e. Click **Yes** on the confirmation dialog box.

**Step 3** Repeat Step 2 for each port.

**Step 4** Remove the fiber from both ends of the span and ensure that traffic is still running.

**Step 5** Remove the OC-N cards from both span endpoints.

**Step 6** At both ends of the span, in node view, right-click the OC-N slot and choose Change Card.

**Step 7** In the Change Card dialog box, choose the new OC-N type.

**Step 8** Click **OK**.

**Step 9** Install the new OC-N cards in both endpoints and attach the fiber to the cards.  
Wait for the IMPROPRMVL alarm to clear and the cards to become standby.

**Step 10** When cards on each end of the line have been successfully upgraded and all the facility alarms (LOS, SD or SF) are cleared, remove the forced switch:

- a. In node view for either endpoint, click the **Maintenance > Protection** tabs.

- b. Under Protection Groups, choose the 1+1 protection group.
- c. Under Selected Group, choose the port with the force on it.
- d. From Switch Commands, click **Clear**.
- e. Click **Yes** on the confirmation dialog box.

The forced switch clears and traffic is running. If you have lost traffic, perform a downgrade. The procedure for downgrading is the same as upgrading except that you choose a lower-rate card.



**Note** You cannot downgrade if circuits exist on the STSs that you will remove (the higher STSs).

**Step 11** Repeat these steps for the other line in the 1+1.

When the other line in the 1+1 has been upgraded, the span upgrade is complete.

## 3.13 Protection Group Switching

Protection group switching allows you to prohibit traffic from switching to a specified card using the Maintenance > Protection tabs. Protection group switching can be accomplished by applying a Lock On or a Lock Out to a specified card. When the Lock On state is applied to a specified working or protect card, any traffic which is currently on that card will remain on that card and will be unable to switch to the opposite card. When the Lock Out state is applied to a specified working or protect card, any traffic which is currently on that card will be switched to the opposite card. A combination of Lock On and Lock Out is allowed in 1:1 and 1:N protection; for example, a Lock On on the working card and a Lock Out on the protect card.



**Note** A non-alarmed event (INHSW) is raised when a card is placed in a Lock On or Lock Out state.

### Procedure: Apply a Lock On



**Note** To apply a Lock On to a protect card in a 1:1 or 1:N protection group, the protect card must be active. If the protect card is not active, the Lock On button is disabled. To make the protect card active, you must switch traffic from the working card to the protect card. When the protect card is active, you can apply the Lock On.

To inhibit traffic from being switched from one card to another, apply a Lock On. Identify which protection group you have to determine which card can be placed in a Lock On state:

- For a 1:1 electrical protection group, both the working and protect cards can be placed in the Lock On state.
- For a 1:N electrical protection group, both the working and protect cards can be placed in the Lock On state.
- For a 1+1 optical protection group, only the working card can be placed in the Lock On state.

**Step 1** In Node view, click the **Maintenance > Protection** tabs.

- Step 2** Under Protection Groups, click on the protection group you want to switch.
- Step 3** Under Selected Group, click on the card you want to lock traffic onto.
- Step 4** From Inhibit Switching, click on **Lock On**.
- Step 5** Click **Yes** on the confirmation dialog box.

The Lock On has been applied and traffic cannot be switched to the opposite card. To clear the Lock On, see the “Clear a Lock On or Lock Out” procedure on page 3-30.

---

## Procedure: Apply a Lock Out



**Note** Multiple Lock Outs in the same protection group is not allowed.

---

To switch traffic from one card to another, apply a Lock Out. Identify which protection group you have to determine which card can be placed in a Lock Out state:

- For a 1:1 electrical protection group, both the working and protect cards can be placed in the Lock Out state.
  - For a 1:N electrical protection group, both the working and protect cards can be placed in the Lock Out state.
  - For a 1+1 optical protection group, only the protect card can be placed in the Lock Out state.
- 

- Step 1** In Node view, click the **Maintenance > Protection** tabs.
- Step 2** Under Protection Groups, click on the protection group you want to switch.
- Step 3** Under Selected Group, click on the card you want to lock traffic out of.
- Step 4** From Inhibit Switching, click on **Lock Out**.
- Step 5** Click **Yes** on the confirmation dialog box.

The lock out has been applied and traffic is switched to the opposite card. To clear the Lock Out, see the “Clear a Lock On or Lock Out” procedure on page 3-30.

---

## Procedure: Clear a Lock On or Lock Out

- Step 1** In Node view, click the **Maintenance > Protection** tabs.
- Step 2** Under Selected Group, click on the card you want to clear.
- Step 3** From Inhibit Switching, click on **Unlock**.
- Step 4** Click **Yes** on the confirmation dialog box.

The Lock On or Lock Out is cleared.

---

## 3.14 Electrical Interface Assembly Replacement

Electrical interface assemblies (EIAs) provide cable connection points on the back of the ONS 15454 and come in several configurations that work with different cards and connections (see Table 3-1). For more information about EIAs, see the “Installation” chapter of the *Cisco ONS 15454 Installation and Operations Guide*.

EIAs have two sides. As you face the rear of the ONS 15454 shelf assembly, the right-hand side is the A side and the left-hand side is the B side. You can install EIAs on one or both sides of the ONS 15454 backplane in any combination. For example, you can use an AMP Champ EIA on side A and a BNC EIA on side B. The top of the EIA connector columns are labelled with the corresponding slot number, and EIA connector pairs are marked Tx and Rx to correspond to transmit and receive cables. EIAs come pre-installed on the ONS 15454 when ordered with the node.

### 3.14.1 EIA Types

Table 3-1 gives the product numbers and common names for EIAs.

**Table 3-1 EIA Configurations**

| EIA Type         | Cards Supported                 | A Side Hosts               | A Side Columns Map to                                    | A Side Product Number | B Side Hosts               | B Side Columns Map to                                          | B Side Product Number |
|------------------|---------------------------------|----------------------------|----------------------------------------------------------|-----------------------|----------------------------|----------------------------------------------------------------|-----------------------|
| BNC              | DS-3<br>DS3XM-6<br>EC-1         | 24 pairs of BNC connectors | Slot 2<br>Slot 4                                         | 15454-EIA-BNC-A24     | 24 pairs of BNC connectors | Slot 14<br>Slot 16                                             | 15454-EIA-BNC-B24     |
| High-Density BNC | DS-3<br>DS3XM-6<br>EC-1         | 48 pairs of BNC connectors | Slot 1<br>Slot 2<br>Slot 4<br>Slot 5                     | 15454-EIA-BNC-A48     | 48 pairs of BNC connectors | Slot 13<br>Slot 14<br>Slot 16<br>Slot 17                       | 15454-EIA-BNC-B48     |
| SMB              | DS-1<br>DS-3<br>EC-1<br>DS3XM-6 | 84 pairs of SMB connectors | Slot 1<br>Slot 2<br>Slot 3<br>Slot 4<br>Slot 5<br>Slot 6 | 15454-EIA-SMB-A84     | 84 pairs of SMB connectors | Slot 12<br>Slot 13<br>Slot 14<br>Slot 15<br>Slot 16<br>Slot 17 | 15454-EIA-SMB-B84     |
| AMP Champ        | DS-1                            | 6 AMP Champ connectors     | Slot 1<br>Slot 2<br>Slot 3<br>Slot 4<br>Slot 5<br>Slot 6 | 15454-EIA-AMP-A84     | 6 AMP Champ connectors     | Slot 12<br>Slot 13<br>Slot 14<br>Slot 15<br>Slot 16<br>Slot 17 | 15454-EIA-AMP-B84     |

**Note**


---

SMB EIAs support 14 ports per slot when used with a DS-1 card, 12 ports per slot when used with a DS-3 or EC-1 card, and 6 ports per slot when used with a DS3XM-6 card.

---

## 3.14.2 EIA Replacement Procedures

The replacement procedure is the same for all the EIA types. However, installing the AMP Champ EIA requires the additional step of attaching the fastening plate to the bottom of the connector row. Before you attach a new EIA, you must remove the backplane cover or EIA already attached to the ONS 15454.

### Procedure: Remove the Backplane Cover or EIA

- 
- Step 1** To remove the lower backplane cover, loosen the five screws that secure it to the ONS 15454 and pull the backplane away from the shelf assembly.
- Step 2** Loosen the nine perimeter screws that hold the backplane sheet metal cover in place. Do not remove the interior screws.

**Note**


---

If you are removing an AMP Champ EIA, remove the fastening plate before proceeding. To remove the fastening plate, loosen the two thumbscrews.

---

- Step 3** If a backplane cover is attached to the ONS 15454, lift the panel by the bottom to remove it from the shelf assembly and store the panel for later use.
- Step 4** If an EIA is attached to the ONS 15454, lift the EIA handles and gently pull the EIA panel away from the backplane.

**Note**


---


Attach backplane sheet metal covers whenever EIAs are not installed.

---

### Procedure: Install the EIAs

- 
- Step 1** Line up the connectors on the EIA with the mating connectors on the backplane.
- Step 2** Gently push the EIA until both sets of connectors fit together snugly.
- Step 3** Replace the nine perimeter screws that you removed while removing the backplane cover.
- Step 4** If you are installing an AMP Champ EIA, attach the fastening plate with the two thumbscrews.
- Step 5** Reattach the lower backplane cover.
- 

Due to the large number of BNC connectors on the High-Density BNC EIA, you might require a special tool for inserting and removing BNC EIAs (Figure 3-14). This tool also helps with ONS 15454 patch panel connections.

**Figure 3-14 BNC insertion and removal tool**

This tool can be obtained with P/N 227-T1000 from:

Amphenol USA ([www.amphenol.com](http://www.amphenol.com))

One Kennedy Drive

Danbury, CT 06810

Phone: 203-743-9272 Fax: 203-796-2032

This tool can be obtained with P/N RT-1L from:

Trompeter Electronics Inc. ([www.trompeter.com](http://www.trompeter.com))

31186 La Baya Drive

Westlake Village, CA 91362-4047

Phone: (800) 982-2629 Fax: (818) 706-1040

## 3.15 Fiber Cleaning

No special instructions apply to cleaning fibers connected to ONS 15454s. Clean the fiber according to local site practice. If no local practice exists, use a CLETOP Real-Type or equivalent fiber-optic cleaner and follow the instructions accompanying the product.

## 3.16 Powering Down a Node



### Note

Always use the supplied ESD wristband when working with the Cisco ONS 15454. Plug the wristband into the ESD jack located on the fan-tray assembly or on the lower right outside edge of the shelf on the NEBS 3 shelf assembly. To access the ESD plug on the NEBS 3 shelf assembly, open the front door of the Cisco ONS 15454. The front door is grounded to prevent electrical shock.



### Caution

The following procedure is designed to minimize traffic outages when powering down nodes, but traffic will be lost if you delete and recreate circuits that passed through a working node.



### Warning

**Do not reach into a vacant slot or chassis while you install or remove a module or a fan. Exposed circuitry could constitute an energy hazard.**

## Procedure: Power Down a Node

- 
- Step 1** Identify the node that you want to power down. If no cards are installed, go to Step 11. If cards are installed, log into the node.
- Step 2** From the network view, verify that the node is not connected to a working network.
- If the node is part of a working network, log out of the node and follow the procedures to remove a BLSR node or UPSR node in the *Cisco ONS 15454 Installation and Operations Guide, Release 3.1*. Then continue with Step 3.
  - If the node is not connected to a working network and the current configurations are no longer required, go to Step 3.




---

**Note** Current configurations will be saved if Steps 3–8 are skipped.

---

- Step 3** From the node view, choose the **Circuits** tab and verify that no circuits are displayed. If circuits are displayed, delete all the circuits that originate or terminate in the node, as follows:
- Click the circuits that need to be deleted and click **Delete**.
  - Click **Yes**.
- If no circuits are displayed, skip to Step 4.
- Step 4** From the node view, choose the **Provisioning > Protection** tabs and delete all protection groups.
- Step 5** From node view, choose the **Provisioning > SONET DCC** tabs and delete all SDCC terminations.
- Step 6** For each installed card, from card view, click the **Provisioning > Line** tabs and place all ports in “Out of Service” mode.
- Step 7** Remove all fiber connections to the cards.
- Step 8** Right-click on the installed card and click **Delete**.
- Click **Yes**.
- Step 9** After you have deleted the card, open the card ejectors and remove it from the node. Repeat Steps 6–9 for each installed card.
- Step 10** Shut off the power from the power supply that feeds the node.
- Step 11** Disconnect the node from its external fuse source.
- Step 12** Store all cards removed and update inventory records according to local site practice.
-



## Card Reference

This chapter describes Cisco ONS 15454 card features and functions. For installation and card turn-up procedures, see the *Cisco ONS 15454 Installation and Operations Guide*.

### 4.1 Card Overview

The card overview section summarizes card functions, power consumption, temperature ranges, and compatibility.



Note

Each card is marked with a symbol that corresponds to a slot (or slots) on the ONS 15454 shelf assembly. The cards are then installed into slots displaying the same symbols. See the *Cisco ONS 15454 Installation and Operations Guide* for a list of slots and symbols.

#### 4.1.1 Common Control Cards

Table 4-1 lists five common control cards for the Cisco ONS 15454 and summarizes card functions.

**Table 4-1 Common Control Card Functions**

| Card        | Description                                                                                                                                                                   | For Additional Information...                                               |
|-------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------|
| <b>TCC+</b> | The TCC+ is the main processing center for the ONS 15454 and provides system initialization, provisioning, alarm reporting, maintenance, and diagnostics.                     | See the “Timing Communication and Control (TCC+) Card” section on page 4-17 |
| <b>XC</b>   | The XC card is the central element for switching; it establishes connections and performs time division switching (TDS).                                                      | See the “XC Cross-Connect Card” section on page 4-20                        |
| <b>XCVT</b> | The XCVT card is the central element for switching; it establishes connections and performs time division switching (TDS). The XCVT can manage STS and VT circuits up to 48c. | See the “XCVT Cross-Connect Card” section on page 4-23                      |

**Table 4-1 Common Control Card Functions (continued)**

| Card         | Description                                                                                                                                                                                                                                                    | For Additional Information...                                  |
|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------|
| <b>XC10G</b> | The XC10G card is the central element for switching; it establishes connections and performs time division switching (TDS). The XC10G can manage STS and VT circuits up to 192c. The XC10G allows up to four times the bandwidth of current XC and XCVT cards. | See the “XC10G Cross-Connect Card” section on page 4-27        |
| <b>AIC</b>   | The AIC card provides customer-defined alarms with its additional input/output alarm contact closures.                                                                                                                                                         | See the “Alarm Interface Controller Card” section on page 4-31 |

## 4.1.2 Electrical Cards

Table 4-2 lists the Cisco ONS 15454 electrical cards.

**Table 4-2 Electrical Cards for the ONS 15454**

| Card                    | Port Description                                                                                                 | For Additional Information...                |
|-------------------------|------------------------------------------------------------------------------------------------------------------|----------------------------------------------|
| <b>EC1-12</b>           | The EC1-12 card provides 12 STS-1 electrical ports.                                                              | See the “EC1-12 Card” section on page 4-35   |
| <b>DS1-14</b>           | The DS1-14 card provides 14 DS-1 ports.                                                                          | See the “DS1-14 Card” section on page 4-38   |
| <b>DS1N-14</b>          | The DS1N-14 card provides 14 DS-1 ports but can also provide 1:N protection when necessary.                      | See the “DS1N-14 Card” section on page 4-41  |
| <b>DS3-12</b>           | The DS3-12 card has 12 DS-3 ports.                                                                               | See the “DS3-12 Card” section on page 4-44   |
| <b>DS3N-12</b>          | The DS3N-12 card has 12 DS-3 ports but can also provide 1:N protection when necessary.                           | See the “DS3N-12 Card” section on page 4-47  |
| <b>DS3-12E</b>          | The DS3-12E card has 12 ports, supports 1:1 protection, and provides enhanced performance-monitoring functions.  | See the “DS3-12E Card” section on page 4-50  |
| <b>DS3N-12E</b>         | The DS3N-12E card has 12 ports, supports 1:N protection, and provides enhanced performance-monitoring functions. | See the “DS3N-12E Card” section on page 4-53 |
| <b>DS3XM-6 Transmux</b> | The DS3XM-6 card can convert six framed DS-3 network connections into 168 VT1.5s.                                | See the “DS3XM-6 Card” section on page 4-56  |

## 4.1.3 Optical Cards

Table 4-3 lists the Cisco ONS 15454 optical cards.

**Table 4-3 Optical Cards for the ONS 15454**

| Card                            | Port Description                                                                                                                                                            | For Additional Information...                                |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------|
| <b>OC3 IR 4 SH 1310</b>         | The OC3 IR 4 1310 card provides four intermediate or short-range OC-3 ports.<br><b>Note</b> The OC3 IR 4 SH 1310 and OC3 IR 4/STM1 SH 1310 cards are functionally the same. | See the “OC3 IR 4/STM1 SH 1310 Card” section on page 4-59    |
| <b>OC12 IR 1310</b>             | The OC12 IR 1310 card provides one intermediate or short-range OC-12 port.<br><b>Note</b> The OC12 IR 1310 and OC12/STM4 SH 1310 cards are functionally the same.           | See the “OC12 IR/STM4 SH 1310 Card” section on page 4-62     |
| <b>OC12 LR 1310</b>             | The OC12 LR 1310 card provides one long-range OC-12 port and operates at 1310 nm.<br><b>Note</b> The OC12 LR 1310 and OC12 LR/STM4 LH 1310 cards are functionally the same. | See the “OC12 LR/STM4 LH 1310 Card” section on page 4-65     |
| <b>OC12 LR 1550</b>             | The OC12 LR 1550 card provides one long-range OC-12 port and operates at 1550 nm.<br><b>Note</b> The OC12 LR 1550 and OC12 LR/STM4 LH 1550 cards are functionally the same. | See the “OC12 LR/STM4 LH 1550 Card” section on page 4-68     |
| <b>OC3 IR 4/STM1 SH 1310</b>    | The OC3 IR 4/STM1 SH 1310 card provides four intermediate or short-range OC-3 ports.                                                                                        | See the “OC3 IR 4/STM1 SH 1310 Card” section on page 4-59    |
| <b>OC12 IR/STM4 SH 1310</b>     | The OC12 IR/STM4 SH 1310 card provides one intermediate or short-range OC-12 port.                                                                                          | See the “OC12 IR/STM4 SH 1310 Card” section on page 4-62     |
| <b>OC12 LR/STM4 LH 1310</b>     | The OC12 LR/STM4 LH 1310 card provides one long-range OC-12 port and operates at 1310 nm.                                                                                   | See the “OC12 LR/STM4 LH 1310 Card” section on page 4-65     |
| <b>OC12 LR/STM4 LH 1550</b>     | The OC12 LR/STM4 LH 1550 card provides one long-range OC-12 port and operates at 1550 nm.                                                                                   | See the “OC12 LR/STM4 LH 1550 Card” section on page 4-68     |
| <b>OC48 IR 1310</b>             | The OC48 IR 1310 card provides one intermediate-range OC-48 port and operates at 1310 nm. This card functions in slots 5, 6, 12, or 13 only.                                | See the “OC48 IR 1310 Card” section on page 4-71             |
| <b>OC48 LR 1550</b>             | The OC48 LR 1550 card provides one long-range OC-48 port and operates at 1550 nm. This card functions in slots 5, 6, 12, or 13 only.                                        | See the “OC48 LR 1550 Card” section on page 4-74             |
| <b>OC48 IR/STM16 SH AS 1310</b> | The OC48 IR/STM16 SH AS 1310 card provides one intermediate-range OC-48 port and operates in any multispeed or high-speed card slot.                                        | See the “OC48 IR/STM16 SH AS 1310 Card” section on page 4-77 |

**Table 4-3 Optical Cards for the ONS 15454 (continued)**

| Card                             | Port Description                                                                                                                    | For Additional Information...                                  |
|----------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------|
| <b>OC48 LR/STM16 LH AS 1550</b>  | The OC48 LR/STM16 LH AS 1550 card provides one long-range OC-48 port and operates in any multispeed or high-speed card slot.        | See the “OC48 LR/STM16 LH AS 1550 Card” section on page 4-80   |
| <b>OC48 ELR/STM16 EH 100 GHz</b> | Thirty-seven distinct OC48 ITU 100 GHz dense wavelength division multiplexing (DWDM) cards provide the ONS 15454 DWDM channel plan. | See the “OC48 ELR/STM16 EH 100 GHz Cards” section on page 4-83 |
| <b>OC48 ELR 200 GHz</b>          | Eighteen distinct OC48 ITU 200GHz DWDM cards provide the ONS 15454 DWDM channel plan.                                               | See the “OC48 ELR 200 GHz Cards” section on page 4-86          |
| <b>OC192 LR/STM64 LH 1550</b>    | The OC192 LR/STM64 LH 1550 card provides one long-range OC-192 port and operates at 1550 nm.                                        | See the “OC192 LR/STM64 LH 1550 Card” section on page 4-89     |

## 4.1.4 Ethernet Cards

Table 4-4 lists the Cisco ONS 15454 Ethernet cards.

**Table 4-4 Ethernet Cards for the ONS 15454**

| Card             | Port Description                                                                                                        | For Additional Information...                 |
|------------------|-------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------|
| <b>E100T-12</b>  | The E100T-12 card provides 12 switched, autosensing, 10/100 Base-T Ethernet ports.                                      | See the “E100T-12 Card” section on page 4-99  |
| <b>E1000-2</b>   | The E1000-2 card provides two ports of IEEE-compliant, 1000 Mbps ports.                                                 | See the “E1000-2 Card” section on page 4-102  |
| <b>E100T-G</b>   | The E100T-G card provides 12 switched, autosensing, 10/100 Base-T Ethernet ports and is compatible with the XC10G card. | See the “E100T-G Card” section on page 4-93   |
| <b>E1000-2-G</b> | The E1000-2-G card provides two ports of IEEE-compliant, 1000 Mbps ports and is compatible with the XC10G card.         | See the “E1000-2-G Card” section on page 4-96 |

## 4.1.5 Card and Fan-Tray Assembly Power Requirements

Table 4-5 lists power requirements for individual cards and Table 4-6 on page 4-6 shows fan-tray assembly power requirements.



Note

Asterisks (\*) next to card or fan tray names mean the power specification shown below is based on a calculation because an actual measurement was not available at the time of publication.

**Table 4-5 Individual Card Power Requirements**

| Card Type               | Card Name                  | Watts | Amps | BTU/Hr. |
|-------------------------|----------------------------|-------|------|---------|
| <b>Control Cards</b>    | TCC+                       | 9.82  | 0.20 | 33.53   |
|                         | XC *                       | 13    | 0.28 | 46      |
|                         | XCVT                       | 34.40 | 0.72 | 117.46  |
|                         | XC10G *                    | 54    | 1.12 | 184.38  |
|                         | AIC                        | 6.01  | 0.12 | 20.52   |
| <b>Electrical Cards</b> | EC1-12                     | 36.60 | 0.76 | 124.97  |
|                         | DS1-14                     | 12.60 | 0.26 | 43.02   |
|                         | DS1N-14                    | 12.60 | 0.26 | 43.02   |
|                         | DS3-12                     | 38.20 | 0.79 | 130.43  |
|                         | DS3N-12                    | 38.20 | 0.79 | 130.43  |
|                         | DS3-12E                    | 26.80 | 0.56 | 91.51   |
|                         | DS3N-12E                   | 26.80 | 0.56 | 91.51   |
|                         | DS3XM-6 Transmux *         | 20    | 0.42 | 68      |
| <b>Optical Cards</b>    | OC3 IR 4 SH 1310           | 19.20 | 0.40 | 65.56   |
|                         | OC12 IR 1310               | 10.90 | 0.23 | 37.22   |
|                         | OC12 LR 1310               | 10.90 | 0.23 | 37.22   |
|                         | OC12 LR 1550               | 9.28  | 0.19 | 31.68   |
|                         | OC3 IR 4/ STM1 SH 1310     | 19.20 | 0.40 | 65.56   |
|                         | OC12 IR/ STM4 SH 1310      | 10.90 | 0.23 | 37.22   |
|                         | OC12 LR/ STM4 LH 1310 *    | 12    | 0.25 | 41      |
|                         | OC12 LR/ STM4 LH 1550      | 9.28  | 0.19 | 31.68   |
|                         | OC48 IR 1310               | 32.20 | 0.67 | 109.94  |
|                         | OC48 LR 1550               | 26.80 | 0.56 | 91.50   |
|                         | OC48 IR/ STM16 SH AS 1310  | 37.20 | 0.77 | 127.01  |
|                         | OC48 LR/ STM16 LH AS 1550  | 37.20 | 0.77 | 127.01  |
|                         | OC48 ELR/ STM16 EH 100 GHz | 31.20 | 0.65 | 106.53  |
|                         | OC48 ELR 200 GHz           | 31.20 | 0.65 | 106.53  |
|                         | OC192 LR/ STM64 LH 1550    | 72.20 | 1.50 | 246.52  |

**Table 4-5 Individual Card Power Requirements (continued)**

| Card Type      | Card Name | Watts | Amps | BTU/Hr. |
|----------------|-----------|-------|------|---------|
| Ethernet Cards | E100T-12  | 65    | 1.35 | 221.93  |
|                | E1000-2   | 53.50 | 1.11 | 182.67  |
|                | E100T-G   | 65    | 1.35 | 221.93  |
|                | E1000-2-G | 53.50 | 1.11 | 182.67  |

**Table 4-6 Fan Tray Assemblies**

| Fan Tray Assembly | Watts | Amps | BTU/Hr. |
|-------------------|-------|------|---------|
| FTA2 *            | 58    | 1.21 | 198     |
| FTA3 *            | 95    | 1.98 | 324     |

## 4.1.6 Card Temperature Ranges

Table 4-7 shows C-Temp and I-Temp compliant cards and their product names.



Note

The I-Temp symbol is displayed on the faceplate of an I-Temp compliant card. A card without symbol is C-Temp compliant.

**Table 4-7 Card Temperature Ranges and Product Names for the ONS 15454**

| Card                  | C-Temp Product Name<br>(0 to +55 degrees Celsius) | I-Temp Product Name<br>(-40 to +65 degrees Celsius) |
|-----------------------|---------------------------------------------------|-----------------------------------------------------|
| TCC+                  | 15454-TCC+                                        | 15454-TCC+T                                         |
| XC                    | 15454-XC                                          | 15454-XC-T                                          |
| XCVT                  | 15454-XC-VT                                       | 15454-XC-VT-T                                       |
| XC10G                 | 15454-XC-10G                                      | —                                                   |
| AIC                   | 15454-AIC                                         | 15454-AIC-T                                         |
| EC1-12                | 15454-EC1-12                                      | 15454-EC1-12-T                                      |
| DS1-14                | 15454-DS1-14                                      | 15454-DS1-14-T                                      |
| DS1N-14               | 15454-DS1N-14                                     | 15454-DS1N-14-T                                     |
| DS3-12                | 15454-DS3-12                                      | 15454-DS3-12-T                                      |
| DS3N-12               | 15454-DS3N-12                                     | 15454-DS3N-12-T                                     |
| DS3-12E               | —                                                 | 15454-DS3-12E-T                                     |
| DS3N-12E              | —                                                 | 15454-DS3N-12E-T                                    |
| DS3XM-6 (Transmux)    | 15454-DS3XM-6                                     | 15454-DS3XM-6-T                                     |
| OC3 IR 4/STM1 SH 1310 | 15454-OC34IR1310                                  | 15454-OC34I13-T                                     |
| OC12 IR/STM4 SH 1310  | 15454-OC121IR1310                                 | 15454-OC121I13-T                                    |
| OC12 LR/STM4 LH 1310  | 15454-OC121LR1310                                 | 15454-OC121L13-T                                    |

**Table 4-7 Card Temperature Ranges and Product Names for the ONS 15454 (continued)**

| <b>Card</b>                      | <b>C-Temp Product Name<br/>(0 to +55 degrees Celsius)</b> | <b>I-Temp Product Name<br/>(-40 to +65 degrees Celsius)</b> |
|----------------------------------|-----------------------------------------------------------|-------------------------------------------------------------|
| <b>OC12 LR/STM4 LH 1550</b>      | 15454-OC121LR1550                                         | 15454-OC121L15-T                                            |
| <b>OC48 IR 1310</b>              | 15454-OC481IR1310                                         | —                                                           |
| <b>OC48 LR 1550</b>              | 15454-OC481LR1550                                         | —                                                           |
| <b>OC48 IR/STM16 SH AS 1310</b>  | 15454-OC481IR1310A                                        | —                                                           |
| <b>OC48 LR/STM16 LH AS 1550</b>  | 15454-OC481LR1550A                                        | —                                                           |
| <b>OC192 LR/STM64 LH 1550</b>    | 15454-OC192LR1550                                         | —                                                           |
| <b>E100T-12</b>                  | 15454-E100T                                               | —                                                           |
| <b>E1000-2</b>                   | 15454-E1000-2                                             | —                                                           |
| <b>E100T-G</b>                   | 15454-E100T-G                                             | —                                                           |
| <b>E1000-2-G</b>                 | 15454-E1000-2-G                                           | —                                                           |
| <b>OC48 ELR/STM16 EH 100 GHz</b> | 15454-OC48E-1-28.7                                        | —                                                           |
|                                  | 15454-OC48E-1-30.3                                        |                                                             |
|                                  | 15454-OC48E-1-31.1                                        |                                                             |
|                                  | 15454-OC48E-1-31.9                                        |                                                             |
|                                  | 15454-OC48E-1-32.6                                        |                                                             |
|                                  | 15454-OC48E-1-33.4                                        |                                                             |
|                                  | 15454-OC48E-1-34.2                                        |                                                             |
|                                  | 15454-OC48E-1-35.0                                        |                                                             |
|                                  | 15454-OC48E-1-35.8                                        |                                                             |
|                                  | 15454-OC48E-1-36.6                                        |                                                             |
|                                  | 15454-OC48E-1-38.1                                        |                                                             |
|                                  | 15454-OC48E-1-38.9                                        |                                                             |
|                                  | 15454-OC48E-1-39.7                                        |                                                             |
|                                  | 15454-OC48E-1-40.5                                        |                                                             |
|                                  | 15454-OC48E-1-41.3                                        |                                                             |
|                                  | 15454-OC48E-1-42.1                                        |                                                             |
|                                  | 15454-OC48E-1-42.9                                        |                                                             |
|                                  | 15454-OC48E-1-43.7                                        |                                                             |
|                                  | 15454-OC48E-1-44.5                                        |                                                             |
|                                  | 15454-OC48E-1-46.1                                        |                                                             |
| 15454-OC48E-1-46.9               |                                                           |                                                             |
| 15454-OC48E-1-47.7               |                                                           |                                                             |
| 15454-OC48E-1-48.5               |                                                           |                                                             |
| 15454-OC48E-1-49.3               |                                                           |                                                             |
| 15454-OC48E-1-50.1               |                                                           |                                                             |

Table 4-7 Card Temperature Ranges and Product Names for the ONS 15454 (continued)

| Card                                             | C-Temp Product Name<br>(0 to +55 degrees Celsius) | I-Temp Product Name<br>(-40 to +65 degrees Celsius) |
|--------------------------------------------------|---------------------------------------------------|-----------------------------------------------------|
| <b>OC48 ELR/STM16 EH 100 GHz<br/>(continued)</b> | 15454-OC48E-1-50.9                                | —                                                   |
|                                                  | 15454-OC48E-1-51.7                                |                                                     |
|                                                  | 15454-OC48E-1-52.5                                |                                                     |
|                                                  | 15454-OC48E-1-54.1                                |                                                     |
|                                                  | 15454-OC48E-1-54.9                                |                                                     |
|                                                  | 15454-OC48E-1-55.7                                |                                                     |
|                                                  | 15454-OC48E-1-56.5                                |                                                     |
|                                                  | 15454-OC48E-1-57.3                                |                                                     |
|                                                  | 15454-OC48E-1-58.1                                |                                                     |
|                                                  | 15454-OC48E-1-58.9                                |                                                     |
|                                                  | 15454-OC48E-1-59.7                                |                                                     |
|                                                  | 15454-OC48E-1-60.6                                |                                                     |
| <b>OC48 ELR/STM16 EH 200 GHz</b>                 | 15454-OC48E-30.33                                 | —                                                   |
|                                                  | 15454-OC48E-31.90                                 |                                                     |
|                                                  | 15454-OC48E-33.47                                 |                                                     |
|                                                  | 15454-OC48E-35.04                                 |                                                     |
|                                                  | 15454-OC48E-36.61                                 |                                                     |
|                                                  | 15454-OC48E-38.19                                 |                                                     |
|                                                  | 15454-OC48E-39.77                                 |                                                     |
|                                                  | 15454-OC48E-31.35                                 |                                                     |
|                                                  | 15454-OC48E-42.94                                 |                                                     |
|                                                  | 15454-OC48E-47.72                                 |                                                     |
|                                                  | 15454-OC48E-49.32                                 |                                                     |
|                                                  | 15454-OC48E-50.92                                 |                                                     |
|                                                  | 15454-OC48E-52.52                                 |                                                     |
|                                                  | 15454-OC48E-54.13                                 |                                                     |
|                                                  | 15454-OC48E-55.75                                 |                                                     |
|                                                  | 15454-OC48E-57.36                                 |                                                     |
| 15454-OC48E-58.98                                |                                                   |                                                     |
| 15454-OC48E-60.61                                |                                                   |                                                     |

## 4.1.7 Card Compatibility

The tables below list ONS 15454 cards, compatible software versions, and compatible cross-connect cards. Read each card description for detailed information about the card. In the tables below, **Yes** means cards are compatible with the listed software versions and cross-connect cards. Table cells with dashes mean cards are not compatible with the listed software versions or cross-connect cards.

**Table 4-8 TCC+ Card Software and Cross-Connect Card Compatibility for the ONS 15454**

| Timing and Control Card | Software R2.2.1 | Software R2.2.2 | Software R3.0.1 | Software R3.1 | XC Card | XCVT Card | XC10G Card |
|-------------------------|-----------------|-----------------|-----------------|---------------|---------|-----------|------------|
| TCC+                    | Yes             | Yes             | Yes             | Yes           | Yes     | Yes       | Yes        |

**Table 4-9 Cross-Connect Card Software and Hardware Compatibility for the ONS 15454**

| Cross-Connect Cards | Software R2.2.1 | Software R2.2.2 | Software R3.0.1 | Software R3.1 | XC Card | XCVT Card | XC10G Card    |
|---------------------|-----------------|-----------------|-----------------|---------------|---------|-----------|---------------|
| XC                  | Yes             | Yes             | Yes             | Yes           | Yes     | Yes       | —             |
| XCVT                | Yes             | Yes             | Yes             | Yes           | Yes     | Yes       | —             |
| XC10G               | —               | —               | —               | Yes           | —       | —         | Yes, See Note |

**Note** To enable OC-192 and OC-48 any slot card operation, use the XC10G card, the TCC+ card, Software R3.1 or higher, and the new 15454-SA-ANSI shelf assembly. Do not pair an XC or XCVT with an XC10G.

**Table 4-10 Alarm Interface Controller Card Software and Cross-Connect Card Compatibility for the ONS 15454**

| Alarm Interface Controller Card | Software R2.2.1 | Software R2.2.2 | Software R3.0.1 | Software R3.1 | XC Card | XCVT Card | XC10G Card |
|---------------------------------|-----------------|-----------------|-----------------|---------------|---------|-----------|------------|
| AIC                             | Yes             | Yes             | Yes             | Yes           | Yes     | Yes       | Yes        |

**Table 4-11 Electrical Card Software and Cross-Connect Card Compatibility for the ONS 15454**

| Electrical Cards | Software R2.2.1 | Software R2.2.2 | Software R3.0.1 | Software R3.1 | XC Card | XCVT Card | XC10G Card |
|------------------|-----------------|-----------------|-----------------|---------------|---------|-----------|------------|
| EC1-12           | Yes             | Yes             | Yes             | Yes           | Yes     | Yes       | Yes        |
| DS1-14           | Yes             | Yes             | Yes             | Yes           | Yes     | Yes       | Yes        |
| DS1N-14          | Yes             | Yes             | Yes             | Yes           | Yes     | Yes       | Yes        |
| DS3-12           | Yes             | Yes             | Yes             | Yes           | Yes     | Yes       | Yes        |
| DS3N-12          | Yes             | Yes             | Yes             | Yes           | Yes     | Yes       | Yes        |
| DS3-12E          | —               | See Note        | Yes             | Yes           | Yes     | Yes       | Yes        |
| DS3N-12E         | —               | See Note        | Yes             | Yes           | Yes     | Yes       | Yes        |

**Table 4-11 Electrical Card Software and Cross-Connect Card Compatibility for the ONS 15454**

| Electrical Cards   | Software R2.2.1 | Software R2.2.2 | Software R3.0.1 | Software R3.1 | XC Card | XCVT Card | XC10G Card |
|--------------------|-----------------|-----------------|-----------------|---------------|---------|-----------|------------|
| DS3XM-6 (Transmux) | Yes             | Yes             | Yes             | Yes           | Yes     | Yes       | Yes        |

**Note** Use Software R3.0 or higher to enable all enhanced performance monitoring functions on the DS-3E cards. With Software R2.2.2, the DS-3E cards operate as the older DS-3 cards without enhanced performance monitoring.

**Table 4-12 Optical Card Software and Cross-Connect Card Compatibility for the ONS 15454**

| Optical Cards | Software R2.2.1 | Software R2.2.2 | Software R3.0.1 | Software R3.1 | XC Card | XCVT Card | XC10G Card |
|---------------|-----------------|-----------------|-----------------|---------------|---------|-----------|------------|
| OC3 IR 4 1310 | Yes             | Yes             | Yes             | Yes, See Note | Yes     | Yes       | Yes        |
| OC12 IR 1310  | Yes             | Yes             | Yes             | Yes, See Note | Yes     | Yes       | Yes        |
| OC12 LR 1310  | Yes             | Yes             | Yes             | Yes, See Note | Yes     | Yes       | Yes        |
| OC12 LR 1550  | Yes             | Yes             | Yes             | Yes, See Note | Yes     | Yes       | Yes        |

**Note** The OC-3 and OC-12 cards listed above are functionally the same as the equivalent card listed below with the STM-N name.

|                          |     |     |     |               |     |     |               |
|--------------------------|-----|-----|-----|---------------|-----|-----|---------------|
| OC3 IR 4/STM1 SH 1310    | Yes | Yes | Yes | Yes           | Yes | Yes | Yes           |
| OC12 IR/STM4 SH 1310     | Yes | Yes | Yes | Yes           | Yes | Yes | Yes           |
| OC12 LR/STM4 LH 1310     | Yes | Yes | Yes | Yes           | Yes | Yes | Yes           |
| OC12 LR/STM4 LH 1550     | Yes | Yes | Yes | Yes           | Yes | Yes | Yes           |
| OC48 IR 1310             | Yes | Yes | Yes | Yes           | Yes | Yes | Yes           |
| OC48 LR 1550             | Yes | Yes | Yes | Yes           | Yes | Yes | Yes           |
| OC48 IR/STM16 SH AS 1310 | —   | —   | —   | Yes, See Note | —   | —   | Yes, See Note |
| OC48 LR/STM16 LH AS 1550 | —   | —   | —   | Yes, See Note | —   | —   | Yes, See Note |

**Note** Use the XC10G card, the TCC+ card, Software R3.1 or higher and the new 15454-SA-ANSI shelf assembly to enable the OC48 IR/STM16 SH AS 1310, OC48 LR/STM16 LH AS 1550, and the OC192 LR/STM64 LH 1550 cards.

|                           |     |     |     |               |     |     |               |
|---------------------------|-----|-----|-----|---------------|-----|-----|---------------|
| OC48 ELR/STM16 EH 100 GHz | Yes | Yes | Yes | Yes           | Yes | Yes | Yes           |
| OC48 ELR 200 GHz          | Yes | Yes | Yes | Yes           | Yes | Yes | Yes           |
| OC192 LR/STM64 LH 1550    | —   | —   | —   | Yes, See Note | —   | —   | Yes, See Note |

**Table 4-13 Ethernet Card Software and Cross-Connect Card Compatibility for the ONS 15454**

| <b>Ethernet Cards</b> | <b>Software R2.2.1</b> | <b>Software R2.2.2</b> | <b>Software R3.0.1</b> | <b>Software R3.1</b> | <b>XC Card</b> | <b>XCVT Card</b> | <b>XC10G Card</b> |
|-----------------------|------------------------|------------------------|------------------------|----------------------|----------------|------------------|-------------------|
| <b>E100T-12</b>       | Yes                    | Yes                    | Yes                    | Yes                  | Yes            | Yes              | —                 |
| <b>E1000-2</b>        | Yes                    | Yes                    | Yes                    | Yes                  | Yes            | Yes              | —                 |
| <b>E100T-G</b>        | Yes                    | Yes                    | Yes                    | Yes                  | Yes            | Yes              | Yes, See Note     |
| <b>E1000-2-G</b>      | Yes                    | Yes                    | Yes                    | Yes                  | Yes            | Yes              | Yes, See Note     |

**Note** To use Ethernet cards with the XC10G, select either the E100T-G card or the E1000-2-G card. Do not use the E100T-12 card or E1000-2 card with the XC10G.


## 4.2 Electrical Card Protection

The ONS 15454 provides a variety of electrical card protection methods. This section describes the protection options. Figure 4-1 shows a 1:1 protection scheme and Figure 4-2 on page 4-13 shows a 1:N protection scheme.

### 4.2.1 Protection, 1:1

In 1:1 protection, a working card is paired with a protect card of the same type. If the working card fails, the traffic from the working card switches to the protect card. When the failure on the working card is resolved, traffic automatically reverts to the working card. Figure 4-1 shows the ONS 15454 in a 1:1 protection configuration. Each working card in an odd-numbered slot is paired with a protect card in an even-numbered slot: Slot 1 is protecting Slot 2, Slot 3 is protecting Slot 4, Slot 5 is protecting Slot 6, Slot 7 is protecting Slot 8, Slot 9 is protecting Slot 10, Slot 11 is protecting Slot 12, Slot 13 is protecting Slot 14, Slot 15 is protecting Slot 16, Slot 17 is protecting Slot 18, and Slot 19 is protecting Slot 20. The following electrical cards use a 1:1 protection scheme: EC1-12, DS1-14, DS3-12 and DS3-12E.

**Figure 4-1 ONS 15454 cards in a 1:1 protection configuration**




### 4.2.2 Protection, 1:N

1:N protection allows a single card to protect up to five working cards of the same DS-N level. A DS1N-14 card protects DS1-14 cards, a DS3N-12 card protects DS3-12 cards, and DS3N-12E cards protect DS3-12E cards. The standard DS1-14, DS3-12, and DS3-12E cards provide 1:1 protection only. Currently, 1:N protection operates only at the DS-1 and DS-3 levels. 1:N cards have added circuitry to act as the protection card in a 1:N protection group. Otherwise, the card is identical to the standard card and can serve as a normal working card.

The physical DS-1 or DS-3 interfaces on the ONS 15454 backplane use the working card until the working card fails. When the node detects this failure, the protection card takes over the physical DS-1 or DS-3 electrical interfaces through the relays and signal bridging on the backplane. Figure 4-2 shows the ONS 15454 in a 1:N protection configuration. Each side of the shelf assembly has only one card protecting all of the cards on that side.

**Figure 4-2 ONS 15454 cards in a 1:N protection configuration**



### 4.2.2.1 Revertive Switching

1:N protection supports revertive switching. Revertive switching sends the electrical interfaces (traffic) back to the original working card after the card comes back online. Detecting an active working card triggers the reversion process. There is a variable time period for the lag between detection and reversion, called the revertive delay, which you can set using the ONS 15454 software, Cisco Transport Controller (CTC). To set the revertive delay, see the *Cisco ONS 15454 Installation and Operations Guide*. All cards in a protection group share the same reversion settings. 1:N protection groups default to automatic reversion.

### 4.2.2.2 Protection Guidelines, 1:N

Several rules apply to 1:N protection groups in the ONS 15454:

- Working and protect card groups must reside in the same card bank (A or B)
- The 1:N protect card must reside in Slot 3 for side A and Slot 15 for side B
- Working cards may sit on either or both sides of the protect card

The ONS 15454 supports 1:N equipment protection for all add-drop multiplexer configurations (ring, linear, and terminal), as specified by Telcordia GR-253-CORE.

The ONS 15454 automatically detects and identifies a 1:N protection card when the card is installed in Slot 3 or Slot 15. However, the slot containing the 1:N card in a protection group must be manually provisioned as a protect slot because by default all cards are working cards.

For detailed procedures on setting up DS-1 and DS-3 protection groups, see the protection information in the *Cisco ONS 15454 Installation and Operations Guide*.

## 4.3 Electrical Card Protection and the Backplane

Protection schemes for electrical cards differ slightly depending on the Electrical Interface Assembly (EIA) type used on the ONS 15454 backplane. The difference is due to the varying connector size. For example, because BNC connectors are larger, fewer DS3-12 cards can be supported when using a BNC connector.



Note

For EIA descriptions and installation, see the *Cisco ONS 15454 Installation and Operations Guide*.



Caution

When a protection switch moves traffic from the DS3-12 working/active card to the DS3-12 protect/standby card, ports on the new active/standby card cannot be taken out of service as long as traffic is switched. Lost traffic can result when a port is taken out of service even if the DS3-12 standby card no longer carries traffic.

### 4.3.1 Standard BNC Protection

When you use BNC connectors, the ONS 15454 supports 1:1 protection or 1:N protection for a total of four working DS-3 electrical cards. If you are using EC-1 electrical cards with the BNC EIA, the ONS 15454 supports 1:1 protection and a total of four working cards. Slots 2, 4, 14 and 16 are designated working slots. These slots are mapped to a set of 12 BNC connectors on the EIA. These slots can be used without protection for unprotected DS-3 access.

With 1:N or 1:1 protection, Slots 1, 3, 15 and 17 are designated for protection when BNC connectors are used. With 1:N protection, Slots 3 and 15 are also designated for protection when BNC connectors are used. Slots 5, 6, 12, and 13 do not support DS3-12 cards when you use the regular BNC EIA.

### 4.3.2 High-Density BNC Protection

When you use the High-Density BNC EIA, the ONS 15454 supports 1:1 protection or 1:N protection for eight total working DS-3 electrical cards. If you are using EC-1 electrical cards with the High-Density BNC EIA, the ONS 15454 supports 1:1 protection and a total of eight working cards. Slots 1, 2, 4, 5, 13, 14, 16, and 17 are designated working slots.

These slots are mapped to a set of 12 BNC type connectors on the EIA. You can use these slots without protection for unprotected DS-3 or EC-1 access. Slots 3 and 15 are designated for 1:N protection slots when you use BNC connectors with the High-Density BNC EIA. Slots 6 and 12 do not support DS-3 or EC-1 cards when you use the High-Density BNC EIA.

### 4.3.3 SMB Protection

When you use SMB connectors, the ONS 15454 supports 1:1 or 1:N protection for the DS-1 and the DS-3 electrical cards. If you are using EC-1 cards with the SMB EIA, the ONS 15454 supports 1:1 protection. Working and protection electrical cards are defined by card slot pairs (the same card type is

used for working and protect modules; the protection of the card is defined by the slot where it is housed). Each slot maps to a set of 12 or 14 SMB connectors on the EIA depending on the number of ports on the corresponding card. Any slot can be used without protection for unprotected DS-1, DS-3, or EC-1 access.

The DS1N-14 card can be a working or protect card in 1:1 or 1:N protection schemes. When used with 1:N protection, the DS1N-14 card can protect up to five DS1-14 plug-ins using the SMB connectors with the DS-1 electrical interface adapters (baluns).

### 4.3.4 AMP Champ Protection

When you use AMP Champ connectors, the ONS 15454 supports 1:1 or 1:N protection for the DS-1 cards. The DS1N-14 card can be a working or protect card in 1:1 or 1:N protection schemes. When used with 1:N protection, the DS1N-14 card can protect up to five DS1-14 plug-ins using the AMP Champ EIA.

## 4.4 Optical Card Protection

With 1+1 port-to-port protection, any number of ports on the protect card can be assigned to protect the corresponding ports on the working card. The working and protect cards do not have to be placed side by side in the node. A working card must be paired with a protect card of the same type, for example, an OC-3 card should be paired with another OC-3 card. The protection takes place on the port level, any number of ports on the protect card can be assigned to protect the corresponding ports on the working card.

For example, on a four-port card, you can assign one port as a protection port on the protect card (protecting the corresponding port on the working card) and leave three ports unprotected. Conversely, you can assign three ports as protection ports and leave one port unprotected.



#### Note

---

Currently, the OC-3 card is the only multiple port optical card. You cannot make protection groups on the same multiport card.

---

With 1:1 or 1:N protection (electrical cards), the protect card must protect an entire slot. In other words, all the ports on the protect card will be used in the protection scheme.


1+1 span protection can be either revertive or non-revertive. With non-revertive 1+1 protection, when a failure occurs and the signal switches from the working card to the protect card, the signal stays switched to the protect card until it is manually switched back. Revertive 1+1 protection automatically switches the signal back to the working card when the working card comes back online.

You create and modify protection schemes using CTC software. For more information, see the *Cisco ONS 15454 Installation and Operations Guide*.

## 4.5 Unprotected Cards

Unprotected cards are not included in a protection scheme; therefore, a card failure or a signal error results in lost data. Because no bandwidth lies in reserve for protection, unprotected schemes maximize the available ONS 15454 bandwidth. Figure 4-3 shows the ONS 15454 in an unprotected configuration. All cards are in a working state.


**Figure 4-3 ONS 15454 in an unprotected configuration**



## 4.6 Timing Communication and Control (TCC+) Card

The TCC+ performs system initialization, provisioning, alarm reporting, maintenance, diagnostics, IP address detection/resolution, SONET Data Communications Channel (DCC) termination, and system fault detection for the ONS 15454. The TCC+ also ensures that the system maintains Telcordia timing requirements. Figure 4-4 shows the TCC+ faceplate and a block diagram of the card.

**Figure 4-4** TCC+ faceplate and block diagram



The node database, IP address, and system software are stored in TCC+ non-volatile memory, which allows quick recovery in the event of a power or card failure.

The TCC+ supports multichannel, high-level data link control (HDLC) processing for the DCC. Up to 48 DCCs can be routed over the Serial Communication Interface (SCI) and terminated at the TCC+. The TCC+ selects and processes ten DCCs to facilitate remote system management interfaces.

The TCC+ performs all system-timing functions for each ONS 15454. The TCC+ monitors the recovered clocks from each traffic card and two DS-1 (BITS) interfaces for frequency accuracy. The TCC+ selects a recovered clock, a BITS, or an internal Stratum 3 reference as the system-timing reference. You can provision any of the clock inputs as primary or secondary timing sources. A slow-reference tracking loop allows the TCC+ to synchronize with the recovered clock, which provides holdover if the reference is lost.

Install TCC+ cards in Slots 7 and 11 for redundancy. If the active TCC+ fails, traffic switches to the protect TCC+. All TCC+ protection switches conform to protection switching standards of less than 50 ms.

The TCC+ features an RJ-45 10Base-T LAN port and an RS-232 DB9 type craft interface for user interfaces. The TL1 craft port runs at 9600 bps.

**Caution**

Cisco does not recommend operating the ONS 15454 with only one TCC+ card. To safeguard your system, always operate in a redundant configuration.

## 4.6.1 TCC+ Card-Level Indicators

The TCC+ faceplate has eight LEDs. The first two LEDs are card-level indicators.

**Table 4-14 TCC+ Card-Level Indicators**

| Card-Level LEDs                                                        | Definition                                                                                                                                                                                                                                                                                                                                                                              |
|------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>                                                    | Indicates a TCC+ hardware problem. Replace the unit if the FAIL LED persists.                                                                                                                                                                                                                                                                                                           |
| <b>ACT/STBY LED</b><br><b>Green (Active)</b><br><b>Amber (Standby)</b> | The ACT/STBY (Active/Standby) LED indicates that the TCC+ is active (green) or in standby (amber). The ACT/STBY LED also provides the timing reference and shelf control. When the TCC+ is writing to the Active or Standby TCC+, its Active or Standby LED will blink.<br><br>To avoid memory corruption, only remove the TCC+ when it is in standby and when the LED is not blinking. |

## 4.6.2 Network-Level Indicators

The TCC+ faceplate has eight LEDs. Six LEDs are network-level indicators.

**Table 4-15 TCC+ System-Level Indicators**

| System-Level LEDs     | Definition                                                                                                                                                                                                                                                                       |
|-----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red CRIT LED</b>   | Indicates a critical alarm in the network at the local node                                                                                                                                                                                                                      |
| <b>Red MAJ LED</b>    | Indicates a major alarm in the network at the local node                                                                                                                                                                                                                         |
| <b>Amber MIN LED</b>  | Indicates a minor alarm in the network at the local node                                                                                                                                                                                                                         |
| <b>Red REM LED</b>    | Provides first-level alarm isolation. The REM LED turns red when an alarm is present in one or several of the remote nodes.                                                                                                                                                      |
| <b>Green SYNC LED</b> | Indicates that node timing is synchronized to an external reference                                                                                                                                                                                                              |
| <b>Green ACO LED</b>  | After pressing the alarm cutoff (ACO) button, the green ACO LED illuminates. The ACO button opens the audible closure on the backplane. The ACO state is stopped if a new alarm occurs. After the originating alarm is cleared, the ACO LED and audible alarm control are reset. |

## 4.6.3 TCC+ Specifications

- CTC Software
  - Interface: 10 Base-T LAN
  - Backplane access: wire wrap
- TL1 Craft Interface
  - Speed: 9600 baud
  - Front panel access: RS-232 DB9 type connector
- Synchronization
  - Stratum 3, per Telcordia GR-253-CORE
  - Free running access: accuracy 4.6 ppm
  - Holdover Stability:  $3.7 \times 10^{-7}$  ppm/day including temperature (<255 slips in first 24 hours)
  - Reference: External BITS, line, internal
- Environmental
  - Operating Temperature:
    - C-Temp (15454-TCC+): 0 to +55 degrees Celsius
    - I-Temp (15454-TCC+T): -40 to +65 degrees Celsius



**Note** The I-Temp symbol is displayed on the faceplate of an I-Temp compliant card. A card without this symbol is C-Temp compliant.




- Operating Humidity: 5 - 95%, non-condensing
- Power Consumption: 9.82 W, 0.20 amps, 33.53 BTU/Hr.
- Dimensions
  - Height: 12.650 in., Width: 0.716 in., Depth: 9.000 in.
  - Card Weight: 1.5 lbs, 0.7 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950

## 4.7 XC Cross-Connect Card


The cross-connect card is the central element for ONS 15454 switching. Available cross-connects are the XC, XCVT, and XC10G. The XC establishes connections and performs time division switching (TDS) at the STS-1 level between ONS 15454 traffic cards. The XC card faceplate and block diagram are shown in Figure 4-5. The cross-connect matrix is shown in Figure 4-6 on page 4-21.

**Figure 4-5** XC card faceplate and block diagram



The switch matrix on the XC card consists of 288 bidirectional ports. When creating bidirectional STS-1 cross-connects, each cross-connect uses two STS-1 ports. This results in 144 bidirectional STS-1 cross-connects. The switch matrix is fully crosspoint, non-blocking, and broadcast supporting. (Any STS-1 on any port can be connected to any other port, meaning that the STS cross-connections are non blocking.) This allows network operators to concentrate or groom low-speed traffic from line cards onto high-speed transport spans and to drop low-speed traffic from transport spans onto line cards.

Figure 4-6 XC cross-connect matrix



The XC card has 12 input ports and 12 output ports. Four input and output ports operate at either STS-12 or STS-48 rates. The remaining eight input and output ports operate at the STS-12 rate. An STS-1 on any of the input ports can be mapped to an STS-1 output port, thus providing full STS-1 time slot assignments (TSA).

The XC card works with the TCC+ card to maintain connections and set up cross-connects within the ONS 15454. Either the XC, XCVT, or XC10G is required to operate the ONS 15454. You establish cross-connect and provisioning information through CTC. The TCC+ establishes the proper internal cross-connect information and relays the setup information to the cross-connect card.

**Caution**

Do not operate the ONS 15454 with a single TCC+ card or a single XC/XCVT/XC10G card installed. Always operate the shelf with one working and one protect card of each type.

For simplex operation, you can install a single XC card in Slots 8 or 10. A second XC should be added for redundancy. The card has no external interfaces. All cross-connect card interfaces are provided through the ONS 15454 backplane.

## 4.7.1 XC Card-Level Indicators

The XC card faceplate has two card-level LEDs.

Table 4-16 XC Card-Level Indicators

| Card-Level Indicators                                                  | Definition                                                                                                                          |
|------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>                                                    | The red FAIL LED indicates that the card's processor is not ready. If the FAIL LED persists, replace the card.                      |
| <b>ACT/STBY LED</b><br><b>Green (Active)</b><br><b>Amber (Standby)</b> | The ACT/STBY LED indicates whether the XC card is active and carrying traffic (green) or in standby mode as a protect card (amber). |

## 4.7.2 XC Specifications

- Cross-Connect
  - Connection Setup Time: 5 ms
  - Latency: 270 ns
- Environmental
  - Operating Temperature:
    - C-Temp (15454-XC): 0 to +55 degrees Celsius
    - I-Temp (15454-XC-T): -40 to +65 degrees Celsius


**Note**

The I-Temp symbol is displayed on the faceplate of an I-Temp compliant card. A card without this symbol is C-Temp compliant.




- Operating Humidity: 5 - 95%, non-condensing
- Power Consumption: 13 W, 0.28 amps, 46 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 1.5 lbs, 0.7 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950

## 4.8 XCVT Cross-Connect Card

The XCVT card provides the same STS capability as a standard XC card and also provides VT cross-connection. The XCVT provides non-blocking STS-48 capacity to all of the high-speed slots and non-bidirectional blocking STS-12 capacity to all multispeed slots. Any STS-1 on any port can be connected to any other port, meaning that the STS cross-connections are non blocking.

Figure 4-7 shows the XCVT faceplate and block diagram. Figure 4-8 on page 4-24 shows the cross-connect matrix.

**Figure 4-7 XCVT faceplate and block diagram**




The STS-1 switch matrix on the XCVT card consists of 288 bidirectional ports and adds a VT matrix that can manage up to 336 bidirectional VT1.5 ports or the equivalent of a bidirectional STS-12. The VT1.5-level signals can be cross connected, dropped, or rearranged. The TCC+ assigns bandwidth to each slot on a per STS-1 or per VT1.5 basis. The switch matrices are fully crosspoint and broadcast supporting.

The XCVT card works with the TCC+ card to maintain connections and set up cross-connects within the node. Either the XCVT, XC10G, or XC is required to operate the ONS 15454. You can establish cross-connect (circuit) information through CTC. The TCC+ establishes the proper internal cross-connect information and relays the setup information to the XCVT card.

**Caution**

Do not operate the ONS 15454 with a single TCC+ card or a single XCVT/XC10G/XC card installed. Always operate the shelf with one working card and one protect card. Duplex cards must be the same type.

**Figure 4-8 XCVT cross-connect matrix**



## 4.8.1 VT Mapping

The VT structure is designed to transport and switch payloads below the DS-3 rate. The Cisco ONS 15454 performs Virtual Tributary (VT) mapping according to Telcordia GR-253 standards. Table 4-17 shows the VT numbering scheme for the ONS 15454 as it relates to the Telcordia standard.

**Table 4-17 ONS 15454 VT Mapping**

| ONS 15454 VT Number | Telcordia Group/VT Number |
|---------------------|---------------------------|
| VT1                 | Group1/VT1                |
| VT2                 | Group2/VT1                |
| VT3                 | Group3/VT1                |
| VT4                 | Group4/VT1                |
| VT5                 | Group5/VT1                |
| VT6                 | Group6/VT1                |
| VT7                 | Group7/VT1                |
| VT8                 | Group1/VT2                |
| VT9                 | Group2/VT2                |
| VT10                | Group3/VT2                |
| VT11                | Group4/VT2                |
| VT12                | Group5/VT2                |
| VT13                | Group6/VT2                |

**Table 4-17 ONS 15454 VT Mapping (continued)**

| <b>ONS 15454 VT Number</b> | <b>Telcordia Group/VT Number</b> |
|----------------------------|----------------------------------|
| VT14                       | Group7/VT2                       |
| VT15                       | Group1/VT3                       |
| VT16                       | Group2/VT3                       |
| VT17                       | Group3/VT3                       |
| VT18                       | Group4/VT3                       |
| VT19                       | Group5/VT3                       |
| VT20                       | Group6/VT3                       |
| VT21                       | Group7/VT3                       |
| VT22                       | Group1/VT4                       |
| VT23                       | Group2/VT4                       |
| VT24                       | Group3/VT4                       |
| VT25                       | Group4/VT4                       |
| VT26                       | Group5/VT4                       |
| VT27                       | Group6/VT4                       |
| VT28                       | Group7/VT4                       |

## 4.8.2 XCVT Hosting DS3XM-6

The XCVT card works with DS3XM-6 (transmux) cards. A single DS3XM-6 can demultiplex (map down to a lower rate) six DS-3 signals into 168 VT1.5s that the XCVT card manages and cross connects. XCVT cards host a maximum of 336 bidirectional VT1.5s. In most network configurations, two DS3XM-6 cards are paired as working and protect cards.

## 4.8.3 XCVT Card-Level Indicators

The XCVT faceplate has two card-level LEDs.

**Table 4-18 XCVT Card-Level Indicators**

| <b>Card-Level Indicators</b>                                           | <b>Definition</b>                                                                                                                                       |
|------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>                                                    | The red FAIL LED indicates that the card's processor is not ready. Replace the card if the red FAIL LED persists.                                       |
| <b>ACT/STBY LED</b><br><b>Green (Active)</b><br><b>Amber (Standby)</b> | The ACT/STBY (Active/Standby) LED indicates whether the XCVT is active and carrying traffic (green) or in standby mode to the active XCVT card (amber). |

## 4.8.4 XC/XCVT Compatibility

The XCVT card is compatible with the XC cards. The XCVT supports run-time compatibility with the XC cross-connect both within a single node and within a ring of mixed XCVT and XC nodes. However, working and protect cards within a single ONS 15454 must be either two XC cards or two XCVT cards. If an XC card or an XCVT card are used together as a working and protect pair, the XCVT acts as an XC card.

The XC and XCVT are supported in unidirectional path switched ring (UPSR) and bidirectional line switched ring (BLSR) configurations. VT and STS-level cross-connect and protection management are also supported in either type of ring. Nodes that rearrange or drop VTs must use an XCVT. Nodes that only rearrange or drop STSs can use an XC. You do not need to upgrade STS-only nodes to XCVT in a ring that can handle both VT and STS drop/rearrangement. In this scenario, however, the XC must run Software R2.0 or higher.

When upgrading from XC to XCVT cards, the first XCVT card installed acts as an XC card until the second XCVT card is installed. For more information, see Chapter 3, “Maintenance.”

To create an STS-capable ring that allows VT drops at some nodes, all of the nodes in the ring must first run Software R2.0 or higher. The nodes that allow VT drops must use XCVT, but the nodes that do not allow VT drops can use the XC or XCVT card.

## 4.8.5 XCVT Card Specifications

- Environmental
  - Operating Temperature:
    - C-Temp (15454-XC-VT): 0 to +55 degrees Celsius
    - I-Temp (15454-XC-VT-T): -40 to +65 degrees Celsius



**Note** The I-Temp symbol is displayed on the faceplate of an I-Temp compliant card. A card without this symbol is C-Temp compliant.




- Operating Humidity: 5 - 95%, non-condensing
- Power Consumption: 34.40 W, 0.72 amps, 117.46 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 1.9 lbs, 0.8 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950

## 4.9 XC10G Cross-Connect Card

New to Software R3.1 is the XC10G card (Figure 4-9), which cross-connects STS-12, STS-48, and STS-192 signal rates. The XC10G allows up to four times the bandwidth of current XC and XCVT cards. The XC10G provides a maximum of 1152 STS-1 cross-connections. Any STS-1 on any port can be connected to any other port, meaning that the STS cross-connections are non blocking.

Figure 4-9 shows the XC10G faceplate and block diagram. Figure 4-10 on page 4-28 shows the cross-connect matrix.

**Figure 4-9** XC10G faceplate and block diagram



The XC10G card manages up to 336 bidirectional VT1.5 ports and 576 bidirectional STS-1 ports. The TCC+ assigns bandwidth to each slot on a per STS-1 or per VT1.5 basis.


Either the XC10G, XCVT, or XC is required to operate the ONS 15454. You can establish cross-connect (circuit) information through the Cisco Transport Controller (CTC). The TCC+ establishes the proper internal cross-connect information and sends the setup information to the cross-connect card.



### Caution

Do not operate the ONS 15454 with a single TCC+ card or a single XC10G/XCVT/XC card installed. Always operate the shelf with one working and one protect card. Duplex cards must be the same type.

Figure 4-10 XC10G cross-connect matrix



## 4.9.1 VT Mapping

The VT structure is designed to transport and switch payloads below the DS-3 rate. The Cisco ONS 15454 performs Virtual Tributary (VT) mapping according to Telcordia GR-253 standards. Table 4-19 shows the VT numbering scheme for the ONS 15454 as it relates to the Telcordia standard.

Table 4-19 ONS 15454 VT Mapping

| ONS 15454 VT Number | Telcordia Group/VT Number |
|---------------------|---------------------------|
| VT1                 | Group1/VT1                |
| VT2                 | Group2/VT1                |
| VT3                 | Group3/VT1                |
| VT4                 | Group4/VT1                |
| VT5                 | Group5/VT1                |
| VT6                 | Group6/VT1                |
| VT7                 | Group7/VT1                |
| VT8                 | Group1/VT2                |
| VT9                 | Group2/VT2                |
| VT10                | Group3/VT2                |
| VT11                | Group4/VT2                |
| VT12                | Group5/VT2                |
| VT13                | Group6/VT2                |
| VT14                | Group7/VT2                |
| VT15                | Group1/VT3                |
| VT16                | Group2/VT3                |

**Table 4-19 ONS 15454 VT Mapping (continued)**

| ONS 15454 VT Number | Telcordia Group/VT Number |
|---------------------|---------------------------|
| VT17                | Group3/VT3                |
| VT18                | Group4/VT3                |
| VT19                | Group5/VT3                |
| VT20                | Group6/VT3                |
| VT21                | Group7/VT3                |
| VT22                | Group1/VT4                |
| VT23                | Group2/VT4                |
| VT24                | Group3/VT4                |
| VT25                | Group4/VT4                |
| VT26                | Group5/VT4                |
| VT27                | Group6/VT4                |
| VT28                | Group7/VT4                |

## 4.9.2 XC10G Hosting DS3XM-6

The XC10G card works with the DS3XM-6 (transmux) card. A single DS3XM-6 can demultiplex (map down to a lower rate) six DS-3 signals into 168 VT1.5s that the XC10G card manages and cross connects. XC10G cards host a maximum of 336 bidirectional VT1.5 ports. In most network configurations, two DS3XM-6 cards are paired as working and protect cards.

## 4.9.3 XC10G Card-Level Indicators

The XC10G faceplate has two card-level LEDs.

**Table 4-20 XC10G Card-Level Indicators**

| Card-Level Indicators                                                  | Definition                                                                                                                                                                                         |
|------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>                                                    | The red FAIL LED indicates that the card's processor is not ready. This LED illuminates during reset. The FAIL LED flashes during the boot process. Replace the card if the red FAIL LED persists. |
| <b>ACT/STBY LED</b><br><b>Green (Active)</b><br><b>Amber (Standby)</b> | The ACT/STBY (Active/Standby) LED indicates whether the XC10G is active and carrying traffic (green) or in standby mode to the active XC10G card (amber).                                          |

## 4.9.4 XC/XCVT/XC10G Compatibility

The XC10G supports the same features as the XC and XCVT cross-connects. The XC10G card is required for OC-192 and OC-48 any-slot operation. Do not use the XCVT or XC cards if you are using the OC-192 card, or if you placed one of the OC-48 any slot cards in a multispeed slot.

**Note**

A configuration mismatch alarm occurs when a XC or XCVT cross-connect card coexists with an OC-192 card placed in the high-speed slot, or with an OC-48 card placed in the multispeed slot.

The TCC+ card, Software R3.1 or higher and the new 15454-SA-ANSI shelf assembly are required for the operation of the XC10G. If you are using Ethernet cards, the E1000-2-G or the E100T-G must be used when the XC10G cross-connect card is in use. Do not pair an XC or XCVT with an XC10G. When upgrading from XC or XCVT to the XC10G card, see the *Cisco ONS 15454 Installation and Operations Guide* for more information.


## 4.9.5 XC10G Card Specifications

- Environmental
  - Operating Temperature:
    - C-Temp (15454-XC-10G): 0 to +55 degrees Celsius
  - Operating Humidity: 5 - 85%, non-condensing
  - Power Consumption: 54 W, 1.12 amps, 184.38 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 1.5 lbs, 0.6 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950

## 4.10 Alarm Interface Controller Card

The optional Alarm Interface Controller (AIC) card provides customer-defined alarm input/output (I/O) and supports local and express orderwire. Figure 4-11 shows the AIC faceplate and a block diagram of the card. Figure 4-12 on page 4-33 shows the RJ-11 cable.

**Figure 4-11 AIC faceplate and block diagram**



### 4.10.1 User-Defined Alarms

The AIC card provides input/output alarm contact closures. You can define up to four external alarms and four external controls. The physical connections are made using the backplane wire-wrap pins. The alarms are defined using CTC and TL1. For instructions, see the *Cisco ONS 15454 Installation and Operations Guide*.

Each alarm contact has a corresponding LED on the front panel of the AIC that indicates that the status of the alarm. External alarms (input contacts) are typically used for external sensors such as open doors, temperature sensors, flood sensors, and other environmental conditions. External controls (output contacts) are typically used to drive visual or audible devices such as bells and lights, but they can control other devices such as generators, heaters, and fans.

You can program each of the four input alarm contacts separately. Choices include Alarm on Closure or Alarm on Open, an alarm severity of any level (Critical, Major, Minor, Not Alarmed, Not Reported), a Service Affecting or Non-Service Affecting alarm-service level, and a 63-character alarm description for CTC display in the alarm log. You cannot assign the fan-tray abbreviation for the alarm; the abbreviation reflects the generic name of the input contacts. The alarm condition remains raised until the external input stops driving the contact or you provision the alarm input.

The output contacts can be provisioned to close on a trigger or to close manually. The trigger can be a local alarm severity threshold, a remote alarm severity, or a virtual wire:

- Local NE alarm severity: A hierarchy of non-reported, non-alarmed, minor, major or critical alarm severities that you set to cause output closure. For example, if the trigger is set to minor, a minor alarm or above is the trigger.
- Remote NE alarm severity: Same as the Local NE alarm severity but applies to remote alarms only.
- Virtual wire entities: You can provision any environmental alarm input to raise a signal on any virtual wire on external outputs 1 through 4 when the alarm input is an event. You can provision a signal on any virtual wire as a trigger for an external control output.

You can also program the output alarm contacts (external controls) separately. In addition to provisionable triggers, you can manually force each external output contact to open or close. Manual operation takes precedence over any provisioned triggers that might be present.

## 4.10.2 Orderwire

Orderwire allows a craftsperson to plug a phoneset into an ONS 15454 and communicate with craftspeople working at other ONS 15454s or other facility equipment. The orderwire is a pulse code modulation (PCM) encoded voice channel that uses E1 or E2 bytes in section/line overhead.

The AIC allows simultaneous use of both local (section overhead signal) and express (line overhead channel) orderwire channels on a SONET ring or particular optics facility. Local orderwire also allows communication at regeneration sites when the regenerator is not a Cisco device.

You can provision orderwire functions with CTC similar to the current provisioning model for DCC channels. In CTC you provision the orderwire communications network during ring turn-up so that all NEs on the ring can reach one another. Orderwire terminations (i.e. the optics facilities that receive and process the orderwire channels) are provisionable. Both express and local orderwire can be configured as on or off on a particular SONET facility. The ONS 15454 supports up to four orderwire channel terminations per shelf. This allows linear, single ring, dual ring, and small hub-and-spoke configurations. Keep in mind that orderwire is not protected in ring topologies such as BLSR and UPSR.



### Caution

---

Do not configure orderwire loops. Orderwire loops cause feedback that disables the orderwire channel.

---

The ONS 15454 implementation of both local and express orderwire is broadcast in nature. The line acts as a party line. There is no signalling for private point-to-point connections. Anyone who picks up the orderwire channel can communicate with all other participants on the connected orderwire subnetwork. The local orderwire party line is separate from the express orderwire party line. Up to four OC-N facilities for each local and express orderwire are provisionable as orderwire paths.

The AIC supports a “call” button on the module front panel which, when pressed, causes all ONS 15454 AICs on the orderwire subnetwork to “ring.” The ringer/buzzer resides on the AIC. There is also a “ring” LED that mimics the AIC ringer. It flashes when any “call” button is pressed on the orderwire subnetwork. The “call” button and ringer/LED allow a remote craftsman to get the attention of craftspeople across the network.


The orderwire ports are standard RJ-11 receptacles. The pins on the orderwire ports correspond to the tip and ring orderwire assignments.

**Table 4-21 Orderwire Pin Assignments**

| RJ-11 Pin Number | Description             |
|------------------|-------------------------|
| 1                | Four-wire receive ring  |
| 2                | Four-wire transmit tip  |
| 3                | Two-wire ring           |
| 4                | Two-wire tip            |
| 5                | Four-wire transmit ring |
| 6                | Four-wire receive tip   |

When provisioning the orderwire subnetwork, make sure that an orderwire loop does not exist. Loops cause oscillation and an unusable orderwire channel.

**Figure 4-12 RJ-11 cable**



### 4.10.3 AIC Specifications

- Environmental
  - Operating Temperature:
    - C-Temp (15454-AIC): 0 to +55 degrees Celsius
    - I-Temp (15454-AIC-T): -40 to +65 degrees Celsius



**Note** The I-Temp symbol is displayed on the faceplate of an I-Temp compliant card. A card without this symbol is C-Temp compliant.




- Operating Humidity: 5 - 95%, non-condensing
- Power Consumption: 6.01 W, 0.12 amps, 20.52 BTU/Hr.
- Dimensions

- Height: 12.650 in., Width: 0.716 in., Depth: 9.000 in.
- Card Weight: 1.6 lbs, 0.7 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950

## 4.11 EC1-12 Card

The EC1-12 card provides 12 Telcordia-compliant, GR-253 STS-1 electrical ports per card. Each port operates at 51.840 Mbps over a single 75 ohm 728A or equivalent coaxial span. Figure 4-13 shows the EC1-12 faceplate and a block diagram of the card.

**Figure 4-13 EC1-12 faceplate and block diagram**



STS path selection for UNEQ-P, AIS-P, and bit error rate (BER) thresholds is done on the SONET ring interfaces (optical cards) in conjunction with the STS cross-connect. The EC1-12 terminates but does not select the 12 working STS-1 signals from the backplane. The EC1-12 maps each of the 12 received EC1 signals into 12 STS-1s with visibility into the SONET path overhead.

You can install the EC1-12 card in any multispeed or high-speed card slot on the ONS 15454. Each EC1-12 interface features DSX-level (digital signal cross-connect frame) outputs supporting distances up to 450 feet depending on facility conditions.

An EC1-12 card can be 1:1 protected with another EC1-12 card but cannot protect more than one EC1-12 card. You must install the EC1-12 in an even-numbered slot to serve as a working card and in an odd-numbered slot to serve as a protect card.

## 4.11.1 EC1-12 Hosted by XCVT

All 14 VT1.5 payloads from a EC1-12 card are carried in a single STS-1 to the XC or XCVT card where the payload is further aggregated for efficient STS-1 transport. XCVT cards host a maximum of 336 bidirectional VT1.5s.

## 4.11.2 EC1-12 Card-Level Indicators

The EC1-12 card faceplate has three card-level LEDs.

**Table 4-22 EC1-12 Card-Level Indicators**

| Card-Level Indicators | Description                                                                                                                                                                 |
|-----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>   | The red FAIL LED signifies that the EC1-12 card's processor is not ready. Replace the unit if the FAIL LED persists.                                                        |
| <b>Green ACT LED</b>  | The green ACT LED indicates that the EC1-12 card is operational and ready to carry traffic.                                                                                 |
| <b>Amber SF LED</b>   | The amber SF LED indicates a signal failure or condition such as loss of signal (LOS), loss of frame (LOF) or high bit error rate (BER) on one or more of the card's ports. |

## 4.11.3 EC1-12 Port-Level Indicators

You can obtain the status of the EC1-12 card ports using the LCD screen on the ONS 15454 fan-tray. Use the LCD to view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, "Alarm Troubleshooting" for a complete description of the alarm messages.

## 4.11.4 EC1-12 Specifications

- EC1-12 Input
  - Bit Rate: 51.84 Mbps +/- 20 ppm
  - Frame Format: SONET
  - Line Code: B3ZS
  - Termination: Unbalanced coaxial cable
  - Input Impedance: 75 ohms +/-5%
  - Cable Loss: Max 450 ft. 734A, RG-59, 728A/Max 79 ft. RG-179
  - AIS: TR-TSY-000191-compliant
- EC1-12 Output
  - Bit Rate: 51.84 Mbps +/- 20 ppm
  - Frame Format: SONET
  - Line Code: B3ZS
  - Termination: Unbalanced coaxial cable

- Input Impedance: 75 ohms +/-5%
- Cable Loss: Max 450 ft. 734A, RG-59, 728A/Max 79 ft. RG-179
- AIS: TR-TSY-000191-compliant
- Power Level: -1.8 - +5.7 dBm
- Pulse Shape: ANSI T1.102-1988 Figure 8
- Pulse Amplitude: 0.36 - 0.85 V peak to peak
- Loopback Modes: Terminal and Facility
- Line Build Out: 0-225 ft.; 226-450 ft.
- EC1-12 Electrical Interface
  - Connectors: BNC or SMB
- Environmental
  - Operating Temperature:
    - C-Temp (15454-EC1-12): 0 to +55 degrees Celsius
    - I-Temp (15454-EC1-12-T): -40 to +65 degrees Celsius

**Note**

The I-Temp symbol is displayed on the faceplate of an I-Temp compliant card. A card without this symbol is C-Temp compliant.




- Operating Humidity: 5 - 95%, non-condensing
- Power Consumption: 36.60 W, 0.76 amps, 124.97 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 2.0 lbs, 0.9 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950

## 4.12 DS1-14 Card

The ONS 15454 DS1-14 card provides 14 Telcordia-compliant, GR-499 DS-1 ports. Each port operates at 1.544 Mbps over a 100 ohm twisted-pair copper cable. The DS1-14 card can function as a working or protect card in 1:1 protection schemes and as a working card in 1:N protection schemes. Figure 4-14 shows the DS1-14 faceplate and a block diagram of the card.

**Figure 4-14 DS1-14 faceplate and block diagram**



You can install the DS1-14 card in any multispeed or high-speed card slot on the ONS 15454. Each DS1-14 port has DSX-level (digital signal cross-connect frame) outputs supporting distances up to 655 feet.

The DS1-14 card supports 1:1 protection. The DS1-14 can be a working card in a 1:N protection scheme with the proper backplane EIA and wire-wrap or AMP Champ connectors. You can also provision the DS1-14 to monitor for line and frame errors in both directions.

You can group and map DS1-14 card traffic in STS-1 increments to any other card in an ONS 15454 except DS-3 cards. Each DS-1 is asynchronously mapped into a SONET VT1.5 payload and the card carries a DS-1 payload intact in a VT1.5. For performance monitoring purposes, you can gather bidirectional DS-1 frame-level information (loss of frame, parity errors, cyclic redundancy check [CRC] errors, etc.).

## 4.12.1 DS1-14 Hosted by XCVT

All 14 VT1.5 payloads from a DS1-14 card are carried in a single STS-1 to the XC or XCVT card where the payload is further aggregated for efficient STS-1 transport. XCVT cards host a maximum of 336 bidirectional VT1.5s.

## 4.12.2 DS1-14 Card-Level Indicators

The DS1-14 card faceplate has three LEDs.

**Table 4-23 DS1-14 Card-Level Indicators**

| Card-Level Indicators                                                  | Description                                                                                                                                  |
|------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>                                                    | The red FAIL LED indicates that the card's processor is not ready. Replace the card if the red FAIL LED persists.                            |
| <b>ACT/STBY LED</b><br><b>Green (Active)</b><br><b>Amber (Standby)</b> | The green/amber ACT/STBY LED indicates whether the DS1-14 card is operational and ready to carry traffic (green) or in standby mode (amber). |
| <b>Amber SF LED</b>                                                    | The amber SF LED indicates a signal failure or condition such as LOS, LOF or high BERs on one or more of the card's ports.                   |

## 4.12.3 DS1-14 Port-Level Indicators

You can obtain the status of the DS1-14 card ports using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, "Alarm Troubleshooting" for a complete description of the alarm messages.

## 4.12.4 DS1-14 Specifications

- DS1-14 Input
  - Bit Rate: 1.544 Mbps +/- 32 ppm
  - Frame Format: Off, SF (D4), ESF
  - Line Code: AMI, B8ZS
  - Termination: Wire-wrap, AMP Champ
  - Input Impedance: 100 ohms
  - Cable Loss: Max 655 ft. ABAM #22 AWG
  - AIS: TR-TSY-000191-compliant
- DS1-14 Output
  - Bit Rate: 1.544 Mbps +/- 32 ppm
  - Frame Format: Off, SF (D4), ESF
  - Line Code: AMI, B8ZS

- Termination: Wire-wrap, AMP Champ
- Input Impedance: 100 ohms
- Cable Loss: Max 655 ft. ABAM #22 AWG
- AIS: TR-TSY-000191-compliant
- Power Level: 12.5 to 17.9 dBm centered @ 772 KHz, -16.4 to -11.1 dBm centered at 1544 KHz
- Pulse Shape: GR-499-CORE Figure 9-5
- Pulse Amplitude: 2.4- 3.6 V peak-to-peak
- Loopback Modes: Terminal and Facility
- Environmental
  - Surge Protection: GR-1089
  - Operating Temperature:
    - C-Temp (15454-DS1-14): 0 to +55 degrees Celsius
    - I-Temp (15454-DS1-14-T): -40 to +65 degrees Celsius

**Note**

The I-Temp symbol is displayed on the faceplate of an I-Temp compliant card. A card without this symbol is C-Temp compliant.




- Operating Humidity: 5 - 95%, non-condensing
- Power Consumption: 12.60 W, 0.26 amps, 43.02 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 1.8 lbs, 0.8 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950

## 4.13 DS1N-14 Card

The DS1N-14 card provides 14 Telcordia-compliant, GR-499 DS-1 ports. Each DS1N-14 port operates at 1.544 Mbps over a 100 ohm twisted-pair copper cable. Figure 4-15 shows the DS1N-14 faceplate and a block diagram of the card.

**Figure 4-15 DS1N-14 faceplate and block diagram**



Each DS1N-14 port features DSX-level outputs supporting distances up to 655 feet depending on facility conditions.

The DS1N-14 card supports 1:N ( $N \leq 5$ ) protection with the proper backplane EIA and wire-wrap or AMP Champ connectors. You can also provision the DS1N-14 to monitor line and frame errors in both directions.

The DS1N-14 card can function as a working or protect card in 1:1 or 1:N protection schemes. If you use the DS1N-14 as a standard DS-1 card in a 1:1 protection group, you can install the DS1N-14 card in any multispeed or high-speed card slot on the ONS 15454. If you use the card's 1:N functionality, you must install a DS1N-14 card in Slots 3 and 15.

You can group and map DS1N-14 card traffic in STS-1 increments to any other card in an ONS 15454 node. Each DS-1 is asynchronously mapped into a SONET VT1.5 payload and the card carries a DS-1 payload intact in a VT1.5. For performance-monitoring purposes, you can gather bidirectional DS-1 frame-level information (loss of frame, parity errors or CRC errors, for example).

## 4.13.1 DS1N-14 Hosted by XCVT

All 14 VT1.5 payloads from a DS1N-14 card are carried in a single STS-1 to the XC or XCVT card where the payload is further aggregated for efficient STS-1 transport. XCVT cards host a maximum of 336 bidirectional VT1.5s.

## 4.13.2 DS1N-14 Card-Level Indicators

The DS1N-14 card faceplate has three LEDs.

**Table 4-24 DS1N-14 Card-Level Indicators**

| Card-Level Indicators                                                  | Description                                                                                                                                     |
|------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>                                                    | The red FAIL LED indicates that the card's processor is not ready. Replace the card if the FAIL LED persists.                                   |
| <b>ACT/STBY LED</b><br><b>Green (Active)</b><br><b>Amber (Standby)</b> | The ACT/STBY LED indicates when the DS1N-14 card is operational and ready to carry traffic (green) or when the card is in standby mode (amber). |
| <b>Amber SF LED</b>                                                    | The amber SF LED indicates a signal failure or condition such as LOS, LOF or high BERs on one or more of the card's ports.                      |

## 4.13.3 DS1N-14 Port-Level Indicators

You can obtain the status of the 14 DS-1 ports using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, "Alarm Troubleshooting" for a complete description of the alarm messages.

## 4.13.4 DS1N-14 Specifications

- DS1N-14 Input
  - Bit Rate: 1.544 Mbps +/- 32 ppm
  - Frame Format: Off, SF (D4), ESF
  - Line Code: AMI, B8ZS
  - Termination: Wire-wrap, AMP Champ
  - Input Impedance: 100 ohms
  - Cable Loss: Max 655 ft. ABAM #22 AWG
  - AIS: TR-TSY-000191-compliant
- DS1N-14 Output
  - Bit Rate: 1.544 Mbps +/- 32 ppm
  - Frame Format: Off, SF (D4), ESF
  - Line Code: AMI, B8ZS

- Termination: Wire-wrap, AMP Champ
- Input Impedance: 100 ohms
- Cable Loss: Max 655 ft. ABAM #22 AWG
- AIS: TR-TSY-000191-compliant
- Power Level: 12.5 to 17.9 dBm centered @ 772 KHz, -16.4 to -11.1 dBm centered at 1544 KHz
- Pulse Shape: GR-499-CORE Figure 9-5
- Pulse Amplitude: 2.4- 3.6 V peak-to-peak
- Loopback Modes: Terminal and Facility
- Environmental
  - Surge Protection: GR-1089
  - Operating Temperature:
    - C-Temp (15454-DS1N-14): 0 to +55 degrees Celsius
    - I-Temp (15454-DS1N-14-T): -40 to +65 degrees Celsius

**Note**

The I-Temp symbol is displayed on the faceplate of an I-Temp compliant card. A card without this symbol is C-Temp compliant.




- Operating Humidity: 5 - 95%, non-condensing
- Power Consumption: 12.60 W, 0.26 amps, 43.02 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 1.9 lbs, 0.8 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950

## 4.14 DS3-12 Card

The ONS 15454 DS3-12 card provides 12 Telcordia-compliant, GR-499 DS-3 ports per card. Each port operates at 44.736 Mbps over a single 75 ohm 728A or equivalent coaxial span. The DS3-12 card operates as a working or protect card in 1:1 protection schemes and as a working card in 1:N protection schemes. Figure 4-16 shows the DS3-12 faceplates, and a block diagram of the card.

**Figure 4-16 DS3-12 faceplate and block diagram**



You can install the DS3-12 card in any multispeed or high-speed card slot on the ONS 15454. Each DS3-12 card port features DSX-level outputs supporting distances up to 450 feet depending on facility conditions.

The DS3-12 card supports 1:1 protection with the proper backplane EIA. EIAs are available with BNC or SMB connectors. For more information, see the “Electrical Card Protection and the Backplane” section on page 4-14.



### Caution

When a protection switch moves traffic from the DS3-12 working/active card to the DS3-12 protect/standby card, ports on the now active/standby card cannot be taken out of service. Lost traffic can result if you take a port out of service even if the DS3-12 standby card no longer carries traffic.

## 4.14.1 DS3-12 Card-Level Indicators

The DS3-12 card faceplate has three LEDs.

**Table 4-25 DS3-12 Card-Level Indicators**

| Card-Level Indicators                                                  | Description                                                                                                                                                                                |
|------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>                                                    | The red FAIL LED indicates that the card's processor is not ready. Replace the card if the red FAIL LED persists.                                                                          |
| <b>ACT/STBY LED</b><br><b>Green (Active)</b><br><b>Amber (Standby)</b> | When the ACTV/STBY LED is green, the DS3-12 card is operational and ready to carry traffic. When the ACTV/STBY LED is amber, the DS3-12 card is operational and in standby (protect) mode. |
| <b>Amber SF LED</b>                                                    | The amber SF LED indicates a signal failure or condition such as port LOS.                                                                                                                 |

## 4.14.2 DS3-12 Port-Level Indicators

You can find the status of the 12 DS3-12 card ports using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, "Alarm Troubleshooting" for a complete description of the alarm messages.

## 4.14.3 DS3-12 Specifications

- DS3-12 Input
  - Bit Rate: 44.736 Mbps +/- 20 ppm
  - Frame Format: DS-3 ANSI T1.107-1988
  - Line Code: B3ZS
  - Termination: Unbalanced coaxial cable
  - Input Impedance: 75 ohms +/-5%
  - Cable Loss: Max 450 ft. 734A, RG-59, 728A/Max 79 ft. RG-179
  - AIS: TR-TSY-000191-compliant
- DS3-12 Output
  - Bit Rate: 44.736 Mbps +/- 20 ppm
  - Frame Format: DS-3 ANSI T1.107-1988
  - Line Code: B3ZS
  - Termination: Unbalanced coaxial cable
  - Input Impedance: 75 ohms +/-5%
  - Cable Loss: Max 450 ft. 734A, RG-59, 728A/Max 79 ft. RG-179
  - AIS: TR-TSY-000191-compliant
  - Power Level: -1.8 - +5.7 dBm
  - Pulse Shape: ANSI T1.102-1988 Figure 8

- Pulse Amplitude: 0.36 - 0.85 V peak-to-peak
- Loopback Modes: Terminal and Facility
- DS3-12 Electrical Interface
  - Connectors: BNC or SMB
- Environmental
  - Operating Temperature:
    - C-Temp (15454-DS3-12): 0 to +55 degrees Celsius
    - I-Temp (15454-DS3-12-T): -40 to +65 degrees Celsius



**Note** The I-Temp symbol is displayed on the faceplate of an I-Temp compliant card. A card without this symbol is C-Temp compliant.




- Operating Humidity: 5 - 95%, non-condensing
- Power Consumption: 38.20 W, 0.79 amps, 130.43 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 1.7 lbs, 0.7 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950

## 4.15 DS3N-12 Card

The ONS 15454 DS3N-12 card provides 12 Telcordia-compliant, TR499 DS-3 ports per card. Each port operates at 44.736 Mbps over a single 75 ohm 728A or equivalent coaxial span. Figure 4-17 shows the DS3N-12 faceplate and a diagram of the card.

**Figure 4-17 DS3N-12 faceplate and block diagram**



You can install the DS3N-12 card in any multispeed or high-speed card slot. Each DS3N-12 card port features DSX-level outputs supporting distances up to 450 feet depending on facility conditions. With the proper backplane EIA, the card supports BNC or SMB connectors.

The DS3N-12 can operate as the protect card in a 1:N ( $N \leq 5$ ) DS-3 protection group. It has additional circuitry not present on the basic DS3-12 card that allows it to protect up to five working DS3-12 cards. The basic DS3-12 card can only function as the protect card for one other DS3-12 card. Other than the protection capabilities, the DS3-12 and DS3N-12 cards are identical.

## 4.15.1 DS3N-12 Card-Level Indicators

The DS3N-12 card faceplate has three LEDs.

**Table 4-26 DS3N-12 Card-Level Indicators**

| Card-Level Indicators                                                  | Description                                                                                                                                                                                  |
|------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>                                                    | The red FAIL LED indicates that the card's processor is not ready. Replace the card if the red FAIL LED persists.                                                                            |
| <b>ACT/STBY LED</b><br><b>Green (Active)</b><br><b>Amber (Standby)</b> | When the ACTV/STBY LED is green, the DS3N-12 card is operational and ready to carry traffic. When the ACTV/STBY LED is amber, the DS3N-12 card is operational and in standby (protect) mode. |
| <b>Amber SF LED</b>                                                    | The amber SF LED indicates a signal failure or condition such as port LOS, AIS, etc.                                                                                                         |

## 4.15.2 DS3N-12 Port-Level Indicators

You can find the status of the 12 DS3N-12 card ports using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to quickly view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, "Alarm Troubleshooting" for a complete description of the alarm messages.

## 4.15.3 DS3N-12 Card Specifications

- DS3N-12 Input
  - Bit Rate: 44.736 Mbps +/- 20 ppm
  - Frame Format: DS-3 ANSI T1.107-1988
  - Line Code: B3ZS
  - Termination: Unbalanced coaxial cable
  - Input Impedance: 75 ohms +/-5%
  - Cable Loss: Max 450 ft. 734A, RG-59, 728A/Max 79 ft. RG-179
  - AIS: TR-TSY-000191-compliant
- DS3N-12 Output
  - Bit Rate: 44.736 Mbps +/- 20 ppm
  - Frame Format: DS-3 ANSI T1.107-1988
  - Line Code: B3ZS
  - Termination: Unbalanced coaxial cable
  - Input Impedance: 75 ohms +/-5%
  - Cable Loss: Max 450 ft. 734A, RG-59, 728A/Max 79 ft. RG-179
  - AIS: TR-TSY-000191-compliant
  - Power Level: -1.8 - +5.7 dBm

- Pulse Shape: ANSI T1.102-1988 Figure 8
- Pulse Amplitude: 0.36 - 0.85 V peak-to-peak
- Loopback Modes: Terminal and Facility
- Line Build Out: 0-225 ft.; 226-450 ft.
- DS3N-12 Electrical Interface
  - Connectors: BNC or SMB
- Environmental
  - Operating Temperature:
    - C-Temp (15454-DS3N-12): 0 to +55 degrees Celsius
    - I-Temp (15454-DS3N-12-T): -40 to +65 degrees Celsius



**Note** The I-Temp symbol is displayed on the faceplate of an I-Temp compliant card. A card without this symbol is C-Temp compliant.




- Operating Humidity: 5 - 95%, non-condensing
- Power Consumption: 38.20 W, 0.79 amps, 130.43 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 1.8 lbs, 0.8 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950

## 4.16 DS3-12E Card

The ONS 15454 DS3-12E card provides 12 Telcordia-compliant ports per card. Each port operates at 44.736 Mbps over a single 75 ohm 728A or equivalent coaxial span. The DS3-12E card provides enhanced performance monitoring functions. The DS3-12E can detect several different errored logic bits within a DS-3 frame. This function allows the ONS 15454 to identify a degrading DS-3 facility caused by upstream electronics (DS-3 Framer). In addition, DS3 frame format auto detection and J1 path trace are supported. By monitoring additional overhead in the DS-3 frame, subtle network degradations can be detected. Figure 4-18 shows the DS3-12E faceplate and a diagram of the card.

**Figure 4-18 DS3-12E faceplate and block diagram**



The following list summarizes DS3-12E card features:

- Provisionable framing format M23, C-bit or unframed
- Autorecognition and provisioning of incoming framing
- P-bit monitoring
- C-bit parity monitoring
- X-bit monitoring
- M-bit monitoring

- F-bit monitoring
- Far-end block errors (FEBE) monitoring
- Far-end alarm and control (FEAC) status and loop code detection
- Path trace byte support with TIM-P alarm generation

You can install the DS3-12E card in any multispeed or high-speed card slot on the ONS 15454. Each DS3-12E port features DSX-level outputs supporting distances up to 450 feet. With the proper backplane EIA, the card supports BNC or SMB connectors.

The DS3-12E supports a 1:1 protection scheme, meaning it can operate as the protect card for one other DS3-12E card.

## 4.16.1 DS3-12E Card-Level Indicators

The DS3-12E card faceplate has three LEDs.

**Table 4-27 DS3-12E Card-Level Indicators**

| Card-Level Indicators                                                  | Description                                                                                                                                                                                  |
|------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>                                                    | The red FAIL LED indicates that the card's processor is not ready. Replace the card if the red FAIL LED persists.                                                                            |
| <b>ACT/STBY LED</b><br><b>Green (Active)</b><br><b>Amber (Standby)</b> | When the ACTV/STBY LED is green, the DS3-12E card is operational and ready to carry traffic. When the ACTV/STBY LED is amber, the DS3-12E card is operational and in standby (protect) mode. |
| <b>Amber SF LED</b>                                                    | The amber SF LED indicates a signal failure or condition such as port LOS, AIS, etc.                                                                                                         |

## 4.16.2 DS3-12E Port-Level Indicators

You can find the status of the DS3-12E card ports using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to quickly view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, "Alarm Troubleshooting" for a complete description of the alarm messages.

## 4.16.3 DS3-12E Compatibility

The DS3-12E is compatible with Software R2.2.x or higher. If Software R3.0 or higher is used, the card uses all enhanced performance monitoring functions. With Software R2.2.2, the DS-3E card operates with the same functions as the older DS-3 card.

## 4.16.4 DS3-12E Card Specifications

- DS3-12E Input
  - Bit Rate: 44.736 Mbps +/- 20 ppm
  - Frame Format: DS-3 ANSI T1.107-1988

- Line Code: B3ZS
- Termination: Unbalanced coaxial cable
- Input Impedance: 75 ohms +/-5%
- Cable Loss: Max 450 ft. 734A, RG-59, 728A/Max 79 ft. RG-179
- AIS: TR-TSY-000191-compliant
- DS3-12E Output
  - Bit Rate: 44.736 Mbps +/- 20 ppm
  - Frame Format: DS-3 ANSI T1.107-1988
  - Line Code: B3ZS
  - Termination: Unbalanced coaxial cable
  - Input Impedance: 75 ohms +/-5%
  - Cable Loss: Max 450 ft. 734A, RG-59, 728A/Max 79 ft. RG-179
  - AIS: TR-TSY-000191-compliant
  - Power Level: -1.8 - +5.7 dBm (The power level is for a signal of all ones and is measured at a center frequency of 22.368 MHz (+/-KHz) bandwidth.)
  - Pulse Shape: ANSI T1.102-1988 Figure 8
  - Pulse Amplitude: 0.36 - 0.85 V peak-to-peak
  - Loopback Modes: Terminal and Facility
  - Line Build Out: 0-225 ft.; 226-450 ft.
- DS3-12E Electrical Interface
  - Connectors: BNC or SMB
- Environmental
  - Operating Temperature:
    - I-Temp (15454-DS3-12E-T): -40 to +65 degrees Celsius



**Note** The I-Temp symbol is displayed on the faceplate of an I-Temp compliant card. A card without this symbol is C-Temp compliant.




- Operating Humidity: 5 - 95%, non-condensing
- Power Consumption: 26.80 W, 0.56 amps, 91.51 BTU/Hr.
- Dimensions
  - Height: 12.650 in., Width: 0.716 in., Depth: 9.000 in.
  - Depth with backplane connector: 9.250 in.
  - Card Weight: 1.8 lbs, 0.8 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950

## 4.17 DS3N-12E Card

The ONS 15454 DS3N-12E card provides 12 Telcordia-compliant ports per card. Each port operates at 44.736 Mbps over a single 75 ohm 728A or equivalent coaxial span. The DS3N-12E card provides enhanced performance monitoring functions. The DS3N-12E can detect several different errored logic bits within a DS-3 frame. This function allows the ONS 15454 to identify a degrading DS-3 facility caused by upstream electronics (DS-3 Framer). In addition, DS3 frame format auto detection and J1 path trace are supported. By monitoring additional overhead in the DS-3 frame, subtle network degradations can be detected. Figure 4-19 shows the DS3N-12E faceplate and a diagram of the card.

**Figure 4-19 DS3N-12E faceplate and block diagram**



The following list summarizes the DS3N-12E card features:

- Provisionable framing format M23, C-bit or unframed
- Autorecognition and provisioning of incoming framing
- P-bit monitoring
- C-bit parity monitoring
- X-bit monitoring
- M-bit monitoring

- F-bit monitoring
- Far-end block errors (FEBE) monitoring
- Far-end alarm and control (FEAC) status and loop code detection
- Path trace byte support with TIM-P alarm generation

You can install the DS3N-12E card in any multispeed or high-speed card slot. Each DS3N-12E port features DSX-level outputs supporting distances up to 450 feet. With the proper backplane EIA, the card supports BNC or SMB connectors.

The DS3N-12E can operate as the protect card in a 1:N ( $N \leq 5$ ) DS-3 protection group. It has additional circuitry not present on the basic DS3-12E card that allows it to protect up to five working DS3-12E cards. The basic DS3-12E card can only function as the protect card for one other DS3-12E card.

## 4.17.1 DS3N-12E Card-Level Indicators

The DS3N-12E card faceplate has three LEDs.

**Table 4-28 DS3N-12E Card-Level Indicators**

| Card-Level Indicators                                                  | Description                                                                                                                                                                                    |
|------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>                                                    | The red FAIL LED indicates that the card's processor is not ready. Replace the card if the red FAIL LED persists.                                                                              |
| <b>ACT/STBY LED</b><br><b>Green (Active)</b><br><b>Amber (Standby)</b> | When the ACTV/STBY LED is green, the DS3N-12E card is operational and ready to carry traffic. When the ACTV/STBY LED is amber, the DS3N-12E card is operational and in standby (protect) mode. |
| <b>Amber SF LED</b>                                                    | The amber SF LED indicates a signal failure or condition such as AIS, LOS, or LOF on one or more of the card's ports.                                                                          |

## 4.17.2 DS3N-12E Port-Level Indicators

You can find the status of the DS3N-12E card ports using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, "Alarm Troubleshooting" for a complete description of the alarm messages.

## 4.17.3 DS3N-12E Compatibility

The DS3N-12E cards are compatible with Software R2.2.x or higher. If Software R3.0 or higher is used, the DS3N-12E operates using all enhanced performance monitoring functions. With Software R2.2.2, the DS3N-12E operates with the same functions as the older DS-3 card.

## 4.17.4 DS3N-12E Card Specifications


- DS3N-12E Input
  - Bit Rate: 44.736 Mbps +/- 20 ppm

- Frame Format: DS-3 ANSI T1.107-1988
  - Line Code: B3ZS
  - Termination: Unbalanced coaxial cable
  - Input Impedance: 75 ohms +/-5%
  - Cable Loss: Max 450 ft. 734A, RG-59, 728A/Max 79 ft. RG-179
  - AIS: TR-TSY-000191-compliant
  - DS3N-12E Output
    - Bit Rate: 44.736 Mbps +/- 20 ppm
    - Frame Format: DS-3 ANSI T1.107-1988
    - Line Code: B3ZS
    - Termination: Unbalanced coaxial cable
    - Input Impedance: 75 ohms +/-5%
    - Cable Loss: Max 450 ft. 734A, RG-59, 728A/Max 79 ft. RG-179
    - AIS: TR-TSY-000191-compliant
    - Power Level: -1.8 - +5.7 dBm (The power level is for a signal of all ones and is measured at a center frequency of 22.368 MHz (+/-KHz) bandwidth.)
    - Pulse Shape: ANSI T1.102-1988 Figure 8
    - Pulse Amplitude: 0.36 - 0.85 V peak-to-peak
    - Loopback Modes: Terminal and Facility
    - Line Build Out: 0-225 ft.; 226-450 ft.
  - DS3N-12E Electrical Interface
    - Connectors: BNC or SMB
  - Environmental
    - Operating Temperature:
      - I-Temp (15454-DS3N-12E-T): -40 to +65 degrees Celsius
- 
-  **Note** The I-Temp symbol is displayed on the faceplate of an I-Temp compliant card. A card without this symbol is C-Temp compliant. 
- 
- Operating Humidity: 5 - 95%, non-condensing
  - Power Consumption: 26.80 W, 0.56 amps, 91.51 BTU/Hr.
  - Dimensions
    - Height: 12.650 in., Width: 0.716 in., Depth: 9.000 in.
    - Depth with backplane connector: 9.250 in.
    - Card Weight: 1.9 lbs, 0.8 kg
  - Compliance
    - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950

## 4.18 DS3XM-6 Card

The DS3XM-6 card, commonly referred to as a transmux card, provides six Telcordia-compliant, GR-499-CORE M13 multiplexing functions. The DS3XM-6 converts six framed DS-3 network connections to 28x6 or 168 VT1.5s. Figure 4-20 shows the DS3XM-6 faceplate and a block diagram of the card.

**Figure 4-20 DS3XM-6 faceplate and block diagram**



### Note

You cannot create circuits from a DS3XM-6 card to a DS-3 card. DS3XM-6 cards operate at the VT1.5 level.

You can install the DS3XM-6 in any multispeed or high-speed card slot. Each DS3XM-6 port features DSX-level outputs supporting distances up to 450 feet depending on facility conditions. The DS3XM-6 card supports 1:1 protection with the proper backplane EIA. EIAs are available with BNC or SMB connectors.

## 4.18.1 DS3XM-6 Hosted By XCVT

The DS3XM-6 card works in conjunction with the XCVT card. A single DS3XM-6 can demultiplex (map down to a lower rate) six DS-3 signals into 168 VT1.5s that the XCVT card then manages and cross connects. XCVT cards host a maximum of 336 bidirectional VT1.5s or two DS3XM-6 cards. In most network configurations two DS3XM-6 cards are paired together as working and protect cards.

## 4.18.2 DS3XM-6 Card-Level Indicators

The DS3XM-6 card faceplate has three LEDs.

**Table 4-29 DS3XM-6 Card-Level Indicators**

| Card-Level Indicators                                                  | Description                                                                                                                                                                                             |
|------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>                                                    | The red FAIL LED indicates that the card's processor is not ready. Replace the card if the red FAIL LED persists.                                                                                       |
| <b>ACT/STBY LED</b><br><b>Green (Active)</b><br><b>Amber (Standby)</b> | When the ACTV/STBY LED is green, the DS3XM-6 card is operational and ready to carry traffic. When the ACTV/STBY LED is amber, the DS3XM-6 card is operational and in standby in a 1:1 protection group. |
| <b>Amber SF LED</b>                                                    | The amber SF LED indicates a signal failure or condition such as LOS, LOF, or high BER on one or more of the card's ports.                                                                              |

## 4.18.3 DS3XM-6 Port-Level Indicators

You can find the status of the six DS3XM-6 card ports using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to quickly view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, "Alarm Troubleshooting" for a complete description of the alarm messages.

## 4.18.4 DS3XM-6 Card Specifications

- DS3XM-6 Input
  - Bit Rate: 44.736 Mbps +/- 20 ppm
  - Frame Format: DS-3 ANSI T1.107-1988
  - Line Code: B3ZS
  - Termination: Unbalanced coaxial cable
  - Input Impedance: 75 ohms +/-5%
  - Cable Loss: Max 450 ft. 734A, RG-59, 728A/Max 79 ft. RG-179
- AIS: TR-TSY-000191-compliant
  - DS3XM-6 Output
    - Bit Rate: 44.736 Mbps +/- 20 ppm
    - Frame Format: DS-3 ANSI T1.107-1988
    - Line Code: B3ZS

- Termination: Unbalanced coaxial cable
- Input Impedance: 75 ohms +/-5%
- Cable Loss: Max 450 ft. 734A, RG-59, 728A/Max 79 ft. RG-179
- AIS: TR-TSY-000191-compliant
- Power Level: -1.8 - +5.7 dBm
- Pulse Shape: ANSI T1.102-1988 Figure 8
- Pulse Amplitude: 0.36 - 0.85 V peak-to-peak
- Loopback Modes: Terminal and Facility
- Line Build Out: 0-225 ft.; 226-450 ft.
- DS3XM-6 Electrical Interface
  - Connectors: BNC or SMB
- Environmental
  - Operating Temperature:
    - C-Temp (15454-DS3XM-6): 0 to +55 degrees Celsius
    - I-Temp (15454-DS3XM-6-T): -40 to +65 degrees Celsius

**Note**

The I-Temp symbol is displayed on the faceplate of an I-Temp compliant card. A card without this symbol is C-Temp compliant.



- Operating Humidity: 5 - 95%, non-condensing
- Power Consumption: 20 W, 0.42 amps, 68 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 1.8 lbs, 0.8 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950

## 4.19 OC3 IR 4/STM1 SH 1310 Card


The OC3 IR 4/STM1 SH 1310 card provides four intermediate or short range SONET/SDH OC-3 ports compliant with the International Telecommunication Union's G.707, G.957, and Telcordia's GR-253. Each port operates at 155.52 Mbps over a single-mode fiber span. The card supports VT and non-concatenated or concatenated payloads at the STS-1 or STS-3c signal levels. Figure 4-21 shows the OC3 IR 4/STM1 SH 1310 faceplate and a diagram of the card.



Note

The OC3 IR 4 SH 1310 and OC3 IR 4/STM1 SH 1310 cards are functionally the same.

Figure 4-21 OC3 IR 4/STM1 SH 1310 faceplate and block diagram



You can install the OC3 IR 4/STM1 SH 1310 card in any multispeed or high-speed card slot. The card can be provisioned as part of a unidirectional path switched ring (UPSR) or in a linear add-drop multiplexer (ADM) configuration. Each port features a 1310 nm laser and contains a transmit and receive connector (labeled) on the card faceplate. The card uses SC connectors.

The OC3 IR 4/STM1 SH 1310 card supports 1+1 unidirectional or bidirectional protection switching. You can provision protection on a per port basis. See the "Optical Card Protection" section on page 4-15, for more information.

The OC3 IR 4/STM1 SH 1310 detects LOS, LOF, Loss of Pointer (LOP), line Alarm Indication Signal (AIS-L), and line Remote Defect Indication (RDI-L) conditions. See Chapter 1, “Alarm Troubleshooting” for a description of these conditions. The card also counts section and line bit interleaved parity (BIP) errors.

## 4.19.1 OC3 IR 4/STM1 SH 1310 Card-Level Indicators

The OC3 IR 4/STM1 SH 1310 card has three card-level LED indicators.

**Table 4-30 OC3 IR 4/STM1 SH 1310 Card-Level Indicators**

| Card-Level Indicators | Description                                                                                                                                                                                                                                                                                     |
|-----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>   | The red FAIL LED indicates that the card’s processor is not ready. Replace the card if the red FAIL LED persists.                                                                                                                                                                               |
| <b>Green ACT LED</b>  | The green ACT LED indicates that the OC3 IR 4/STM1 SH 1310 card is carrying traffic or is traffic-ready.                                                                                                                                                                                        |
| <b>Amber SF LED</b>   | The amber SF LED indicates a signal failure or condition such as LOS, LOF, AIS-L or high BER on one or more of the card’s ports. The amber SF LED also illuminates when the transmit and receive fibers are incorrectly connected. When the fibers are properly connected, the light turns off. |

## 4.19.2 OC3 IR 4/STM1 SH 1310 Port-Level Indicators

You can find the status of the four card ports using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, “Alarm Troubleshooting” for a complete description of the alarm messages.



**Warning**

**Invisible laser radiation may be emitted from the end of the unterminated fiber cable or connector. Do not stare into the beam or view directly with optical instruments. Viewing the laser output with certain optical instruments (for example, eye loupes, magnifiers, and microscopes) within a distance of 100 mm may pose an eye hazard. Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.**

## 4.19.3 OC3 IR 4/STM1 SH 1310 Card Specifications

- Line
  - Bit Rate: 155.52 Mbps
  - Code: Scrambled NRZ
  - Fiber: 1310 nm single-mode
  - Loopback Modes: Terminal and Facility
  - Connector: SC
  - Compliance: Telcordia SONET, GR-GSY-00253, ITU-T G.707, ITU-T G.957
  - Transmitter

- Max. Transmitter Output Power: -8 dBm
- Min. Transmitter Output Power: -15 dBm
- Center Wavelength: 1274 nm – 1356 nm
- Nominal Wavelength: 1310 nm
- Transmitter: Fabry Perot laser
- Receiver
  - Max. Receiver Level: -8 dBm
  - Min. Receiver Level: -28 dBm
  - Receiver: InGaAs/InP photo detector
  - Link Loss Budget: 13 dB
- Environmental
  - Operating Temperature:
    - C-Temp (15454-OC34IR1310): 0 to +55 degrees Celsius
    - I-Temp (15454-OC34I13-T): -40 to +65 degrees Celsius

**Note**

The I-Temp symbol is displayed on the faceplate of an I-Temp compliant card. A card without this symbol is C-Temp compliant.



- Operating Humidity: 5 - 95%, non-condensing
- Power Consumption: 19.20 W, 0.40 amps, 65.56 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 1.0 lbs, 0.4 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950
  - Eye Safety Compliance: Class I

## 4.20 OC12 IR/STM4 SH 1310 Card


The OC12 IR/STM4 SH 1310 card provides one intermediate or short range SONET/SDH OC-12 port compliant with the International Telecommunication Union's G.707, G.957, and Telcordia's GR-253. The port operates at 622.08 Mbps over a single-mode fiber span. The card supports VT and non-concatenated or concatenated payloads at STS-1, STS-3c, STS-6c or STS-12c signal levels. Figure 4-22 shows the OC12 IR/STM4 SH 1310 faceplate and a block diagram of the card.



### Note

The OC12 IR 1310 and OC12/STM4 SH 1310 cards are functionally the same.

**Figure 4-22 OC12 IR/STM4 SH 1310 faceplate and block diagram**



You can install the OC12 IR/STM4 SH 1310 card in any multispeed or high-speed card slot and provision the card as a drop card or span card in a two-fiber BLSR, UPSR, or in ADM (linear) configurations.

The OC12 IR/STM4 SH 1310 port features a 1310 nm laser and contains a transmit and receive connector (labeled) on the card faceplate. The OC12 IR/STM4 SH 1310 uses SC optical connections and supports 1+1 unidirectional and bidirectional protection.

The OC12 IR/STM4 SH 1310 detects LOS, LOF, LOP, AIS-L, and RDI-L conditions. See Chapter 1, “Alarm Troubleshooting” for a description of these conditions. The card counts section and line BIT errors.

## 4.20.1 OC12 IR/STM4 SH 1310 Card-Level Indicators

The OC12 IR/STM4 SH 1310 card has three card-level LED indicators.

**Table 4-31 OC12 IR/STM4 SH 1310 Card-Level Indicators**

| Card-Level Indicators | Description                                                                                                                                                                                                                                                                      |
|-----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Red FAIL LED          | The red FAIL LED indicates that the card’s processor is not ready. Replace the card if the red FAIL LED persists.                                                                                                                                                                |
| Green ACT LED         | The green ACT LED indicates that the OC12 IR/STM4 SH 1310 card is operational and is carrying traffic or is traffic-ready.                                                                                                                                                       |
| Amber SF LED          | The amber SF LED indicates a signal failure or condition such as LOS, LOF, AIS-L or high BERs on the card’s port. The amber SF LED also illuminates when the transmit and receive fibers are incorrectly connected. When the fibers are properly connected, the light turns off. |

## 4.20.2 OC12 IR/STM4 SH 1310 Port-Level Indicators

You can find the status of the OC-12 card port using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, “Alarm Troubleshooting” for a complete description of the alarm messages.



Warning

**Invisible laser radiation may be emitted from the end of the unterminated fiber cable or connector. Do not stare into the beam or view directly with optical instruments. Viewing the laser output with certain optical instruments (for example, eye loupes, magnifiers, and microscopes) within a distance of 100 mm may pose an eye hazard. Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.**

## 4.20.3 OC12 IR/STM4 SH 1310 Card Specifications

- Line
  - Bit Rate: 622.08 Mbps
  - Code: Scrambled NRZ
  - Fiber: 1310 nm single-mode
  - Loopback Modes: Terminal and Facility
  - Connectors: SC
  - Compliance: Telcordia SONET, GR-GSY-00253, ITU-T G.707, ITU-T G.957
- Transmitter
  - Max. Transmitter Output Power: -8 dBm

- Min. Transmitter Output Power: -15 dBm
- Center Wavelength: 1274 nm – 1356 nm
- Nominal Wavelength: 1310 nm
- Transmitter: Fabry Perot laser
- Receiver
  - Max. Receiver Level: -8 dBm
  - Min. Receiver Level: -28 dBm
  - Receiver: InGa As/InP photo detector
  - Link Loss Budget: 13 dB
- Environmental
  - Operating Temperature:
    - C-Temp (15454-OC121IR1310): 0 to +55 degrees Celsius
    - I-Temp (15454-OC121I13-T): -40 to +65 degrees Celsius

**Note**

The I-Temp symbol is displayed on the faceplate of an I-Temp compliant card. A card without this symbol is C-Temp compliant.



- Operating Humidity: 5 - 95%, non-condensing
- Power Consumption: 10.90 W, 0.23 amps, 37.22 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 1.4 lbs, 0.6 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950
  - Eye Safety Compliance: Class I

## 4.21 OC12 LR/STM4 LH 1310 Card


The OC12 LR/STM4 LH 1310 card provides one long-range, ITU-T G.707, ITU-T G.957, and Telcordia-compliant, GR-253 SONET OC-12 port per card. The port operates at 622.08 Mbps over a single-mode fiber span. The card supports VT and non-concatenated or concatenated payloads at STS-1, STS-3c, STS-6c or STS-12c signal levels. Figure 4-23 shows the OC12 LR/STM4 LH 1310 faceplate and a block diagram of the card.



Note

The OC12 LR 1310 and OC12 LR/STM4 LH 1310 cards are functionally the same.

**Figure 4-23 OC12 LR/STM4 LH 1310 faceplate and block diagram**



You can install the OC12 LR/STM4 LH 1310 card in any multispeed or high-speed card slot and provision the card as a drop card or span card in a two-fiber BLSR (Bidirectional line switched ring), UPSR, or ADM (linear) configuration.

The OC12 LR/STM4 LH 1310 card port features a 1310 nm laser and contains a transmit and receive connector (labeled) on the card faceplate. The card uses SC optical connections supporting 1+1 unidirectional and bidirectional protection.

The OC12 LR/STM4 LH 1310 detects LOS, LOF, LOP, AIS-L, and RDI-L conditions. See Chapter 1, “Alarm Troubleshooting” for a description of these conditions. The card also counts section and line BIT errors.

## 4.21.1 OC12 LR/STM4 LH 1310 Card-Level Indicators

The OC12 LR/STM4 LH 1310 card has three card-level LED indicators.

**Table 4-32 OC12 LR/STM4 LH 1310 Card-Level Indicators**

| Card-Level Indicators | Description                                                                                                                                                                                                                                                                      |
|-----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>   | The red FAIL LED indicates that the card’s processor is not ready. Replace the card if the red FAIL LED persists.                                                                                                                                                                |
| <b>Green ACT LED</b>  | The green ACT LED indicates that the OC12 LR/STM4 LH 1310 card is operational and is carrying traffic or is traffic-ready.                                                                                                                                                       |
| <b>Amber SF LED</b>   | The amber SF LED indicates a signal failure or condition such as LOS, LOF, AIS-L or high BERs on the card’s port. The amber SF LED also illuminates when the transmit and receive fibers are incorrectly connected. When the fibers are properly connected, the light turns off. |

## 4.21.2 OC12 LR/STM4 LH 1310 Port-Level Indicators

You can find the status of the OC12 LR/STM4 LH 1310 card port using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to quickly view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, “Alarm Troubleshooting” for a complete description of the alarm messages.



**Warning**

**Invisible laser radiation may be emitted from the end of the unterminated fiber cable or connector. Do not stare into the beam or view directly with optical instruments. Viewing the laser output with certain optical instruments (for example, eye loupes, magnifiers, and microscopes) within a distance of 100 mm may pose an eye hazard. Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.**

## 4.21.3 OC12 LR/STM4 LH 1310 Card Specifications

- Line
  - Bit Rate: 622.08 Mbps
  - Code: Scrambled NRZ
  - Fiber: 1310 nm single-mode
  - Loopback Modes: Terminal and Facility
  - Connectors: SC
  - Compliance: Telcordia SONET, GR-253-CORE, ITU-T G.707, ITU-T G.957
- Transmitter
  - Max. Transmitter Output Power: +2 dBm

- Min. Transmitter Output Power: -3 dBm
- Center Wavelength: 1280 nm – 1335 nm
- Nominal Wavelength: 1310 nm
- Transmitter: Distributed feedback laser
- Receiver
  - Max. Receiver Level: -8 dBm
  - Min. Receiver Level: -28 dBm
  - Receiver: InGaAs/InP photo detector
  - Link Loss Budget: 25 dB
- Environmental
  - Operating Temperature:
    - C-Temp (15454-OC121LR1310): 0 to +55 degrees Celsius
    - I-Temp (15454-OC121L13-T): -40 to +65 degrees Celsius

**Note**

The I-Temp symbol is displayed on the faceplate of an I-Temp compliant card. A card without this symbol is C-Temp compliant.



- Operating Humidity: 5 - 95%, non-condensing
- Power Consumption: 12 W, 0.25 amps, 41 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 1.4 lbs, 0.6 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950
  - Eye Safety Compliance: Class I

## 4.22 OC12 LR/STM4 LH 1550 Card


The OC12 LR/STM4 LH 1550 card provides one long-range SONET/SDH OC-12 port compliant with the International Telecommunication Union's G.707, G.957, and Telcordia's GR-253. The port operates at 622.08 Mbps over a single-mode fiber span. The card supports VT and non-concatenated, or concatenated payloads at STS-1, STS-3c, STS-6c, or STS-12c signal levels. Figure 4-24 shows the OC12 LR/STM4 LH 1550 faceplate and a block diagram of the card.



Note

The OC12 LR 1550 and OC12 LR/STM4 LH 1550 cards are functionally the same.

**Figure 4-24 OC12 LR/STM4 LH 1550 faceplate and block diagram**



You can install the OC12 LR/STM4 LH 1550 card in any multispeed card slot. The OC12 LR/STM4 LH 1550 can be provisioned as part of a two-fiber BLSR, UPSR or linear ADM.

The OC12 LR/STM4 LH 1550 uses long-reach optics centered at 1550 nm and contains a transmit and receive connector (labeled) on the card faceplate. The OC12 LR/STM4 LH 1550 uses SC optical connections and supports 1+1 bidirectional or unidirectional protection switching.

The OC12 LR/STM4 LH 1550 detects LOS, LOF, LOP, AIS-L, and RDI-L conditions. See Chapter 1, “Alarm Troubleshooting” for a description of these conditions. The card also counts section and line BIT errors.

## 4.22.1 OC12 LR/STM4 LH 1550 Card-Level Indicators

The OC12 LR/STM4 LH 1550 card has three card-level LED indicators.

**Table 4-33 OC12 LR/STM4 LH 1550 Card-Level Indicators**

| Card-Level Indicators | Description                                                                                                                                                                                                                                                                      |
|-----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Red FAIL LED          | The red FAIL LED indicates that the card's processor is not ready. Replace the card if the red FAIL LED persists.                                                                                                                                                                |
| Green ACT LED         | The green ACT LED indicates that the OC12 LR/STM4 LH 1550 card is operational and ready to carry traffic.                                                                                                                                                                        |
| Amber SF LED          | The amber SF LED indicates a signal failure or condition such as LOS, LOF, AIS-L or high BERs on the card's port. The amber SF LED also illuminates when the transmit and receive fibers are incorrectly connected. When the fibers are properly connected, the light turns off. |

## 4.22.2 OC12 LR/STM4 LH 1550 Port-Level Indicators

You can find the status of the OC12 LR/STM4 LH 1550 card port using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, "Alarm Troubleshooting" for a complete description of the alarm messages.



### Warning

**Invisible laser radiation may be emitted from the end of the unterminated fiber cable or connector. Do not stare into the beam or view directly with optical instruments. Viewing the laser output with certain optical instruments (for example, eye loupes, magnifiers, and microscopes) within a distance of 100 mm may pose an eye hazard. Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.**

## 4.22.3 OC12 LR/STM4 LH 1550 Card Specifications

- Line
  - Bit Rate: 622.08 Mbps
  - Code: Scrambled NRZ
  - Fiber: 1550 nm single-mode
  - Loopback Modes: Terminal and Facility
  - Connectors: SC
  - Compliance: Telcordia SONET, GR-253-CORE, ITU-T G.707, ITU-T G.957
- Transmitter
  - Max. Transmitter Output Power: +2 dBm
  - Min. Transmitter Output Power: -3 dBm
  - Center Wavelength: 1480 nm – 1580 nm
  - Nominal Wavelength: 1550 nm

- Transmitter: Distributed feedback laser
- Receiver
  - Max. Receiver Level: -8 dBm
  - Min. Receiver Level: -28 dBm
  - Receiver: InGaAs/InP photo detector
  - Link Loss Budget: 25 dB
- Environmental
  - Operating Temperature:
    - C-Temp (15454-OC121LR1550): 0 to +55 degrees Celsius
    - I-Temp (15454-OC121L15-T): -40 to +65 degrees Celsius

**Note**

The I-Temp symbol is displayed on the faceplate of an I-Temp compliant card. A card without this symbol is C-Temp compliant.




- Operating Humidity: 5 - 95%, non-condensing
- Power Consumption: 9.28 W, 0.19 amps, 31.68 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 1.4 lbs, 0.6 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950
  - Eye Safety Compliance: Class I

## 4.23 OC48 IR 1310 Card

The OC48 IR 1310 card provides one intermediate-range, Telcordia-compliant, GR-253 SONET OC-48 port per card. Each port operates at 2.49 Gbps over a single-mode fiber span. The card supports VT and non-concatenated, or concatenated payloads at STS-1, STS-3c, STS-6c, STS-12c, or STS-48c signal levels. Figure 4-25 shows the OC48 IR 1310 faceplate and a block diagram of the card.

**Figure 4-25 OC48 IR 1310 faceplate and block diagram**



You can install the OC48 IR 1310 card in any high-speed card slot and provision the card as a drop or span card in a two-fiber or four-fiber BLSR, UPSR, or in an ADM (linear) configuration.

The OC-48 port features a 1310 nm laser and contains a transmit and receive connector (labeled) on the card faceplate. The OC48 IR 1310 uses SC connectors. The card supports 1+1 unidirectional and bidirectional protection switching.

The OC48 IR 1310 detects LOS, LOF, LOP, AIS-L, and RDI-L conditions. See Chapter 1, “Alarm Troubleshooting” for a description of these conditions. The card also counts section and line BIT errors.

## 4.23.1 OC48 IR 1310 Card-Level Indicators

The OC48 IR 1310 card has three card-level LED indicators.

**Table 4-34 OC48 IR 1310 Card-Level Indicators**

| Card-Level Indicators | Description                                                                                                                                                                                                                                                                      |
|-----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>   | The red FAIL LED indicates that the card's processor is not ready. Replace the card if the red FAIL LED persists.                                                                                                                                                                |
| <b>Green ACT LED</b>  | The green ACT LED indicates that the OC48 IR 1310 card is carrying traffic or is traffic-ready.                                                                                                                                                                                  |
| <b>Amber SF LED</b>   | The amber SF LED indicates a signal failure or condition such as LOS, LOF, AIS-L or high BERs on the card's port. The amber SF LED also illuminates when the transmit and receive fibers are incorrectly connected. When the fibers are properly connected, the light turns off. |

## 4.23.2 OC48 IR 1310 Port-Level Indicators

You can find the status of the OC48 IR 1310 card port using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, "Alarm Troubleshooting" for a complete description of the alarm messages.



### Warning

**Invisible laser radiation may be emitted from the end of the unterminated fiber cable or connector. Do not stare into the beam or view directly with optical instruments. Viewing the laser output with certain optical instruments (for example, eye loupes, magnifiers, and microscopes) within a distance of 100 mm may pose an eye hazard. Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.**

## 4.23.3 OC48 IR 1310 Card Specifications

- Line
  - Bit Rate: 2.49 Gbps
  - Code: Scrambled NRZ
  - Fiber: 1310 nm single-mode
  - Loopback Modes: Terminal and Facility
  - Connectors: SC
  - Compliance: Telcordia SONET, GR-GSY-00253
- Transmitter
  - Max. Transmitter Output Power: 0 dBm
  - Min. Transmitter Output Power: -5 dBm
  - Center Wavelength: 1280 nm – 1350 nm
  - Nominal Wavelength: 1310 nm


Transmitter: Uncooled direct modulated DFB

- Receiver
  - Max. Receiver Level: 0 dBm
  - Min. Receiver Level: -18 dBm
  - Receiver: InGaAs InP photo detector
  - Link Loss Budget: 13 dB min.
- Environmental
  - Operating Temperature:  
C-Temp (15454-OC481IR1310): 0 to +55 degrees Celsius
  - Operating Humidity: 5 - 95%, non-condensing
  - Power Consumption: 32.20 W, 0.67 amps, 109.94 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 1.8 lbs, 0.8 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950
  - Eye Safety Compliance: Class I

## 4.24 OC48 LR 1550 Card

The OC48 LR 1550 card provides one long-range, Telcordia-compliant, GR-253 SONET OC-48 port per card. Each port operates at 2.49 Gbps over a single-mode fiber span. The card supports VT, non-concatenated or concatenated payloads at STS-1, STS-3c, STS-6c STS-12c or STS-48c signal levels. Figure 4-26 shows the OC48 LR 1550 faceplate and a block diagram of the card.

**Figure 4-26 OC48 LR 1550 faceplate and block diagram**



You can install OC48 LR 1550 cards in any high-speed slot on the ONS 15454 and provision the card as a drop or span card in a two-fiber or four-fiber BLSR, UPSR, or in an ADM (linear) configuration.

The OC48 LR 1550 port features a 1550 nm laser and contains a transmit and receive connector (labeled) on the card faceplate. The card uses SC connectors, and it supports 1+1 unidirectional and bidirectional protection switching.

The OC48 LR 1550 detects LOS, LOF, LOP, AIS-L, and RDI-L conditions. See Chapter 1, “Alarm Troubleshooting” for a description of these conditions. The card also counts section and line BIT errors.

## 4.24.1 OC48 LR 1550 Card-Level Indicators

The OC48 LR 1550 card has three card-level LED indicators.

**Table 4-35 OC48 LR 1550 Card-Level Indicators**

| Card-Level Indicators | Description                                                                                                                                                                                                                                                               |
|-----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Red FAIL LED          | The red FAIL LED indicates that the card's processor is not ready. Replace the card if the red FAIL LED persists.                                                                                                                                                         |
| Green ACT LED         | The green ACT LED indicates that the OC48 LR 1550 card is carrying traffic or is traffic-ready.                                                                                                                                                                           |
| Amber SF LED          | The amber SF LED indicates a signal failure or condition such as LOS, LOF or high BERs on the card's port. The amber SF LED also illuminates when the transmit and receive fibers are incorrectly connected. When the fibers are properly connected, the light turns off. |

## 4.24.2 OC48 LR 1550 Port-Level Indicators

You can find the status of the OC48 LR 1550 card port using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, "Alarm Troubleshooting" for a complete description of the alarm messages.



### Warning

**Invisible laser radiation may be emitted from the end of the unterminated fiber cable or connector. Do not stare into the beam or view directly with optical instruments. Viewing the laser output with certain optical instruments (for example, eye loupes, magnifiers, and microscopes) within a distance of 100 mm may pose an eye hazard. Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.**

## 4.24.3 OC48 LR 1550 Card Specifications


- Line
  - Bit Rate: 2.49 Gbps
  - Code: Scrambled NRZ
  - Fiber: 1550 nm single-mode
  - Loopback Modes: Terminal and Facility
  - Connectors: SC
  - Compliance: Telcordia SONET, GR-GSY-00253
- Transmitter
  - Max. Transmitter Output Power: +3 dBm
  - Min. Transmitter Output Power: -2 dBm
  - Center Wavelength: 1520 nm – 1580 nm
  - Nominal Wavelength: 1550 nm

- Transmitter: Distributed feedback laser
- Receiver
  - Max. Receiver Level: -8 dBm
  - Min. Receiver Level: -28 dBm
  - Receiver: InGaAs APD photo detector
  - Link Loss Budget: 26 dB min., with 1 dB dispersion penalty
- Environmental
  - Operating Temperature:
    - C-Temp (15454-OC481LR1550): 0 to +55 degrees Celsius
  - Operating Humidity: 5 - 95%, non-condensing
  - Power Consumption: 26.80 W, 0.56 amps, 91.50 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 1.8 lbs, 0.8 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950
  - Eye Safety Compliance: Class I

## 4.25 OC48 IR/STM16 SH AS 1310 Card

The OC48 IR/STM16 SH AS 1310 card provides one intermediate-range SONET/SDH OC-48 port compliant with the International Telecommunication Union's G.707, G.957, and Telcordia's GR-253. The port operates at 2.49 Gbps over a single-mode fiber span. The card supports VT and non-concatenated or concatenated payloads at STS-1, STS-3c, STS-6c, STS-12c, or STS-48c signal levels. Figure 4-27 shows the OC48 IR/STM16 SH AS 1310 faceplate and a block diagram of the card.

**Figure 4-27 OC48 IR/STM16 SH AS 1310 faceplate and block diagram**



You can install the OC48 IR/STM16 SH AS 1310 card in any multispeed or high-speed card slot on the ONS 15454 and provision the card as a drop or span card in a two-fiber or four-fiber BLSR, UPSR, or in an ADM (linear) configuration.

The OC-48 port features a 1310 nm laser and contains a transmit and receive connector (labeled) on the card faceplate. The OC48 IR/STM16 SH AS 1310 uses SC connectors. The card supports 1+1 unidirectional and bidirectional protection switching.

The OC48 IR/STM16 SH AS 1310 detects LOS, LOF, LOP, AIS-L, and RDI-L conditions. See Chapter 1, "Alarm Troubleshooting" for a description of these conditions. The card also counts section and line BIT errors.

## 4.25.1 OC48 IR/STM16 SH AS 1310 Card-Level Indicators

The OC48 IR/STM16 SH AS 1310 card has three card-level LED indicators.

**Table 4-36 OC48 IR/STM16 SH AS 1310 Card-Level Indicators**

| Card-Level Indicators | Description                                                                                                                                                                                                                                                                      |
|-----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>   | The red FAIL LED indicates that the card's processor is not ready. Replace the card if the red FAIL LED persists.                                                                                                                                                                |
| <b>Green ACT LED</b>  | The green ACT LED indicates that the OC48 IR/STM16 SH AS 1310 card is carrying traffic or is traffic-ready.                                                                                                                                                                      |
| <b>Amber SF LED</b>   | The amber SF LED indicates a signal failure or condition such as LOS, LOF, AIS-L or high BERs on the card's port. The amber SF LED also illuminates when the transmit and receive fibers are incorrectly connected. When the fibers are properly connected, the light turns off. |

## 4.25.2 OC48 IR/STM16 SH AS 1310 Port-Level Indicators

You can find the status of the OC48 IR/STM16 SH AS 1310 card port using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, "Alarm Troubleshooting" for a complete description of the alarm messages.



**Warning**

**Invisible laser radiation may be emitted from the end of the unterminated fiber cable or connector. Do not stare into the beam or view directly with optical instruments. Viewing the laser output with certain optical instruments (for example, eye loupes, magnifiers, and microscopes) within a distance of 100 mm may pose an eye hazard. Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.**

## 4.25.3 OC48 IR/STM16 SH AS 1310 Compatibility

Use the XC10G card, the TCC+ card, the new 15454-SA-ANSI shelf assembly, and Software R3.1 or higher to enable the OC48 IR/STM16 SH AS 1310 card. The OC48 IR/STM16 SH AS 1310 card uses the BTC backplane interface to provide recognition in both the high-speed and multispeed slots.

## 4.25.4 OC48 IR/STM16 SH AS 1310 Card Specifications


- Line
  - Bit Rate: 2.49 Gbps
  - Code: Scrambled NRZ
  - Fiber: 1310 nm Single Mode
  - Loopback Modes: Terminal and Facility
  - Connectors: SC
  - Compliance: Telcordia SONET, GR-GSY-00253, ITU-T G.707, ITU-T G.957

- Transmitter
  - Max. Transmitter Output Power: 0 dBm
  - Min. Transmitter Output Power: -5 dBm
  - Center Wavelength: 1280 nm – 1350 nm
  - Nominal Wavelength: 1310nm
  - Transmitter: Distributed feedback laser
- Receiver
  - Max. Receiver Level: 0 dBm
  - Min. Receiver Level: -18 dBm
  - Receiver: InGaAs InP photo detector
  - Link Loss Budget: 13 dB min.
- Environmental
  - Operating Temperature:
    - C-Temp (15454-OC481IR1310A): 0 to +55 degrees Celsius
  - Operating Humidity: 5 - 95%, non-condensing
  - Power Consumption: 37.20 W, 0.77 amps, 127.01 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 2.2 lbs, 0.9 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950
  - Eye Safety Compliance: Class I

## 4.26 OC48 LR/STM16 LH AS 1550 Card

The OC48 LR/STM16 LH AS 1550 card provides one long-range SONET/SDH OC-48 port compliant with the International Telecommunication Union's G.707, G.957, and Telcordia's GR-253. Each port operates at 2.49 Gbps over a single-mode fiber span. The card supports VT and non-concatenated or concatenated payloads at STS-1, STS-3c, STS-6c, STS-12c, or STS-48c signal levels. Figure 4-28 shows the OC48 LR/STM16 LH AS 1550 faceplate and a block diagram of the card.

**Figure 4-28** OC48 LR/STM16 LH AS 1550 faceplate and block diagram



You can install OC48 LR/STM16 LH AS 1550 cards in any multispeed or high-speed slot on the ONS 15454 and provision the card as a drop or span card in a two-fiber or four-fiber BLSR, UPSR, or in an ADM (linear) configuration.

The OC48 LR/STM16 LH AS 1550 port features a 1550 nm laser and contains a transmit and receive connector (labeled) on the card faceplate. The card uses SC connectors, and it supports 1+1 unidirectional and bidirectional protection switching.

The OC48 LR/STM16 LH AS 1550 detects LOS, LOF, LOP, AIS-L, and RDI-L conditions. See Chapter 1, "Alarm Troubleshooting" for a description of these conditions. The card also counts section and line BIT errors.

## 4.26.1 OC48 LR/STM16 LH AS 1550 Card-Level Indicators

The OC48 LR/STM16 LH AS 1550 card has three card-level LED indicators.

**Table 4-37 OC48 LR/STM16 LH AS 1550 Card-Level Indicators**

| Card-Level Indicators | Description                                                                                                                                                                                                                                                               |
|-----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Red FAIL LED          | The red FAIL LED indicates that the card's processor is not ready. Replace the card if the red FAIL LED persists.                                                                                                                                                         |
| Green ACT LED         | The green ACT LED indicates that the OC48 LR/STM16 LH AS 1550 card is carrying traffic or is traffic-ready.                                                                                                                                                               |
| Amber SF LED          | The amber SF LED indicates a signal failure or condition such as LOS, LOF or high BERs on the card's port. The amber SF LED also illuminates when the transmit and receive fibers are incorrectly connected. When the fibers are properly connected, the light turns off. |

## 4.26.2 OC48 LR/STM16 LH AS 1550 Port-Level Indicators

You can find the status of the OC48 LR/STM16 LH AS 1550 card port using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, "Alarm Troubleshooting" for a complete description of the alarm messages.



**Warning**

**Invisible laser radiation may be emitted from the end of the unterminated fiber cable or connector. Do not stare into the beam or view directly with optical instruments. Viewing the laser output with certain optical instruments (for example, eye loupes, magnifiers, and microscopes) within a distance of 100 mm may pose an eye hazard. Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.**

## 4.26.3 OC48 LR/STM16 LH AS 1550 Compatibility

Use the XC10G card, the TCC+ card, the new 15454-SA-ANSI shelf assembly, and Software R3.1 or higher to enable the OC48 LR/STM16 LH AS 1550 card. The OC48 LR/STM16 LH AS 1550 card uses the BTC backplane interface to provide recognition in both the high-speed and multispeed slots.

## 4.26.4 OC48 LR/STM16 LH AS 1550 Card Specifications

- Line
  - Bit Rate: 2.49 Gbps
  - Code: Scrambled NRZ
  - Fiber: 1550 nm Single Mode
  - Loopback Modes: Terminal and Facility
  - Connectors: SC
  - Compliance: Telcordia SONET, GR-GSY-00253, ITU-T G.707, ITU-T G.957


- Transmitter
  - Max. Transmitter Output Power: +3 dBm
  - Min. Transmitter Output Power: -2 dBm
  - Center Wavelength: 1520 nm – 1580 nm
  - Nominal Wavelength: 1550 nm
  - Transmitter: Distributed feedback laser
- Receiver
  - Max. Receiver Level: -8 dBm
  - Min. Receiver Level: -28 dBm
  - Receiver: InGaAs APD photo detector
  - Link Loss Budget: 26 dB min., with 1 dB dispersion penalty
- Environmental
  - Operating Temperature:  
C-Temp (15454-OC481LR1550A): 0 to +55 degrees Celsius
  - Operating Humidity: 5 - 95%, non-condensing
  - Power Consumption: 37.20 W, 0.77 amps, 127.01 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 2.2 lbs, 0.9 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950
  - Eye Safety Compliance: Class I

## 4.27 OC48 ELR/STM16 EH 100 GHz Cards

Thirty-seven distinct OC48 ITU 100GHz dense wavelength division multiplexing (DWDM) cards provide the ONS 15454 DWDM channel plan. Each OC-48 DWDM card has one SONET OC-48/SDH STM-16 port that complies with Telcordia, GR-253 SONET, and the International Telecommunication Union's ITU-T G.692, and ITU-T G.958.

The port operates at 2.49 Gbps over a single-mode fiber span. The card carries VT, concatenated, and non-concatenated payloads at STS-1, STS-3c, STS-6c, STS-12c, or STS-48c signal levels. Figure 4-29 shows the OC48 ELR/STM16 EH 100 GHz faceplate and a block diagram of the card.

**Figure 4-29 OC48 ELR/STM16 EH 100 GHz faceplate and block diagram**



Nineteen of the cards operate in the blue band with spacing of 100 GHz on the ITU grid standard G.692 and Telcordia GR-2918-CORE, issue 2 (1528.77 nm, 1530.33 nm, 1531.12 nm, 1531.90 nm, 1532.68 nm, 1533.47 nm, 1534.25 nm, 1535.04 nm, 1535.82 nm, 1536.61 nm, 1538.19 nm, 1538.98 nm, 1539.77 nm, 1540.56 nm, 1541.35 nm, 1542.14 nm, 1542.94 nm, 1543.73 nm, 1544.53 nm).

The other eighteen cards operate in the red band with spacing of 100 GHz on the ITU grid (1546.12 nm, 1546.92 nm, 1547.72 nm, 1548.51 nm, 1549.32 nm, 1550.12 nm, 1550.92 nm, 1551.72 nm, 1552.52 nm, 1554.13 nm, 1554.94 nm, 1555.75 nm, 1556.55 nm, 1557.36 nm, 1558.17 nm, 1558.98 nm, 1559.79 nm, 1560.61 nm). These cards are also designed to interoperate with the Cisco ONS 15216 DWDM solution.

You can install the OC48 ELR/STM16 EH 100 GHz cards in any high-speed slot and provision the card as a drop or span card in a two-fiber or four-fiber BLSR, UPSR, or in an ADM (linear) configuration. Each OC48 ELR/STM16 EH 100 GHz card uses extended long reach optics operating individually within the ITU-T 100 GHz grid. The OC-48 DWDM cards are intended to be used in applications with long unregenerated spans of up to 200 km (with mid-span amplification). These transmission distances are achieved through the use of inexpensive optical amplifiers (flat gain amplifiers) such as Cisco ONS 15216 erbium-doped fiber amplifiers (EDFAs).

Maximum system reach in filterless applications is 26 dB without the use of optical amplifiers or regenerators. However, system reach also depends on the condition of the facilities, number of splices and connectors, and other performance-affecting factors. When used in combination with ONS 15216 100 GHz filters, the link budget is reduced by the insertion loss of the filters plus an additional 2dB power penalty. The OC-48 ELR DWDM cards wavelength stability is +/- 0.12 nm for the life of the product and over the full range of operating temperatures. Each interface contains a transmitter and receiver.

The OC-48 ELR cards detect loss of signal (LOS), loss of frame (LOF), loss of pointer (LOP), and line-layer alarm indication signal (AIS-L) conditions. See Chapter 1, “Alarm Troubleshooting” for a description of these conditions. The cards also count section and line BIT errors.

## 4.27.1 OC48 ELR 100 GHz Card-Level Indicators

The OC48 ELR/STM16 EH 100 GHz cards have three card-level LED indicators.

**Table 4-38 OC48 ELR/STM16 EH 100 GHz Card-Level Indicators**

| Card-Level Indicators | Description                                                                                                                                                                                                                                                               |
|-----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>   | The red FAIL LED indicates that the card’s processor is not ready. Replace the card if the red FAIL LED persists.                                                                                                                                                         |
| <b>Green ACT LED</b>  | The green ACT LED indicates that the OC48 ELR card is carrying traffic or is traffic-ready.                                                                                                                                                                               |
| <b>Amber SF LED</b>   | The amber SF LED indicates a signal failure or condition such as LOS, LOF or high BERs on the card’s port. The amber SF LED also illuminates when the transmit and receive fibers are incorrectly connected. When the fibers are properly connected, the light turns off. |

## 4.27.2 OC48 ELR 100 GHz Port-Level Indicators

You can find the status of the OC48 ELR card ports using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to quickly view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, “Alarm Troubleshooting” for a complete description of the alarm messages.



Warning

**Invisible laser radiation may be emitted from the end of the unterminated fiber cable or connector. Do not stare into the beam or view directly with optical instruments. Viewing the laser output with certain optical instruments (for example, eye loupes, magnifiers, and microscopes) within a distance of 100 mm may pose an eye hazard. Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.**

## 4.27.3 OC48 ELR 100 GHz Compatibility

The OC48 ELR/STM16 EH 100 GHz card requires a cross-connect (XC) card, cross-connect virtual tributary (XCVT) card, or an XC10G for proper operation.


## 4.27.4 OC48 ELR 100 GHz Card Specifications

- Line
  - Bit Rate: 2.49 Gbps
  - Code: Scrambled NRZ
  - Fiber: 1550 nm single-mode
  - Loopback Modes: Terminal and Facility
  - Connectors: SC
  - Compliance: Telcordia SONET, GR-GSY-00253, ITU-T G.692, ITU-T G.958
- Transmitter
  - Max. Transmitter Output Power: 0 dBm
  - Min. Transmitter Output Power: -2 dBm
  - Center Wavelength:  $\pm 12$  nm
  - Transmitter: Electro-absorption laser
- Receiver
  - Max. Receiver Level: -9 dBm
  - Min. Receiver Level: -27 dBm at 1E-12 BER
  - Receiver: InGaAs APD photo detector
  - Link Loss Budget: 25 dB min. at BER=10E-12, (not including the power dispersion penalty)
  - Dispersion Penalty: 2dB for a dispersion of up to 5400 ps/nm
- Environmental
  - Operating Temperature:
    - C-Temp: 0 to +55 degrees Celsius (For product names, see Card Temperature Ranges, page 4-6)
  - Operating Humidity: 5 - 95%, non-condensing
  - Power Consumption: 31.20 W, 0.65 amps, 106.53 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 2.4 lbs, 1.1 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950
  - Eye Safety Compliance: Class I

## 4.28 OC48 ELR 200 GHz Cards

Eighteen distinct OC48 ITU 200GHz dense wavelength division multiplexing (DWDM) cards provide the ONS 15454 DWDM channel plan. Each OC-48 DWDM card provides one Telcordia-compliant, GR-253 SONET OC-48 port. The port operates at 2.49 Gbps over a single-mode fiber span. The card carries VT, concatenated, and non-concatenated payloads at STS-1, STS-3c, STS-6c, STS-12c, or STS-48c signal levels. Figure 4-29 shows the OC48 ELR DWDM faceplate and a block diagram of the card.

Figure 4-30 OC48 ELR 200 GHz faceplate and block diagram



Nine of the cards operate in the blue band with spacing of 200 GHz on the ITU grid (1530.33 nm, 1531.90 nm, 1533.47 nm, 1535.04 nm, 1536.61 nm, 1538.19 nm, 1539.77 nm, 1541.35 nm, 1542.94 nm).

The other nine cards operate in the red band with spacing of 200 GHz on the ITU grid (1547.72 nm, 1549.32 nm, 1550.92 nm, 1552.52 nm, 1554.13 nm, 1555.75 nm, 1557.36 nm, 1558.98 nm, 1560.61 nm). These cards are also designed to interoperate with the Cisco ONS 15216 DWDM solution.

You can install the OC48 ELR 200 GHz cards in any high-speed slot and provision the card as a drop or span card in a two-fiber or four-fiber BLSR, UPSR, or in an ADM (linear) configuration. Each OC48 ELR DWDM card uses extended long reach optics operating individually within the ITU-T 200 GHz grid. The OC48 DWDM cards are intended to be used in applications with long unregenerated spans of up to 200 km (with mid-span amplification). These transmission distances are achieved through the use

of inexpensive optical amplifiers (flat gain amplifiers) such as erbium doped fiber amplifiers (EDFAs). Using co-located amplification, distances up to 200 km can be achieved for a single channel (160 km for 8 channels).

Maximum system reach in filterless applications is 24 dB or approximately 80 km without the use of optical amplifiers or regenerators. However, system reach also depends on the condition of the facilities, number of splices and connectors or other performance-affecting factors. The OC48 ELR DWDM cards feature wavelength stability of +/- 0.25 nm. Each interface contains a transmitter and receiver.

The OC48 ELR DWDM cards are the first in a family of cards meant to support extended long reach applications in conjunction with optical amplification. Using electro-absorption technology, the OC48 DWDM cards provide a solution at the lower-extended long reach distances.

The OC48 LR 1550 interface features a 1550 nm laser and contains a transmit and receive connector (labeled) on the card faceplate. The card uses SC connectors and supports 1+1 unidirectional and bidirectional protection switching.

The OC48 ELR cards detect LOS, LOF, LOP, AIS-L, and RDI-L conditions. See Chapter 1, “Alarm Troubleshooting” for a description of these conditions. The cards also count section and line BIT errors.

To enable APS, the OC48 ELR cards extract the K1 and K2 bytes from the SONET overhead. The DCC bytes are forwarded to the TCC+ card; the TCC+ terminates the DCC.

## 4.28.1 OC48 ELR 200 GHz Card-Level Indicators

The OC48 ELR cards have three card-level LED indicators.

**Table 4-39 OC48 ELR 200 GHz Card-Level Indicators**

| Card-Level Indicators | Description                                                                                                                                                                                                                                                               |
|-----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>   | The red FAIL LED indicates that the card's processor is not ready. Replace the card if the red FAIL LED persists.                                                                                                                                                         |
| <b>Green ACT LED</b>  | The green ACT LED indicates that the OC48 ELR card is carrying traffic or is traffic-ready.                                                                                                                                                                               |
| <b>Amber SF LED</b>   | The amber SF LED indicates a signal failure or condition such as LOS, LOF or high BERs on the card's port. The amber SF LED also illuminates when the transmit and receive fibers are incorrectly connected. When the fibers are properly connected, the light turns off. |

## 4.28.2 OC48 ELR 200 GHz Port-Level Indicators

You can find the status of the OC48 ELR card ports using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to quickly view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, “Alarm Troubleshooting” for a complete description of the alarm messages.



**Warning**

**Invisible laser radiation may be emitted from the end of the unterminated fiber cable or connector. Do not stare into the beam or view directly with optical instruments. Viewing the laser output with certain optical instruments (for example, eye loupes, magnifiers, and microscopes) within a distance of 100 mm may pose an eye hazard. Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.**

## 4.28.3 OC48 ELR 200 GHz Compatibility

The OC48 ELR/STM16 EH 200 GHz card requires an XC card, XCVT card, or XC10G card for proper operation.

## 4.28.4 OC48 ELR 200 GHz Card Specifications

- Line
  - Bit Rate: 2.49 Gbps
  - Code: Scrambled NRZ
  - Fiber: 1550 nm single-mode
  - Loopback Modes: Terminal and Facility
  - Connectors: SC
  - Compliance: Telcordia SONET, GR-GSY-00253, ITU-T G692, ITU-T G958
- Transmitter
  - Max. Transmitter Output Power: 0 dBm
  - Min. Transmitter Output Power: -2 dBm
  - Center Wavelength:  $\pm 0.25$  nm
  - Transmitter: Electro-absorption laser
- Receiver
  - Max. Receiver Level: -8 dBm
  - Min. Receiver Level: -28 dBm
  - Receiver: InGaAs APD photo detector
  - Link Loss Budget: 26 dB min., with 1 dB dispersion penalty
- Environmental
  - Operating Temperature:
    - C-Temp: 0 to +55 degrees Celsius
  - Operating Humidity: 5 - 95%, non-condensing
  - Power Consumption: 31.20 W, 0.65 amps, 106.53 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 2.9 lbs, 1.3 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950
  - Eye Safety Compliance: Class I

## 4.29 OC192 LR/STM64 LH 1550 Card

The OC192 LR/STM64 LH 1550 card provides one long-range SONET/SDH OC-192 port compliant with the International Telecommunication Union’s G.707, G.957, and Telcordia’s GR-1377 and GR-253. The card port operates at 9.96 Gbps over unamplified distances up to 80 km with different types of fiber such as C-SMF or dispersion compensated fiber limited by loss and/or dispersion. The card supports VT and non-concatenated or concatenated payloads.

Figure 4-31 shows the OC192 LR/STM64 LH 1550 faceplate and a block diagram of the card. Figure 4-32 on page 4-90 shows an enlarged view of the faceplate warning.

**Figure 4-31 OC192 LR/STM64 LH 1550 faceplate and block diagram**





Figure 4-32 Enlarged section of the OC192 LR/STM64 LH 1550 faceplate

**Caution**

You must use a 19 to 24 dB (20 recommended) fiber attenuator when connecting a fiber loopback to an OC192 LR/STM64 LH 1550 card. Never connect a direct fiber loopback. Using fiber loopbacks causes irreparable damage to the OC-192 card. A Tx to Rx connection that is not attenuated will damage the receiver.

You can install OC192 LR/STM64 LH 1550 cards in any high-speed slot on the ONS 15454 and provision the card as a drop or span card in a two-fiber or four-fiber BLSR, UPSR, or in an ADM (linear) configuration.

The OC-192 card port features a 1550 nm laser and contains a transmit and receive connector (labeled) on the card faceplate.

**Warning**

**On the OC-192 card, the laser is on when the card is booted and the safety key is in the on position (labeled 1). The port does not have to be in service for the laser to be on. The laser is off when the safety key is off (labeled 0).**

The card uses a dual SC connector for optical cable termination. The card supports 1+1 unidirectional and bidirectional facility protection. It also supports 1:1 protection in four-fiber bidirectional line switched ring applications where both span switching and ring switching may occur.

The OC192 LR/STM64 LH 1550 card detects SF, LOS, or LOF conditions on the optical facility. See Chapter 1, “Alarm Troubleshooting” for a description of these conditions. The card also counts section and line BIT errors from B1 and B2 byte registers in the section and line overhead.

## 4.29.1 OC192 LR/STM64 LH 1550 Card-Level Indicators

The OC192 LR/STM64 LH 1550 card has three card-level LED indicators.

**Table 4-40 OC192 LR/STM64 LH 1550 Card-Level Indicators**

| Card-Level Indicators                                      | Description                                                                                                                                                                                                                                                               |
|------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>                                        | The red FAIL LED indicates that the card's processor is not ready. Replace the card if the red FAIL LED persists.                                                                                                                                                         |
| <b>ACT/STBY LED<br/>Green (Active)<br/>Amber (Standby)</b> | When the ACTV/STBY LED is green, the OC-192 card is operational and ready to carry traffic. When the ACTV/STBY LED is amber, the OC-192 card is operational and in standby (protect) mode.                                                                                |
| <b>Amber SF LED</b>                                        | The amber SF LED indicates a signal failure or condition such as LOS, LOF or high BERs on the card's port. The amber SF LED also illuminates when the transmit and receive fibers are incorrectly connected. When the fibers are properly connected, the light turns off. |

## 4.29.2 OC192 LR/STM64 LH 1550 Port-Level Indicators

You can find the status of the OC192 LR/STM64 LH 1550 card port using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to view the status of the port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, "Alarm Troubleshooting" for a complete description of the alarm messages.



**Warning**

**Invisible laser radiation may be emitted from the end of the unterminated fiber cable or connector. Do not stare into the beam or view directly with optical instruments. Viewing the laser output with certain optical instruments (for example, eye loupes, magnifiers, and microscopes) within a distance of 100 mm may pose an eye hazard. Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.**

## 4.29.3 OC192 LR/STM64 LH 1550 Compatibility

Use the XC10G card, the TCC+ card, the new 15454-SA-ANSI shelf assembly, and Software R3.1 or higher to enable the OC192 LR/STM64 LH 1550 card.

## 4.29.4 OC192 LR/STM64 LH 1550 Card Specifications

- Line
  - Bit Rate: 9.96 Gbps
  - Code: Scrambled NRZ
  - Fiber: 1550 nm Single Mode
- Loopback Modes: Terminal and Facility




**Note** You must use a 19 to 24 dB (20 recommended) fiber attenuator when connecting a fiber loopback to an OC192 LR/STM64 LH 1550 card. Never connect a direct fiber loopback.

- Connectors: SC
- Compliance: Telcordia SONET, GR-GSY-00253, ITU-T G.707, ITU-T G.957
- Transmitter
  - Max. Transmitter Output Power: +10 dBm
  - Min. Transmitter Output Power: +7 dBm
  - Center Wavelength: 1530 nm – 1565 nm
  - Nominal Wavelength: 1550 nm
  - Transmitter: LN (Lithium Niobate) external modulator transmitter
- Receiver
  - Max. Receiver Level: -10 dBm
  - Min. Receiver Level: -19 dBm
  - Receiver: APD/TIA
  - Link Loss Budget: 24 dB min., with no dispersion or 22 dB optical path loss at BER = 1- exp (-12) including dispersion
- Environmental
  - Operating Temperature:
    - C-Temp (15454-OC192LR1550): 0 to +55 degrees Celsius
  - Operating Humidity: 5 - 95%, non-condensing
  - Power Consumption: 72.20 W, 1.50 amps, 246.52 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 3.1 lbs, 1.3 kg
- Compliance
  - ONS 15454 OC192/STM64 cards, when installed in a system, comply with these standards:
    - Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950
  - Eye Safety Compliance: Class I (21 CFR 1040.10 and 1040.11) and Class 1M (IEC 60825-12001-01) laser products

## 4.30 E100T-G Card

Use the E100T-G when the XC10G cross-connect card is in use. The ONS 15454 uses E100T-G cards for Ethernet (10 Mbps) and Fast Ethernet (100 Mbps). Each card provides 12 switched, IEEE 802.3-compliant, 10/100 Base-T Ethernet ports that can independently detect the speed of an attached device (auto-sense) and automatically connect at the appropriate speed. The ports auto-configure to operate at either half or full duplex and determine whether to enable or disable flow control. You can also configure Ethernet ports manually. Figure 4-33 shows the faceplate and a block diagram of the card.

**Figure 4-33 E100T-G faceplate and block diagram**



The E100T-G Ethernet card provides high-throughput, low-latency packet switching of Ethernet traffic across a SONET network while providing a greater degree of reliability through SONET “self-healing” protection services. This Ethernet capability enables network operators to provide multiple 10/100 Mbps access drops for high-capacity customer LAN interconnects, Internet traffic, and cable modem traffic aggregation. It enables the efficient transport and co-existence of traditional TDM traffic with packet-switched data traffic.

Each E100T-G card supports standards-based, wire-speed, layer 2 Ethernet switching between its Ethernet interfaces. The 802.1Q tag logically isolates traffic (typically subscribers). 802.1Q also supports multiple classes of service.

You can install the E100T-G card in any multispeed slot. Multiple Ethernet cards installed in an ONS 15454 can act independently or as a single Ethernet switch. You can create logical SONET ports by provisioning a number of STS channels to the packet switch entity within the ONS 15454. Logical ports can be created with a bandwidth granularity of STS-1. The ONS 15454 supports STS-1, STS-3c, STS-6c, or STS-12c circuit sizes.



**Note** When making an STS-12c Ethernet circuit, the E100 or E1000 cards must be configured as single-card EtherSwitch.

### 4.30.1 E100T-G Card-Level Indicators

The E100T-G card faceplate has two card-level LED indicators.

**Table 4-41 E100T-G Card-Level Indicators**

| Card-Level Indicators | Description                                                                                                                                                                                                                             |
|-----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>   | The red FAIL LED indicates that the card's processor is not ready or catastrophic software failure occurred on the E100T-G card. As part of the boot sequence, the FAIL LED is turned on until the software deems the card operational. |
| <b>Green ACT LED</b>  | A green ACT LED provides the operational status of the E100T-G. When the ACT LED is green it indicates that the E100T-G card is active and the software is operational.                                                                 |
| <b>SF LED</b>         | Not used                                                                                                                                                                                                                                |

### 4.30.2 E100T-G Port-Level Indicators

The E100T-G card also has 12 pairs of LEDs (one pair for each port) to indicate port conditions. You can find the status of the E100T-G card port using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, "Alarm Troubleshooting" for a complete description of the alarm messages.

**Table 4-42 E100T-G Port-Level Indicators**

| LED State              | Description                                   |
|------------------------|-----------------------------------------------|
| <b>Amber</b>           | Transmitting and Receiving                    |
| <b>Solid Green</b>     | Idle and Link Integrity                       |
| <b>Green Light Off</b> | Inactive Connection or Unidirectional Traffic |

### 4.30.3 E100T-G Compatibility

Use the E100T-G when the XC10G cross-connect card is in use.

### 4.30.4 E100T-G Card Specifications

- Environmental
  - Operating Temperature:  
C-Temp (15454-E100T-G): 0 to +55 degrees Celsius
  - Operating Humidity: 5 - 95%, non-condensing
  - Power Consumption: 65 W, 1.35 amps, 221.93 BTU/Hr.
- Dimensions
  - Height: 12.650 in, Width: 0.716 in., Depth: 9.000 in.
  - Card Weight: 2.3 lbs, 1.0 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950


## 4.31 E1000-2-G Card

Use the E1000-2-G when the XC10G cross-connect card is in use. The ONS 15454 uses E1000-2-G cards for Gigabit Ethernet (1000 Mbps). The E1000-2-G card provides two IEEE-compliant, 1000 Mbps ports for high-capacity customer LAN interconnections. Each port supports full-duplex operation. Figure 4-34 shows the card faceplate and a block diagram of the card.

The E1000-2-G card uses standard Cisco gigabit interface converter (GBIC) modular receptacles for the optical ports. GBICs are hot-swappable input/output devices that plug into a Gigabit Ethernet port to link the port to the fiber-optic network. Cisco provides two GBIC models: one for short-reach applications and one for long-reach applications. The short-reach model connects to multimode fiber and the long-reach model requires single-mode fiber.

For Software R2.2.0 and later, both GBIC modules are offered as separate orderable products: an IEEE 1000Base-SX compliant, 850 nm optical module and an IEEE 1000Base-LX-compliant, 1300 nm optical module, the 850 nm SX optics are designed for multimode fiber and distances of up to 220 meters on 62.5 micron fiber and up to 550 meters on 50 micron fiber. For more information see the *Cisco ONS 15454 Installation and Operations Guide*.

**Figure 4-34 E1000-2-G faceplate and block diagram**



The E1000-2-G Gigabit Ethernet card provides high-throughput, low-latency packet switching of Ethernet traffic across a SONET network while providing a greater degree of reliability through SONET “self-healing” protection services. This enables network operators to provide multiple 1000 Mbps access drops for high-capacity customer LAN interconnects. It enables efficient transport and co-existence of traditional TDM traffic with packet-switched data traffic.

Each E1000-2-G card supports standards-based, layer 2 Ethernet switching between its Ethernet interfaces and SONET interfaces on the ONS 15454. The 802.1Q VLAN tag logically isolates traffic (typically subscribers). The E1000-2-G supports two 802.1Q.

You can install the E1000-2-G card into any multispeed slot. Multiple Ethernet cards installed in an ONS 15454 can act together as a single switching entity or as an independent single switch supporting a variety of SONET port configurations.

You can create logical SONET ports by provisioning STS channels to the packet switch entity within the ONS 15454. Logical ports can be created with a bandwidth granularity of STS-1. The ONS 15454 supports STS-1, STS-3c, STS-6c, or STS-12c circuit sizes.



Note

When making an STS-12c Ethernet circuit, the E100 or E1000 cards must be configured as single-card EtherSwitch.

### 4.31.1 E1000-2-G Card-Level Indicators

The E1000-2-G card faceplate has two card-level LED indicators.

**Table 4-43 E1000-2-G Card-Level Indicators**

| Card-Level Indicators | Description                                                                                                                                                                                                                               |
|-----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>   | The red FAIL LED indicates that the card’s processor is not ready or catastrophic software failure occurred on the E1000-2-G card. As part of the boot sequence, the FAIL LED is turned on until the software deems the card operational. |
| <b>Green ACT LED</b>  | A green ACT LED provides the operational status of the E1000-2-G. When the ACT LED is green it indicates that the E1000-2-G card is active and the software is operational.                                                               |
| <b>SF LED</b>         | Not used                                                                                                                                                                                                                                  |

### 4.31.2 E1000-2-G Port-Level Indicators

The E1000-2-G card also has one bicolor LED per port. When the green LINK LED is on, carrier is detected, meaning an active network cable is installed. When the green LINK LED is off, an active network cable is not plugged into the port, or the card is carrying unidirectional traffic. The amber port ACT LED flashes at a rate proportional to the level of traffic being received and transmitted over the port.

**Table 4-44 E1000-2-G Port-Level Indicators**

| LED State       | Description                                   |
|-----------------|-----------------------------------------------|
| Amber           | Transmitting and Receiving                    |
| Solid Green     | Idle and Link Integrity                       |
| Green Light Off | Inactive Connection or Unidirectional Traffic |

### 4.31.3 E1000-2-G Compatibility

Use the E1000-2-G when the XC10G cross-connect card is in use.


### 4.31.4 E1000-2-G Card Specifications

- Environmental
  - Operating Temperature:
    - C-Temp (15454-E1000-2-G): 0 to +55 degrees Celsius
  - Operating Humidity: 5- 95%, non-condensing
  - Power Consumption: 53.50 W, 1.11 amps, 182.67 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 2.1 lbs, 0.9 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950
  - Eye Safety Compliance: Class I (21 CFR 1040.10 and 1040.11) and Class 1M (IEC 60825-1 2001-01) laser products

## 4.32 E100T-12 Card

Do not use the E100T-12 when the XC10G cross-connect card is in use. The ONS 15454 uses E100T-12 cards for Ethernet (10 Mbps) and Fast Ethernet (100 Mbps). Each card provides 12 switched, IEEE 802.3-compliant, 10/100 Base-T Ethernet ports that can independently detect the speed of an attached device (auto-sense) and automatically connect at the appropriate speed. The ports auto-configure to operate at either half or full duplex and determine whether to enable or disable flow control. You can also configure Ethernet ports manually. Figure 4-35 shows the faceplate and a block diagram of the card.

**Figure 4-35 E100T-12 faceplate and block diagram**



The E100T-12 Ethernet card provides high-throughput, low-latency packet switching of Ethernet traffic across a SONET network while providing a greater degree of reliability through SONET “self-healing” protection services. This Ethernet capability enables network operators to provide multiple 10/100 Mbps access drops for high-capacity customer LAN interconnects, Internet traffic, and cable modem traffic aggregation. It enables the efficient transport and co-existence of traditional TDM traffic with packet-switched data traffic.

Each E100T-12 card supports standards-based, wire-speed, layer 2 Ethernet switching between its Ethernet interfaces. The 802.1Q tag logically isolates traffic (typically subscribers). 802.1Q also supports multiple classes of service.

You can install the E100T-12 card in any multispeed slot. Multiple Ethernet cards installed in an ONS 15454 can act independently or as a single Ethernet switch. You can create logical SONET ports by provisioning a number of STS channels to the packet switch entity within the ONS 15454. Logical ports can be created with a bandwidth granularity of STS-1. The ONS 15454 supports STS-1, STS-3c, STS-6c, or STS-12c circuit sizes.



**Note** When making an STS-12c Ethernet circuit, the E100 or E1000 cards must be configured as single-card EtherSwitch.

## 4.32.1 E100T-12 Card-Level Indicators

The E100T-12 card faceplate has two card-level LED indicators.

**Table 4-45 E100T-12 Card-Level Indicators**

| Card-Level Indicators | Description                                                                                                                                                                                                                              |
|-----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>   | The red FAIL LED indicates that the card's processor is not ready or catastrophic software failure occurred on the E100T-12 card. As part of the boot sequence, the FAIL LED is turned on until the software deems the card operational. |
| <b>Green ACT LED</b>  | A green ACT LED provides the operational status of the E100T-12. When the ACT LED is green it indicates that the E100T-12 card is active and the software is operational.                                                                |
| <b>SF LED</b>         | Not used                                                                                                                                                                                                                                 |

## 4.32.2 E100T-12 Port-Level Indicators

The E100T-12 card also has 12 pairs of LEDs (one pair for each port) to indicate port conditions. You can find the status of the E100T-12 card port using the LCD screen on the ONS 15454 fan-tray assembly. Use the LCD to view the status of any port or card slot; the screen displays the number and severity of alarms for a given port or slot. See Chapter 1, "Alarm Troubleshooting" for a complete description of the alarm messages.

**Table 4-46 E100T-12 Port-Level Indicators**

| LED State              | Description                                   |
|------------------------|-----------------------------------------------|
| <b>Amber</b>           | Transmitting and Receiving                    |
| <b>Solid Green</b>     | Idle and Link Integrity                       |
| <b>Green Light Off</b> | Inactive Connection or Unidirectional Traffic |

## 4.32.3 E100T-12 Compatibility

Do not use the E100T-12 card with the XC10G card. If you want to use the XC10G card, the E100T-G is compatible with the XC10G.

## 4.32.4 E100T-12 Card Specifications

- Environmental
  - Operating Temperature:  
C-Temp (15454-E100T): 0 to +55 degrees Celsius
  - Operating Humidity: 5 - 95%, non-condensing
  - Power Consumption: 65 W, 1.35 amps, 221.93 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 2.3 lbs, 1.0 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950


## 4.33 E1000-2 Card

Do not use the E1000-2 when the XC10G cross-connect card is in use. The ONS 15454 uses E1000-2 cards for Gigabit Ethernet (1000 Mbps). The E1000-2 card provides two IEEE-compliant, 1000 Mbps ports for high-capacity customer LAN interconnections. Each port supports full-duplex operation. Figure 4-36 shows the card faceplate and a block diagram of the card.

The E1000-2 card uses standard Cisco gigabit interface converter (GBIC) modular receptacles for the optical ports. GBICs are hot-swappable input/output devices that plug into a Gigabit Ethernet port to link the port to the fiber-optic network. Cisco provides two GBIC models: one for short-reach applications and one for long-reach applications. The short-reach model connects to multimode fiber and the long-reach model requires single-mode fiber.

For Software R2.2.0 and later, both GBIC modules are offered as separate orderable products: an IEEE 1000Base-SX compliant, 850 nm optical module and an IEEE 1000Base-LX-compliant, 1300 nm optical module, the 850 nm SX optics are designed for multimode fiber and distances of up to 220 meters on 62.5 micron fiber and up to 550 meters on 50 micron fiber. For more information see the *Cisco ONS 15454 Installation and Operations Guide*.

**Figure 4-36 E1000-2 faceplate and block diagram**



The E1000-2 Gigabit Ethernet card provides high-throughput, low-latency packet switching of Ethernet traffic across a SONET network while providing a greater degree of reliability through SONET “self-healing” protection services. This enables network operators to provide multiple 1000 Mbps access drops for high-capacity customer LAN interconnects. It enables efficient transport and co-existence of traditional TDM traffic with packet-switched data traffic.

Each E1000-2 card supports standards-based, layer 2 Ethernet switching between its Ethernet interfaces and SONET interfaces on the ONS 15454. The 802.1Q VLAN tag logically isolates traffic (typically subscribers). The E1000-2 supports two 802.1Q.

You can install the E1000-2 card into any multispeed slot. Multiple Ethernet cards installed in an ONS 15454 can act together as a single switching entity or as an independent single switch supporting a variety of SONET port configurations.

You can create logical SONET ports by provisioning STS channels to the packet switch entity within the ONS 15454. Logical ports can be created with a bandwidth granularity of STS-1. The ONS 15454 supports STS-1, STS-3c, STS-6c, or STS-12c circuit sizes.



Note

When making an STS-12c Ethernet circuit, the E100 or E1000 cards must be configured as single-card EtherSwitch.

### 4.33.1 E1000-2 Card-Level Indicators

The E1000-2 card faceplate has two card-level LED indicators.

**Table 4-47 E1000-2 Card-Level Indicators**

| Card-Level Indicators | Description                                                                                                                                                                                                                             |
|-----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Red FAIL LED</b>   | The red FAIL LED indicates that the card’s processor is not ready or catastrophic software failure occurred on the E1000-2 card. As part of the boot sequence, the FAIL LED is turned on until the software deems the card operational. |
| <b>Green ACT LED</b>  | A green ACT LED provides the operational status of the E1000-2. When the ACT LED is green it indicates that the E1000-2 card is active and the software is operational.                                                                 |
| <b>SF LED</b>         | Not used                                                                                                                                                                                                                                |

### 4.33.2 E1000-2 Port-Level Indicators

The E1000-2 card also has one bicolor LED per port. When the green LINK LED is on, carrier is detected, meaning an active network cable is installed. When the green LINK LED is off, an active network cable is not plugged into the port, or the card is carrying unidirectional traffic. The amber port ACT LED flashes at a rate proportional to the level of traffic being received and transmitted over the port.

**Table 4-48 E1000-2 Port-Level Indicators**


| LED State       | Description                                   |
|-----------------|-----------------------------------------------|
| Amber           | Transmitting and Receiving                    |
| Solid Green     | Idle and Link Integrity                       |
| Green Light Off | Inactive Connection or Unidirectional Traffic |

### 4.33.3 E1000-2 Compatibility

Do not use the E1000-2 card with the XC10G card. If you want to use the XC10G card, the E1000-2-G is compatible with the XC10G.

### 4.33.4 E1000-2 Card Specifications

- Environmental
  - Operating Temperature:
    - C-Temp (15454-E1000-2): 0 to +55 degrees Celsius
  - Operating Humidity: 5- 95%, non-condensing
  - Power Consumption: 53.50 W, 1.11 amps, 182.67 BTU/Hr.
- Dimensions
  - Height: 12.650 in.
  - Width: 0.716 in.
  - Depth: 9.000 in.
  - Card Weight: 2.1 lbs, 0.9 kg
- Compliance
  - ONS 15454 cards, when installed in a system, comply with these standards: Safety: UL 1950, CSA C22.2 No. 950, EN 60950, IEC 60950
  - Eye Safety Compliance: Class I (21 CFR 1040.10 and 1040.11) and Class 1M (IEC 60825-1 2001-01) laser products



---

## **Numerics**

### **10BaseT**

standard 10 megabit per second local area network over unshielded twisted pair copper wire

### **100BaseT**

standard 100 megabit per second ethernet network

### **100BaseTX**

specification of 100BaseT that supports full duplex operation

---

## **A**

### **ACO**

Alarm Cutoff

### **ACT/STBY**

Active/Standby

### **ADM**

Add-Drop Multiplexer

### **AIC**

Alarm Interface Controller

### **AID**

Access Identifier

### **AIP**

Alarm Interface Panel

### **AIS**

Alarm Indication Signal

### **AIS-L**

Line Alarm Indication Signal

**AMI**

Alternate Mark Inversion

**ANSI**

American National Standards Institute

**APS**

Automatic Protection Switching

**ARP**

Address Resolution Protocol

**ATAG**

Autonomous Message Tag

**ATM**

Asynchronous Transfer Mode

**AWG**

American Wire Gauge

---

**B**

**B8ZS**

Bipolar 8 Zero Substitution

**BER**

Bit Error Rate

**BIC**

Backplane Interface Connector

**BIP**

Bit Interleaved Parity

**BITS**

Building Integrated Timing Supply

**BLSR**

Bidirectional line switched ring

**BNC**

Bayonet Neill-Concelman (coaxial cable bayonet locking connector)

**BPDU**

Bridge Protocol Data Unit

---

**C****CAT 5**

Category 5 (cabling)

**CCITT**

Consultative Committee International Telegraph and Telephone (France)

**CEO**

Central Office Environment

**CEV**

Controlled Environment Vaults

**CLEI**

Common Language Equipment Identifier code

**CLNP**

Correctionless Network Protocol

**CMIP**

Common Management Information Protocol

**cm**

centimeter

**COE**

Central Office Environment

**CORBA**

Common Object Request Broker Architecture

**CPE**

Customer Premise Environments

**CTAG**

Correlation Tag

**CTC**

Cisco Transport Controller

---

## **D**

### **DCC**

Data Communications Channel

### **DCN**

Data Communications Network

### **DCS**

Distributed Communications System

### **DRAM**

Dynamic Random Access Memory

### **DS-1**

Digital Signal Level One

### **DS-3**

Digital Signal Level Three

### **DS1-14**

Digital Signal Level One (14 ports)

### **DS1N-14**

Digital Signal Level One (N-14 ports)

### **DS3-12**

Digital Signal Level Three (12 ports)

### **DS3N-12**

Digital Signal Level Three (N-12 ports)

### **DS3XM-6**

Digital Service, level 3 Trans Multiplexer 6 ports

### **DSX**

Digital Signal Cross Connect frame

---

## **E**

### **EDFA**

Erbium Doped Fiber Amplifier

**EFT**

Electrical Fast Transient/Burst

**EIA**

Electrical Interface Assemblies

**ELR**

Extended Long Reach

**EMI**

Electromagnetic interface

**EML**

Element Management Layer

**EMS**

Element Management System

**EOW**

Express Orderwire

**ERDI**

Enhanced Remote Defect Indicator

**ES**

Errored Seconds

**ESD**

Electrostatic Discharge

**ESF**

Extended Super Frame

**ETSI**

European Telecommunications Standards Institute

---

**F****FC**

Failure Count

**FDDI**

Fiber Distributed Data Interface

**FE**

Frame Bit Errors

**FG1**

Frame Ground #1(pins are labeled “FG1,” “FG2,” etc.)

**FSB**

Field Service Bulletin

---

**G**

**Gbps**

Gigabits per second

**GBIC**

Gigabit Interface Converter

**GR-253-CORE**

General Requirements #253 Council Of Registrars

**GR-1089**

General Requirements #1089

**GUI**

Graphical User Interface

---

**H**

**HDLC**

High-Level Data Link Control

---

**I**

**IEC**

InterExchange Carrier

**IEEE**

Institute of Electrical and Electronics Engineers

**IETF**

Internet Engineering Task Force

**IP**

Internet Protocol

**IPPM**

Intermediate-Path Performance Monitoring

**I/O**

Input/Output

**ITU-T**

The International Telecommunication Union-Telecommunication Standards Sector

---

**J****JRE**

Java Runtime Environment

---

**L****LAN**

Local Area Network

**LCD**

Liquid Crystal Display

**LDCC**

Line Data Communications Channel

**LOP**

Loss of Pointer

**LOS**

Loss of Signal

**LOF**

Loss of Frame

**LOW**

Local Orderwire

**LTE**

Line Terminating Equipment

**LVDS**

Low Voltage Differential Signal

---

**M**

**MAC**

Media Access Control

**Mbps**

Million bits per second, or Million bytes per second

**Mhz**

Megahertz

**MIB**

Management Information Bases

**MIME**

Multipurpose Internet Mail Extensions

**Mux/Demux**

Multiplexer/Demultiplexer

---

**N**

**NE**

Network Element

**NEL**

Network Element Layer

**NEBS**

Network Equipment-Building Systems

**NML**

Network Management Layer

**NMS**

Network Management System

---

**O****OAM&P**

Operations, Administration, Maintenance, and Provisioning

**OC**

Optical carrier

**OOS AS**

Out of Service Assigned

**OSI**

Open Systems Interconnection

**OSPF**

Open Shortest Path First

**OSS**

Operations Support System

**OSS/NMS**

Operations Support System/Network Management System

---

**P****PCM**

Pulse Code Modulation

**PCMCIA**

Personal Computer Memory Card International Association

**PCN**

Product Change Notices

**PDI-P**

STS Payload Defect Indication-Path

**POP**

Point of Presence

**PM**

Performance Monitoring

**PPMN**

Path-Protected Mesh Network

**PSC**

Protection Switching Count

**PSD**

Protection Switching Duration

**PTE**

Path Terminating Equipment

---

**R**

**RAM**

Random Access Memory

**RDI-L**

Remote Defect Indication Line

**RES**

Reserved

**RJ45**

Registered Jack #45 (8 pin)

**RMA**

Return Material Authorization

**RMON**

Remote Network Monitoring

**RS232**

Recommended Standard #232 (ANSI Electrical Interface for Serial Communication)

**Rx**

Receive

---

**S**

**SCI**

Serial Communication Interface

**SCL**

System Communications Link

**SDCC**

Section Data Communications Channel

**SDH/SONET**

Synchronous Digital Hierarchy/Synchronous Optical Network

**SEF**

Severely Errored Frame

**SELV**

Safety Extra Low Voltage

**SES**

Severely Errored Seconds

**SF**

Super Frame

**SML**

Service Management Layer

**SMF**

Single Mode Fiber

**SNMP**

Simple Network Management Protocol

**SNTP**

Simple Network Time Protocol

**SONET**

Synchronous Optical Network

**SPE**

Synchronous Payload Envelope

**SSM**

Synchronous Status Messaging

**STA**

Spanning Tree Algorithm

**STP**

Shielded Twisted Pair

**STS-1**

Synchronous Transport Signal Level 1

**SWS**

SONET WAN Switch

**SXC**

SONET Cross Connect ASIC

---

**T**

**TAC**

Technical Assistance Center

**TBOS**

Telemetry Byte Oriented Serial protocol

**TCA**

Threshold Crossing Alert

**TCC+**

Timing Communications and Control+ Card

**TCP/IP**

Transmission Control Protocol/Internet Protocol

**TDM**

Time Division Multiplexing

**TDS**

Time Division Switching

**TID**

Target Identifier

**TL1**

Transaction Language 1

**TLS**

Transparent LAN service

**TMN**

Telecommunications Management Network

**TSA**

Time Slot Assignment

**TSI**

Time-Slot Interchange

**Tx**

Transmit

---

**U****UAS**

Unavailable Seconds

**UDP/IP**

User Datagram Protocol/Internet Protocol

**UID**

User Identifier

**UPSR**

Unidirectional Path Switched Ring

**UTC**

Universal Time Coordinated

**UTP**

Unshielded Twisted Pair

---

**V****VDC**

Volts Direct Current

**VLAN**

Virtual Local Area Network

**VPN**

Virtual Private Network

**VT1.5**

Virtual Tributary equals 1.544 megabits per second

---

**W**

**WAN**

Wide Area Network

**W**

Watts

---

**X**

**XC**


Cross-Connect

**XCVT**

Cross-Connect Virtual Tributary

**X.25**

Protocol providing devices with direct connection to a packet switched network



---

## Numerics

### 1:1 protection

A card protection scheme that pairs a working card with a protect card of the same type in an adjacent slot. If the working card fails, the traffic from the working card switches to the protect card. When the failure on the working card is resolved, traffic reverts back to the working card if this option is set. This protection scheme is specific to electrical cards.

### 1+1 protection

A card protection scheme that pairs a single working card with a single dedicated protect card. A term specific to optical cards.

### 1:N protection

A card protection scheme that allows a single card to protect several working cards. When the failure on the working card is resolved, traffic reverts back to the working card. A term specific to electrical cards.

---

## A

### Access drop

Points where network devices can access the network.

### Address mask

Bit combination used to describe the portion of an IP address that refers to the network or subnet and the part that refers to the host. Sometimes referred to as mask. See also *subnet mask*.

### ADM

Add/drop multiplexer. ADM allows a signal to be added into or dropped from a SONET span.

### Agent

1. Generally, software that processes queries and returns replies on behalf of an application.
2. In a network management system, a process that resides in all managed devices and reports the values of specified variables to management stations.

### AID

Access Identifier. An access code used in TL1 messaging that identifies and addresses specific objects within the ONS 15454. These objects include individual pieces of equipment, transport spans, access tributaries, and others.

**AMI**

Alternate Mark Inversion. Line-code format used on T1 circuits that transmits ones by alternate positive and negative pulses. Zeroes are represented by 01 during each bit cell and ones are represented by 11 or 00, alternately, during each bit cell. AMI requires that the sending device maintain ones density. Ones density is not maintained independently of the data stream. Sometimes called binary-coded alternate mark inversion.

**APS**

Automatic Protection Switching. SONET switching mechanism that routes traffic from working lines to protect lines in case a line card failure or fiber cut occurs.

**ATAG**

Autonomous Message Tag. ATAG is used for TL1 message sequencing.

---

**B****B8ZS**

Binary 8-zero Substitution. A line-code type, used on T1 circuits, that substitutes a special code whenever 8 consecutive zeros are sent over the link. This code is then interpreted at the remote end of the connection. This technique guarantees ones density independent of the data stream. Sometimes called bipolar 8-zero substitution.

**BER**

Bit Error Rate. Ratio of received bits that contain errors.

**Bit rate**

Speed at which bits are transmitted, usually expressed in bits per second.

**BITS**

Building Integrated Timing Supply. A single building master timing supply that minimizes the number of synchronization links entering an office. Sometimes referred to as a Synchronization Supply Unit.

**BLSR**

Bidirectional Line Switched Ring. SONET ring architecture that provides working and protection fibers between nodes. If the working fiber between nodes is cut, traffic is automatically routed onto the protection fiber.

**Blue band**

Dense Wavelength Division Multiplexing (DWDM) wavelengths are broken into two distinct bands: red and blue. DWDM cards for the ONS 15454 operate on wavelengths between 1530.33nm and 1542.94nm in the blue band. The blue band is the lower frequency band.

**Bridge**

Device that connects and passes packets between two network segments that use the same communications protocol. In general, a bridge will filter, forward, or flood an incoming frame based on the MAC address of that frame.

**Broadcast**

Data packet that will be sent to all nodes on a network. Broadcasts are identified by a broadcast address. Compare with *multicast* and *unicast*. See also *Broadcast address*.

**Broadcast address**

Special address reserved for sending a message to all stations. Generally, a broadcast address is a MAC destination address of all ones.

**Broadcast storm**

Undesirable network event in which many broadcasts are sent simultaneously across all network segments. A broadcast storm uses substantial network bandwidth and, typically, causes network time-outs.

**Bus**

Common physical signal path composed of wires or other media across which signals can be sent from one part of a computer to another.

---

**C****C2 byte**

The C2 byte is the signal label byte in the STS path overhead. This byte tells the equipment what the SONET payload envelope contains and how it is constructed.

**Collision**

In Ethernet, the result of two nodes transmitting simultaneously. The frames from each device impact and are damaged when they meet on the physical media.

**Concatenation**

A mechanism for allocating contiguous bandwidth for payload transport. Through the use of Concatenation Pointers, multiple OC-1s can be linked together to provide contiguous bandwidth through the network, from end to end.

**Crosspoint**

A set of physical or logical contacts that operate together to extend the speech and signal channels in a switching network.

**CTAG**

Correlation Tag. A unique identifier given to each input command by the TL1 operator. When the ONS 15454 system responds to a specific command, it includes the command's CTAG in the reply. This eliminates discrepancies about which response corresponds to which command.

**CTC**

Cisco Transport Controller. A Java-based graphical user interface (GUI) that allows operations, administration, maintenance, and provisioning (OAM&P) of the ONS 15454 using an Internet browser.

**CTM**

Cisco Transport Manager. A Java-based network management tool used to support large networks of Cisco 15000-class equipment.

---

**D****DCC**

Data Communications Channel. Used to transport information about operation, administration, maintenance, and provisioning (OAM&P) over a SONET interface. DCC can be located in section DCC (SDCC) or line overhead (LDCC.)

**Demultiplex**

To separate multiple multiplexed input streams from a common physical signal back into multiple output streams. See also *Multiplexing*.

**DSX**

Digital Signal Cross-connect frame. A manual bay or panel where different electrical signals are wired. A DSX permits cross-connections by patch cords and plugs.

**DWDM**

Dense Wave Division Multiplexing. A technology that increases the information carrying capacity of existing fiber optic infrastructure by transmitting and receiving data on different light wavelengths. Many of these wavelengths can be combined on a single strand of fiber.

---

**E****EDFA**

Erbium Doped Fiber Amplifier. A type of fiber optical amplifier that transmits a light signal through a section of erbium-doped fiber and amplifies the signal with a laser pump diode. EDFA is used in transmitter booster amplifiers, in-line repeating amplifiers, and in receiver preamplifiers.

**EIA**

Electrical Interface Assemblies. Provides connection points for the ONS 15454 and DS-1, DS-3, or EC-1 units.

**EMI**

Electromagnetic Interference. Interference by electromagnetic signals that can cause reduced data integrity and increased error rates on transmission channels.

**Envelope**

The part of messaging that varies in composition from one transmittal step to another. It identifies the message originator and potential recipients, documents its past, directs its subsequent movement by the Message Transfer System (MTS), and characterizes its content.

**EOW**

Express Orderwire. A permanently connected voice circuit between selected stations for technical control purposes.

**Ethernet switch**

An Ethernet data switch. Ethernet switches provide the capability to increase the aggregate LAN bandwidth by allowing simultaneous switching of packets between switch ports. Ethernet switches subdivide previously-shared LAN segments into multiple networks with fewer stations per network.

### External timing reference

A timing reference obtained from a source external to the communications system, such as one of the navigation systems. Many external timing references are referenced to Coordinated Universal Time (UTC).

---

## F

### Falling threshold

A falling threshold is the counterpart to a rising threshold. When the number of occurrences drops below a falling threshold, this triggers an event to reset the rising threshold. See also *rising threshold*.

### FDDI

Fiber Distributed Data Interface. LAN standard, defined by ANSI X3T9.5, specifying a 100-Mbps token-passing network using fiber optic cable, with transmission distances of up to 2 km. FDDI uses a dual-ring architecture to provide redundancy.

### Frame

Logical grouping of information sent as a data link layer unit over a transmission medium. Often refers to the header and trailer, used for synchronization and error control that surrounds the user data contained in the unit.

### Free run synchronization mode

Occurs when the external timing sources have been disabled and the ONS 15454 is receiving timing from its Stratum 3 level internal timing source.

---

## G

### GBIC

Gigabit Interface Converter. A hot-swappable input/output device that plugs into a Gigabit Ethernet port to link the port with the fiber optic network.

---

## H

### Hard reset

The physical removal and insertion of a card. A card pull.

### HDLC

High-Level Data Link Control. Bit-oriented, synchronous, data-link layer protocol developed by ISO. HDLC specifies a data encapsulation method on synchronous serial links using frame characters and checksums.

### Host number

Part of IP address used to address an individual host within the network or subnetwork.

### Hot swap

The process of replacing a failed component while the rest of the system continues to function normally.

---

**I****Input alarms**

Used for external sensors such as open doors, temperature sensors, flood sensors, and other environmental conditions.

**IP**

Internet Protocol. Network layer protocol in the TCP/IP stack offering a connectionless internetwork service. IP provides features for addressing, type-of-service specification, fragmentation and reassembly, and security.

**IP address**

32-bit address assigned to host using TCP/IP. An IP address belongs to one of five classes (A, B, C, D, or E) and is written as 4 octets separated by periods (dotted decimal format). Each address consists of a network number, an optional subnetwork number, and a host number.

---

**K****K bytes**

Automatic protection switching bytes. K bytes are located in the SONET line overhead and monitored by equipment for an indication to switch to protection.

---

**L****LAN**

Local Area Network. High-speed, low error data network covering a relatively small geographic area. LANs connect workstations, peripherals, terminals, and other devices in a single building or other geographically limited area. Ethernet, FDDI, and Token Ring are widely used LAN technologies.

**LCD**

Liquid Crystal Display. An alphanumeric display using liquid crystal sealed between two pieces of glass. LCDs conserve electricity.

**Line layer**

Refers to the segment between two SONET devices in the circuit. The line layer deals with SONET payload transport, and its functions include multiplexing and synchronization. Sometimes called a maintenance span.

**Line timing mode**

A node that derives its clock from the SONET lines.

**Link budget**

The difference between the output power and receiver power of an optical signal expressed in dB. Link refers to an optical connection and all of its component parts (optical transmitters, repeaters, receivers, and cables).

**Link integrity**

The network communications channel is intact.

**Loopback test**

Test that sends signals then directs them back toward their source from some point along the communications path. Loopback tests are often used to test network interface usability.

**LOW**

Local Orderwire. A communications circuit between a technical control center and selected terminal or repeater locations.

---

**M****MAC address**

Standardized data link layer address that is required for every port or device that connects to a LAN. Other devices in the network use these addresses to locate specific ports in the network and to create and update routing tables and data structures. MAC addresses are six bytes long and are controlled by the IEEE. Also known as the hardware address, MAC-layer address, and physical address.

**Maintenance user**

A security level that limits user access to maintenance options only. See also *Superuser*, *Provisioning User*, and *Retrieve User*.

**Managed device**

A network node that contains an SNMP agent and resides on a managed network. Managed devices include routers, access servers, switches, bridges, hubs, computer hosts, and printers.

**Managed object**

In network management, a network device that can be managed by a network management protocol. Sometimes called an MIB object.

**Mapping**

A logical association between one set of values, such as addresses on one network, with quantities or values of another set, such as devices on another network.

**MIB**

Management Information Base. Database of network management information that is used and maintained by a network management protocol such as SNMP or CMIP. The value of a MIB object can be changed or retrieved using SNMP or CMIP commands, usually through a GUI network management system. MIB objects are organized in a tree structure that includes public (standard) and private (proprietary) branches.

**Multicast**

Single packets copied by the network and sent to a specific subset of network addresses.

**Multiplex payload**

Generates section and line overhead, and converts electrical/optical signals when the electrical/optical card is transmitting.

**Multiplexing**

Scheme that allows multiple logical signals to be transmitted simultaneously across a single physical channel. Compare with *Demultiplex*.

---

**N****NE**

Network Element. In an Operations Support System, a single piece of telecommunications equipment used to perform a function or service integral to the underlying network.

**Network number**

Part of an IP address that specifies the network where the host belongs.

**NMS**

Network Management System. System that executes applications that monitor and control managed devices. NMSs provide the bulk of the processing and memory resources required for network management.

**Node**

Endpoint of a network connection or a junction common to two or more lines in a network. Nodes can be processors, controllers, or workstations. Nodes, which vary in routing and other functional capabilities, can be interconnected by links, and serve as control points in the network. Node is sometimes used generically to refer to any entity that can access a network. In this manual the term “node” usually refers to an ONS 15454.

---

**O****OAM&P**

Operations, Administration, Maintenance, and Provisioning. Provides the facilities and personnel required to manage a network.

**Optical amplifier**

A device that amplifies an optical signal without converting the signal from optical to electrical and back again to optical energy.

**Optical receiver**

An opto-electric circuit that detects incoming lightwave signals and converts them to the appropriate signal for processing by the receiving device.

**Orderwire**

Equipment that establishes voice contact between a central office and carrier repeater locations.

**Output contacts (alarms)**

Triggers that drive visual or audible devices such as bells and lights. Output contacts can control other devices such as generators, heaters, and fans.

---

**P****Passive devices**

Components that do not require external power to manipulate or react to electronic output. Passive devices include capacitors, resistors, and coils.

**Path layer**

The segment between the originating equipment and the terminating equipment. This path segment may encompass several consecutive line segments or segments between two SONET devices.

**Payload**

Portion of a cell, frame, or packet that contains upper-layer information (data).

**Ping**

Packet internet grouper. ICMP echo message and its reply. Often used in IP networks to test the reachability of a network device.

**PPMN**

Path Protected Mesh Network. PPMN extends the protection scheme of a unidirectional path switched ring (UPSR) beyond the basic ring configuration to the meshed architecture of several interconnecting rings.

**Priority queuing**

Routing feature that divides data packets into two queues: one low-priority and one high-priority.

**Provisioning user**

A security level that allows the user to access only provisioning and maintenance options in CTC. See also *Superuser*, *Maintenance user*, and *Retrieve user*.

---

**Q****Queue**

In routing, a backlog of packets waiting to be forwarded over a router interface.

---

**R****Red band**

DWDM wavelengths are broken into two distinct bands: red and blue. The red band is the higher frequency band. The red band DWDM cards for the ONS 15454 operate on wavelengths between 1547.72nm and 1560.61nm.

**Retrieve user**

A security level that allows the user to retrieve and view CTC information but not set or modify parameters. See also *Superuser*, *Maintenance user*, and *Provisioning user*.

**Revertive switching**

A process that sends electrical interfaces back to the original working card after the card comes back online.

**Rising threshold**

The number of occurrences (collisions) that must be exceeded to trigger an event.

**RMON**

Remote Network Monitoring. Allows network operators to monitor the health of the network with a Network Management System (NMS). RMON watches several variables, such as Ethernet collisions, and triggers an event when a variable crosses a threshold in the specified time interval.

---

**S****SNMP**

Simple Network Management Protocol. Network management protocol used almost exclusively in TCP/IP networks. SNMP monitors and controls network devices and manages configurations, statistics collection, performance, and security.

**SNTP**

Simple Network Time Protocol. Using an SNTP server ensures that all ONS 15454 network nodes use the same date and time reference. The server synchronizes alarm timing during power outages or software upgrades.

**Soft reset**

A soft reset reloads the operating system, application software, etc., and reboots the card. It does not initialize the ONS 15454 ASIC hardware.

**SONET**

Synchronous Optical Network. High-speed synchronous network specification developed by Telcordia Technologies, Inc. and designed to run on optical fiber. STS-1 is the basic building block of SONET. Approved as an international standard in 1988.

**Spanning tree**

Loop-free subset of a network topology. See also *STA* and *STP*.

**SPE**

Synchronous Payload Envelope. A SONET term describing the envelope that carries the user data or payload.

**SSM**

Sync Status Messaging. A SONET protocol that communicates information about the quality of the timing source using the S1 byte of the line overhead.

**STA**

Spanning-Tree Algorithm. An algorithm used by the spanning tree protocol to create a spanning tree. See also *Spanning tree* and *STP*.

**Static route**

A route that is manually entered into a routing table. Static routes take precedence over routes chosen by all dynamic routing protocols.

**STP**

Spanning Tree Protocol. Bridge protocol that uses the spanning-tree algorithm to enable a learning bridge to dynamically work around loops in a network topology by creating a spanning tree. See also *Spanning tree*, *STA*, and *Learning bridge*.

**STS-1**

Synchronous Transport Signal 1. Basic building block signal of SONET, operating at 51.84 Mbps for transmission over OC-1 fiber. Faster SONET rates are defined as STS-*n*, where *n* is a multiple of 51.84 Mbps. See also *SONET*.

**Subnet mask**

32-bit address mask used in IP to indicate the bits of an IP address that are used for the subnet address. Sometimes referred to simply as mask. See also *IP address mask* and *IP address*.

**Subnetwork**

In IP networks, a network confined to a particular subnet address. Subnetworks are networks segmented by a network administrator in order to provide a multilevel, hierarchical routing structure while shielding the subnetwork from the addressing complexity of attached networks. Sometimes called a subnet.

**Subtending rings**

SONET rings that incorporate nodes that are also part of an adjacent SONET ring.

**Superuser**

A security level that can perform all of the functions of the other security levels as well as set names, passwords, and security levels for other users. A superuser is usually the network element administrator. See also *Retrieve user*, *Maintenance user*, and *Provisioning user*.

---

**T****T1**

T1 transmits DS-1-formatted data at 1.544 Mbps through the telephone-switching network using AMI or B8ZS coding. See also *AMI*, *B8ZS*, and *DS-1*.

**Tag**

Identification information, including a number plus other information.

**TDM**

Time Division Multiplexing. Allocates bandwidth on a single wire for information from multiple channels based on preassigned time slots. Bandwidth is allocated to each channel regardless of whether the station has data to transmit.

**Telcordia**

Telcordia Technologies, Inc., formerly named Bellcore. Eighty percent of the U.S. telecommunications network depends on software invented, developed, implemented, or maintained by Telcordia.

**TID**

Target Identifier. Identifies the particular network element (in this case, the ONS 15454) where each TL1 command is directed. The TID is a unique name given to each system at installation.

**TLS**

Transparent LAN Service. Provides private network service across a SONET backbone.

**Transponder**

Optional devices of a DWDM system providing the conversion of one optical wavelength to a precision narrow band wavelength.

**Trap**

Message sent by an SNMP agent to an NMS (CTM), console, or terminal to indicate the occurrence of a significant event, such as an exceeded threshold.

**Tributary**

The lower-rate signal directed into a multiplexer for combination (multiplexing) with other low rate signals to form an aggregate higher rate level.

**Trunk**

Network traffic travels across this physical and logical connection between two switches. A backbone is composed of a number of trunks. See also *Backbone*.

**Tunneling**

Architecture that is designed to provide the services necessary to implement any standard point-to-point encapsulation scheme. See also *encapsulation*.

---

**U****Unicast**

The communication of a single source to a single destination.

**UPSR**

Unidirectional Path Switched Ring. Path-switched SONET rings that employ redundant, fiber-optic transmission facilities in a pair configuration. One fiber transmits in one direction and the backup fiber transmits in the other. If the primary ring fails, the backup takes over.

**Upstream**

Set of frequencies used to send data from a subscriber to the headend.

---

**V****Virtual fiber**

A fiber that carries signals at different rates and uses the same fiber optic cable.

**Virtual ring**

Entity in a source-route bridging (SRB) network that logically connects two or more physical rings together either locally or remotely. The concept of virtual rings can be expanded across router boundaries.

**Virtual wires**

Virtual wires route external alarms to one or more alarm collection centers across the SONET transport network.

**VLAN**

Virtual LAN. Group of devices located on a number of different LAN segments that are configured (using management software) to communicate as if they were attached to the same wire. Because VLANs are based on logical instead of physical connections, they are extremely flexible.

**VPN**

Virtual Private Network. Enables IP traffic to travel securely over a public TCP/IP network by encrypting all traffic from one network to another. A VPN uses “tunneling” to encrypt all information at the IP level. (See also *Tunneling*.)


**VT**

Virtual Tributary. A structure designed for the transport and switching of sub-DS3 payloads.

**VT layer**

The VT layer or electrical layer occurs when the SONET signal is broken down into an electrical signal.





---

## Numerics

- 1+1 optical card protection **4-15**
- 1:1 electrical card protection **4-12**
- 1:N electrical card protection **4-12**

---

## A

- acronyms **AC-1**
- add-drop multiplexer *see* linear ADM
- AIC card
  - description **4-31**
  - input/output alarm contacts **4-31**
  - power requirements **4-5**
  - software compatibility **4-9**
  - specifications **4-33**
  - temperature range **4-6**
- air filter
  - description **3-1**
  - disposable type **3-3**
  - inspect and clean the reusable filter **3-2**
  - inspect and replace the disposable filter **3-3**
  - reusable type **3-2**
- AIS (alarm) **1-4**
- AIS-L (alarm) **1-4**
- AIS-P (alarm) **1-5, 2-28**
- AIS-V (alarm) **1-5, 2-27**
- alarm indication signal **1-4**
- Alarm Interface Controller card *see* AIC card
- alarms
  - alarms are indexed individually by name*
  - customer-defined capability **4-31**
  - TL1 **1-1**

- alarm troubleshooting **1-1 to 1-83**
- AMP Champ EIA
  - DS-1 card requirements **4-41**
  - electrical protection **4-15**
  - replacing **3-31**
- APSB (alarm) **1-6**
- APSCDFLTK (alarm) **1-6**
- APSCIMP (alarm) **1-7**
- APSCINCON (alarm) **1-8**
- APSCM (alarm) **1-8**
- APSCNMIS (alarm) **1-9**
- APSCONNL (alarm) **1-10**
- APSM (alarm) **1-11**
- APS *see* protection switching
- ARP **2-25**
- AUTOLSROFF (alarm) **1-11**
- automatic protection switching *see* protection switching
- automatic reset **1-12**
- AUTORESET (alarm) **1-12**
- AUTOSW-AIS (alarm) **1-12**
- AUTOSW-LOP (alarm) **1-13**
- AUTOSW-PDI (alarm) **1-13**
- AUTOSW-SDBER (alarm) **1-13**
- AUTOSW-SFBER (alarm) **1-13**
- AUTOSW-UNEQ (alarm) **1-13**

---

## B

- bidirectional line switched ring *see* BLSR
- BITS
  - daisy-chained **2-29**
  - errors **2-28**
  - holdover timing **2-29**

loss of frame **1-48**

BKUPMEMP (alarm) **1-13**

blades *see* cards

BLSR

- APS channel connection loss **1-10**
- channel/node mismatch **1-9**
- channel connection loss **1-17**
- far-end protection line failure **1-41**
- improper configuration (alarms) **1-6**
- increasing the traffic speed **3-22**
- lockout protection span alarm **1-40**
- manual speed upgrade **3-25, 3-26**
- ring switch failure **1-35**
- squench alarm **1-74**
- XC and XCVT support **4-26**

BLSROSYNC (alarm) **1-6, 1-14**

BNC EIA

- DS-3 card requirements **4-44**
- electrical protection **4-14**
- insertion and removal tool **3-33**
- replacing **3-31**

browser

- applet security restrictions **2-20**
- cache pointing to invalid directory **2-18**
- cannot launch Java **2-22**
- stalls during download **2-17**

---

## C

cache

- delete CTC cache file **2-18**
- redirect Netscape cache **2-18**

card compatibility **4-9**

card protection

- 1:1 electrical **4-12**
- 1:N electrical **4-12**
- backplane differences **4-14**
- electrical *see* EIA
- optical **4-15**
- unprotected **4-16**

cards

*individual cards are indexed by name*

- common control, overview **4-1**
- electrical **4-2**
- Ethernet **4-4**
- improper removal **1-44**
- optical **4-3**
- replacing **3-14**
- resetting **3-8**
- software compatibility **4-9**
- temperature ranges **4-6**

CARLOSS (alarm) **1-15**

carrier loss **1-15**

CAT-5 cables **2-33**

CBIT framing **2-16**

channel connection loss *see* BLSR

circuits

- AIS-V alarm on DS3XM-6 card **2-27**
- VT1.5 creation error **2-27**

CONCAT (alarm) **1-16**

connection loss **1-17**

CONNLOS (alarm) **1-17**

CONTBUS-A-18 (alarm) **1-19**

CONTBUS-A-X (alarm) **1-18**

CONTBUS-B-18 (alarm) **1-21**

CONTBUS-B-X (alarm) **1-20**

cross-connect

- bidirectional STS-1 **4-20**
- see also card entries*
- see also circuits*
- see also VT1.5*
- setup description **4-23**
- STS capability on XC10G **4-27**
- STS capability on XCVT **4-23**
- STS path selection **4-35**
- XC10G VT1.5 capability **4-27**
- XCVT VT1.5 capability **4-23**

CTC

- applet not loaded 2-22
- applet security restrictions 2-20
- backing up the database 3-10
- clearing the cache file 2-18
- grey node icon 2-19
- list of alarms 1-1
- log-in errors 2-17, 2-18, 2-20, 2-21, 2-22
- loss of TCP/IP connection 1-27
- release interoperability problems 2-21
- restoring the database 3-11
- reverting to earlier load 3-12
- username and password mismatch 2-21
- verifying PC connection 2-23

C-Temp ranges 4-6

CTNEQPT-PB1PROT (alarm) 1-21

CTNEQPT-PB1WORK (alarm) 1-23

CTNEQPT-PBX PROT (alarm) 1-24

CTNEQPT-PBXWORK (alarm) 1-25

cyclic redundancy checking 1-14

---

## D

database

- back up 3-10
- memory exceeded 1-27
- restore 3-11
- revert 3-12

DATAFLT (alarm) 1-27

DCC 2-22

- and the TCC+ 4-17
- channel lost 1-28
- limitations with OC-3 2-28

default K alarm 1-6

DISCONNECTED (alarm) 1-27

DISSCONNECTED (alarm) 2-23

DS1-14 card

- description 4-38
- card protection 4-38
- in a facility loopback 2-3

- LEDs 4-39
- port status 4-39
- power requirements 4-5
- slot requirements 4-38
- specifications 4-39
- temperature range 4-6
- traffic mapping 4-38

DS1N-14 card

- description 4-41
- card protection 4-41
- LEDs 4-42
- port status 4-42
- power requirements 4-5
- specifications 4-42
- temperature range 4-6
- traffic mapping 4-41

DS3-12 card

- description 4-44
- and AIS-P 2-28
- card protection 4-44
- LEDs 4-45
- port status 4-45
- power requirements 4-5
- slot requirements 4-44
- specifications 4-45
- temperature range 4-6
- upgrading to DS3-12E 3-20

DS3-12E card

- description 4-50
- alarms 1-82
- card protection 4-51
- CTC release compatibility 4-51
- downgrading to a DS3-12 card 3-21
- LEDs 4-51
- port status 4-51
- power requirements 4-5
- slot requirements 4-51
- specifications 4-51
- temperature range 4-6

upgrading from a DS3-12 card **3-20**

#### DS3N-12 card

description **4-47**

*see also* DS3-12 card

card protection **4-47**

LEDs **4-48**

port status **4-48**

power requirements **4-5**

slot requirements **4-47**

specifications **4-48**

temperature range **4-6**

#### DS3N-12E card

*see also* DS3-12E

description **4-53**

alarms **1-82**

LEDs **4-54**

port status **4-54**

power requirements **4-5**

release compatibility **4-54**

specifications **4-54**

temperature range **4-6**

#### DS3XM-6 card

description **4-56**

AIS-V alarm and unused VT circuits **2-27**

FEAC features **2-16**

LEDs **4-57**

port status **4-57**

power requirements **4-5**

specifications **4-57**

temperature range **4-6**

traffic mapping **4-57**

with XCVT **4-57**

#### DS-N cards

*see individual card names*

power requirements **4-5**

product names **4-6**

software compatibility **4-9**

temperature ranges **4-6**

DWDM **4-83, 4-86**

## E

#### E1000-2 card

descriptions **4-102**

GBIC **4-102**

incompatibility with XC10G **4-104**

LEDs **4-103**

port status **4-103**

power requirements **4-6**

replace faulty GBIC **2-31**

slot requirements **4-103**

specifications **4-104**

temperature range **4-7**

#### E1000-2-G card

compatibility **4-98**

description **4-96**

GBIC **4-96**

LEDs **4-97**

port status **4-97**

power requirements **4-6**

slot requirements **4-97**

specifications **4-98**

temperature range **4-7**

#### E100T-12 card

description **4-99**

LEDs **4-100**

port status **4-100**

power requirements **4-6**

slot requirements **4-100**

specifications **4-101**

temperature range **4-7**

#### E100T-G card

compatibility **4-95**

description **4-93**

LEDs **4-94**

port status **4-94**

power requirements **4-6**

specifications **4-95**

temperature range **4-7**

EC1-12 card

- description 4-35
- card protection 4-35
- LEDs 4-36
- port status 4-36
- power requirements 4-5
- slot requirements 4-35
- specifications 4-36
- temperature range 4-6

EIA

- description 4-14
- installing 3-32
- removing 3-32
- replacement, all types 3-31
- replacing 3-32
- see* AMP Champ EIA
- see* BNC EIA
- see* high-density BNC EIA
- see* SMB EIA
- types 3-31

electrical connectors *see* EIA

electrical protection *see* card protection

EOC (alarm) 1-28

EQPT (alarm) 1-14, 1-30

equipment failure 1-30, 1-39

Ethernet

- cable connectors *see* GBIC
- card descriptions 4-93, 4-96, 4-99, 4-102
- card software compatibility 4-11
- carrier loss 1-16
- configuring VLANs 2-26
- connectivity problems 2-24
- Tag/Untag port connectivity 2-25
- troubleshooting connections 2-24

E-W-MISMATCH (alarm) 1-30

EXCCOL (alarm) 1-32

excess collisions 1-32

EXERCISE-RING-FAIL (alarm) 1-32

EXERCISE-SPAN-FAILED (alarm) 1-32

EXT (alarm) 1-32

---

## F

facility loopback

- definition 2-3
- test a destination DS-N card 2-13
- test on a source DS-N card 2-4

FAILTOSW (alarm) 1-33

FAILTOSW-PATH (alarm) 1-33

FAILTOSWR (alarm) 1-35

FAILTOSWS (alarm) 1-36

FAN (alarm) 1-37

fan-tray air filter *see* air filter

fan-tray assembly

- error 1-37
- power requirements 4-5
- replacing 3-6

FEAC 2-16 to 2-17

FEAC (alarm) 2-17

FE-AIS (alarm) 1-37

FE-DS1-MULTLOS (alarm) 1-38

FE-DS1-SNGLLOS (alarm) 1-38

FE-EQPT-FAIL-SA (alarm) 1-38

FE-EQPT-NSA (alarm) 1-39

FE-IDLE (alarm) 1-39

FE-LOCKOUT (alarm) 1-40

FE-LOF (alarm) 1-40

FE-LOS (alarm) 1-41

FEPRLF (alarm) 1-41

fiber cleaning 3-33

fiber-optic connections 2-29

FORCED-REQ (alarm) 1-41

free run synchronization 1-42

FRNGSYNC (alarm) 1-42, 2-29

FSTSYNC (alarm) 1-42

**G**

## GBIC

- E1000-2 card **4-102**
- E1000-2-G card **4-96**
- replacing **2-31**
- glossary **GL-1**

**H**

## hairpin circuit

- create on a destination node **2-10**
- create on a source node **2-8**
- definition **2-3**

hard loop **2-5, 2-6**hard reset (card pull) **3-9**

## high-density BNC EIA

- electrical protection **4-14**
- removing **3-32**
- replacing **3-31**

HITEMP (alarm) **1-42**HLDOVERSYNC (alarm) **1-43, 2-29**holdover synchronization **1-43****I**IMPROPRMVL (alarm) **1-44**INCOMPATIBLE-SW (alarm) **1-45, 2-21**insertion and removal tool (BNC) **3-33**interoperability **2-21**INVMACADR (alarm) **1-45**

## IP

- connectivity **2-22**
- designing subnets **2-24**

I-Temp ranges **4-6****J**

## Java

- browser will not launch **2-22**
- Jave Runtime Environment **2-20**

## JRE

- description **2-20**
- incompatibility **2-20**
- launch failure **2-22**

**K**k bytes **1-6, 1-7, 1-9****L**lamp test **2-37**LED test **2-37**

## linear ADM

- increasing the traffic speed **3-22**
- OC-12 cards **4-62, 4-65, 4-68**
- OC-192 card **4-90**
- OC-3 card **4-59**
- OC-48 cards **4-71, 4-74, 4-77, 4-80**
- OC-48 DWDM cards **4-84, 4-86**
- see also* 1+1 optical card protection

lock on **3-29**lock out **3-30**LOCKOUT-REQ (alarm) **1-46**

## LOF (alarm)

- BITS **1-48**
- DS-1 **1-46**
- DS3XM-6 **1-47**
- EC-1 **1-49**
- OC-N **1-50**

## log-in errors

- applet security restrictions **2-20**
- browser cache pointing to an invalid directory **2-18**
- browser login does not launch Java **2-22**

browser stalls when downloading .jar file **2-17**  
 clear the CTC cache file **2-18**  
 no DCC connection **2-22**  
 no IP connectivity **2-22**  
 username/password mismatch **2-21**

loopback  
   alarms **1-56, 1-57, 1-58**  
   description **2-3**  
   *see also* facility loopback  
   *see also* terminal loopback

LOP-P (alarm) **1-50**  
 LOP-V (alarm) **1-52**

LOS (alarm)  
   BITS **1-54**  
   DS-3, DS3XM-6, DS-1 **1-53**  
   EC-1 **1-55**  
   OC-N **1-54**

loss of frame *see* LOF  
 loss of pointer *see* LOP

LPBKDS1FEAC (alarm) **1-56**  
 LPBKDS3FEAC (alarm) **1-56**  
 LPBKFACILITY (alarm)  
   DS-N **1-56**  
   OC-N **1-57**

LPBKTERMINAL (alarm)  
   DS-N **1-57**  
   OC-N **1-58**

---

## M

MAC address  
   data memory failure **1-61**  
   invalid **1-46**  
   mismatch **2-25**

maintenance **3-1 to 3-34**

MANRESET (alarm) **1-59**  
 MANUAL-REQ (alarm) **1-59**  
 MEA (alarm) **1-59**  
 MEM-GONE (alarm) **1-60**

MEM-LOW (alarm) **1-60**  
 MFGMEM (alarm) **1-61**  
 modules *see* cards

---

## N

network testing  
   *see* hairpin circuits  
   *see* loopback

NIC card **2-23, 2-25**  
 NOT-AUTHENTICATED (alarm) **1-62, 2-21**

---

## O

OC12 IR/STM4 SH 1310 card  
   description **4-62**  
   LEDs **4-63**  
   port status **4-63**  
   power requirements **4-5**  
   slot requirements **4-62**  
   specifications **4-63**  
   temperature range **4-6**

OC12 LR/STM4 LH 1310 card  
   description **4-65**  
   LEDs **4-66**  
   port status **4-66**  
   power requirements **4-5**  
   slot requirements **4-65**  
   specifications **4-66**  
   temperature range **4-6**

OC12 LR/STM4 LH 1550 card  
   description **4-68**  
   LEDs **4-69**  
   port status **4-69**  
   power requirements **4-5**  
   slot requirements **4-68**  
   specifications **4-69**  
   temperature range **4-7**

- OC192 LR/STM64 LH 1550 card
  - description 4-89
  - LEDs 4-91
  - port status 4-91
  - power requirements 4-5
  - requirements 4-91
  - slot requirements 4-90
  - specifications 4-91
  - temperature alarm 1-12
  - temperature range 4-7
- OC3 IR 4/STM1 SH 1310 card
  - DCC limitations 2-28
  - description 4-59
  - LEDs 4-60
  - port status 4-60
  - power requirements 4-5
  - slot requirements 4-59
  - specifications 4-60
  - temperature range 4-6
- OC-48 any-slot card 4-77, 4-80
- OC48 ELR/STM16 EH 100 GHz (DWDM) cards
  - description 4-83
  - LEDs 4-84
  - port status 4-84
  - specifications 4-85
  - temperature range 4-5, 4-7, 4-8
- OC48 ELR 200 GHz (DWDM) cards
  - description 4-86
  - LEDs 4-87
  - port status 4-87
  - power requirements 4-5
  - slot requirements 4-86
  - specifications 4-88
- OC48 IR/STM16 SH AS 1310 card
  - description 4-77
  - LEDs 4-78
  - port status 4-78
  - power requirements 4-5
  - specifications 4-78
  - temperature range 4-7
- OC48 IR 1310 card
  - description 4-71
  - LEDs 4-72
  - port status 4-72
  - power requirements 4-5
  - slot requirements 4-71
  - specifications 4-72
  - temperature range 4-7
- OC48 LR/STM16 LH AS 1550 card
  - description 4-80
  - card-level LEDs 4-81
  - port status 4-81
  - power requirements 4-5
  - specifications 4-81
  - temperature range 4-7
- OC48 LR 1550 card
  - description 4-74
  - LEDs 4-75
  - port status 4-75
  - power requirements 4-5
  - slot requirements 4-74
  - specifications 4-75
  - temperature range 4-7
- OC-N cards
  - see also specific card names*
  - bit errors 2-29
  - power requirements 4-5
  - product names 4-6
  - signal levels 4-59, 4-62, 4-65, 4-68
  - software compatibility 4-10
  - temperature ranges 4-6
  - transmit and receive levels 2-35
  - upgrading to a higher rate while in-service 3-22
- optical protection *see* card protection
- orderwire
  - description 4-32
  - pin assignments 4-33

**P**

password/username mismatch **2-21**  
 path trace **1-78**  
 PDI-P (alarm) **1-63**  
 PEER-NORESPONSE (alarm) **1-64**  
 ping an ONS 15454 **2-23**  
 PLM-P (alarm) **1-64**  
 PLM-V (alarm) **1-65**  
 power  
   consumption **2-37**  
   fan-tray assembly **4-6**  
   individual card requirements **4-5**  
   supply **2-36**  
 PRC-DUPID (alarm) **1-66**  
 protection *see* card protection  
 protection switching  
   APS channel/node mismatch **1-9**  
   APS channel connection loss **1-10, 1-17**  
   APS channel mismatch **1-8**  
   APS mode mismatch failure **1-11**  
   byte failure (alarm) **1-6**  
   inconsistent APS code **1-8**  
   invalid k bytes in APS **1-7**  
   lock on **3-29**  
   lock out **3-30**  
   lockout switch alarm **1-46**  
   non-revertive **4-15**  
   preventing **3-29**  
   revertive **4-13**  
   ring switch failure **1-35**  
   span switch failure **1-36**  
   UPSR alarms **1-13**  
 PWRRESTART (alarm) **1-66**

**R**

RAI (alarm) **1-67**  
 RCVRLMISS (alarm) **1-67**

receive levels **2-35**  
 remote fault indication *see* RFI  
 revert **3-12**  
 RFI (alarm)  
   line level **1-67**  
   path level **1-68**  
   VT level **1-68**  
 RING-MISMATCH (alarm) **1-69**  
 rings  
   ID mismatch **1-69**  
   *see* BLSR  
   *see* UPSR

**S**

SDBER (alarm) **1-70**  
 SFBER (alarm) **1-71, 1-72**  
 SFTWDWN-FAIL (alarm) **1-73**  
 side switch **2-9**  
 signal degrade (alarm) **1-13**  
 signal failure **1-71, 1-72**  
 signal failure (alarm) **1-13**  
 signal label mismatch failure *see* SMLF **1-64**  
 SLMF **1-64**  
 SMB EIA **4-47**  
   DS-3 card requirements **4-44**  
   electrical protection **4-14**  
   replacing **3-31**  
 soft reset (software initiated) **3-8**  
 software  
   card compatibility **4-9**  
   revert **3-12**  
 SONET  
   data communications channel **4-17**  
   improper APS alarm **1-7**  
   line layer (maintenance span) **1-4**  
   path layer **1-5**  
   VT layer **1-5, 1-52**  
 span upgrades

description **3-22**  
 manual upgrades **3-25 to 3-29**  
 Span Upgrade Wizard (automated) **3-23**  
 SQUELCH (alarm) **1-74**  
 SSM  
   failure **1-75**  
   synchronization traceability alarm **1-75**  
   timing switch **2-28**  
 SSM-FAIL (alarm) **1-75**  
 STS concatenation error **1-16**  
 STU (alarm) **1-75**  
 SWFTDWN (alarm) **1-73**  
 switching *see* protection switching  
 SWTOPRI (alarm) **1-75**  
 SWTOSEC (alarm) **1-76**  
 SWTOTHIRD (alarm) **1-76**  
 synchronization status messaging *see* SSM  
 SYNCPRI (alarm) **1-76**  
 SYNCSEC (alarm) **1-77**  
 SYNCTHIRD (alarm) **1-77**  
 SYSBOOT (alarm) **1-78**

---

## T

TCC+ card  
   database backup **3-10**  
   description **4-17**  
   flash memory problems **1-14**  
   hard reset **3-9**  
   jar file download problem **2-17**  
   LEDs **4-18**  
   low memory **1-60**  
   memory capacity exceeded **1-60**  
   power requirements **4-5**  
   soft reset **3-8**  
   software compatibility **4-9**  
   specifications **4-19**  
   temperature range **4-6**  
   upgrading from TCC to TCC+ **3-15**

TCP/IP **2-23**  
 Telcordia  
   default severities **1-1**  
   protection configurations **4-13**  
   signal degrade definition **1-70, 1-71**  
   signal failure definition **1-71, 1-72**  
   timing **4-17**  
   trouble categories **1-3**  
   VT mapping standards **4-24, 4-28**  
 temperature  
   card ranges **4-6**  
   fan-tray assembly alarm **1-37**  
   node alarm **1-42**  
   OC-192 alarm **1-12**  
 terminal loopback  
   definition **2-3**  
   test on a destination DS-N card **2-6**  
 testing  
   *see* lamp test  
   *see* loopback  
   *see* power  
 timing alarms  
   loss of primary reference **1-76**  
   loss of third reference **1-77**  
   switching to secondary timing source **1-75**  
   switching to third timing source **1-76**  
   synchronization **1-42, 1-43**  
 Timing Communications and Control Card *see* TCC+ card  
 timing reference switch **2-28**  
 TIM-P (alarm) **1-78**  
 TL1 alarms **1-1**  
 traffic switching  
   manual switch (sideswitch) **2-9**  
   time division switching **4-20**  
   XC10G card switch matrix **4-27**  
   XC card switch matrix **4-20**  
   XCVT card switch matrix **4-23**  
 transmission failure **1-79**  
 transmit levels **2-35**

transmux card *see* DS3XM-6 card

TRMT (alarm) **1-79**

TRMTMISS (alarm) **1-79**

troubleclearing *see* troubleshooting

troubleshooting **2-1 to 2-37**

*see also* alarms

*see also* loopback

---

## U

UNEQ-P (alarm) **1-80**

unequipped path **1-13**

UNEQ-V (alarm) **1-81**

unidirectional path switched ring *see* UPSR

upgrade

DS3-12E to DS3N-12E **3-20**

DS3 to DS3N **3-20**

spans **3-22**

TCC to TCC+ **3-15**

XC/XCVT to XC10G **3-18**

XC to XCVT **3-17**

UPSR

AIS alarm **1-13**

failed APS *see* FAILTOSW-PATH

increasing the traffic speed **3-22**

LOP alarm **1-13**

PDI alarm **1-13**

SD alarm **1-13**

signal failure alarm **1-13**

speed upgrade **3-27**

XC and XCVT support **4-26**

user-defined alarms **4-31**

username/password mismatch **2-21**

---

## V

VirusScan **2-17**

VT1.5s

and DS1-14 card **4-39**

and DS3XM-6 card **4-56, 4-57**

and EC1-12 card **4-36**

creation error **2-27**

VT mapping **4-24, 4-28**

---

## X

XC10G card

description **4-27**

compatibility with XC and XCVT **4-29**

LEDs **4-29**

manual switch (side switch) *see* traffic switching

power requirements **4-5**

software (CTC) compatibility **4-9**

specifications **4-30**

temperature range **4-6**

VT1.5 cross-connect capability **4-27**

VT mapping **4-28**

with transmux card **4-29**

XC card

description **4-20**

LEDs **4-21**

manual sideswitch *see* traffic switching

power requirements **4-5**

replacing while in-service **3-14**

software (CTC) compatibility **4-9**

specifications **4-22**

temperature range **4-6**

upgrading to XC10G **3-18**

upgrading to XCVT **3-17**

XCVT card

description **4-23**

compatibility with XC card **4-26**

LEDs **4-25**

manual switch (side switch) *see* traffic switching

power requirements **4-5**

replacing while in-service **3-14**

software (CTC) compatibility **4-9**

specifications **4-26**  
temperature range **4-6**  
upgrading to XC10G **3-18**  
VT1.5 cross-connects capacity **4-23**  
VT mapping **4-24**  
with DS1-14 cards **4-39**  
with DS1N-14 cards **4-42**  
with EC1-12 cards **4-36**  
with transmux cards **4-25**