

# Route Switch Processor (RSP1) Installation and Configuration

---

Product Numbers: RSP1=, MEM-RSP-8M=, MEM-RSP-16M, MEM-RSP-24M, MEM-RSP-32M(=), MEM-RSP-64M(=), and MEM-RSP-128M(=)

Part Number 78-1715-03  
Customer Order Number: DOC-781715=

This document discusses the installation and configuration for the Route Switch Processor (RSP1), which is a processor module for the Cisco 7505 router. The RSP1 combines all of the switched routing and high-speed switching functions required by the Cisco 7505 router. Refer to the section “[What Is the RSP1?](#), page 2.

## Document Contents

Following are the sections in this document:

- [What Is the Cisco 7505?](#), page 2
- [What Is the RSP1?](#), page 2
- [Prerequisites](#), page 6
- [Installation](#), page 13
- [Troubleshooting the Installation](#), page 19
- [Reference Information](#), page 22
- [Obtaining Documentation](#), page 41



---

Corporate Headquarters:  
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

Copyright © 2001. Cisco Systems, Inc. All rights reserved.


## What Is the Cisco 7505?

The Cisco 7505 is a five-slot router chassis, which uses the RSP1 and CxBus and CyBus interface processors. The Cisco 7505 provides up to four interface processor slots. Although the Cisco 7505 uses the high-speed, 1.067-gigabit-per-second (Gbps) CyBus, it can accommodate all CxBus-based interface processors.

Any combination of network interface types is supported: Ethernet, Token Ring, Fiber Distributed Data Interface (FDDI), channel attachment, multichannel, serial, and so forth. The RSP1 and interface processors are keyed with guides on the backplane to prevent them from being fully inserted in the wrong slot.

**Figure 1** shows the interface processor end of the Cisco 7505, which provides access to the five slots, the power switch, the chassis ground screw, the power receptacle, and the DC OK LED. When facing the interface processor end of the chassis, the RSP1 slot is at the top. The four interface processor slots are numbered from slot 0 (the bottom slot) through slot 3 (second slot from the top).

**Figure 1** Cisco 7505—Interface Processor End



## What Is the RSP1?

The RSP1 is the main system processor module for the Cisco 7505. It combines all of the switched routing and high-speed switching functions of the separate Route Processor (RP) and Switch Processor (SP), which are used in the Cisco 7000 series routers. Because the RSP1 combines the RP and SP functions, four slots are available for interface processors, allowing greater port density. The RSP1 contains the central processing unit (CPU) and most of the memory components for the Cisco 7505.

The Cisco Internetwork Operating System (Cisco IOS) software images reside in Flash memory, which is located either on the RSP1, in the form of a single in-line memory module (SIMM), or on up to two Personal Computer Memory Card International Association (PCMCIA) cards (called *Flash memory cards*) that insert in the two PCMCIA slots (slot 0 and slot 1) on the front of the RSP1. (See [Figure 9](#).)

Storing the Cisco IOS images in Flash memory enables you to download and boot from upgraded Cisco IOS images remotely or from software images resident in the RSP1 Flash memory, without having to remove and replace read-only memory (ROM) devices.

The RSP1 uses a software-controlled configuration register, so it is not necessary to remove the RSP1 to configure jumpers. There are no user-configurable jumpers on the RSP1.

The RSP1 contains the following components:

- Mips R4600 Reduced Instruction Set Computing (RISC) processor, used for the CPU. The CPU runs at an external clock speed of 50 MHz and an internal clock speed of 100 MHz.
- Bank of hardware (Media Access Control [MAC]–layer) addresses for the interface ports
- Most of the memory components used by the system, including onboard Flash
- Air-temperature sensors for environmental monitoring (All of the logic for the environmental monitoring functions is contained on the chassis interface card.)

In addition to the system software, the RSP1 contains and executes the following management functions that control the system:


- Sending and receiving routing protocol updates
- Managing tables and caches
- Monitoring interface and environmental status
- Providing Simple Network Management Protocol (SNMP) management and the console/Telnet interface

The high-speed switching section of the RSP1 communicates with and controls the interface processors on the high-speed CyBus. This section decides the destination of a packet and switches it based on that decision. The RSP1 uses a 16-million-instructions-per-second (mips) processor to provide high-speed, autonomous switching and routing.

## Memory Components

Figure 2 shows the various types of memory components on the RSP1, and Table 1 lists the functions of each type.

Figure 2 Route Switch Processor (RSP1)



**Table 1 RSP1 Memory Components**

Type	Size	Quantity	Description	Location
DRAM	16 to 128 MB	2 to 4	8, 16, or 32-MB SIMMs (based on maximum DRAM required)	Bank 0: U4 and U12 Bank 1: U18 and U25
NVRAM	128 KB	1	Nonvolatile EPROM for the system configuration file. <sup>1</sup>	U17
Flash SIMM Flash Card	8 MB 8, 16, and 20 MB <sup>2</sup>	1 Up to 2	Contains the Cisco IOS images on the RSP1 (standard) Contains the Cisco IOS images on up to two PCMCIA cards	U1 Slot 0, slot 1
Boot ROM	256 KB	1	EPROM for the ROM monitor program	U24

1. A system configuration file is contained in NVRAM, which allows the software to control several system variables.
2. Only Intel Series 2 Flash memory cards can be used with the RSP1.

## System Software

The Cisco 7505 router supports downloadable system software and microcode for most Cisco IOS and microcode upgrades, which enables you to remotely download, store, and boot from a new image. The publication *Upgrading Software and Microcode in Cisco 7000 Series Routers* (Document Number 78-1144-xx), which accompanies all Cisco IOS upgrade kits, provides instructions for upgrading over the network or from floppy disks. Flash memory contains the default system software. An erasable programmable read-only memory (EPROM) device contains the latest microcode version, in compressed form, for each interface processor. At system startup, an internal system utility scans for compatibility problems between the installed interface processor types and the bundled microcode images, then decompresses the images into running dynamic random-access memory (DRAM). The bundled microcode images then function the same as the EPROM images.

## DRAM

DRAM stores routing tables, protocols, and network accounting applications. The standard RSP1 configuration is 16 megabytes (MB) of DRAM, with up to 128 MB available through single in-line memory module (SIMM) upgrades.



**Note**

When upgrading DRAM, you must use SIMMs from an approved vendor. To ensure that you obtain the most current vendor information, obtain the list from Customer Information Online (CIO) or the Technical Assistance Center (TAC). (See the section “[Compatibility Requirements, page 7.](#)”)

## NVRAM

The system configuration, software configuration register settings, and environmental monitoring logs are contained in the 128-kilobyte (KB), nonvolatile random-access memory (NVRAM), which is backed up with built-in lithium batteries that retain the contents for a minimum of five years. When replacing an RSP1, be sure to back up your configuration to a remote server so you can retrieve it later.

**Caution**

---

Before you replace an RSP1, back up the running configuration to a Trivial File Transfer Protocol (TFTP) file server so you can retrieve it later. If the configuration is not saved, the entire configuration will be lost—inside the NVRAM on the removed RSP1—and you will have to reenter the entire configuration manually. For instructions on how to save the configuration file, refer to the section “[Saving and Retrieving the Configuration File, page 9](#). This procedure is not necessary if you are temporarily removing an RSP1 you will reinstall; lithium batteries retain the configuration in memory until you replace the RSP1 in the system.

---

## Flash Memory

The imbedded or PCMCIA card-based Flash memory allows you to remotely load and store multiple Cisco IOS software and microcode images. You can download a new image over the network or from a local server and then add the new image to Flash or replace the existing files. You can then boot routers either manually or automatically from any of the stored images. Flash memory also functions as a TFTP server to allow other servers to remotely boot from stored images or to copy them into their own Flash memory.

Before you can use a Flash memory card that was previously used on a Route Processor (RP) in a Cisco 7000 series router, you must reformat the Flash memory card. Flash memory cards formatted on RP-based (Cisco 7000 series) routers will not work properly in RSP-based (Cisco 7500 series) routers.

## Jumpers

There are no user-configurable jumpers on the RSP1.

## LEDs

The two LEDs on the RSP1 indicate the system and RSP1 status. The normal LED is on when the system is operational. During normal operation, the CPU halt LED should be off. The CPU halt LED goes on only if the system detects a processor hardware failure. The RSP1 controls both LEDs and turns both on in parallel to indicate that the system is operational.

## Serial Ports

Two asynchronous serial ports on the RSP1, the console and auxiliary ports, allow you to connect external devices to monitor and manage the system. The console port is an Electronics Industries Association/Telecommunications Industry Association (EIA/TIA)-232 receptacle (female) that provides a data circuit-terminating equipment (DCE) interface for connecting a console terminal.

**Note**

---

EIA/TIA-232 was known as recommended standard RS-232 before its acceptance as a standard by the Electronic Industries Association (EIA) and Telecommunications Industry Association (TIA).

---

The auxiliary port is an EIA/TIA-232 plug (male) that provides a data terminal equipment (DTE) interface; the auxiliary port supports flow control and is often used to connect a modem, a channel service unit (CSU), or other optional equipment for Telnet management.

# Prerequisites

Before beginning any of these procedures, review the following sections to ensure that your equipment configuration meets the minimum requirements for the upgrade or replacement you will perform, and that you have all the parts and tools you will need. Also, review safety and ESD-prevention guidelines to help you to avoid injury or damage to the equipment.

If you are replacing the existing RSP1, upload your current configuration file to a remote server before you remove the RSP1 to avoid having to reenter all your current configuration information manually. To upload the file, you need access to a remote server. Refer to the section “[Saving and Retrieving the Configuration File](#), page 9, for instructions for uploading the file and retrieving it after the new RSP1 is installed.

## Safety

This section lists safety guidelines you should follow when working with any equipment that connects to electrical power or telephone wiring.

## Electrical Equipment

Follow these basic guidelines when working with any electrical equipment:

- Before beginning any procedures requiring access to the chassis interior, locate the emergency power-off switch for the room in which you are working.
- Disconnect all power and external cables before moving a chassis.
- Do not work alone when potentially hazardous conditions exist.
- Never assume that power has been disconnected from a circuit; always check.
- Do not perform any action that creates a potential hazard to people or makes the equipment unsafe.
- Carefully examine your work area for possible hazards such as moist floors, ungrounded power extension cables, and missing safety grounds.

## Telephone Wiring

Use the following guidelines when working with any equipment that is connected to telephone wiring or to other network cabling:

- Never install telephone wiring during a lightning storm.
- Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.

## Preventing Electrostatic Discharge Damage

ESD damage, which can occur when electronic cards or components are improperly handled, results in complete or intermittent failures. Each processor module contains a printed circuit card that is fixed in a metal carrier. Electromagnetic interference (EMI) shielding, connectors, and a handle are integral components of the carrier. Although the metal carrier helps to protect the board from ESD, use an ESD-preventive wrist or ankle strap whenever you handle any electronic system component.

Following are guidelines for preventing ESD damage:

- Always use an ESD-preventive wrist or ankle strap and ensure that it makes good skin contact.
- When you work at the interface processor end of the chassis, connect the equipment end of the strap to the captive installation screw on an installed interface processor, or to the chassis ground screw that is located to the left of the power receptacle. (See [Figure 1](#).)
- When you install a processor module, use the ejector levers to properly seat the bus connectors in the backplane, then tighten both captive installation screws. These screws prevent accidental removal, provide proper grounding for the system, and help to ensure that the bus connectors are seated in the backplane.
- Handle processor modules by the carrier handles and carrier edges only; never touch the board or any connector pins.
- When you remove a processor module, place it card side up on an antistatic surface or in a static shielding bag. Immediately place the module in a static shielding bag if you need to return it to the factory.
- Avoid contact between electronic equipment and clothing. Antistatic straps only protect the equipment from ESD voltages on the body; ESD voltages on clothing can still cause damage.



### Caution

For safety, periodically check the resistance value of the antistatic strap. The measurement should be between 1 and 10 megohms.

## Compatibility Requirements

You must install the RSP1 in the top slot (slot 4) of the Cisco 7505. (See the section “[What Is the Cisco 7505?](#), page 2.) You must obtain the replacement SIMMs from an approved vendor. To ensure that you obtain the latest available product and vendor information, obtain the list from one of the following sources:

- Customer Information Online (CIO). If you have a CIO account, you can access the list remotely. (See the “[Obtaining Documentation](#)” section on page 41 at the end of this document.)
- Technical Assistance Center at 800 553-2447, 408 526-7209, or send an e-mail message to [tac@cisco.com](mailto:tac@cisco.com).
- Customer Response Center at 800 553-6387, 408 526-7208, or send an e-mail message to [cs-rep@cisco.com](mailto:cs-rep@cisco.com).

Although the PCMCIA card and SIMM specifications are defined in the manufacturers’ part numbers, they must meet the following requirements:

- Flash PCMCIA card and DRAM SIMMs must be obtained from an approved vendor.
- Minimum DRAM speed is 60 nanosecond (ns).
- Maximum SIMM height is 1 inch.

## Software Prerequisites

The RSP1 is compatible with Cisco IOS Release 10.3(3) or later. The **show version** and **show hardware** commands display the current hardware configuration of the router, including the system software version that is currently loaded and running. The **show microcode** command lists the bundled microcode (target hardware) version for each processor type. The **show controller cybus** or **show controller cbus** commands show the microcode version you are running. (For complete descriptions of **show** commands, refer to the *Configuration Fundamentals Configuration Guide* and *Configuration Fundamentals Command Reference* publications.)

You can determine the current version of software or microcode stored in ROM either by removing the processor module and checking the ROM labels or by configuring the system to boot the system software or microcode from ROM, reloading the system, and using **show** commands to check the version that is loaded and running. Refer to the appropriate software documentation for complete configuration instructions and examples.

**Note**

---

If the displays indicate that the required system software and microcode are not available in your system, contact a customer service representative for upgrade information. (Refer to the [“Obtaining Documentation” section on page 41](#) at the end of this document.) Cisco IOS Release 11.1(1) might require more than 16 MB of DRAM for your RSP1; refer to the [“Replacing and Upgrading DRAM SIMMs” section on page 23](#).

---

## Microcode Prerequisites

Microcode is a set of processor-specific software instructions that enables and manages the features and functions of a specific processor type. At system startup or reload, the system loads the microcode for each processor type present in the system. The latest available microcode image for each processor type is bundled and distributed with the system software image.

New microcode is released to enable new features, improve performance, or fix bugs in earlier versions. The Cisco routers feature downloadable software and microcode for most upgrades. These features enable you to download new (upgraded) images remotely, store the images in router memory, and load the new images at system startup without having to physically access the router.

You can store multiple versions for a specific processor type in Flash memory and use configuration commands to specify which version the system should load at startup. All interfaces of the same type (for example, all CIPs) use the same microcode image. Although most upgrades can be downloaded, some exceptions require ROM replacement to ensure proper startup and operation. Microcode images that are bundled with the system image load automatically along with the new software image.

**Note**

---

The software and interface processor microcode images are carefully optimized and bundled to work together. Overriding the bundle can result in incompatibility between the various interface processors in the system. We recommend that you use *only* the microcode image that is bundled. The exception to this is CIP microcode, which as of Cisco IOS Release 11.1(1) is unbundled from the Cisco IOS image bundle, and is available in a separate bundle on floppy disks, a TFTP server, from CIO, or on Flash memory cards.

---



## List of Tools and Parts

You need some or all of the following tools and parts to remove and replace an RSP1. If you need additional equipment, contact a customer service representative for ordering information.

- Number 2 Phillips or 1/4-inch, flat-blade screwdriver for the captive installation screws that secure the RSP1 in its slot.
- ESD-prevention equipment or the disposable ESD-preventive wrist strap included with all spares and upgrade kits.
- Antistatic mat, foam pad, or bag for the removed RSP1 (place the removed RSP1 into an antistatic bag if you plan to return it to the factory, or on an antistatic mat or foam if you are replacing components and will reinstall the RSP1)
- If you are replacing SIMMs, you will need 60-ns SIMMs from an approved vendor.

## Saving and Retrieving the Configuration File

This section describes the procedures for saving and retrieving the system configuration. Configuration information resides in two places when the router is operating: the default (permanent) configuration in NVRAM, and the running (temporary) memory in RAM. The default configuration always remains available; NVRAM retains the information even when the power is shut down. The current information is lost when if the system power is shut down. The current configuration contains all nondefault configuration information that you added with the **configure** command, the **setup** command facility, or by editing the configuration file.

The **copy running-config startup-config** command adds the current configuration to the default configuration in NVRAM, so that it will also be saved when power is shut down. Whenever you make changes to the system configuration, issue the **copy running-config startup-config** command to ensure that the new configuration is saved.

If you replace the RSP1, you will also replace the entire configuration (NVRAM resides in socket U17 on the RSP1). If you upload (copy) the configuration file to a remote server before removing the RSP1, you can retrieve it later and write it into NVRAM on the new RSP1. If you do not upload the configuration file, you will have to use the **configure** command or the **setup** command facility to reenter the configuration information after you install the new RSP1. For complete descriptions of these commands and instructions for using them, refer to the appropriate software documentation.

This procedure is not necessary if you are temporarily removing an RSP1 that you will reinstall; the lithium batteries will retain the configuration in memory until you replace the RSP1 in the system. This procedure requires privileged-level access to the EXEC command interpreter, which usually requires a password. Refer to the description that follows and contact your system administrator if necessary, to obtain access.

## Using the EXEC Command Interpreter

Before you use the **configure** command, you must enter the privileged level of the EXEC command interpreter with the **enable** command. The system will prompt you for a password if one has been set.

The system prompt for the privileged level ends with a pound sign (#) instead of an angle bracket (>). At the console terminal, enter the privileged level as follows:

- 
- Step 1** At the user-level EXEC prompt (>), enter the **enable** command. The EXEC command interpreter prompts you for a privileged-level password, as follows:

```
Router> enable
```

```
Password:
```

**Step 2** Enter the password (the password is case sensitive). For security purposes, the password is not displayed.

**Step 3** When you enter the correct password, the system displays the privileged-level system prompt (#) as follows:

```
Router#
```

The pound sign (#) at the system prompt indicates that you are at the privileged level of the EXEC command interpreter; you can now execute the EXEC-level commands that are described in the following sections.

## Using the Ping Command

Before you attempt to upload or retrieve a file from a remote host, ensure that the connection is good between the router and the remote server. The *packet internet groper* (ping) program sends a series of echo request packets to the remote device and waits for a reply. If the connection is good, the remote device echoes them back to the local device.

The console terminal displays the results of each message sent: an exclamation point (!) indicates that the local device received an echo, and a period (.) indicates that the server timed out while awaiting the reply. If the connection between the two devices is good, the system will display a series of exclamation points (! ! !) or [ok]. If the connection fails, the system will display a series of periods ( . . . ) or [timed out] or [failed].

To verify the connection between the router and a remote host, issue the **ping** command followed by the name or Internet Protocol (IP) address of the remote server, then press **Return**. Although the **ping** command supports configurable options, the defaults, including interface processor as the protocol, are enabled when you enter a host name or address on the same line as the **ping** command. For a description of the configurable options, refer to the appropriate software documentation.

The following example shows a successful ping:

```
Router# ping 1.1.1.1
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 1.1.1.1, timeout is 2 seconds:
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 12/12/12 ms
Router#
```

The following example shows the results of a failed ping:

```
Sending 5, 100-byte ICMP Echos to 1.1.1.1, timeout is 2 seconds:
.....
Success rate is 0 percent (0/5)
Router#
```

If the connection fails, check the physical connection to the remote file server and verify that you are using the correct address or name, then ping the server again. If you are unable to establish a good connection, contact your network administrator or refer to the end of this document for instructions on contacting technical assistance.

## Uploading (Copying) the Configuration File

Before you upload (copy) the running configuration to the TFTP file server, ensure the following:

- You have a connection to the router either with a console terminal connected to the RSP1 console port, or remotely through a Telnet session.
- The router is connected to a network supporting a file server (remote host).
- The remote host supports the TFTP application.
- You have the interface processor address or name of the remote host available.

To store information on a remote host, enter the privileged EXEC command **write network**. The command will prompt you for the destination host's address and a filename, then display the instructions for confirmation. When you confirm the instructions, the router sends a copy of the currently running configuration to the remote host. The system default is to store the configuration in a file called by the name of the router with *-config* appended. You can either accept the default filename by pressing **Return** at the prompt, or enter a different name before pressing **Return**.

Follow these steps to upload (copy) the currently running configuration to a remote host:

- 
- Step 1** The system prompt should display a pound sign (#) to indicate the privileged level of the EXEC command interpreter. If it does not, follow the steps in the [“Using the EXEC Command Interpreter” section on page 9](#) to enable the privileged level.
- Step 2** Use the **ping** command to check the connection between the router and the remote host. (See the [“Using the Ping Command” section on page 10](#).)
- Step 3** Issue the **write term** command to display the currently running configuration on the terminal, and ensure that the configuration information is complete and correct. If it is not, use the **configure** command to add or modify the existing configuration. (Refer to the appropriate software documentation for descriptions of the configuration options available for the system and individual interfaces, and for specific configuration instructions.)
- Step 4** Issue the **write net** command. The EXEC command interpreter will prompt you for the name or interface processor address of the remote host that is to receive the configuration file. (The prompt might include the name or address of a default file server.)
- ```
Router# write net
Remote host []?
```
- Step 5** Enter the name or interface processor address of the remote host. In the following example, the name of the remote server is *servername*:
- ```
Router# write net
Remote host []? servername
Translating "servername"...domain server (1.1.1.1) [OK]
```
- Step 6** The EXEC command interpreter will prompt you for the name of the file that will contain the configuration. By default, the system appends *-config* to the router's name to create the new filename. Press **Return** to accept the default filename, or enter a different name for the file before pressing **Return**. In the following example, the default is accepted:
- ```
Name of configuration file to write [Router-config]?
Write file Router-config on host 1.1.1.1? [confirm]
Writing Router-config .....
```
- Step 7** Before the router executes the copy process, it displays the instructions you entered for confirmation. If the instructions are not correct, enter **n** (no) then **Return** to abort the process. To accept the instructions, press **Return** or **y** then **Return**, and the system will begin the copy process. In the following example, the default is accepted:
- ```
Write file Router-config on host 1.1.1.1? [confirm]
Writing Router-config: !!!! [ok]
```

While the router copies the configuration to the remote host, it displays a series of exclamation points (! !) or periods (. . .). The !!!! and [ok] indicate that the operation is successful. A display of . . . [timed out] or [failed] indicates a failure, which would probably be due to a network fault or the lack of a writable, readable file on the remote file server.

- Step 8** If the display indicates that the process was successful (with the series of ! ! ! and [ok]), the upload process is complete. The configuration is safely stored in the temporary file on the remote file server. If the display indicates that the process failed (with the series of . . . as shown in the following example):

```
Writing Router-config . . . . .
```

your configuration was not saved. Repeat the preceding steps, or select a different remote file server and repeat the preceding steps.

After you upload the configuration file, proceed to [““Removing the RSP1” section on page 15](#). If you are unable to copy the configuration to a remote host successfully, contact your network administrator or refer to the end of this document for instructions on contacting technical assistance.

## Downloading (Retrieving) the Configuration File

After you install the new RSP1, you can retrieve the saved configuration and copy it to NVRAM. To retrieve the configuration, enter configuration mode and specify that you will configure the router from the network. The system will prompt you for a host name and address, the name of the configuration file stored on the host, and confirmation to reboot using the remote file.

You can access the router through a console terminal attached directly to the RSP1 console port, or you can configure an interface port and Telnet to the router from a remote terminal.

Follow these steps to download (retrieve) the currently running configuration from a remote host:

- Step 1** On the console terminal, the system prompt should display a pound sign (#) to indicate the privileged level of the EXEC command interpreter. If it does not, follow the steps in the [“Using the EXEC Command Interpreter” section on page 9](#) to enable the privileged level.



**Note** Until you retrieve the previous configuration, the router will be running from the default configuration in NVRAM. Therefore, any passwords that were configured on the previous system will not be valid until you retrieve the configuration.

- Step 2** Use the **ping** command to verify the connection between the router and the remote host. (See the [“Using the Ping Command” section on page 10](#).)
- Step 3** At the system prompt, issue the **configure network** command and press **Return** to enter the configuration mode and specify that you will configure the system from a network device (instead of from the console terminal, which is the default).
- ```
Router# configure network
```
- Step 4** The system will ask you to select a host or network configuration file. The default is host; press **Return** to accept the default.
- ```
Host or network configuration file [host]?
```
- Step 5** The system will prompt you for the interface processor address of the host. Enter the interface processor address or name of the remote host (the remote file server to which you uploaded the configuration file).
- ```
IP address of remote host [255.255.255.255]? 1.1.1.1
```

- Step 6** The system will prompt you for the name of the configuration file. When uploading the file, the default is to use the name of the router with the suffix *-cfg* (*router-cfg* in the following example). If you specified a different filename when you uploaded the configuration, enter the filename; otherwise, press **Return** to accept the default.

```
Name of configuration file [router-cfg]?
```

- Step 7** Before the system reboots with the new configuration, it displays the instructions you entered for confirmation. If the instructions are not correct, enter **n** (no) then press **Return** to cancel the process. To accept the instructions, press **Return**, or **y** then **Return**.

```
Configure using router-cfg from 1.1.1.1? [confirm]
Booting router-cfg from 1.1.1.1: !! [OK - 874/16000 bytes]
```

While the router retrieves and boots from the configuration on the remote host, the console display indicates whether or not the operation was successful. A series of !!!! and [OK] (as shown in the preceding example) indicates that the operation was successful. A series of . . . and [timed out] or [failed] indicate a failure (which would probably be due to a network fault or an incorrect server name, address, or filename). The following is an example of a failed attempt to boot from a remote server:

```
Booting Router-cfg . . . . [timed out]
```

- Step 8** If the display indicates that the process was successful, proceed to the next step.
- If the display indicates that the process failed, verify the name or address of the remote server and the filename, and repeat the preceding steps. If you are unable to retrieve the configuration, contact your network administrator or refer to the end of this document for instructions on contacting technical assistance.
- Step 9** Issue the **write term** command to display the currently running configuration on the terminal. Review the display and ensure that the configuration information is complete and correct. If it is not, verify the filename and repeat the preceding steps to retrieve the correct file, or use the **configure** command to add or modify the existing configuration. (Refer to the appropriate software documentation for descriptions of the configuration options available for the system and individual interfaces and specific configuration instructions.)
- Step 10** When you have verified that the currently running configuration is correct, issue the **copy running-config startup-config** command to save the retrieved configuration in NVRAM. Otherwise, the new configuration will be lost if you restart the system. This completes the procedure for downloading (retrieving) the configuration file.

## Installation

The following sections provide a functional overview of online insertion and removal (OIR), and describe the procedures for installing or replacing processor modules. Before installing any new interfaces, ensure that your system meets the minimum software and microcode requirements described in the [“Software Prerequisites” section on page 8](#) and the [“Microcode Prerequisites” section on page 8](#).

The OIR feature allows you to remove and install interface processors without turning off system power. However, *you must shut down the system before removing or installing the RSP1*, which is a required system component.



### Caution

To avoid unnecessary errors, read the following OIR overview before removing or replacing an RSP1.

Following the OIR overview, proceed to the [“Removing the RSP1” section on page 15](#) for instructions on removing the RSP1, and then to the [“Replacing the RSP1” section on page 16](#) for the installation instructions. After the new RSP1 is secure, follow the procedures in the [“Troubleshooting the Installation” section on page 19](#) to verify that it is installed and functioning properly.

## Online Insertion and Removal—An Overview

OIR allows you to remove and replace CyBus interface processors while the system is operating; you do not need to notify the software or shut down the system power. This section describes the mechanical functions of the system components and stresses the importance of following the correct procedures to avoid unnecessary restarts or card failures. This section is for background information only. Subsequent sections provide specific procedures for removing and installing an RSP1.



### Caution

---

All CyBus interface processors support OIR; however, *you must shut down the system before removing or installing the RSP1*, which is a required system component. Removing an RSP1 while the system is operating will cause the system to shut down or crash, and might damage or destroy memory files.

---

Each RSP1 and interface processor contains a bus connector with which it connects to the system backplane. The bus connector is a set of tiered pins, in three lengths. The pins send specific signals to the system as they make contact with the backplane.

The system assesses the signals it receives and the order in which it receives them to determine what event is occurring and what task it needs to perform, such as reinitializing new interfaces or shutting down removed ones. For example, when you insert an interface processor, the longest pins make contact with the backplane first, and the shortest pins make contact last. The system recognizes the signals and the sequence in which it receives them. The system expects to receive signals from the individual pins in this logical sequence, and the ejector levers help to ensure that the pins mate in this sequence.

When you remove or insert an interface processor, the backplane pins send signals to notify the system, which then performs as follows:

1. Rapidly scans the backplane for configuration changes and does not reset any interfaces.
2. Initializes all newly inserted interface processors, noting any removed interfaces and placing them in the administratively shutdown state.
3. Brings all previously configured interfaces on the interface processor back to the state they were in when they were removed. Any newly inserted interfaces are put in the administratively shutdown state, as if they were present (but unconfigured) at boot time. If a similar interface processor type has been reinserted into a slot, then its ports are configured and brought online up to the port count of the original interface processor.

OIR functionality enables you to add, remove, or replace interface processors with the system online, which provides a method that is seamless to end users on the network, maintains all routing information, and ensures session preservation.

When you insert a new interface processor, the system runs a diagnostic test on the new interfaces and compares them to the existing configuration.

If this initial diagnostic test fails, the system remains off line for another 15 seconds while it performs a second set of diagnostic tests to determine whether or not the interface processor is faulty and if normal system operation is possible.

If the second diagnostic test passes, which indicates that the system is operating normally and the new interface processor is faulty, the system resumes normal operation but leaves the new interfaces disabled. If the second diagnostic test fails, the system crashes, which usually indicates that the new interface processor has created a problem on the bus and should be removed.

The system brings online only interfaces that match the current configuration and were previously configured as up; all other interfaces require that you configure them with the **configure** command. On interface processors with multiple interfaces, only the interfaces that have already been configured are brought online.

For example, if you replace a single-PCA CIP with a dual-PCA CIP, only the previously configured interface is brought online automatically; the new interface remains in the administratively shutdown state until you configure it and bring it online.



**Caution**

When removing or replacing interface processors, you can avoid erroneous failure messages by allowing at least 15 seconds for the system to reinitialize before removing or inserting another interface processor.

## Removing the RSP1

When you remove or install the RSP1, be sure to use the ejector levers, which help to ensure that the RSP1 is fully inserted in the backplane or fully dislodged from it. Any RSP1 or interface processor that is only partially connected to the backplane can halt the system. [Figure 3](#) shows a detail of the ejector lever mechanism in a horizontal position that is appropriate for the Cisco 7505. When you simultaneously push the ejector levers inward (toward the carrier handle), the levers push the RSP1 into the slot and ensure that the board connectors are fully seated in the backplane.



**Caution**

You must shut down the system before removing or installing the RSP1, which is a required system component. Removing an RSP1 while the system is operating will cause the system to shut down or crash and might damage or destroy memory files.

Follow these steps to remove the RSP1:

- Step 1** Optional step: If you are replacing the RSP1, upload (copy) the currently running configuration file to a TFTP server so you can retrieve it later. (See the [“Saving and Retrieving the Configuration File” section on page 9](#).)
- Step 2** Slip on an antistatic strap and connect the equipment end of the strap to a captive installation screw on an installed interface processor, or to the chassis ground screw that is located to the left of the power receptacle. (See [Figure 1](#).)
- Step 3** If you are replacing the RSP1, disconnect any devices that are attached to the console or auxiliary ports. If you are removing the RSP1 for maintenance and will reinstall the same one, you can leave the devices attached provided that doing so will not strain the cables.
- Step 4** Use a screwdriver (number 2 Phillips or 1/4-inch flat-blade) to loosen the two captive installation screws. (See [Figure 3](#).)
- Step 5** Place your thumbs on the ends of each of the ejectors and simultaneously pull them both outward, away from the carrier handle (in the opposite direction from that shown in [c in Figure 3](#)) to release the carrier from the slot and to dislodge the RSP1 from the backplane.

**Step 6** Grasp the handle with one hand and pull the RSP1 straight out of the slot, keeping your other hand under the carrier to guide it. (See [Figure 3](#).) Keep the carrier at a 90-degree orientation to the backplane. Avoid touching the board or any connector pins.

**Step 7** Place the removed RSP1 on an antistatic mat or foam. If you plan to return the RSP1 to the factory, immediately place it in an antistatic bag to prevent ESD damage.

This completes the removal procedure.

If you removed the RSP1 to replace SIMMs, proceed to the appropriate section.

If you are replacing the RSP1, proceed to the next section to install the new RSP1.

## Replacing the RSP1

Ensure that all system power is turned off before installing the RSP1 in the chassis. The RSP1 is keyed for installation only in the RSP1 slot. (See [Figures 1 and 2](#).)

Follow these steps to install an RSP1:

---


**Step 1** Ensure that all power supplies are turned OFF.

**Step 2** Grasp the RSP1 handle with one hand and place your other hand under the carrier to support and guide it into the slot. (See [Figure 3](#).) Avoid touching the board or any connectors.

**Step 3** Place the back of the RSP1 in the top slot and align the notches along the edge of the carrier with the grooves in the slot. (See [Figure 3](#).)



**Figure 3** Ejector Levers and Captive Installation Screw



**Caution**

To prevent damage to the backplane, you must install the RSP1 in the top slot of the Cisco 7505. (See [Figure 2](#).) The slots are keyed for correct installation. Forcing the RSP1 into a different slot can damage the backplane and the RSP1.

**Step 4**

While keeping the RSP1 at a 90-degree orientation to the backplane, carefully slide the carrier into the slot until the RSP1 faceplate makes contact with the ejector levers, then *stop*. (See [b](#) in [Figure 3](#).)

- Step 5** Using the thumb and forefinger of each hand to pinch each ejector, simultaneously push both ejectors inward (toward the handle) until they are at a full 90-degree orientation to the faceplate. (See c in [Figure 3](#).)
- Step 6** Use a screwdriver (number 2 Phillips or 1/4-inch flat-blade) to tighten the captive installation screws on the ends of the RSP1. (See a in [Figure 3](#).)
- Step 7** Use a screwdriver to tighten the two captive screws on the RSP1 faceplate to prevent the RSP1 from becoming partially dislodged from the backplane and to ensure proper EMI shielding. (These screws must be tightened to meet EMI specifications.)
- Step 8** If you disconnected the console terminal to remove the RSP1, or if you are installing a new RSP1, connect the console terminal to the console port.
- Step 9** Ensure that the console terminal is turned on.
- Step 10** Turn the system power back ON, and proceed to the next section to check the installation.

## Restarting the System

When you turn the system power back on, verify that the system boots and resumes normal operation. If you are restarting the system after upgrading the DRAM expect that it will take the system longer to complete the memory initialization portion of the boot sequence with more DRAM. (See the [“System Startup Sequence”](#) section on page 20.)

Follow these steps to verify that the RSP1 is installed and functioning properly:

- 
- Step 1** Check the RSP1 connections to make sure they are secure:
    - The RSP1 is inserted all the way into its slot, and both of the captive installation screws are tightened.
    - The console terminal is turned on and is connected to the console port.
  - Step 2** Observe the RSP1 LEDs. While the system initializes, the yellow boot error LED on the RSP1 stays on, then goes off when the boot is complete. As the RSP1 initializes each interface processor, the status LEDs on each interface processor go on and off in irregular sequence.
  - Step 3** Verify that the console terminal displays the system banner and startup screen as the system restarts. The display should look similar to the following:
 

```
GS Software (GS7), Version 10.3(3), SOFTWARE
Copyright (c) 1986-1995 by cisco Systems, Inc.
Compiled Wed 10-May-95

System Bootstrap, Version 4.6(7.3)

Current date and time is Sat 5-13-1995 21:38:35
Boot date and time is Thur 5-11-1995 15:32:28
[displayed text omitted from this example]
```
  - Step 4** After the system boots the software and initializes the interface processors (approximately 30 seconds for systems with 16 MB of DRAM, and approximately 2 minutes for systems with 64 MB of DRAM), verify that the RSP1 LEDs are in the following states:
    - RSP1 normal LED is on
    - CPU halt LED is off
    - Boot error LED is off
  - Step 5** Verify that all the enabled LEDs (on the interface processors) are on.

When you have verified all the conditions in [Step 2](#) through [Step 5](#), the installation is complete.

If you replaced the RSP1 and saved your configuration file to a remote server before doing so, proceed to the [“Downloading \(Retrieving\) the Configuration File”](#) section on [page 12](#). If you replaced the RSP1 and did not save the configuration, use the **configure** command or the **setup** command facility to reenter the configuration information. Refer to the appropriate software documentation for command descriptions and instructions for using them.

An error condition exists if no LEDs go on at power up or after initialization, or if the boot error or CPU halt LEDs go on and remain on. If this happens, proceed to the [“Troubleshooting the Installation”](#) section on [page 19](#) to try to isolate the problem.

## Troubleshooting the Installation

This section contains procedures to follow if the system does not restart and boot as expected. Review the descriptions that follow so you can anticipate the expected system startup sequence. Then restart the system and try to isolate the problem by observing the LEDs as the system attempts to boot the software and initialize the RSP1 and each interface processor.

### Verifying LEDs

Following are functional descriptions of the LEDs on the power supplies and processor modules, and the behavior you should observe at system startup.

#### System Power LEDs

On the Cisco 7505, the DC OK LED is located on the lower right of the interface processor end of the chassis and is labeled DC OK. (See [Figure 1](#).) If the DC OK LED does not go on or stay on, there is most likely a problem with the input power or one of the internal DC lines.


The DC OK LED will not go on or will go off if the power supply reaches an out-of-tolerance temperature or voltage condition. It is unlikely that the power supply will shut down during startup because of an overtemperature condition; however, it can shut down if it detects an over or undervoltage condition during startup. For descriptions of environmental monitoring functions, refer to the *Cisco 7505 Hardware Installation and Maintenance* publication.

#### RSP1 LEDs

[Figure 4](#) shows the LEDs and reset switch on the RSP1 faceplate. The LEDs on the RSP1 indicate the system and RSP1 status and which Flash memory card slot is active. The CPU halt LED, which goes on only if the system detects a processor hardware failure, should remain off. A successful boot is indicated when the normal LED goes on; however, this does not necessarily mean that the system has reached normal operation. During normal operation, the CPU halt LED should be off, and the normal LED should be on.

The slot 0 and slot 1 LEDs indicate which PCMCIA (Flash memory) card slot is in use, and each LED blinks when the card is accessed by the system.

Figure 4 Route Switch Processor LEDs



The reset switch (see Figure 4) resets the RSP1 and the entire system. To prevent system errors and problems, use it *only* at the direction of your service representative.

## Interface Processor LEDs

Each interface processor contains an enabled LED. The enabled LED goes on to indicate that the interface processor is operational and that it is powered up. It does not necessarily mean that the interface ports on the interface processors are functional or enabled. When the boot sequence is complete, all of the enabled LEDs should go on. If any do not, one of the following errors is indicated:

- The interface processor is not installed correctly (it is not fully seated in the backplane connector).
- The microcode and software that are loading at startup are not compatible.
- The interface processor has failed.

## System Startup Sequence

By checking the state of the LEDs, you can determine when and where the system failed in the startup sequence. Because you turn on the system power with the on/off switches on each power supply, it is easiest to observe the startup behavior from the rear of the chassis. Use the following descriptions of the normal startup sequence to isolate the problem, then use the troubleshooting procedures wherever the system fails to operate as expected. If you are able to isolate the problem to a faulty hardware component, or if you are unable to successfully restart the system, refer to the end of this document for instructions on contacting a service representative.



Note

The time required for the system to initialize (boot) varies with different router configurations and the amount of memory that must be initialized. During the system startup sequence, the time required to initialize the memory (not necessarily the entire boot sequence) in a system that contains 128 MB of DRAM will be longer than in a system that contains 16 MB of DRAM.

During the boot sequence, the system banner display pauses while it initializes the memory. If your router has more than 16 MB of DRAM, you may notice an increase in the amount of time required to initialize the memory. The pause in the banner display occurs after the copyright line, and before the system displays the list of installed hardware, as shown in the following display:

```
%SYS-5-RELOAD: Reload requested
System Bootstrap, Version 4.6(7.3)
Copyright (c) 1986-1995 by cisco Systems, Inc.
```

[System initializes memory at this point in the display]

**Note**

The procedures in this section are based on the assumption that your system was operating correctly until you removed (or replaced) the RSP1. If the following sequence indicates a new problem with the power subsystem or one of the interface processors, refer to the *Cisco 7505 Hardware Installation and Maintenance* publication for system startup troubleshooting procedures.

Use the following startup sequences and troubleshooting procedures to isolate system problems:

1. When you restart up the system, the system power the DC OK LED should go on.
  - If the system power LED remains off, the RSP1 is probably not fully inserted and connected to the backplane. Loosen the captive installation screws on the RSP1, then use the ejector levers to release the RSP1 and reseal it in the backplane. (For a description and illustration of the ejector levers, refer to the “[Removing the RSP1](#)” section on page 15.) Tighten both captive installation screws.
 

If the LED on the power supply still fails to go on as expected, a power supply or input power failure could be the problem. Before contacting a service representative, refer to the *Cisco 7505 Hardware Installation and Maintenance* publication for power subsystem troubleshooting procedures.
  - If the system power LED goes on, the power source is good and the power supply is functional. When the system power LED indicates normal operation, proceed to number 2.
2. Listen for the fans. You should hear them start operating immediately after you turn on the system power. If you determine that the power supply is functioning normally and that a fan (or the fan array) is faulty, contact a service representative. If the fan array does not function properly at initial startup, you cannot make any installation adjustments.
3. When you have verified that the power supply is functioning properly, observe the LEDs on the RSP1. The CPU halt LED on the RSP1 should always remain off. If it goes on during the startup sequence, the system has encountered a processor hardware error.
  - Use the **show config** command to check the configuration register settings.
  - If the CPU halt LED goes on during a second startup attempt, suspect a processor hardware error and contact a service representative.
4. During the boot process, the LEDs on most of the interfaces light in irregular sequence; this does not indicate either correct system startup or failure.
5. When the system boot is complete, the RSP1 begins to initialize the interface processors. During this initialization, the LEDs on each interface processor behave differently (most flash on and off). The enabled LED on each interface processor goes on when initialization has been completed.
  - If the enabled LEDs on the interface processors go on, the system has booted successfully and is now functional.
  - If the RSP1 LEDs previously indicated a successful system boot, but none of the enabled LEDs on the interface processors go on, suspect that one of them has shifted out of its backplane connector and halted the system. Use the ejector levers to release the interface processor and reseal it in the backplane. (For an illustration of the ejector levers, refer to [Figure 3](#).) Tighten both captive installation screws.
  - If the enabled LED on a single interface processor remains off, suspect that the interface processor has shifted out of its slot. Use the ejector levers to release the interface processor and reseal it in the backplane. (For an illustration of the ejector levers, refer to [Figure 3](#).) Tighten both captive installation screws. After the system reinitializes the interfaces, the enabled LED on the interface processor should go on.

- If an enabled LED still fails to go on after performing these steps, suspect that the specific interface processor has failed.
6. When the system boot is complete and all interface processors have been initialized, the console screen displays a script and system banner similar to the following:

```
GS Software (GS7), Version 10.3(3)
Copyright (c) 1986-1995 by Cisco Systems, Inc.
Compiled Wed 10-May-95 11:06
```

- If all the previous conditions are met and this banner is displayed, the system startup was successful and your installation is complete.
- If an error message is displayed on the terminal, refer to the appropriate software publication for error message definitions.
- If the console screen is blank, check the terminal and ensure that it is turned on and that the console cable is correctly connected between the terminal and the console port on the RSP1.
- Check the terminal settings and ensure that the terminal is set for 9600 baud, 8 data bits, no parity, and 2 stop bits.
- If the terminal is set correctly and still fails to operate, suspect that the terminal is faulty. Connect a different terminal and restart the system.

If the system still fails to start up or operate properly, or if you isolate the cause of the problem to a failed component, contact a service representative for further assistance. This completes the RSP1 installation and replacement procedure. For complete command descriptions and examples, refer to the appropriate software documentation.

## Reference Information

Following is reference information for replacing SIMMs, configuring the software configuration register, recovering a lost password, and using the front-panel PCMCIA slots for additional Flash memory.

## Console Port Signals

The console port on the RSP1 is an EIA/TIA-232, DCE, DB-25 receptacle. Both DSR and DCD are active when the system is running. The RTS signal tracks the state of the CTS input. The console port does not support modem control or hardware flow control. The console port requires a straight-through EIA/TIA-232 cable. [Table 2](#) lists the signals used on this port.

*Table 2 Console Port Signals*

| Pin | Signal | Direction | Description                     |
|-----|--------|-----------|---------------------------------|
| 1   | GND    | —         | Ground                          |
| 2   | TxD    | <—        | Transmit Data                   |
| 3   | RxD    | —>        | Receive Data                    |
| 6   | DSR    | —>        | Data Set Ready (always on)      |
| 7   | GND    | —         | Ground                          |
| 8   | DCD    | —>        | Data Carrier Detect (always on) |

## Auxiliary Port Signals

The auxiliary port on the RSP1 is an EIA/TIA-232 DTE, DB-25 plug to which you can attach a CSU/DSU or other equipment in order to access the router from the network. [Table 3](#) lists the EIA/TIA-232 signals used on this port.

The asynchronous auxiliary port supports hardware flow control and modem control.

**Table 3** *Auxiliary Port Signals*

| Pin | Signal        | Direction | Description                                       |
|-----|---------------|-----------|---------------------------------------------------|
| 2   | TxD           | —>        | Transmit Data                                     |
| 3   | RxD           | <—        | Receive Data                                      |
| 4   | RTS           | —>        | Request To Send (used for hardware flow control)  |
| 5   | CTS           | <—        | Clear To Send (used for hardware flow control)    |
| 6   | DSR           | <—        | Data Set Ready                                    |
| 7   | Signal Ground | —         | Signal Ground                                     |
| 8   | CD            | <—        | Carrier Detect (used for modem control)           |
| 20  | DTR           | —>        | Data Terminal Ready (used for modem control only) |

## Replacing and Upgrading DRAM SIMMs

The system DRAM resides on up to four SIMMs on the RSP1. The DRAM SIMM sockets are U4 and U12 for bank 0, and U18 and U25 for bank 1. The default DRAM configuration is 16 MB (two 8-MB SIMMs in bank 0). (See [Figure 5](#).)




### Note

The total number of memory devices per SIMM differs for each manufacturer. The SIMMs in the following illustrations are generic representations of the actual DRAM SIMMs for your RSP1. To be assured that you are using the correct SIMMs, refer to your specific DRAM upgrade requirements.

This section describes the steps for increasing the amount of DRAM by replacing up to four SIMMs that you obtain from an approved vendor.

Figure 5 RSP1 DRAM SIMMs



The SIMM sockets use the thumb tabs that are often used in PCs and other computer equipment. Each RSP1 SIMM socket has two metal retaining springs, one at each end. (See Figure 6.) When a SIMM is fully seated in the socket, the retaining springs snap over the ends of the SIMM to lock it in the socket.

Before proceeding, ensure that you have the proper ESD-prevention equipment available. To upgrade DRAM, install SIMMs in one or two banks. Table 4 lists the various configurations of DRAM SIMMs that are available. Note which banks are used given the combinations of available SIMM sizes and the maximum DRAM you require. SIMMs must be 60 ns or faster and no taller than one inch.

**Note**

Depending on your router configuration, Cisco IOS Release 11.1(1) might require more than 16 MB of DRAM for your RSP7000. Upgrade your system DRAM based on your current configuration and this potential requirement.

Table 4 DRAM SIMM Configurations

| DRAM Bank 0 | Quantity      | DRAM Bank 1 | Quantity     | Total DRAM         | Product Numbers |
|-------------|---------------|-------------|--------------|--------------------|-----------------|
| U4 and U12  | 2 8-MB SIMMs  | U18 and U25 | —            | 16 MB              | MEM-RSP-16M     |
| U4 and U12  | 2 8-MB SIMMs  | U18 and U25 | 2 4-MB SIMMs | 24 MB <sup>1</sup> | MEM-RSP-24M     |
| U4 and U12  | 2 16-MB SIMMs | U18 and U25 | —            | 32 MB              | MEM-RSP-32M(=)  |
| U4 and U12  | 2 32-MB SIMMs | U18 and U25 | —            | 64 MB              | MEM-RSP-64M(=)  |
| U4 and U12  | 2 32-MB SIMMs | U18 and U25 | 2 2-MB SIMMs | 128 MB             | MEM-RSP-128M(=) |

1. The 24-MB DRAM configuration is also available as an 8-MB upgrade to the standard 16-MB configuration, by adding DRAM-Product Number MEM-RSP-8M= (consisting of two, 4-MB DRAM SIMMs), for a total of 24 MB.



**Caution**

---

To prevent DRAM errors, each DRAM bank used must contain no fewer than two SIMMs of the same type. You must install either two SIMMs in bank 0 or four SIMMs in two banks.

---

## Removing SIMMs

Place removed SIMMs on an antistatic mat and store them in an antistatic bag. You can use the SIMMs that you remove in compatible equipment.

**Caution**

---


To prevent ESD damage, handle SIMMs by the card edges only.

---

Follow these steps to remove the existing SIMMs:

- 
- Step 1** Turn OFF the system power and follow the steps in the [“Removing the RSP1” section on page 15](#).
  - Step 2** Place the RSP1 on an antistatic mat or pad, and ensure that you are wearing an antistatic device, such as a wrist strap. Position the RSP1 so that the handle is away from you and the edge connector is toward you—opposite of the position shown in [Figure 2](#).
  - Step 3** Locate the SIMMs. The DRAM SIMMs occupy U4 and U12 in bank 0, and U18 and U25 in bank 1. (See [Figure 2](#).)
  - Step 4** Release the spring clips from the SIMM that you want to remove and release the SIMM from the socket. (See [Figure 6](#).)

**Figure 6** Releasing the SIMM Spring Clips



- Step 5** When both ends of the SIMM are released from the socket, grasp the ends of the SIMM with your thumb and forefinger and pull the SIMM completely out of the socket. Handle the edges of the SIMM only; avoid touching the memory module or pins, and the metal traces, or *fingers*, along the socket edge.
- Step 6** Place the SIMM in an antistatic bag to protect it from ESD damage.
- Step 7** Repeat Steps 4 through 6 for the remaining SIMMs, as required for your upgrade.
- This completes the SIMM removal procedure. Proceed to the next section to install the new SIMMs.

## Installing New SIMMs

Following is the procedure for installing new SIMMs.




### Caution

SIMMs are sensitive components that are susceptible to ESD damage. Handle SIMMs by the edges only; avoid touching the memory modules, pins, or traces (the metal fingers along the connector edge of the SIMM). (See [Figure 7](#).)

**Figure 7 Handling a SIMM**

\*



Follow these steps to install the new SIMMs:

- 
- Step 1** Ensure that the RSP1 is in the same orientation as the previous procedure (with the handle away from you and the edge connector toward you).
- Step 2** Remove a new SIMM from the antistatic bag.
- Step 3** Hold the SIMM component side up, with the connector edge (the metal fingers) closest to you. Hold the sides of the SIMM between your thumb and middle finger, with your forefinger against the far edge, opposite the connector edge. (See [Figure 7](#).)
- Step 4** Tilt the SIMM to approximately the same angle as the socket and insert the entire the connector edge into the socket. (Install the first SIMM in the slot farthest away from you. Install the last SIMM in the slot closest to you.)



**Caution**

When inserting SIMMs, use firm but not excessive pressure. If you damage a socket, you will have to return the RSP1 to the factory for repair.

- 
- Step 5** Gently push the SIMM into the socket until the spring clips snap over the ends of the SIMM. If necessary, rock the SIMM gently back and forth to seat it properly.
- Step 6** Repeat Steps 2 through 5 for the remaining SIMMs.
- Step 7** When all SIMMs are installed, check all alignment holes (two on each SIMM) and ensure that the spring retainer is visible. If it is not, the SIMM is not seated properly. If any SIMM appears misaligned, carefully remove it and reseat it in the socket. Push the SIMM firmly back into the socket until the retainer springs snap into place.

If the system fails to boot properly, or if the console terminal displays a checksum or memory error, check the following:

- Ensure that all SIMMs are installed correctly. If necessary, shut down the system and remove the RSP1. Check the SIMMs by looking straight down on them and then inspecting them at eye level. The SIMMs should all be aligned at the same angle and the same height when properly installed. If a SIMM appears to stick out or rest in the socket at a different angle from the others, remove the SIMM and reinsert it. Then replace the RSP1 and reboot the system for another installation check.
- Each DRAM SIMM bank must contain SIMMs of the same size and speed or the system will not operate. SIMMs must be 60 ns or faster. The speed is printed along one edge of the SIMM.

If after several attempts the system fails to restart properly, contact a service representative for assistance. Before you call, make note of any error messages, unusual LED states, or any other indications that might help solve the problem.

**Note**

The time required for the system to initialize varies with different router configurations. Routers with 128 MB of DRAM will take longer to boot than those with 16 MB of DRAM.

This completes the SIMM replacement procedure.

To replace the RSP1 in the chassis, proceed to the “[Replacing the RSP1](#)” section on page 16, and then restart the system for an installation check.

## Software Configuration Register Settings

Settings for the 16-bit software configuration register are written into the NVRAM. Following are some reasons for changing the software configuration register settings:

- To select a boot source and default boot filename.
- To enable or disable the Break function.
- To control broadcast addresses.
- To set the console terminal baud rate.
- To load operating software from Flash memory.
- To enable booting from a Trivial File Transfer Protocol (TFTP) server.
- To recover a lost password.
- To allow you to manually boot the system using the **b** command at the bootstrap program prompt.
- To force the router to boot automatically from the system bootstrap software (boot image) or from its default system image in onboard Flash memory, and read any **boot system** commands that are stored in the configuration file in NVRAM. If the router finds no **boot system** commands, it uses the configuration register value to form a filename from which to netboot a default system image stored on a network server. (See [Table 7](#).)

[Table 5](#) lists the meaning of each of the software configuration memory bits, and [Table 6](#) defines the boot field.

**Caution**

To avoid confusion and possibly halting the router, remember that valid configuration register settings might be combinations of settings and not just the individual settings listed in [Table 5](#). For example, the factory default value of 0x0101 is a combination of settings.

**Table 5** *Software Configuration Register Bit Meanings*

| Bit Number <sup>1</sup> | Hexadecimal      | Meaning                                         |
|-------------------------|------------------|-------------------------------------------------|
| 00 to 03                | 0x0000 to 0x000F | Boot field (see <a href="#">Table 6</a> )       |
| 06                      | 0x0040           | Causes system software to ignore NVRAM contents |
| 07                      | 0x0080           | OEM <sup>2</sup> bit enabled                    |
| 08                      | 0x0100           | Break disabled                                  |
| 09                      | 0x0200           | Use secondary bootstrap                         |
| 10                      | 0x0400           | Internet Protocol (IP) broadcast with all zeros |
| 11 to 12                | 0x0800 to 0x1000 | Console line speed (default is 9600 baud)       |

**Table 5** *Software Configuration Register Bit Meanings (continued)*

| Bit Number <sup>1</sup> | Hexadecimal | Meaning                                              |
|-------------------------|-------------|------------------------------------------------------|
| 13                      | 0x2000      | Boot default Flash software if network boot fails    |
| 14                      | 0x4000      | IP broadcasts do not have network numbers            |
| 15                      | 0x8000      | Enable diagnostic messages and ignore NVRAM contents |

1. The factory default value for the configuration register is 0x0101. This value is a combination of the following: bit 8 = 0x0100 and bits 00 through 03 = 0x0001 (see [Table 6](#)).
2. OEM = original equipment manufacturer.

**Table 6** *Explanation of Boot Field (Software Configuration Register Bits 00 to 03)*

|          |                                                                                                                 |
|----------|-----------------------------------------------------------------------------------------------------------------|
| 00       | Stays at the system bootstrap prompt                                                                            |
| 01       | Boots the first system image in onboard Flash memory                                                            |
| 02 to 0F | Specifies a default netboot filename<br>Enables boot system commands that override the default netboot filename |
| 00       | Stays at the system bootstrap prompt                                                                            |

## Changing Settings

To change the configuration register while running the system software, follow these steps:

- 
- Step 1** Enter the **enable** command and your password to enter privileged level, as follows:
- ```
Router> enable
Password:
router#
```
- Step 2** At the privileged-level system prompt (router #), enter the **configure terminal** command. You will be prompted as shown in the following example:
- ```
Router# conf t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#
```
- Step 3** To set the contents of the configuration register, enter the **config-register value** configuration command, where *value* is a hexadecimal number preceded by 0x (see [Table 5](#)), as in the following:
- ```
Router(config)# config-register 0xvalue
```
- Step 4** Exit the configuration mode by entering **Ctrl-Z**. The new value settings will be saved to memory; however, the new settings do not take effect until the system software is reloaded by rebooting the router.
- Step 5** To display the configuration register value currently in effect and the value that will be used at the next reload, enter the **show version EXEC** command. The value will be displayed on the last line of the screen display, as in the example following:
- ```
Configuration register is 0x141 (will be 0x101 at next reload)
```

- Step 6** Reboot the router. The new value takes effect. Configuration register changes take effect only when the server restarts, such as when you switch the power off and on or when you issue a **reload** command from the console.

## Bit Meanings

The lowest four bits of the software configuration register (bits 3, 2, 1, and 0) form the *boot field*. (See [Table 6](#).) The boot field specifies a number in binary form. If you set the boot field value to 0, you must boot the operating system manually by entering the **b** command at the bootstrap prompt as follows:

```
> b [tftp] flash filename
```

Definitions of the various **b** command options follow:

- **b**—Boots the default system software from Flash memory
- **b flash**—Boots the first file in onboard Flash memory
- **b slot0: filename**—Boots the file *filename* from the Flash memory card in PCMCIA slot 0
- **b slot1: filename**—Boots the file *filename* from the Flash memory card in PCMCIA slot 1
- **b filename [host]**—Netboots from server *host* using TFTP
- **b flash: [filename]**—Boots the file *filename* from onboard Flash memory

For more information about the **b [tftp] flash [filename]** command, refer to the set of configuration fundamentals configuration and reference publications.

If you set the boot field value to *0x2* through *0xF* and there is a valid **boot system** command stored in the configuration file, then the router boots the system software as directed by that value. If you set the boot field to any other bit pattern, the router uses the resulting number to form a default boot filename for netbooting. (See [Table 7](#).)

In the following example, the software configuration register is set to boot the router from onboard Flash memory and to ignore Break at the next reboot of the router:

```
Router# conf term
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# config-register 0x102
Router(config)# boot system flash [filename]
Ctrl-z
Router#
```

The server creates a default boot filename as part of the automatic configuration processes. To form the boot filename, the server starts with the name *cisco* and adds the octal equivalent of the boot field number, a hyphen, and the processor-type name. [Table 7](#) lists the default boot filenames or actions for the processor.



### Note

A **boot system** configuration command in the router configuration in NVRAM overrides the default netboot filename.

**Table 7** Default Boot Filenames

| Action/File Name | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|------------------|-------|-------|-------|-------|
| Bootstrap mode   | 0     | 0     | 0     | 0     |
| Default software | 0     | 0     | 0     | 1     |

**Table 7** *Default Boot Filenames (continued)*

| Action/File Name | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|------------------|-------|-------|-------|-------|
| cisco2-RSP       | 0     | 0     | 1     | 0     |
| cisco3-RSP       | 0     | 0     | 1     | 1     |
| cisco4-RSP       | 0     | 1     | 0     | 0     |
| cisco5-RSP       | 0     | 1     | 0     | 1     |
| cisco6-RSP       | 0     | 1     | 1     | 0     |
| cisco7-RSP       | 0     | 1     | 1     | 1     |
| cisco10-RSP      | 1     | 0     | 0     | 0     |
| cisco11-RSP      | 1     | 0     | 0     | 1     |
| cisco12-RSP      | 1     | 0     | 1     | 0     |
| cisco13-RSP      | 1     | 0     | 1     | 1     |
| cisco14-RSP      | 1     | 1     | 0     | 0     |
| cisco15-RSP      | 1     | 1     | 0     | 1     |
| cisco16-RSP      | 1     | 1     | 1     | 0     |
| cisco17-RSP      | 1     | 1     | 1     | 1     |

Bit 8 controls the console Break key. Setting bit 8 (the factory default) causes the processor to ignore the console Break key. Clearing bit 8 causes the processor to interpret the Break key as a command to force the system into the bootstrap monitor, thereby halting normal operation. A break can be sent in the first 60 seconds while the system reboots, regardless of the configuration settings.

Bit 9 controls the secondary bootstrap program function. Setting bit 9 causes the system to use the secondary bootstrap; clearing bit 9 causes the system to ignore the secondary bootstrap. The secondary bootstrap program is used for system debugging and diagnostics.

Bit 10 controls the host portion of the IP broadcast address. Setting bit 10 causes the processor to use all zeros; clearing bit 10 (the factory default) causes the processor to use all ones. Bit 10 interacts with bit 14, which controls the network and subnet portions of the broadcast address. [Table 8](#) shows the combined effect of bits 10 and 14.

**Table 8** *Configuration Register Settings for Broadcast Address Destinations*

| Bit 14 | Bit 10 | Address (<net> <host>) |
|--------|--------|------------------------|
| Off    | Off    | <ones> <ones>          |
| Off    | On     | <zeros> <zeros>        |
| On     | On     | <net> <zeros>          |
| On     | Off    | <net> <ones>           |

Bits 11 and 12 in the configuration register determine the baud rate of the console terminal. [Table 9](#) shows the bit settings for the four available baud rates. (The factory-set default baud rate is 9600.)





```
Router#
```

## Additional Commands Associated to Flash Memory

Following are additional commands related to the Flash memory on the RSP1 and the Flash memory cards. You can determine which memory media you are accessing using the **pwd** command as follows:

```
Router# pwd
slot1
```

You can move between Flash memory media using the **cd [bootflash | slot0 | slot1]** command as follows:

```
Router# cd slot0
slot0
Router# cd slot1
Router# pwd
slot1
```

You can list the directory of Flash memory media using the **dir [bootflash | slot0 | slot1]** command as follows:

```
Router# dir
-#- -length- ----date/time----- name
1  4601977  May 19 1994 09:42:19 myfile1
6   679     May 19 1994 05:43:56 todays-config
7   1       May 19 1994 09:54:53 fun1
```

You can delete a file from any Flash memory media using the **delete** command as follows:

```
Router# delete slot0:fun1
Router# dir
-#- -length- ----date/time----- name
1  4601977  May 19 1994 09:42:19 myfile1
6   679     May 19 1994 05:43:56 todays-config
```

Files that are deleted are simply marked as deleted, but still occupy space in Flash memory. The **squeeze** command removes them permanently, and pushes all other undeleted files together to eliminate spaces between them. Following is the syntax of the **squeeze** command:

```
Router# squeeze slot0:
All deleted files will be removed, proceed? [confirm]
Squeeze operation may take a while, proceed? [confirm]
ebESZ
```

To prevent loss of data due to sudden power loss, the “squeezed” data is temporarily saved to another location of Flash memory, which is specially used by the system.

In the previous command display output, the character “e” means this special location has been erased (which must be performed before any write operation). The character “b” means that the data that is about to be written to this special location has been temporarily copied. The character “E” signifies that the sector which was temporarily occupied by the data has been erased. The character “S” signifies that the data was written to its permanent location in Flash memory.

The **squeeze** command operation keeps a log of which of these functions has been performed so upon sudden power failure, it can come back to the right place and continue with the process. The character “Z” means this log was erased after the successful **squeeze** command operation.

The configuration register setting 0x0101 tells the system to boot the default image (the first image) from onboard Flash memory, but does *not* reset the Break disable or checking for a default netboot filename. The configuration register setting 0x0102 tells the system to boot from Flash memory if netboot fails,

disable Break, and check for a default netboot filename. For more information on the **copy tftp:filename [ bootflash | slot0 | slot1 ]:filename** command, and other related commands, refer to the set of configuration fundamentals configuration and reference publications.

## Recovering a Lost Password

An overview of recovering a lost password follows:

- Enter the **show version** command to note the existing software configuration register value.
- Break to the bootstrap program prompt.
- Change the configuration register to ignore NVRAM.



### Note

A key to recovering a lost password is to set the configuration register so that the contents of NVRAM are ignored (0x0040), allowing you to see your password.

- Enter privileged level in the system EXEC.
- Enter the **show startup-configuration** command to display the enable password.
- Change the configuration register value back to its original setting.

To recover a lost password, follow these procedures.

- 
- Step 1** Attach an ASCII terminal to the router console port, which is located on the rear panel.
- Step 2** Configure the terminal to operate at 9600 baud, 8 data bits, no parity, 2 stop bits (or to whatever settings the router is set).
- Step 3** Enter the **show version** command to display the existing configuration register value. Note this value for later use in Step 13.
- Step 4** If Break is disabled, power cycle the router. (To power cycle, turn off the router, wait five seconds, and then turn it on again.) If Break is enabled on the router, press the Break key or send a break (^[]) and then proceed to Step 5.
- Step 5** Within 60 seconds of turning on the router, press the Break key. This action causes the terminal to display the bootstrap program prompt:

```
rommon 1 >
```

- Step 6** Set the configuration register to ignore the configuration file information as follows:

```
rommon 1 > confreg
```

```
Configuration Summary
```

```
enabled are:
```

```
console baud: 9600
```

```
boot: image specified by the boot system command  
or default to: cisco2-RSP
```

```
do you wish to change the configuration? y/n [n]: y
```

```
enable "diagnostic mode"? y/n [n]:
```

```
enable "use net in IP bcast address"? y/n [n]:
```

```
enable "load rom after netbootfails"? y/n [n]:
```

```
enable "use all zero broadcast"? y/n [n]:
```

```
enable "break/abort has effect?" y/n [n]:
```

```
enable "ignore system config info?" [n]: y
```

```
change console baud rate? y/n [n]:
```

```
change boot characteristics? y/n [n]
```

```
Configuration Summary
enabled are:
console baud: 9600
boot: image specified by the boot system command
or default to: cisco2-RSP
```

```
do you wish to change the configuration? y/n [n]
```

You must reset or power cycle for the new config to take effect

- Step 7** Initialize the router by entering the **i** command as follows:

```
rommon 1 > i
```

The router will power cycle, the configuration register will be set to ignore the configuration file, and the router will boot the boot system image and prompt you with the system configuration dialog as follows:

```
--- System Configuration Dialog ---
```

- Step 8** Enter **no** in response to the system configuration dialog prompts until the following system message is displayed:

```
Press RETURN to get started!
```

- Step 9** Press **Return**. After some interface information, the prompt appears as follows:

```
Router>
```

- Step 10** Enter the **enable** command to enter the enabled mode. The prompt changes to the following:

```
Router#
```

- Step 11** Enter the **show configuration EXEC** command to display the enable password in the configuration file.

- Step 12** Enter the **configure terminal** command at the EXEC prompt. You are prompted as follows:

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#
```

- Step 13** Using the **config-register 0x<value>** command, change the configuration register value back to its original value (noted from Step 3) or change it to a value of 0x0101 (factory default).

- Step 14** Exit the configuration mode by entering **Ctrl-Z**.

- Step 15** Reboot the router and enable it using the recovered password.

- Step 16** This completes the procedure for recovering from a lost password.

## Using Flash Memory Cards

The Flash memory (PCMCIA) card slots on the front panel of the RSP1 are for additional PCMCIA-based Flash memory for your system. You can use this Flash memory to store and run Cisco IOS images, or as a file server for other routers to access as clients. Occasionally, it might be necessary to remove and replace Flash memory cards; however, removing Flash memory cards is not required and is not recommended after the cards are installed in the slots.

## Replacing a Flash Memory Card

It might become necessary for you to replace or install a Flash memory card in your RSP1. The RSP1 has two PCMCIA slots: slot 0 (bottom) and slot 1 (top). (See [Figure 9](#).) The following procedure is generic and can be used for a Flash memory card in either slot position.




### Note

The Flash memory card can be inserted and removed with the power on.

Before you install a card, verify that the Flash memory card is set with write protection off. The write protect switch is located on the front edge of the card when oriented with the printing right side up and the edge connector end away from you. (See [Figure 8](#).)


**Figure 8** Locating the Flash Memory Card Write Protection Switch



Following is the procedure for installing and removing a Flash memory card:

- Step 1** Face the front panel of the RSP1 (as shown in [Figure 9](#)), and hold the Flash memory card with the connector end of the card toward the slot. The connector end of the card is the end opposite the end with the write protection switch, which is shown in [Figure 8](#).
- Step 2** Insert the card into the appropriate slot until the card completely seats in the connector at the back of the slot and the eject button pops out toward you (See [Figure 9](#).) Note that the card does not insert all the way inside the RSP1; a portion of the card will remain outside the slot. *Do not attempt to force the card past this point.*
- Step 3** To eject a card, press the appropriate ejector button until the card is free of the connector at the back of the slot. (See [Figure 9](#).)
- Step 4** Remove the card from the slot and place it in an antistatic bag to protect it.

**Figure 9** Installing and Removing a Flash Memory Card



## Formatting a Flash Memory Card

The Flash memory (PCMCIA) card that shipped with your Cisco 7505 contains the Cisco IOS software image. In some cases, you might need to insert a new Flash memory card and copy images or backup configuration files onto it. Before you can use a new Flash memory card, you must format it. Before you can use a Flash memory card that was previously used on a Route Processor (RP) in a Cisco 7000 series router, you must reformat the Flash memory card. Flash memory cards formatted on RP-based (Cisco 7000 series) routers will not work properly in RSP-based (Cisco 7500 series) routers.



**Note**

The following procedure assumes you have already booted your router.



**Warning**

The following formatting procedure erases all information on the Flash memory card. To prevent the loss of important data on a Flash memory card, proceed carefully. If you wish to save the data on a Flash memory card, upload the data to a server before you format the card.

Use the following procedure to format a new Flash memory card:

- Step 1** Using the procedure in the [“Replacing a Flash Memory Card” section on page 36](#) insert the Flash memory card into slot 0. (If slot 0 is not available, use slot 1.)
- Step 2** To format the Flash memory card, use the **format slot0:** (or **format slot1:**) command as follows. (Use only Intel Series 2+ Flash memory cards.)

```
Router# format slot0:
All sectors will be erased, proceed? [confirm]
Enter volume id (up to 30 characters): MyNewCard
Formatting sector 1
Format device slot0 completed
Router#
```



**Note** For this example, an 8-MB Flash memory card was used, and at the line “Formatting sector,” the system counted the card’s sectors backwards from 64 to 1 as it formatted them. For 16-MB Flash memory cards, the system counts backwards from 128 to 1, and for 20-MB Flash memory cards, the system counts backwards from 160 to 1.

The new Flash memory card is now formatted and ready to use.



**Note** For complete command descriptions and configuration information, refer to the *Configuration Fundamentals Command Reference* and the *Configuration Fundamentals Configuration Guide* publications.

## Making the Flash Memory Card Image Bootable

Use the following series of commands to make the image (the file named *new.image*) bootable. Note that, since the configuration register must be set to 0x2102, the **config-register** command is part of the sequence.

```
Router# config terminal
Router(config)# no boot system
Router(config)# boot system flash slot0:new.image
Router(config)# config-register 0x2102
Ctrl-z
Router# copy running-config startup-config
Router# reload
```

When the system reloads, it will boot the image *new.image* from the Flash memory card in slot 0.

## Copying a Bootable Image into a Flash Memory Card

With the Flash memory card formatted, you can now copy a bootable image into it. To copy an image, use the following procedure, which assumes the following:

- You have an RSP1 with a good image in the onboard Flash SIMM so you can start the router
- The bootable image you want to copy to the Flash memory card exists on a TFTP server to which you have access (know its name and have connectivity to it), and at least one interface is available over which you can access this server

**Note**

To assure access to a TFTP sever, you will need to configure at least one interface using the **setup** command facility. For instructions on using this procedure, refer to the *Configuration Fundamentals Configuration Guide* publications.

- You know the filename of the image you wish to copy into the Flash memory card

Following is the procedure for copying a bootable file (called *new.image*) into the Flash memory card:

**Step 1** Boot the router and allow it to initialize.

**Step 2** Insert an unformatted Flash memory card and format it using the procedure in the “[Formatting a Flash Memory Card](#)” section on page 37, and then proceed to Step 1.

**Note**

If you have already formatted a Flash memory card, you can use it instead; however, you cannot boot from or use a Flash memory card formatted on another type of system. You must reformat it to use it as a boot or storage source.

**Step 1** To enable the router, copy the image *new.image* to the Flash memory card, make this image in the Flash memory card (in slot 0) the default boot image, and reboot the router, use the following series of commands:

```
Router> en
Password:
Router# copy tftp:new.image slot0:new.image
20575008 bytes available on device slot0, proceed? [confirm]
Address or name of remote host [1.1.1.1]?
Loading new.image from 1.1.1.1 (via Ethernet1/0): !!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!
!!
[OK - 7799951/15599616 bytes]
cc
cc
cc
Router#
```

**Note**

In the preceding example, the exclamation points (!!!) appear as the file is downloaded and the “C” characters signify calculation of the checksum, which is a verification that the file has been correctly downloaded to the Flash memory card.

```
Router# config terminal
Router(config)# no boot system
Router(config)# boot system flash slot0:new.image
Ctrl-z
Router# copy running-config startup-config
Router# reload
```

When the system reloads, it will boot the image *new.image* from the Flash memory card in slot 0.

## Copying Bootable Images Between Flash Memory Cards

As future releases of Cisco IOS images become available, you will receive these images either as a netbooted file, a file on floppy disk, or a file on a Flash memory card.

The following scenario describes how to use a newly released image on a Flash memory card in a system that has an older image on a Flash memory card in slot 0 (and a default boot image in the onboard Flash SIMM).

For this scenario, the filenames are as follows:

- The new image on the new Flash memory card is *image.new*
- The old image in the Flash memory card in slot 0 is *image.old*
- The bootable image in onboard Flash memory is *image.boot*

You will copy the new image from the new Flash memory card onto the Flash memory card that contains the old image.



#### Note

The scenario assumes that the new image will fit on the Flash memory card in slot 0, alongside the old image. If there is not enough available space, use the **delete** command to delete files from the Flash memory card to make sufficient room for the new image; however, *do not* delete the *image.old* file. Then use the **squeeze** command to remove these deleted files from the Flash memory card. If, after you have deleted files and used the **squeeze** command, the two files cannot coexist on the Flash memory card in slot 0, remove this card (place it in an anti-static bag and store it in a safe place), then insert the new Flash memory card (with the file *image.new*) in slot 0. Proceed to Step 5 and use the command **boot system flash slot0:image.new** to designate the file *image.new* as the default boot image.

**Step 1** Boot the router. By default, the file *image.boot* will be used.

**Step 2** Enable the router as follows:

```
Router> en
Password:
Router#
```

**Step 3** Insert the new Flash memory card in slot 1.

**Step 4** Use the following command to copy the file *image.new* in slot 1 to the Flash memory card in slot 0 *only if* there is enough memory space for the two images to coexist. If there is not enough memory space, proceed to Step 5.

```
Router# copy slot1:image.new slot0:image.new
```



#### Note

The previous command can also be entered as **copy slot1:image.new slot0:**.

**Step 5** Use the following series of commands to designate the file *image.new* (which is in the Flash memory card in slot 0) as the default boot image:

```
Router# config t
Router(config)# no boot system
Router(config)# boot system flash slot0:image.new
Ctrl-z
Router# copy running-config startup-config
Router# reload
```

When the system reloads, it will boot the file *image.new* from the Flash memory card in slot 0.



## Recovering from Locked Blocks

A locked block of Flash memory occurs when power is lost or a Flash memory card is unplugged during a write or erase operation. When a block of Flash memory is locked, it cannot be written to or erased, and the operation will consistently fail at a particular block location. The only way to recover from locked blocks is by reformatting the Flash memory card with the **format** command.



Caution

---

Formatting a Flash memory card will cause existing data to be lost.

---

## Obtaining Documentation

The following sections explain how to obtain documentation from Cisco Systems.

### World Wide Web

You can access the most current Cisco documentation on the World Wide Web at the following URL:

<http://www.cisco.com>

Translated documentation is available at the following URL:

[http://www.cisco.com/public/countries\\_languages.shtml](http://www.cisco.com/public/countries_languages.shtml)

### Documentation CD-ROM

Cisco documentation and additional literature are available in a Cisco Documentation CD-ROM package, which is shipped with your product. The Documentation CD-ROM is updated monthly and may be more current than printed documentation. The CD-ROM package is available as a single unit or through an annual subscription.

### Ordering Documentation

Cisco documentation is available in the following ways:

- Registered Cisco Direct Customers can order Cisco product documentation from the Networking Products MarketPlace:  
[http://www.cisco.com/cgi-bin/order/order\\_root.pl](http://www.cisco.com/cgi-bin/order/order_root.pl)
- Registered Cisco.com users can order the Documentation CD-ROM through the online Subscription Store:  
<http://www.cisco.com/go/subscription>
- Nonregistered Cisco.com users can order documentation through a local account representative by calling Cisco corporate headquarters (California, USA) at 408 526-7208 or, elsewhere in North America, by calling 800 553-NETS (6387).

## Documentation Feedback

If you are reading Cisco product documentation on Cisco.com, you can submit technical comments electronically. Click **Leave Feedback** at the bottom of the Cisco Documentation home page. After you complete the form, print it out and fax it to Cisco at 408 527-0730.

You can e-mail your comments to [bug-doc@cisco.com](mailto:bug-doc@cisco.com).

To submit your comments by mail, use the response card behind the front cover of your document, or write to the following address:

Cisco Systems  
Attn: Document Resource Connection  
170 West Tasman Drive  
San Jose, CA 95134-9883

We appreciate your comments.

## Obtaining Technical Assistance

Cisco provides Cisco.com as a starting point for all technical assistance. Customers and partners can obtain documentation, troubleshooting tips, and sample configurations from online tools by using the Cisco Technical Assistance Center (TAC) Web Site. Cisco.com registered users have complete access to the technical support resources on the Cisco TAC Web Site.

## Cisco.com

Cisco.com is the foundation of a suite of interactive, networked services that provides immediate, open access to Cisco information, networking solutions, services, programs, and resources at any time, from anywhere in the world.

Cisco.com is a highly integrated Internet application and a powerful, easy-to-use tool that provides a broad range of features and services to help you to

- Streamline business processes and improve productivity
- Resolve technical issues with online support
- Download and test software packages
- Order Cisco learning materials and merchandise
- Register for online skill assessment, training, and certification programs

You can self-register on Cisco.com to obtain customized information and service. To access Cisco.com, go to the following URL:

<http://www.cisco.com>

## Technical Assistance Center

The Cisco TAC is available to all customers who need technical assistance with a Cisco product, technology, or solution. Two types of support are available through the Cisco TAC: the Cisco TAC Web Site and the Cisco TAC Escalation Center.

Inquiries to Cisco TAC are categorized according to the urgency of the issue:

- Priority level 4 (P4)—You need information or assistance concerning Cisco product capabilities, product installation, or basic product configuration.
- Priority level 3 (P3)—Your network performance is degraded. Network functionality is noticeably impaired, but most business operations continue.
- Priority level 2 (P2)—Your production network is severely degraded, affecting significant aspects of business operations. No workaround is available.
- Priority level 1 (P1)—Your production network is down, and a critical impact to business operations will occur if service is not restored quickly. No workaround is available.

Which Cisco TAC resource you choose is based on the priority of the problem and the conditions of service contracts, when applicable.

## Cisco TAC Web Site

The Cisco TAC Web Site allows you to resolve P3 and P4 issues yourself, saving both cost and time. The site provides around-the-clock access to online tools, knowledge bases, and software. To access the Cisco TAC Web Site, go to the following URL:

<http://www.cisco.com/tac>

All customers, partners, and resellers who have a valid Cisco services contract have complete access to the technical support resources on the Cisco TAC Web Site. The Cisco TAC Web Site requires a Cisco.com login ID and password. If you have a valid service contract but do not have a login ID or password, go to the following URL to register:

<http://www.cisco.com/register/>

If you cannot resolve your technical issues by using the Cisco TAC Web Site, and you are a Cisco.com registered user, you can open a case online by using the TAC Case Open tool at the following URL:

<http://www.cisco.com/tac/caseopen>

If you have Internet access, it is recommended that you open P3 and P4 cases through the Cisco TAC Web Site.

## Cisco TAC Escalation Center

The Cisco TAC Escalation Center addresses issues that are classified as priority level 1 or priority level 2; these classifications are assigned when severe network degradation significantly impacts business operations. When you contact the TAC Escalation Center with a P1 or P2 problem, a Cisco TAC engineer will automatically open a case.

To obtain a directory of toll-free Cisco TAC telephone numbers for your country, go to the following URL:

<http://www.cisco.com/warp/public/687/Directory/DirTAC.shtml>

Before calling, please check with your network operations center to determine the level of Cisco support services to which your company is entitled; for example, SMARTnet, SMARTnet Onsite, or Network Supported Accounts (NSA). In addition, please have available your service agreement number and your product serial number.

his document is to be used in conjunction with the appropriate installation and configuration guide that shipped with your router.

AccessPath, AtmDirector, Browse with Me, CCIP, CCSI, CD-PAC, *CiscoLink*, the *Cisco Powered Network* logo, Cisco Systems Networking Academy, the Cisco Systems Networking Academy logo, Fast Step, Follow Me Browsing, FormShare, FrameShare, GigaStack, IGX, Internet Quotient, IP/VC, iQ Breakthrough, iQ Expertise, iQ FastTrack, the iQ Logo, iQ Net Readiness Scorecard, MGX, the Networkers logo, *Packet*, RateMUX, ScriptBuilder, ScriptShare, SlideCast, SMARTnet, TransPath, Unity, Voice LAN, Wavelength Router, and WebViewer are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn, Discover All That's Possible, and Empowering the Internet Generation, are service marks of Cisco Systems, Inc.; and Aironet, ASIST, BPX, Catalyst, CCDA, CCDP, CCIE, CCNA, CCNP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, the Cisco IOS logo, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Enterprise/Solver, EtherChannel, EtherSwitch, FastHub, FastSwitch, IOS, IP/TV, LightStream, MICA, Network Registrar, PIX, Post-Routing, Pre-Routing, Registrar, StrataView Plus, Stratm, SwitchProbe, TeleRouter, and VCO are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and certain other countries.

All other trademarks mentioned in this document or Web site are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0108R)

Copyright © 2001, Cisco Systems, Inc.  
All rights reserved.