



Configuring the Gigabit Ethernet Ports



Warning

Before you install, operate, or service the system, read the *Site Preparation and Safety Guide*. This guide contains important safety information you should know before working with the system. Statement 200



Warning

Only trained and qualified personnel should be allowed to install, replace, or service this equipment. Statement 1030

This chapter describes how to configure the Gigabit Ethernet ports on the Catalyst 2948G and 2980G switches and how to configure the small form-factor-pluggable (SFP) module slot on the Catalyst 2948G-GE-TX switches. The chapter contains these sections:

- [Installing, Removing, and Maintaining GBICs, page 4-1](#)
- [Connecting To an SFP Module, page 4-13](#)

The Gigabit Ethernet ports can be configured with any combination of GBICs. The Gigabit Ethernet ports on these modules are used primarily for backbone interconnection of other high-performance switches and routers.

Installing, Removing, and Maintaining GBICs

The following sections describe Gigabit Interface Converters (GBICs) and how to install, remove, and maintain them:

- [GBIC Features](#), page 4-2
- [Port Cabling Specifications](#), page 4-3
- [GBIC Optical Power Characteristics](#), page 4-4
- [GBIC Cabling Restrictions](#), page 4-5
- [Installing GBICs](#), page 4-6
- [Removing GBICs](#), page 4-9
- [GBIC Maintenance Guidelines](#), page 4-10
- [Patch Cord](#), page 4-10

GBIC Features




Warning

Because invisible laser radiation may be emitted from the aperture of the port when no cable is connected, avoid exposure to laser radiation and do not stare into open apertures. Statement 70

GBICs (see [Figure 4-1](#)) are hot-swappable input/output devices that plug into a Gigabit Ethernet switching module, linking the module with a fiber-optic network. The GBICs use SC-type connectors and plug into connectors on the module. You can install any combination of GBICs in the Gigabit Ethernet switching module.

Figure 4-1 GBIC Module



[Table 4-1](#) lists the GBIC modules that are supported by the Catalyst 2948G and 2980G switches.

Table 4-1 Supported GBIC modules

GBIC Type	Model Number
Fiber-optic 1000BASE-SX	WS-G5484=
Fiber-optic 1000BASE-LX/LH	WS-G5486=
Fiber-optic 1000BASE-ZX	WS-G5487=
Copper 1000BASE-TX GBIC	WS-G5483=
Coarse Wave Division Multiplexing (CWDM) fiber-optic 1000BASE-X GBIC	CWDM-GBIC-1470= CWDM-GBIC-1490= CWDM-GBIC-1510= CWDM-GBIC-1530= CWDM-GBIC-1550= CWDM-GBIC-1570= CWDM-GBIC-1590= CWDM-GBIC-1610=

**Note**

Cisco 1000BASE-LX/LH interfaces fully comply with the IEEE 802.3z 1000BASE-LX standard. However, their higher optical quality allows them to reach 10 kilometers over single-mode fiber (SMF) versus the 5 kilometers specified in the standard.

Other GBIC media types may be supported as additional technology becomes available.

**Note**

Because of interoperability issues, Cisco does not support GBICs purchased from third-party vendors.

Port Cabling Specifications

[Table 4-2](#) provides cabling specifications for the GBICs. The minimum cable distance for all GBICs listed (MMF [multimode fiber] and SMF) is 6.5 feet (2 meters).

**Note**

For information about the Coarse Wave Division Multiplexing (CWDM), refer to the *Cisco CWDM GBIC and CWDM SFP Installation Note*.

Table 4-2 GBIC Port Cabling Specifications

GBIC	Wavelength ¹ (nm)	Fiber Type	Core Size (microns)	Modal Bandwidth (MHz/km)	Maximum Distance
SX ²	850	MMF	62.5	160	722 ft (0.22 km)
			62.5	200	902 ft (0.27 km)
			50.0	400	1640 ft (0.50 km)
			50.0	500	1804 ft (0.55 km)
LX/LH	1300	MMF ³	62.5	500	1804 ft (0.55 km)
			50.0	400	1804 ft (0.55 km)
			50.0	500	1804 ft (0.55 km)
		SMF	9/10	–	6.2 mi (10.0 km)
ZX	1550	SMF	9/10	–	43.5 mi (70.0 km)
		SMF ⁴	–	–	62.1 mi (100.0 km)

1. Nominal fiber specification wavelength.
2. MMF only.
3. Patch cord required (refer to the [“Patch Cord”](#) section on page 4-10 for details).
4. Dispersion-shifted single-mode fiber-optic.

GBIC Optical Power Characteristics

[Table 4-3](#) provides the GBIC optical power characteristics.

**Note**

For information about the Coarse Wave Division Multiplexing (CWDM), refer to the *Cisco CWDM GBIC and CWDM SFP Installation Note*.

Table 4-3 GBIC Optical Power Characteristics

Parameter	1000BASE-SX (WS-G5484)	1000BASE-LX/LH (WS-G5486)	1000BASE-ZX (WS-G5487)
Transmitter output power (min/max)	0/−9.5 dBm	−3/−9.5 dBm	0/4.77 dBm
Receiver maximum input power	0 dBm	−3 dBm	−3 dBm
Receiver sensitivity	−17 dBm	−19 dBm	−23 dBm
Channel insertion loss			
50/125 micron ¹ MMF	3.4 dBm	4.4 dBm	—
62.5/125 micron MMF	3.2 dBm	6 dBm	—
9/10 micron SMF	—	6.5 dBm	21.5 dBm

1. 1 micron (μ) equals 1 micrometer or 10^{-6} meters

GBIC Cabling Restrictions

You must observe the following fiber-optic cabling restrictions when using GBICs:

- The minimum cabling distance for 1000BASE-SX and 1000BASE-LX/LH GBICs is 6.5 feet (2 meters).
- The maximum cabling distance for each GBIC type is listed in [Table 4-2](#).
- When using the 1000BASE-LX/LH GBIC with 62.5-micron diameter MMF, you must install a mode-conditioning patch cord between the MMF fiber-optic network and the GBIC. The mode-conditioning patch cord (CAB-GELX-625 or equivalent) is required to comply with IEEE standards. See the [“Patch Cord” section on page 4-10](#) for more information.
- You must insert a 10-dB inline optical attenuator between the single-mode fiber-optic network and the receiving port on the 1000BASE-ZX GBIC at each end of the link if the link length is less than 15.5 miles (25 km).

- You must insert a 5-dB inline optical attenuator between the single-mode fiber-optic network and the receiving port on the 1000BASE-ZX GBIC at each end of the link if the link is greater than 15.5 miles (25 km), but less than 31 miles (50 km).

Installing GBICs

This section describes how to install GBICs.



Caution

Unnecessary removal and insertion of a GBIC could lead to premature failure of the GBIC. A GBIC has a lifetime of 100 to 500 removals and insertions.

A switch can be shipped with or without GBICs installed.



Caution

When removing or inserting a GBIC, always wear an ESD wrist strap connected to the ESD wrist strap connector. For more information about ESD, refer to the *Site Preparation and Safety Guide*.



Note

GBICs are online swappable.

To install a GBIC, perform these steps:

-
- Step 1** Remove the GBIC from its protective packaging.
- Step 2** Verify that the GBIC is the correct type for your network by checking the part number.
- The part number indicates whether it is 1000BASE-SX, 1000BASE-LX/LH, or 1000BASE-ZX.
- Step 3** Grip the sides of the GBIC with your thumb and forefinger; insert the GBIC into the slot on the front of the module.
- See [Figure 4-2](#) for GBIC installation on a Catalyst 2948G switch. See [Figure 4-3](#) for GBIC installation on a Catalyst 2980G switch.



Note GBICs are keyed to prevent incorrect slot insertion. See [Figure 4-4](#).

Figure 4-2 Installing a GBIC on a Catalyst 2948G Switch





Figure 4-3 Installing a GBIC on a Catalyst 2980G Switch




- Step 4** Slide the GBIC into the slot until you hear a click. The click indicates that the GBIC is locked into the slot.
- Step 5** When you are ready to attach the fiber-optic cable, remove the plug from the GBIC and save it for future use.

**Caution**

Do not remove the plug from the GBIC optical bores or the fiber-optic cable until you are ready to connect the cable. The plug protects the GBIC optical bores and cable from contamination.

- Step 6** Remove the protective plug from the SC-type connector on the fiber-optic cable if necessary. Insert the connector into the GBIC.
- When you plug the SC-type connector into the GBIC, make sure that both the Tx and Rx fiber-optic cables are already fully inserted into the SC-type connector.

Figure 4-4 Connecting the SC-Type Connector

**Note**

If you are using the LX/LH GBIC with MMF, you need to install a patch cord between the GBIC and the MMF cable. See the [“Patch Cord”](#) section on page 4-10 for details.

Removing GBICs

**Note**

If you are removing the GBIC from an online switch, enter the **show port** command to verify the type of GBIC that is installed.

To remove a GBIC, perform these steps:

- Step 1** Disconnect the fiber-optic cable from the GBIC SC-type connector.
- Step 2** Release the GBIC from the slot by simultaneously squeezing the plastic tabs (one on each side of the GBIC).

- Step 3** Slide the GBIC out of the slot.
- Step 4** Install the plug into the GBIC optical bores and place the GBIC in its protective packaging.
-

GBIC Maintenance Guidelines

Follow these GBIC maintenance guidelines:

- GBICs are static sensitive. To prevent ESD damage, follow your normal board and component handling procedures.
- GBICs are dust sensitive. When the GBIC is stored or when a fiber-optic cable is not plugged in, always keep plugs in the GBIC optical bores.
- The most common source of contaminants in the optical bores is debris picked up on the ferrules of the optical connectors. Use an alcohol swab or Kim-Wipe to clean the ferrules of the optical connector.

Patch Cord

When using the LX/LH GBIC with a 62.5-micron diameter core size MMF, you must install a mode-conditioning patch cord (Cisco product number CAB-GELX-625 or equivalent) between the GBIC and the MMF cable on both the transmit and receive ends of the link. The patch cord is required for link distances greater than 984 feet (300 meters).



Note

We do not recommend using the LX/LH GBIC with MMF without a patch cord for very short link distances (tens of meters). The result could be an elevated bit error rate (BER).



Note

The patch cord is required to comply with IEEE standards. The IEEE found that link distances could not be achieved with certain types of fiber-optic cable due to a problem in the center of some fiber-optic cable cores. The solution is to launch light from the laser at a precise offset from the center by using the patch cord. At

the output of the patch cord, the LX/LH GBIC is compliant with the IEEE 802.3z standard for 1000BASE-LX. For a detailed description of this problem, refer to [Appendix C, “Differential Mode Delay.”](#)


**Note**

Cisco Gigabit Ethernet products have been tested and evaluated to comply with the standards listed in [Appendix A, “Specifications.”](#) Equivalent cables should also meet these standards.

Patch Cord Configuration Example

Figure 4-5 shows a typical configuration using patch cords.


Figure 4-5 Patch Cord Configuration



Patch Cord Installation

Plug the end of the patch cord labeled “To equipment” into the GBIC (see Figure 4-6). Plug the end labeled “To cable plant” into the patch panel. The patch cord is 9.84 feet (3 meters) long and has duplex SC-type male connectors at each end.

Figure 4-6 Patch Cord Installation



Connecting To an SFP Module

This section describes how to connect to an SFP module. For instructions about how to install or remove an SFP module, refer to the *Cisco Small Form-Factor Pluggable Modules Installation Notes* (not orderable but is available on Cisco.com) and to the documentation that came with your SFP module.

[Table 4-4](#) lists the SFP modules supported by the Catalyst 2948G-GE-TX switch.

Table 4-4 Supported SFP Modules

SFP Type	Model Number
Fiber-optic 1000BASE-LX	GLC-LS-SM=
Fiber-optic 1000BASE-SX	GLC-SX-MM=
Fiber-optic 1000BASE-ZX	GLC-ZX-SM=
Copper 1000BASE-T	GLC-T=
Coarse Wave Division Multiplexing (CWDM) fiber-optic SFP modules	CWDM-SFP-1470= CWDM-SFP-1490= CWDM-SFP-1510= CWDM-SFP-1530= CWDM-SFP-1550= CWDM-SFP-1570= CWDM-SFP-1590= CWDM-SFP-1610=

The restrictions are that each port must match the wave-length specifications on the other end of the cable, and the cable must not exceed the recommended cable length for reliable communications. [Table 4-5](#) lists these recommendations.

Table 4-5 *Fiber-Optic SFP Module Port Cabling Specifications*

SFP Module	Wavelength (nanometers)	Fiber Type	Core Size (micron)	Modal Bandwidth (MHz/km)	Cable Dis
1000BASE-SX	850	MMF	62.5	160	722 ft (222 m)
			62.5	200	902 ft (275 m)
			50.0	400	1640 ft (500 m)
			50.0	500	1804 ft (550 m)
1000BASE-LX/LH	1300	MMF ¹	62.5	500	1804 ft (550 m)
			50.0	400	1804 ft (550 m)
		SMF	50.0	500	1804 ft (550 m)
			9/10	—	6.2 mi (10 km)
1000BASE-ZX	1550	SMF	9/10	—	43.4 to 60.4 km (100 km) ²

1. A mode-conditioning patch cord is required. Using an ordinary patch cord with MMF, 1000BASE-LX/LH SFP modules can cause transceiver saturation, resulting in an elevated bit error rate (BER). When using an SFP module with 62.5-micron diameter MMF, you must also install a mode-conditioning patch cord between the SFP module and the MMF cable on both the sending and receiving ends of the link. The mode-conditioning patch cord is required for link distances greater than 984 feet (300 m).
2. 1000BASE-ZX SFP modules can reach up to 100 km by using dispersion-shifted SMF or low-attenuation SMF. The maximum link distance depends on the fiber quality, the number of splices, and the connectors.

**Note**

For information about the Coarse Wave Division Multiplexing (CWDM), refer to the *Cisco CWDM GBIC and CWDM SFP Installation Note*.

The 1000BASE-T (copper) SFP module is used to establish a Gigabit Ethernet connection through a Category 5 Category 5 cable.

Use only Cisco SFP modules on the Catalyst 2948G-GE-TX switch. Each SFP module has an internal serial EEPROM that is encoded with security information. This encoding provides a way for Cisco to identify and validate that the SFP module meets the requirements for the switch.

For more information about these SFP modules, refer to your SFP module documentation and to the *Cisco Small Form-Factor Pluggable Modules Installation Notes* (not orderable but is available on Cisco.com.)

For the latest information about SFP modules supported by the switch, refer to the release notes.

**Caution**

Do not remove the rubber plugs from the ports on fiber-optic SFP modules or the rubber caps from the fiber-optic cable until you are ready to connect the cable. The plugs and caps protect the SFP module ports and cables from contamination and ambient light.

Before connecting to an SFP module, be sure that you understand the port and cabling stipulations in [Table 4-5](#). See [Appendix A, “Specifications,”](#) for information about the LC on the SFP modules for fiber-optic connections.


Follow these steps to connect a fiber-optic cable to an SFP module:

**Warning**

Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments.
Statement 272

- Step 1** Remove the rubber plugs from the module port and fiber-optic cable, and store them for future use.
- Step 2** Insert one end of the fiber-optic cable into the SFP module port, as shown in [Figure 4-7](#).

Figure 4-7 Connecting to an SFP Module Port



- Step 3** Insert the other cable end in a fiber-optic receptacle on a target device.

Step 4 Observe the port LED.

- The LED turns green when the switch and the target device have an established link.
- The LED turns amber while the STP discovers the network topology and searches for loops. This process takes about 30 seconds, and then the port LED turns green.
- If the LED is off, the target device might not be turned on, there might be a cable problem, or there might be problem with the adapter installed in the target device. See [Chapter 5, “Troubleshooting the Installation,”](#) for solutions to cabling problems.

- Step 5** If necessary, reconfigure and restart the switch or target device.
- The Gigabit Ethernet ports on these modules are used primarily for backbone interconnection of other high-performance switches and routers.
-

After you have connected all the interfaces, check all connections, and then perform the steps described in the [“Verifying Switch Operation” section on page 3-20](#) to verify that the switch is operational.

