

You'll be entered into a quarterly drawing for **free** Cisco Press books by returning this survey! Cisco is dedicated to customer satisfaction and would like to hear your thoughts on these printed manuals. Please visit the Cisco Product Comments on-line survey at www.cisco.com/go/crc to submit your comments about accessing Cisco technical manuals. Thank you for your time.

General Information

- 1 Years of networking experience: _____ Years of experience with Cisco products: _____
- 2 I have these network types: ___ LAN ___ Backbone ___ WAN
 ___ Other: _____
- 3 I have these Cisco products: ___ Switches ___ Routers
 ___ Other (specify models): _____
- 4 I perform these types of tasks: ___ H/W installation and/or maintenance ___ S/W configuration
 ___ Network management ___ Other: _____
- 5 I use these types of documentation: ___ H/W installation ___ H/W configuration ___ S/W configuration
 ___ Command reference ___ Quick reference ___ Release notes ___ Online help
 ___ Other: _____
- 6 I access this information through: ___ % Cisco.com ___ % CD-ROM ___ % Printed manuals
 ___ % Other: _____
- 7 I prefer this access method: ___ Cisco.com ___ CD-ROM ___ Printed manuals
 ___ Other: _____
- 8 I use the following three product features the most: _____

Document Information

Document Title: Catalyst 3750 Switch Hardware Installation Guide

Part Number: 78-15136-03 S/W Release (if applicable): _____

On a scale of 1–5 (5 being the best), please let us know how we rate in the following areas:

- ___ The document is complete. ___ The information is accurate.
___ The information is well organized. ___ The information I wanted was easy to find.
___ The document is written at my ___ The information I found was useful to my job.
 technical level of understanding.

Please comment on our lowest scores: _____

Mailing Information

Organization _____ Date _____

Contact Name _____

Mailing Address _____

City _____ State/Province _____ Zip/Postal Code _____


Country _____ Phone () _____ Extension _____

E-mail _____ Fax () _____


May we contact you further concerning our documentation? ___ Yes ___ No

You can also send us your comments by e-mail to bug-doc@cisco.com, or by fax to **408-527-8089**.

When mailing this card from outside of the United States, please enclose in an envelope addressed to the location on the back of this card with the required postage or fax to 1-408-527-8089.



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES



BUSINESS REPLY MAIL
FIRST-CLASS MAIL PERMIT NO. 4631 SAN JOSE CA

POSTAGE WILL BE PAID BY ADDRESSEE

DOCUMENT RESOURCE CONNECTION
CISCO SYSTEMS INC
170 WEST TASMAN DR
SAN JOSE CA 95134-9916





Catalyst 3750 Switch Hardware Installation Guide

February 2004

Corporate Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 526-4100

Customer Order Number: DOC-7815136=
Text Part Number: 78-15136-03



THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The following information is for FCC compliance of Class A devices: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to correct the interference at their own expense.

The following information is for FCC compliance of Class B devices: The equipment described in this manual generates and may radiate radio-frequency energy. If it is not installed in accordance with Cisco's installation instructions, it may cause interference with radio and television reception. This equipment has been tested and found to comply with the limits for a Class B digital device in accordance with the specifications in part 15 of the FCC rules. These specifications are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation.

Modifying the equipment without Cisco's written authorization may result in the equipment no longer complying with FCC requirements for Class A or Class B digital devices. In that event, your right to use the equipment may be limited by FCC regulations, and you may be required to correct any interference to radio or television communications at your own expense.

You can determine whether your equipment is causing interference by turning it off. If the interference stops, it was probably caused by the Cisco equipment or one of its peripheral devices. If the equipment causes interference to radio or television reception, try to correct the interference by using one or more of the following measures:

- Turn the television or radio antenna until the interference stops.
- Move the equipment to one side or the other of the television or radio.
- Move the equipment farther away from the television or radio.
- Plug the equipment into an outlet that is on a different circuit from the television or radio. (That is, make certain the equipment and the television or radio are on circuits controlled by different circuit breakers or fuses.)

Modifications to this product not authorized by Cisco Systems, Inc. could void the FCC approval and negate your authority to operate the product.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

CCSP, the Cisco Square Bridge logo, Cisco Unity, Follow Me Browsing, FormShare, and StackWise are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn, and iQuick Study are service marks of Cisco Systems, Inc.; and Aironet, ASIST, BPX, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Empowering the Internet Generation, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Fast Step, GigaDrive, GigaStack, HomeLink, Internet Quotient, IOS, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, LightStream, Linksys, MeetingPlace, MGX, the Networkers logo, Networking Academy, Network Registrar, *Packet*, PIX, Post-Routing, Pre-Routing, ProConnect, RateMUX, Registrar, ScriptShare, SlideCast, SMARTnet, StrataView Plus, SwitchProbe, TeleRouter, The Fastest Way to Increase Your Internet Quotient, TransPath, and VCO are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0406R)

Catalyst 3750 Switch Hardware Installation Guide

Copyright © 2004 Cisco Systems, Inc. All rights reserved.



Cisco 90-Day Limited Hardware Warranty Terms xi

Preface xv

Audience xv

Purpose xv

Conventions xvi

Related Publications xxiv

Obtaining Documentation xxv

 Cisco.com xxv

 Ordering Documentation xxv

Documentation Feedback xxvi

Obtaining Technical Assistance xxvi

 Cisco TAC Website xxvi

 Opening a TAC Case xxvii

 TAC Case Priority Definitions xxvii

Obtaining Additional Publications and Information xxviii

CHAPTER 1

Using Express Setup 1-1

Taking Out What You Need 1-3

Powering On the Switch 1-4

Starting Express Setup 1-5

Configuring the Switch 1-11

Rerunning Express Setup 1-13

Verifying Switch IP Address 1-13

Where to Go Next **1-14**
 Other Switch Home Page Features **1-15**
 Installing or Connecting Devices to the Switch **1-15**

CHAPTER 2

Product Overview 2-1

Features **2-1**
 Front Panel Description **2-4**
 10/100 Ports **2-8**
 10/100/1000 Ports **2-11**
 SFP Module Slots **2-12**
 SFP Modules **2-12**
 XENPAK Module Slot **2-13**
 LEDs **2-13**
 System LED **2-16**
 RPS LED **2-16**
 Master LED **2-17**
 Port LEDs and Modes **2-17**
 Rear Panel Description **2-23**
 StackWise Ports **2-25**
 Power Connectors **2-25**
 Internal Power Supply Connector **2-25**
 Cisco RPS Connector **2-26**
 Console Port **2-27**
 Management Options **2-28**
 Network Configurations **2-29**

CHAPTER 3**Switch Installation 3-1**

Preparing for Installation 3-2

Warnings 3-2

EMC Regulatory Statements 3-4

U.S.A. 3-4

Class A Notice for Taiwan and Other Traditional Chinese Markets 3-4

VCCI Class A Notice for Japan 3-5

Class A Notice for Korea 3-5

Class A Notice for Hungary 3-6

Installation Guidelines 3-7

Verifying Package Contents 3-9

Verifying Switch Operation 3-10

Connecting a PC or Terminal to the Console Port 3-10

Powering On the Switch and Running POST 3-12

Powering Off the Switch and Disconnecting the Console Port 3-13

Planning the Stack 3-14

Planning Considerations 3-14

Powering Considerations 3-15

Cabling Considerations 3-15

Recommended Cabling Configurations 3-17

Installing the Switch 3-19

Rack Mounting 3-19

Removing Screws from the Switch 3-20

Attaching Brackets to the Catalyst 3750G-24TS Switch 3-21

Attaching Brackets to the Catalyst 3750-24TS, 3750G-24T, 3750G-12S, 3750-24PS, 3750-48PS, 3750G-16TD, and 3750-48TS Switches 3-26

Mounting the Switch in a Rack 3-29

Attaching the Cable Guide 3-31

- Wall Mounting **3-33**
 - Attaching the Brackets to the Switch for Wall-Mounting **3-33**
 - Attaching the RPS Connector Cover **3-34**
 - Mounting the Switch on a Wall **3-35**
 - Table or Shelf Mounting **3-37**
- Connecting StackWise Cable to StackWise Ports **3-38**
- Installing and Removing SFP Modules **3-41**
 - Installing SFP Modules into SFP Module Slots **3-42**
 - Removing SFP Modules from SFP Module Slots **3-44**
- Installing and Removing XENPAK Modules **3-45**
 - Installing a XENPAK Module **3-46**
 - Removing a XENPAK Module **3-49**
- Connecting to the 10/100 and 10/100/1000 Ports **3-51**
- Connecting to an SFP Module **3-55**
 - Connecting to a Fiber-Optic SFP Module **3-56**
 - Connecting to 1000BASE-T SFP Modules **3-58**
- Connecting to a XENPAK Module **3-59**
- Where to Go Next **3-61**

CHAPTER 4

Troubleshooting 4-1

- Understanding POST Results **4-1**
- Clearing the Switch IP Address and Configuration **4-2**
- Diagnosing Problems **4-4**
- Replacing a Failed Stack Member **4-9**

APPENDIX A**Technical Specifications A-1**

APPENDIX B**Connector and Cable Specifications B-1**Connector Specifications **B-1**10/100 and 10/100 /1000 Ports **B-2**SFP Module Ports **B-3**XENPAK Module Ports **B-4**Console Port **B-4**Cable and Adapter Specifications **B-5**Two Twisted-Pair Cable Pinouts **B-5**Four Twisted-Pair Cable Pinouts for 10/100 Ports **B-6**Four Twisted-Pair Cable Pinouts for 1000BASE-T Ports **B-7**Crossover Cable and Adapter Pinouts **B-8**Identifying a Crossover Cable **B-8**Adapter Pinouts **B-9**

APPENDIX C**Configuring the Switch with the CLI-Based Setup Program C-1**Accessing the CLI **C-2**Accessing the CLI Through Express Setup **C-2**Accessing the CLI Through the Console Port **C-3**Taking Out What You Need **C-4**Stacking the Switches (Optional) **C-5**Connecting to the Console Port **C-7**Starting the Terminal Emulation Software **C-9**Connecting to a Power Source **C-9**Entering the Initial Configuration Information **C-11**IP Settings **C-11**Completing the Setup Program **C-11**

APPENDIX D

Translated Safety Warnings D-1

- Attaching the Cisco RPS (model PWR300-AC-RPS-N1) **D-1**
- Attaching the Cisco RPS (model PWR675-AC-RPS-N1) **D-3**
- Shock Hazard From Interconnections **D-4**
- Installation Warning **D-8**
- Installation Instructions **D-9**
- Jewelry Removal Warning **D-10**
- Stacking the Chassis Warning **D-12**
- Main Disconnecting Device **D-14**
- Grounded Equipment Warning **D-15**
- Installing or Replacing the Unit **D-16**
- Overtemperature Warning **D-18**
- Working During Lightning Activity **D-20**
- Product Disposal Warning **D-21**
- Chassis Warning for Rack-Mounting and Servicing **D-23**
- Redundant Power Supply Connection Warning **D-27**
- Switch Installation Warning **D-29**
- Restricted Area **D-30**
- Ethernet Cable Shielding in Offices **D-32**
- Class 1 Laser Product **D-33**
- Laser Beam Exposure **D-35**
- Laser Radiation **D-36**

INDEX



Cisco 90-Day Limited Hardware Warranty Terms

There are special terms applicable to your hardware warranty and various services that you can use during the warranty period. Your formal Warranty Statement, including the warranties and license agreements applicable to Cisco software, is available on Cisco.com. Follow these steps to access and download the *Cisco Information Packet* and your warranty and license agreements from Cisco.com.

1. Launch your browser, and go to this URL:

http://www.cisco.com/univercd/cc/td/doc/es_inpk/cetrans.htm

The Warranties and License Agreements page appears.

2. To read the *Cisco Information Packet*, follow these steps:

- a. Click the **Information Packet Number** field, and make sure that the part number 78-5235-03A0 is highlighted.
- b. Select the language in which you would like to read the document.
- c. Click **Go**.

The Cisco Limited Warranty and Software License page from the Information Packet appears.

- d. Read the document online, or click the **PDF** icon to download and print the document in Adobe Portable Document Format (PDF).



Note You must have Adobe Acrobat Reader to view and print PDF files. You can download the reader from Adobe's website: <http://www.adobe.com>

3. To read translated and localized warranty information about your product, follow these steps:
 - a. Enter this part number in the Warranty Document Number field:
78-5236-01C0
 - b. Select the language in which you would like to read the document.
 - c. Click **Go**.
The Cisco warranty page appears.
 - d. Review the document online, or click the **PDF** icon to download and print the document in Adobe Portable Document Format (PDF).

You can also contact the Cisco service and support website for assistance:

http://www.cisco.com/public/Support_root.shtml.

Duration of Hardware Warranty

Ninety (90) days.

Replacement, Repair, or Refund Policy for Hardware

Cisco or its service center will use commercially reasonable efforts to ship a replacement part within ten (10) working days after receipt of a Return Materials Authorization (RMA) request. Actual delivery times can vary, depending on the customer location.

Cisco reserves the right to refund the purchase price as its exclusive warranty remedy.

To Receive a Return Materials Authorization (RMA) Number

Contact the company from whom you purchased the product. If you purchased the product directly from Cisco, contact your Cisco Sales and Service Representative.

Complete the information below, and keep it for reference:

Company product purchased from	
Company telephone number	
Product model number	
Product serial number	
Maintenance contract number	





Preface

Audience

This guide is for the networking or computer technician responsible for installing the Catalyst 3750 switches. We assume that you are familiar with the concepts and terminology of Ethernet and local area networking.

Purpose

This guide documents the hardware features of the Catalyst 3750 family of switches. It describes the physical and performance characteristics of each switch, explains how to install a switch, and provides troubleshooting information.

This guide does not describe system messages that you might receive or how to configure your switch. For more information, refer to the switch software configuration guide, the switch command reference, and the switch system message guide on the Cisco.com Product Documentation home page. For information about the standard Cisco IOS Release 12.1 commands or Cisco IOS Release 12.2 commands, refer to the Cisco IOS documentation set on Cisco.com.

Conventions

This document uses these conventions and symbols for notes, cautions, and warnings:



Note

Means *reader take note*. Notes contain helpful suggestions or references to materials not contained in this manual.



Caution

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.



Warning

IMPORTANT SAFETY INSTRUCTIONS

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device.

SAVE THESE INSTRUCTIONS

Waarschuwing

BELANGRIJKE VEILIGHEIDSINSTRUCTIES

Dit waarschuwingssymbool betekent gevaar. U verkeert in een situatie die lichamelijk letsel kan veroorzaken. Voordat u aan enige apparatuur gaat werken, dient u zich bewust te zijn van de bij elektrische schakelingen betrokken risico's en dient u op de hoogte te zijn van de standaard praktijken om ongelukken te voorkomen. Gebruik het nummer van de verklaring onderaan de waarschuwing als u een vertaling van de waarschuwing die bij het apparaat wordt geleverd, wilt raadplegen.

BEWAAR DEZE INSTRUCTIES

Varoitus TÄRKEITÄ TURVALLISUUSOHJEITA

Tämä varoitusmerkki merkitsee vaaraa. Tilanne voi aiheuttaa ruumiillisia vammoja. Ennen kuin käsittelet laitteistoa, huomioi sähköpiirien käsittelemiseen liittyvät riskit ja tutustu onnettomuuksien yleisiin ehkäisytapoihin. Turvallisuusvaroitusten käännökset löytyvät laitteen mukana toimitettujen käännettyjen turvallisuusvaroitusten joukosta varoitusten lopussa näkyvien lausuntonumeroiden avulla.

SÄILYTÄ NÄMÄ OHJEET**Attention IMPORTANTES INFORMATIONS DE SÉCURITÉ**

Ce symbole d'avertissement indique un danger. Vous vous trouvez dans une situation pouvant entraîner des blessures ou des dommages corporels. Avant de travailler sur un équipement, soyez conscient des dangers liés aux circuits électriques et familiarisez-vous avec les procédures couramment utilisées pour éviter les accidents. Pour prendre connaissance des traductions des avertissements figurant dans les consignes de sécurité traduites qui accompagnent cet appareil, référez-vous au numéro de l'instruction situé à la fin de chaque avertissement.

CONSERVEZ CES INFORMATIONS**Warnung WICHTIGE SICHERHEITSHINWEISE**

Dieses Warnsymbol bedeutet Gefahr. Sie befinden sich in einer Situation, die zu Verletzungen führen kann. Machen Sie sich vor der Arbeit mit Geräten mit den Gefahren elektrischer Schaltungen und den üblichen Verfahren zur Vorbeugung vor Unfällen vertraut. Suchen Sie mit der am Ende jeder Warnung angegebenen Anweisungsnummer nach der jeweiligen Übersetzung in den übersetzten Sicherheitshinweisen, die zusammen mit diesem Gerät ausgeliefert wurden.

BEWAHREN SIE DIESE HINWEISE GUT AUF.

Avvertenza IMPORTANTI ISTRUZIONI SULLA SICUREZZA

Questo simbolo di avvertenza indica un pericolo. La situazione potrebbe causare infortuni alle persone. Prima di intervenire su qualsiasi apparecchiatura, occorre essere al corrente dei pericoli relativi ai circuiti elettrici e conoscere le procedure standard per la prevenzione di incidenti. Utilizzare il numero di istruzione presente alla fine di ciascuna avvertenza per individuare le traduzioni delle avvertenze riportate in questo documento.

CONSERVARE QUESTE ISTRUZIONI**Advarsel VIKTIGE SIKKERHETSINSTRUKSJONER**

Dette advarselssymbolet betyr fare. Du er i en situasjon som kan føre til skade på person. Før du begynner å arbeide med noe av utstyret, må du være oppmerksom på farene forbundet med elektriske kretser, og kjenne til standardprosedyrer for å forhindre ulykker. Bruk nummeret i slutten av hver advarsel for å finne oversettelsen i de oversatte sikkerhetsadvarslene som fulgte med denne enheten.

TA VARE PÅ DISSE INSTRUKSJONENE**Aviso INSTRUÇÕES IMPORTANTES DE SEGURANÇA**

Este símbolo de aviso significa perigo. Você está em uma situação que poderá ser causadora de lesões corporais. Antes de iniciar a utilização de qualquer equipamento, tenha conhecimento dos perigos envolvidos no manuseio de circuitos elétricos e familiarize-se com as práticas habituais de prevenção de acidentes. Utilize o número da instrução fornecido ao final de cada aviso para localizar sua tradução nos avisos de segurança traduzidos que acompanham este dispositivo.

GUARDE ESTAS INSTRUÇÕES

¡Advertencia! INSTRUCCIONES IMPORTANTES DE SEGURIDAD

Este símbolo de aviso indica peligro. Existe riesgo para su integridad física. Antes de manipular cualquier equipo, considere los riesgos de la corriente eléctrica y familiarícese con los procedimientos estándar de prevención de accidentes. Al final de cada advertencia encontrará el número que le ayudará a encontrar el texto traducido en el apartado de traducciones que acompaña a este dispositivo.

GUARDE ESTAS INSTRUCCIONES**Varning! VIKTIGA SÄKERHETSANVISNINGAR**

Denna varningssignal signalerar fara. Du befinner dig i en situation som kan leda till personskada. Innan du utför arbete på någon utrustning måste du vara medveten om farorna med elkretsar och känna till vanliga förfaranden för att förebygga olyckor. Använd det nummer som finns i slutet av varje varning för att hitta dess översättning i de översatta säkerhetsvarningar som medföljer denna anordning.

SPARA DESSA ANVISNINGAR**Figyelem FONTOS BIZTONSÁGI ELOÍRÁSOK**

Ez a figyelmeztető jel veszélyre utal. Sérülésveszélyt rejtő helyzetben van. Mielőtt bármely berendezésen munkát végezte, legyen figyelemmel az elektromos áramkörök okozta kockázatokra, és ismerkedjen meg a szokásos balesetvédelmi eljárásokkal. A kiadványban szereplő figyelmeztetések fordítása a készülékhez mellékelt biztonsági figyelmeztetések között található; a fordítás az egyes figyelmeztetések végén látható szám alapján kereshető meg.

ORIZZE MEG EZEKET AZ UTASÍTÁSOKAT!

Предупреждение

ВАЖНЫЕ ИНСТРУКЦИИ ПО СОБЛЮДЕНИЮ ТЕХНИКИ БЕЗОПАСНОСТИ

Этот символ предупреждения обозначает опасность. То есть имеет место ситуация, в которой следует опасаться телесных повреждений. Перед эксплуатацией оборудования выясните, каким опасностям может подвергаться пользователь при использовании электрических цепей, и ознакомьтесь с правилами техники безопасности для предотвращения возможных несчастных случаев. Воспользуйтесь номером заявления, приведенным в конце каждого предупреждения, чтобы найти его переведенный вариант в переводе предупреждений по безопасности, прилагаемом к данному устройству.

СОХРАНИТЕ ЭТИ ИНСТРУКЦИИ

警告

重要的安全性说明

此警告符号代表危险。您正处于可能受到严重伤害的工作环境中。在您使用设备开始工作之前，必须充分意识到触电的危险，并熟练掌握防止事故发生的标准工作程序。请根据每项警告结尾提供的声明号码来找到此设备的安全性警告说明的翻译文本。

请保存这些安全性说明

警告

安全上の重要な注意事項

「危険」の意味です。人身事故を予防するための注意事項が記述されています。装置の取り扱い作業を行うときは、電気回路の危険性に注意し、一般的な事故防止策に留意してください。警告の各国語版は、各注意事項の番号を基に、装置に付属の「Translated Safety Warnings」を参照してください。

これらの注意事項を保管しておいてください。

تحذير

إرشادات الأمان الهامة

يوضح رمز التحذير هذا وجود خطر. وهذا يعني أنك متواجد في مكان قد ينتج عنه التعرض لإصابات. قبل بدء العمل، احذر مخاطر التعرض للصدمات الكهربائية وكن على علم بالإجراءات القياسية للحيلولة دون وقوع أي حوادث. استخدم رقم البيان الموجود في آخر كل تحذير لتحديد مكان ترجمته داخل تحذيرات الأمان المترجمة التي تأتي مع الجهاز. قم بحفظ هذه الإرشادات

Upozorenje

VAŽNE SIGURNOSNE NAPOMENE

Ovaj simbol upozorenja predstavlja opasnost. Nalazite se u situaciji koja može prouzročiti tjelesne ozljede. Prije rada s bilo kojim uređajem, morate razumjeti opasnosti vezane uz električne sklopove, te biti upoznati sa standardnim načinima izbjegavanja nesreća. U prevedenim sigurnosnim upozorenjima, priloženima uz uređaj, možete prema broju koji se nalazi uz pojedino upozorenje pronaći i njegov prijevod.

SAČUVAJTE OVE UPUTE

Upozornění

DŮLEŽITÉ BEZPEČNOSTNÍ POKYNY

Tento upozorňující symbol označuje nebezpečí. Jste v situaci, která by mohla způsobit nebezpečí úrazu. Před prací na jakémkoliv vybavení si uvědomte nebezpečí související s elektrickými obvody a seznamte se se standardními opatřeními pro předcházení úrazům. Podle čísla na konci každého upozornění vyhledejte jeho překlad v přeložených bezpečnostních upozorněních, která jsou přiložena k zařízení.

USCHOVEJTE TYTO POKYNY

Προειδοποίηση ΣΗΜΑΝΤΙΚΕΣ ΟΔΗΓΙΕΣ ΑΣΦΑΛΕΙΑΣ

Αυτό το προειδοποιητικό σύμβολο σημαίνει κίνδυνο. Βρίσκεστε σε κατάσταση που μπορεί να προκαλέσει τραυματισμό. Πριν εργαστείτε σε οποιοδήποτε εξοπλισμό, να έχετε υπόψη σας τους κινδύνους που σχετίζονται με τα ηλεκτρικά κυκλώματα και να έχετε εξοικειωθεί με τις συνήθειες πρακτικές για την αποφυγή ατυχημάτων. Χρησιμοποιήστε τον αριθμό δήλωσης που παρέχεται στο τέλος κάθε προειδοποίησης, για να εντοπίσετε τη μετάφρασή της στις μεταφρασμένες προειδοποιήσεις ασφαλείας που συνοδεύουν τη συσκευή.

ΦΥΛΑΞΤΕ ΑΥΤΕΣ ΤΙΣ ΟΔΗΓΙΕΣ

Figyelem FONTOS BIZTONSÁGI ELOÍRÁSOK

Ez a figyelmeztető jel veszélyre utal. Sérülésveszélyt rejtő helyzetben van. Mielőtt bármely berendezésen munkát végezne, legyen figyelemmel az elektromos áramkörök okozta kockázatokra, és ismerkedjen meg a szokásos balesetvédelmi eljárásokkal. A kiadványban szereplő figyelmeztetések fordítása a készülékhez mellékelt biztonsági figyelmeztetések között található; a fordítás az egyes figyelmeztetések végén látható szám alapján kereshető meg.

ORIZZE MEG EZEKET AZ UTASÍTÁSOKAT!

Предупреждение ВАЖНЫЕ ИНСТРУКЦИИ ПО СОБЛЮДЕНИЮ ТЕХНИКИ БЕЗОПАСНОСТИ

Этот символ предупреждения обозначает опасность. То есть имеет место ситуация, в которой следует опасаться телесных повреждений. Перед эксплуатацией оборудования выясните, каким опасностям может подвергаться пользователь при использовании электрических цепей, и ознакомьтесь с правилами техники безопасности для предотвращения возможных несчастных случаев. Воспользуйтесь номером заявления, приведенным в конце каждого предупреждения, чтобы найти его переведенный вариант в переводе предупреждений по безопасности, прилагаемом к данному устройству.

СОХРАНИТЕ ЭТИ ИНСТРУКЦИИ

警告 重要的安全性说明

此警告符号代表危险。您正处于可能受到严重伤害的工作环境中。在您使用设备开始工作之前，必须充分意识到触电的危险，并熟练掌握防止事故发生的标准工作程序。请根据每项警告结尾提供的声明号码来找到此设备的安全性警告说明的翻译文本。

请保存这些安全性说明

警告 安全上の重要な注意事項

「危険」の意味です。人身事故を予防するための注意事項が記述されています。装置の取り扱い作業を行うときは、電気回路の危険性に注意し、一般的な事故防止策に留意してください。警告の各国語版は、各注意事項の番号を基に、装置に付属の「Translated Safety Warnings」を参照してください。

これらの注意事項を保管しておいてください。

تحذير**إرشادات الأمان الهامة**

يوضح رمز التحذير هذا وجود خطر. وهذا يعني أنك متواجد في مكان قد ينتج عنه التعرض لإصابات. قبل بدء العمل، احذر مخاطر التعرض للصدمات الكهربائية وكن على علم بالإجراءات القياسية للحيلولة دون وقوع أي حوادث. استخدم رقم البيان الموجود في آخر كل تحذير لتحديد مكان ترجمته داخل تحذيرات الأمان المترجمة التي تأتي مع الجهاز. قم بحفظ هذه الإرشادات

Upozorenje **VAŽNE SIGURNOSNE NAPOMENE**

Ovaj simbol upozorenja predstavlja opasnost. Nalazite se u situaciji koja može prouzročiti tjelesne ozljede. Prije rada s bilo kojim uređajem, morate razumjeti opasnosti vezane uz električne sklopove, te biti upoznati sa standardnim načinima izbjegavanja nesreća. U prevedenim sigurnosnim upozorenjima, priloženima uz uređaj, možete prema broju koji se nalazi uz pojedino upozorenje pronaći i njegov prijevod.

SAČUVAJTE OVE UPUTE

Related Publications

You can order printed copies of documents with a DOC-xxxxxx= number. For more information, see the “[Obtaining Documentation](#)” section on page xxv.

These documents provide complete information about the switch and are available from this Cisco.com site:

<http://www.cisco.com/univercd/cc/td/doc/product/lan/cat3750/index.htm>

- *Release Notes for the Catalyst 3750 Switch* (not orderable but available on Cisco.com)



Note

Before installing, configuring, or upgrading the switch, refer to the release notes on Cisco.com for the latest information.

- *Catalyst 3750 Switch Software Configuration Guide* (order number DOC-7815164=)
- *Catalyst 3750 Switch Command Reference* (order number DOC-7815165=)
- *Catalyst 3750 Switch System Message Guide* (order number DOC-7815166=)
- Cluster Management Suite (CMS) online help (available only from the switch CMS software)
- *Catalyst 3750 Switch Hardware Installation Guide* (order number DOC-7815136=)
- *Cisco Small Form-Factor Pluggable Modules Installation Notes* (order number DOC-7815160=)
- *Cisco Small Form-Factor Pluggable Modules Compatibility Matrix* (not orderable but available on Cisco.com)
- *Compatibility Matrix for 1000BASE-T Small Form-Factor Pluggable Modules* (not orderable but available on Cisco.com)

Obtaining Documentation

Cisco documentation and additional literature are available on Cisco.com. Cisco also provides several ways to obtain technical assistance and other technical resources. These sections explain how to obtain technical information from Cisco Systems.

Cisco.com

You can access the most current Cisco documentation on the World Wide Web at this URL:

<http://www.cisco.com/univercd/home/home.htm>

You can access the Cisco website at this URL:

<http://www.cisco.com>

International Cisco websites can be accessed from this URL:

http://www.cisco.com/public/countries_languages.shtml

Ordering Documentation

You can find instructions for ordering documentation at this URL:

http://www.cisco.com/univercd/cc/td/doc/es_inpk/pdi.htm

You can order Cisco documentation in these ways:

- Registered Cisco.com users (Cisco direct customers) can order Cisco product documentation from the Ordering tool:

<http://www.cisco.com/en/US/partner/ordering/index.shtml>

- Nonregistered Cisco.com users can order documentation through a local account representative by calling Cisco Systems Corporate Headquarters (California, USA) at 408 526-7208 or, elsewhere in North America, by calling 800 553-NETS (6387).

Documentation Feedback

You can submit e-mail comments about technical documentation to bug-doc@cisco.com.

You can submit comments by using the response card (if present) behind the front cover of your document or by writing to the following address:

Cisco Systems
Attn: Customer Document Ordering
170 West Tasman Drive
San Jose, CA 95134-9883

We appreciate your comments.

Obtaining Technical Assistance

For all customers, partners, resellers, and distributors who hold valid Cisco service contracts, the Cisco Technical Assistance Center (TAC) provides 24-hour-a-day, award-winning technical support services, online and over the phone. Cisco.com features the Cisco TAC website as an online starting point for technical assistance. If you do not hold a valid Cisco service contract, please contact your reseller.

Cisco TAC Website

The Cisco TAC website provides online documents and tools for troubleshooting and resolving technical issues with Cisco products and technologies. The Cisco TAC website is available 24 hours a day, 365 days a year. The Cisco TAC website is located at this URL:

<http://www.cisco.com/tac>

Accessing all the tools on the Cisco TAC website requires a Cisco.com user ID and password. If you have a valid service contract but do not have a login ID or password, register at this URL:

<http://tools.cisco.com/RPF/register/register.do>

Opening a TAC Case

Using the online TAC Case Open Tool is the fastest way to open P3 and P4 cases. (P3 and P4 cases are those in which your network is minimally impaired or for which you require product information.) After you describe your situation, the TAC Case Open Tool automatically recommends resources for an immediate solution. If your issue is not resolved using the recommended resources, your case will be assigned to a Cisco TAC engineer. The online TAC Case Open Tool is located at this URL:

<http://www.cisco.com/tac/caseopen>

For P1 or P2 cases (P1 and P2 cases are those in which your production network is down or severely degraded) or if you do not have Internet access, contact Cisco TAC by telephone. Cisco TAC engineers are assigned immediately to P1 and P2 cases to help keep your business operations running smoothly.

To open a case by telephone, use one of the following numbers:

Asia-Pacific: +61 2 8446 7411 (Australia: 1 800 805 227)

EMEA: +32 2 704 55 55

USA: 1 800 553-2447

For a complete listing of Cisco TAC contacts, go to this URL:

<http://www.cisco.com/warp/public/687/Directory/DirTAC.shtml>

TAC Case Priority Definitions

To ensure that all cases are reported in a standard format, Cisco has established case priority definitions.

Priority 1 (P1)—Your network is “down” or there is a critical impact to your business operations. You and Cisco will commit all necessary resources around the clock to resolve the situation.

Priority 2 (P2)—Operation of an existing network is severely degraded, or significant aspects of your business operation are negatively affected by inadequate performance of Cisco products. You and Cisco will commit full-time resources during normal business hours to resolve the situation.

Priority 3 (P3)—Operational performance of your network is impaired, but most business operations remain functional. You and Cisco will commit resources during normal business hours to restore service to satisfactory levels.

Priority 4 (P4)—You require information or assistance with Cisco product capabilities, installation, or configuration. There is little or no effect on your business operations.

Obtaining Additional Publications and Information

Information about Cisco products, technologies, and network solutions is available from various online and printed sources.

- Cisco Marketplace provides a variety of Cisco books, reference guides, and logo merchandise. Go to this URL to visit the company store:

<http://www.cisco.com/go/marketplace/>

- The Cisco *Product Catalog* describes the networking products offered by Cisco Systems, as well as ordering and customer support services. Access the Cisco Product Catalog at this URL:

<http://cisco.com/univercd/cc/td/doc/pcat/>

- *Cisco Press* publishes a wide range of general networking, training and certification titles. Both new and experienced users will benefit from these publications. For current Cisco Press titles and other information, go to Cisco Press online at this URL:

<http://www.ciscopress.com>

- *Packet* magazine is the Cisco quarterly publication that provides the latest networking trends, technology breakthroughs, and Cisco products and solutions to help industry professionals get the most from their networking investment. Included are networking deployment and troubleshooting tips, configuration examples, customer case studies, tutorials and training, certification information, and links to numerous in-depth online resources. You can access Packet magazine at this URL:

<http://www.cisco.com/packet>

- *iQ Magazine* is the Cisco bimonthly publication that delivers the latest information about Internet business strategies for executives. You can access iQ Magazine at this URL:

<http://www.cisco.com/go/iqmagazine>

- *Internet Protocol Journal* is a quarterly journal published by Cisco Systems for engineering professionals involved in designing, developing, and operating public and private internets and intranets. You can access the Internet Protocol Journal at this URL:

<http://www.cisco.com/ipj>

- Training—Cisco offers world-class networking training. Current offerings in network training are listed at this URL:

<http://www.cisco.com/en/US/learning/index.html>



Using Express Setup

Express Setup is a browser-based program that you can use to set up and configure the switch. You assign the IP information so that the switch can connect to local routers and the Internet. The IP address is also required if you plan to further configure the switch. This chapter provides an Express Setup procedure for a standalone switch.

Express Setup is supported on switches running Cisco IOS Release 12.1(14)EA1 or later. When you are installing a switch, refer to the Cisco IOS release label on the rear panel of the switch to determine the software release.

For setup instructions using the CLI-based setup program, go to [Appendix C, “Configuring the Switch with the CLI-Based Setup Program.”](#)



Note

Before connecting the switch to a power source, review the safety warnings in [Chapter 3, “Switch Installation.”](#)

The setup procedure includes these steps:

- [Taking Out What You Need, page 1-3](#)
- [Powering On the Switch, page 1-4](#)
- [Starting Express Setup, page 1-5](#)
- [Configuring the Switch, page 1-11](#)
- [Where to Go Next, page 1-14](#)

**Caution**

Do not start Express Setup when there are any devices connected to the switch or connect a switch that is already in Express Setup mode to any device other than the PC or workstation that is being used to configure it.

The switch acts as a Dynamic Host Configuration Protocol (DHCP) server during the Express Setup procedure. Only the PC or workstation connected to the switch after Express Setup is started should receive an address from the switch. If your PC has a statically-assigned IP address, you should change your PC to use DHCP temporarily to complete the Express Setup procedure.

You need this information from your system administrator before you complete the setup program:

- Fixed IP address
- Subnet mask (IP netmask)
- Default gateway IP address


You can also configure these optional parameters through the Express Setup program:

- Local access password
- Telnet access password
- Names of the Simple Network Management Protocol (SNMP) read and write community strings if you are going to use a network-management program like CiscoWorks
- Host name, system contact, and system location

Taking Out What You Need

Remove the items shown in [Figure 1-1](#) from the shipping container.

Figure 1-1 Catalyst 3750 Switch and AC Power Cord



1	Switch	2	AC power cord
---	--------	---	---------------

You also need to provide an Ethernet (Category 5) straight-through cable (not included), as shown in [Figure 1-2](#), to connect the switch to your PC or workstation.

Figure 1-2 Ethernet Cable




Powering On the Switch

Complete these steps to power on the switch:

- Step 1** Connect one end of the AC power cord to the power connector on the switch rear panel, as shown in [Figure 1-3](#).

Figure 1-3 Connecting the Power



1	Switch	2	AC power cord
----------	--------	----------	---------------

- Step 2** Connect the other end of the power cable to a grounded AC outlet.

As the switch powers on, it begins the power-on self-test (POST), a series of tests that runs automatically to ensure that the switch functions properly. POST lasts approximately 1 minute.

When the switch begins POST, the System, the RPS, the Master, the Status, the Duplex, the Speed, and the Stack LEDs turn green. (On the Catalyst 3750-24PS and 3750-48PS switches, the Power over Ethernet [PoE] LED also turns green as POST begins.) The System LED flashes green, and the other LEDs remain continuous green.

When POST completes successfully, the System LED remains green. The RPS LED remains green for some time and then returns to its operating status. The other LEDs turn off and return to their operating status. When POST fails, the System LED turns amber. If POST fails, see [Chapter 4, “Troubleshooting,”](#) to determine a course of action.

Starting Express Setup

Express Setup provides the minimum configuration for a switch. You do not create a username with Express Setup. To create a username for the switch, use the Cluster Management Suite (CMS) or the command-line interface (CLI).



Note

Before starting Express Setup, verify that the switch has passed POST and that the SYST and STAT LEDs are green. For information about troubleshooting a POST failure, see the [“Understanding POST Results”](#) section on page 4-1. You cannot start Express Setup until POST has completed.



Caution

Do not start Express Setup when there are any devices connected to the switch. The switch acts as a DHCP server during the Express Setup procedure, and only the PC or workstation connected to the switch after Express Startup is started should receive a DHCP address from the switch.


Follow these steps to start the Express Setup program:

-
- Step 1** Verify that no devices are connected to the switch.
- Step 2** Press and hold the Mode button, as shown in [Figure 1-4](#), until the four LEDs above the Mode button turn green. This takes approximately 2 seconds.




Note On the Catalyst 3750-24PS and 3750-48PS switches, the five LEDs above the Mode button turn green during this step.

Figure 1-4 Catalyst 3750 switch Mode Button



1 Mode button

Figure 1-5 Catalyst 3750-24PS and 3750-48PS Switch Mode Button

1 Mode button

Step 3 Release the Mode button.


**Note**

If all of the LEDs begin to blink after you press the Mode button, release it. Blinking LEDs mean that the switch has already been configured and cannot go into Express Setup mode. For more information, see the [“Clearing the Switch IP Address and Configuration”](#) section on page 4-2.

Step 4 Connect a straight-through Ethernet cable (not included) to an Ethernet port on the front panel of the switch, as shown in [Figure 1-6](#).

**Caution**

Do not connect the switch to any device other than the PC or workstation being used to configure it.

Figure 1-6 Connecting the Switch and PC or Workstation Ethernet Ports

97174

1	Switch	3	PC or workstation
2	Ethernet cable		

- Step 5** Connect the other end of the cable to the Ethernet port on the PC or workstation. Verify that the port status LEDs on both connected Ethernet ports are green.
- Step 6** Wait approximately 30 seconds *after* the port LEDs turn green, and launch a web browser on your PC or workstation.
- Step 7** Enter the IP address **10.0.0.1**, as shown in [Figure 1-7](#), and press **Enter**.

Figure 1-7 Entering the IP Address

The Express Setup home page appears, as shown in [Figure 1-8](#).

Figure 1-8 Express Setup Home Page

If the Express Setup does not run, or the Express Setup home page does not appear in your browser:

- Did you wait 30 seconds after connecting the switch and PC or workstation before entering the IP address in your browser?
If not, wait 30 seconds, and re-enter **10.0.0.1** in the browser, and press **Enter**.
- Did you enter the wrong address in the browser, or is there an error message displayed in the browser window?
Re-enter **10.0.0.1** in the browser, and press **Enter**.
- Did you connect a crossover instead of a straight-through Ethernet cable between an Ethernet port of the switch and the Ethernet port of the PC or workstation?



Note See the [“Identifying a Crossover Cable”](#) section on page B-8 for instructions on identifying a crossover cable.

**Note**

For switches running Cisco IOS Release 12.2(18)SE or later, the automatic medium-dependent interface crossover (Auto-MDIX) feature enables the switch to detect the required cable type for copper Ethernet connections and configures the interfaces accordingly. Therefore, you can use either a crossover or a straight-through cable for connections to a copper 10/100, 10/100/1000, or 1000BASE-T SFP module port on the switch, regardless of the type of device on the other end of the connection.

The Auto-MDIX feature is enabled by default on switches running Cisco IOS Release 12.2(18)SE or later.

If not, reconnect the straight-through cable to the Ethernet port on the switch and PC or workstation. Wait 30 seconds before entering **10.0.0.1** in the browser.

- Did you verify that POST successfully ran before starting Express Setup?
If not, make sure that only the SYST and STAT LEDs are green before pressing the Mode button to begin Express Setup.

**Note**

The rest of this chapter explains how to configure a switch by using the Express Setup web page. To configure the switch by using the command-line interface (CLI)-based setup program, see [Appendix C, “Configuring the Switch with the CLI-Based Setup Program.”](#)

Configuring the Switch

Follow these steps to configure your switch by using Express Setup:

-
- Step 1** Contact your system administrator and obtain the management VLAN ID, the IP address, the IP subnet mask, and the default gateway for your switch.
- Step 2** Enter a VLAN ID in the **Management Interface (VLAN ID)** field. This is the management interface through which you manage the switch and to which you assign IP information. The Management Interface field displays **1** by default. The VLAN ID range for this field is 1 to 1001.



Note The **Management Interface (VLAN ID)** field is only available on switches running Cisco IOS Release 12.1(20)EA1 or 12.2(18)SE or later.

- Step 3** Enter the IP address of the switch in the **IP Address** field.
- Step 4** Click the drop-down arrow in the **IP Subnet Mask** field, and select an **IP Subnet Mask**.
- Step 5** Enter the IP address for the default gateway in the **Default Gateway** field.
- A gateway (router or dedicated network device) is a system that connects a network on one subnet to one or more networks on a different subnet.
- You must specify a default gateway if the management workstation and the switch are on different IP segments.
- Step 6** Enter your password in the **Switch Password** field.
- The password can be from 1 to 25 alphanumeric characters, can start with a number, is case sensitive, allows embedded spaces, but does not allow embedded spaces at the beginning or end.
- Step 7** Enter your password again in the **Confirm Switch Password** field.
- You do not enter a username for the switch. After the switch is configured with an IP address, you can use CMS to configure a username.
- Step 8** (Optional) Enter a host name for the switch in the **Host Name** field. The host name is limited to 31 characters; embedded spaces are not allowed.
- Step 9** (Optional) Enter the name of your system contact in the **System Contact** field. This identifies the system administrator for the switch or network.

- Step 10** (Optional) Enter your system location in the **System Location** field. This identifies the physical location of the switch.
- Step 11** (Optional) Click **Enable** in the **Telnet Access** field if you are going to use Telnet to manage the switch by using the CLI. If you enable Telnet access, you must enter a Telnet password:
- a. Enter a password in the **Telnet Password** field. The Telnet password can be from 1 to 25 alphanumeric characters, is case sensitive, allows embedded spaces, but does not allow embedded spaces at the beginning or end.
 - b. Enter the Telnet password again in the **Confirm Telnet Password** field.
- Step 12** (Optional) Click **Enable** to configure Simple Network Management Protocol (SNMP). Enable SNMP only if you plan to manage switches by using Cisco Works or another SNMP-based network-management system.
- If you enable SNMP, you must enter a community string in the **SNMP Read Community** field, the **SNMP Write Community** field, or both. SNMP community strings authenticate access to MIB objects. Embedded spaces are not allowed in SNMP community strings. If you set the SNMP read community, users can access MIB objects, but cannot modify them. If you set the SNMP write community, users can access and modify MIB objects.
- Step 13** Click **Save** to save your settings to the switch, or click **Cancel** to clear your settings.
-

The switch exits Express Setup mode.

Your switch is now configured with the new IP address. You can install the switch in your production network.

Rerunning Express Setup

If you did not click Save at the end of the [Configuring the Switch](#) section, you can rerun Express Setup by clicking **Express Setup** on the Switch home page.

If you have entered a wrong IP address or need to change the IP address of your switch, you can clear the IP address on your switch by following the steps in the [“Clearing the Switch IP Address and Configuration”](#) section on page 4-2.

Verifying Switch IP Address

This procedure is optional. After you have installed the switch in your network, follow these steps to verify the IP address configured on your switch:

-
- Step 1** Launch a web browser on a PC or workstation that is connected the network.
 - Step 2** Enter the IP address of your switch (for example: *172.20.139.142.*) The switch home page appears, as shown in Figure 1-9.
-

Figure 1-9 Switch Home Page

Close Window Toolkit: Roll over tools below

CISCO SYSTEMS

Cisco WS-C3750-48P

HOME

- EXPRESS SETUP
- CLUSTER
- MANAGEMENT SUITE
- TOOLS
- HELP RESOURCES

Home: Master Summary Status

Network Identity	
IP Address	10.89.153.42
MAC Address	00:03:FD:63:A4:80

System Details	
Host Name	Bilbo48_CMS
System Uptime	3 days, 4 hours, 46 minutes
Serial Number	
Software Version	12.1(0.0.713)EA1
System Contact	
System Location	

Refresh

Close Window Copyright (c) 2003 by Cisco Systems, Inc.

97178

Where to Go Next

After you have saved your configuration to the switch, you can install the switch or further configure it by using CMS or the CLI.

Other Switch Home Page Features

These additional features are available from the switch home page, as shown on the left menu bar in [Figure 1-9 on page 1-14](#):

- **Cluster Management Suite**—Launch the CMS, through which you can configure and monitor a switch or switch clusters, display network topologies to gather link information, and display switch images to modify switch- and port-level settings. For more information, refer to the switch software configuration guide.
- **Tools**—Access diagnostic and monitoring tools such as Telnet and Extended Ping.
- **Help Resources**—Access Catalyst 3750 documentation.

Installing or Connecting Devices to the Switch

For detailed installation procedures on mounting your switch on or under a desk or on a wall, or connecting devices to the switch, see [Chapter 3, “Switch Installation.”](#)



Product Overview

The Catalyst 3750 family of switches—also referred to as the *switches*—are stackable Ethernet switches to which you can connect devices like Cisco IP Phones, Cisco Wireless Access Points workstations, and other network devices such as servers, routers, and other switches. This chapter provides a functional overview of the Catalyst 3750 switch models. These topics are included:

- [Features, page 2-1](#)
- [Front Panel Description, page 2-4](#)
- [Rear Panel Description, page 2-23](#)
- [Management Options, page 2-28](#)

Features

The switches can be deployed as backbone switches, aggregating 10BASE-T, 100BASE-TX, and 1000BASE-T Ethernet traffic from other network devices. Refer to the switch software configuration guide for examples showing how you might deploy the switches in your network.

Figure 2-1 through Figure 2-8 show the Catalyst 3750 switches.

These are the switch features:

- Hardware
 - Catalyst 3750-24TS—24 10/100 Ethernet ports and 2 small form-factor pluggable (SFP) module slots
 - Catalyst 3750G-24T—24 10/100/1000 Ethernet ports
 - Catalyst 3750G-24TS—24 10/100/1000 Ethernet ports and 4 SFP module slots
 - Catalyst 3750-48TS—48 10/100 Ethernet ports and 4 SFP module slots
 - Catalyst 3750G-12S—12 SFP module slots
 - Catalyst 3750-24PS switch—24 10/100 Power over Ethernet (PoE) ports and 2 SFP module slots
 - Catalyst 3750-48PS switch—48 10/100 PoE ports and 4 SFP module slots
 - Catalyst 3750G-16TD switch—16 10/100/1000 Ethernet ports and 1 10-Gigabit Ethernet XENPAK module slot



Note The 10-Gigabit Ethernet XENPAK modules are referred to as 10-Gigabit Ethernet module ports in the software documentation.

- The switches support these SFP modules:
 - 1000BASE-SX
 - 1000BASE-LX
 - 1000BASE-ZX
 - 1000BASE-T
 - CWDM



Note When installed in Catalyst 3750 switches, 1000BASE-T SFP modules can either operate at 10, 100, or 1000 Mbps in full-duplex mode or in half-duplex mode at 10 or 100 Mbps.

- For a list of the XENPAK modules that the Catalyst 3750G-16TD switch supports, refer to the Catalyst 3750 release notes.
- Configuration
 - For 10/100 ports, autonegotiates the speed and duplex settings
 - For 10/100/1000 ports, autonegotiates the speed and supports only full-duplex mode
- The Catalyst 3750 switches support stacking. You can stack up to nine switches in a stack by cabling the StackWise ports. StackWise ports are not user-configurable.
- Switches are hot-swappable
- Power redundancy
 - Connection for optional Cisco RPS 300 redundant power system that operates on AC input and supplies backup DC power output to the Catalyst 3750-24TS, 3750G-24T, 3750-48TS, and 3750G-12S switches.

**Note**


The Cisco RPS 300 does not support the Catalyst 3750G-24TS, 3750-24PS, 3750-48PS, and 3750G-16TD switches.

- Connection for optional Cisco RPS 675 redundant power system that operates on AC input and supplies backup DC power output to the family of Catalyst 3750 switches.

Front Panel Description

The Catalyst 3750-24TS 10/100 ports are numbered 1 through 24. The ports are grouped in pairs. The first member of the pair (port 1) is above the second member (port 2), as shown in [Figure 2-1](#). Port 3 is above port 4, and so on. The SFP module slots are numbered 1 (left) and 2 (right).


Figure 2-1 Catalyst 3750-24TS Front Panel



1	10/100 ports	2	SFP module slots
----------	--------------	----------	------------------


The 10/100/1000 ports on the Catalyst 3750G-24T and 3750G-24TS are grouped in pairs. The first member of the pair (port 1) is above the second member (port 2), as shown in [Figure 2-2](#) and [Figure 2-3](#). Port 3 is above port 4, and so on. In [Figure 2-3](#), the SFP module slots are numbered 25 to 28.

Figure 2-2 Catalyst 3750G-24T Front Panel



1	10/100/1000 ports
----------	-------------------


Figure 2-3 Catalyst 3750G-24TS Front Panel



1	10/100 ports	2	SFP module slots
----------	--------------	----------	------------------

The Catalyst 3750G-12S SFP module slots are numbered 1 through 12. The slots are grouped in three sets of four, as shown in [Figure 2-4](#).


Figure 2-4 Catalyst 3750G-12S Front Panel



1	SFP module slots
---	------------------

The Catalyst 3750-48TS 10/100 ports are numbered 1 through 48. The ports are grouped in pairs. The first member of the pair (port 1) is above the second member (port 2), as shown in Figure 2-1. Port 3 is above port 4, and so on. The SFP module slots are numbered 1 (top) and 2 (bottom) and so on.


Figure 2-5 Catalyst 3750-48TS Front Panel



1	10/100 ports	2	SFP module slots
---	--------------	---	------------------

The 10/100 PoE ports on the Catalyst 3750-24PS switch are grouped in pairs. The first member of the pair (port 1) is above the second member (port 2), as shown in [Figure 2-6](#). Port 3 is above port 4, and so on. The SFP module slots are numbered 1 and 2.


Figure 2-6 Catalyst 3750-24PS Switch Front Panel



1	10/100 PoE ports	2	SFP module slots
----------	------------------	----------	------------------

The 10/100 PoE ports on the Catalyst 3750-48PS switch are grouped in pairs. The first member of the pair (port 1) is above the second member (port 2), as shown in [Figure 2-7](#). Port 3 is above port 4, and so on. The SFP module slots are numbered 1 to 4.

Figure 2-7 Catalyst 3750-48PS Switch Front Panel




1	10/100 PoE ports	2	SFP module slots
----------	------------------	----------	------------------

The 10/100/1000 ports on the Catalyst 3750G-16TD switch are grouped in pairs. The first member of the pair (port 1) is above the second member (port 2), as shown in [Figure 2-8](#). Port 3 is above port 4, and so on. The XENPAK module slot is numbered 1.

**Note**

The 10-Gigabit Ethernet XENPAK modules are referred to as 10-Gigabit Ethernet module ports in the software documentation.

Figure 2-8 Catalyst 3750G-16TD Switch Front Panel



1	10/100/1000 ports	2	XENPAK module slot
----------	-------------------	----------	--------------------

10/100 Ports

You can set the 10/100 ports on the Catalyst 3750 switches to operate in any combination of half duplex, full duplex, 10 Mbps, or 100 Mbps. You can also set these ports for speed and duplex autonegotiation, in compliance with IEEE 802.3ab. (The default setting is autonegotiate.) When set for autonegotiation, the port senses the speed and duplex settings of the attached device and advertises its own capabilities. If the connected device also supports autonegotiation, the switch port negotiates the best connection (that is, the fastest line speed that both devices support and full-duplex transmission if the attached device supports it) and configures itself accordingly. In all cases, the attached device must be within 328 feet (100 meters).

**Note**

100BASE-TX and 1000BASE-T traffic requires Category 5 cable. 10BASE-T traffic can use Category 3 or Category 4 cables.

When connecting the switch to workstations, servers, routers, and Cisco IP Phones, be sure that the cable is a straight-through cable. When connecting the switch to switches or hubs, use a crossover cable. When using a straight-through or crossover cable for 1000BASE-T connections, be sure to use a twisted four-pair, Category 5 cable for proper operation. Pinouts for the cables are described in [Appendix B, “Connector and Cable Specifications.”](#)

**Note**

You can use the **mdix auto** interface configuration command in the CLI to enable the automatic medium-dependent interface crossover (Auto-MDIX) feature. When the Auto-MDIX feature is enabled, the switch detects the required cable type for copper Ethernet connections and configures the interfaces accordingly. Therefore, you can use either a crossover or a straight-through cable for connections to a copper 10/100, 10/100/1000, or 1000BASE-T SFP module port on the switch, regardless of the type of device on the other end of the connection.

The Auto-MDIX feature is enabled by default on switches running Cisco IOS Release 12.2(18)SE or later. For releases between Cisco IOS Release 12.1(14)EA1 and 12.2(18)SE, the Auto-MDIX feature is disabled by default. For configuration information for this feature, refer to the switch software configuration guide or the switch command reference.

**Warning**

Voltagages that present a shock hazard may exist on Power over Ethernet (PoE) circuits if interconnections are made using uninsulated exposed metal contacts, conductors, or terminals. Avoid using such interconnection methods, unless the exposed metal parts are located within a restricted access location and users and service people who are authorized within the restricted access location are made aware of the hazard. A restricted access area can be accessed only through the use of a special tool, lock and key or other means of security.

The 10/100 ports on the on the Catalyst 3750-24PS and Catalyst 3750-48PS switches provide PoE support for devices compliant with IEEE 802.3af and also provide Cisco pre-standard PoE support for Cisco IP Phones and Cisco Aironet Access Points.

Each of the Catalyst 3750-24PS switch 10/100 ports can deliver up to 15.4 W of PoE. On the Catalyst 3750-48PS switch, any 24 of the 48 10/100 ports can deliver 15.4 W of PoE, or any combination of the 10/100 ports can deliver an average of 7.7 W of PoE at the same time, up to a maximum switch power output of 370 W.

On a per-port basis, you can control whether or not a 10/100 port on a Catalyst 3750-24PS or Catalyst 3750-48PS switch automatically provides power when an IP phone or an access point is connected. CMS and the CLI provide two PoE settings for each 10/100 port: Auto and Never.

When you select the Auto setting, the port only provides power if a valid powered device, such as an IEEE 802.3af-compliant powered device, a Cisco pre-standard IP phone, or a Cisco pre-standard Cisco access point, is connected to it. The Auto setting is the default. However, when you select the Never setting, the port does not provide power even if a Cisco IP phone or an access point is connected to it.

**Note**

You also can connect a Cisco IP phone or Cisco Aironet Access Point to a Catalyst 3750-24PS or Catalyst 3750-48PS switch 10/100 port and to an AC power source. When the powered device is connected to the AC power source, it might begin to use that as its primary power source. In that case, the 10/100 PoE port becomes the backup power source for the powered device.

If the primary source fails, the second power source becomes the primary power source. During the power transfer, an IP Phone might reboot or reestablish link with the switch.

For information about Cisco IP Phones and Cisco Aironet Access Points, refer to the documentation that came with your IP phone or access point.

**Note**

Many legacy powered devices, including older Cisco IP phones and access points that do not fully support IEEE 802.3af, might not support PoE when connected to the switches by a crossover cable.

10/100/1000 Ports

You can set the 10/100/1000 ports to operate in 10, 100, or 1000 Mbps in full duplex. You can also set these ports for speed and duplex autonegotiation in compliance with IEEE 802.3ab. (The default setting is autonegotiate.) When set for autonegotiation, the port senses the speed and duplex settings of the attached device and advertises its own capabilities. If the connected device also supports autonegotiation, the switch port negotiates the best connection (that is, the fastest line speed that both devices support and full-duplex transmission if the attached device supports it) and configures itself accordingly. In all cases, the attached device must be within 328 feet (100 meters).

**Note**

You can configure duplex mode to half, full, or autonegotiate on Gigabit Ethernet interfaces if the speed is set to 10 or 100 Mbps. You cannot configure half-duplex mode on Gigabit Ethernet interfaces if the interface speed is 1000 Mbps.

**Note**

100BASE-TX and 1000BASE-T traffic requires Category 5 cable. 10BASE-T traffic can use Category 3 or Category 4 cables.

When connecting the switch to workstations, servers, routers, and Cisco IP Phones, be sure that the cable is a straight-through cable. When connecting the switch to switches or hubs, use a crossover cable. When using a straight-through or crossover cable for 1000BASE-T connections, be sure to use a twisted four-pair, Category 5 cable for proper operation. Pinouts for the cables are described in [Appendix B, “Connector and Cable Specifications.”](#)

**Note**

You can use the **mdix auto** interface configuration command in the CLI to enable the automatic medium-dependent interface crossover (Auto-MDIX) feature. When the Auto-MDIX feature is enabled, the switch detects the required cable type for copper Ethernet connections and configures the interfaces accordingly. Therefore, you can use either a crossover or a straight-through cable for connections to a copper 10/100, 10/100/1000, or 1000BASE-T SFP module port on the switch, regardless of the type of device on the other end of the connection.

The Auto-MDIX feature is enabled by default on switches running Cisco IOS Release 12.2(18)SE or later. For releases between Cisco IOS Release 12.1(14)EA1 and 12.2(18)SE, the Auto-MDIX feature is disabled by default. For configuration information for this feature, refer to the switch software configuration guide or the switch command reference.

SFP Module Slots

Catalyst 3750 switches with SFP module slots support these SFP modules:

- 1000BASE-SX
- 1000BASE-LX
- 1000BASE-ZX
- 1000BASE-T
- CWDM

For a list of the SFP modules that the switches support, refer to the Catalyst 3750 release notes.

SFP Modules

The Catalyst 3750 switch uses Gigabit Ethernet SFP modules to establish fiber-optic connections. These transceiver modules are field-replaceable, providing the uplink interfaces when inserted in an SFP module slot. You can use the SFP modules for Gigabit uplink connections to other switches. You use

fiber-optic cables with LC or MT-RJ connectors to connect to a fiber-optic SFP module. You use Category 5 cable with RJ-45 connectors to connect to a copper SFP module.

For more information about these SFP modules, refer to your SFP module documentation.

XENPAK Module Slot

The Catalyst 3750G-16TD switch uses 10-Gigabit Ethernet XENPAK modules to establish connections to networks. The modules are installed in the module slot in the switch front panel.

For a list of the XENPAK modules that the Catalyst 3750G-16TD switch supports, refer to the Catalyst 3750 release notes. For more information about XENPAK modules, refer to your XENPAK module documentation.

**Note**

The 10-Gigabit Ethernet XENPAK modules are referred to as 10-Gigabit Ethernet module ports in the software documentation.


LEDs

You can use the switch LEDs to monitor switch activity and its performance. [Figure 2-9](#) shows the Catalyst 3750 switch LEDs and the Mode button that you use to select one of the port modes.

All of the LEDs described in this section are visible on the Cluster Management Suite (CMS) home page. The switch software configuration guide describes how to use CMS to configure and monitor individual switches and switch clusters.

Front Panel Description


Figure 2-9 Catalyst 3750-24TS, 3750G-24T, 3750G-12S, 3750G-16TD, 3750-48TS, and 3750G-24TS LEDs



866545

1	Mode button	6	Master LED
2	Stack LED	7	RPS LED
3	Speed LED	8	System LED
4	Duplex LED	9	Port LED
5	Status LED		

Figure 2-10 Catalyst 3750-24PS and 3750-48PS LEDs



1	Mode button	6	Status LED
2	PoE LED	7	Master LED
3	Stack LED	8	RPS LED
4	Speed LED	9	System LED
5	Duplex LED		

System LED

The System LED shows whether the system is receiving power and is functioning properly. [Table 2-1](#) lists the LED colors and their meanings.

Table 2-1 System LED

Color	System Status
Off	System is not powered on.
Green	System is operating normally.
Amber	System is receiving power but is not functioning properly.

For information on the System LED colors during power-on self-test (POST), see the [“Powering On the Switch and Running POST”](#) section on page 3-12.

RPS LED

The RPS LED shows the RPS status. [Table 2-2](#) lists the LED colors and their meanings.

Table 2-2 RPS LED

Color	RPS Status
Off	RPS is off or not properly connected.
Green	RPS is connected and ready to provide back-up power, if required.
Flashing green	RPS is connected but is unavailable because it is providing power to another device (redundancy has been allocated to a neighboring device).
Amber	The RPS is in standby mode or in a fault condition. Press the Standby/Active button on the RPS, and the LED should turn green. If it does not, the RPS fan could have failed. Contact Cisco Systems.
Flashing amber	The internal power supply in a switch has failed, and the RPS is providing power to the switch (redundancy has been allocated to this device).

For more information about the Cisco RPS 300, refer to the *Cisco RPS 300 Redundant Power System Hardware Installation Guide*. For more information about the Cisco RPS 675, refer to the *Cisco RPS 675 Redundant Power System Hardware Installation Guide*.

**Note**

The Cisco RPS 300 does not support the Catalyst 3750G-24TS, 3750-24PS, 3750-48PS, and 3750G-16TD switches.

Master LED

The Master LED shows the stack master status. [Table 2-2](#) lists the LED colors and their meanings.

Table 2-3 Master LED

Port Mode	Description
Off	Switch is not the stack master.
Green	Switch is the stack master or a standalone switch.
Amber	An error occurred when the switch was selecting the stack master switch or a stack error.

Port LEDs and Modes

Each RJ-45 port, SFP module slot, and XENPAK module slot has a port LED. These port LEDs, as a group or individually, display information about the switch and about the individual ports. The port modes determine the type of information displayed through the port LEDs. [Table 2-4](#) lists the mode LEDs and their associated port mode and meaning.

To select or change a mode, press the Mode button until the desired mode is highlighted. When you change port modes, the meanings of the port LED colors also change. [Table 2-6](#) explains how to interpret the port LED colors in different port modes.

If your switches are stacked and you press the Mode button on any one of the switches in the stack, all the switches in the stack change to display the same selected mode. For example, if you press the mode button on the stack master to display SPEED, all the other switches in the stack also display SPEED.

Table 2-4 Port Mode LEDs

Mode LED	Port Mode	Description
STAT	Port status	The port status. This is the default mode.
DUPLX	Port duplex mode	The port duplex mode: full duplex or half duplex. Note The 10/100/1000 ports operate only in full-duplex mode.
SPEED	Port speed	The port operating speed: 10, 100, or 1000 Mbps.
STACK	Stack member status StackWise port status	The stack member status. The StackWise port status. See the “Stack LED” section on page 2-21 for more information.
PoE ¹	10/100 PoE port power	The PoE status.

1. The PoE LED is only on the Catalyst 3750-24PS and 3750-48PS switches.

Even if PoE mode is not selected on a Catalyst 3750-24PS or 3750-48PS switch, the PoE LED still shows PoE problems when they are detected.

[Table 2-5](#) lists the PoE mode LED colors and their meanings.

Table 2-5 PoE Mode LED

Color	PoE Status
Off	PoE mode is not selected. None of the 10/100 ports have been denied power or are in a fault condition.
Green	PoE mode is selected, and the PoE status is shown on the port LEDs.
Blinking amber	PoE mode is not selected. At least one of the 10/100 ports has been denied power, or at least one of the 10/100 ports has a PoE fault.

Table 2-6 *Meaning of LED Colors in Different Modes on the Switch*


Port Mode	Port LED Color	Meaning
PoE ¹	Off	PoE is off. If the powered device is receiving power from an AC power source, the port LED is off even if the powered device is connected to the switch port.
	Green	PoE is on. The port LED is green only when the switch port is providing power.
	Alternating green and amber	PoE is denied because providing power to the powered device will exceed the 370 W switch power capacity.
	Blinking amber	PoE is off due to a fault.  Caution PoE faults are caused when noncompliant cabling or powered devices are connected to a PoE port. Only standard-compliant cabling can be used to connect Cisco pre-standard IP Phones and wireless access points or IEEE 802.3af-compliant devices to PoE ports. A cable or device that causes a PoE fault must be removed from the network.
	Amber	PoE for the port has been disabled. Note PoE is enabled by default.

Table 2-6 Meaning of LED Colors in Different Modes on the Switch (continued)

Port Mode	Port LED Color	Meaning
STAT (port status)	Off	No link, or port was administratively shut down.
	Green	Link present.
	Flashing green	Activity. Port is transmitting or receiving data.
	Alternating green-amber	Link fault. Error frames can affect connectivity, and errors such as excessive collisions, CRC errors, and alignment and jabber errors are monitored for a link-fault indication.
	Amber	Port is blocked by Spanning Tree Protocol (STP) and is not forwarding data. Note After a port is reconfigured, the port LED can remain amber for up to 30 seconds as STP checks the switch for possible loops.
	Flashing amber	Port is blocked by STP and is transmitting or receiving packets.
DUPLX (duplex)	Off	Port is operating in half duplex.
	Green	Port is operating in full duplex.
SPEED	10/100 and 10/100/1000 ports	
	Off	Port is operating at 10 Mbps.
	Green	Port is operating at 100 Mbps.
	Flashing green	Port is operating at 1000 Mbps.
	SFP ports	
	Off	Port is operating at 10 Mbps.
	Green	Port is operating at 100 Mbps.
	Flashing green	Port is operating at 1000 Mbps. Note When installed in Catalyst 3750 switches, 1000BASE-T SFP modules can operate at 10, 100, or 1000 Mbps in full-duplex mode or in half-duplex mode at 10 or 100 Mbps.
	XENPAK port	
	Off	Port is not operating.
	Flashing Green	Port is operating at up to 10 Gbps.

Table 2-6 *Meaning of LED Colors in Different Modes on the Switch (continued)*

Port Mode	Port LED Color	Meaning
STACK (stack member)	Off	No stack member corresponding to that member number.
	Flashing Green	Selected switch's member number.
	Green	Member number of other stack member switches.

1. The PoE LED is only on the Catalyst 3750-24PS and 3750-48PS switches.

Stack LED

The stack LED shows the sequence of member switches in a stack. Up to nine switches can be members of a stack. The first nine port LEDs show the position of a switch in a stack. [Figure 2-11](#) shows a magnified view of the LEDs on the first switch, which is member number 8 of the stack. For example, if you press the Mode button to select the stack member on this switch, the port LED 8 flashes green because this represents the member number of this switch. The port LEDs 3 and 4 are solid green, as these represent the member numbers of other switches in the stack. The other port LEDs are off because there are no more members in the stack.


When the stack LED is selected, the representative stack LEDs are green when the StackWise ports (on the switch rear panel) are up, and the representative stack LEDs are amber when the ports are down:

- SFP port LEDs 1 and 2 on the Catalyst 3750-24TS switch show the status for StackWise ports 1 and 2, respectively.
- SFP port LEDs 3 and 4 on the Catalyst 3750-48TS switch show the status for StackWise ports 1 and 2, respectively.
- SFP port LEDs 27 and 28 on the Catalyst 3750G-24TS switch show the status for StackWise ports 1 and 2, respectively.
- The 10/100/1000 port LEDs 23 and 24 on the Catalyst 3750G-24T switch show the status for StackWise ports 1 and 2, respectively.
- SFP port LEDs 11 and 12 on the Catalyst 3750G-12S switch show the status for StackWise ports 1 and 2, respectively.

**Note**

If both the port LEDs are green on all the switches in the stack, the stack is operating at full bandwidth (32 Gbps). If any of the port LEDs are not green, the stack is not operating at full bandwidth.

Figure 2-11 Stack LED




939398

1	Stack member 8	3	Stack member 4
2	Stack member 3		

Rear Panel Description

The switch rear panels have an AC power connector, an RPS connector, an RJ-45 console port, and two StackWise ports. (See [Figure 2-12](#) through [Figure 2-13](#).)


Figure 2-12 Catalyst 3750-24TS, 3750G-24T, 3750G-12S, 3750G-16TD, and 3750-48TS Rear Panel



1	StackWise ports	4	AC power connector
2	RJ-45 console port	5	RPS connector
3	Fan exhaust		


Rear Panel Description

Figure 2-13 Catalyst 3750G-24TS Rear Panel



1	StackWise ports	4	AC power connector
2	RJ-45 console port	5	RPS connector
3	Fan exhaust		

Figure 2-14 Catalyst 3750-24PS and 3750-48PS Rear Panel



1	StackWise ports	4	AC power connector
2	RJ-45 console port	5	RPS connector
3	Fan exhaust		

StackWise Ports

The Catalyst 3750 switch ships with a 0.5-meter StackWise cable (72-2632-XX CABASY) that you can use to connect the StackWise ports.

**Caution**

Use only approved cables (CAB-STACK-50CM, CAB-STACK-1M, or CAB-STACK-3M), and connect only to similar Cisco equipment. Equipment might be damaged if connected to other nonapproved Cisco cables or equipment.

You can order these StackWise cables from your Cisco sales representative:

- CAB-STACK-50CM= (0.5-meter cable)
- CAB-STACK-1M= (1-meter cable)
- CAB-STACK-3M= (3-meter cable)

Power Connectors

The switch is powered through the internal power supply. You can also connect the Cisco RPS 300 or the Cisco RPS 675 to provide backup power if the switch internal power supply should fail.

**Note**

The Catalyst 3750 switch and the Cisco RPS 300 or RPS 675 should be connected to the same AC power source.

Internal Power Supply Connector

The internal power supply is an autoranging unit that supports input voltages between 100 and 240 VAC. Use the supplied AC power cord to connect the AC power connector to an AC power outlet.

Cisco RPS Connector

Specific Cisco RPS modes support specific Catalyst 3750 switches:

- Cisco RPS 300 (model PWR300-AC-RPS-N1) supports the Catalyst 3750-24TS, 3750G-24T, 3750G-12S, and 3750-48TS switches.
- Cisco RPS 675 (model PWR675-AC-RPS-N1=) supports the Catalyst 3750 family of switches.

Cisco RPS 300

The Cisco RPS 300 has two output levels: –48V and 12V with a total maximum output power of 300W. Use the supplied RPS connector cable to connect the RPS to the switch.

**Note**

The Cisco RPS 300 does not support the Catalyst 3750G-24TS, 3750-24PS, 3750-48PS, and 3750G-16TD switches.

**Warning**

Attach only the Cisco RPS (model PWR300-AC-RPS-N1) to the RPS receptacle.

The RPS is a redundant power system that can support six external network devices and provides power to one failed device at a time. It automatically senses when the internal power supply of a connected device fails and provides power to the failed device, preventing loss of network traffic. For more information on the Cisco RPS 300, refer to the *Cisco RPS 300 Redundant Power System Hardware Installation Guide*.

Cisco RPS 675

The Cisco RPS 675 has two output levels: –48V and 12V with a total maximum output power of 675W. Use the supplied RPS connector cable to connect the RPS to the switch.



Warning

Attach only the Cisco RPS (model PWR675-AC-RPS-N1=) to the RPS receptacle.

The RPS is a redundant power system that can support six external network devices and provides power to one failed device at a time. It automatically senses when the internal power supply of a connected device fails and provides power to the failed device, preventing loss of network traffic. For more information on the Cisco RPS 675, refer to the *Cisco RPS 675 Redundant Power System Hardware Installation Guide*.

Console Port

You can connect the switch to a PC by means of the console port and the supplied RJ-45-to-DB-9 female cable. If you want to connect the switch console port to a terminal, you need to provide an RJ-45-to-DB-25 female DTE adapter. You can order a kit (part number ACS-DSBUASYN=) containing that adapter from Cisco. For console port and adapter pinout information, see the [“Connector and Cable Specifications” section on page B-1](#).

Management Options

The Catalyst 3750 switches offer several management options:

- Cluster Management Suite (CMS)

CMS is a graphical user interface that can be launched from anywhere in your network through a web browser such as Netscape Communicator or Microsoft Internet Explorer. CMS is already installed on the switch, and no additional installation is required. From CMS, you can fully configure and monitor a switch or switch clusters, display network topologies to gather link information, and display switch images to modify switch- and port-level settings. For more information, refer to the switch software configuration guide on Cisco.com, and the online help for this application.

- Cisco IOS command-line interface (CLI)

The switch CLI is based on Cisco IOS software and is enhanced to support desktop-switching features. You can fully configure and monitor the switch and switch cluster members from the CLI. You can access the CLI either by connecting your management station directly to the switch console port or by using Telnet from a remote management station. Refer to the *Catalyst 3750 Switch Command Reference* on Cisco.com for more information.

- CiscoView application

The CiscoView device-management application displays the switch image that you can use to set configuration parameters and to view switch status and performance information. The CiscoView application, which you purchase separately, can be a standalone application or part of a Simple Network Management Protocol (SNMP) platform. Refer to the CiscoView documentation for more information.

- SNMP network management

You can manage switches from a SNMP-compatible management station that is running platforms such as HP OpenView or SunNet Manager. The switch supports a comprehensive set of Management Information Base (MIB) extensions and four Remote Monitoring (RMON) groups. Refer to the switch software configuration guide on Cisco.com and the documentation that came with your SNMP application for more information.

Network Configurations

Refer to the switch software configuration guide on Cisco.com for network configuration concepts and examples of using the switch to create dedicated network segments and interconnecting the segments through Gigabit Ethernet connections.



Switch Installation

This chapter describes how to start your switch and how to interpret the power-on self-test (POST) that ensures proper operation. It describes the planning and cabling considerations to keep in mind while planning your stack. It describes how to install the switch and make connections to the switch. Read the topics and perform the procedures in this order:

- [Preparing for Installation, page 3-2](#)
- [Verifying Switch Operation, page 3-10](#)
- [Planning the Stack, page 3-14](#)
- [Installing the Switch, page 3-19](#)
- [Connecting StackWise Cable to StackWise Ports, page 3-38](#)
- [Installing and Removing SFP Modules, page 3-41](#)
- [Installing and Removing XENPAK Modules, page 3-45](#)
- [Connecting to the 10/100 and 10/100/1000 Ports, page 3-51](#)
- [Connecting to an SFP Module, page 3-55](#)
- [Connecting to a XENPAK Module, page 3-59](#)
- [Where to Go Next, page 3-61](#)

Preparing for Installation

This section covers these topics:

- [Warnings, page 3-2](#)
- [EMC Regulatory Statements, page 3-4](#)
- [Installation Guidelines, page 3-7](#)
- [Verifying Package Contents, page 3-9](#)
- [Verifying Switch Operation, page 3-10](#)

Warnings

These warnings are translated into several languages in [Appendix D, “Translated Safety Warnings.”](#)



Warning

Voltages that present a shock hazard may exist on Power over Ethernet (PoE) circuits if interconnections are made using uninsulated exposed metal contacts, conductors, or terminals. Avoid using such interconnection methods, unless the exposed metal parts are located within a restricted access location and users and service people who are authorized within the restricted access location are made aware of the hazard. A restricted access area can be accessed only through the use of a special tool, lock and key or other means of security.



Warning

This equipment is to be installed and maintained by service personnel only as defined by AS/NZS 3260 Clause 1.2.14.3 Service Personnel.



Warning

Only trained and qualified personnel should be allowed to install or replace this equipment.



Warning

Read the installation instructions before you connect the system to its power source.

**Warning**

Before working on equipment that is connected to power lines, remove jewelry (including rings, necklaces, and watches). Metal objects will heat up when connected to power and ground and can cause serious burns or weld the metal object to the terminals.

**Warning**

Do not stack the chassis on any other equipment. If the chassis falls, it can cause severe bodily injury and equipment damage.

**Warning**

The plug-socket combination must be accessible at all times because it serves as the main disconnecting device.

**Warning**

To prevent the switch from overheating, do not operate it in an area that exceeds the maximum recommended ambient temperature of 113° F (45° C). To prevent airflow restriction, allow at least 3 inches (7.6 cm) of clearance around the ventilation openings.

**Warning**

When installing or replacing the unit, the ground connection must always be made first and disconnected last.

**Warning**

This equipment is intended to be grounded. Ensure that the host is connected to earth ground during normal use.

**Warning**

Do not work on the system or connect or disconnect cables during periods of lightning activity.

**Warning**

Ultimate disposal of this product should be handled according to all national laws and regulations.

**Warning****Attach only the Cisco RPS (model PWR675-AC-RPS-N1) to the RPS receptacle.****Warning****Attach only the Cisco RPS (model PWR300-AC-RPS-N1) to the RPS receptacle.****Warning****Class 1 laser product****Warning****Avoid direct exposure to the laser beam.**

EMC Regulatory Statements

This section includes specific regulatory statements about the Catalyst 3750 family of switches.

U.S.A.

U.S. regulatory information for this product is in the front matter of this manual.

Class A Notice for Taiwan and Other Traditional Chinese Markets

**Warning****This is a Class A Information Product, when used in residential environment, it may cause radio frequency interference, under such circumstances, the user may be requested to take appropriate countermeasures.****警告****這是甲類資訊產品，在居住環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。**

VCCI Class A Notice for Japan

**Warning**

This is a Class A product based on the standard of the Voluntary Control Council for Interference by Information Technology Equipment (VCCI). If this equipment is used in a domestic environment, radio disturbance may arise. When such trouble occurs, the user may be required to take corrective actions.

警告

これは、情報処理装置等電波障害自主規制協議会（VCCI）の規定に基づくクラスA装置です。この装置を家庭環境で使用すると、電波妨害を引き起こすことがあります。この場合には、使用者が適切な対策をるように要求されることがあります。

Class A Notice for Korea

**Warning**

This is a Class A Device and is registered for EMC requirements for industrial use. The seller or buyer should be aware of this. If this type was sold or purchased by mistake, it should be replaced with a residential-use type.

주의

A급 기기 이 기기는 업무용으로 전자파 적합 등록을 한 기기이오니 판매자 또는 사용자는 이 점을 주의하시기 바라며 만약 잘못 판매 또는 구입하였을 때에는 가정용으로 교환하시기 바랍니다.

Class A Notice for Hungary

**Warning**

This equipment is a class A product and should be used and installed properly according to the Hungarian EMC Class A requirements (MSZEN55022). Class A equipment is designed for typical commercial establishments for which special conditions of installation and protection distance are used.

Figyelem

Figyelmeztetés a felhasználói kézikönyv számára: Ez a berendezés "A" osztályú termék, felhasználására és üzembe helyezésére a magyar EMC "A" osztályú követelményeknek (MSZ EN 55022) megfelelően kerülhet sor, illetve ezen "A" osztályú berendezések csak megfelelő kereskedelmi forrásból származhatnak, amelyek biztosítják a megfelelő speciális üzembe helyezési körülményeket és biztonságos üzemelési távolságok alkalmazását.

Installation Guidelines

When deciding where to place the switch, be sure to observe these requirements:

- For copper Ethernet ports, including 10/100 ports and 1000BASE-T SFP module ports, cable lengths from the switch to connected devices can be up to 328 feet (100 meters).
- [Table 3-1](#) lists the cable specifications for 1000BASE-SX, 1000BASE-LX, 1000BASE-ZX, and CWDM fiber-optic SFP module connections. Each port must match the wave-length specifications on the other end of the cable, and for reliable communications, the cable must not exceed the stipulated cable length.

Table 3-1 *Fiber-Optic SFP Module Port Cabling Specifications*

SFP Module	Wavelength (nanometers)	Fiber Type	Core Size (micron)	Modal Bandwidth (MHz/km)	Cable Distance
1000BASE-SX	850	MMF	62.5	160	722 feet (220 m)
			62.5	200	902 feet (275 m)
			50	400	1640 feet (500 m)
			50	500	1804 feet (550 m)
1000BASE-LX/LH	1300	MMF ¹	62.5	500	1804 feet (550 m)
			50	400	1804 feet (550 m)
		SMF	50	500	1804 feet (550 m)
			9/10	—	32,810 feet (10 km)
1000BASE-ZX	1550	SMF	9/10	—	43.4 to 62 miles (70 to 100 km)

Table 3-1 Fiber-Optic SFP Module Port Cabling Specifications (continued)

SFP Module	Wavelength (nanometers)	Fiber Type	Core Size (micron)	Modal Bandwidth (MHz/km)	Cable Distance
CWDM	1470, 1490, 1510, 1530, 1550, 1570, 1590, 1610	SMF	9/125	—	62 miles (100 km)

1. A mode-conditioning patch cord is required. Using an ordinary patch cord with MMF, 1000BASE-LX/LH SFP modules, and a short link distance can cause transceiver saturation, resulting in an elevated bit error rate (BER). When using the LX/LH SFP module with 62.5-micron diameter MMF, you must also install a mode-conditioning patch cord between the SFP module and the MMF cable on both the sending and receiving ends of the link. The mode-conditioning patch cord is required for link distances greater than 984 feet (300 m).

**Note**

When using shorter distances of single-mode fiber cable, you might need to insert an inline optical attenuator in the link to avoid overloading the receiver.

When the fiber-optic cable span is less than 15.43 miles (25 km), at each end of the link, insert a 5-decibel (dB) or 10-dB inline optical attenuator between the fiber-optic cable plant and the receiving port on the 1000BASE-ZX SFP module.

- Refer to the Catalyst 3750 release notes for cable stipulations for XENPAK module connections. Each port must match the wave-length specifications on the other end of the cable, and for reliable communications, the cable must not exceed the stipulated cable length.
- Operating environment is within the ranges listed in [Appendix A, “Technical Specifications.”](#)
- Clearance to front and rear panels is such that
 - Front-panel indicators can be easily read.
 - Access to ports is sufficient for unrestricted cabling.

Make sure that there is access to the rear of the rack if you are planning to stack the switches. If you do not have access to the rear panel, make sure you cable the switches before you rack mount them.

 - Rear-panel power connector is within reach of an AC power receptacle.

- Cabling is away from sources of electrical noise, such as radios, power lines, and fluorescent lighting fixtures. Make sure the cabling is safely away from other devices that might damage the cables.
- Airflow around the switch and through the vents is unrestricted.
- Temperature around the unit does not exceed 113°F (45°C).



Note If the switch is installed in a closed or multirack assembly, the temperature around it might be greater than normal room temperature.

Verifying Package Contents



Note Carefully remove the contents from the shipping container, and check each item for damage. If any item is missing or damaged, contact your Cisco representative or reseller for support. Return all packing material to the shipping container, and save it.

The switch is shipped with these items:

- This *Catalyst 3750 Switch Hardware Installation Guide*
- *About the Catalyst 3750 Documentation* flyer
- AC power cord (AC-powered switches)
- One RJ-45-to-DB-9 adapter cable
- Mounting kit containing:
 - Four rubber feet for mounting the switch on a table
 - Two 19-inch rack-mounting brackets
 - Four Phillips flat-head screws for attaching the brackets to the switch (Catalyst 3750G-24TS switch)
 - Six Phillips flat-head screws for attaching the brackets to the switch (Catalyst 3750-24TS, 3750G-24T, 3750-48TS, 3750-24PS, 3750-48PS, and 3750G-16TD switches)
 - Four Phillips machine screws for attaching the brackets to a rack

- One cable guide and one black Phillips machine screw for attaching the cable guide to one of the mounting brackets
- One RPS connector cover (for wall mounting)
- Two Phillips pan-head screws (for attaching the RPS cover)
- Four Phillips truss-head screws (for wall-mounting brackets)
- StackWise cable: 0.5-meter, 1-meter, or 3-meter cable.

**Note**

If you do not specify the length of the StackWise cable, the 0.5-meter cable is supplied.

Verifying Switch Operation

Before installing the switch in a rack, on a wall, or on a table or shelf, you should power the switch and verify that the switch passes POST. These sections describe the steps required to connect a PC to the switch console port, and to power on the switch and observe POST:

- [Connecting a PC or Terminal to the Console Port, page 3-10](#)
- [Powering On the Switch and Running POST, page 3-12](#)

Connecting a PC or Terminal to the Console Port


To connect a PC to the console port, use the supplied RJ-45-to-DB-9 adapter cable. To connect the switch console port to a terminal, you need to provide a RJ-45-to-DB-25 female DTE adapter. You can order a kit (part number ACS-DSBUASYN=) containing that adapter from Cisco. For console port and adapter pinout information, see the [“Cable and Adapter Specifications” section on page B-5](#).

The terminal-emulation software—frequently a PC application such as Hyperterminal or Procomm Plus—makes communication between the switch and your PC or terminal possible.

Follow these steps to connect the PC or terminal to the switch:

-
- Step 1** Configure the baud rate and character format of the PC or terminal to match these console port default characteristics:
- 9600 baud
 - 8 data bits
 - 1 stop bit
 - No parity
 - None (flow control)
- After you have gained access to the switch, you can change the console baud rate through the **Administration > Console Baud Rate** window in the Cluster Management Suite (CMS).
- Step 2** Using the supplied RJ-45-to-DB-9 adapter cable, insert the RJ-45 connector into the console port, as shown in [Figure 3-1](#).
- Step 3** Attach the DB-9 female DTE adapter of the RJ-45-to-DB-9 adapter cable to a PC, or attach an appropriate adapter to the terminal.
- Step 4** Start the terminal-emulation program if you are using a PC or terminal.
-

Figure 3-1 Connecting to the Console Port



1	Console port
---	--------------

Powering On the Switch and Running POST

If your configuration has an RPS, connect the switch and the RPS to the same AC power source. See the [“Power Connectors” section on page 2-25](#), and refer to the Cisco RPS documentation for more information.



Note

Always put the RPS in standby mode when you are connecting devices to it and in active mode during normal operation.

To power on the switch, follow these steps:

- Step 1** Make sure that you have started the terminal emulation software program (such as ProComm, HyperTerminal, tip, or minicom) from your management station. See the [“Connecting a PC or Terminal to the Console Port” section on page 3-10](#) for information on connecting to the switch console port.
- Step 2** Connect one end of the AC power cord to the AC power connector on the switch.

Step 3 Connect the other end of the power cord to an AC power outlet.

If you are installing the Catalyst 3750-24TS, 3750G-24T, 3750G-12S, or 3750-48TS switches, you can use the Cisco RPS 300.



Warning

Attach only the Cisco RPS 300 (model PWR300-AC-RPS-N1) to the RPS receptacle

If you are installing the Catalyst 3750-24TS, 3750G-24T, 3750G-24T, 3750G-12S, 3750-24PS, 3750-48PS, 3750G-16TD, or 3750-48TS switches, you can use the Cisco RPS 675.



Warning

Attach only the Cisco RPS 675 (model PWR675-AC-RPS-N1=) to the RPS receptacle

As the switch powers on, it begins the power-on self-test (POST), a series of tests that runs automatically to ensure that the switch functions properly. POST lasts approximately 1 minute.

When the switch begins POST, the System, the RPS, the Master, the Status, the Duplex, the Speed, and the Stack LEDs turn green. (On the Catalyst 3750-24PS and 3750-48PS switches, the PoE LED also turns green as POST begins.) The System LED flashes green, and the other LEDs remain continuous green.

When POST completes successfully, the System LED remains green. The RPS LED remains green for some time and then returns to its operating status. The other LEDs turn off and return to their operating status. When POST fails, the System LED turns amber. If POST fails, see [Chapter 4, “Troubleshooting,”](#) to determine a course of action.

Powering Off the Switch and Disconnecting the Console Port

Disconnect the power cord from the switch. Disconnect the cable from the switch console port. Install the switch in a rack, on a wall, or on a table or shelf as described in the [“Installing the Switch” section on page 3-19](#).

Planning the Stack

If you plan to stack your switches, read these sections:

- [Planning Considerations, page 3-14](#)
- [Powering Considerations, page 3-15](#)
- [Cabling Considerations, page 3-15](#)
- [Recommended Cabling Configurations, page 3-17](#)

Planning Considerations

Before connecting the Catalyst 3750 switches in a stack, observe these planning considerations:

- Size of the switch. For switch dimensions, see [Appendix A, “Technical Specifications.”](#) The Catalyst 3750-24TS, 3750G-24TS, and 3750-48TS switches are the same depth. The Catalyst 3750G-12S, 3750-24PS, 375048-PS, 3750G-16TD, and 3750G-24T switches are deeper than the other switches. Stacking together switches of the same size will make it easier to cable the switches.
- Length of cable. Depending on the configurations you have, you might need different sized cables. If you don't specify the length of the StackWise cable, the 0.5-meter cable is supplied. If you require the 1-meter cable or 3-meter cable, you can order it from your Cisco supplier. For cable numbers, see the [“StackWise Ports” section on page 2-25](#). The [“Recommended Cabling Configurations” section on page 3-17](#) provides examples of recommended configurations.
- Access to the rear ports for unrestricted cabling.
Make sure that there is access to the rear of the rack if you are planning to stack the switches. If you do not have access to the rear panel, make sure you cable the switches before you rack-mount them.
- For concepts and procedures to manage switch stacks, refer to the switch software configuration guide.

Powering Considerations

Consider the following guidelines before you power the switches in a stack:

- The sequence in which the switches are initially powered on might affect the switch that becomes the stack master.
- If you want a particular switch to become the stack master, power on that switch first. This switch becomes the stack master and remains the stack master until a master re-election is required. After approximately 10 seconds power on the remaining switches in the stack.
- If you have no preference as to which switch becomes the stack master, power on the all the switches in the stack within a 10-second timeframe. These switches participate in the stack master election. Switches powered on after the 10-second timeframe do not participate in the election.
- Power off a switch before you add it to or remove it from an existing switch stack.



Note

For conditions that can cause a stack master re-election or to manually elect the stack master, refer to the “Managing Switch Stacks” chapter in the switch software configuration guide.

Cabling Considerations

The illustrations in this section display cabling configuration examples that show the stack bandwidth and possible stack partitioning.

[Figure 3-2](#) shows an example of a stack of Catalyst 3750 switches that provides full bandwidth and redundant StackWise cable connections.

Figure 3-2 Example of a Stack with Full Bandwidth Connections




Figure 3-3 shows an example of a stack of Catalyst 3750 switches with incomplete StackWise cabling connections. This stack provides only half bandwidth and does not have redundant connections.

Figure 3-3 Example of a Stack with Half Bandwidth Connections




Figure 3-4 and Figure 3-5 show examples of stacks of Catalyst 3750 switches with failover conditions. In Figure 3-4, the StackWise cable is bad in link B; therefore, this stack provides only half bandwidth and does not have redundant connections. In Figure 3-5, link B is bad; therefore, this stack partitions into two stacks, and switch 1 and switch 3 are stack masters.

Figure 3-4 Example of a Stack with a Failover Condition





Figure 3-5 Example of a Partitioned Stack with a Failover Condition




Recommended Cabling Configurations

This section describes the recommended cabling configurations for stacking the switches.

Stacking Switches in Vertical Racks or on a Table


[Figure 3-6](#) is an example of a recommended configuration using the supplied 0.5-meter StackWise cable. In this example, the switches are stacked in a vertical rack or on a table. This configuration provides redundant connections.

Figure 3-6 *Stacking the Switches in a Vertical Rack or on a Table Using the 0.5-meter StackWise Cable*



The configuration examples in [Figure 3-7](#) use the 3-meter StackWise cable in addition to the supplied 0.5-meter StackWise cable. This configuration also provides redundant connections.

Figure 3-7 Stacking the Catalyst 3750 Switches in a Vertical Rack or on a Table Using 0.5-meter and 3-meter StackWise Cables




86585

Side-by-Side Mounting in a Rack or on a Wall


Figure 3-8 and Figure 3-9 are examples of recommended configurations where the switches are rack- or wall-mounted side-by-side. Use the 1-meter and 3-meter StackWise cables to connect the switches. These configuration provide redundant connections.

Figure 3-8 Stacking up to Eight Switches in a Side-by-Side Mounting Configuration



86825

Figure 3-9 Stacking Nine Switches in a Side-by-Side Mounting Configuration



90532

Installing the Switch

This section describes these installation procedures:

- [Rack Mounting, page 3-19](#)
- [Wall Mounting, page 3-33](#)
- [Table or Shelf Mounting, page 3-37](#)

Rack Mounting



Warning

To prevent bodily injury when mounting or servicing this unit in a rack, you must take special precautions to ensure that the system remains stable. The following guidelines are provided to ensure your safety:

- **This unit should be mounted at the bottom of the rack if it is the only unit in the rack.**
 - **When mounting this unit in a partially filled rack, load the rack from the bottom to the top with the heaviest component at the bottom of the rack.**
 - **If the rack is provided with stabilizing devices, install the stabilizers before mounting or servicing the unit in the rack.**
-

To install the switch in a 19-inch or 24-inch rack (24-inch racks require optional mounting hardware), follow the instructions described in these procedures:

- [Removing Screws from the Switch, page 3-20](#)
- [Attaching Brackets to the Catalyst 3750G-24TS Switch, page 3-21](#)
- [Attaching Brackets to the Catalyst 3750-24TS, 3750G-24T, 3750G-12S, 3750-24PS, 3750-48PS, 3750G-16TD, and 3750-48TS Switches, page 3-26](#)
- [Mounting the Switch in a Rack, page 3-29](#)
- [Attaching the Cable Guide, page 3-31](#)

**Note**

Installing the switch in a 24-inch rack requires an optional bracket kit not included with the switch. You can order a kit containing the 24-inch rack-mounting brackets and hardware from Cisco. For the Catalyst 3750G-24TS switches, order part number RCKMNT-3550-1.5RU=. For the Catalyst 3750-24TS, 3750G-24T, 3750G-12S, and 3750-48TS switches, order part number RCKMNT-1RU=.

Removing Screws from the Switch

If you plan to install the switch in a rack, you must first remove screws in the switch chassis so that mounting brackets can be attached. [Figure 3-10](#) and [Figure 3-11](#) show how to remove the chassis screws in a one-rack-unit (RU) switch.

Figure 3-10 Removing Screws from the Catalyst 3750-24TS, 3750G-24T, 3750-24PS, 3750-48PS, 3750G-16TD, and 3750-48TS Switches




Figure 3-11 Removing Screws from the Catalyst 3750G-12S Switch





Figure 3-12 shows how to remove the chassis screws in a 1.5-RU switch.

Figure 3-12 Removing Screws from the 3750G-24TS Switch




Attaching Brackets to the Catalyst 3750G-24TS Switch


The bracket orientation and the brackets that you use depend on whether you are attaching the brackets for a 19-inch or a 24-inch rack. For 19-inch racks, use part number 700-11523-XX; for 24-inch racks, use part number 700-12398-XX.

Figure 3-13 through Figure 3-18 show how to attach each type bracket to one side of the switch. Follow the same steps to attach the second bracket to the opposite side.

Installing the Switch

Figure 3-13 Attaching Brackets for 19-inch Racks, Front Panel Forward


1	Phillips flat-head screws
---	---------------------------

Figure 3-14 Attaching Brackets for 24-Inch Racks, Front Panel Forward

1	Phillips flat-head screws
----------	---------------------------


Installing the Switch

Figure 3-15 Attaching Brackets for 19-Inch Racks, Rear Panel Forward




1 Phillips flat-head screws


Figure 3-16 Attaching Brackets for 24-Inch Racks, Rear Panel Forward



1 Phillips flat-head screws

Figure 3-17 Attaching Brackets for 19-Inch Telco Racks

-
- | | |
|----------|---------------------------|
| 1 | Phillips flat-head screws |
|----------|---------------------------|
-


Figure 3-18 Attaching Brackets for 24-Inch Telco Racks

-
- | | |
|----------|---------------------------|
| 1 | Phillips flat-head screws |
|----------|---------------------------|
-

Attaching Brackets to the Catalyst 3750-24TS, 3750G-24T, 3750G-12S, 3750-24PS, 3750-48PS, 3750G-16TD, and 3750-48TS Switches


The bracket orientation and the brackets you use depend on whether you are attaching the brackets for a 19-inch or a 24-inch rack. For 19-inch racks, use bracket part number 700-8209-XX; for 24-inch racks, use bracket part number 700-13248-XX. [Figure 3-19](#) through [Figure 3-25](#) show how to attach each type bracket to one side of the switch. Follow the same steps to attach the second bracket to the opposite side.

Figure 3-19 Attaching Brackets for 19-Inch Racks, Front Panel Forward




1	Phillips flat-head screws
----------	---------------------------

Figure 3-20 Attaching Brackets for 24-Inch Racks, Front Panel Forward



1 Phillips flat-head screws


Figure 3-21 Attaching Brackets for 19-Inch Racks, Rear Panel Forward



1 Phillips flat-head screws


Installing the Switch

Figure 3-22 Attaching Brackets for 24-Inch Racks, Rear Panel Forward




-
- | | |
|----------|---------------------------|
| 1 | Phillips flat-head screws |
|----------|---------------------------|
-


Figure 3-23 Attaching Brackets for 19-Inch Telco Racks



-
- | | |
|----------|---------------------------|
| 1 | Phillips flat-head screws |
|----------|---------------------------|
-

Figure 3-24 Attaching Brackets for 19-Inch Racks

1	Phillips truss-head screws
----------	----------------------------

Figure 3-25 Attaching Brackets for 24-Inch Telco Racks


1	Phillips flat-head screws
----------	---------------------------

Mounting the Switch in a Rack

After the brackets are attached to the switch, use the four supplied number-12 Phillips machine screws to securely attach the brackets to the rack, as shown in [Figure 3-26](#) and [Figure 3-27](#).

Installing the Switch


Figure 3-26 Mounting the Catalyst 3750G-24TS Switch in a Rack



86566

1 Phillips machine screws

Figure 3-27 Mounting the Catalyst 3750-24TS, 3750G-24T, 3750G-12S, 3750-24PS, 3750-48PS, 3750G-16TD, and 3750-48TS Switches in a Rack



86567

1 Phillips machine screws

After the switch is mounted in the rack, you might need to perform these tasks to complete the installation, run the setup program, and access the switch:


- (Optional) Connect the switches in the stacks. See the [“Connecting StackWise Cable to StackWise Ports”](#) section on page 3-38.
- Connect to the console port, and start the emulation software. See the [“Connecting to the Console Port”](#) section on page C-7 and the [“Starting the Terminal Emulation Software”](#) section on page C-9.
- Power on the switch. See the [“Connecting to a Power Source”](#) section on page C-9. If the switches are stacked, see the [“Powering Considerations”](#) section on page 3-15.
- Run the setup program. See the [“Completing the Setup Program”](#) section on page C-11.
- Connect to the front-panel ports. See the [“Connecting to the 10/100 and 10/100/1000 Ports”](#) section on page 3-51, the [“Connecting to an SFP Module”](#) section on page 3-55, and the [“Connecting to a XENPAK Module”](#) section on page 3-59 to complete the installation.

To use the CLI, enter commands at the *Switch>* prompt through the console port by using a terminal program or through the network by using Telnet. For configuration information, refer to the switch software configuration guide or the switch command reference.

Attaching the Cable Guide

We recommend attaching the cable guide to prevent the cables from obscuring the front panel of the switch and the other devices installed in the rack. Use the supplied black screw, as shown in [Figure 3-28](#) and [Figure 3-29](#) to attach the cable guide to the left or right bracket.

Figure 3-28 Attaching the Cable Guide on the Catalyst 3750-24TS, 3750G-24T, 3750G-24TS, 3750G-12S, 3750-24PS, 3750-48PS, and 3750G-16TD Switches




86568

1	Cable guide screws
---	--------------------

**Note**

The Catalyst 3750-48TS switch ships with the cable guide shown in [Figure 3-29](#). This cable guide secures up to 48 cables. Use the supplied black screw to mount it on the left bracket.

Figure 3-29 Attaching the Cable Guide on the Catalyst 3750-48TS Switch



86569

1	Cable guide screws
---	--------------------

Wall Mounting

To install the switch on a wall, follow the instructions in these procedures:

- [Attaching the Brackets to the Switch for Wall-Mounting, page 3-33](#)
- [Attaching the RPS Connector Cover, page 3-34](#)
- [Mounting the Switch on a Wall, page 3-35](#)


**Note**

The illustrations in this section show the Catalyst 3750G-24TS switch as an example. All the Catalyst 3750 switches are wall-mounted following the same procedures.

Attaching the Brackets to the Switch for Wall-Mounting

[Figure 3-30](#) shows how to attach a 19-inch bracket to one side of the switch. Follow the same steps to attach the second bracket to the opposite side.

Figure 3-30 Attaching the 19-inch Brackets for Wall-Mounting



1 Phillips truss-head screws

Attaching the RPS Connector Cover


If you are not using an RPS with your switch, use the two Phillips pan-head screws to attach the RPS connector cover to the back of the switch, as shown in [Figure 3-31](#) and [Figure 3-32](#).



Warning

If an RPS is not connected to the switch, install an RPS connector cover on the back of the switch.


Figure 3-31 Attaching the RPS Connector Cover on the Catalyst 3750G-24TS Switch



86571

1	Phillips pan-head screws	3	RPS connector
2	RPS connector cover		

Figure 3-32 Attaching the RPS Connector Cover on the Catalyst 3750G-12S, 3750-24TS, 3750G-24T, 3750-24PS, 3750-48PS, 3750G-16TD, and 3750-48TS Switches



86572

1	Phillips pan-head screws	3	RPS connector
2	RPS connector cover		

Mounting the Switch on a Wall


For the best support of the switch and cables, make sure the switch is attached securely to wall studs or to a firmly attached plywood mounting backboard. Mount the switch with the front panel facing up, as shown in [Figure 3-33](#).



Warning

To comply with safety regulations, mount the switches on a wall with the front panel facing up.

Figure 3-33 Mounting the Switch on a Wall



1	User-supplied screws
----------	----------------------

After the switch is mounted on the wall, you might need to perform these tasks to complete the installation, run the setup program, and access the switch:

- (Optional) Connect the switches in the stacks. See the [“Connecting StackWise Cable to StackWise Ports”](#) section on page 3-38.
- Connect to the console port, and start the emulation software. See the [“Connecting to the Console Port”](#) section on page C-7 and the [“Starting the Terminal Emulation Software”](#) section on page C-9.
- Power on the switch. See the [“Connecting to a Power Source”](#) section on page C-9. If the switches are stacked, see the [“Powering Considerations”](#) section on page 3-15.

- Run the setup program. See the [“Completing the Setup Program”](#) section on page C-11.
- Connect to the front-panel ports. See the [“Connecting to the 10/100 and 10/100/1000 Ports”](#) section on page 3-51, the [“Connecting to an SFP Module”](#) section on page 3-55, and the [“Connecting to a XENPAK Module”](#) section on page 3-59 to complete the installation.

To use the CLI, enter commands at the *Switch>* prompt through the console port by using a terminal program or through the network by using Telnet. For configuration information, refer to the switch software configuration guide or the switch command reference.

Table or Shelf Mounting

Follow these steps to install the switch on a table or shelf:

-
- Step 1** Locate the adhesive strip with the rubber feet in the mounting-kit envelope. Attach the four rubber feet to the recessed areas on the bottom of the unit.
- Step 2** Place the switch on the table or shelf near an AC power source.

After the switch is mounted on the table, you might need to perform these tasks to complete the installation, run the setup program, and access the switch:

- (Optional) Connect the switches in the stacks. See the [“Connecting StackWise Cable to StackWise Ports”](#) section on page 3-38.
- Connect to the console port, and start the emulation software. See the [“Connecting to the Console Port”](#) section on page C-7 and the [“Starting the Terminal Emulation Software”](#) section on page C-9.
- Power on the switch. See the [“Connecting to a Power Source”](#) section on page C-9. If the switches are stacked, see the [“Powering Considerations”](#) section on page 3-15.

- Run the setup program. See the “[Completing the Setup Program](#)” section on page C-11.
 - Connect to the front-panel ports. See the “[Connecting to the 10/100 and 10/100/1000 Ports](#)” section on page 3-51, the “[Connecting to an SFP Module](#)” section on page 3-55, and the “[Connecting to a XENPAK Module](#)” section on page 3-59 to complete the installation.
-

To use the CLI, enter commands at the *Switch>* prompt through the console port by using a terminal program or through the network by using Telnet. For configuration information, refer to the switch software configuration guide or the switch command reference.

Connecting StackWise Cable to StackWise Ports

Follow these steps to connect the StackWise cable to the StackWise ports:

Step 1 Remove the dust covers from the StackWise cables and StackWise ports, and store them for future use.

Step 2 Insert one end of the StackWise cable into the StackWise port on the back of the switch.



Note Always use a Cisco-approved StackWise cable to connect the switches.

Step 3 Use the window in the StackWise cable to align the connector correctly. Secure the screws tightly.

Step 4 Insert the other end of the cable into the connector of the other switch, and secure the screws tightly.




Caution Removing and installing the StackWise cable can shorten its useful life. Do not remove and insert the cable more often than is absolutely necessary.

**Note**

When the connectors are not being used, replace the dust covers on them to protect them from dust.

Figure 3-34 Inserting the StackWise Cable in a StackWise Port



When you need to remove the StackWise cable from the connector, make sure to fully unscrew the screws before removing the connector. Also make sure that you remove the correct screws from the StackWise port. See [Figure 3-35](#) for correct removal procedures and [Figure 3-36](#) for incorrect removal procedures.

Figure 3-35 Correct Removal of the StackWise Cable from a StackWise Port





Figure 3-36 *Incorrect Removal of a StackWise Cable from a StackWise Port*



Installing and Removing SFP Modules

These sections describe how to install and remove SFP modules. SFP modules are inserted into SFP module slots on the front of the Catalyst 3750 switches. These field-replaceable modules provide uplink interfaces.

You can use any combination of SFP modules. Refer to the Catalyst 3750 release notes for the list of SFP modules that the Catalyst 3750 switch supports. Each port must match the wave-length specifications on the other end of the cable, and the cable must not exceed the stipulated cable length for reliable communications. See the [“Installation Guidelines” section on page 3-7](#) for cable stipulations for SFP connections.

Use only Cisco SFP modules on the Catalyst 3750 switch. Each SFP module has an internal serial EEPROM that is encoded with security information. This encoding provides a way for Cisco to identify and validate that the SFP module meets the requirements for the switch.

For detailed instructions on installing, removing, and cabling the SFP module, refer to your SFP module documentation.

Installing SFP Modules into SFP Module Slots

Figure 3-37 shows an SFP module that has a bale-clasp latch.




Caution

We strongly recommend that you do not install or remove fiber-optic SFP modules with cables attached because of the potential damage to the cables, the cable connector, or the optical interfaces in the SFP module. Disconnect all cables before removing or installing an SFP module.

Removing and installing an SFP module can shorten its useful life. Do not remove and insert SFP modules more often than is absolutely necessary.

Figure 3-37 SFP Module with a Bale-Clasp Latch



To insert an SFP module into the SFP module slot, follow these steps:


- Step 1** Attach an ESD-preventive wrist strap to your wrist and to a bare metal surface on the chassis.
- Step 2** Find the send (TX) and receive (RX) markings that identify the top side of the SFP module.



Note On some SFP modules, the send and receive (TX and RX) markings might be replaced by arrows that show the direction of the connection, either send or receive (TX or RX).

- Step 3** Align the SFP module in front of the slot opening.
- Step 4** Insert the SFP module into the slot until you feel the connector on the module snap into place in the rear of the slot.

Figure 3-38 Installing an SFP Module into an SFP Module Slot



- Step 5** For fiber-optic SFP modules, remove the dust plugs from the optical ports, and store them for later use.



Caution Do not remove the dust plugs from the fiber-optic SFP module port or the rubber caps from the fiber-optic cable until you are ready to connect the cable. The plugs and caps protect the SFP module ports and cables from contamination and ambient light.

- Step 6** Insert the cable connector into the SFP module:
- For fiber-optic SFP modules, insert the LC or MT-RJ cable connector into the SFP module.
 - For copper SFP modules, insert the RJ-45 cable connector into the SFP module.



Note When connecting to 1000BASE-T SFP modules, be sure to use a twisted four-pair, Category 5 cable.

Removing SFP Modules from SFP Module Slots

To remove an SFP module from a module receptacle, follow these steps:

Step 1 Attach an ESD-preventive wrist strap to your wrist and to a bare metal surface on the chassis.

Step 2 Disconnect the cable from the SFP module.




Tip For reattachment, note which cable connector plug is send (TX) and which is receive (RX).

Step 3 For fiber-optic SFP modules, insert a dust plug into the optical ports of the SFP module to keep the optical interfaces clean.

Step 4 Unlock and remove the SFP module, as shown in [Figure 3-39](#).

If the module has a bale-clasp latch, pull the bale out and down to eject the module. If the bale-clasp latch is obstructed and you cannot use your index finger to open it, use a small, flat-blade screwdriver or other long, narrow instrument to open the bale-clasp latch.

Figure 3-39 Removing a Bale-Clasp Latch SFP Module by Using a Flat-Blade Screwdriver



1	Bale clasp
----------	------------

- Step 5** Grasp the SFP module between your thumb and index finger, and carefully remove it from the module slot.
- Step 6** Place the removed SFP module in an antistatic bag or other protective environment.

Installing and Removing XENPAK Modules

These sections describe how to install and remove XENPAK modules. XENPAK modules are inserted into the XENPAK module slot on the front panel of the Catalyst 3750G-16TD switch. These field-replaceable transceiver modules provide 10-Gigabit interfaces.



Note

The 10-Gigabit Ethernet XENPAK modules are referred to as 10-Gigabit Ethernet module ports in the switch software documentation.

Refer to the Catalyst 3750 release notes for the list of XENPAK modules that the Catalyst 3750G-16TD switch supports. Use only Cisco XENPAK modules on the Catalyst 3750G-16TD switch. Each XENPAK module has an internal serial EEPROM that is encoded with security information. This encoding provides a way for Cisco to identify and validate that the XENPAK module meets the requirements for the switch.

Refer to the Catalyst 3750 release notes for cable stipulations for XENPAK module connections. For detailed instructions on installing, removing, cabling, and troubleshooting the XENPAK module, refer to your XENPAK module documentation.

Installing a XENPAK Module

Figure 3-40 shows a XENPAK module.




Caution

We strongly recommend that you do not install or remove fiber-optic XENPAK modules with cables attached because of the potential damage to the cables, the cable connector, or the optical interfaces in the XENPAK module. Disconnect all cables before removing or installing the XENPAK module.



Caution

Do not remove the dust plugs from the fiber-optic XENPAK module or the rubber caps from the fiber-optic cable until you are ready to connect the cable. The plugs and caps protect the XENPAK module ports and cables from contamination and ambient light.

Figure 3-40 XENPAK Module


99376

1	Captive installation screw	3	Transmit optical bore
2	Optical bore dust plug	4	Receive optical bore

To insert a XENPAK module, follow these steps:

-
- Step 1** Attach an ESD-preventive wrist strap to your wrist and to a bare metal surface on the chassis.
- Step 2** Remove the two Phillips-head retaining screws from the XENPAK module slot cover, and store them for later use.
- Step 3** Remove the cover, as shown in [Figure 3-41](#).

Figure 3-41 Removing the XENPAK Module Slot Cover




1	Phillips-head screw	2	Module slot cover
---	---------------------	---	-------------------

Step 4 Remove the XENPAK module from the protective packaging.

Step 5 Align the XENPAK module with the guide rails inside the module slot, and slide the module into the opening until the back of the XENPAK faceplate is flush with the switch faceplate. (See [Figure 3-42](#).)

Figure 3-42 Installing a XENPAK Module in the Catalyst 3750G-16TD Switch



1	Optical bore dust plug	2	Captive installation screw
---	------------------------	---	----------------------------

- Step 6** Secure the XENPAK module in place by tightening the two captive installation screws. Do not overtighten the captive screws.


Removing a XENPAK Module

To remove a XENPAK module, follow these steps:

- Step 1** Attach an ESD-preventive wrist strap to your wrist and to a bare metal surface on the chassis.
- Step 2** Disconnect the cable from the XENPAK module. For fiber-optic modules, install the optical bore dust plugs.
- Step 3** Loosen the two captive installation screws that secure the XENPAK module in the slot.
- Step 4** Carefully pull on the two captive installation screws to disconnect the XENPAK module from the slot.

- Step 5** Grasp the edges of the XENPAK module, and carefully slide it out of the slot, as shown in [Figure 3-43](#).


Figure 3-43 Removing a XENPAK Module



1	Optical bore dust plug	2	Captive installation screw
---	------------------------	---	----------------------------

- Step 6** Use two Phillips-head screws to attach the XENPAK module slot cover to the switch front panel, as shown in [Figure 3-44](#).

Figure 3-44 Replacing the XENPAK Module Slot Cover



1	Phillips-head screw	2	Module slot cover
---	---------------------	---	-------------------

Connecting to the 10/100 and 10/100/1000 Ports

The switch 10/100 and 10/100/1000 ports configure themselves to operate at the speed of attached devices. If the attached ports do not support autonegotiation, you can explicitly set the speed and duplex parameters. Connecting devices that do not autonegotiate or that have their speed and duplex parameters manually set can reduce performance or result in no linkage.

To maximize performance, choose one of these methods for configuring the Ethernet ports:

- Let the ports autonegotiate both speed and duplex.
- Set the port speed and duplex parameters on both ends of the connection.

**Warning**

Voltages that present a shock hazard may exist on Power over Ethernet (PoE) circuits if interconnections are made using uninsulated exposed metal contacts, conductors, or terminals. Avoid using such interconnection methods, unless the exposed metal parts are located within a restricted access location and users and service people who are authorized within the restricted access location are made aware of the hazard. A restricted access area can be accessed only through the use of a special tool, lock and key or other means of security.

You can configure the 10/100 ports on the Catalyst 3750-24PS and 3750-48PS switches either to automatically provide PoE when a Cisco IP Phone, Cisco Aironet Access Point, or end device compliant with IEEE 802.3af is connected or never to provide PoE, even if an IP phone or an access point is connected. The default setting is Auto. To prevent ESD damage, follow your normal board and component handling procedures.

Use the guidelines in [Table 3-2](#) to select the correct cable for connecting the switch 10/100 and 10/100/1000 ports to other devices. See the [“Cable and Adapter Specifications”](#) section on page B-5 for cable-pinout descriptions.

Table 3-2 Recommended Ethernet Cables

Device	Crossover Cable ¹	Straight-Through Cable ¹
Switch to switch	Yes	No
Switch to hub	Yes	No
Switch to computer or server	No	Yes
Switch to router	No	Yes
Switch to IP phone	No	Yes

1. 100BASE-TX and 1000BASE-T traffic requires twisted four-pair, Category 5 cable. 10BASE-T traffic can use Category 3 or Category 4 cable.

**Note**

You can use the **mdix auto** interface configuration command in the CLI to enable the automatic medium-dependent interface crossover (Auto-MDIX) feature. When the Auto-MDIX feature is enabled, the switch detects the required cable type for copper Ethernet connections and configures the interfaces accordingly. Therefore, you can use either a crossover or a straight-through cable for connections to a copper 10/100, 10/100/1000, or 1000BASE-T SFP module port on the switch, regardless of the type of device on the other end of the connection.

The Auto-MDIX feature is enabled by default on switches running Cisco IOS Release 12.2(18)SE or later. For releases between Cisco IOS Release 12.1(14)EA1 and 12.2(18)SE, the Auto-MDIX feature is disabled by default. For configuration information for this feature, refer to the switch software configuration guide or the switch command reference.

Follow these steps to connect to 10BASE-T, 100BASE-TX or 1000BASE-T devices:

**Caution**

PoE faults are caused when noncompliant cabling or powered devices are connected to a PoE port. Only standard-compliant cabling can be used to connect Cisco pre-standard IP Phones and wireless access points or IEEE 802.3af-compliant devices to PoE ports. A cable or device that causes a PoE fault must be removed from the network.

Step 1

When connecting to workstations, servers, routers, and Cisco IP Phones, connect a straight-through cable to an RJ-45 connector on the front panel. (See [Figure 3-45](#).) When connecting to switches or repeaters, use a crossover cable. (See the “[Cable and Adapter Specifications](#)” section on page B-5 for cable-pinout descriptions.)

**Note**

When connecting to 1000BASE-T-compatible devices, be sure to use a twisted four-pair, Category 5 cable.



Note The Catalyst 3750 switch can connect to a Cisco IP Phone through a straight-through, twisted four-pair Category 5 cable. The rear panel of the Cisco IP Phone might have more than one RJ-45 connector. Use the LAN-to-phone connector to connect the IP phone to the switch. Refer to the Cisco IP Phone documentation for more information about connecting devices to it.




Note Many legacy powered devices, including older Cisco IP phones and access points that do not fully support IEEE 802.3af, might not support PoE when connected to the switches by a crossover cable.

Step 2 Connect the other end of the cable to an RJ-45 connector on the other device. The port LED turns on when both the switch and the connected device have established link.

The port LED is amber while Spanning Tree Protocol (STP) discovers the topology and searches for loops. This takes about 30 seconds, and then the port LED turns green. If the port LED does not turn on, the device at the other end might not be turned on, or there might be a cable problem or a problem with the adapter installed in the attached device. See [Chapter 4, “Troubleshooting,”](#) for solutions to cabling problems.

Step 3 Reconfigure and reboot the connected device if necessary.

Step 4 Repeat Steps 1 through 3 to connect each device.

Figure 3-45 Connecting to an Ethernet Port

Connecting to an SFP Module

This section describes how to connect to SFP modules. For instructions on how to connect to fiber-optic SFP modules, see the [“Connecting to 1000BASE-T SFP Modules”](#) section. For instructions on how to connect to 1000BASE-T SFP modules, see the [“Connecting to 1000BASE-T SFP Modules”](#) section.

For instructions about how to install or remove an SFP module, see the [“Installing and Removing SFP Modules”](#) section on page 3-41.

Connecting to a Fiber-Optic SFP Module

Follow these steps to connect a fiber-optic cable to an SFP module:

**Caution**

Do not remove the rubber plugs from the SFP module port or the rubber caps from the fiber-optic cable until you are ready to connect the cable. The plugs and caps protect the SFP module ports and cables from contamination and ambient light.

Before connecting to the SFP module, be sure that you understand the port and cabling stipulations in [“Installation Guidelines”](#) section on page 3-7 and in the [“SFP Module Slots”](#) section on page 2-12. See [Appendix B, “Connector and Cable Specifications”](#) for information about the LC on the SFP module.


-
- Step 1** Remove the rubber plugs from the module port and fiber-optic cable, and store them for future use.
 - Step 2** Insert one end of the fiber-optic cable into the SFP module port (see [Figure 3-46](#)).
 - Step 3** Insert the other cable end into a fiber-optic receptacle on a target device.
 - Step 4** Observe the port status LED.

The LED turns green when the switch and the target device have an established link.

The LED turns amber while the STP discovers the network topology and searches for loops. This process takes about 30 seconds, and then the port LED turns green.

If the LED is off, the target device might not be turned on, there might be a cable problem, or there might be problem with the adapter installed in the target device. See [Chapter 4, “Troubleshooting,”](#) for solutions to cabling problems.

Figure 3-46 Connecting to an SFP Module Port



1	LC connector
---	--------------

Step 5 If necessary, reconfigure and restart the switch or target device.

**Caution**

For detailed instructions on removing the SFP modules, refer to your SFP documentation.

Connecting to 1000BASE-T SFP Modules

Follow these steps to connect a Category 5 cable to a 1000BASE-T SFP module:



Caution

To prevent ESD damage, follow your normal board and component handling procedures.

Step 1


When connecting to servers, workstations, and routers, insert a four twisted-pair, straight-through cable in the RJ-45 connector. When connecting to switches or repeaters, insert a four twisted-pair, crossover cable.



Note

When connecting to a 1000BASE-T device, be sure to use a four twisted-pair, Category 5 cable.

Figure 3-47 Connecting to an SFP Module Port



1	RJ-45 connector
----------	-----------------

Step 2 Insert the other cable end in an RJ-45 connector on a target device.

Step 3 Observe the port status LED.

The LED turns green when the switch and the target device have an established link.

The LED turns amber while the STP discovers the network topology and searches for loops. This process takes about 30 seconds, and then the port LED turns green.

If the LED is off, the target device might not be turned on, there might be a cable problem, or there might be problem with the adapter installed in the target device. See [Chapter 4, “Troubleshooting,”](#) for solutions to cabling problems.

Step 4 If necessary, reconfigure and restart the switch or target device.

Connecting to a XENPAK Module

Follow these steps to connect a fiber-optic cable to a XENPAK module:



Caution

Do not remove the rubber plugs from the XENPAK module ports or the rubber caps from the fiber-optic cable until you are ready to connect the cable. The plugs and caps protect the XENPAK module ports and cables from contamination and ambient light.



Note

The 10-Gigabit Ethernet XENPAK modules are referred to as 10-Gigabit Ethernet module ports in the switch software documentation.



Note

Make sure that the XENPAK module is fully inserted into the module slot and that the captive installation screws are fully tightened before attaching the fiber-optic interface cable connector to the XENPAK module connector.

Step 1 Remove the rubber plugs from the XENPAK module ports and fiber-optic cable, and store them for future use.

Step 2 Align the fiber-optic cable SC connector with the XENPAK module connector, so that transmit (TX) on the cable meets receive (RX) on the XENPAK module connector, and RX on the cable meets TX on the XENPAK module.

Step 3 Insert the fiber-optic cable connector into the XENPAK module ports (see [Figure 3-48](#)).

Connecting to a XENPAK Module

Step 4 Insert the other cable end into a fiber-optic receptacle on a target device.


Step 5 Observe the XENPAK module port status LED.

The LED turns green when the switch and the target device have an established link.

The LED turns amber while the STP discovers the network topology and searches for loops. This process takes about 30 seconds, and then the port LED turns green.

If the LED is off, the target device might not be turned on, there might be a cable problem, or there might be problem with the adapter installed in the target device. See [Chapter 4, “Troubleshooting,”](#) for solutions to cabling problems.

Figure 3-48 Connecting to a XENPAK Module Port



1	SC connector
----------	--------------

Step 6 If necessary, reconfigure and restart the switch or target device.

Where to Go Next

If the default configuration is satisfactory, the switch does not need further configuration. You can use any of these management options to change the default configuration:

- Start CMS as described in the switch software configuration guide, and configure the switch as a member of a cluster or as an individual switch.
- Use the CLI to configure the switch as a member of a cluster or as an individual switch from the console. Refer to the *Catalyst 3750 Switch Command Reference* on Cisco.com for information on using the CLI with a Catalyst 3750 switch.
- Start an SNMP application such as the CiscoView application.

■ Where to Go Next



Troubleshooting

The LEDs on the front panel provide troubleshooting information about the switch. They show failures in the power-on self-test (POST), port-connectivity problems, and overall switch performance. For a full description of the switch LEDs, see the [“LEDs” section on page 2-13](#).

You can also get statistics from the browser interface, from the command-line interface (CLI), or from a Simple Network Management Protocol (SNMP) workstation. Refer to the software configuration guide, the switch command reference guide on Cisco.com, or the documentation that came with your SNMP application for details.

This chapter describes these topics for troubleshooting problems:

- [Understanding POST Results, page 4-1](#)
- [Clearing the Switch IP Address and Configuration, page 4-2](#)
- [Replacing a Failed Stack Member, page 4-9](#)

Understanding POST Results

As the switch powers on, it begins the power-on self-test (POST), a series of tests that runs automatically to ensure that the switch functions properly. POST lasts approximately 1 minute.

When the switch begins POST, the System, the RPS, the Master, the Status, the Duplex, the Speed, and the Stack LEDs turn green. (On the Catalyst 3750-24PS and 3750-48PS switches, the Power over Ethernet [PoE] LED also turns green as POST begins.) The System LED flashes green, and the other LEDs remain continuous green.

When POST completes successfully, the System LED remains green. The RPS LED remains green for some time and then returns to its operating status. The other LEDs turn off and return to their operating status.

**Note**

For information on operating status for the LEDs, go to the “LEDs” section on page 2-13.

If a switch fails POST, the System LED turns amber. A POST failure usually means that there is physical damage to a port. A common cause for failure is ESD. If an Ethernet controller fails, it results in port failure. During the switch power-up sequence, you can monitor the POST tests through a console port connection. When the switch is running, you can also use the **show post** privileged EXEC command to see if any port has failed a POST test.

**Note**

POST failures are usually fatal. Call Cisco Systems if your switch does not pass POST.

Clearing the Switch IP Address and Configuration

If you have configured a new switch with a wrong IP address, or all the switch LEDs start blinking when you are trying to enter Express Setup mode, you can clear the IP address that is configured on the switch.

**Note**

This procedure will clear the IP address and all configuration information stored on the switch. Do not follow this procedure unless you want to completely reconfigure the switch.

To clear the IP address and the switch configuration information, follow these steps:

Step 1 Press and hold the Mode button. (see [Figure 1-4 on page 1-6.](#))

The switch LEDs begin blinking after about 2 seconds.



Note If the switch is not configured, the mode buttons are all green. You can omit Step 2 and run Express Setup to configure the switch.

Step 2 Continue holding down the Mode button. The LEDs stop blinking after 8 additional seconds, and then the switch reboots.



Note These steps only work on a previously-configured switch.

The switch now behaves like an unconfigured switch. You can configure the switch by using Express Setup as described in these sections.

- [“Starting Express Setup” section on page 1-5](#)
- [“Configuring the Switch” section on page 1-11](#)
- [“Verifying Switch IP Address” section on page 1-13](#)

You can also configure the switch by using the command-line interface (CLI) setup procedure described in these sections:

- [“Starting the Terminal Emulation Software” section on page C-9](#)
- [“Entering the Initial Configuration Information” section on page C-11](#)

Diagnosing Problems

The LEDs on the front panel provide troubleshooting information about the switch. They show POST failures, port-connectivity problems, and overall switch performance. For a full description of the switch LEDs, see the “LEDs” section on page 2-13.

You can also get statistics from the browser interface, from the CLI, or from an SNMP workstation. Refer to the software configuration guide, the switch command reference guide on Cisco.com, or the documentation that came with your SNMP application for details.

You can access the Technical Support Website (<http://www.cisco.com/techsupport>) for a list of known hardware problems and extensive troubleshooting documentation including:

- Field notices
- Security advisories
- Troubleshooting resources
- Factory defaults
- Password recovery
- Recovery from corrupted or missing software
- Switch port problems
- Network interface cards
- Troubleshooting tools

Common switch problems fall into these categories:

- Poor performance
- No connectivity
- Corrupted software

[Table 4-1](#) describes how to detect and resolve these problems.

Table 4-1 Common Problems and Solutions

Symptom	Possible Cause	Resolution
Poor performance or excessive errors	Duplex autonegotiation mismatch.	Refer to the switch software configuration guide for information on identifying autonegotiation mismatches. Verify that the autonegotiation settings are the same at both ends.
	<p>Cabling distance exceeded</p> <ul style="list-style-type: none"> • Port statistics show excessive frame check sequence (FCS), late-collision, or alignment errors. • For 10/100 and 10/100/1000BASE-T connections: <ul style="list-style-type: none"> – The distance between the port and the attached device exceeds 328 feet (100 meters). – If the switch is attached to a repeater, the total distance between the two end stations exceeds the cabling guidelines. • SFP or XENPAK cabling guidelines exceeded. 	<ul style="list-style-type: none"> • Refer to the switch software configuration guide for information on displaying port statistics. • Reduce the cable length to within the recommended distances. • Refer to your repeater documentation for cabling guidelines. • Refer to your SFP or XENPAK documentation for cabling guidelines.
	<p>Bad adapter in attached device</p> <ul style="list-style-type: none"> • Excessive errors found in port statistics. • STP checking for possible loops. 	<ul style="list-style-type: none"> • Run adapter card diagnostic utility. • Wait 30 seconds for the port LED to turn green.

Table 4-1 Common Problems and Solutions (continued)

Symptom	Possible Cause	Resolution
No connectivity	<p data-bbox="452 287 676 313">Incorrect or bad cable</p> <p data-bbox="452 329 844 386">These are results of no link at both ends:</p> <ul data-bbox="466 407 854 1425" style="list-style-type: none"> <li data-bbox="466 407 854 500">• A crossover cable was used when a straight-through was required, or vice-versa. <li data-bbox="466 1154 854 1180">• The cable is wired incorrectly. <li data-bbox="466 1230 854 1287">• A crossover or straight-through cable is wired incorrectly. <li data-bbox="466 1370 854 1425">• STP checking for possible loops. 	<ul data-bbox="893 407 1237 797" style="list-style-type: none"> <li data-bbox="893 407 1237 626">• For the correct pinouts and the proper application of crossover vs. straight-through cables, see the “Two Twisted-Pair Cable Pinouts” section on page B-5. <li data-bbox="893 675 1237 797">• Enable the automatic medium-dependent-interface crossover (Auto-MDIX) feature. <p data-bbox="880 816 1237 1125">Note Many legacy powered devices, including older Cisco IP phones and access points that do not fully support IEEE 802.3af, might not support PoE when connected to the switches by a crossover cable.</p> <ul data-bbox="893 1159 1237 1435" style="list-style-type: none"> <li data-bbox="893 1159 1237 1216">• Replace with a tested good cable. <li data-bbox="893 1234 1237 1356">• For 1000BASE-T connections, be sure to use a twisted four-pair, Category 5 cable. <li data-bbox="893 1373 1237 1435">• Wait 30 seconds for the port LED to turn green.

Table 4-1 Common Problems and Solutions (continued)

Symptom	Possible Cause	Resolution
Unreadable characters on the management console	Incorrect baud rate.	Reset the emulation software to 9600 baud.
Amber system LED	Fatal POST error detected.	Contact Cisco Systems.
Switch port in error-disabled state after SFP or XENPAK inserted	Bad or non-Cisco-approved SFP or XENPAK module.	Remove the SFP or XENPAK module from the switch, and replace it with a Cisco-approved module. Use the errdisable recovery cause gbic-invalid global configuration command to verify the port status, and enter a time interval to recover from the error-disable state. Refer to the switch command reference guide for information on the errdisable recovery command.
Powered device connected to PoE port, but no power given	Switch might not have enough power capacity to deliver PoE to a new powered device.	Use the Mode button to show the PoE status for all ports. <ul style="list-style-type: none"> If the port status LED is alternating green and amber, connect the powered device to an external AC power source.
	PoE might be disabled on switch port.	<ul style="list-style-type: none"> If the port status LED is amber, configure the switch port PoE setting to Auto. <p>Note PoE is enabled by default.</p>

Table 4-1 Common Problems and Solutions (continued)


Symptom	Possible Cause	Resolution
<p>PoE mode LED blinks amber</p> <p>Note When the PoE mode is selected, a green PoE LED means that the port status LEDs show the PoE status.</p>	<p>At least one PoE port has a fault, or power has been denied to at least one of the PoE ports.</p> <p> Caution PoE faults are caused when noncompliant cabling or powered devices are connected to a PoE port. Only standard-compliant cabling can be used to connect Cisco pre-standard IP Phones and wireless access points or IEEE 802.3af-compliant devices to PoE ports. A cable or device that causes a PoE fault must be removed from the network.</p>	<p>Use the Mode button to show the PoE status for all ports. The affected port LEDs blink amber or alternate green and amber.</p> <p>If a port LED blinks amber, there is a PoE fault. A cable or device that causes a PoE fault must be removed from the network.</p> <p>If a port status LED is alternating green and amber, connect the powered device to an external AC power source.</p> <p>Note You can also use the CMS or CLI to search for PoE faults.</p>

Table 4-1 Common Problems and Solutions (continued)

Symptom	Possible Cause	Resolution
SFP or XENPAK module not recognized	<p>The SFP or XENPAK module might be installed upside down.</p> <p>The SFP or XENPAK module does not snap into the slot.</p>	<p>Verify that the SFP or XENPAK module is not installed upside down.</p> <p>Remove the SFP or XENPAK module. Inspect for physical damage to the connector, the module, and the module slot.</p> <p>Replace the SFP or XENPAK module with a known good module.</p>
No stack link between switches or high error rate between switches in the stack	<p>Poor cable connection.</p> <p>Bad StackWise cable or damaged StackWise port.</p>	<p>Secure the thumb screws on the StackWise cables. See Figure 3-35.</p> <p>Remove the StackWise cable, and inspect the cable and StackWise port for bent pins or damaged connectors.</p> <p>If the StackWise cable is bad, replace it with a known good cable.</p>

Replacing a Failed Stack Member

If you need to replace a failed stack member, you can hot swap or replace the switch by following this procedure:

-
- Step 1** Get a replacement switch that has the same model number as the failed switch.
 - Step 2** Power down the failed switch.

Step 3 Make sure the replacement switch is powered off, and then connect the replacement switch to the stack.



Note If you had manually set the member numbers for any members in the stack, you need to manually assign the replacement switch the same member number as the failed switch. To assign the member number manually, refer to the switch software configuration guide.

Step 4 Make the same Ethernet and Gigabit Ethernet connections on the replacement switch (as were on the failed switch).

Step 5 Power on the replacement switch.

The replacement switch will have the same configuration for all the interfaces as the failed switch and will function the same as the failed switch.



Technical Specifications

This appendix lists the switch technical specifications in [Table A-2](#), [Table A-3](#), [Table A-7](#), [Table A-8](#), and the regulatory agency approvals in [Table A-9](#).

Table A-1 *Specifications for the Catalyst 3750G-12S Switch*

Environmental Ranges	
Operating temperature	32 to 113°F (0 to 45°C)
Storage temperature	-13 to 158°F (-25 to 70°C)
Relative humidity	10 to 85% (noncondensing)
Operating altitude	Up to 10,000 ft (3049 m)
Storage altitude	Up to 15,000 ft (4573 m)
Power Requirements	
AC input voltage	100 to 240 VAC (autoranging) 1.2A/0.6A, 50 to 60 Hz
DC input voltages for RPS 300	---+12V---@13A
DC input voltages for RPS 675	---+12V---@13A
Power consumption	120 W, 409 BTUs per hour
Power rating	0.120 kVA

Table A-1 Specifications for the Catalyst 3750G-12S Switch (continued)

Environmental Ranges	
Physical Dimensions	
Weight	10 lb (4.55 kg)
Dimensions (H x D x W)	1.73 x 12.83 x 17.5 in. (4.39 x 32.59 x 44.45 cm)

Table A-2 Specifications for the Catalyst 3750-24TS Switch

Environmental Ranges	
Operating temperature	32 to 113°F (0 to 45°C)
Storage temperature	-13 to 158°F (-25 to 70°C)
Relative humidity	10 to 85% (noncondensing)
Operating altitude	Up to 10,000 ft (3049 m)
Storage altitude	Up to 15,000 ft (4573 m)
Power Requirements	
AC input voltage	100 to 240 VAC (autoranging) 1.2A/0.6A, 50 to 60 Hz
DC input voltages for RPS 300	+++12V+++ @8.5A
DC input voltages for RPS 675	+++12V+++ @8.5A
Power consumption	50W, 171 BTUs per hour
Power rating	0.083 kVA

Table A-2 Specifications for the Catalyst 3750-24TS Switch (continued)

Environmental Ranges	
Physical Dimensions	
Weight	8 lb (3.6 kg)
Dimensions (H x D x W)	1.73 x 11.83 x 17.5 in. (4.39 x 30.05 x 44.45 cm)

Table A-3 Specifications for the Catalyst 3750G-24T Switch

Environmental Ranges	
Operating temperature	32 to 113°F (0 to 45°C)
Storage temperature	-13 to 158°F (-25 to 70°C)
Relative humidity	10 to 85% (noncondensing)
Operating altitude	Up to 10,000 ft (3049 m)
Storage altitude	Up to 15,000 ft (4573 m)
Power Requirements	
AC input voltage	100 to 240 VAC (autoranging) 1.6A/0.9A, 50 to 60 Hz
DC input voltage for RPS 300	+++12V--- @ 13A
DC input voltages for RPS 675	+++12V--- @ 13A
Power consumption	165W, 563 BTUs per hour
Power rating	0.165 kVA
Physical Dimensions	
Weight	10 lb (4.55 kg)
Dimensions (H x D x W)	1.73 x 12.83 x 17.5 in. (4.39 x 32.59 x 44.45 cm)

Table A-4 Technical Specifications for the Catalyst 3750-24PS Switch

Environmental Ranges	
Operating temperature	32 to 113°F (0 to 45°C)
Storage temperature	-13 to 158°F (-25 to 70°C)
Relative humidity	10 to 85% (noncondensing)
Operating altitude	Up to 10,000 ft (3049 m)
Storage altitude	Up to 15,000 ft (4573 m)
Power Requirements	
AC input voltage	100 to 127/200 to 240 VAC (autoranging) 5.5 A/2.8 A, 50 to 60 Hz
DC input voltage for RPS 675	---+12 V---@7.5 A and ---48 V---@7.8 A
Power consumption	495 W
Power dissipation	125 W, 426 BTUs per hour
Power rating	0.495 kVA
Power over Ethernet	
15.4 W per port maximum, 370 W switch maximum	
Physical Dimensions	
Weight	11.3 lb (5.14 kg)
Dimensions (H x D x W)	1.73 x 11.83 x 17.5 in. (4.39 x 30.05 x 44.45 cm)

Table A-5 Specifications for the Catalyst 3750-48PS Switch

Environmental Ranges	
Operating temperature	32 to 113°F (0 to 45°C)
Storage temperature	-13 to 158°F (-25 to 70°C)
Relative humidity	10 to 85% (noncondensing)
Operating altitude	Up to 10,000 ft (3049 m)
Storage altitude	Up to 15,000 ft (4573 m)
Power Requirements	
AC input voltage	100 to 127/200 to 240 VAC (autoranging) 5.5 A/2.8 A, 50 to 60 Hz
DC input voltages for RPS 675	---+12 V---@7.5 A and ---48 V---@7.8 A
Power consumption	540 W
Power dissipation	170 W, 580 BTUs per hour
Power rating	0.54 kVA
Power over Ethernet	
Range from 4.0 to 15.4 W per port, up to 370 W switch maximum	
Physical Dimensions	
Weight	13.2 lb (6 kg)
Dimensions (H x D x W)	1.73 x 14.87 x 17.5 in. (4.39 x 37.77 x 44.45 cm)

Table A-6 Specifications for the Catalyst 3750G-16TD Switch

Environmental Ranges	
Operating temperature	32 to 113°F (0 to 45°C)
Storage temperature	-13 to 158°F (-25 to 70°C)
Relative humidity	10 to 85% (noncondensing)
Operating altitude	Up to 10,000 ft (3049 m)
Storage altitude	Up to 15,000 ft (4573 m)
Power Requirements	
AC input voltage	100 to 240 VAC (autoranging) 1.6A/0.9A, 50 to 60 Hz
DC input voltages for RPS 675	---+12V--- @17A
Power consumption	180 W, 615 BTUs per hour
Power rating	0.180 kVA
Physical Dimensions	
Weight	12.5 lb (5.68 kg)
Dimensions (H x D x W)	1.73 x 17.5 x 16.1 in. (4.39 x 44.45 x 40.89 cm)

Table A-7 Specifications for the Catalyst 3750G-24TS Switch

Environmental Ranges	
Operating temperature	32 to 113°F (0 to 45°C)
Storage temperature	-13 to 158°F (-25 to 70°C)
Relative humidity	10 to 85% (noncondensing)
Operating altitude	Up to 10,000 ft (3049 m)
Storage altitude	Up to 15,000 ft (4573 m)
Power Requirements	
AC input voltage	100 to 240 VAC (autoranging) 2.3A/1.5A, 50 to 60 Hz
DC input voltages for RPS 675	---+12V--- @17A
Power consumption	190W, 650 BTUs per hour
Power rating	0.190 kVA
Physical Dimensions	
Weight	12.5 lb (5.68 kg)
Dimensions (H x D x W)	2.59 x 11.60 x 17.5 in. (6.59 x 29.46 x 44.45 cm)

Table A-8 Specifications for the Catalyst 3750-48TS Switch

Environmental Ranges	
Operating temperature	32 to 113°F (0 to 45°C)
Storage temperature	-13 to 158°F (-25 to 70°C)
Relative humidity	10 to 85% (noncondensing)
Operating altitude	Up to 10,000 ft (3049 m)
Storage altitude	Up to 15,000 ft (4573 m)
Power Requirements	
AC input voltage	100 to 240 VAC (autoranging) 1.2A/0.6A, 50 to 60 Hz
DC input voltages for RPS 300	+++12V@8.5A
DC input voltages for RPS 675	+++12V---@8.5A
Power consumption	75W, 256 BTUs per hour
Power rating	0.075 kVA
Physical Dimensions	
Weight	9.1 lb (4.1 kg)
Dimensions (H x D x W)	1.73 x 11.83 x 17.5 in. (4.39 x 30.05 x 44.45 cm)

Table A-9 Catalyst 3750 Switch Agency Approvals

Safety	EMC
UL to UL 60950, Third Edition	FCC Part 15 Class A
c-UL to CAN/CSA -C22.2 No. 60950-00, Third Edition	EN 55022 1998 Class A (CISPR 22)
	EN 55024 1998 Class A (CISPR 24)
TUV/GS to EN 60950:2000	VCCI Class A
CB to IEC 60950 with all country deviations	AS/NZS 3548 Class A
NOM to NOM-019-SCFI	CNS13438 Class A

Table A-9 Catalyst 3750 Switch Agency Approvals (continued)

Safety	EMC
CE Marking	CE
	MIC



Connector and Cable Specifications

This appendix describes the Catalyst 3750 switch ports and the cables and adapters that you use to connect the switch to other devices.

Connector Specifications


These sections describe the connectors used with the Catalyst 3750 switches.

10/100 and 10/100 /1000 Ports

The 10/100 and 10/100/1000 Ethernet ports on Catalyst 3750 switches use standard RJ-45 connectors and Ethernet pinouts with internal crossovers.


Figure B-2 and Figure B-1 show the pinouts.

Figure B-1 10/100 Port Pinouts

Pin	Label	1 2 3 4 5 6 7 8
1	RD+	
2	RD-	
3	TD+	
4	NC	
5	NC	
6	TD-	
7	NC	
8	NC	

H5318

Figure B-2 10/100/1000 Port Pinouts


Pin	Label	1 2 3 4 5 6 7 8
1	TP0+	
2	TP0-	
3	TP1+	
4	TP2+	
5	TP2-	
6	TP1-	
7	TP3+	
8	TP3-	

60915

SFP Module Ports

The Catalyst 3750 switch uses SFP modules for fiber-optic and copper uplink ports. Refer to the Catalyst 3750 release notes for a list of supported SFP modules.

Figure B-3 Fiber-Optic SFP Module LC Connector



58476



Warning

Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments.

Figure B-4 Copper SFP Module RJ-45 Connector


Pin	Label	1	2	3	4	5	6	7	8
1	TP0+								
2	TP0-								
3	TP1+								
4	TP2+								
5	TP2-								
6	TP1-								
7	TP3+								
8	TP3-								

60915

XENPAK Module Ports

The Catalyst 3750G-16TD switch uses XENPAK modules for 10-Gigabit fiber-optic connections to networks. Refer to the Catalyst 3750 release notes for a list of supported XENPAK modules. Fiber-optic XENPAK modules use SC connectors, as shown in [Figure B-5](#).

Figure B-5 Fiber-Optic XENPAK Module SC Connector



Warning

Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments.

Console Port

The console port uses an 8-pin RJ-45 connector, which is described in [Table B-1](#) and [Table B-2](#). The supplied RJ-45-to-DB-9 adapter cable is used to connect the console port of the switch to a console PC. You need to provide a RJ-45-to-DB-25 female DTE adapter if you want to connect the switch console port to a terminal. You can order a kit (part number ACS-DSBUASYN=) containing that adapter from Cisco. For console port and adapter pinout information, see [Table B-1](#) and [Table B-2](#).

Cable and Adapter Specifications

These sections describe the cables and adapters used with Catalyst 3750 switches.

Two Twisted-Pair Cable Pinouts

Figure B-6 and Figure B-7 show the schematics of two twisted-pair cables for 10/100 ports.

Figure B-6 Two Twisted-Pair Straight-Through Cable Schematic






Figure B-7 Two Twisted-Pair Crossover Cable Schematic



Four Twisted-Pair Cable Pinouts for 10/100 Ports


Figure B-8 and Figure B-9 show the schematics of four twisted-pair cables for 10/100 ports.

Figure B-8 *Four Twisted-Pair Straight-Through Cable Schematic for 10/100 Ports*



65271

Figure B-9 *Four Twisted-Pair Crossover Cable Schematic for 10/100 Ports*



65273

Four Twisted-Pair Cable Pinouts for 1000BASE-T Ports

Figure B-10 and Figure B-11 show the schematics of four twisted-pair cables for 10/100/1000 ports on Catalyst 3750 switches.

Figure B-10 Four Twisted-Pair Straight-Through Cable Schematic for 10/100/1000 Ports





Figure B-11 Four Twisted-Pair Crossover Cable Schematics for 10/100/1000 and 1000BASE-T SFP Module Ports




Crossover Cable and Adapter Pinouts

This section describes how to identify a crossover cable and also describes the adapter pinouts.

Identifying a Crossover Cable

To identify a crossover cable, compare the two modular ends of the cable. Hold the cable ends side-by-side, with the tab at the back. The wire connected to the pin on the outside of the left plug should be the same color as the wire connected to the pin on the outside of the right plug. (See [Figure B-12](#).)

Figure B-12 Identifying a Crossover Cable



**Note**

You can use the **mdix auto** interface configuration command in the CLI to enable the automatic medium-dependent interface crossover (Auto-MDIX) feature. When the Auto-MDIX feature is enabled, the switch detects the required cable type for copper Ethernet connections and configures the interfaces accordingly. Therefore, you can use either a crossover or a straight-through cable for connections to a copper 10/100, 10/100/1000, or 1000BASE-T SFP module port on the switch, regardless of the type of device on the other end of the connection.

The Auto-MDIX feature is enabled by default on switches running Cisco IOS Release 12.2(18)SE or later. For releases between Cisco IOS Release 12.1(14)EA1 and 12.2(18)SE, the Auto-MDIX feature is disabled by default. For configuration information for this feature, refer to the switch software configuration guide or the switch command reference.

Adapter Pinouts

[Table B-1](#) lists the pinouts for the console port, the RJ-45-to-DB-9 adapter cable, and the console device.

Table B-1 Console Port Signaling Using a DB-9 Adapter

Switch Console Port (DTE)	RJ-45-to-DB-9 Terminal Adapter	Console Device
Signal	DB-9 Pin	Signal
RTS	8	CTS
DTR	6	DSR
TxD	2	RxD
GND	5	GND
GND	5	GND
RxD	3	TxD
DSR	4	DTR
CTS	7	RTS

Table B-2 lists the pinouts for the console port, RJ-45-to-DB-25 female DTE adapter, and the console device.

**Note**

The RJ-45-to-DB-25 female DTE adapter is not supplied with the switch. You can order a kit (part number ACS-DSBUASYN=) containing this adapter from Cisco.

Table B-2 Console Port Signaling Using a DB-25 Adapter

Switch Console Port (DTE)	RJ-45-to-DB-25 Terminal Adapter	Console Device
Signal	DB-25 Pin	Signal
RTS	5	CTS
DTR	6	DSR
TxD	3	RxD
GND	7	GND
GND	7	GND
RxD	2	TxD
DSR	20	DTR
CTS	4	RTS



Configuring the Switch with the CLI-Based Setup Program

This appendix provides a CLI-based setup procedure for a standalone switch or a switch stack. Before connecting the switch to a power source, review the safety warnings in [Chapter 3, “Switch Installation.”](#)



Note

For detailed installation procedures on rack-mounting your switch, stacking your switches, or connecting to small form-factor pluggable (SFP) or XENPAK modules, see [Chapter 3, “Switch Installation.”](#) For product overview information, see [Chapter 2, “Product Overview.”](#)

These steps describe how to do a simple installation:

1. [Accessing the CLI, page C-2](#)
2. [Taking Out What You Need, page C-4](#)
3. [Stacking the Switches \(Optional\), page C-5](#)
4. [Connecting to the Console Port, page C-7](#)
5. [Starting the Terminal Emulation Software, page C-9](#)
6. [Connecting to a Power Source, page C-9](#)
7. [Entering the Initial Configuration Information, page C-11](#)

Accessing the CLI

For an unconfigured switch, you can access the CLI through Express Setup or through the console port.

Accessing the CLI Through Express Setup

**Note**

Express Setup is supported on switches running Cisco IOS Release 12.1(14)EA1 or later. If you are installing a new switch, refer to the Cisco IOS release label on the rear panel of the switch to determine the release.

For switches running releases earlier than Cisco IOS Release 12.1(14)EA1, go to the [“Taking Out What You Need” section on page C-4](#).

You can access the CLI on an unconfigured switch by placing the switch in Express Setup mode and then connecting an Ethernet port of the switch to the Ethernet port of your PC or workstation. To put the switch into Express Setup mode, follow the steps described in [Chapter 1, “Using Express Setup,”](#) for powering on the switch and using Express Setup.

After the switch is in Express Setup mode, use Telnet to connect to the switch by using the IP address *10.0.0.1*, and enter the **setup** user EXEC command. See these sections in this chapter to then configure the switch by using the CLI:

- [Entering the Initial Configuration Information, page C-11](#)
- [Completing the Setup Program, page C-11](#)

After you have entered the configuration information for the switch, save it to flash memory by using the **write memory** privileged EXEC command.

**Note**

While in Express Setup mode, the IP address 10.0.0.1 remains active on the switch until you enter the **write memory** command. You lose the Telnet connection after entering the **write memory** command.

For more information about using the CLI, refer to the command reference for this release.

Accessing the CLI Through the Console Port

You can access the CLI on a configured or unconfigured switch by connecting the console port of the switch to the serial port on your PC or workstation and accessing the switch through a Telnet session.


To access the switch through the console port, follow these steps:

- [“Taking Out What You Need” section on page C-4.](#)
- [“Connecting to the Console Port” section on page C-7](#)
- [“Starting the Terminal Emulation Software” section on page C-9](#)
- [“Connecting to a Power Source” section on page C-9](#)
- [“Entering the Initial Configuration Information” section on page C-11](#)

Taking Out What You Need

Remove the items shown in Figure C-1 from the shipping container:

Figure C-1 The Catalyst 3750 Switch, Adapter Cable, AC Power Cord, and the StackWise Cable



90533

1	Catalyst 3750 switch	3	AC power cord
2	RJ-45-to-DB-9 adapter cable	4	StackWise cable (optional)

**Note**

You need to provide the Category 5 straight-through cables to connect the switch ports to other Ethernet devices.

**Note**

You can use the **mdix auto** interface configuration command in the CLI to enable the automatic medium-dependent interface crossover (Auto-MDIX) feature. When the Auto-MDIX feature is enabled, the switch detects the required cable type for copper Ethernet connections and configures the interfaces accordingly. Therefore, you can use either a crossover or a straight-through cable for connections to a copper 10/100, 10/100/1000, or 1000BASE-T SFP module port on the switch, regardless of the type of device on the other end of the connection.

The Auto-MDIX feature is enabled by default on switches running Cisco IOS Release 12.2(18)SE or later. For releases between Cisco IOS Release 12.1(14)EA1 and 12.2(18)SE, the Auto-MDIX feature is disabled by default. For configuration information for this feature, refer to the switch software configuration guide or the switch command reference.

Stacking the Switches (Optional)

You can stack up to nine switches by using the StackWise cables and ports to connect the switches.

Read the “[Planning the Stack](#)” section on page 3-14 before you stack your switches.

Figure C-2 Stacking the Switches



90529

Step 1 Insert one end of the StackWise cable into the StackWise port at the back of a switch. See Figure C-3.




Note Always use a Cisco-approved StackWise cable to connect the switches.

Step 2 Use the window in the StackWise cable to align the connector correctly. Secure the screws tightly.

Step 3 Insert the other end of the cable into the connector of the other switch, and secure the screws tightly.

See the [“Connecting StackWise Cable to StackWise Ports”](#) section on page 3-38 for detailed installation procedures on how to connect the switches in a stack.

Figure C-3 Connecting the StackWise Cable to a StackWise Port



Connecting to the Console Port

You can use the console port to perform the initial configuration. To connect the switch console port to a PC, use the supplied RJ-45-to-DB-9 adapter cable.


**Note**

If you have stacked your switches, connect to the console port of one of the switches in the stack. The initial configuration for the entire stack can be performed on any switch in the stack.

Follow these steps to connect the PC or terminal to the switch:

-
- Step 1** Using the supplied RJ-45-to-DB-9 adapter cable, insert the RJ-45 connector into the console port on the rear of a switch, as shown in [Figure C-4](#).
- Step 2** Attach the DB-9 female DTE of the adapter cable to a PC's serial port, or attach an appropriate adapter to the terminal.
-

Figure C-4 Connecting a Switch to a PC



1	Catalyst 3750 switches	3	RJ-45-to-DB-9 adapter cable
2	Power cord		

90531

Starting the Terminal Emulation Software

Before you power on the switch, start the terminal emulation session so that you can see the output display from the power-on self-test (POST).

The terminal-emulation software—frequently a PC application such as Hyperterminal or ProcommPlus—makes communication between the switch and your PC or terminal possible.

-
- Step 1** Start the terminal-emulation program if you are using a PC or terminal.
- Step 2** Start a terminal-emulation session.
- Step 3** Configure the baud rate and character format of the PC or terminal to match these console port default characteristics:
- 9600 baud
 - 8 data bits
 - 1 stop bit
 - No parity
 - None (flow control)
-

Connecting to a Power Source

Follow these steps to connect to a power source:

-
- Step 1** Connect one end of the supplied AC power cord to the power connector on a switch rear panel. See [Figure C-4](#).
- Step 2** Connect the other end of the power cable to a grounded AC outlet.
- Step 3** (Optional) If you have a stack, power on all the switches in the stack.



Note If you have stacked your switches, refer to the [“Powering Considerations” section on page 3-15](#) for more information.



Note If you are connecting the switch to a Cisco redundant power system (RPS), refer to the documentation that shipped with your RPS.

As the switch powers on, it begins the power-on self-test (POST), a series of tests that runs automatically to ensure that the switch functions properly. POST lasts approximately 1 minute.

When the switch begins POST, the System, the RPS, the Master, the Status, the Duplex, the Speed, and the Stack LEDs turn green. (On the Catalyst 3750-24PS and 3750-48PS switches, the Power over Ethernet [PoE] LED also turns green as POST begins.) The System LED flashes green, and the other LEDs remain continuous green.

When POST completes successfully, the System LED remains green. The RPS LED remains green for some time and then returns to its operating status. The other LEDs turn off and return to their operating status. When POST fails, the System LED turns amber. If POST fails, see [Chapter 4, “Troubleshooting,”](#) to determine a course of action.

After you have powered all the switches in the stack, a switch is elected as the stack master. The master LED is green on the stack master switch.

If you started the terminal emulation program before you powered on your switch, the PC or terminal displays the bootloader sequence. You need to press **Enter** to display the setup program prompt.

Entering the Initial Configuration Information

To set up the switch, you need to complete the setup program, which runs automatically after the switch is powered up. You must assign an IP address and other configuration information necessary for the switch to communicate with the local routers and the Internet. This information is also required if you plan to use the Cluster Management Suite (CMS) to configure and manage the switch.

IP Settings

You will need this information from your network administrator before you complete the setup program:

- Switch IP address
- Subnet mask (IP netmask)
- Default gateway (router)
- Enable secret password
- Enable password
- Telnet password

Completing the Setup Program

**Note**

If your switches are stacked and there are multiple console connections to individual switches in the stack, the initial setup dialog appears in the first console where the user presses **Enter**.

Follow these steps to complete the setup program and to create an initial configuration for the switch:

Step 1 Enter **Yes** at the following two prompts.

■ Entering the Initial Configuration Information

```
Would you like to enter the initial configuration dialog? [yes/no]:  
yes
```

At any point you may enter a question mark '?' for help.
Use ctrl-c to abort configuration dialog at any prompt.
Default settings are in square brackets '[]'.

Basic management setup configures only enough connectivity
for management of the system, extended setup will ask you
to configure each interface on the system.

```
Would you like to enter basic management setup? [yes/no]: yes
```

Step 2 Enter a host name for the switch, and press **Return**.

On a command switch, the host name is limited to 28 characters; on a member switch to 31 characters. Do not use *-n*, where *n* is a number, as the last character in a host name for any switch.

```
Enter host name [Switch]: host_name
```

Step 3 Enter an enable secret password, and press **Return**.

The password can be from 1 to 25 alphanumeric characters, can start with a number, is case sensitive, allows spaces, but ignores leading spaces. The secret password is encrypted and the enable password is in plain text.

```
Enter enable secret: secret_password
```

Step 4 Enter an enable password, and press **Return**.

```
Enter enable password: enable_password
```

Step 5 Enter a virtual terminal (Telnet) password, and press **Return**.

The password can be from 1 to 25 alphanumeric characters, is case sensitive, allows spaces, but ignores leading spaces.

```
Enter virtual terminal password: terminal-password
```

Step 6 (Optional) Configure Simple Network Management Protocol (SNMP) by responding to the prompts. You can also configure SNMP later through the CLI or CMS interface. To configure SNMP later type **no**.

```
Configure SNMP Network Management? [no]: no
```

- Step 7** Enter the interface name (physical interface or VLAN name) of the interface that connects to the management network, and press **Return**. For this release, always use **vlan1** as that interface.

```
Enter interface name used to connect to the
management network from the above interface summary: vlan1
```

- Step 8** Configure the interface by entering the switch IP address and subnet mask and pressing **Return**. The IP address and subnet masks shown below are examples.

```
Configuring interface vlan1:
Configure IP on this interface? [yes]: yes
IP address for this interface: 10.4.120.106
Subnet mask for this interface [255.0.0.0]: 255.0.0.0
```

- Step 9** Enter **Y** to configure the switch as the cluster command switch. Enter **N** to configure it as a member switch or as a standalone switch.

If you enter **N**, the switch appears as a candidate switch in the CMS. You can configure the switch as a command switch later through the CLI or CMS interface. To configure it later type **no**.

```
Would you like to enable as a cluster command switch? [yes/no]: no
```

You have now completed the initial configuration of the switch and the switch displays its initial configuration. This is an example of output that appears:

The following configuration command script was created:

```
hostname switch1
enable secret 5 $1$U1q8$D1A/OiaEb190WcBPd9cOn1
enable password enable_password
line vty 0 15
password terminal-password
no snmp-server
!
no ip routing

!
interface Vlan1
no shutdown
ip address 10.4.120.106 255.0.0.0
!
interface FastEthernet1/0/1
!
interface FastEthernet1/0/2

interface FastEthernet1/0/3
!
```

```
...<output abbreviated>
!  
interface GigabitEthernet2/0/28  
!  
end
```

Step 10 These choices are displayed:

- [0] Go to the IOS command prompt without saving this config.
- [1] Return back to the setup without saving this config.
- [2] Save this configuration to nvram and exit.

If you want to save the configuration and use it the next time the switch reboots, save it in nonvolatile RAM (NVRAM) by selecting option 2.

```
Enter your selection [2]:2
```

Make your selection, and press **Return**.

After you complete the setup program, the switch can run the default configuration that you created. If you want to change this configuration or want to perform other management tasks, use one of these tools:

- Command-line interface (CLI)
- CMS from your browser

To use the CLI, enter commands at the *Switch*> prompt through the console port by using a terminal program or through the network by using telnet. For configuration information, refer to the switch software configuration guide or the switch command reference.



Translated Safety Warnings

This appendix repeats in multiple languages the warnings in this guide. These translated warnings can be used with other documents related to this guide.

Attaching the Cisco RPS (model PWR300-AC-RPS-N1)



Warning

Attach only the Cisco RPS (model PWR300-AC-RPS-N1) to the RPS receptacle.

Waarschuwing

Slechts de Cisco RPS (model PWR300-AC-RPS-N1) aan de RPS contactdoos verbinden.

Varoitus

Kiinnitä RPS-vastakappaleeseen vain Cisco RPS (malli PWR300-AC-RPS-N1).

Avertissement

Raccordez le bloc d'alimentation Cisco RPS (modèle PWR300-AC-RPS-N1) uniquement au connecteur RPS.

Warnung

An die RPS-Steckhülse darf nur das Cisco RPS (Modell PWR300-AC-RPS-N1) angeschlossen werden.

Avvertenza

Collegare soltanto il Cisco RPS (modello PWR300-AC-RPS-N1) alla presa RPS.

■ Attaching the Cisco RPS (model PWR300-AC-RPS-N1)

Advarsel! Koble bare Cisco RPS (modell PWR300-AC-RPS-N1) til RPS-stikkontakten.

Aviso Anexe o RPS Cisco (modelo PWR300-AC-RPS-N1) apenas ao receptáculo RPS.

¡Advertencia! Sólo conecte el Cisco RPS (modelo PWR300-AC-RPS-N1) al receptáculo RPS.

Varning! Koppla endast Ciscos RPS (modell PWR300-AC-RPS-N1) till RPS-uttaget.

Figyelem Az RPS csatlakozóhoz csak Cisco RPS (PWR300-AC-RPS-N1 modell) aljzatot csatlakoztasson.

Предупреждение К гнезду RPS можно подключать только системы питания Cisco RPS (модель PWR300-AC-RPS-N1).

警告 只能将 Cisco RPS (型号 PWR300-AC-RPS-N1) 连接到 RPS 插座。

警告 RPS レセプタクルには、Cisco RPS (モデル番号 PWR300-AC-RPS-N1) だけを接続してください。

Attaching the Cisco RPS (model PWR675-AC-RPS-N1)

**Warning**

Attach only the Cisco RPS (model PWR675-AC-RPS-N1) to the RPS receptacle.

Waarschuwing

Slechts de Cisco RPS (model PWR675-AC-RPS-N1) aan de RPS contactdoos verbinden.

Varoitus

Kiinnitä RPS-vastakappaleeseen vain Cisco RPS (malli PWR675-AC-RPS-N1).

Avertissement

Raccordez le bloc d'alimentation Cisco RPS (modèle PWR675-AC-RPS-N1) uniquement au connecteur RPS.

Warnung

An die RPS-Steckhülse darf nur das Cisco RPS (Modell PWR675-AC-RPS-N1) angeschlossen werden.

Avvertenza

Collegare soltanto il Cisco RPS (modello PWR675-AC-RPS-N1) alla presa RPS.

Advarsel!

Koble bare Cisco RPS (modell PWR675-AC-RPS-N1) til RPS-stikkontaktene.

Aviso

Anexe o RPS Cisco (modelo PWR675-AC-RPS-N1) apenas ao receptáculo RPS.

¡Advertencia!

Sólo conecte el Cisco RPS (modelo PWR675-AC-RPS-N1) al receptáculo RPS.

Varning!

Koppla endast Ciscos RPS (modell PWR675-AC-RPS-N1) till RPS-uttaget.

Figyelem

Az RPS csatlakozóhoz csak Cisco RPS (PWR675-AC-RPS-N1 modell) aljzatot csatlakoztasson.

Предупреждение

К гнезду RPS можно подключать только системы питания Cisco RPS (модель PWR675-AC-RPS-N1=).

警告 只能将 Cisco RPS (型号 PWR675-AC-RPS-N1=) 连接到 RPS 插座。

警告 RPS レセプタクルには、Cisco RPS (モデル番号 PWR675-AC-RPS-N1=) だけを接続してください。

Shock Hazard From Interconnections



Warning

Voltages that present a shock hazard may exist on Power over Ethernet (PoE) circuits if interconnections are made using uninsulated exposed metal contacts, conductors, or terminals. Avoid using such interconnection methods, unless the exposed metal parts are located within a restricted access location and users and service people who are authorized within the restricted access location are made aware of the hazard. A restricted access area can be accessed only through the use of a special tool, lock and key or other means of security.

Waarschuwing

Voltages kunnen elektrische schokken veroorzaken in PoE (Power over Ethernet)-circuits als er verbindingen worden gemaakt met blootliggende metalen contactpunten, geleiders of aansluitingspunten die niet zijn geïsoleerd. Gebruik dit type verbinding niet tenzij de blootliggende metalen onderdelen zich bevinden op een locatie met beperkte toegang en de gebruikers en onderhoudstechnici die toegang tot deze locatie hebben, op het gevaar worden gewezen. De locatie met beperkte toegang kan alleen worden geopend met speciaal gereedschap, slot en sleutel of een andere beveiligingsmethode.

Varoitus

Sisäisissä Ethernet (PoE) -virtapiireissä voi olla sähköiskun vaaran aiheuttavia jännitteitä, jos kytkentöihin käytetään eristämättömiä paljaita metalliliittimiä tai -johtimia. Vältä tällaisia kytkentöjä, elleivät paljaat metalliosat ole rajatussa paikassa. Ilmoita valtuutetuille käyttäjille ja huoltohenkilöille vaarasta. Rajattuun alueeseen pääsee käsiksi ainoastaan erityistyökäluä, lukkoa ja avainta tai muuta turvallista menetelmää käyttämällä.

- Attention** Les tensions existant sur les alimentations utilisant la technologie PoE (Power over Ethernet) peuvent constituer un risque d'électrocution si les interconnexions sont effectuées en utilisant des terminaux, conducteurs ou contacts métalliques exposés non isolés. Évitez d'utiliser de telles méthodes d'interconnexion à moins que les pièces métalliques exposées ne se trouvent dans un emplacement d'accès restreint et que les utilisateurs et les responsables du service autorisés dans cet emplacement d'accès restreint ne soient conscients du danger. Une zone d'accès restreint peut être accédée uniquement à l'aide d'une clé, d'un outil et d'un verrou spécial, ou d'autres moyens de sécurité.
- Warnung** Bei Power-over-Ethernet-(PoE-)Schaltkreisen besteht u.U. Stromschlaggefahr, wenn Verbindungen unter Verwendung nicht isolierter, freiliegender Metallkontakte, Leiter oder Anschlussklemmen hergestellt werden. Vermeiden Sie das Herstellen solcher Verbindungen, es sei denn, die freiliegenden Metallteile befinden sich an Orten mit beschränktem Zugang, und Personen, die Zugang dazu haben, sind ausdrücklich über diese Gefahr informiert worden. Ein Ort mit beschränktem Zugang ist nur mit Hilfe eines speziellen Werkzeugs, Schloss und Schlüssels oder anderen Sicherheitseinrichtungen zugänglich.
- Avvertenza** Nei circuiti con alimentazione via Ethernet (PoE) possono verificarsi pericoli di scosse elettriche se si creano connessioni con contatti metallici, conduttori o terminali scoperti. Evitare di utilizzare i metodi di connessione sopraelencati a meno che le parti metalliche esposte non si trovino in una zona riservata e gli utenti e il personale di assistenza, che sono autorizzati ad accedere nella suddetta zona, siano stati messi al corrente del pericolo. È possibile accedere alla zona riservata solamente utilizzando gli appositi elementi di sicurezza.
- Advarsel** I strømkretser med PoE (Power over Ethernet) kan det være spenninger som kan utgjøre støffare hvis det blir foretatt sammenkoblinger med uisolerte, eksponerte kontakter, ledere eller terminaler av metall. Unngå å bruke slike sammenkoblingsmetoder med mindre de eksponerte metalldelene er i et område med begrenset tilgang, og brukere og servicepersonell som har tilgang til det begrensede området, blir gjort oppmerksom på faren. Et område med begrenset tilgang kan bare åpnes ved hjelp av spesialverktøy, nøkkel eller andre sikkerhetstiltak.

- Aviso** **Pode haver voltagens que representam perigo de choque em circuitos PoE (Power over Ethernet) se as interconexões forem feitas utilizando-se terminais, condutores ou contatos de metal exposto e sem isolamento. Evite utilizar tais métodos de interconexão a não ser que as partes de metal expostas estejam em um local de acesso restrito e os usuários e o pessoal de serviço com acesso autorizado a este local restrito estejam cientes do perigo. Uma área de acesso restrito só pode ser acessada com o uso de uma ferramenta, fechadura e chave especial ou de outros meios de segurança.**
- ¡Advertencia!** **Puede haber voltajes con riesgo de shock en circuitos de alimentación sobre el cableado Ethernet (PoE), si para las interconexiones se utilizan contactos, conductores o terminales metálicos descubiertos. Evite tales métodos de interconexión, a menos que las partes metálicas descubiertas se encuentren en un lugar de acceso restringido y tanto los usuarios como el personal de servicios en dicho lugar sean conscientes de la existencia de tal riesgo. Sólo se puede tener acceso a una zona de acceso restringido mediante el uso de una herramienta especial, un candado y una llave u otros medios de seguridad.**
- Varning!** **Det kan finnas spänningar på PoE-kretsarna (Power over Ethernet) som utgör risk för stötar om sammankopplingarna görs med ej isolerade, exponerade kontakter, ledare och/eller terminaler av metall. Undvik att använda sådana sammankopplingsmetoder, såvida inte de exponerade metalldelarna finns i en plats med begränsad åtkomst. Användare och servicepersonal som tillåts inom platsen med begränsad åtkomst måste vara medvetna om risken. Ett begränsat område kan bara nås med ett speciellt verktyg eller lås, en speciell nyckel eller någon annan säkerhetsmetod.**
- Figyelem** **Áramütést okozó feszültség keletkezhet a feszültség alatt lévő Ethernet (Power over Ethernet, PoE) áramkörökben, amennyiben összeköttetés jön létre a szigetetlen fém érintkezők, vezetékek vagy csatlakozók között. Ne alkalmazzon ilyen összeköttetéseket, kivéve, ha az érintésnek kitétt fém alkatrészek korlátozottan hozzáférhető területen található, és a terület elérésére felhatalmazott felhasználók és szervizszakemberek tudatában vannak az áramütés veszélyének. A korlátozottan hozzáférhető területekhez csak speciális szerszám, zár és kulcs, vagy más biztonsági berendezés segítségével lehet hozzáférni.**

- Предупреждение** При выполнении соединений с использованием неизолированных металлических контактов, проводников или разъемов в электроцепях Power over Ethernet (PoE) могут возникать напряжения, представляющие опасность поражения электрическим током. Старайтесь не использовать такие способы соединений, если только неизолированные металлические части не находятся в местах, доступ к которым разрешен для ограниченного круга лиц, а пользователи и специалисты по обслуживанию, уполномоченные выполнять работы в таких местах, предупреждены о наличии такой опасности. При работе в местах, доступ к которым разрешен для ограниченного круга лиц, следует использовать только специальные инструменты, закрывать их на ключ или предпринимать другие меры безопасности.
- 警告** 如果使用不绝缘、暴露的金属接头、导体或终端进行互联、在以太网供电 (PoE) 电路中就会产生导致电击危险的电压。只有暴露的金属部件处于限制进入的位置、并且被授权进入此位置的用户和服务人员意识到此危险、才能使用这样的互联方式。要进入受限区域、仅能使用特殊的工具、锁和密钥或其他安全方法。
- 警告** 絶縁処理が施されていない金属製の部品、コンダクタ、またはターミナルを使用して内部接続されている場合、感電を引き起こす電圧が Power over Ethernet (PoE) 回路に存在する可能性があります。絶縁処理が施されていない金属製の部品がアクセス制限区域にのみ存在する場合や、アクセス制限区域への立ち入りが必要と認められているユーザおよびサービス担当者が感電の可能性について熟知している場合を除き、そのような内部接続の方法は避けてください。アクセス制限区域には、特殊な工具、施錠などのセキュリティ手段を使用しなければアクセスできません。

Installation Warning


Warning

Only trained and qualified personnel should be allowed to install, replace, or service this equipment.

Waarschuwing

Deze apparatuur mag alleen worden geïnstalleerd, vervangen of hersteld door bevoegd geschoold personeel.

Varoitus

Tämän laitteen saa asentaa, vaihtaa tai huoltaa ainoastaan koulutettu ja laitteen tunteva henkilökunta.

Attention

Il est vivement recommandé de confier l'installation, le remplacement et la maintenance de ces équipements à des personnels qualifiés et expérimentés.

Warnung

Das Installieren, Ersetzen oder Bedienen dieser Ausrüstung sollte nur geschultem, qualifiziertem Personal gestattet werden.

Avvertenza

Questo apparato può essere installato, sostituito o mantenuto unicamente da un personale competente.

Advarsel

Bare opplært og kvalifisert personell skal foreta installasjoner, utskiftninger eller service på dette utstyret.

Aviso

Apenas pessoal treinado e qualificado deve ser autorizado a instalar, substituir ou fazer a revisão deste equipamento.

¡Advertencia!

Solamente el personal calificado debe instalar, reemplazar o utilizar este equipo.

Varning!

Endast utbildad och kvalificerad personal bör få tillåtelse att installera, byta ut eller reparera denna utrustning.

Installation Instructions



Warning

Read the installation instructions before connecting the system to the power source.

Waarschuwing

Raadpleeg de installatie-instructies voordat u het systeem op de voedingsbron aansluit.

Varoitus

Lue asennusohjeet ennen järjestelmän yhdistämistä virtalähteeseen.

Attention

Avant de brancher le système sur la source d'alimentation, consulter les directives d'installation.

Warnung

Vor dem Anschließen des Systems an die Stromquelle die Installationsanweisungen lesen.

Avvertenza

Consultare le istruzioni di installazione prima di collegare il sistema all'alimentatore.

Advarsel

Les installasjonsinstruksjonene før systemet kobles til strømkilden.

Aviso

Leia as instruções de instalação antes de ligar o sistema à fonte de energia.

¡Advertencia!

Lea las instrucciones de instalación antes de conectar el sistema a la red de alimentación.

Varning!

Läs installationsanvisningarna innan du kopplar systemet till strömförsörjningsenheten.

Figyelem

Mielőtt áramforráshoz csatlakoztatná a rendszert, olvassa el az üzembe helyezési útmutatót!

Предупреждение

Перед подключением устройства к источнику электропитания ознакомьтесь с данной инструкцией по установке.

Jewelry Removal Warning

警告 在将系统与电源连接之前，请仔细阅读安装说明。

警告 必ず設置手順を読んでから、システムを電源に接続してください。

Jewelry Removal Warning



Warning

Before working on equipment that is connected to power lines, remove jewelry (including rings, necklaces, and watches). Metal objects will heat up when connected to power and ground and can cause serious burns or weld the metal object to the terminals.

Waarschuwing

Alvorens aan apparatuur te werken die met elektrische leidingen is verbonden, sieraden (inclusief ringen, kettingen en horloges) verwijderen. Metalen voorwerpen worden warm wanneer ze met stroom en aarde zijn verbonden, en kunnen ernstige brandwonden veroorzaken of het metalen voorwerp aan de aansluitklemmen lassen.

Varoitus

Ennen kuin työskentelet voimavirtajohtoihin kytkettyjen laitteiden parissa, ota pois kaikki korut (sormukset, kaulakorut ja kellot mukaan lukien). Metalliesineet kuumenevat, kun ne ovat yhteydessä sähkövirran ja maan kanssa, ja ne voivat aiheuttaa vakavia palovammoja tai hitsata metalliesineet kiinni liitännänapoihin.

Attention

Avant d'accéder à cet équipement connecté aux lignes électriques, ôter tout bijou (anneaux, colliers et montres compris). Lorsqu'ils sont branchés à l'alimentation et reliés à la terre, les objets métalliques chauffent, ce qui peut provoquer des blessures graves ou souder l'objet métallique aux bornes.

Warnung	Vor der Arbeit an Geräten, die an das Netz angeschlossen sind, jeglichen Schmuck (einschließlich Ringe, Ketten und Uhren) abnehmen. Metallgegenstände erhitzen sich, wenn sie an das Netz und die Erde angeschlossen werden, und können schwere Verbrennungen verursachen oder an die Anschlußklemmen angeschweißt werden.
Avvertenza	Prima di intervenire su apparecchiature collegate alle linee di alimentazione, togliersi qualsiasi monile (inclusi anelli, collane, braccialetti ed orologi). Gli oggetti metallici si riscaldano quando sono collegati tra punti di alimentazione e massa: possono causare ustioni gravi oppure il metallo può saldarsi ai terminali.
Advarsel	Fjern alle smykker (inkludert ringer, halskjeder og klokker) før du skal arbeide på utstyr som er koblet til kraftledninger. Metallgjenstander som er koblet til kraftledninger og jord blir svært varme og kan forårsake alvorlige brannskader eller smelte fast til polene.
Aviso	Antes de trabalhar em equipamento que esteja ligado a linhas de corrente, retire todas as jóias que estiver a usar (incluindo anéis, fios e relógios). Os objectos metálicos aquecerão em contacto com a corrente e em contacto com a ligação à terra, podendo causar queimaduras graves ou ficarem soldados aos terminais.
¡Advertencia!	Antes de operar sobre equipos conectados a líneas de alimentación, quitarse las joyas (incluidos anillos, collares y relojes). Los objetos de metal se calientan cuando se conectan a la alimentación y a tierra, lo que puede ocasionar quemaduras graves o que los objetos metálicos queden soldados a los bornes.
Varning!	Tag av alla smycken (inklusive ringar, halsband och armbandsur) innan du arbetar på utrustning som är kopplad till kraftledningar. Metallobjekt hettas upp när de kopplas ihop med ström och jord och kan förorsaka allvarliga brännskador; metallobjekt kan också sammansvetsas med kontakterna.
Figyelem	Mielőtt hálózati feszültséghez csatlakozó készülékkel kezd el dolgozni, vegye le magáról az ékszereket (például gyűrűt, nyakláncot, órát). A fém tárgyak felmelegszenek, ha hálózati feszültséghez és földhöz érnek, és súlyos égési sérülést okozhatnak, illetve a fém tárgyak hozzáforrhathatnak a csatlakozókhoz.

Stacking the Chassis Warning

Предупреждение	Прежде чем использовать оборудование, подключенное к электросети, снимите все украшения (включая кольца, ожерелья и часы). Металлические части нагреваются при соединении с источником питания и землей, что может привести к серьезным ожогам или привариванию металлических объектов к клеммам.
警告	在操作与电源线连接的设备以前，请取下首饰（包括戒指、项链和手表）。连接电源和接地后，金属物品会升温，可能导致严重灼伤，也可能使金属物品熔接在线端。
警告	電源に接続されている装置を取り扱う際は、事前に、指輪、ネックレス、腕時計などの装身具をはずしてください。金属のオブジェクトが電源とアースと接触すると、金属が過熱して大やけどをしたり、また金属類が端子に焼き付くことがあります。

Stacking the Chassis Warning



Warning

Do not stack the chassis on any other equipment. If the chassis falls, it can cause severe bodily injury and equipment damage.

Waarschuwing

Het chassis mag niet op andere apparatuur gestapeld te worden. Als het chassis mocht vallen, kan dit ernstig lichamelijk letsel en beschadiging van de apparatuur veroorzaken.

Varoitus

Älä aseta asennuspohjaa minkään muun laitteen päälle. Asennuspohja voi pudotessaan aiheuttaa vaikean ruumiinvamman tai laitevaurion.

Avertissement

Ne placez pas ce châssis sur un autre appareil. En cas de chute, il pourrait provoquer de graves blessures corporelles et d'importants dommages.

Achtung

Das Gehäuse nicht auf andere Geräte stellen. Wenn das Gehäuse herunterfällt, besteht Gefahr schwerer Personenverletzungen und Geräteschäden.

Avvertenza	Non collocare lo chassis su nessun altro apparecchio. Se lo chassis cade, può causare lesioni gravi e danni alle apparecchiature.
Advarsel	Stable ikke kabinettet oppå annet utstyr. Hvis kabinettet faller, kan det forårsake alvorlig skade på mennesker og utstyr.
Aviso	Não coloque o chassis em cima de qualquer outro equipamento. Se o chassis cair, poderá causar ferimentos graves e danos no equipamento.
¡Atención!	No apilar los chasis sobre ningún otro equipo. Si el chasis se cae al suelo puede causar graves lesiones físicas y daños al equipo.
Varning	Placera inte chassit ovanpå annan utrustning. Om chassit faller kan allvarlig kroppsskada såväl som skada på utrustningen uppstå.
Figyelem	A készüléket ne tegye rá másik készülékre. Ha a készülék leesik, súlyos testi sérülést okozhat, és maga a készülék is megkárosodhat.
Предупреждение	Не устанавливайте данное устройство на любое другое оборудование. Если устройство упадет, то это может привести к тяжелым травмам и повреждению оборудования.
警告	不要将底盘堆放在其它任何设备上。如果底盘倒下，可能使身体受伤并损坏设备。
警告	別のいかなる装置の上にもシャーシを載せないでください。シャーシを落とすと、大けがをしたり装置を損傷させたりする場合があります。

Main Disconnecting Device



Warning

The plug-socket combination must be accessible at all times, because it serves as the main disconnecting device.

Waarschuwing

De combinatie van de stekker en het elektrisch contactpunt moet te allen tijde toegankelijk zijn omdat deze het hoofdmecanisme vormt voor verbreking van de aansluiting.

Varoitus

Pistoke/liitinkohta toimii pääkatkaisumekanismina. Pääsy siihen on pidettävä aina esteettömänä.

Attention

La combinaison de prise de courant doit être accessible à tout moment parce qu'elle fait office de système principal de déconnexion.

Warnung

Der Netzkabelanschluß am Gerät muß jederzeit zugänglich sein, weil er als primäre Ausschaltvorrichtung dient.

Avvertenza

Il gruppo spina-presa deve essere sempre accessibile, poiché viene utilizzato come dispositivo di scollegamento principale.

Advarsel

Kombinasjonen støpsel/uttak må alltid være tilgjengelig ettersom den fungerer som hovedfrakoplingsenhet.

Aviso

A combinação ficha-tomada deverá ser sempre acessível, porque funciona como interruptor principal.

¡Advertencia!

El conjunto de clavija y toma ha de encontrarse siempre accesible ya que hace las veces de dispositivo de desconexión principal.

Varning!

Man måste alltid kunna komma åt stickproppen i uttaget, eftersom denna koppling utgör den huvudsakliga frånkopplingsanordningen.

Figyelem

A dugaszolóaljzat és a dugasz együttesének mindig hozzáférhetőnek kell lennie, mivel ez szolgál főmegszakítóként.

Предупреждение	Штепсельная розетка всегда должна быть доступна, поскольку она служит основным устройством отключения.
警告	插销和插座必须便于随时插拔，因为它是主要断电设备。
警告	主要な切断装置となるので、プラグとソケットは常に手が届く場所に置く必要があります。

Grounded Equipment Warning



Warning

This equipment is intended to be grounded. Ensure that the host is connected to earth ground during normal use.

Waarschuwing

Deze apparatuur hoort geaard te worden. Zorg dat de host-computer tijdens normaal gebruik met aarde is verbonden.

Varoitus

Tämä laitteisto on tarkoitettu maadoitettavaksi. Varmista, että isäntälaitte on yhdistetty maahan normaalikäytön aikana.

Attention

Cet équipement doit être relié à la terre. S'assurer que l'appareil hôte est relié à la terre lors de l'utilisation normale.

Warnung

Dieses Gerät muß geerdet werden. Stellen Sie sicher, daß das Host-Gerät während des normalen Betriebs an Erde gelegt ist.

Avvertenza

Questa apparecchiatura deve essere collegata a massa. Accertarsi che il dispositivo host sia collegato alla massa di terra durante il normale utilizzo.

Advarsel

Dette utstyret skal jordes. Forviss deg om vertsterminalen er jordet ved normalt bruk.

■ Installing or Replacing the Unit

Aviso	Este equipamento deverá estar ligado à terra. Certifique-se que o host se encontra ligado à terra durante a sua utilização normal.
¡Advertencia!	Este equipo debe conectarse a tierra. Asegurarse de que el equipo principal esté conectado a tierra durante el uso normal.
Varning!	Denna utrustning är avsedd att jordas. Se till att värdenheten är jordad vid normal användning.
Figyelem	A készüléket védőföldeléssel kell ellátni. Győződjön meg róla, hogy a készülék normál használat során csatlakozik a földhöz.
Предупреждение	Данное устройство должно быть заземлено. Убедитесь, что при обычной работе устройство заземлено.
警告	此设备应该接地。请确保主机在正常使用期间连接接地。
警告	この装置はアースに接続するものです。通常の使用では、ホストがアース端子に接続されていることを確認してください。

Installing or Replacing the Unit



Warning

When installing or replacing the unit, the ground connection must always be made first and disconnected last.

Waarschuwing

Bij installatie of vervanging van het toestel moet de aardverbinding altijd het eerste worden gemaakt en het laatste worden losgemaakt.

Varoitus

Laitetta asennettaessa tai korvattaessa on maahan yhdistäminen aina tehtävä ensiksi ja maadoituksen irti kytkeminen viimeiseksi.

Attention	Lors de l'installation ou du remplacement de l'appareil, la mise à la terre doit toujours être connectée en premier et déconnectée en dernier.
Warnung	Der Erdanschluß muß bei der Installation oder beim Austauschen der Einheit immer zuerst hergestellt und zuletzt abgetrennt werden.
Avvertenza	In fase di installazione o sostituzione dell'unità, eseguire sempre per primo il collegamento a massa e disconnetterlo per ultimo.
Advarsel	Når enheten installeres eller byttes, må jordledningen alltid tilkobles først og frakobles sist.
Aviso	Ao instalar ou substituir a unidade, a ligação à terra deverá ser sempre a primeira a ser ligada, e a última a ser desligada.
¡Advertencia!	Al instalar o sustituir el equipo, conecte siempre la toma de tierra al principio y desconéctela al final.
Varning!	Vid installation eller utbyte av enheten måste jordledningen alltid anslutas först och kopplas bort sist.
Figyelem	A készülék üzembe helyezése és cserélése közben mindig a földelés vezetéket kell elsőként csatlakoztatni és azt kell utolsóként leválasztani.
Предупреждение	При установке или замене устройства контакт заземления должен подключаться первым, а отключаться последним.
警告	安装或更换该部件时，必须首先进行接地连接，而接地连接的断开应在最后进行。
警告	装置を設置または交換するときは、必ずアースを最初に接続し、最後に切断します。

Overtemperature Warning



Warning

To prevent the switch from overheating, do not operate it in an area that exceeds the maximum recommended ambient temperature of 113°F (45°C). To prevent airflow restriction, allow at least 3 inches (7.6 cm) of clearance around the ventilation openings.

Waarschuwing

Om oververhitting van de schakelaar te voorkomen, mag u die niet bedienen in een ruimte die de maximale aanbevolen omgevingstemperatuur van 113°F (45°C) overschrijdt. Om beperking van de luchtstroom te voorkomen, dient u ten minste 3 inch (7,6 cm) speling te laten rondom de ventilatie-openingen.

Varoitus

Estääksesi kytkimen ylikuumentumisen älä käytä sitä sellaisissa paikoissa, joiden lämpötila ylittää ympäristön enimmäislämpötilaksi suositellun 45°C. Jätä vähintään 7,6 cm:n vapaa tila tuuletusaukkojen ympärille, jotta ilma pääsee vapaasti virtaamaan.

Attention

Pour éviter une surchauffe du commutateur, ne pas le faire fonctionner dans un local dont la température ambiante dépasse le maximum recommandé de 45°C (113°F). Pour faciliter la circulation d'air, aménager un dégagement d'au moins 7,6 cm (3 pouces) autour des bouches d'aération.

Warnung

Um eine Überhitzung des Schalters zu vermeiden, ist das System nicht in einem Bereich zu betreiben, in dem die empfohlene Höchsttemperatur von 45°C überschritten wird. Damit der Luftfluß nicht behindert wird, ist ein Freiraum von mindestens 7,6 cm um die Belüftungsöffnungen herum einzuhalten.

Avvertenza

Per evitare il surriscaldamento dell'interruttore, non usare l'apparecchiatura in un'area che supera la temperatura ambientale minima consigliata di 45°C. Per evitare una limitazione del flusso dell'aria, lasciare come minimo uno spazio libero di 7,6 cm intorno alle aperture di ventilazione.

Advarsel	For å unngå at bryteren overopphetes skal utstyret ikke brukes på steder hvor anbefalt maks omgivelsestemperatur overstiger 113 grader Farenheit (45°C). La det være minst 3 tommer (7,6 cm) klaring rundt ventilasjonsåpningene for at luftsirkulasjonen skal være uhindret.
Aviso	Para evitar sobreaquecimento do interruptor, não utilize o equipamento numa área que exceda uma temperatura máxima de 45°C. Para evitar o bloqueamento da circulação de ar, deixe pelo menos um espaço de 7.6 cm em volta das aberturas de ventilação.
¡Advertencia!	Para evitar que el interruptor se recaliente, no se debe usar en áreas cuya temperatura ambiente exceda la máxima recomendada, esto es, 45°C (113°F). Para no entorpecer la corriente de aire, dejar por lo menos 7,6 cm (3 pulgadas) de espacio muerto alrededor de la rejilla de ventilación.
Varning!	I syfte att undvika överhettning av switchen skall den inte användas i utrymmen vars temperatur överskrider den maximalt rekommenderade omgivningstemperaturen som är 45°C. Kontrollera att det finns minst 7,6 cm fritt utrymme runt ventilationsöppningarna så att luftflödet inte begränsas.
Figyelem	A túlmelegedés megelőzése végett ne üzemeltesse a kapcsolót olyan területen, ahol a hőmérséklet meghaladja a 45°C maximális ajánlott környezeti hőmérsékletet. A megfelelő légáramlás biztosítása érdekében a szellőzőnyílások körül hagyjon szabadon legalább 7,6 cm helyet.
Предупреждение	Во избежание перегрева переключателя его не следует использовать в помещениях, в которых температура воздуха выше максимальной рекомендованной: 113°F (45°C). Во избежание ограничения воздушного потока около вентиляционных отверстий должно быть не менее 3 дюймов (7,6 см) свободного пространства.

Working During Lightning Activity

警告 为了防止开关过热，不要在超过所建议的最大环境温度华氏 113 度（摄氏 45 度）下运行该系统。为了防止空气流量受限，要在通风口周围至少留出 3 英寸（7.6 厘米）的空间。

警告 スイッチの加熱を防ぐため、推奨されている最高周囲温度、摂氏 45 度（華氏 113 度）を超える場所で作業をしないでください。気流の停滞を防ぐため、換気孔から 7.6cm（3 インチ）以上の間隔をとってください。

Working During Lightning Activity



Warning

Do not work on the system or connect or disconnect cables during periods of lightning activity.

Waarschuwing

Tijdens onweer dat gepaard gaat met bliksem, dient u niet aan het systeem te werken of kabels aan te sluiten of te ontkoppelen.

Varoitus

Älä työskentele järjestelmän parissa äläkä yhdistä tai irrota kaapeleita ukkosilmalla.

Attention

Ne pas travailler sur le système ni brancher ou débrancher les câbles pendant un orage.

Warnung

Arbeiten Sie nicht am System und schließen Sie keine Kabel an bzw. trennen Sie keine ab, wenn es gewittert.

Avvertenza

Non lavorare sul sistema o collegare oppure scollegare i cavi durante un temporale con fulmini.

Advarsel

Utfør aldri arbeid på systemet, eller koble kabler til eller fra systemet når det tordner eller lynr.

Aviso	Não trabalhe no sistema ou ligue e desligue cabos durante períodos de mau tempo (trovoada).
¡Advertencia!	No operar el sistema ni conectar o desconectar cables durante el transcurso de descargas eléctricas en la atmósfera.
Varning!	Vid åska skall du aldrig utföra arbete på systemet eller ansluta eller koppla loss kablar.
Figyelem	Villámlás közben ne dolgozzon a rendszeren, valamint ne csatlakoztasson és ne húzzon ki kábeleket!
Предупреждение	Не следует работать с устройством, а также подключать или отключать кабели во время грозы.
警告	请勿在发生雷电时操作系统，也不要在此期间连接或断开电缆。
警告	雷が発生しているときは、システムに手を加えたり、ケーブルの接続や取り外しを行わないでください。

Product Disposal Warning



Warning

Ultimate disposal of this product should be handled according to all national laws and regulations.

Waarschuwing

Het uiteindelijke wegruimen van dit product dient te geschieden in overeenstemming met alle nationale wetten en reglementen.

Varoitus

Tämä tuote on hävitettävä kansallisten lakien ja määräysten mukaisesti.

■ Product Disposal Warning

Attention	La mise au rebut ou le recyclage de ce produit sont généralement soumis à des lois et/ou directives de respect de l'environnement. Renseignez-vous auprès de l'organisme compétent.
Warnung	Die Entsorgung dieses Produkts sollte gemäß allen Bestimmungen und Gesetzen des Landes erfolgen.
Avvertenza	Lo smaltimento di questo prodotto deve essere eseguito secondo le leggi e regolazioni locali.
Advarsel	Endelig kassering av dette produktet skal være i henhold til alle relevante nasjonale lover og bestemmelser.
Aviso	Deitar fora este produto em conformidade com todas as leis e regulamentos nacionais.
¡Advertencia!	Al deshacerse por completo de este producto debe seguir todas las leyes y reglamentos nacionales.
Varning!	Vid deponering hanteras produkten enligt gällande lagar och bestämmelser.
Figyelem	A készülék végső elhelyezéséről az adott országban érvényes törvények és előírások szerint kell intézkedni.
Предупреждение	Окончательная установка данного изделия должна выполняться в соответствии со всеми региональными и местными правилами и нормами.
警告	本产品的废弃处理应根据所有国家的法律和规章进行。
警告	この製品を廃棄するときは、各国の法律および規制に従って処理してください。

Chassis Warning for Rack-Mounting and Servicing



Warning

To prevent bodily injury when mounting or servicing this unit in a rack, you must take special precautions to ensure that the system remains stable. The following guidelines are provided to ensure your safety:

- This unit should be mounted at the bottom of the rack if it is the only unit in the rack.
- When mounting this unit in a partially filled rack, load the rack from the bottom to the top with the heaviest component at the bottom of the rack.
- If the rack is provided with stabilizing devices, install the stabilizers before mounting or servicing the unit in the rack.

Waarschuwing

Om lichamelijk letsel te voorkomen wanneer u dit toestel in een rek monteert of het daar een servicebeurt geeft, moet u speciale voorzorgsmaatregelen nemen om ervoor te zorgen dat het toestel stabiel blijft. De onderstaande richtlijnen worden verstrekt om uw veiligheid te verzekeren:

- Dit toestel dient onderaan in het rek gemonteerd te worden als het toestel het enige in het rek is.
- Wanneer u dit toestel in een gedeeltelijk gevuld rek monteert, dient u het rek van onderen naar boven te laden met het zwaarste onderdeel onderaan in het rek.
- Als het rek voorzien is van stabiliseringshulpmiddelen, dient u de stabilisatoren te monteren voordat u het toestel in het rek monteert of het daar een servicebeurt geeft.

Varoitus

Kun laite asetetaan telineeseen tai huolletaan sen ollessa telineessä, on noudatettava erityisiä varotoimia järjestelmän vakavuuden säilyttämiseksi, jotta vältetään loukkaantumiselta. Noudata seuraavia turvallisuusohjeita:

- Jos telineessä ei ole muita laitteita, aseta laite telineen alaosaan.
- Jos laite asetetaan osaksi täytettyyn telineeseen, aloita kuormittaminen sen alaosaan kaikkein raskaimmalla esineellä ja siirry sitten sen yläosaan.
- Jos telinettä varten on vakaimet, asenna ne ennen laitteen asettamista telineeseen tai sen huoltamista siinä.

- Attention** Pour éviter toute blessure corporelle pendant les opérations de montage ou de réparation de cette unité en casier, il convient de prendre des précautions spéciales afin de maintenir la stabilité du système. Les directives ci-dessous sont destinées à assurer la protection du personnel:
- Si cette unité constitue la seule unité montée en casier, elle doit être placée dans le bas.
 - Si cette unité est montée dans un casier partiellement rempli, charger le casier de bas en haut en plaçant l'élément le plus lourd dans le bas.
 - Si le casier est équipé de dispositifs stabilisateurs, installer les stabilisateurs avant de monter ou de réparer l'unité en casier.
- Warnung** Zur Vermeidung von Körperverletzung beim Anbringen oder Warten dieser Einheit in einem Gestell müssen Sie besondere Vorkehrungen treffen, um sicherzustellen, daß das System stabil bleibt. Die folgenden Richtlinien sollen zur Gewährleistung Ihrer Sicherheit dienen:
- Wenn diese Einheit die einzige im Gestell ist, sollte sie unten im Gestell angebracht werden.
 - Bei Anbringung dieser Einheit in einem zum Teil gefüllten Gestell ist das Gestell von unten nach oben zu laden, wobei das schwerste Bauteil unten im Gestell anzubringen ist.
 - Wird das Gestell mit Stabilisierungszubehör geliefert, sind zuerst die Stabilisatoren zu installieren, bevor Sie die Einheit im Gestell anbringen oder sie warten.
- Avvertenza** Per evitare infortuni fisici durante il montaggio o la manutenzione di questa unità in un supporto, occorre osservare speciali precauzioni per garantire che il sistema rimanga stabile. Le seguenti direttive vengono fornite per garantire la sicurezza personale:
- Questa unità deve venire montata sul fondo del supporto, se si tratta dell'unica unità da montare nel supporto.
 - Quando questa unità viene montata in un supporto parzialmente pieno, caricare il supporto dal basso all'alto, con il componente più pesante sistemato sul fondo del supporto.
 - Se il supporto è dotato di dispositivi stabilizzanti, installare tali dispositivi prima di montare o di procedere alla manutenzione dell'unità nel supporto.

- Advarsel** **Unngå fysiske skader under montering eller reparasjonsarbeid på denne enheten når den befinner seg i et kabinett. Vær nøye med at systemet er stabilt. Følgende retningslinjer er gitt for å verne om sikkerheten:**
- Denne enheten bør monteres nederst i kabinettet hvis dette er den eneste enheten i kabinettet.
 - Ved montering av denne enheten i et kabinett som er delvis fylt, skal kabinettet lastes fra bunnen og opp med den tyngste komponenten nederst i kabinettet.
 - Hvis kabinettet er utstyrt med stabiliseringsutstyr, skal stabilisatorene installeres før montering eller utføring av reparasjonsarbeid på enheten i kabinettet.
- Aviso** **Para se prevenir contra danos corporais ao montar ou reparar esta unidade numa estante, deverá tomar precauções especiais para se certificar de que o sistema possui um suporte estável. As seguintes directrizes ajudá-lo-ão a efectuar o seu trabalho com segurança:**
- Esta unidade deverá ser montada na parte inferior da estante, caso seja esta a única unidade a ser montada.
 - Ao montar esta unidade numa estante parcialmente ocupada, coloque os itens mais pesados na parte inferior da estante, arrumando-os de baixo para cima.
 - Se a estante possuir um dispositivo de estabilização, instale-o antes de montar ou reparar a unidade.
- ¡Advertencia!** **Para evitar lesiones durante el montaje de este equipo sobre un bastidor, o posteriormente durante su mantenimiento, se debe poner mucho cuidado en que el sistema quede bien estable. Para garantizar su seguridad, proceda según las siguientes instrucciones:**
- Colocar el equipo en la parte inferior del bastidor, cuando sea la única unidad en el mismo.
 - Cuando este equipo se vaya a instalar en un bastidor parcialmente ocupado, comenzar la instalación desde la parte inferior hacia la superior colocando el equipo más pesado en la parte inferior.
 - Si el bastidor dispone de dispositivos estabilizadores, instalar éstos antes de montar o proceder al mantenimiento del equipo instalado en el bastidor.

Varning! För att undvika kroppsskada när du installerar eller utför underhållsarbete på denna enhet på en ställning måste du vidta särskilda försiktighetsåtgärder för att försäkra dig om att systemet står stadigt. Följande riktlinjer ges för att trygga din säkerhet:

- Om denna enhet är den enda enheten på ställningen skall den installeras längst ned på ställningen.
- Om denna enhet installeras på en delvis fylld ställning skall ställningen fyllas nedifrån och upp, med de tyngsta enheterna längst ned på ställningen.
- Om ställningen är försedd med stabiliseringsdon skall dessa monteras fast innan enheten installeras eller underhålls på ställningen.

Figyelem A készülék rackbe történő beszerelése és karbantartása során bekövetkező sérülések elkerülése végett speciális óvintézkedésekkel meg kell őrizni a rendszer stabilitását. A személyes biztonsága érdekében tartsa be a következő szabályokat:

- Ha a rackben csak ez az egy készülék található, a rack aljába kell beszerelni.
- Ha nincs teljesen tele az a rack, amelybe beszerelik a készüléket, alulról fölfelé haladva töltsse fel a racket úgy, hogy a legnehezebb készülék kerüljön a rack aljába.
- Ha stabilizáló eszközök is tartoznak a rackhez, szerelje fel a stabilizátorokat, mielőtt beszerelné az egységet a rackbe, vagy karbantartást végezne rajta.

Предупреждение Во избежание травм при монтаже и обслуживании устройства в стойке следует принять особые меры предосторожности, чтобы убедиться в устойчивости оборудования. Для обеспечения безопасности работ необходимо соблюдать следующие правила.

- Если в стойке находится одно устройство, оно должно быть установлено в нижней части.
- При монтаже устройств в частично заполненную стойку устанавливайте оборудование снизу вверх, размещая наиболее тяжелые устройства в нижней части.
- Если стойка снабжена приспособлениями для стабилизации, их необходимо установить до начала монтажа или обслуживания оборудования.

警告 为避免在机架中安装或维修该部件时使身体受伤，您必须采取特殊的预防措施确保系统固定。以下是确保安全的原则：

- 如果此部件是机架中唯一的部件，应将其安装在机架的底部。
- 如果在部分装满的机架中安装此部件，请按从下往上的顺序安装各个部件，并且最重的组件应安装在机架的底部。
- 如果机架配有固定装置，请先装好固定装置，然后再在机架中安装或维修部件。

警告 この装置をラックに設置したり保守作業を行ったりするときは、人身事故を防ぐため、システムが安定しているかどうかを十分に確認する必要があります。次の注意事項に従ってください。

- ラックにこの装置を単独で設置する場合は、ラックの一番下に設置します。
- ラックに別の装置がすでに設置されている場合は、最も重量のある装置を一番下にして、重い順に下から上へ設置します。
- ラックに安定器具が付属している場合は、その安定器具を取り付けてから、装置をラックに設置するか、またはラック内の装置の保守作業を行ってください。

Redundant Power Supply Connection Warning



Warning

If a redundant power system (RPS) is not connected to the switch, install an RPS connector cover on the back of the switch. Statement 265

Waarschuwing

Als er geen redundant voedingsstelsel (RPS) aan de schakelaar is gekoppeld, dient u een RPS-connectorplaatje op de achterkant van de schakelaar te installeren.

Varoitus

Jos korvautuvaa tehojärjestelmää (redundant power system, RPS) ei ole liitetty kytkimeen, kiinnitä RPS-liittimen suojuus kytkimen takapuolelle.

Redundant Power Supply Connection Warning

Attention	Si un système d'alimentation électrique redondant (RPS) n'est pas connecté au commutateur, installez un cache de connecteur RPS à l'arrière du commutateur.
Warnung	Wenn keine redundante Stromversorgung (RSV) an den Schalter angeschlossen ist, eine RSV-Steckerabdeckung an der Rückseite des Schalters anbringen.
Avvertenza	Se un sistema RPS (Redundant Power System) di alimentazione ridondante non è collegato al dispositivo switch, installare un copri-connettore RPS sul retro del switch.
Advarsel	Dersom et redundant strømsystem (Redundant Power System -RPS) ikke er koblet til bryteren, skal det installeres et RPS-koblingsdeksel på baksiden av bryteren.
Aviso	Se um sistema de alimentação redundante (RPS) não estiver conectado a um switch, instale uma capa de conector RPS na parte de trás do switch.
¡Advertencia!	Si no se conecta un sistema de potencia redundante (RPS) al interruptor, instale una cubierta de conector RPS en la parte posterior del interruptor.
Varning!	Om ett redundant strömförsörjningssystem (redundant power system, RPS) inte finns anslutet till switchen skall ett RPS-kontaktsskydd installeras på switchens baksida.
Figyelem	Ha a kapcsolóhoz nem csatlakozik redundáns tápegység (RPS), az RPS csatlakozófedelét a kapcsoló hátuljára szerelje fel.
Предупреждение	Если система питания с избыточными источниками и распределением нагрузки (RPS) не подсоединена к переключателю, установите крышку соединителя RPS на задней стенке переключателя.

警告 如果冗余电源系统 (RPS) 未连接切换开关，请在开关后面安装 RPS 接头盖。

警告 Redundant Power System (RPS) がスイッチに接続されていない場合、スイッチの後ろの部分に RPS コネクタ カバーを設置してください。

Switch Installation Warning



Warning

To comply with safety regulations, mount switches on a wall with the front panel facing up.

Waarschuwing

Om te voldoen aan de veiligheidsvoorschriften dient u de schakelaars op een muur te monteren met het voorpaneel omhoog.

Varoitus

Turvallisuusmääräykset edellyttävät, että kytkimet kiinnitetään seinään etupaneeli ylöspäin.

Attention

Pour satisfaire aux dispositions de sécurité, installez les commutateurs muraux avec le panneau frontal vers le haut.

Warnung

Zur Einhaltung der Sicherheitsvorschriften die Schalter so an einer Wand montieren, dass die Frontplatte nach oben zeigt.

Avvertenza

In conformità ai regolamenti di sicurezza, installare i dispositivi switch a muro con il pannello frontale rivolto in su.

Advarsel

For å etterkomme sikkerhetsreglene skal brytere monteres på en vegg med frontpanelet vendt opp.

Aviso

Para cumprir com os regulamentos de segurança, faça a montagem de switches em uma parede com o painel frontal virado para cima.

Restricted Area

¡Advertencia!	Para cumplir con las reglas de seguridad, instale los interruptores en una pared con el panel del frente hacia arriba.
Varning!	För att uppfylla säkerhetsföreskrifter skall switcharna monteras på en vägg med frampanelen riktad uppåt.
Figyelem	A biztonsági előírások betartása érdekében a kapcsolókat úgy szerelje a falra, hogy az előlapjuk felfelé nézzen.
Предупреждение	В соответствии с положениями безопасности установите переключатели на стене передней панелью наружу.
警告	为符合安全规章，请将切换开关安装在墙上，前面板朝上。
警告	安全既定に準拠するために、フロントパネルを上向きにしてスイッチを壁にマウントします。

Restricted Area



Warning

This unit is intended for installation in restricted access areas. A restricted access area can be accessed only through the use of a special tool, lock and key, or other means of security.

Waarschuwing

Deze eenheid is bestemd voor installatie in plaatsen met beperkte toegang. Toegang tot een dergelijke plaats kan alleen verkregen worden door middel van een speciaal instrument, een slot en sleutel of een ander veiligheidsmiddel.

Varoitus

Tämä laite on tarkoitettu asennettavaksi paikkaan, johon pääsy on rajoitettua. Tällaiseen paikkaan pääsee vain erikoistyökäluä, lukkoon sopivaa avainta tai jotakin muuta turvalaitetta käyttämällä.

Attention	Cet appareil est à installer dans des zones d'accès réservé. L'accès à une zone d'accès réservé n'est possible qu'en utilisant un outil spécial, un mécanisme de verrouillage et une clé, ou tout autre moyen de sécurité.
Warnung	Diese Einheit ist zur Installation in Bereichen mit beschränktem Zutritt vorgesehen. Der Zutritt zu derartigen Bereichen ist nur mit einem Spezialwerkzeug, Schloss und Schlüssel oder einer sonstigen Sicherheitsvorkehrung möglich.
Avvertenza	Questa unità è prevista per essere installata in un'area ad accesso limitato, vale a dire un'area accessibile solo mediante l'uso di un attrezzo speciale, come lucchetto e chiave, o altri dispositivi di sicurezza.
Advarsel	Denne enheten er beregnet på installasjon i områder med begrenset tilgang. Et begrenset tilgangsområde kan bare nås ved hjelp av et spesielt verktøy, lås og nøkkel, eller andre sikkerhetsanordninger.
Aviso	Esta unidade foi concebida para instalação em áreas de acesso restrito. Uma área de acesso restrito é uma área à qual apenas tem acesso o pessoal de serviço autorizado, que possua uma ferramenta, chave e fechadura especial, ou qualquer outra forma de segurança.
¡Advertencia!	Esta unidad ha sido diseñada para instalación en áreas de acceso restringido. Sólo puede obtenerse acceso a una de estas áreas mediante la utilización de una herramienta especial, cerradura con llave u otro medio de seguridad.
Varning!	Denna enhet är avsedd för installation i områden med begränsat tillträde. Ett område med begränsat tillträde kan endast tillträdas med hjälp av specialverktyg, lås och nyckel eller annan säkerhetsanordning.
Figyelem	A készülék korlátozottan hozzáférhető területre történő beszerelésre készült. A korlátozottan hozzáférhető területekhez csak speciális szerszám, zár és kulcs vagy más biztonsági berendezés segítségével lehet hozzáférni.
Предупреждение	Данное устройство предназначено для установки в помещениях с ограниченным доступом. В такие помещения можно попасть, только имея специальное устройство доступа, карту или ключ или пройдя проверку другими средствами обеспечения безопасности.

警告 此部件应安装在限制进出的场所。限制进出的场所指只能通过使用特殊工具、锁和钥匙或其它安全手段进出的场所。

警告 この装置は立ち入り制限区域内に設置することが前提になっています。立ち入り制限区域とは、鍵、錠、またはその他の保全手段を使用しないと立ち入ることができない区域です。

Ethernet Cable Shielding in Offices



Warning

Ethernet cables must be shielded when used in a central office environment.

Waarschuwing

Ethernetkabels dienen beveiligd te worden als ze in een centrale kantooromgeving worden gebruikt.

Varoitus

Ethernet-kaapelit täytyy suojata, kun niitä käytetään yleisessä toimistoympäristössä.

Attention

Pour une utilisation en site central, les câbles Ethernet doivent être impérativement blindés.

Warnung

Ethernet-Kabel müssen abgeschirmt werden, wenn sie in einer Zentrale eingesetzt werden.

Avvertenza

I cavi Ethernet devono essere schermati se utilizzati in un ambiente di ufficio centrale.

Advarsel

Ethernet-kabler skal være skjermet når de brukes i et sentralt kontormiljø.

Aviso

Os cabos “Ethernet” deverão estar armados quando usados em ambiente de escritório central.

¡Advertencia!	Los cables Ethernet deben estar protegidos cuando se usen dentro de una oficina central.
Varning!	Ethernetkablar måste vara avskärmda vid användning i central kontorsmiljö.
Figyelem	Az Ethernet kábeleket árnyékolással kell ellátni, ha azokat helyi központban használják.
Предупреждение	Необходимо экранировать кабели Ethernet, используемые в офисе.
警告	在中心局环境中使用以太网电缆时，必须加以屏蔽。
警告	中央オフィス環境で使用される場合、イーサネットケーブルは遮蔽される必要があります。

Class 1 Laser Product



Warning **Class 1 laser product.**

Waarschuwing **Klasse-1 laser produkt.**

Varoitus **Luokan 1 lasertuote.**

Attention **Produit laser de classe 1.**

Warnung **Laserprodukt der Klasse 1.**

Avvertenza **Prodotto laser di Classe 1.**

Advarsel **Laserprodukt av klasse 1.**

■ Class 1 Laser Product

Aviso	Produto laser de classe 1.
¡Advertencia!	Producto láser Clase I.
Varning!	Laserprodukt av klass 1.
Figyelem	Class 1 besorolású lézeres termék.
Предупреждение	Лазерное устройство класса 1.
警告	这是 1 类激光产品。
警告	クラス1レーザー製品です。
주의	1급 레이저 제품.
تحذير	Class 1 Laser منتج ١
Upozorenje	Laserski proizvod klase 1
Upozornění	Laserový výrobek třídy 1.
Προειδοποίηση	Προϊόν λέιζερ κατηγορίας 1.
Figyelem	Class 1 besorolású lézeres termék.
Предупреждение	Лазерное устройство класса 1.
警告	这是 1 类激光产品。
警告	クラス1レーザー製品です。

주의 1급 레이저 제품.

تحذير Class 1 Laser منتج

Upozorenje Laserski proizvod klase 1

Laser Beam Exposure



Warning

Avoid direct exposure to the laser beam.

Waarschuwing

Voorkom rechtstreekse blootstelling aan de laserstraal.

Varoitus

Vältä säteelle altistumista.

Attention

Éviter toute exposition directe au faisceau.

Warnung

Schützen Sie sich vor direkter Laserbestrahlung.

Avvertenza

Evitare l'esposizione diretta al raggio laser.

Advarsel

Unngå direkte eksponering til laserstrålen.

Aviso

Evite exposição a raios laser.

¡Advertencia!

Evite la exposición directa al haz del láser.

Varning!

Utsätt dig inte för laserstrålning.

Figyelem

Kerülje a lézersugárral való közvetlen érintkezést!

Предупреждение	Избегайте прямого воздействия лазерного луча.
警告	注意避免遭受激光光束的直接辐射。
警告	レーザー光線を直接浴びないように注意してください。

Laser Radiation



Warning

Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments.

Waarschuwing

Losgekoppelde of losgeraakte glasvezels of aansluitingen kunnen onzichtbare laserstraling produceren. Kijk niet rechtstreeks in de straling en gebruik geen optische instrumenten rond deze glasvezels of aansluitingen.

Varoitus

Irrotetuista kuiduista tai liittimistä voi tulla näkymätöntä lasersäteilyä. Älä tuijota säteitä tai katso niitä suoraan optisilla välineillä.

Attention

Les fibres ou connecteurs débranchés risquent d'émettre des rayonnements laser invisibles à l'œil. Ne regardez jamais directement les faisceaux laser à l'œil nu, ni d'ailleurs avec des instruments optiques.

Warnung

Unterbrochene Fasern oder Steckerverbindungen können unsichtbare Laserstrahlung abgeben. Blicken Sie weder mit bloßem Auge noch mit optischen Instrumenten direkt in Laserstrahlen.

Avvertenza

Le fibre ottiche ed i relativi connettori possono emettere radiazioni laser. I fasci di luce non devono mai essere osservati direttamente o attraverso strumenti ottici.

Advarsel	Det kan forekomme usynlig laserstråling fra fiber eller kontakter som er frakoblet. Stirr ikke direkte inn i strålene eller se på dem direkte gjennom et optisk instrument.
Aviso	Radiação laser invisível pode ser emitida de conectores ou fibras desconectadas. Não olhe diretamente para os feixes ou com instrumentos ópticos.
¡Advertencia!	Es posible que las fibras desconectadas emitan radiación láser invisible. No fije la vista en los rayos ni examine éstos con instrumentos ópticos.
Varning!	Osynlig laserstrålning kan avges från frånkopplade fibrer eller kontaktdon. Rikta inte blicken in i strålar och titta aldrig direkt på dem med hjälp av optiska instrument.
Figyelem	A nem csatlakoztatott üvegszálak és csatlakozók láthatatlan lézersugárzást bocsáthatnak ki. Ne nézzen bele a sugárba, és ne nézze közvetlenül, optikai berendezések segítségével!
Предупреждение	Отключенные световоды и разъемы могут испускать невидимое лазерное излучение. Не допускайте попадания лазерного луча в глаза и не смотрите на него через оптические приборы.
警告	断开的光纤或接头有可能发出不可见的激光辐射。请勿直视光束或直接用光学仪器观看光束。
警告	光ファイバ ケーブルまたはコネクタを取り外した状態では、目に見えないレーザー光が放射されていることがあります。光線をのぞきこんだり、光学機器を使用して光線を直接見たりしないでください。

■ Laser Radiation



Numerics

10/100/1000 ports

- connecting to [3-51](#)
- described [2-11](#)
- illustrated [2-4](#)
- pinouts [B-2](#)
- recommended cables [3-52](#)

10/100 ports

- cable lengths [3-7](#)
- connecting to [3-51](#)
- described [2-8](#)
- illustrated [2-5](#)
- numbering [2-4](#)
- pinouts [B-2](#)
- recommended cables [3-52](#)

19- and 24-inch racks [3-19](#)

A

AC power

- connecting to [3-12](#)
- connector [2-25](#)
- specifications [A-1 to A-8](#)

adapter cable [3-11](#)

adapter pinouts, terminal

- RJ-45-to-DB-25 [B-10](#)
- RJ-45-to-DB-9 [B-9](#)

agency approvals [A-8](#)

altitude, operating and storage [A-1 to A-8](#)

autonegotiation [2-8, 2-11](#)

B

brackets

- See mounting brackets

C

cable guide, attaching [3-31](#)

cable lengths [3-7](#)

cables

crossover

- four twisted-pair pinout, 10/100 ports [B-6](#)
- four twisted-pair pinout, 1000BASE-T ports [B-7](#)
- identifying [B-8](#)
- two twisted-pair pinout, 10/100 ports [B-5](#)
- recommended [3-52](#)

- SFP module
 - 1000BASE-T module [3-58](#)
- straight-through
 - four twisted-pair pinout, 10/100 ports [B-6](#)
 - four twisted-pair pinout, 1000BASE-T ports [B-7](#)
 - two twisted-pair pinout, 10/100 ports [B-5](#)
- cabling
 - 10/100/1000 ports [2-11, 3-51](#)
 - 10/100 ports [2-9, 2-11, 3-51](#)
 - considerations [3-15](#)
 - pinouts [B-5](#)
 - StackWise cables
 - cable numbers [2-25](#)
 - connecting to [3-38](#)
- cautions [xvi](#)
- chassis warning, rack-mounting and servicing [D-23](#)
- Cisco IP Phones, connecting to [2-10, 3-53](#)
- Cisco RPS
 - See RPS
- CiscoView [2-28](#)
- CLI [2-28](#)
 - accessing by using Express Setup [C-2](#)
 - accessing through console port [C-3](#)
- Cluster Management Suite
 - See CMS
- CMS [2-28](#)
- command-line interface
 - See CLI
- connecting
 - to 10/100/1000 ports [3-51](#)
 - to 10/100 ports [3-51](#)
 - to console port [3-10, B-4](#)
 - to SFP modules [3-55 to 3-59](#)
 - to XENPAK modules [3-59 to 3-60](#)
- connecting to the console port [C-7](#)
- connection procedures [3-51 to 3-60](#)
- connectivity problems, solving [4-4](#)
- connectors and cables
 - console port [B-4 to B-10](#)
 - power (AC and RPS) [2-25](#)
 - SC connectors [B-3](#)
 - SFP module ports [B-3](#)
 - XENPAK module ports [B-4](#)
- console port
 - connecting to [3-10, C-7](#)
 - connectors and cables [B-4 to B-10](#)
 - described [2-27](#)
- conventions, document [xvi](#)
- crossover cable [B-8 to B-10](#)
 - connecting to
 - 1000BASE-T SFP module ports [3-58](#)
- connectivity problems [4-6](#)
- pinout
 - four twisted-pair, 1000BASE-T ports [B-7](#)
 - four twisted-pair 10/100 ports [B-6](#)

D

DC power

RPS [2-3](#)

diagnosing problems [4-4](#)

dimensions [A-2 to A-8](#)

document conventions [xvi](#)

duplex LED [2-18](#)

E

electrical noise, avoiding [3-9](#)

electromagnetic interference (EMI) [A-8](#)

EMC regulatory statements [3-4](#)

Ethernet cable shielding in offices
warning [D-32](#)

Express Setup

accessing CLI by using [C-2](#)

procedure [1-5 to 1-12](#)

troubleshooting [1-9 to 1-10](#)

F

features [2-1 to 2-3](#)

front panel

10/100/1000 ports [2-11](#)

10/100 ports [2-8](#)

clearance [3-8](#)

description [2-4 to 2-6](#)

LEDs [2-13 to 2-21](#)

SFP module ports [2-12 to 2-13](#)

XENPAK module ports [2-3, 2-13](#)

G

Grounded [D-15](#)

grounded equipment warning [D-15](#)

H

HP OpenView [2-28](#)

humidity, relative [A-1 to A-8](#)

I

installation

assigning the IP Address [C-11](#)

connecting to a power source [C-9](#)

rack-mounting [3-19 to 3-38](#)

site requirements [3-7](#)

stacking the switches

See also stacking

starting the terminal emulation software [C-9](#)

table or shelf-mounting [3-37](#)

wall mounting [3-33](#)

warning [D-9](#)

See also procedures

installing or replacing the unit warning [D-16](#)

installing SFP modules [3-42 to 3-44](#)

installing XENPAK modules [3-46 to 3-49](#)
 IOS command-line interface [2-28](#)
 IP address
 configuring by using Express Setup [1-11](#)
 verifying [1-13 to 1-14](#)

J

jewelry removal warning [D-10](#)

L

laser beam exposure warning [D-35](#)
 laser radiation warning [D-36](#)
 LEDs
 color meanings [2-17](#)
 duplex [2-18](#)
 front panel [2-14 to 2-15](#)
 interpreting [2-17](#)
 master [2-17](#)
 port [2-17 to 2-21](#)
 port mode [2-17 to 2-21](#)
 POST results [4-2](#)
 Power over Ethernet [2-18](#)
 RPS [2-16 to 2-17](#)
 speed [2-18](#)
 stack [2-21](#)
 STATUS [2-18](#)

 system [2-16](#)
 troubleshooting with [4-4](#)
 lightning activity warning [D-20](#)

M

main disconnecting device warning [D-14](#)
 mode button [2-13](#)
 mounting, table or shelf [3-37](#)
 mounting, wall mounting [3-33](#)
 mounting brackets
 attaching [3-21 to 3-29](#)
 rack-mount [3-29](#)

N

noise, electrical [3-9](#)

P

packing list [3-9](#)
 PC, connecting to switch [3-11](#)
 performance problems, solving [4-4](#)
 pinouts
 10/100/1000 ports [B-2](#)
 10/100 ports [B-2](#)
 adapters [B-8 to B-10](#)
 console port [B-10](#)
 crossover cable [B-8](#)

- crossover cables
 - four twisted-pair, 1000BASE-T ports [B-7](#)
 - four twisted-pair 10/100 ports [B-6](#)
 - two twisted-pair 10/100 ports [B-5](#)
- RJ-45-to-DB-25 terminal adapter [B-10](#)
- RJ-45-to-DB-9 terminal adapter [B-9](#)
- SFP module ports [B-3](#)
- straight-through cables
 - four twisted-pair 10/100 ports [B-6](#)
 - four twisted-pair 1000BASE-T ports [B-7](#)
 - two twisted-pair 10/100 ports [B-5](#)
- PoE [2-8](#)
 - LED [2-18](#)
- port LEDs [2-17 to 2-21](#)
- port modes
 - changing [2-13](#)
 - LEDs [2-17 to 2-18](#)
 - See also mode button
- ports
 - 10/100 [2-8](#)
 - pinouts [B-2](#)
 - recommended cables [3-52](#)
 - 10/100/1000 [2-4](#)
 - pinouts [B-2](#)
 - recommended cables [3-52](#)
 - numbering of 10/100 [2-8](#)
 - numbering of 10/100/1000 [2-11](#)
 - numbering of SFP module ports [2-7 to 2-8](#)

- POST
 - LEDs [4-2](#)
 - results [4-1](#)
 - running at powerup [1-5, 3-13, 4-2, C-10](#)
- power
 - connecting to [3-12](#)
 - connectors [2-23, 2-25](#)
 - specifications [A-1 to A-8](#)
- power on [3-12](#)
- Power over Ethernet
 - LED [2-18](#)
- power supply
 - AC power outlet [2-25](#)
 - RPS connector [2-25](#)
- procedures
 - connection [3-51 to 3-60](#)
 - installation [3-19 to 3-37](#)
- product disposal warning [D-21](#)
- publications, related [xxiv](#)

Q

- qualified personnel warning [D-8](#)

R

rack-mounting [3-19 to 3-38](#)

rear panel

clearance [3-8](#)

description [2-23 to 2-27](#)

redundant power supply

See RPS

regulatory statements, EMC [3-4](#)

removing SFP modules [3-44 to 3-45](#)

removing XENPAK modules [3-49](#)

restricted area warning [D-30](#)

RJ-45 connector, console port [B-4](#)

RJ-45 console port [2-23](#)

RPS

connecting to [3-12](#)

connector [2-26](#)

LED [2-16 to 2-17](#)

RPS connection warning [D-27](#)

S

safety [3-2, D-1](#)

SC connector [B-3](#)

SFP modules

1000BASE-T

supported speeds [2-20](#)

bale-clasp latch

removal [3-44](#)

connecting to [3-55 to 3-59](#)

connectors [B-3](#)

described [2-12 to 2-13](#)

installation [3-42 to 3-44](#)

shelf-mounting [3-37](#)

Simple Network Management Protocol

See SNMP

SNMP network management platforms [2-28](#)

software switch management [2-28](#)

specifications [A-1](#)

stacking

cabling considerations [3-15](#)

connecting to a StackWise port [3-14](#)

examples [3-14](#)

planning considerations [3-14](#)

powering considerations [3-15](#)

StackWise ports [2-25](#)

straight-through cable

pinout

four twisted-pair 10/100 ports [B-6](#)

four twisted-pair 1000BASE-T ports [B-7](#)

two twisted-pair 10/100 ports [B-5](#)

SunNet Manager [2-28](#)

switch installation warning [D-29](#)

switch powering on [3-12](#)

system LED [2-16](#)

T

table-mounting [3-37](#)
technical specifications [A-1](#)
telco racks [3-19](#)
Telnet, and accessing the CLI [2-28](#)
temperature, operating [A-1](#)
terminal, connecting to switch [3-11](#)
terminal emulation software [3-10, C-9](#)
translated warnings [D-1 to D-36](#)
troubleshooting [4-1 to 4-7](#)

W

wall mounting [3-33](#)
warnings
 defined [xvi](#)
 installation [3-2](#)
 translated [D-1 to D-36](#)

X

XENPAK modules [2-3, 2-13](#)
 connecting to [3-59 to 3-60](#)
 installation [3-46 to 3-49](#)
 removal [3-49](#)

