

ATM Configuration Commands

This chapter describes the commands available to configure an Asynchronous Transfer Mode (ATM) interface.

For ATM configuration information and examples, refer to the chapter entitled “Configuring ATM” in the *Router Products Configuration Guide*.

atm backward-max-burst-size-clp0

To change the maximum number of high-priority cells coming from the destination router to the source router at the burst level on the switched virtual circuit (SVC), use the **atm backward-max-burst-size-clp0** map-class configuration command. The **no** form of this command restores the default.

```
atm backward-max-burst-size-clp0 cell-count  
no atm backward-max-burst-size-clp0
```

Syntax Description

cell-count Maximum number of high-priority cells coming from the destination router at the burst level. Default is -1.

Default

-1. The router does not request this quality of service (QoS) parameter of the ATM switch, so the switch provides a “best effort service.” The switch will drop cells if there is not enough buffer space.

Command Mode

Map-class configuration

Usage Guidelines

The keyword **clp0** indicates that this command affects only cells with a cell loss priority (CLP) of 0 (high-priority cells).

Example

The following example sets the maximum number of high-priority cells coming from the destination router at the burst level to 800 cells:

```
atm backward-max-burst-size-clp0 800
```

atm backward-max-burst-size-clp1

To change the maximum number of low-priority cells coming from the destination router to the source router at the burst level on the SVC, use the **atm backward-max-burst-size-clp1** map-class configuration command. The **no** form of this command restores the default value.

```
atm backward-max-burst-size-clp1 cell-count  
no atm backward-max-burst-size-clp1
```

Syntax Description

cell-count Maximum number of low-priority cells coming from the destination router at the burst level. Default is -1.

Default

-1. The router does not request this quality of service (QOS) parameter of the ATM switch, so the switch provides a “best effort service.” The switch will drop cells if there is not enough buffer space.

Command Mode

Map-class configuration

Usage Guidelines

The keyword **clp1** indicates that this command affects only cells with a cell loss priority (CLP) of 1 (low-priority cells).

Example

The following example sets the maximum number of low-priority cells coming from the destination router at the burst level to 100,000:

```
atm backward-max-burst-size-clp1 100000
```

atm backward-peak-cell-rate-clp0

To change the peak rate of high-priority cells coming from the destination router to the source router on the SVC, use the **atm backward-peak-cell-rate-clp0** map-class configuration command. The **no** form of this command restores the default.

```
atm backward-peak-cell-rate-clp0 rate  
no atm backward-peak-cell-rate-clp0
```

Syntax Description

<i>rate</i>	Maximum rate in kilobits per second (kbps) that this SVC can receive high-priority cells from the destination router. Default is -1. Maximum upper range is 155,000 kbps.
-------------	---

Default

-1. The router does not request this quality of service (QoS) parameter of the ATM switch, so the switch provides a “best effort service.” The switch will drop cells if there is not enough buffer space.

Command Mode

Map-class configuration

Usage Guidelines

The keyword **clp0** indicates that this command affects only cells with a cell loss priority (CLP) of 0 (high-priority cells).

Example

The following example sets the peak rate for high-priority cells from the destination router to 8000 kbps:

```
atm backward-peak-cell-rate-clp0 8000
```

atm backward-peak-cell-rate-clp1

To change the peak rate of low-priority cells coming from the destination router to the source router on the SVC, use the **atm backward-peak-cell-rate-clp1** map-class configuration command. The **no** form of this command restores the default.

```
atm backward-peak-cell-rate-clp1 rate  
no atm backward-peak-cell-rate-clp1
```

Syntax Description

<i>rate</i>	Maximum rate in kilobits per second (kbps) that this SVC can receive low-priority cells from the destination router. Default is -1. Maximum upper range is 155,000 kbps.
-------------	--

Default

-1. The router does not request this quality of service (QOS) parameter of the ATM switch, so the switch provides a “best effort service.” The switch will drop cells if there is not enough buffer space.

Command Mode

Map-class configuration

Usage Guidelines

The keyword **clp1** indicates that this command affects only cells with a cell loss priority (CLP) of 1 (low-priority cells).

Example

The following example sets the peak rate for low-priority cells from the destination router to 7000 kbps:

```
atm backward-peak-cell-rate-clp1 7000
```

atm backward-sustainable-cell-rate-clp0

To change the sustainable rate of high-priority cells coming from the destination router to the source router on the SVC, use the **atm backward-sustainable-cell-rate-clp0** map-class configuration command. The **no** form of this command restores the default.

```
atm backward-sustainable-cell-rate-clp0 rate  
no atm backward-sustainable-cell-rate-clp0
```

Syntax Description

<i>rate</i>	Sustainable rate in kilobits per second (kbps) that this SVC can receive high-priority cells from the destination router. Default is -1. Maximum upper range is 155,000 kbps.
-------------	---

Default

-1. The router does not request this quality of service (QoS) parameter of the ATM switch, so the switch provides a “best effort service.” The switch will drop cells if there is not enough buffer space.

Command Mode

Map-class configuration

Usage Guidelines

The keyword **clp0** indicates that this command affects only cells with a cell loss priority (CLP) of 0 (high-priority cells).

Example

The following example sets the sustainable rate for high-priority cells from the destination router to 800 kbps:

```
atm backward-sustainable-cell-rate-clp0 800
```

atm backward-sustainable-cell-rate-clp1

To change the sustainable rate of low-priority cells coming from the destination router to the source router on the SVC, use the **atm backward-sustainable-cell-rate-clp1** map-class configuration command. The **no** form of this command restores the default value.

```
atm backward-sustainable-cell-rate-clp1 rate  
no atm backward-sustainable-cell-rate-clp1
```

Syntax Description

<i>rate</i>	Sustainable rate in kilobits per second (kbps) that this SVC can receive low-priority cells from the destination router. Default is -1. Maximum upper range is 155,000 kbps.
-------------	--

Default

-1. The router does not request this quality of service (QOS) parameter of the ATM switch, so the switch provides a “best effort service.” The switch will drop cells if there is not enough buffer space.

Command Mode

Map-class configuration

Usage Guidelines

The keyword **clp1** indicates that this command affects only cells with a cell loss priority (CLP) of 1 (low-priority cells).

Example

The following example sets the sustainable rate for low-priority cells from the destination router to 700 kbps:

```
atm backward-sustainable-cell-rate-clp1 700
```

atm clock internal

To cause the AIP to generate the transmit clock internally, use the **atm clock internal** interface configuration command. The **no** form of this command restores the default value.

atm clock internal
no atm clock internal

Syntax Description

This command has no arguments or keywords.

Default

The AIP uses the transmit clock signal from the remote connection (the line). The switch provides the clocking.

Command Mode

Interface configuration

Usage Guidelines

This command is meaningless on a 4B/5B PLIM.

Example

The following example causes the AIP to generate the transmit clock internally:

```
atm clock internal
```


atm exception-queue

To set the exception-queue length, use the **atm exception-queue** interface configuration command. The **no** form of this command restores the default value.

atm exception-queue *number*
no atm exception-queue

Syntax Description

number Number of entries in the range of 8 to 256. Default is 32 entries.

Default

32 entries

Command Mode

Interface configuration

Usage Guidelines

The exception-queue is used for reporting ATM events, such as CRC errors.

Example

In the following example, the exception-queue is set to 50 entries:

```
atm exception-queue 50
```

atm forward-max-burst-size-clp0

To change the maximum number of high-priority cells going from the source router to the destination router at the burst level on the SVC, use the **atm forward-max-burst-size-clp0** map-class configuration command. The **no** form of this command restores the default value.

```
atm forward-max-burst-size-clp0 cell-count  
no atm forward-max-burst-size-clp0
```

Syntax Description

cell-count Maximum number of high-priority cells going from the source router at the burst level. Default is -1.

Default

-1. The router does not request this quality of service (QOS) parameter of the ATM switch, so the switch provides a “best effort service.” The switch will drop cells if there is not enough buffer space.

Command Mode

Map-class configuration

Usage Guidelines

The keyword **clp0** indicates that this command affects only cells with a cell loss priority (CLP) of 0 (high-priority cells).

Example

The following example sets the maximum number of high-priority cells going from the source router at the burst level to 100,000:

```
atm forward-max-burst-size-clp0 100000
```

atm forward-max-burst-size-clp1

To change the maximum number of low-priority cells going from the source router to the destination router at the burst level on the SVC, use the **atm forward-max-burst-size-clp1** map-class configuration command. The **no** form of this command restores the default value.

```
atm forward-max-burst-size-clp1 cell-count  
no atm forward-max-burst-size-clp1
```

Syntax Description

cell-count Maximum number of low-priority cells going from the source router at the burst level. Default is -1.

Default

-1. The router does not request this quality of service (QoS) parameter of the ATM switch, so the switch provides a “best effort service.” The switch will drop cells if there is not enough buffer space.

Command Mode

Map-class configuration

Usage Guidelines

The keyword **clp1** indicates that this command affects only cells with a cell loss priority (CLP) of 1 (low-priority cells).

Example

The following example sets the maximum number of low-priority cells going from the source router at the burst level to 100,000:

```
atm forward-max-burst-size-clp1 100000
```

atm forward-peak-cell-rate-clp0

To change the peak rate of high-priority cells going from the source router to the destination router on the SVC, use the **atm forward-peak-cell-rate-clp0** map-class configuration command. The **no** form of this command restores the default value.

```
atm forward-peak-cell-rate-clp0 rate  
no atm forward-peak-cell-rate-clp0
```

Syntax Description

rate Maximum rate in kilobits per second (kbps) that this SVC can send high-priority cells from the source router. Default is -1. Maximum upper range is 155,000 kbps.

Default

-1. The router does not request this quality of service (QoS) parameter of the ATM switch, so the switch provides a “best effort service.” The switch will drop cells if there is not enough buffer space.

Command Mode

Map-class configuration

Usage Guidelines

The keyword **clp0** indicates that this command affects only cells with a cell loss priority (CLP) of 0 (high-priority cells).

Example

The following example sets the peak high-priority cell rate from the source router to 1000 Kbps:

```
atm forward-peak-cell-rate-clp0 1000
```

atm forward-peak-cell-rate-clp1

To change the peak rate of low-priority cells coming from the source router to the destination router on the SVC, use the **atm forward-peak-cell-rate-clp1** map-class configuration command. The **no** form of this command restores the default value.

```
atm forward-peak-cell-rate-clp1 rate  
no atm forward-peak-cell-rate-clp1
```

Syntax Description

rate Maximum rate in kilobits per second (kbps) that this SVC can send low-priority cells from the source router. Default is -1. Maximum upper range is 155,000 kbps.

Default

-1. The router does not request this quality of service (QoS) parameter of the ATM switch, so the switch provides a “best effort service.” The switch will drop cells if there is not enough buffer space.

Command Mode

Map-class configuration

Usage Guidelines

The keyword **clp1** indicates that this command affects only cells with a cell loss priority (CLP) of 1 (low-priority cells).

Example

The following example sets the peak low-priority cell rate from the source router to 100,000 kbps:

```
atm forward-peak-cell-rate-clp1 100000
```

atm forward-sustainable-cell-rate-clp0

To change the sustainable rate of high-priority cells coming from the source router to the destination router on the SVC, use the **atm forward-sustainable-cell-rate-clp0** map-class configuration command. The **no** form of this command restores the default value.

```
atm forward-sustainable-cell-rate-clp0 rate  
no atm forward-sustainable-cell-rate-clp0
```

Syntax Description

rate Sustainable rate in kilobits per second (kbps) that this SVC can send high-priority cells from the source router. Default is -1. Maximum upper range is 155,000 kbps.

Default

-1. The router does not request this quality of service (QOS) parameter of the ATM switch, so the switch provides a “best effort service.” The switch will drop cells if there is not enough buffer space.

Command Mode

Map-class configuration

Usage Guidelines

The keyword **clp0** indicates that this command affects only cells with a cell loss priority (CLP) of 0 (high-priority cells).

Example

The following example sets the sustainable rate for high-priority cells from the source router to 100,000 kbps:

```
atm forward-sustainable-cell-rate-clp0 100000
```

atm forward-sustainable-cell-rate-clp1

To change the sustainable rate of low-priority cells coming from the source router to the destination router on the SVC, use the **atm forward-sustainable-cell-rate-clp1** map-class configuration command. The **no** form of this command restores the default value.

```
atm forward-sustainable-cell-rate-clp1 rate  
no atm forward-sustainable-cell-rate-clp1
```

Syntax Description

rate Sustainable rate in kilobits per second (kbps) that this SVC can send low-priority cells from the source router. Default is -1. Maximum upper range is 155,000 kbps.

Default

-1. The router does not request this quality of service (QoS) parameter of the ATM switch, so the switch provides a “best effort service.” The switch will drop cells if there is not enough buffer space.

Command Mode

Map-class configuration

Usage Guidelines

The keyword **clp1** indicates that this command affects only cells with a cell loss priority (CLP) of 1 (low-priority cells).

Example

The following example sets the sustainable rate for low-priority cells from the source router to 100,000 kbps:

```
atm forward-sustainable-cell-rate-clp1 100000
```

atm maxvc

To set the maximum number of virtual circuits the AIP will support, use the **atm maxvc** interface configuration command. The **no** form of this command restores the default value.

atm maxvc *number*

no atm maxvc

Syntax Description

number Maximum number of supported virtual circuits. Valid values are 256, 512, 1024, 2048, or 4096. Default is 4096.

Default

4096 virtual circuits

Command Mode

Interface configuration

Usage Guidelines

This command does not affect the VPI/VCI of each virtual circuit. It limits the number of virtual circuits on which the AIP allows segmentation and reassembly (SAR) to occur.

Example

The following example restricts the AIP to supporting a maximum of 2048 virtual circuits:

```
atm maxvc 2048
```


atm nsap-address

To set the NSAP address for an ATM interface using SVC mode, use the **atm nsap-address** interface configuration command. The **no** form of this command removes any configured address for the interface.

```
atm nsap-address nsap-address  
no atm nsap-address
```

Syntax Description

nsap-address The 40-digit (hexadecimal) NSAP address of this interface (the source address)

Default

No NSAP address is defined for this interface.

Command Mode

Interface configuration

Usage Guidelines

When you are configuring an SVC, the **atm nsap-address** command is required, as it defines the source NSAP address. It identifies a particular port on the ATM network and must be unique across the network.

Configuring a new address on the interface will overwrite the previous address. The router considers the address as a string of bytes and will not prefix or suffix the address with any other strings or digits. The complete NSAP address must be specified, because this value will be used in the Calling Party Address Information Element in the SETUP message to establish a virtual circuit.

ATM NSAP addresses have a fixed length of 40 hexadecimal digits. You must configure the complete address in the following format:

```
xx.xxxx.xx.xxxxxx.xxxx.xxxx.xxxx.xxxx.xxxx.xxxx.xx
```

Note All ATM NSAP addresses must be entered in the dotted hexadecimal format shown above, which conforms to the UNI specification.

Example

In the following example, the source NSAP address for the interface is AB.CDEF.01.234567.890A.BCDE.F012.3456.7890.1234.12 :

```
atm nsap-address AB.CDEF.01.234567.890A.BCDE.F012.3456.7890.1234.12
```

atm pvc

To create a permanent virtual circuit (PVC) on the AIP interface, use the **atm pvc** interface configuration command. The **no** form of this command destroys the specified PVC.

```
atm pvc vcd vpi vci aal-encap [peak] [average] [burst]  
no atm pvc vcd vpi vci aal-encap [peak] [average] [burst]
```

Syntax Description

<i>vcd</i>	Virtual circuit descriptor. A unique number per AIP that identifies to the AIP which VPI/VCI to use for a particular packet. Valid values range from 1 to the value set with the atm maxvc command. The AIP requires this feature to manage packet transmission. The <i>vcd</i> is not associated with the VPI/VCI used for the ATM network cells.
<i>vpi</i>	ATM network virtual path identifier (VPI) of this PVC, in the range from 0 through 255. The VPI is an 8-bit field in the header of the ATM cell. The VPI value is unique only on a single interface, not throughout the ATM network (it has local significance only).
<i>vci</i>	ATM network virtual channel identifier (VCI) of this PVC, in the range of 0 through 65535. The VCI is a 16-bit field in the header of the ATM cell. The VCI value is unique only on a single interface, not throughout the ATM network (it has local significance only).
<i>aal-encap</i>	ATM adaptation layer (AAL) and encapsulation type. When aal5mux is specified, a protocol is also required. Therefore, possible values are as follows: aal5mux decnet (a MUX-type VC) aal5mux ip (a MUX-type VC) aal5mux novell (a MUX-type VC) aal5mux vines (a MUX-type VC) aal5mux xns (a MUX-type VC) aal5snap (LLC/SNAP precedes the protocol datagram) qsaal (a signaling-type PVC used for setting up/tearing down SVCs)
<i>peak</i>	(Optional) Maximum rate (in kbps) at which this virtual circuit (VC) can transmit. Valid values are in the range from 1 to the maximum rate set for a rate queue. If you set this value, it should match a value specified by the atm rate-queue command.
<i>average</i>	(Optional) Average rate (in kbps) at which this VC will transmit. Valid values are in the range from 1 to the maximum rate set for a rate queue.
<i>burst</i>	(Optional) Value (in the range 1 through 2047) that relates to the maximum number of ATM cells the VC can transmit to the network at the <i>peak</i> rate of the PVC. The actual burst cells equals <i>burst</i> * 32 cells, thereby allowing for a burst size of 32 cells to 65535 cells. The largest practical value of <i>burst</i> is the MTU size of the AIP card.

Default

If no *peak* and *average* rates are specified, the PVC defaults to the highest bandwidth rate-queue available. *Peak* and *average* rates are then equal. By default, the VC is configured to run as fast as possible.

Command Mode

Interface configuration

Usage Guidelines

This command creates a PVC and attaches it to the VPI and VCI specified. Both *vpi* and *vci* cannot be specified as 0; if one is 0, the other cannot be 0. The *aal-encap* argument determines the AAL mode and the encapsulation method used. The *peak* and *average* arguments determine the rate queue used.

If you are configuring an SVC, this command is required to configure the PVC that handles the SVC call setup and termination. In this case, specify **qsaal** for the *aal-encap* argument. See the second example that follows.

Examples

The following example creates a PVC with VPI 0 and VCI 6. The PVC uses AAL aal5mux with IP protocol.

```
atm pvc 1 0 6 aal5mux ip
```

The following example creates a PVC to be used for ATM signalling for an SVC. It specifies VPI 0 and VCI 5.

```
atm pvc 1 0 5 qsaal
```

Related Commands

A dagger (†) indicates that the command is documented in another chapter.

atm maxvc

atm rate-queue

mtu †

atm rate-queue

To create a rate queue for the AIP, use the **atm rate-queue** interface configuration command. The **no** form of this command removes the rate queue.

```
atm rate-queue queue-number speed  
no atm rate-queue
```

Syntax Description

<i>queue-number</i>	Queue number in the range 0 through 7.
<i>speed</i>	Speed in megabits per second (Mbps) in the range from 1 through 155. The maximum speed is determined by the detected PLIM type on the AIP: 34 Mbps for E3 45 Mbps for DS-3 (when available) 100 Mbps for TAXI 155 Mbps for SONET

Default

No rate-queue is defined.

Command Mode

Interface configuration

Usage Guidelines

You must create a rate queue before a virtual circuit can be created. You can create multiple rate queues. A warning message appears if all rate queues are deconfigured or if the combined rate-queues exceed the PLIM rate.

Example

In the following example, rate queue 1 is configured for 100 Mbps:

```
atm rate-queue 1 100
```

atm rawq-size

To define the AIP raw-queue size, use the **atm rawq-size** interface configuration command. The **no** form of this command restores the default value.

atm rawq-size *number*
no atm rawq-size

Syntax Description

number Maximum number of cells in the raw queue simultaneously, in the range 8 through 256. Default is 32.

Default

32 cells

Command Mode

Interface configuration

Usage Guidelines

The raw queue is used for raw ATM cells, which include OAM (F4 and F5) and Interim Local Management Interface (ILMI) cells.

Example

In the following example, a maximum of 48 cells are allowed in the raw queue:

```
atm rawq-size 48
```

atm rxbuff

To set the maximum number of Receive buffers for simultaneous packet reassembly, use the **atm rxbuff** interface configuration command. The **no** form of this command restores the default value.

atm rxbuff *number*
no atm rxbuff

Syntax Description

number Maximum number of packet reassemblies that the AIP can perform simultaneously, in the range 0 through 512. Default is 256.

Default

256 packet reassemblies

Command Mode

Interface configuration

Example

In the following example, the AIP can perform a maximum of 300 packet reassemblies simultaneously:

```
atm rxbuff 300
```

atm sonet stm-1

To set the proper mode of operation for the SONET PLIM, use the **atm sonet stm-1** interface configuration command. The **no** form of this command restores the default.

atm sonet stm-1
no atm sonet stm-1

Syntax Description

This command has no arguments or keywords.

Default

STS-3C

Command Mode

Interface configuration

Usage Guidelines

Use STM-1 in applications where the ATM switch requires “unassigned cells” for rate adaptation. Use the default (STS-3C) in applications where the ATM switch requires “idle cells” for rate adaptation.

Example

The following example specifies ATM SONET STM-1:

```
atm sonet stm-1
```

atm txbuff

To set the maximum number of Transmit buffers for simultaneous packet fragmentation, use the **atm txbuff** interface configuration command. The **no** form of this command restores the default value.

atm txbuff *number*
no atm txbuff

Syntax Description

number Maximum number of packet fragmentations that the AIP can perform simultaneously, in the range 0 through 512. Default is 256.

Default

256 packet fragmentations

Command Mode

Interface configuration

Example

In the following example, the AIP is configured to perform up to 300 packet fragmentations simultaneously:

```
atm txbuff 300
```


atm vc-per-vp

To set the maximum number of VCIs to support per VPI, use the **atm vc-per-vp** interface configuration command. The **no** form of this command restores the default value.

atm vc-per-vp *number*
no atm vc-per-vp

Syntax Description

number Maximum number of VCIs to support per VPI. Valid values are 32, 64, 128, 256, 512, 1024, 2048, or 4096. Default is 1024.

Default

1024

Command Mode

Interface configuration

Usage Guidelines

This command controls the memory allocation in the AIP to deal with the VCI table. It defines the maximum number of VCIs to support per VPI; it does not bound the VCI numbers.

An invalid VCI causes a warning message to be displayed.

Example

In the following example, the maximum number of VCIs to support per VPI is set to 512:

```
atm vc-per-vp 512
```

Related Command

atm pvc

atm vp-filter

To set the AIP filter register, use the **atm vp-filter** interface configuration command. The **no** form of this command restores the default value.

```
atm vp-filter hexvalue  
no atm vp-filter
```

Syntax Description

hexvalue Value in hexadecimal format. Default is 0x7B.

Default

0x7B

Command Mode

Interface configuration

Usage Guidelines

This command configures the hexadecimal value used in the VP filter register in the reassembly operation. When a cell is received, the right half of the filter is exclusively NORed with the incoming VPI. The result is then ORed with the left half of the filter (the mask). If the result is all ones, then reassembly is done using the VCI/MID table (AAL3/4 processing). Otherwise, reassembly is done using the VPI/VCI table.

In other words, this command allows a way to specify which VPI (or range of VPIs) will be used for AAL3/4 processing; all other VPIs map to AAL5 processing. If only AAL5 processing is desired, the VP filter can default or be set to an arbitrary VPI and AAL5 processing will be performed on all VPIs.

Example

In the following example, the VP filter is set to the value 0xFF:

```
atm vp-filter ff
```

atm-nsap

To define an ATM map statement for an SVC, use the **atm-nsap** map-list configuration command in conjunction with the **map-list** global configuration command. The **no** form of this command removes the address.

```
protocol protocol-address atm-nsap atm-nsap-address [class class-name] [broadcast]
no protocol protocol-address atm-nsap atm-nsap-address [class class-name] [broadcast]
```

Syntax Description

<i>protocol</i>	One of the following keywords: appletalk , apollo , bridge , clns , decnet , ip , ipx , vines , xns .
<i>protocol-address</i>	Destination address that is being mapped to this SVC.
<i>atm-nsap-address</i>	Destination ATM NSAP address. Must be exactly 40 hexadecimal digits long and in the correct dotted-decimal format.
class	(Optional) Keyword.
<i>class-name</i>	(Optional) Name of a table that contains encapsulation-specific parameters. Such a table can be shared between maps that have the same encapsulation.
broadcast	(Optional) Indicates this map entry is to be used when the corresponding <i>protocol</i> wants to send broadcast packets to the interface (for example, IGRP updates).

Default

No map statements are defined.

Command Mode

Map-list configuration

Usage Guidelines

This command is required with the **map-list** command when you are configuring an SVC.

Example

In the following example, a map list named `atmsvc` includes one map statement for a destination address being mapped:

```
map-list atmsvc
ip 131.108.97.17 atm-nsap AB.CDEF.01.234567.890A.BCDE.F012.3456.7890.1234.12 class qos
broadcast
```

Related Command

map-list

atm-vc

To define an ATM map statement for a PVC, use the **atm-vc** map-list configuration command in conjunction with the **map-list** global configuration command. The **no** form of this command removes the address.

```
protocol protocol-address atm-vc vcd [broadcast]  
no protocol protocol-address atm-vc vcd [broadcast]
```

Syntax Description

<i>protocol</i>	One of the following keywords: appletalk , apollo , bridge , clns , decnet , ip , ipx , vines , xns .
<i>protocol-address</i>	Destination address that is being mapped to this PVC.
<i>vcd</i>	Virtual circuit descriptor of the PVC.
broadcast	(Optional) Indicates that this map entry is to be used when the corresponding <i>protocol</i> wants to send broadcast packets to the interface (for example, IGRP updates). Provides pseudo-broadcasting support.

Default

No map statements are defined.

Command Mode

Map-list configuration

Usage Guidelines

When operating in PVC mode, multicast capabilities may not exist in the ATM switch. For this reason, all static maps for a specific protocol should be marked as **broadcast** for multicasting. When a protocol is sending a packet to its multicast address, all static maps marked as **broadcast** will get a copy of that packet. This procedure simulates the multicast environment of a LAN.

Some switches may have point-to-multipoint PVCs that do the equivalent process. If one exists, then that PVC may be used as the sole **broadcast** PVC for all multicast requests.

Example

In the following example, a map list named atm includes two map statements for protocol addresses being mapped:

```
map-list atm  
ip 131.108.168.112 atm-vc 1 broadcast  
decnet 10.2 atm-vc 2 broadcast
```

Related Command

map-list

atmsig close

To disconnect an SVC, use the **atmsig close** EXEC command.

```
atmsig close atmslot/0 vcd
```

Syntax Description

slot Slot of the SVC to close.

vcd Virtual circuit descriptor of the signaling PVC to close.

Command Mode

EXEC

Usage Guidelines

Since the AIP does not perform packet-level accounting on a per-VC basis, the interface does not close an idle SVC automatically. You must execute this command if you want to close a particular SVC. Since VCs are numbered per interface, you must specify which ATM interface by its slot number.

Example

The following example closes SVC 2 on ATM interface 4/0:

```
atmsig close atm4/0 2
```

loopback plim

To place the AIP into loopback mode, use the **loopback plim** interface configuration command. The **no** form of this command removes the loopback.

loopback plim
no loopback plim

Syntax Description

This command has no arguments or keywords.

Default

Packets go from the AIP to the ATM network.

Command Mode

Interface configuration

Usage Guidelines

This command is useful for testing because it loops all packets from the AIP back to the AIP as well as directing the packets to the network.

Example

The following example places the AIP into loopback mode:

```
loopback plim
```

map-class

To define quality of service (QOS) parameters that are associated with a static map for an SVC, use the **map-class** global configuration command. The **no** form of this command deletes this class.

```
map-class encapsulation class-name  
no map-class encapsulation class-name
```

Syntax Description

encapsulation Encapsulation type. One of the following: **atm**, **dialer**, **frame-relay**, **smds**, or **x25**.

class-name User-assigned name of the QOS parameters table.

Default

No QOS parameters are defined.

Command Mode

Global configuration

Usage Guidelines

If the map class identified by *class-name* does not already exist, the router creates a new one. In either case, this command specifies the map class to which subsequent encapsulation-specific commands apply. Configuration of a map class is allowed only if the subsystem corresponding to the encapsulation is linked.

It is up to the media-specific routing that uses a static map to ensure that the referenced class exists if parameters are required.

Example

The following example establishes QOS parameters for map-class atmclass1 and map-class atmclass2:

```
map-list atmlist  
ip 131.108.170.21 atm-vc 12  
ip 131.108.180.121 atm-nsap 12.3456.7890.abcd.0000.00 broadcast  
ip 131.108.190.221 atm-vc 88 class atmclass1  
decnet 10.23 atm-vc 33 class atmclass2 broadcast  
map-class atm atmclass1  
atm forward-peak-cell-rate-clp0 8000  
atm backward-peak-cell-rate-clp0 8000  
map-class atm atmclass2  
atm forward-peak-cell-rate-clp1 7000  
atm backward-peak-cell-rate-clp1 7000  
atm backward-sustainable-cell-rate-clp0 800  
interface atm 2/0  
map-group atmlist
```

Related Commands

atm backward-peak-cell-rate-clp0
atm backward-peak-cell-rate-clp1
atm backward-max-burst-size-clp0
atm backward-max-burst-size-clp1
atm backward-sustainable-cell-rate-clp0
atm backward-sustainable-cell-rate-clp1
atm forward-peak-cell-rate-clp0
atm forward-peak-cell-rate-clp1
atm forward-max-burst-size-clp0
atm forward-max-burst-size-clp1
atm forward-sustainable-cell-rate-clp0
atm forward-sustainable-cell-rate-clp1

map-group

To associate an ATM map list to an interface or subinterface for either a PVC or SVC, use the **map-group** interface configuration command. The **no** form of this command removes the reference to the map list.

```
map-group name  
no map-group name
```

Syntax Description

name Name of the map list identified by the **map-list** command

Default

No ATM map lists are associated.

Command Mode

Interface configuration

Usage Guidelines

More than one map-group can be configured for an interface.

Example

In the following example, the map list named atm is associated with the ATM interface:

```
interface atm 2/0  
map-group atm
```

Related Command

map-list

map-list

To define an ATM map statement for either a PVC or SVC, use the **map-list** global configuration command. The **no** form of this command deletes this list and all associated map statements.

```
map-list name  
no map-list name
```

Syntax Description

name Name of the map list

Default

No map statements are defined.

Command Mode

Global configuration

Usage Guidelines

ATM currently does not provide broadcasting or multicasting capabilities. To allow the router to propagate routing updates and ARP requests, a static map that maps the protocol address and the ATM address of the next-hop ATM station must be configured. The router supports a mapping scheme that identifies the ATM address of remote hosts/routers. This address can be specified either as a virtual circuit descriptor (*vcd*) for a PVC or an NSAP address for an SVC.

The **map-list** command specifies the map list to which the subsequent map-list configuration commands apply. These map-list configuration commands identify destination addresses. One map list can contain multiple map entries. A map-list can be referenced by more than one interface.

Examples

In the following example for a PVC, a map list named atm includes two map statements for protocol addresses being mapped:

```
Router(config)# map-list atm  
Router(config-map-list)# ip 131.108.168.112 atm-vc 1 broadcast  
Router(config-map-list)# decnet 10.2 atm-vc 2 broadcast
```

In the following example for an SVC, a map list named atm includes two map statements for protocol addresses being mapped:

```
map-list atm  
ip 131.108.97.165 atm-nsap BC.CDEF.01.234567.890A.BCDE.F012.3456.7890.1234.13  
ip 131.108.97.166 atm-nsap BC.CDEF.01.234567.890A.BCDE.F012.3456.7890.1234.12
```

Related Commands

```
atm-nsap  
atm-vc  
map-group
```

show atm interface atm

To display ATM-specific information about an interface, use the **show atm interface atm** privileged EXEC command.

```
show atm interface atm slot/0
```

Syntax Description

slot Slot number of the AIP

Command Mode

EXEC

Sample Display

The following is sample output from the **show atm interface atm** command to display statistics on a given interface, in this case, slot 4, port 0:

```
Router# show atm interface atm 4/0

ATM interface ATM4/0:
AAL enabled: AAL5 , Maximum VCs: 1024, Current VCs: 6
Tx buffers 256, Rx buffers 256, Exception Queue: 32, Raw Queue: 32
VP Filter: 0x7B, VCIs per VPI: 1024
PLIM Type:4B5B - 100Mbps, No Framing, TX clocking: LINE
4897 input, 2900 output, 0 IN fast, 0 OUT fast
Rate-Queue 1 set to 100Mbps, reg=0x4EA
Config. is ACTIVE
```

Table 7-1 describes the fields shown in the display.

Table 7-1 Show ATM Interface ATM Field Descriptions

Field	Description
ATM interface	Slot/port number of the interface.
AAL enabled	Type of AAL.
Maximum VCs	Maximum number of virtual circuits this interface can support.
Current VCs	Number of active virtual circuits.
Tx buffers, Rx buffers	Number of buffers configured with the atm txbuff or atm rxbuff command, respectively.
Exception Queue	Number of buffers configured with the atm exception-queue command.
Raw Queue	Queue size configured with the atm rawq-size command
VP Filter	Hexadecimal value of the VP filter as configured by the atm vp-filter command.
VCIs per VPI	Maximum number of VCIs to support per VPI, as configured by the atm vc-per-vp command.
PLIM Type	Physical Layer Interface Module (PLIM) type (E3, 4B/5B, or SONET).
Framing	For E3, this might be G.804; otherwise, no framing.

Field	Description
TX clocking	Clocking on the router. For E3 or SONET, this might be INTERNAL, meaning the AIP generates the clock. Otherwise, LINE indicates that the ATM switch provides the clocking.
input	Number of packets received and process switched.
output	Number of packets sent from process switch.
IN fast	Number of input packets fast-switched.
OUT fast	Number of output packets fast-switched.
Rate-Queue	List of configured rate queues.
reg=	Actual register value passed to the AIP to define a specific rate queue.
Config. is	ACTIVE or VALID in <i>n</i> SECONDS. ACTIVE indicates that the current AIP configuration has been loaded into the AIP and is being used. There is a 5-second window when a user changes a configuration and the configuration is sent to the AIP.

Related Command

atm pvc

show atm map

To display the list of all configured ATM static maps to remote hosts on an ATM network, use the **show atm map** privileged EXEC command.

show atm map

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Sample Display

The following is sample output from the **show atm map** command:

```
Router# show atm map
Map list atm :

vines 3004B310:0001 maps to VC 4, broadcast
ip 131.108.168.110 maps to VC 1, broadcast
clns 47.0004.0001.0000.0c00.6e26.00 maps to VC 6, broadcast
appletalk 10.1 maps to VC 7, broadcast
decnet 10.1 maps to VC 2, broadcast
```

Table 7-2 describes the fields shown in the display.

Table 7-2 Show ATM Map Field Descriptions

Field	Description
Map list	Name of map list.
<i>protocol address maps to VC x</i>	Name of protocol, the protocol address, and the VCD that the address is mapped to.
broadcast	Indicates pseudo broadcasting.

Related Commands

atm pvc
map-list

show atm traffic

To display current, global ATM traffic information to and from all ATM networks connected to the router, use the **show atm traffic** privileged EXEC command.

show atm traffic

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Sample Display

The following is sample output from the **show atm traffic** command:

```
Router# show atm traffic

4915 Input packets
0 Output packets
2913 Broadcast packets
0 Packets for non-existent VC
```

Table 7-3 describes the fields shown in the display.

Table 7-3 Show ATM Traffic Field Descriptions

Field	Description
Input packets	Total packets input.
Output packets	Total packets output (non-broadcast).
Broadcast packets	Total broadcast packets output.
Packets for non-existent VC	Packets sent to virtual circuits not configured.

Related Command

atm pvc

show atm vc

To display all active ATM virtual circuits (PVCs and SVCs) and traffic information, use the **show atm vc** privileged EXEC command.

```
show atm vc [vcd]
```

Syntax Description

vcd (Optional) Specifies which VC to display information about.

Command Mode

Privileged EXEC

Usage Guidelines

If no *vcd* is specified, the command displays information for all PVCs and SVCs. The output is in summary form (one line per VC).

Sample Displays

The following is sample output from the **show atm vc** command when no *vcd* is specified, displaying statistics for all VCs:

```
Router# show atm vc

  Intfc. VCD  VPI  VCI  Input  Output  Infast  Outfast  Broadcast  AAL/Encaps
  ATM4/0 1    1    1    305    0        0        0        309        AAL5-SNAP
  ATM4/0 2    2    2    951    0        0        0        951        AAL5-SNAP
  ATM4/0 3    3    3     0     0        0        0         0        AAL5-SNAP
  ATM4/0 4    4    4    162    0        0        0         0        AAL5-MUX
  ATM4/0 6    6    6   2722    0        0        0        876        AAL5-SNAP
  ATM4/0 7    7    7    733    0        0        0        753        AAL5-SNAP
```

The following is sample output from the **show atm vc** command when a *vcd* is specified, displaying statistics for that VC only:

```
Router# show atm vc 4

ATM4/0: VCD: 4, VPI: 4, VCI: 4, etype:0xBAD, AAL5 - MUX, Flags: 0x34
PeakRate: 0, Average Rate: 0, Burst: 0 *32cells, Vcmode: 0xE200
InPkts: 164, OutPkts: 0, InFast: 0, OutFast: 0, Broadcasts: 0
```

Table 7-4 describes the fields shown in the display.

Table 7-4 Show ATM VC Field Descriptions

Field	Description
Intfc.	Interface slot/port.
VCD	Virtual circuit descriptor (VC number).
VPI	Virtual path identifier.
VCI	Virtual channel identifier.
Input	Number of packets input to the ATM interface.
Output	Number of packets output from the ATM interface.

Field	Description
Infast	Number of input packets fast-switched.
Outfast	Number of output packets fast-switched.
Broadcast	Number of packets broadcast by the ATM interface.
AAL/Encaps	Type of ATM adaptation layer (AAL) and encapsulation.
etype	Ether type.
Flags	Bit mask describing VC info. 0x40 SVC 0x20 PVC 0x10 ACTIVE 0x1 AAL5SNAP 0x2 AAL5NLPID 0x3 AAL5FRNLPID 0x4 AAL5MUX 0x5 AAL3/4-SMDS 0x6 SAAL
PeakRate	Number of packets transmitted at the peak rate.
Average Rate	Number of packets transmitted at the average rate.
Burst	Value that, when multiplied by 32, equals the maximum number of ATM cells the VC can transmit at the peak rate of the VC.
Vcmode	AIP-specific register describing the usage of the VC. Contains values such as rate queue, peak rate, and AAL mode, which are also displayed in other fields.

Related Command

atm pvc

show sscop

To show SSCOP details for all ATM interfaces, use the **show sscop** privileged EXEC command.

show sscop

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Sample Display

The following is sample output from the **show sscop** command:

```
Router# show sscop
SSCOP details for interface ATM4/0
  Current State = Data Transfer Ready
  Send Sequence Number: Current = 2, Maximum = 9
  Send Sequence Number Acked = 3
  Rcv Sequence Number: Lower Edge = 2, Upper Edge = 2, Max = 9
  Poll Sequence Number = 1876, Poll Ack Sequence Number = 2
  Vt(Pd) = 0
  Connection Control: timer = 1000
  Timer currently Inactive
  Keep Alive Timer = 30000
  Current Retry Count = 0, Maximum Retry Count = 10
  Statistics -
  Pdu's Sent = 0, Pdu's Received = 0, Pdu's Ignored = 0
  Begin = 0/1, Begin Ack = 1/0, Begin Reject = 0/0
  End = 0/0, End Ack = 0/0
  Resync = 0/0, Resync Ack = 0/0
  Sequenced Data = 2/0, Sequenced Poll Data = 0/0
  Poll = 1591/1876, Stat = 0/1591, Unsolicited Stat = 0/0
  Unassured Data = 0/0, Mgmt Data = 0/0, Unknown Pdu's = 0
```

Table 7-5 describes the fields shown in the display. Interpreting this output requires a good understanding of the SSCOP; it is usually displayed by our technicians to help diagnose network problems.

Table 7-5 Show SSCOP Field Descriptions

Field	Description
SSCOP details for interface	Interface slot and port.
Current State	SSCOP state for the interface.
Send Sequence Number	Current and maximum send sequence number.
Send Sequence Number Acked	Sequence number of packets already acknowledged.
Rcv Sequence Number	Sequence number of packets received.
Poll Sequence Number	Current poll sequence number.
Poll Ack Sequence Number	Poll sequence number already acknowledged.
Vt(Pd)	Number of Sd frames sent which triggers a sending of a Poll frame.

Field	Description
Connection Control	Timer used for establishing and terminating SSCOP.
Keep Alive Timer	Timer used to send keepalives on an idle link.
Current Retry Count	Current count of the retry counter.
Maximum Retry Count	Maximum value the retry counter can take.
Pdu's Sent	Total number of SSCOP frames sent.
Pdu's Received	Total number of SSCOP frames received.
Pdu's Ignored	Number of invalid SSCOP frames ignored.
Begin	Number of Begin frames sent/received.
Begin Ack	Number of Begin Ack frames sent/received.
Begin Reject	Number of Begin Reject frames sent/received.
End	Number of End frames sent/received.
End Ack	Number of End Ack frames sent/received.
Resync	Number of Resync frames sent/received.
Resync Ack	Number of Resync Ack frames sent/received.
Sequenced Data	Number of Sequenced Data frames sent/received.
Sequenced Poll Data	Number of Sequenced Poll Data frames sent/received.
Poll	Number of Poll frames sent/received.
Stat	Number of Stat frames sent/received.
Unsolicited Stat	Number of Unsolicited Stat frames sent/received.
Unassured Data	Number of Unassured Data frames sent/received.
Mgmt Data	Number of Mgmt Data frames sent/received.
Unknown Pdu's	Number of Unknown Pdu's frames sent/received.

sscop cc-timer

To change the connection control timer, use the **sscop cc-timer** interface configuration command. The **no** form of this command restores the default value.

```
sscop cc-timer seconds  
no sscop cc-timer
```

Syntax Description

seconds Number of seconds between Begin messages. Default is 10 seconds.

Default

10 seconds

Command Mode

Interface configuration

Usage Guidelines

The connection control timer determines the time between transmission of BGN, END, or RS PDUs as long as an acknowledgment has not been received.

Example

In the following example, the connection control timer is set to 15 seconds:

```
sscop cc-timer 15
```

Related Command

sscop max-cc

sscop keepalive-timer

To change the keepalive timer, use the **sscop keepalive-timer** interface configuration command. The **no** form of this command restores the default value.

sscop keepalive-timer *seconds*
no sscop keepalive-timer *seconds*

Syntax Description

seconds Number of seconds the router waits between transmission of POLL PDUs when no SD or SDP PDUs are queued for transmission or are outstanding pending acknowledgments.

Default

30 seconds

Command Mode

Interface configuration

Example

In the following example, the keepalive timer is set to 15 seconds:

```
sscop keepalive-timer 15
```

sscop max-cc

To change the retry count of connection control, use the **sscop max-cc** interface configuration command. The **no** form of this command restores the default value.

```
sscop max-cc retries  
no sscop max-cc
```

Syntax Description

retries Number of times that SSCOP will retry to transmit BGN, END, or RS PDUs as long as an acknowledgment has not been received. Valid range is 1 to 6000.

Default

10 retries

Command Mode

Interface configuration

Example

In the following example, the retry count of the connection control is set to 20:

```
sscop max-cc 20
```

Related Command

sscop cc-timer

sscop poll-timer

To change the poll timer, use the **sscop poll-timer** interface configuration command. The **no** form of this command restores the default value.

sscop poll-timer *seconds*
no sscop poll-timer

Syntax Description

seconds Number of seconds the router waits between transmission of POLL PDUs

Default

10 seconds

Command Mode

Interface configuration

Usage Guidelines

The poll timer controls the maximum time between transmission of POLL PDUs when SD or SDP PDUs are queued for transmission or are outstanding pending acknowledgments.

Example

In the following example, the poll timer is set to 15 seconds:

```
sscop poll-timer 15
```

sscop rcv-window

To change the receiver window, use the **sscop rcv-window** interface configuration command. The **no** form of this command restores the default value.

sscop rcv-window *packets*
no sscop rcv-window

Syntax Description

packets Number of packets the interface can receive before it must send an acknowledgment to the ATM switch. Valid range is 1 to 6000.

Default

7 packets

Command Mode

Interface configuration

Example

In the following example, the receiver's window is set to 10 packets:

```
sscop rcv-window 10
```

sscop send-window

To change the transmitter window, use the **sscop send-window** interface configuration command. The **no** form of this command restores the default value.

sscop send-window *packets*
no sscop send-window

Syntax Description

packets Number of packets the interface can send before it must receive an acknowledgment from the ATM switch. Valid range is 1 to 6000.

Default

7 packets

Command Mode

Interface configuration

Example

In the following example, the transmitter's window is set to 10 packets:

```
sscop send-window 10
```