

System Management Commands

This section describes the function and displays the syntax of commands used to manage the router system and its performance on the network. For more information about defaults and usage guidelines, see the corresponding chapter of the *Router Products Command Reference* publication.

[no] buffers {small | middle | big | large | huge} {permanent | max-free | min-free | initial} number

Use the **buffers** global configuration command to make adjustments to initial buffer pool settings and to the limits at which temporary buffers are created and destroyed. Use the **no** form of this command to return the buffers to their default size.

small	Small buffer size.
middle	Medium buffer size.
big	Big buffer size.
large	Large buffer size.
huge	Huge buffer size.
permanent	Number of permanent buffers that the system tries to allocate. Permanent buffers are normally not deallocated by the system.
max-free	Maximum number of free or unallocated buffers in a buffer pool.
min-free	Minimum number of free or unallocated buffers in a buffer pool.
initial	Number of additional temporary buffers that should be allocated when the system is reloaded. This can be used to ensure that the system has necessary buffers immediately after reloading in a high-traffic environment.

number Number of buffers to be allocated.

[no] buffers huge size *number*

Use the **buffers huge size** global configuration command to dynamically resize all huge buffers to the value you specify. Use the **no** form of this command to restore the default buffer values.

number Number of buffers to be allocated.

calendar set *hh:mm:ss day month year*

calendar set *hh:mm:ss month day year*

To set the Cisco 7000 series system calendar, use the **calendar set EXEC** command.

hh:mm:ss Current time in hours (military format), minutes,
and seconds

day Current day (by date) in the month

month Current month (by name)

year Current year (no abbreviation)

[no] clock calendar-valid

To configure the Cisco 7000 series as a time source for a network based on its calendar, use the **clock calendar-valid** global configuration command. Use the **no** form of this command to set the router so that the calendar is not an authoritative time source.

clock read-calendar

To manually read the calendar into the Cisco 7000 series system clock, use the **clock read-calendar EXEC** command.

clock set *hh:mm:ss day month year*

clock set *hh:mm:ss month day year*

To manually set the system clock, use the **clock set** EXEC command.

hh:mm:ss Current time in hours (military format), minutes, and seconds

day Current day (by date) in the month

month Current month (by name)

year Current year (no abbreviation)

clock summer-time *zone recurring [week day month hh:mm week day month hh:mm [offset]]*

clock summer-time *zone date date month year hh:mm date month year hh:mm [offset]*

clock summer-time *zone date month date year hh:mm month date year hh:mm [offset]*

no clock summer-time

To configure the system to automatically switch to summer time (daylight savings time), use one of the formats of the **clock summer-time** configuration command. Use the **no** form of this command to configure the router not to automatically switch to summer time.

zone Name of the time zone (PDT, ...) to be displayed when summer time is in effect

week Week of the month (1 to 5 or **last**)

day Day of the week (Sunday, Monday, ...)

date Date of the month (1 to 31)

month Month (January, February, ...)

year Year (1993 to 2035)

hh:mm Time (military format) in hours and minutes

offset (Optional) Number of minutes to add during daylight savings time (default is 60)

System Management Commands

clock timezone *zone hours* [*minutes*]

no clock timezone

To set the time zone for display purposes, use the **clock timezone** global configuration command. To set the time to Coordinated Universal Time (UTC), use the **no** form of this command.

<i>zone</i>	Name of the time zone to be displayed when standard time is in effect
<i>hours</i>	Hours offset from UTC
<i>minutes</i>	(Optional) Minutes offset from UTC

clock update-calendar

To set the Cisco 7000 series calendar from the system clock, use the **clock update-calendar EXEC** command.

custom-queue-list *list*

no custom-queue-list [*list*]

To assign a custom queue list to an interface, use the **custom-queue-list** interface configuration command. To remove a specific list or all list assignments, use the **no** form of the command.

<i>list</i>	Number of the custom queue list you want to assign to the interface. An integer from 1 to 10.
-------------	---

[no] enable last-resort {**password** | **succeed**}

To specify what happens if the TACACS servers used by the **enable** command do not respond, use the **enable last-resort** global configuration command. The **no** form of this command restores the default.

password	Allows you to enable by entering the privileged command level password.
succeed	Allows you to enable without further question.

enable password *password*

To assign a password for the privileged command level, use the **enable password** global configuration command. The commands **enable password** and **enable-password** are synonymous.

password Case-sensitive character string that specifies the line password prompted for in response to the EXEC command **enable**. The first character cannot be a number. The string can contain any alphanumeric characters, including spaces, up to 80 characters. You cannot specify the *password* in the format *number-space-anything*. The space after the number causes problems.

[no] enable use-tacacs

To enable use of the TACACS to determine whether a user can access the privileged command level, use the **enable use-tacacs** global configuration command. Use the **no** form of this command to disable TACACS verification.

hostname *name*

To specify or modify the host name for the network server, use the **hostname** global configuration command. The host name is used in prompts and default configuration filenames. The **setup** command facility also prompts for a host name at startup.

name New host name for the network server; the name is case sensitive.

[no] logging *host*

To log messages to a syslog server host, use the **logging** global configuration command. The **no** form of this command deletes the syslog server with the specified address from the list of syslogs.

host Name or IP address of the host to be used as a syslog server.

System Management Commands

[no] logging buffered

To log messages to an internal buffer, use the **logging buffered** global configuration command. The **no** form of this command cancels the use of the buffer and writes messages to the console terminal, which is the default.

logging console *level*

no logging console

To limit messages logged to the console based on severity, use the logging console global configuration command. The no logging console command disables logging to the console terminal.

level Limits the logging of messages displayed on the console terminal to the named level. See the error message logging priorities table in the *Router Products Command Reference* publication for a list of the *level* keywords.

logging facility *facility-type*

no logging facility

To configure the syslog facility in which error messages are sent, use the **logging facility** global configuration command. To revert to the default of local7, use the **no logging facility** global configuration command.

facility-type See the logging facility *facility-type* keywords table in the *Router Products Command Reference* publication.

logging monitor *level*

no logging monitor

To limit messages logged to the terminal lines (monitors) based on severity, use the logging monitor global configuration command. This command limits the logging messages displayed on terminal lines other

than the console line to messages with a level at or above *level*. The **no logging monitor** command disables logging to terminal lines other than the console line.

level One of the *level* keywords listed in the error message logging priorities table in the *Router Products Command Reference* publication.

[no] logging on

To control logging of error messages, use the **logging on** global configuration command. This command enables message logging to all destinations except the console terminal. The **no** form of this command enables logging to the console terminal only.

logging trap *level* **no logging trap**

To limit messages logged to the syslog servers based on severity, use the **logging trap** global configuration command. The command limits the logging of error messages sent to syslog servers to only those messages at the specified level. The **no** form of this command disables logging to syslog servers.

level One of the *level* keywords listed in the error message logging priorities table in the *Router Products Command Reference* publication.

ntp access-group { query-only | serve-only | serve | peer } *access-list-number*

no ntp access-group { query-only | serve-only | serve | peer }

To control access to the system's Network Time Protocol (NTP) services, use the **ntp access-group** global configuration command. To remove access control to the system's NTP services, use the **no** form of this command.

query-only Allows only NTP control queries. See RFC 1305 (NTP version 3).

System Management Commands

serve-only	Allows only time requests.
serve	Allows time requests and NTP control queries, but does not allow the system to synchronize to the remote system.
peer	Allows time requests and NTP control queries and allows the system to synchronize to the remote system.
<i>number</i>	Number (1 to 99) of a standard IP access list.

[no] ntp authenticate

To enable NTP authentication, use the **ntp authenticate** global configuration command. Use the **no** form of this command to disable the feature.

ntp authentication-key *number* **md5** *value*
no ntp authentication-key *number*

To define an authentication key for Network Time Protocol (NTP), use the **ntp authentication-key** global configuration command. Use the **no** form of this command to remove the authentication key for NTP.

<i>number</i>	Key number (1 to 4294967295)
<i>value</i>	Key value (an arbitrary string of up to eight characters)

ntp broadcast [**version** *number*]
no ntp broadcast

To specify that a specific interface should send Network Time Protocol (NTP) broadcast packets, use the **ntp broadcast** interface configuration command. Use the **no** form of this command to disable this capability.

version <i>number</i>	(Optional) Number from 1 to 3 indicating the NTP version
---------------------------------	--

ntp broadcast client
no ntp broadcast client

To allow the system to receive NTP broadcast packets on an interface, use the **ntp broadcast client** command. Use the **no** form of this command to disable this capability.

ntp broadcastdelay *microseconds*
no ntp broadcastdelay

To set the estimated round-trip delay between the router and a Network Time Protocol (NTP) broadcast server, use the **ntp broadcastdelay** global configuration command. Use the **no** form of this command to revert to the default value.

microseconds Estimated round-trip time (in microseconds) for NTP broadcasts. The range is from 1 to 999999. The default is 3000.

ntp clock-period *value*
no ntp clock-period

Do not enter this command; it is documented for informational purposes only. As NTP compensates for the error in the system clock, it keeps track of the correction factor for this error. The system will automatically save this value into the system configuration using the **ntp clock-period** global configuration command. The system uses the **no** form of this command to revert to the default.

value Amount to add to the system clock for each clock hardware tick (in units of 2^{-32} seconds). The default is 17179869 (4 milliseconds).

[no] ntp disable

To prevent an interface from receiving Network Time Protocol (NTP) packets, use the **ntp disable** interface configuration command. To enable receipt of NTP packets on an interface, use the **no ntp disable** interface configuration command.

System Management Commands

[no] ntp master [*stratum*]

To configure the router as an NTP master clock to which peers synchronize themselves when an external NTP source is not available, use the **ntp master** global configuration command. To disable the master clock function, use the **no** form of this command.

stratum (Optional) Number from 1 to 15. Indicates the NTP stratum number that the system will claim.

ntp peer *ip-address* [**version number**] [**key keyid**] [**source interface**]
[**prefer**]
no ntp peer *ip-address*

To configure the router's system clock to synchronize a peer or to be synchronized by a peer, use the **ntp peer** global configuration command. To disable this capability, use the **no** form of this command.

ip-address IP address of the peer providing, or being provided, the clock synchronization.

version (Optional) Defines the Network Time Protocol (NTP) version number.

number (Optional) NTP version number (1 to 3).

key (Optional) Defines the authentication key.

keyid (Optional) Authentication key to use when sending packets to this peer.

source (Optional) Identifies the interface from which to pick the IP source address.

interface (Optional) Name of the interface from which to pick the IP source address.

prefer (Optional) Makes this peer the preferred peer that provides synchronization.

ntp server *ip address* [**version** *number*] [**key** *keyid*] [**source** *interface*]
[**prefer**]
no ntp server *ip address*

To allow the router's system clock to be synchronized by a time server, use the **ntp server** global configuration command. To disable this capability, use the **no** form of this command.

<i>ip address</i>	IP address of the time server providing the clock synchronization.
version	(Optional) Defines the Network Time Protocol (NTP) version number.
<i>number</i>	(Optional) NTP version number (1 to 3).
key	(Optional) Defines the authentication key.
<i>keyid</i>	(Optional) Authentication key to use when sending packets to this peer.
source	(Optional) Identifies the interface from which to pick the IP source address.
<i>interface</i>	(Optional) Name of the interface from which to pick the IP source address.
prefer	(Optional) Makes this server the preferred server that provides synchronization.

ntp source *interface*
no ntp source

To use a particular source address in Network Time Protocol (NTP) packets, use the **ntp source** global configuration command. Use the **no** form of this command to remove the specified source address.

interface Any valid system interface name.

[no] ntp trusted-key *key-number*

To authenticate the identity of a system to which Network Time Protocol (NTP) will synchronize, use the **ntp trusted-key** global configuration command. Use the **no** form of this command to disable authentication of the identity of the system.

key-number Key number of authentication key to be trusted.

[no] ntp update-calendar

To periodically update the Cisco 7000 series calendar from Network Time Protocol (NTP), use the **ntp update-calendar** global configuration command. Use the **no** form of this command to disable this feature.

ping [*protocol*] {*host* | *address*}

Use the **ping** (packet internet groper) user or privileged EXEC or user command to diagnose basic network connectivity on Apollo, AppleTalk, CLNS, DECnet, IP, Novell IPX, VINES, or XNS networks.

protocol (Optional) Protocol keyword—one of **apollo**, **appletalk**, **clns**, **decnet**, **ip**, **ipx**, **vines**, or **xns**

host Host name of system to ping

address Address of system to ping

priority-group *list*
no priority-group

To assign the specified priority list to an interface, use the **priority-group** interface configuration command. Use the **no priority-group** command to remove the specified **priority-group** assignment.

list Priority list number assigned to the interface

[no] priority-list *list-number* **default** {**high** | **medium** | **normal** | **low**}

To assign a priority queue for those packets that do not match any other rule in the priority list, use the **priority-list default** global configuration command. Use the **no** form of this command to return to the default or assign **normal** as the default.

<i>list-number</i>	Arbitrary integer between 1 and 10 that identifies the priority list selected by the user
high medium normal low	Priority queue level

[no] priority-list *list-number* **interface** *interface-type* *interface-number* {**high** | **medium** | **normal** | **low**}

To establish queuing priorities on packets entering from a given interface, use the **priority-list interface** global configuration command. Use the **no** form of this command with the appropriate arguments to remove an entry from the list.

<i>list-number</i>	Arbitrary integer between 1 and 10 that identifies the priority list selected by the user.
<i>interface-type</i>	Name of the interface.
<i>interface-number</i>	Number of the specified interface.
high medium normal low	Priority queue level.

priority-list *list-number* **protocol** *protocol-name* { **high** | **medium** | **normal** | **low** } *queue-keyword* *keyword-value*
no priority-list *list-number* **protocol**

To establish queuing priorities based upon the protocol type, use the **priority-list protocol** global configuration command. Use the **no** form of this command with the appropriate list number to remove an entry from the list.

<i>list-number</i>	Arbitrary integer between 1 and 10 that identifies the priority list selected by the user.
<i>protocol-name</i>	Specifies the protocol type: aarp , arp , apollo , appletalk , bridge (transparent), clns , clns_es , clns_is , compressedtcp , cmns , decnet , decnet_node , decnet_router , ip , ipx , pad , rsrb , stun , vines , xns , and x25 .
high medium normal low	Priority queue level.
<i>queue-keyword</i> <i>keyword-value</i>	Possible queue keywords are fragments , gt , lt , list , tcp , and udp . See the queue keywords table for this command in the <i>Router Products Command Reference</i> publication.

priority-list *list-number* **queue-limit** *high-limit* *medium-limit*
normal-limit *low-limit*
no priority-list *list-number* **queue-limit**

To specify the maximum number of packets that can be waiting in each of the priority queues, use the **priority-list queue-limit** global configuration command. The **no** form of this command selects the normal queue.

<i>list-number</i>	Arbitrary integer between 1 and 10 that identifies the priority list selected by the user.
<i>high-limit</i> <i>medium-limit</i> <i>normal-limit</i> <i>low-limit</i>	Priority queue maximum length. A value of 0 for any of the four arguments means that the queue can be of unlimited size for that particular queue.

[no] priority-list *list-number* **stun** {**high** | **medium** | **normal** | **low**}
address *group-number* *address*

To establish queuing priorities based on the address of the serial link on a STUN connection, use the **priority-list stun** global configuration command. Use the **no** form of this command with the appropriate arguments to remove an entry from the list.

<i>list-number</i>	Arbitrary integer between 1 and 10 that identifies the priority list selected by the user.
high medium normal low	Priority queue level.
address	Required keyword.
<i>group-number</i>	Group number used in the stun group command.
<i>address</i>	Address of the serial link. The format of the address is either a 1-byte hex value (for example, C1) for an SDLC link or one that is specified by the stun schema global configuration command.

[no] queue-list *list* **default** *queue-number*

To assign a priority queue for those packets that do not match any other rule in the queue list, use the **queue-list default** global configuration command. To restore the default value, use the **no** form of this command.

<i>list</i>	Number of the queue list. An integer from 1 to 10.
<i>queue-number</i>	Number of the queue. An integer from 1 to 10.

queue-list *list-number* **interface** *interface-type* *interface-number*
queue-number
no queue-list *list-number* **interface** *queue-number*

To establish queuing priorities on packets entering on an interface, use the **queue-list interface** global configuration command. To remove an entry from the list, use the **no** form of the command.

<i>list-number</i>	Number of the queue list. An integer from 1 to 10.
<i>interface-type</i>	Required argument that specifies the name of the interface.
<i>interface-number</i>	Number of the specified interface.
<i>queue-number</i>	Number of the queue. An integer from 1 to 10.

queue-list *list-number* **protocol** *protocol-name* *queue-number*
queue-keyword *keyword-value*
no queue-list *list-number* **protocol** *protocol-name*

To establish queuing priority based upon the protocol type, use the **queue-list protocol** global configuration command. Use the **no queue-list protocol** command with the appropriate list number to remove an entry from the list.

<i>list-number</i>	Number of the queue list. An integer from 1 to 10.
<i>protocol-name</i>	Required argument that specifies the protocol type: aarp , arp , apollo , appletalk , bridge (transparent), clns , clns_es , clns_is , compressedtcp , cmns , decnet , decnet_node , decnet_router , ip , ipx , pad , rsrb , stun , vines , xns , and x25 .
<i>queue-number</i>	Number of the queue. An integer from 1 to 10.

queue-keyword
keyword-value Possible keywords are **gt**, **lt**, **list**, **tcp**, and **udp**. See the protocol priority queue values table in the *Router Products Command Reference* publication.

[no] queue-list *list-number* **queue** *queue-number* **byte-count**
byte-count-number

To designate the byte size allowed per queue, use the **queue-list queue byte-count** global configuration command. To return the byte size to the default value, use the **no** form of this command.

list-number Number of the queue list. An integer from 1 to 10.

queue-number Number of the queue. An integer from 1 to 10.

byte-count-number Specifies the lower boundary on how many bytes the system allows to be delivered from a given queue during a particular cycle.

[no] queue-list *list-number* **queue** *queue-number* **limit** *limit-number*

To designate the queue length limit for a queue, use the **queue-list queue limit** global configuration command. To return the queue length to the default value, use the **no** form of this command.

list-number Number of the queue list. An integer from 1 to 10.

queue-number Number of the queue. An integer from 1 to 10.

limit-number Maximum number of packets which can be queued at any time. Range is 0 to 32767 queue entries.

[no] queue-list *list-number* **stun** *queue-number* **address** *group-number*
address-number

To establish queuing priorities based on the address of the serial link on a STUN connection, use the **queue-list stun** global configuration command. Use the **no** form of this command with the appropriate arguments to remove an entry from the list.

<i>list-number</i>	Number of the queue list. An integer from 1 to 10.
<i>queue-number</i>	Queue number in the range from 1 to 10.
address	Required keyword.
<i>group-number</i>	Group number used in the stun group command.
<i>address-number</i>	Address of the serial link. The format of the address is either a 1-byte hex value (for example, C1) for an SDLC link or one that is specified by the stun schema configuration command.

scheduler-interval *milliseconds*
no scheduler-interval

To control the maximum amount of time that can elapse without running the lowest-priority system processes, use the **scheduler-interval** global configuration command. The **no** form of this command restores the default.

<i>milliseconds</i>	Integer that specifies the interval, in milliseconds. The minimum interval that you can specify is 500 milliseconds; there is no maximum value.
---------------------	---

[no] service exec-wait

To delay the startup of the EXEC on noisy lines, use the **service exec-wait** global configuration command. Use the **no** form of this command to disable this feature.

[no] service nagle

To enable the Nagle congestion control algorithm, use the **service nagle** global configuration command. Use the **no** form of this command to disable this feature.

[no] service password-encryption

To encrypt passwords, use the **service password-encryption** global configuration command. Use the **no** form of this command to disable this service.

[no] service tcp-keepalives {in | out}

To generate keepalive packets on idle network connections, use the **service tcp-keepalives** global configuration command. The **no** form of this command with the appropriate keyword disables the keepalives.

- in** Generates keepalives on incoming connections (initiated by remote host).
- out** Generates keepalives on outgoing connections (initiated by a user).

[no] service telnet-zero-idle

To set the TCP window to zero (0) when the Telnet connection is idle, use the **service telnet-zero-idle** global configuration command. Use the **no** form of this command to disable this feature.

service timestamps [type uptime]

service timestamps type datetime [msec] [localtime] [show-timezone]

no service timestamps [type]

To configure the system to timestamp debugging or logging messages, use one of the **service timestamps** global configuration commands. Use the **no** form of this command to disable this service.

- type* (Optional) Type of message to timestamp:
debug or **log**.

System Management Commands

uptime	(Optional) Timestamp with time since the system was rebooted.
datetime	Timestamp with the date and time.
msec	(Optional) Add milliseconds to the date and time.
localtime	(Optional) Timestamp relative to the local time zone.
show-timezone	(Optional) Include the time zone name in the timestamp.

show buffers [*interface*]

Use the **show buffers** EXEC command to display statistics for the buffer pools on the network server.

The network server has one pool of queuing elements and five pools of packet buffers of different sizes. For each pool, the network server keeps counts of the number of buffers outstanding, the number of buffers in the free list, and the maximum number of buffers allowed in the free list.

<i>interface</i>	(Optional) Causes a search of all buffers that have been associated with that interface for longer than one minute. The contents of these buffers are printed to the screen. This option is useful in diagnosing problems where the input queue count on an interface is consistently nonzero.
------------------	--

show calendar

To display the calendar hardware setting for the Cisco 7000 series, use the **show calendar** EXEC command.

show clock [detail]

To display the system clock, use the **show clock** EXEC command.

detail (Optional) Indicates the clock source (NTP, VINES, 7000 calendar, and so forth) and the current summer-time setting (if any).

show environment

Use the **show environment** EXEC command to display temperature and voltage information on the AGS+ and Cisco 7000 series console.

show environment all

Use the **show environment all** EXEC command to display temperature and voltage information on the Cisco 7000 series console.

show environment last

If a shutdown occurs due to detection of fatal environmental margins, the CSC-ENVM (on the AGS+) or the route processor (RP) (on the Cisco 7000 series) logs the last measured value from each of the six test points to internal nonvolatile memory. Only one set of measurements may be stored at any one time.

Use the **show environment last** EXEC command to display these test points.

show environment table

Use the **show environment table** EXEC command to display environmental measurements and a table that lists the ranges of environment measurement that are within specification. This command is available on the Cisco 7000 series only.

show logging

Use the **show logging** EXEC command to display the state of logging (syslog).

This command displays the state of syslog error and event logging, including host addresses, and whether console logging is enabled. This command also displays Simple Network Management Protocol (SNMP) configuration parameters and protocol activity.

show memory [type] [free]

Use the **show memory** EXEC command to show statistics about the router's memory, including memory free pool statistics.

type (Optional) Memory type to display (**processor, multibus, io, sram**). If *type* is not specified, statistics for all memory types present in the router will be displayed.

free (Optional) Displays free memory statistics.

show ntp associations [detail]

To show the status of Network Time Protocol (NTP) associations, use the **show ntp associations** EXEC command.

detail (Optional) Shows detailed information about each NTP association.

show ntp status

To show the status of Network Time Protocol (NTP), use the **show ntp status** EXEC command.

show processes [cpu]

Use the **show processes EXEC** command to display information about the active processes.

cpu (Optional) Displays detailed CPU utilization statistics.

show processes memory

Use the **show processes memory EXEC** command to show memory utilization.

show protocols

Use the **show protocols EXEC** command to display the configured protocols.

This command shows the global and interface-specific status of any configured Level 3 protocol; for example, IP, DECnet, IPX, AppleTalk, and so forth.

show queueing [custom | priority]

To list the current state of the queue lists, use the **show queueing** privileged EXEC command.

custom (Optional) Shows status of custom queue lists.

priority (Optional) Shows status of priority lists.

show snmp

To check the status of communications between the SNMP agent and SNMP manager, use the **show snmp EXEC** command.

show stacks

Use the **show stacks EXEC** command to monitor the stack utilization of processes and interrupt routines. Its display includes the reason for the last system reboot. If the system was reloaded because of a system failure, a saved system stack trace is displayed. This information is of use only to Cisco engineers analyzing crashes in the field. It is included here in case you need to read the displayed statistics to an engineer over the phone.

[no] snmp-server access-list *list-number*

To set up an access list that determines which hosts can send requests to the network server, use the **snmp-server access-list** global configuration command. Use the **no** form of this command to remove the specified access list.

list-number Integer from 1 to 99 that specifies an IP access list number.

snmp-server chassis-id *text* **no snmp-server chassis-id**

To provide a message line identifying the SNMP server serial number, use the **snmp-server chassis-id** global configuration command. Use the **no** form of this command to remove the message line.

text Message you want to enter to identify the chassis serial number.

snmp-server community [*string* [**RO** | **RW**] [*number*]]
no snmp-server [**community** [*string*]]

To set up the community access string, use the **snmp-server community** global configuration command. This command enables SNMP server operation on the router. The **no** form of this command removes the specified community string or access list.

<i>string</i>	(Optional) Community string that acts like a password and permits access to the SNMP protocol.
RO	(Optional) Specifies read-only access.
RW	(Optional) Specifies read-write access.
<i>number</i>	(Optional) Integer from 1 to 99 that specifies an access list of IP addresses that might use the community string.

snmp-server contact *text*
no snmp-server contact

To set the system contact (syscontact) string, use the **snmp-server contact** global configuration command. Use the **no** form of this command to remove the system contact information.

<i>text</i>	String that describes the system contact information.
-------------	---

snmp-server host *address community-string* [**snmp**] [**tty**]
no snmp-server host *address community-string*

To specify the recipient of an SNMP trap operation, use the **snmp-server host** global configuration command. The **no** form of this command removes the specified host.

<i>address</i>	Name or IP address of the host.
<i>community-string</i>	Password-like community string to send with the trap operation.

snmp	(Optional) Enables the SNMP traps defined in RFC 1157.
tty	(Optional) Enables Cisco enterprise-specific traps when a TCP connection closes.

snmp-server location *text*
no snmp-server location

To set the system location string, use the **snmp-server location** global configuration command. Use the **no** form of this command to remove the location string.

text String that describes the system location information.

snmp-server packetsize *byte-count*
no snmp-server packetsize

To specify the largest SNMP packet size permitted when the SNMP server is receiving a request or generating a reply, use the **snmp-server packetsize** global configuration command. Use the **no** form of this command to restore the default value.

byte-count Integer byte count from 484 to 8192

snmp-server queue-length *length*

To establish the message queue length for each trap host, use the **snmp-server queue-length** global configuration command. This command defines the length of the message queue for each trap host. Once a trap message is successfully transmitted, software will continue to empty the queue, but never faster than at a rate of four trap messages per second.

length Integer that specifies the number of trap events that can be held before the queue must be emptied.

[no] snmp-server system-shutdown

To use the SNMP message reload feature, the device configuration must include the `snmp-server system-shutdown` global configuration command. The `no snmp-server system-shutdown` option prevents an SNMP system-shutdown request (from an SNMP manager) from resetting the Cisco agent.

[no] snmp-server trap-authentication

To establish trap message authentication, use the `snmp-server trap-authentication` global configuration command. This command enables the network server to send a trap message when it receives a packet with an incorrect community string. Use the `no snmp-server trap-authentication` command to remove message authentication.

snmp-server trap-source *interface*

no snmp-server trap-source

To specify the interface (and hence the corresponding IP address) that an SNMP trap should originate from, use the `snmp-server trap-source` global configuration command. Use the **no** form of this command to remove the source designation.

interface Interface from which the SNMP trap originates. The argument includes the interface type and number in platform-specific syntax.

snmp-server trap-timeout *seconds*

To define how often to try resending trap messages on the retransmission queue, use the `snmp-server trap-timeout` global configuration command.

seconds Integer that sets the interval, in seconds, for resending the messages.

tacacs-server attempts *count*

no tacacs-server attempts

To control the number of login attempts that can be made on a line set up for TACACS verification, use the **tacacs-server attempts** global configuration command. Use the **no** form of this command to remove this feature and restore the default.

count Integer that sets the number of attempts.

tacacs-server authenticate {**connection** | **enable**}

The **tacacs-server authenticate** global configuration command requires a response from the network or router to indicate whether the user may perform the indicated action. Enter one of the keywords to specify the action (when a user makes TCP connection, for example).

connection Configures a required response when a user makes a TCP connection.

enable Configures a required response when a user enters the **enable** command.

[no] tacacs-server extended

To enable an extended TACACS mode, use the **tacacs-server extended** global configuration command. Use the **no tacacs-server extended** command to disable the mode.

[no] tacacs-server host *name*

To specify a TACACS host, use the **tacacs-server host** global configuration command. You can use multiple **tacacs-server host** commands to specify multiple hosts. The software searches for the hosts in the order you specify them. The **no** form of this command deletes the specified name or address.

name Name or IP address of the host.

[no] tacacs-server last-resort {password | succeed}

To cause the network server to request the privileged password as verification, or to force successful login without further input from the user, use the `tacacs-server last-resort` global configuration command. The **no** form of this command restores the system to the default behavior.

- password** Allows the user to access the EXEC command mode by entering the password set by the **enable** command.
- succeed** Allows the user to access the EXEC command mode without further question.

tacacs-server notify {connection | enable | logout}

Use the `tacacs-server notify` global configuration command to cause a message to be transmitted to the TACACS server, with retransmission being performed by a background process for up to 5 minutes. The terminal user, however, receives an immediate response allowing access to the feature specified. Enter one of the keywords to specify notification of the TACACS server upon the corresponding action (when user logs out, for example).

- connection** Specifies that a message be transmitted when a user makes a TCP connection.
- enable** Specifies that a message be transmitted when a user enters the **enable** command.
- logout** Specifies that a message be transmitted when a user logs out.

[no] tacacs-server optional-passwords

To specify that the first TACACS request to a TACACS server be made *without* password verification, use the `tacacs-server optional-passwords` global configuration command. Use the **no** form of this command to restore the default.

tacacs-server retransmit *retries*

no tacacs-server retransmit

To specify the number of times the router software will search the list of TACACS server hosts before giving up, use the **tacacs-server retransmit** global configuration command. The router software will try all servers, allowing each one to time out before increasing the retransmit count. The **no tacacs-server retransmit** command restores the default.

retries Integer that specifies the retransmit count.

tacacs-server timeout *seconds*

no tacacs-server timeout

To set the interval that the server waits for a server host to reply, use the **tacacs-server timeout** global configuration command. The **no** form of this command restores the default.

seconds Integer that specifies the timeout interval in seconds.

test flash

To test Flash memory on MCI and envm Flash EPROM interfaces, use the **test flash EXEC** command.

test interfaces

To test the system interfaces on the modular router, use the **test interfaces EXEC** command.

test memory

To perform a test of Multibus memory (including nonvolatile memory) on the AGS+ router, use the **test memory EXEC** command.

trace [*protocol*] [*destination*]

Use the **trace EXEC** command to discover the routes the router's packets will actually take when traveling to their destination.

protocol (Optional) Protocols that can be used are **appletalk**, **clns**, **ip** and **vines**.

destination (Optional) Destination address or host name on the command line. The default parameters for the appropriate protocol are assumed and the tracing action begins.

username *name* [**nopassword** | **password** *encryption-type* **password**]

username *name* **password** *secret*

username *name* [**access-class** *number*]

username *name* [**autocommand** *command*]

username *name* [**noescape**] [**nohangup**]

To establish a username-based authentication system at login, even though your network cannot support a TACACS service, use the **username** global configuration command.

name Host name, server name, user ID, or command name.

nopassword (Optional) Specifies that no password is required for this user to log in. This is usually most useful in combination with the **autocommand** keyword.

password Specifies a possibly encrypted password for this username.

encryption-type (Optional) A single-digit number that defines whether the text immediately following is encrypted, and, if so, what type of encryption is used. Currently defined encryption types are 0, which means that the text immediately following is not encrypted, and 7, which means that the text is encrypted using a Cisco-defined encryption algorithm.

<i>password</i>	(Optional) A password can contain embedded spaces and must be the last option specified in the username command.
<i>secret</i>	For CHAP authentication: specifies the secret for the local router or the remote device. The secret is encrypted when it is stored on the local router. This prevents the secret from being stolen. The secret can consist of any string of up to 11 printable ASCII characters. There is no limit to the number of username/password combinations that can be specified, allowing any number of remote devices to be authenticated.
access-class	(Optional) Specifies an outgoing access list that overrides the access list specified in the access-class line configuration command. It is used for the duration of the user's session.
<i>number</i>	(Optional) The access list number.
autocommand	(Optional) Causes the specified command to be issued automatically after the user logs in. When the command is complete, the session is terminated. As the command can be any length and contain imbedded spaces, commands using the autocommand keyword must be the last option on the line.
<i>command</i>	(Optional) The command string.
noescape	(Optional) Prevents a user from using an escape character on the host to which that user is connected.
nohangup	(Optional) Prevents the router /from disconnecting the user after an automatic command (set up with the autocommand keyword) has completed. Instead, the user gets another login prompt.