



A

access control list

See ACL

accessing

ASI, MRP, and SSP cards, using IOS
CLI [5-11](#)

backup utility [5-30](#)

CallManager [5-8](#)

Cisco ICS 7750 [5-2](#)

ICSConfig [5-4](#)

SAP card [5-3](#), [5-12 to 5-14](#)

SPE310s with Telnet [5-11](#)

SPE desktop, using Terminal Services
Client [5-3](#)

System Manager [5-5](#)

ACL

applying to interfaces [6-121](#)

description [6-118](#)

design [6-118](#)

examples [6-119 to 6-120](#)

filtering traffic with [6-121](#)

administrator password [4-22](#)

analog station interface card

See ASI card

antistatic strap, resistance value [2-3](#)

application command, in MGCP [6-94](#), [6-98](#)

ASI160 card [1-5](#)

ASI81 card [1-5](#)

ASI card

accessing, using CLI [5-11](#)

ASI160, PVDM requirements [C-3](#)

codec options [6-14](#)

connections [3-28](#)

default DSP software images [C-1](#)

DSP, requirements for [6-14](#)

features [6-13](#)

PVDM requirements (table) [C-3 to C-16](#)

removing [8-2](#)

setting date and time [6-5 to 6-8](#)

asynchronous/synchronous serial interface,
configuring [6-28](#), [7-3](#)

authentication [6-115](#)

authorization [6-115](#)

availability, power supplies [3-33](#)

B

background explicit congestion notification

See BECN

backup

CallManager 5-29

CallManager data 6-129

installing CallManager backup utility 4-37 to 4-39

scheduling 5-30 to 5-32

system data 5-28 to 5-33

using Backup Now 5-32 to 5-33

utility, accessing 5-30

backup power 1-6

backup server, CallManager 4-37 to 4-39

BC 7-43

BE 7-43

BECN 6-70

best practices

DHCP 5-15

IOS 5-17, 6-2

System Manager 5-17, 6-2 to 6-3

blackout 2-9

blinking lights 2-11

BOOTP 5-15

branch circuit 2-10

brownout 2-9

browser, configuring 4-7 to 4-9

C

cables

determining distances 2-15 to 2-16

evaluating 2-13

planning for installation 2-14 to 2-15

termination points 2-17

cabling

cascaded Catalyst switches 4-41 to 4-43

GigaStack GBIC ports 4-41 to 4-43

guidelines 2-13 to 2-17

UPS 3-32

CallManager

accessing 5-8

backing up data 6-129

backup 5-29

backup server 4-37 to 4-39

backup utility, installing 4-37 to 4-39

cluster 4-32

configuration checklist 6-124 to 6-128

configuring 6-122 to 6-128

configuring download to MGCP gateway 6-102 to 6-103

definition 5-2

differences on Cisco ICS 7750 6-122

documentation xxiii

installing 4-31 to 4-41

MGCP gateway, configuring for use with 6-100 to 6-101

MOH 6-123

- name configuration [6-123](#)
- product key [4-33](#)
- publisher [4-32, 4-35](#)
- server automatically configured [6-123](#)
- subscriber [4-32, 4-35](#)
- card ports, connecting [3-19 to 3-31](#)
- cards, number of ports on [1-4 to 1-6](#)
- Catalyst 3500 Series XL documentation [xxiv](#)
- Catalyst 3524 PWR-XL [1-7](#)
- Catalyst 3524-PWR XL [2-10](#)
- Catalyst switches, stacking [3-8 to 3-10](#)
- caution, described [xxii](#)
- CCMAdmin account password [4-39](#)
- ccm-manager command [6-100](#)
- ccm-manager redundant host command [6-100](#)
- ccm-manager switchback command [6-101](#)
- ccm-manager switchover-to-backup command [6-101](#)
- CCO, downloading and installing system software [8-22 to 8-24](#)
- chassis dimensions [3-2](#)
- chassis placement [2-13](#)
- chassis-to-switch attachment brackets [3-8](#)
- CIR [6-69, 6-70](#)
- circuit, branch [2-10](#)
- circuit breaker panel [2-10](#)
- circuit breakers [2-9](#)
- Cisco CallManager
 - See* CallManager
- Cisco Customer Response Applications, documentation [xxiv](#)
- Cisco IP Phone, connecting [4-45](#)
- Cisco Network Registrar
 - See* CNR
- Cisco Unity, documentation [6-131](#)
- Cisco Unity Voice Messaging, documentation [xxiv](#)
- CiscoWorks2000
 - description [6-137](#)
 - LAN Management Solution [6-138 to 6-140](#)
 - Routed WAN Management Solution [6-141 to 6-142](#)
 - Service Management Solution [6-143](#)
- CLI
 - accessing on ASI, MRP, and SSP cards [5-11](#)
 - definition [5-3](#)
 - determining software release on ASI, MRP, or SSP cards [5-11](#)
 - clock rate settings [6-29](#)
 - clock set command [6-7](#)
 - clock timezone command [6-6](#)
 - cluster, CallManager [4-32](#)
 - CNR [5-15](#)
 - codecs
 - choosing [6-20](#)
 - delay introduced by [6-17](#)
 - G.711 [6-15](#)
 - G.723.1 [6-15](#)
 - G.726 [6-16](#)
 - G.729 [6-16](#)

- G.729a [6-16](#)
- interoperability [6-16](#)
- options on MRPs and ASIs (table) [6-14](#)
- transcoding [6-24](#)
- voice compression algorithms [6-14](#)
- command conventions [xxii](#)
- command-line interface
 - See* CLI
- commands
 - async default routing [7-4](#)
 - async mode dedicated [7-4](#)
 - channel-group [7-9](#)
 - clockrate [7-4](#)
 - configure terminal [7-2](#)
 - controller t1 [7-8, 7-40](#)
 - copy running-config startup-config [6-4](#)
 - cptone [6-57](#)
 - dce-terminal-timing-enable [7-4](#)
 - destination-pattern [6-41, 7-31](#)
 - dial-peer voice [7-31, 7-37](#)
 - dial-type [6-57](#)
 - direct-inward dial [7-37](#)
 - enable [6-4](#)
 - fair-queue [7-44](#)
 - framing [7-9, 7-40](#)
 - half-duplex timer [6-28](#)
 - half-duplex timer cts-delay [6-28](#)
 - half-duplex timer cts-drop-timeout [6-28](#)
 - half-duplex timer dcd-drop-delay [6-28, 7-4](#)
 - half-duplex timer dcd-txstart-delay [6-28](#)
 - half-duplex timer rts-drop-delay [6-28](#)
 - half-duplex timer rts-timeout [6-29](#)
 - half-duplex timer transmit-delay [6-29](#)
 - interface [7-2](#)
 - invert-txc [7-4](#)
 - ip precedence [6-73](#)
 - ip routing [7-2](#)
 - ip rsvp bandwidth [6-74, 7-44](#)
 - ip rtp compression connections [6-78, 7-45](#)
 - ip rtp header-compression [6-78, 7-45](#)
 - ip rtp header-compression iphc-format [7-46](#)
 - ip rtp reserve [7-45](#)
 - isdn spid [6-34](#)
 - isdn switch-type [7-6, 7-37, 7-40](#)
 - line async [7-4](#)
 - memory-size iomem [7-6](#)
 - multilink virtual-template [7-45](#)
 - num-exp [7-32](#)
 - operation [6-57](#)
 - physical-layer async [7-4](#)
 - ping [7-64](#)
 - port [7-31](#)
 - ppp multilink [7-44](#)
 - ppp multilink fragment-delay [7-45](#)
 - ppp multilink interleave [7-44](#)
 - req-qos controlled-load [7-44](#)
 - service-module t1 framing [7-7](#)
 - service-module t1 linecode [7-7](#)

- session target [7-31](#)
- show controllers [7-59](#)
- show controller t1 [7-58, 7-59](#)
- show dialplan number [7-30](#)
- show interfaces [7-60](#)
- show num-exp [7-30](#)
- show protocols [7-60](#)
- show running-config [7-60, 7-61](#)
- show version [7-58](#)
- show voice dsp [6-21, 6-26](#)
- signal [6-57](#)
- type [6-57](#)
- committed burst
 - See* BC
- committed information rate
 - See* CIR
- community strings, SNMP [4-21](#)
- COM Port Manager, in System Manager [5-6](#)
- conduit ground, using [2-11](#)
- configuration, saving [6-4](#)
- configuration wizard
 - See* ICSCConfig
- configuring
 - asynchronous/synchronous serial interface [6-28, 7-3](#)
 - CallManager [6-122 to 6-128](#)
 - custom queuing [6-72](#)
 - dial plans [6-40](#)
 - DID [6-53 to 6-55](#)
 - download of CallManager information to MGCP gateway [6-102 to 6-103](#)
 - E&M interface [6-57](#)
 - Fast Ethernet ports [6-26, 7-2 to 7-3](#)
 - fax over IP [6-112 to 6-115](#)
 - Frame Relay for VoIP [6-69](#)
 - FXO interface [6-55](#)
 - FXS interface [6-44, 7-30, 7-33, 7-34](#)
 - IP networks for real-time voice traffic [6-71](#)
 - ISDN BRI interface [6-30, 7-5 to 7-6](#)
 - ISDN for voice [6-64 to 6-68](#)
 - ISDN PRI voice interfaces [6-67 to 6-68](#)
 - ISDN signaling backhaul on MGCP [6-106 to 6-111](#)
 - MFT-T1 CAS [6-60](#)
 - MGCP [6-91 to 6-115](#)
 - MGCP with CallManager [6-100 to 6-101](#)
 - multilink PPP interleaving [6-75](#)
 - RGW with MGCP [6-97 to 6-100](#)
 - RSVP for voice [6-73](#)
 - RTP [6-76](#)
 - serial interfaces [7-3 to 7-5](#)
 - SSP [6-10](#)
 - T1 & E1 VWIC interfaces [7-8 to 7-9](#)
 - T1 & fractional T1 interfaces [7-7 to 7-8](#)
 - T1 (FT1) WAN interface [6-34, 7-7](#)
 - T1 CAS for MGCP [6-103 to 6-106](#)
 - TGW with MGCP [6-93 to 6-97](#)
 - weighted fair queuing [6-73](#)

- connecting
 - Cisco IP Phone [4-45](#)
 - modem [4-45 to 4-51](#)
 - power [3-32 to 3-33](#)
 - switches to chassis [3-8 to 3-10](#)
 - to card ports [3-19 to 3-31](#)
 - console port, connecting to [3-29](#)
 - controller t1 command, in MGCP [6-93](#)
 - conventions, command [xxii](#)
 - cooling the system [2-7](#)
 - custom queuing [6-72](#)
-
- ## D
- data link connection identifier
 - See* DLCI
 - date
 - setting on MRP and ASI cards [6-5 to 6-8](#)
 - setting on SPE310 cards [6-5](#)
 - DC Directory Administrator account
 - password [4-36](#)
 - default gateway, IP address [4-17](#)
 - delay
 - definition [6-17](#)
 - propagation [6-17](#)
 - serialization [6-17](#)
 - desktop mounting [3-6 to 3-10](#)
 - DHCP
 - best practices [5-15](#)
 - enabling for IP phones [4-16](#)
 - Microsoft DHCP Server [5-16](#)
 - other DHCP servers [5-16](#)
 - dial peer
 - command [7-31](#)
 - description [6-45](#)
 - POTS [6-46](#)
 - VoIP [6-50](#)
 - dial-peer voice command, in MGCP [6-94, 6-98](#)
 - dial plans, configuring [6-40](#)
 - dial-up connection, testing [4-51](#)
 - DID, configuring [6-53 to 6-55](#)
 - digital signal processors
 - See* DSPs
 - digital voice ports, configuring [6-60](#)
 - dimensions, chassis [3-2](#)
 - direct-inward-dial command [6-54](#)
 - Direct Inward Dialing
 - See* DID
 - distributed call processing [4-32](#)
 - DLCI [6-69](#)
 - DNS, primary IP address [4-17](#)
 - documentation
 - CallManager [xxiii](#)
 - Catalyst 3500 Series XL [xxiv](#)
 - Cisco Customer Response Applications [xxiv](#)
 - Cisco Unity Voice Messaging [xxiv](#)
 - included [xxiii](#)
 - IOS [xxv](#)
 - IP Phones [xxiii](#)

- power supply, backup [xxiv](#)
 - related [xxiii](#)
 - VIC [xxiv](#)
 - VWIC [xxiv](#)
 - WIC [xxiv](#)
 - ds0-group command, in MGCP [6-94](#)
 - DSP modules, removing and replacing [8-3](#)
 - DSPs
 - call processing examples (table) [6-19](#)
 - choosing DSP firmware [6-20 to 6-21](#)
 - configuration rules (table) [6-22](#)
 - determining how many are needed [6-22 to 6-23](#)
 - determining how many are needed for transcoding [6-26](#)
 - grouping [6-18 to 6-19](#)
 - on MRPs and ASIs [6-14](#)
 - understanding usage for transcoding [6-26](#)
 - DSP software images, defaults [C-1](#)
 - dust, effects of [2-13](#)
-
- E**
- E&M
 - configuring [6-57](#)
 - description [6-38](#)
 - E1 PRI [6-39](#)
 - E1 VIC, connection [3-28](#)
 - E1 VWIC, connection [3-28](#)
 - E1 VWIC interfaces, configuring [7-8 to 7-9](#)
 - E1 WIC, connection [3-28](#)
 - earth ground [2-12](#)
 - electricity, static [2-12](#)
 - electromagnetic interference
 - See* EMI
 - electrostatic discharge (ESD), preventing [2-3](#)
 - electrostatic discharge, preventing
 - See* ESD, preventing
 - EMI [2-6](#)
 - enable password [4-21](#)
 - environmental requirements [2-12](#)
 - ESD, preventing [2-3](#)
 - Event Manager, default settings, configuring [4-25 to 4-28](#)
 - Event Manager, in System Manager [5-6](#)
 - excess burst
 - See* BE
 - extension cords, using [2-13](#)
-
- F**
- Fancy Queuing [6-71](#)
 - Fan Manager, in System Manager [5-6](#)
 - fans
 - location [1-7](#)
 - Fast Ethernet, configuring ports [6-26, 7-2 to 7-3](#)
 - fax over IP, configuring [6-112 to 6-115](#)
 - firewall
 - defined [6-116](#)
 - setting up [6-116](#)

flooring [2-13](#)
floor loading [2-8](#)
foreign exchange office
 See FXO
Foreign Exchange Office (FXO) card,
 connection [3-28](#)
foreign exchange station
 See FXS
Foreign Exchange Station (FXS) card,
 connection [3-28](#)
fractional T1 interfaces, configuring [7-7 to 7-8](#)
Frame Relay for VoIP
 configuring [6-69](#)
 example [6-70](#)
FXO
 configuring [6-55](#)
 described [6-38](#)
FXS
 configuring [6-44, 7-30, 7-33, 7-34](#)
 described [6-38](#)

G

G.711 [6-15](#)
G.723.1 [6-15](#)
G.726 [6-16](#)
G.729 [6-16](#)
G.729a [6-16](#)
Gigabit cascade configuration [4-41 to 4-43](#)

grounding
 chassis [2-12](#)
 configurations [3-15 to 3-17](#)
 lug, location (illustration) [3-18](#)
 procedure [3-18 to 3-19](#)
 receptacles [2-9](#)
 third-wire [2-11](#)
ground start [6-62](#)
guidelines
 installation [2-25 to 2-28](#)
 power supply [3-11 to 3-14](#)

H

H.323 [6-85 to 6-87](#)
hardware
 cards [1-4 to 1-6](#)
 components [1-2](#)
 system configuration (illustration) [1-3](#)
high-complexity DSP software images [6-14, C-1](#)
host name
 changing [5-22 to 5-28](#)
 guidelines [5-22](#)
 updating SQL Server with [5-24 to 5-28](#)
humidity [2-12](#)

- ICSConfig
 - accessing 5-4
 - collecting information for 4-2 to 4-5
 - description 5-2
 - PC requirements 2-18
 - running 4-11 to 4-31
 - saving configuration 4-29
 - tasks 5-17, 6-2
- ICS System Manager
 - See* System Manager
- immediate start 6-61
- information required for initial configuration 4-2 to 4-5
- initial configuration program
 - See* ICSConfig
- installation
 - cooling guidelines 2-7
 - floor loading 2-8
 - guidelines 2-25 to 2-28
 - placement guidelines 2-7
 - power and grounding 2-8 to 2-12
 - safety warnings 2-2 to 2-3
 - verifying 3-34
 - weight distribution in rack 2-8
- installing system software
 - CCO, using 8-22 to 8-24
 - CD-ROM, using 8-20 to 8-21
 - scenarios 8-19 to 8-20
- Internet Explorer, configuring 4-8 to 4-9
- IOS
 - best practices 5-17, 6-2
 - documentation xxv
 - software release on ASI, MRP, or SSP cards, determining with CLI 5-11
 - software release on SSP card, determining with System Manager 5-7
 - upgrading images using ICS System Manager 8-25 to 8-26
 - upgrading images using the CLI 8-26 to 8-27
 - versions preinstalled 1-8
- IP address
 - changing 4-13, 4-15
 - default gateway 4-17
 - DNS, primary 4-17
 - PC, configuring 4-6 to 4-7
 - pool for IP phones 4-16
 - pool for system cards 4-14
 - SPE, determining 5-21
 - TFTP server 4-16, 6-123
 - WINS server 4-17
- IP Phones, documentation xxiii
- IP phones, IP address 4-16
- ISDN
 - configuring for voice 6-64 to 6-68
 - switch types 6-66

ISDN BRI

- configuring interface [7-5 to 7-6](#)
- configuring interfaces [6-30](#)
- description [6-38, 6-64](#)

ISDN PRI

- configuring voice interfaces [6-67 to 6-68](#)
- description [6-65](#)

ISDN signaling backhaul, configuring on MGCP [6-106 to 6-111](#)**ISDN switch types [6-31](#)**

K**key, product**

See product key

L**LEDs, verifying installation with [3-34](#)****lighting [2-13](#)****line filter [2-10](#)****login password [4-21](#)**

M**maximum transmission unit**

See MTU

Media Gateway Control Protocol

See MGCP

medium-complexity DSP software images [6-14, C-1](#)**memory modules, removing and replacing [8-3](#)****MFT-T1 CAS**

- configuring [6-60](#)
- description [6-39](#)
- signaling systems [6-61](#)

MGCP

- application command [6-94, 6-98](#)
- blocking new calls [6-112](#)
- CallManager, configuring for use with [6-100 to 6-101](#)
- ccm-manager MGCP command [6-100](#)
- ccm-manager redundant host command [6-100](#)
- ccm-manager switchback command [6-101](#)
- ccm-manager switchover-to-backup command [6-101](#)
- command settings [6-115](#)
- configuring [6-91 to 6-115](#)
- controller t1 command [6-93](#)
- description [6-87 to 6-89](#)
- dial-peer voice command [6-94, 6-98](#)
- download of information from CallManager [6-102 to 6-103](#)
- ds0-group command [6-94](#)
- fax over IP, configuration of [6-112 to 6-115](#)
- gateway types supported [6-89](#)
- ISDN PRI backhaul, description of [6-89](#)
- ISDN signaling backhaul, configuring on [6-106 to 6-111](#)
- mgcp block-newcalls command [6-112](#)

- mgcp call-agent command [6-93, 6-98](#)
- mgcp command [6-93, 6-98](#)
- mgcp default-package command [6-96, 6-99](#)
- mgcp dtmf-relay command [6-96](#)
- mgcp package-capability command [6-95, 6-99](#)
- mgcp restart-delay command [6-95](#)
- mgcp sdp simple command [6-96, 6-100](#)
- multicast music-on-hold
 - description [6-90](#)
 - enabling [6-115](#)
- RGW, configuring [6-97 to 6-100](#)
- sample configuration [7-9 to 7-28](#)
- T1 CAS, configuring for [6-103 to 6-106](#)
- TGW, configuring [6-93 to 6-97](#)
- mgcp block-newcalls command [6-112](#)
- mgcp call-agent command [6-93, 6-98](#)
- mgcp command [6-93](#)
- mgcp command, in MGCP [6-98](#)
- mgcp default-package command [6-96, 6-99](#)
- mgcp dtmf-relay command [6-96](#)
- mgcp package-capability command [6-95, 6-99](#)
- mgcp restart-delay command [6-95](#)
- mgcp sdp simple command [6-96, 6-100](#)
- MIB, SNMP [5-3](#)
- Microsoft SQL Server
 - host name, recognizing new on SPE310 [5-24 to 5-28](#)
- modem
 - connecting [4-45 to 4-51](#)
 - data compression setting [4-48](#)
 - dial-up connection, testing [4-51](#)
 - error correction setting [4-48](#)
 - initialization string [4-46](#)
 - initializing for an SAP card [4-48](#)
- MOH [6-123](#)
- Monitor, in System Manager [5-6](#)
- monitoring tools, System Manager [5-6](#)
- mounting the system
 - in a rack [3-4 to 3-5](#)
 - on a desktop [3-6 to 3-10](#)
- MRP
 - saving configuration [6-4](#)
 - supported WICs and VICs [6-13](#)
- MRP200 card [1-4](#)
- MRP300 card [1-4](#)
- MRP3-16FXS card [1-5](#)
- MRP3-8FXS card [1-5](#)
- MRP card
 - accessing, using CLI [5-11](#)
 - codec options [6-14](#)
 - connections [3-28](#)
 - default DSP software images [C-1](#)
 - DSP, requirements for [6-14](#)
 - features [6-12, 6-13](#)
 - MRP3-16FXS, PVDM requirements [C-3](#)
 - PVDM requirements (table) [C-3 to C-16](#)
 - removing and replacing [8-2](#)
 - setting date and time [6-5 to 6-8](#)
- MTU [6-69](#)

multicast music-on-hold
 description [6-90](#)
 enabling [6-115](#)
 multilink PPP Interleaving [6-75](#)
 music on hold
See MOH

N

Netscape Communicator, configuring [4-7](#)
 network management, third-party
 applications [6-144](#)
 Network Time Protocol
See NTP
 noise, power [2-10](#)
 note, described [xxii](#)
 NTP [6-130](#)
 number expansion
 command [6-41](#)
 configuring [7-30](#)
 table [6-42](#)

O

organization, document [xx](#)

P

packet filter
 defined [6-117](#)
 setting up [6-117](#)
 packet voice data module
See PVDM
 pager number [4-27](#)
 password
 CallManager DC Directory Administrator
 account [4-36](#)
 CCMAAdmin account [4-39](#)
 enable [4-21](#)
 login [4-21](#)
 rules [4-20](#)
 SQL server SA account [4-40](#)
 System Manager admin [4-24](#)
 Windows 2000 administrator [4-22](#)
 PC, IP address for [4-6 to 4-7](#)
 PC requirements [2-18](#)
 peripheral equipment, documentation
 (table) [2-25](#)
 permanent virtual circuit
See PVC
 planning cable installation [2-14](#)
 ports, number per card [1-4 to 1-6](#)
 POTS dial peer [6-46](#)

power

- circuit protection [2-9](#)
- configuration with five Catalyst switches (illustration) [3-12](#)
- connecting [3-32 to 3-33](#)
- fluctuation [2-11](#)
- outage [2-11](#)
- reasons for outages [2-11](#)
- recommended configuration [3-11 to 3-12, 3-32](#)

power and grounding [2-8 to 2-12](#)

power consumption, system [B-1 to B-4](#)

power cord [2-13](#)

power spike [2-9](#)

power strip [2-11](#)

power supply

- backup [1-7](#)
- configurations (table) [3-13 to 3-14](#)
- guidelines [3-11 to 3-14](#)
- location in chassis [1-6](#)

power supply, backup, documentation [xxiv](#)

power surge [2-9](#)

power transient [2-10](#)

product key, CallManager [4-33](#)

propagation delay [6-17](#)

publications

- See* documentation

publisher, CallManager [4-32, 4-35](#)

PVC [6-69](#)

PVDM

- DSP groups and [6-18](#)
- requirements on ASI160 and MRP3-16FXS cards [C-3](#)
- requirements on ASI and MRP cards (table) [C-3 to C-16](#)

Q

QoS

- description [6-71](#)
- tools
 - custom queuing [6-72](#)
 - listed [6-72](#)
 - multilink PPP Interleaving [6-75](#)
 - RSVP [6-73](#)
 - RTP header compression [6-76](#)
 - weighted fair queuing [6-73](#)

Quality of Service

- See* QoS

R

- rack mounting [3-4 to 3-5](#)
- Random Early Detection
 - See* RED
- Real-Time Transport Protocol
 - See* RTP
- receptacles [2-9](#)
- RED [6-71](#)

- redundant power supply
 - See* RPS 300
 - regulatory compliance [2-28](#)
 - remote System Manager dial-up [8-4 to 8-6](#)
 - removing
 - memory, DSP, and VPN modules [8-3](#)
 - MRP and ASI cards [8-2](#)
 - SPE310 cards [8-2](#)
 - required tools [2-17](#)
 - requirements, environmental [2-12](#)
 - residential gateway
 - See* RGW
 - Resource Reservation Protocol
 - See* RSVP
 - restoring system data [8-7 to 8-18](#)
 - RGW, configuring [6-97 to 6-100](#)
 - routing, wire [2-16](#)
 - RPS 300 [1-7, 2-10, 3-32](#)
 - RSVP
 - configuring for voice [6-73](#)
 - enabling [6-74](#)
 - RTP [6-76](#)
-
- S
- SA account password [4-40](#)
 - safety standards [2-28](#)
 - SAP card
 - accessing [5-12 to 5-14](#)
 - connecting legacy voice mail system [3-30](#)
 - connecting to the console port [3-29](#)
 - connections to COM ports [3-30](#)
 - connection to UPS [3-30](#)
 - definition [1-6](#)
 - initializing the modem [4-48](#)
 - remote access to System Manager [3-31](#)
 - saving configuration [6-4](#)
 - scenarios, TDM clocking [6-79 to 6-85, 7-46 to 7-58](#)
 - security
 - considerations [6-115](#)
 - firewall [6-116](#)
 - setting privileges [5-34](#)
 - Security, in System Manager [5-6](#)
 - serial interfaces, configuring [7-3 to 7-5](#)
 - serialization delay [6-17](#)
 - shutting down the system [5-35 to 5-36](#)
 - signaling types
 - E&M [6-38](#)
 - E1 PRI [6-39](#)
 - FXS/FXO [6-38](#)
 - ISDN BRI [6-38](#)
 - MFT-T1 CAS [6-39](#)
 - T1 PRI [6-39](#)
 - SMTP server [4-26](#)

- SNMP
 - community strings [4-21](#)
 - configuring [4-21](#)
 - MIB [5-3](#)
- Software Upgrade, in System Manager [5-6](#)
- SPE310 card
 - accessing [5-10](#)
 - accessing with Terminal Services Client [5-9](#)
 - definition [1-4](#)
- SPE310 cards
 - removing and replacing [8-2](#)
 - restoring data [8-7 to 8-18](#)
 - setting date and time [6-5](#)
- SPE310 running System Manager, changing
 - host name [5-22 to 5-28](#)
- SPE card
 - determining IP address [5-21](#)
 - lithium battery warning [2-3](#)
- spoofing [6-121](#)
- SQL Server
 - host name, recognizing new on SPE310 [5-24 to 5-28](#)
- SQL server
 - SA account password [4-40](#)
- SSP
 - configuring [6-10](#)
 - features [6-9](#)
 - overview [6-8](#)
- SSP card
 - accessing, using CLI [5-11](#)
 - connections [3-29](#)
 - definition [1-6](#)
- SSP Manager, in System Manager [5-5](#)
- stacking Catalyst switches [3-8 to 3-10](#)
- star-wired switch configuration [4-43 to 4-45](#)
- static electricity, effects of [2-12](#)
- subscriber, CallManager [4-32, 4-35](#)
- sunlight, effects of [2-13](#)
- surge suppressor [2-11](#)
- switches [1-7](#)
- switch types, ISDN [6-31, 6-66](#)
- syslog server [4-28](#)
- system, power consumption [B-1 to B-4](#)
- system cards, in which slots to install [2-27](#)
- system cards, IP address [4-14](#)
- system data, backing up [5-28 to 5-33](#)
- system hardware configuration illustration [1-3](#)
- System Maintenance, in System Manager [5-6](#)
- System Manager
 - accessing [5-5](#)
 - best practices [5-17, 6-2 to 6-3](#)
 - configuring for remote dial-up [8-4 to 8-6](#)
 - definition [5-2](#)
 - determining version of [5-7](#)
 - navigating in [5-5](#)
 - restoring data [8-7 to 8-18](#)
 - using to determine IOS software release on SSP card [5-7](#)

System Manager admin password [4-24](#)
System Manager software, remote access to [3-31](#)
System Setup, in System Manager [5-5](#)
system software
 installing from CCO [8-22 to 8-24](#)
 installing from CD-ROM [8-20 to 8-21](#)
 media options [8-20](#)
 upgrade and installation scenarios [8-19 to 8-20](#)

T

T1

See MFT-T1 CAS, MFT-T1 WIC, T1 (FT1) WIC

T1 (FT1) WIC [6-34, 7-7](#)

T1 CAS, configuring for MGCP [6-103 to 6-106](#)

T1 interfaces, configuring [7-7 to 7-8](#)

T1 PRI [6-39](#)

T1 VIC, connection [3-28](#)

T1 VWIC, connection [3-28](#)

T1 VWIC interfaces, configuring [7-8 to 7-9](#)

T1 WIC, connection [3-28](#)

TDM clock

 configuring [6-35](#)

 scenarios [6-79 to 6-85, 7-46 to 7-58](#)

Telnet, accessing SPE310s with [5-11](#)

temperature [2-12](#)

terminal emulation interfaces [5-3](#)

Terminal Services Client

 accessing SPE310 cards with [5-9](#)

 download [5-3](#)

 installing [4-9](#)

 use of on the ICS 7750 [5-3](#)

TFTP server, IP address [4-16, 6-123](#)

TGW, configuring [6-93 to 6-97](#)

third-wire ground [2-11](#)

time

 setting on MRP and ASI cards [6-5 to 6-8](#)

 setting on SPE310 cards [6-5](#)

tools, required [2-17](#)

traffic shaping in Frame Relay [6-70](#)

transcoding [6-24](#)

 choosing DSP firmware for [6-25](#)

 deciding when to use [6-24](#)

 determining how many DSPs are needed for [6-26](#)

 understanding DSP usage for [6-26](#)

transient suppressor [2-11](#)

trunking gateway

See TGW

turning on the system [3-32 to 3-33](#)

U

uninterruptible power supply

See UPS

unpacking, box [2-21](#)

- upgrading
 - IOS images using ICS System Manager [8-25 to 8-26](#)
 - IOS images using the CLI [8-26 to 8-27](#)
 - upgrading system software
 - CCO, using [8-22 to 8-24](#)
 - CD-ROM, using [8-20 to 8-21](#)
 - scenarios [8-19 to 8-20](#)
 - UPS
 - connecting to SAP card [3-30](#)
 - described [1-6](#)
 - purpose [2-10](#)
 - recommended power configuration [3-32](#)
-
- V
- verifying box contents [2-23](#)
 - verifying system installation [3-34](#)
 - vibration [2-12](#)
 - VIC
 - configuring
 - E&M [6-57](#)
 - FXO [6-55](#)
 - FXS [6-44, 7-30, 7-33, 7-34](#)
 - MFT-T1 CAS [6-60](#)
 - connecting to PSTN [6-39](#)
 - connection [3-28](#)
 - description [6-38](#)
 - documentation [xxiv](#)
 - supported on MRP [6-13](#)
 - voice interface card
 - See* VIC
 - voice mail
 - direct serial connection [6-132 to 6-137](#)
 - legacy system, connecting to SAP card [3-30](#)
 - voice ports
 - E&M
 - configuring [6-57](#)
 - described [6-38](#)
 - E1 PRI [6-39](#)
 - FXO
 - configuring [6-55](#)
 - description [6-38](#)
 - FXS
 - configuring [6-44, 7-30, 7-33, 7-34](#)
 - description [6-38](#)
 - ISDN BRI [6-38](#)
 - MFT-T1 CAS
 - configuring [6-60](#)
 - description [6-39](#)
 - T1 PRI [6-39](#)
 - voice WAN interface card
 - See* VWIC
 - VoIP, Frame Relay, configuring for [6-69](#)
 - VoIP dial peer [6-50](#)
 - VPN modules, removing and replacing [8-3](#)

VWIC

- connection [3-28](#)
- documentation [xxiv](#)
- types of

W

WAN interface card

See WIC

- web browser, configuring [4-7 to 4-9](#)
- weight distribution [2-8](#)
- weighted fair queuing [6-73](#)
- Weighted Random Early Detection [6-71](#)
 - See* WRED

WIC

- configuring
 - asynchronous/synchronous serial [6-28, 7-3](#)
 - ISDN BRI [6-30](#)
 - T1 (FT1) [6-34, 7-7](#)
 - connection [3-28](#)
 - documentation [xxiv](#)
 - supported on MRP [6-13](#)
- Windows 2000 interface, accessing SPE310
 - Windows 2000 interface [5-10](#)
- wink start [6-61](#)
- WINS server, IP address [4-17](#)
- wire routing [2-16](#)
- WRED [6-71](#)