



Spare Parts Lists

This chapter contains tables that list the spare parts for the VCO/4K system (contact your Cisco Systems sales representative for current assembly numbers and prices):

- Table 4-1 lists the System Spares Kit and kit replacement parts.
- Table 4-2 lists the Power Subsystem spare parts.
- Table 4-3 lists the port interface and service circuit card spares.
- Table 4-4 list the miscellaneous spare parts.

Table 4-1 System Spares Kit and Replacement Parts

System Controller Spares	Assembly Number	Quantity ¹
System Spares Kit		1
System Spares Kit Contents (quantity)		
CPU ¹		
SWI/Floppy/Carrier Assembly ¹		
Storage/Control I/O Module ¹		
Alarm Arbiter Card (AAC) ¹		
Network Bus Controller 3 (NBC3) ¹		
Digital Tone Generator 2 (DTG-2) ¹		

1. Typically order one per system.

Table 4-2 Power Subsystem Spare Parts

Power Subsystem Spare Parts	Assembly Number	Quantity
-48 VDC Power Supply Module		
120 VAC Power Supply Module		

Table 4-3 Network Interface and Service Circuit Card Spares

Variable Item Spares	Quantity	Assembly Number
Interface Controller Card (ICC) with 16 Span T1 I/O Module		
Interface Controller Card (ICC) with 8 Span T1 I/O Module		
Interface Controller Card (ICC) with 4 Span T1 I/O Module		
Interface Controller Card (ICC) with 16 Span E1 I/O Module		
Interface Controller Card (ICC) with 8 Span E1 I/O Module		
Interface Controller Card (ICC) with 4 Span E1 I/O Module		
IPRC (8 port)		
IPRC (64 port)		
IPRC (128 port)		
Subrate Switch Card (SSC)		
Service Platform Card (SPC)		
Service Resource Module (SRM)		
D+I Card		

Table 4-4 Miscellaneous Spare Parts

Power Subsystem Spare Parts	Assembly Number	Quantity
Fan Unit		
Spare Fuse Kit (AC or DC)		
Ring Generator (optional)		

