



## Card Error Messages

---

### Card Error Messages

Table A-1 shows the object identifiers for the respective ErrorStatus objects.

*Table A-1 Card Error Messages*

Object Name	Object Identifier
lcErrorStatus	1.3.6.1.4.1.886.1.2.1.1.11
tcErrorStatus	1.3.6.1.4.1.886.1.3.1.1.13
ptcErrorStatus	1.3.6.1.4.1.886.1.4.1.1.27
isdnErrorStatus	1.3.6.1.4.1.886.1.5.1.1.42
nbcErrorStatus	1.3.6.1.4.1.886.1.6.4.1.10
dtgCardErrorStatus	1.3.6.1.4.1.886.1.7.1.1.11
rcErrorStatus	1.3.6.1.4.1.886.1.7.6.1.11

### Message Listing

Table A-2 shows the meanings for the error message values.

*Table A-2 Message Listing*

Value	Message
256	Invalid Operation Specified
257	Card Already Exists
260	Invalid Port
262	NBC and BRC Do Not Have Ports
263	NBC in 1-1-1 for A-side 1-1-2 for B side
264	Cannot Add NBC in Non-redundant System
265	Only NBC In This Slot
266	Only BRC In Slot One of Expansion Rack
267	ISDN Not Installed
268	No Available Port Memory
269	BRC Cannot Be Added to 1-1-1
270	Invalid BRC Rack Level Slot Position
272	Invalid Card Type
273	Cannot Be Put Into Diagnostic
274	Card Does Not Support Remote Loopback
275	Cannot Be Put Into Maintenance
276	This Card Is Not Out Of Service
277	Card Must Be Active, Diag or Campon
278	Invalid Status Change Request
280	Can't Change Status of NBC
282	Card Already Active
283	Download In Progress On This Card
284	An Alarm Exists On This Card
285	No Standby DTG, Cannot Change State
286	Ports Active—Put in Campon
287	Card Must Be Active, Maint Or Campon
289	Ports Still In Resource Group # <sup>1</sup>
290	Ports Still Active—Left in Campon
292	No Standby BRC pair, Cannot Change State
296	No Available Card Memory
299	Card Does Not Support Payload Loopback
305	Span Must Be Active, Diag or Campon
306	Span Must Be Active, Maint or Campon
308	Exceeded Time-Slot Capacity
309	Standby Capacity is Zero
310	Invalid card location

*Table A-2 Message Listing (continued)*

Value	Message
2560	Invalid card status specified
2561	Card already in the status specified
2562	Code download in progress
2563	Alarms exist for the card
2564	No standby BRC card
2565	Only one dtg card exists in the system
2566	Card is in Out Of Service, Must be in Active or Maint, Diag
2567	Card must be in Active or Maintenance state

1. This number symbol (#) is replaced by the group number.

