Loading the Cisco BBSM Hotspot 1.0 Image

The BBSM Hotspot Version 1.0 Recovery CD contains an image that can be used only with the BBSM Hotpot 1.0 server.

⚠
Caution   Loading this image onto any other hardware platform will render the system inoperable. This CD will erase all data on the server and revert the server to its default state.

Loading the Image

Use this procedure to load the BBSM Hotspot 1.0 image onto your server:

Step 1   Insert the BBSM Hotspot Version 1.0 Recovery CD into the CD-ROM drive.

Step 2   Reboot the server.

Your system boots up to the *You have booted the BBSM Hotspot 1.0 Image CD for the HP/Compaq Evo D51S server, Dated 1-3-2003* screen.

Step 3   Press **Enter**. The autoload procedure begins.

Wait approximately seven minutes for the image to be loaded on the server.

Step 4   From the *Imaging is now complete!* screen, remove the CD and reboot the server again.

After you load the image, the BBSM Hotspot 1.0 server is ready to be configured.

Related Documentation

This document provides information about the BBSM Hotspot:

- *Cisco BBSM Hotspot 1.0 User Guide* (order number DOC-7815293=)

CISCO SYSTEMS

Corporate Headquarters:
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

This document is to be used in conjunction with the documents listed in the "Related Documentation" section.