

Numerics

- 100BASE-FX 23, 115
- 100BASE-T 23, 115
- 100BASE-TX 23, 115
- 10BaseT 133
- 16 Mbps LED on TRIP
 - See LEDs
- 16-bit CRC
 - See CRC 247
- 4 Mbps LED on TRIP
 - See LEDs

A

- AC Power LED on power supply
 - See LEDs
- AC power, input 67
- acronyms, definition of 59
- active monitor in Token Ring network 138
- addresses, ports 97
- agency approvals 63
- AIP
 - cable connections 169
 - LEDs 308
 - microcode ROM replacement 210
- air
 - cooling 63
 - dam 63
 - exhaust 105
 - filter
 - and environmental monitor 105
 - cleaning 277
 - flow 62, 68
- AMD SuperNet chipset 88
- ANSI X3.1 88
- ANSI X3.1 standard 141
- arbiter
 - replacing 286
- arbiter board 286
- arbiter, description of 63, 65
- arbitration, CxBus 63
- Asynchronous Transfer Mode (ATM) Interface Processor
 - See AIP
- attachment unit interface
 - See AUI
- AUI
 - connector pinouts 290
 - EIP ports 85
- autoreconfiguration in Token Ring network 138
- auxiliary port 149
 - pinouts 290
- auxiliary port, description 73

B

- backplane
 - description 63
 - interface processor connections 202
 - slot keys 65
 - speed 62
- back-up batteries 72
- batteries, lithium backup 72
- baud-rate settings 222
- beaconing on ring network 138
- blower
 - air flow path (illustration) 63
 - and environmental monitor 104
 - description 68
 - noise 196
 - replacing 282
- boot command 214
- Boot Error LED on RP
 - See LEDs
- boot filenames 215
- boot system flash command 35, 192
- boot-load failure 216
- bootload-failure response 222
- Break key (interrupt) 221
- broadcast address destination, configuration register
 - settings 222
- broadcast address, setting 216
- burn in 195
- bus
 - arbitration 63
 - CxBus 16, 59
 - traffic control 65
- bypass switch, optical for FDDI 140

C

- CAB-ATM-DS3/E3 170
- cable
 - MIP 144
- cables
 - 100BASE-T 23, 115
 - AC power 67
 - attaching
 - FEIP 27, 173
 - avoiding crossing 168
 - connecting external 168
 - console 126
 - console port 290
 - distance limitations 114
 - E1-G.703/G.704 146
 - Ethernet transceiver 290
 - Fast Ethernet specifications 23, 115

- FEIP 25, 135
- guidelines 168
- hazardous 112
- interference 114
- lobe (Token Ring) 136
- MII and RJ-45, FEIP 25, 135
- MII specifications 23, 115
- optical bypass 293
- patch (Token Ring) 136
- power 269
- retention clip, power 269
- strain relief 210
- swapping power 198
- Token Ring 292
- ungrounded 112
- uninsulated 112
- captive installation screws
 - for ESD prevention 112
 - interface processors 200, 207
 - power supply 66, 272
- caution
 - description lvii
 - EMI filter clip 128, 130
 - hanging the router 218
 - reset switch 51, 307
- Channel Interface Processir
 - See CIP
- chassis
 - clearance 105
 - dimensions 62
 - front panel 60
 - internal components 63, 278
 - lifting 110
 - panels, removing 273
 - physical specifications 62
 - rear view (illustration) 61
 - top-down view (illustration) 64
 - warning against stacking 63
- checklist, installation 155
- CIP
 - LEDs 309
 - microcode ROM replacement 210
- Cisco Extended Bus
 - See CxBus
- cleaning the air filter 277
- clearance, chassis 105
- clock
 - acceptable rates 246
 - arbiter 65
- clockrate command 246
- Collision LED on EIP
 - See LEDs
- commands
 - b (boot) 220
 - boot 214
 - boot system 221, 225
 - boot system flash 222
 - boot system flash filename 35, 192, 222
 - Break (interrupt) 221
 - clockrate 246
 - config-register 35, 192, 219, 221, 222, 225
 - configure 208
 - configure terminal 219, 221, 225
 - copy 33, 190
 - crc32 248
 - early token release 139
 - enable 219, 225
 - Flash-related 220
 - i (initialize) 224
 - invert-transmit-clock 246
 - microcode card rom 211
 - microcode reload 212
 - nrzi encoding 247, 248
 - o/r (reset) 224
 - reload 220
 - ring-speed 139
 - setup 208
 - show configuration 224
 - show controller 208, 211
 - show controller cxbus 249
 - show environment 105, 125
 - show interfaces 99, 208
 - show version 220, 224
- concentrator 143
- config-register command 35, 192
- configuration
 - register
 - boot field 220
- configuration notes, description of 201
- configuration register, description 213
- configuration worksheet 153, 168
- configure command 208
- Conn LED on FSIP
 - See LEDs
- Conn LED on SIP
 - See LEDs
- connector 291
 - auxiliary port 290
 - console port 290
 - DB-9 87
 - DIN 140
 - Ethernet 290
 - FC 88
 - MIC 88
 - MII and RJ-45 25, 135
 - mini-DIN 89, 293
 - optical bypass switch 293
 - RS-232 93, 294
 - RS-449 93, 295
 - Token Ring 292

- TRIP 292
- V.35 93, 297
- X.21 93
- console
 - cable 126
 - terminal 197
- console port 149, 290
 - baud rate 216
 - description 73
 - pinouts 290
 - settings 222
- conventions
 - See document conventions
- cooling subsystem 196
- copy command 33, 190
- copying to Flash 223
- copying to Flash memory 193
- CPU
 - FSIP 89
 - system 197
- CPU Halt LED on RP
 - See LEDs
- CRC
 - configuring 247
 - description of 147
- crc32 command 248
- Critical status level, environmental monitor 104
- CSU 127
- current rating, chassis 62
- CxBus 16, 59
 - arbitration 63
- Cyclic Redundancy Check
 - see CRC

D

- damage from overheating 103
- danger, warning
 - description lvii
- DAS
 - description 141
- DB-9 connector 87
- DC Fail LED on power supply
 - See LEDs
- DC power 104
 - and environmental monitor 104
 - voltages 195
- DCE
 - clock signals 246
 - devices 181
- debug commands 216
- dimensions
 - chassis 62
 - interface processors 80

- DIN connector 293
- displays, environmental 105
- document conventions lvii
- downloadable microcode 209
- downloadable microcode, description of 101
- DRAM 70
- DSU 127, 181
- DTE
 - devices 181
- dual attachment stations
 - See DAS
- dual homing
 - description 143
- dual ring
 - description 141
- dual-attached station 88, 313
- dust 277

E

- E1-G.703/G.704
 - cables 146
- early token release 138
- early token release command 139
- EIA 310C 63
- EIP
 - description of 85
 - LEDs 311
 - microcode ROM replacement 210
 - port signals 290
 - speed 80
- ejector levers 200
 - description 62
- electromagnetic pulse (EMP), avoiding 114
- electrostatic discharge 113
- EMI filter clip, AIP 170
- enable command 225
- Enabled LED on interface processors 81
- enabled LED on interface processors 196
 - See LEDs
- environmental monitor description 103
- EPROM 70
- error correction, CRC 148
- ESD prevention 113
- Ethernet 115
 - AUI connector pinouts 290
 - AUI port signals 290
 - cables 290
 - connector locks 134
 - ports on EIP 85
 - transceiver 85, 127, 133, 207
- Ethernet interface processor
 - See EIP
- example of port addresses 98

examples
 copying
 images to a Flash memory card 33, 190
 ring-speed command 174
exhaust air 105

F

faceplates 200
factory burn in 195
failure
 AC source 104, 304
 boot-load 216
 power supply, DC section 304
Fast Ethernet Interface Processor
 See FEIP
fast serial interface processor
 See FSIP
fault management
 Token Ring 138
FC connector 88
FCS, and CRC 247
FDDI
 FIP description 88
 interface processor
 See FIP
 optical bypass switch 293
FEIP
 cable attachment 27, 173
 cables and connectors 25, 135
 LEDs 52, 312
 microcode EPROM location 37, 210
 pinouts 50, 291
 product numbers and descriptions 22, 86
 See also Fast Ethernet
field-replaceable unit
 See FRU
filenames, netbooting 221
filler, interface processor 207
filter, air 105
filter, avoiding wet 277
FIP
 description of 88
 LEDs 312
 microcode ROM replacement 210
 mini-DIN signals 293
 speed 80
Flash
 copying to 223
 downloading images into 16, 72
 loading microcode from 212
 write protect jumper 212
 write-protection 217
Flash memory

 copying files 33, 190
 copying to 193
 formatting a new PCMCIA card 189
formatting a new PCMCIA card 189
frame check sequence 247
frequency, specifications 62
front panel
 description of 60
 LEDs 60
FRU
 definition of 59
FRUs 286
FSIP
 description of 89
 interface pinouts 293
 LEDs 315
 modes, description 90
 speed 80

G

gravity, maintaining low center 62, 123
guides, backplane slot keys 64

H

Halt LED on RP 73
handles
 interface processors 112, 207
heat dissipation 62
High-Level Data Link Control (HDLC) 127
high-speed serial interface processor
 See HIP
HIP
 LEDs 317
 microcode ROM replacement 210
 speed 81
HSSI
 cable pinouts 300
 LEDs 317
HSSI interface processor
 See HIP
humidity, specifications 63

I

i command (initialize and reboot) 224
IBM
 and NRZI format 147
 Token Ring network, description 136
IBM, chipset on TRIP 87

IEEE
 802.3u 23, 115
IEEE 802.3
 and EIP 85
IEEE 802.5
 and TRIP 136
 specification 136
images, downloading 16, 72, 208
In Ring LED on TRIP
 See LEDs
injury
 avoiding 110
inlet air 108
installation checklist 155
interface
 configuration 195
interface processors
 carriers 206
 configuration 202
 description of 80
 dimensions 80
 enabled LED 308
 installation 202
 LEDs 81
 slot keys 65
 troubleshooting 199
interface types supported 61
interlock, power supply 66, 163, 270
intermittent powerfails 105, 106
inverted clock 246
invert-transmit-clock command 246
ISO 9314 88

J

jackscrews
 FEIP MII connector 25, 135
jewelry, avoiding for safety 110

K

key, Break (interrupt) 221
keys, backplane slots 65

L

label, chassis serial number 195
laser radiation 168
last, show environment 106
LED board
 replacing 278

LEDs
 AIP 308
 Boot Error 306
 CIP 309
 CPU Halt 306
 DC Fail 304
 EIP 85, 311
 Enabled on interface processors 81
 FEIP 52, 312
 FIP 89, 312
 FSIP 91, 315
 HIP 317
 interface processor 81
 interface processor enabled 308
 MII, link, and RJ-45 53, 312
 MIP 318
 Normal on power supply 303
 PCMCIA slots 1 and 2 51, 307
 power supply 66, 197, 304
 RP 73, 197, 306
 serial ports 315
 system 60, 303
 TRIP 87, 319
 Upper Power 60
levels, status for environmental monitor 104
lifting the chassis 110
lightning storm, safety during 112
Link LED 53, 312
load sharing, power 62
lobe cables, Token Ring 136
locked blocks
 recovering 36, 193
log, environmental 105
Lower Power LED on power supply
 See LEDs

M

MAU 127
 EIP interface to 85
 TRIP interface to 88, 292
maximum configurations 97
maximum distance limitatians 115
memory
 system 70
memory, Flash
 See Flash
messages, environmental 105
MIC connector 88
microcode
 and troubleshooting 197
 ROM replacement 210
 specifying file to load 211
microcode card rom command 211

microcode reload command 212
microcode, downloadable 81, 101

MII

cable attachment 27, 173
cable specifications 24, 115
connections, FEIP 25, 135
LED 53, 312
pinouts 50, 291

mini-DIN connector 89, 140

MIP

cables 144
LEDs 318
microcode ROM replacement 210
speed 81

modem 127

MSAU, description 136

MultiChannel Interface Processor

See MIP

multimode FIP

description 88

multistation access unit

See MSAU

N

neighbors, upstream and downstream 142

netbooting 220

noise

blower 196

Normal LED

See LEDs

Normal LED on RP

See LEDs

Normal status level, environmental monitor 104, 106

note

description lvii

NRZI encoding 245

NRZI Format

description 147

NRZI format

configuring 247

nrzi-encoding command 247, 248

null modem cable

pinouts 300

numbers, port 98

NVRAM 70

description of 72

log 104

O

o/r command (reset) 224

OIR

functional description 100

interface processor support 80

onscreen messages during 208

overview 202

screen displays during 208

online insertion and removal

See OIR

operating conditions

for chassis 63

operating temperature 62

optical bypass cable 89

optical bypass switch

cable pinouts 293

functional description 143

out-of-tolerance condition 104, 304

overheating

preventing 63

overtemperature conditions 195

P

password, recovering 224

patch cables, Token Ring 136

PCMCIA

formatting a new card 32, 189

PHY A/B LEDs on FIP

See LEDs

PHY, description 141

physical port addresses 98

physical sublayer

See PHY

pinouts

FEIP 50, 291

port

addresses 97

auxiliary 73, 149

console 73, 149

densities 97

EIP 290

Ethernet 290

RS-232 93, 294

RS-449 93, 295

Token Ring 291

V.35 93, 297

X.21 93

port adapter cables

pinouts 293

port adapters

description of 92, 140

installation 250

power

+24V DC line 104

cord 67, 110, 198

- DC status 104
- disabled 104
- emergency switch 112
- loss 304
- normal startup sequence 197
- ramp down 104
- redundant, description of 62, 103
- safety 111
- service 169
- site 113
- specifications 62
- subsystem, for troubleshooting 196
- surge suppression 114
- troubleshooting 198
- ungrounded 112
- power factor corrector 62, 113
- power supply
 - active 304
 - and environmental monitor 104
 - bay 60, 61, 163, 198
 - description 66
 - description of 62
 - installation 269
 - LEDs 66, 197, 304
 - removing 270
 - safety interlock 111, 163, 270
 - shutdown 104, 304
 - specifications 62
 - troubleshooting 196
- powerfails 106
- procedures
 - copying to Flash 223
 - copying to Flash memory 193
 - maintenance ?? to 224
 - recovering from a lost password 224
- processor
 - shutdown 104
- processor modules, definition of 62
- protocols 16, 59

R

- radio frequency interference (RFI) 114
- Receive LED on EIP
 - See LEDs
- recovering a lost password 224
- redundant power
 - description of 62
- redundant power, description of 103
- refresh, environmental display 106
- reliability, system 16, 59
- reload command 220
- replaceable system components 201
- reports, environmental 105

- reset switch 51, 307
- ring
 - in Token Ring networks 136
- ring recovery
 - description 142
- rings, primary and secondary 89
- ring-speed command 139
- RJ-45
 - cable attachment 27, 173
 - cable specifications 24, 115
 - connections, FEIP 25, 135
 - LED 53, 312
 - pinouts, FEIP 50, 291
- ROM
 - booting from 213
 - microcode 210
- ROM monitor, system boot 215
- route processor
 - See RP
- RP
 - configuration 202
 - configuring 212
 - description of 68
 - Flash write-protection 217
 - installation 202
 - LEDs 197, 306
 - normal startup 197
 - replacing 212
 - slot key 65
- RS-232
 - cable pinouts 294
 - description 149
 - port 294
 - port adapter 93
 - serial port adapter cable 145
- RS-449
 - cable pinouts 295
 - description 149
 - port adapter 93
 - serial port adapter cable 145
- RS-530
 - cable pinouts 298
 - description 150
 - serial port adapter cable 145
- RxC LED on FSIP
 - See LEDs
- RxD LED on FSIP
 - See LEDs

S

- safety recommendations 110
- SAS
 - description 141

- self-check messages 216
- sensors, temperature 106
- serial
 - port adapters 92
 - ports, LED indications 315
- serial interface processor
 - See FSIP
- serial port adapters
 - description 92
- setup command facility 208
- show controller command 208, 211
- show controller cxbus command 249
- show environment command 105, 125
- show interface command 99
- show interfaces command 99, 208
- shutdown
 - environmental 103
 - power supply 104, 304
 - processor 104
- signal loss with optical bypass 89
- Silicon Switch Processor
 - See SSP
- single attachment stations
 - See SAS
- single-mode FIP
 - description 88
- SIP
 - microcode ROM replacement 210
- site, cabling 114
- slot
 - locations 61
 - numbers 98
- SMDS networks and CRCs 247
- software
 - upgrades 37
- software commands 59
- SP
 - configuration 202
 - description of 78
 - installation 202
 - microcode ROM replacement 210
 - normal startup 197
 - slot key 65
 - troubleshooting 199
- specifications
 - chassis, physical 62
 - Fast Ethernet 23, 115
- SRAM, FSIP 89
- SSP
 - configuration 202
 - installation 202
 - microcode ROM replacement 210
- standards, ISO 9314 88
- startup 196
- statistics, environmental 107

- status
 - environmental 106
 - power supply 67
 - system LEDs 60
- subsystems for troubleshooting 196
- switch
 - reset 51, 307
- switch processor
 - See SP
- switch, optical bypass 89, 140, 293
- system
 - architecture (illustration) 64
 - banner 197
 - boot instructions 213
 - components, descriptions of 63, 153
 - functional overview 97
 - internal components 278
 - LEDs 60, 303
 - lifting 110
 - maximum configurations 97
 - problems at startup 195
 - replaceable components 201
 - upgrades 201

T

- T1 network connections 127
- telephone jacks 112
- temperature
 - internal chassis 103
 - parameters for environmental monitor 108
 - power supply 305
 - sensors 106
 - specifications 63
- thresholds
 - environmental 104
 - shutdown 103
- time saver
 - description lvii
- Token Ring
 - autoreconfiguration 138
 - beaconing 138
 - cable pinouts 292
 - cables 292
 - MAU 136
 - ports 291
- Token Ring interface processor
 - See TRIP
- traffic on CxBus 65
- transceiver
 - Ethernet 85, 133, 290
 - fiber optic 89
- Transmit LED on EIP
 - See LEDs

TRIP
 LEDs 319
 microcode ROM replacement 210
 port signals 291
 speed 80
TxC LED on FSIP
 See LEDs

U

Universal (cable unattached) message 249
upgrades
 microcode 208
upgrades, system 201
Upper Power LED on power supply
 See LEDs

V

V.35
 cable pinouts 297
 description 150
 port adapter 93
 serial port adapter cable 145
vacuuming, air filter 277
virtual configuration register
 functions 218 to 223
voltage
 input 62
 out-of-tolerance condition 104

W

warning
 against stacking the chassis 63
 description lvii
 environmental 108
weight, chassis 62
wiring
 color codes 321
 second scheme 323
 interference 114
 plant 114
 telephone 112
 telephone industry 25-pair color code 321
write-protect, Flash 212

X

X.21
 cable pinouts 51, 296
 description 150
 port adapter 93
 serial port adapter cable 145