

Repacking a Switch

If you need to return or move a Catalyst 2926 or Catalyst 2926G series switch, follow these steps to repack the switch using the original packaging material:

- Step 1** Slide the padding foam over the switch (see Figure D-1).
- Step 2** Place the accessory kit on the top packing material.
- Step 3** Place the outside carton over the entire package.
- Step 4** Fold the outside carton down over the top of the accessory boxes and seal with packing tape.

Figure D-1 **Switch Packing Material**

