

User Interface Commands

This chapter describes the function and displays the syntax of each command used to enter and exit the command modes supported by the Internetwork Operating System (IOS). For more information about defaults and usage guidelines, see the corresponding chapter of the *Router Products Command Reference* publication.

disable

To exit privileged EXEC mode and return to user EXEC mode, enter the **disable** EXEC command.

[no] editing

To enable enhanced editing mode for a particular line, use the **editing** line configuration command. To disable the enhanced editing mode, use the **no** form of this command.

enable

To enter privileged EXEC mode, use the **enable** EXEC command.

end

To exit configuration mode, use the **end** global configuration command.

exit

To exit any command mode or close an active terminal session and terminate the EXEC, use the **exit** command at the system prompt.

full-help

To get help for the full set of user-level commands, use the **full-help** line configuration command.

help

To display a brief description of the help system, enter the **help** command.

[no] history [size *number-of-lines*]

To enable the command history function, or to change the command history buffer size for a particular line, use the **history** line configuration command. To disable the command history feature, use the **no** form of this command.

number-of-lines Number of command lines that the system will record in its history buffer. The range is 0 to 256.

show history

To list the commands you have entered in the current EXEC session, use the **show history** EXEC command.