

## Introduction

This document provides a summary of the commands used by system administrators to configure routers. This book is divided into sections that correspond to the chapters of the *Router Products Command Reference* publication. Within each section the commands are listed in alphabetical order. The table of contents shows the sections in this book; the index lists all the commands in alphabetical order, without regard to the section where they are located. See the *Router Products Command Reference* publication for complete command descriptions and examples.

## Conventions

This document uses the following conventions:

- The symbol ^ and the text Ctrl represent the key labeled *Control*.  
For example, the key combination ^D or Ctrl-D mean hold down the *Control* key while you press the *D* key.
- A string is defined as a nonquoted set of characters.  
For example, when setting up a community string for SNMP to “public,” do not use quotes around the string, or the string will include the quotation marks.

Command descriptions use the following conventions:

- Commands and keywords are in **boldface** font.
- Arguments for which you supply values are in *italic* font.
- Optional elements are shown in square brackets ([ ]); alternative optional elements are separated by vertical bars (|).
- Alternative but required elements are grouped in braces ({ }) and separated by vertical bars (|).

- If the **no** form of a command has exactly the same keywords and arguments as the command, **no** appears in square brackets at the beginning of the command line. If the **no** form of a command does not have all the same keywords and arguments, the **no** form is displayed separately.
- If the **no** form of a command is not explicitly explained in the description, it negates the command.

## EXEC System Use

- Enter commands by typing their names at the EXEC prompt and pressing the Return key.
- There are two EXEC prompt levels. The user-level prompt is the server name followed by a >, as in this example:

```
Router>
```

There is also a privileged-level prompt available to the system administrator by entering a password. It is the server name followed by a #, as in this example:

```
Router#
```

- Use the following editing commands when typing commands at the EXEC prompt:
  - Delete or Backspace to erase characters
  - Ctrl-U to delete a line
- As a shortcut, you can abbreviate commands to the fewest letters that make them unique. The letters “sho” can be entered for the **show** command, for example.
- Certain EXEC commands display multiple screens with this prompt at the bottom of the screen:

```
--More--
```

Press the space bar to continue the output or press Return to display the next line. Press any other key to return to the prompt.

## System Help

You can obtain help when entering commands by using the following methods:

- For a brief description of the context-sensitive help system, type **help**.
- To list all commands for a command mode, enter a question mark (?) at the system prompt.
- To obtain a list of commands that start with a particular character set, enter an abbreviated command immediately followed by a question mark (?).
- To list a command's keywords or arguments, enter a question mark (?) in place of a keyword or argument on the command line.
- At any time during an active Telnet session, you can list the Telnet commands by typing the following command at the system prompt:

**Ctrl-^ ?**

Press the Ctrl, Shift, and 6 keys simultaneously, let go, and type ?.