



Doc. No. 78-5326-01

Release Notes for Cisco IOS Release 11.3(3a)T Software Feature Packs—Cisco 3600 Series Routers

June 15, 1998

These release notes discuss the Cisco IOS Release 11.3(3a)T feature packs for Cisco 3600 series routers. These are the product numbers for the supported feature packs:

- CD36-C-11.3= (Cisco 3600 IP Feature Pack)
- CD36-CP-11.3= (Cisco 3600 IP Plus Feature Pack)
- CD36-CW-11.3= (Cisco 3600 IP Plus 40 Feature Pack)*
- CD36-CY-11.3= (Cisco 3600 IP Plus 56 Feature Pack)*
- CD36-B-11.3= (Cisco 3600 IP/IPX/AT/DEC Feature Pack)
- CD36-BP-11.3= (Cisco 3600 IP/IPX/AT/DEC Plus Feature Pack)
- CD36-AP-11.3= (Cisco 3600 Enterprise Plus Feature Pack)
- CD36-AW-11.3= (Cisco 3600 Enterprise Plus 40 Feature Pack)*
- CD36-AY-11.3= (Cisco 3600 Enterprise Plus 56 Feature Pack)*

* These feature packs contain encryption images.

Note The feature packs discussed in this document contain Cisco IOS Release 11.3(3a)T software images and Router Software Loader (RSL) Version 7.0.

Note Before running RSL, read the “Installing Software Images Using RSL” section on page 11.

Corporate Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA

Copyright © 1998
Cisco Systems, Inc.
All rights reserved.

Contents

These release notes discuss the following topics:

- “Cisco Feature Packs and Memory Requirements” section on page 2
- “Cisco IOS Feature Sets for the Cisco 3600 Series Routers” section on page 5
- “Modem Code Alert” section on page 11
- “Modem Code Information” section on page 11
- “Installing Software Images Using RSL” section on page 11
- “Alternatives to RSL” section on page 13
- “Related Documentation” section on page 16
- “Online Navigation” section on page 19
- “Cisco Connection Online” section on page 20
- “Documentation CD-ROM” section on page 21

Cisco Feature Packs and Memory Requirements

This section explains the following:

- What Is a Feature Pack?
- Cisco IOS Release 11.3(3a)T Feature Pack Descriptions and Memory Requirements

What Is a Feature Pack?

The heart of a Cisco IOS software feature pack is a CD-ROM that contains a software image and Router Software Loader (RSL), a Windows 95 application that loads the image onto the access server or router. Each Cisco IOS Release 11.3 feature pack CD-ROM contains one feature set. For users without Windows 95, images can also be loaded with a Trivial File Transfer Protocol (TFTP) server application, as explained in these release notes.

Each Cisco IOS Release 11.3 software feature pack box contains the following:

- CD-ROM with the following software:
 - Feature set software image that includes bundled modem firmware
 - RSL program (Windows 95 application)
 - TFTP server application (Windows 95 application)
- Instruction booklet for using RSL
- Release notes (this document), which includes instructions for using a TFTP server application on a system not running Windows 95 Software license, for using Cisco software in object code form on a single access server or router
- Cisco Documentation CD-ROM, which contains all Cisco IOS software documentation

Cisco IOS Release 11.3(3a)T Feature Pack Descriptions and Memory Requirements

This section includes two tables:

- Table 1—Describes each feature pack image, including a brief description of each feature set, the images' UNIX and DOS filenames, and memory requirements.
- Table 2—Describes the factory default available memory and the possible memory upgrades for the Cisco 3600 series routers.

You can use Table 1 to identify the memory required for your configuration based on the image you run. You can then check this against Table 2 to determine how much memory is available on the router as the factory default and the upgrades that you can obtain to satisfy your requirements.

Table 1 Cisco Feature Pack Image Filenames and Memory Requirements

Model Number	CD-ROM Title	UNIX Image Name	DOS Image Name	Flash Memory Req'd	Main Memory Req'd	Software Description
CD36-C-11.3=	Cisco 3600 IP Feature Pack Release 11.3(3a)T RSL Version 7.0	c3640-i-mz.113-3a.T	80235903	4 MB	16 MB	Cisco 3640 IP feature set, Release 11.3(3a)T
		c3620-i-mz-113-3a.T	80236403	4 MB	16 MB	Cisco 3620 IP feature set, Release 11.3(3a)T
		mica-modem-portware.2.2.3.0.bin	80264101	4 MB	16 MB	MICA Modem Portware Version 2.2.3.0
CD36-CP-11.3=	Cisco 3600 IP Plus Feature Pack Release 11.3(3a)T RSL Version 7.0	c3640-is-mz.113-3a.T	80235803	8 MB	24 MB	Cisco 3640 IP Plus feature set, Release 11.3(3a)T
		c3620-is-mz.113-3a.T	80236303	8 MB	24 MB	Cisco 3620 IP Plus feature set, Release 11.3(3a)T
		mica-modem-portware.2.2.3.0.bin	80264101	8 MB	24 MB	MICA Modem Portware Version 2.2.3.0
CD36-CW-11.3=	Cisco 3600 IP Plus 40 Feature Pack Release 11.3(3a)T RSL Version 7.0	c3640-is40-mz.113-3a.T	80264001	8 MB	24 MB	Cisco 3640 IP Plus 40 feature set, Release 11.3(3a)T
		c3620-is40-mz.113-3a.T	80263901	8 MB	24 MB	Cisco 3620 IP Plus 40 feature set, Release 11.3(3a)T
		mica-modem-portware.2.2.3.0.bin	80264101	8 MB	24 MB	MICA Modem Portware Version 2.2.3.0
CD36-CY-11.3=	Cisco 3600 IP Plus 56 Feature Pack Release 11.3(3a)T RSL Version 7.0	c3640-is56-mz.113-3a.T	80263801	8 MB	32 MB	Cisco 3640 IP Plus 56 feature set, Release 11.3(3a)T
		c3620-is56-mz.113-3a.T	80263701	8 MB	32 MB	Cisco 3620 IP Plus 56 feature set, Release 11.3(3a)T
		mica-modem-portware.2.2.3.0.bin	80264101	8 MB	32 MB	MICA Modem Portware Version 2.2.3.0

Table 1 Cisco Feature Pack Image Filenames and Memory Requirements (Continued)

Model Number	CD-ROM Title	UNIX Image Name	DOS Image Name	Flash Memory Req'd	Main Memory Req'd	Software Description
CD36-B-11.3=	Cisco 3600 IP/IPX/AT/DEC Feature Pack Release 11.3(3a)T RSL Version 7.0	c3640-d-mz.113-3a.T	80236103	4 MB	24 MB	Cisco 3640 IP/IPX/AppleTalk/DECnet feature set, Release 11.3(3a)T
		c3620-d-mz-113-3a.T	80236603	4 MB	24 MB	Cisco 3620 IP/IPX/AppleTalk/DECnet feature set, Release 11.3(3a)T
		mica-modem-portware. 2.2.3.0.bin	80264101	4 MB	24 MB	MICA Modem Portware Version 2.2.3.0
CD36-BP-11.3=	Cisco 3600 IP/IPX/AT/DEC Plus Feature Pack Release 11.3(3a)T RSL Version 7.0	c3640-ds-mz.113-3a.T	80236003	8 MB	32 MB	Cisco 3640 IP/IPX/AppleTalk/DECnet Plus feature set, Release 11.3(3a)T
		c3620-ds-mz.113-3a.T	80236503	8 MB	32 MB	Cisco 3620 IP/IPX/AppleTalk/DECnet feature set, Release 11.3(3a)T
		mica-modem-portware. 2.2.3.0.bin	80264101	8 MB	32 MB	MICA Modem Portware Version 2.2.3.0
CD36-AP-11.3=	Cisco 3600 Enterprise Plus Feature Pack Release 11.3(3a)T RSL Version 7.0	c3640-js-mz.113-3a.T	80263601	8 MB	32 MB	Cisco 3640 Enterprise Plus feature set, Release 11.3(3a)T
		c3620-js-mz.113-3a.T	80263501	8 MB	32 MB	Cisco 3620 Enterprise Plus feature set, Release 11.3(3a)T
		mica-modem-portware. 2.2.3.0.bin	80264101	8 MB	32 MB	MICA Modem Portware Version 2.2.3.0
CD36-AW-11.3=	Cisco 3600 Enterprise Plus 40 Feature Pack Release 11.3(3a)T RSL Version 7.0	c3640-js40-mz.113-3a. T	80263401	8 MB	32 MB	Cisco 3640 Enterprise Plus 40 feature set, Release 11.3(3a)T
		c3620-js40-mz.113-3a. T	80263301	8 MB	24 MB	Cisco 3620 Enterprise Plus 40 feature set, Release 11.3(3a)T
		mica-modem-portware. 2.2.3.0.bin	80264101	8 MB	24 MB	MICA Modem Portware Version 2.2.3.0
CD36-AY-11.3=	Cisco 3600 Enterprise Plus 56 Feature Pack Release 11.3(3a)T RSL Version 7.0	c3640-js56-mz.113-3a. T	80263201	8 MB	32 MB	Cisco 3640 Enterprise Plus 56 feature set, Release 11.3(3a)T
		c3620-js56-mz.113-3a. T	80263101	8 MB	32 MB	Cisco 3620 Enterprise Plus 56 feature set, Release 11.3(3a)T
		mica-modem-portware. 2.2.3.0.bin	80264101	8 MB	32 MB	MICA Modem Portware Version 2.2.3.0

Cisco IOS Feature Sets for the Cisco 3600 Series Routers

The Cisco IOS software is packaged into feature sets (also called software images). There are many different feature sets available, and each feature set contains a specific subset of Cisco IOS features. The feature set matrix is used to see the overall feature set organization.

Feature Set Matrix

The feature set matrix (see Table 2) shows the new feature set organization and lists which feature sets are available on the Cisco 3600 series for Cisco IOS Release 11.3(3a)T. The matrix uses the following terms:

Feature Set Matrix Term	Description
Basic	This feature is offered in the basic feature set.
Plus	This feature is offered in the Plus feature set.
Encrypt	This feature is offered in the encryption feature sets, which consist of 40-bit (Plus 40) or 56-bit (Plus 56) data encryption feature sets.

Table 2 Feature Set Matrix for the Cisco 3600 Series

Standard Feature Sets	Cisco 3600 Series Routers
IP	Basic, Plus
Desktop (IP/IPX/AppleTalk/DEC)	Basic, Plus
Enterprise	Basic, Plus

Cisco IOS images with strong encryption (including but not limited to 56-bit DES) are subject to U.S. Government export controls, and have a limited distribution. Images to be installed outside the U.S. require an export license. Customer orders might be denied or subject to delay due to U.S. Government regulations. Contact your sales representative or distributor for more information, or send e-mail to export@cisco.com.

Feature Set Table

To determine what features are available with each feature set, see Table 3. The table summarizes what features you can use when running a specific feature set on the Cisco 3600 series for Cisco IOS Release 11.3(3a)T. The feature set table uses the following terms:

Feature Set Table Term	Description
Basic	This feature is offered in the feature set.
-	This feature is not offered in the feature set.

Feature Set Table Term	Description
Plus	This feature is offered in the Plus feature set.
Encrypt	This feature is offered in the Encryption feature sets, which consist of 40-bit (Plus 40) or 56-bit (Plus 56) data encryption feature sets.

Table 3 Cisco IOS Software Feature Sets for the Cisco 3600 Series

Feature	Feature Set											
	IP	IP Plus	IP Plus 40	IP Plus 56	IP/IPX/AT/DEC	IP/IPX/AT/DEC Plus	Enterprise Plus	Enterprise Plus 40	Enterprise Plus 56	Enterprise/APPN Plus	Enterprise/APPN Plus 40	Enterprise/APPN Plus 56
IBM Support												
APPN High Performance Routing	No	No	No	No	No	No	No	No	No	Yes	Yes	Yes
APPN MIB Enhancements	No	No	No	No	No	No	No	No	No	Yes	Yes	Yes
APPN over Ethernet LAN Emulation	No	No	No	No	No	No	No	No	No	Yes	Yes	Yes
APPN Scalability Enhancements	No	No	No	No	No	No	No	No	No	Yes	Yes	Yes
Bisync Enhancements, includes:	No	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes
— Bisync 3780 Support												
— BSC Extended Addressing												
— Block Serial Tunneling (BSTUN) over Frame Relay												
Cisco MultiPath Channel (CMPC)	No											
DLSw+ Enhancements, includes:	No	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes
— Backup Peer Extensions for Encapsulation Types												
— DLSw+ Border Peer Caching												
— DLSw+ MIB Enhancements												
— DLSw+ SNA Type of Service												
— LLC2-to-SDLC Conversion between PU4 Devices												
— NetBIOS Dial-on-Demand Routing												
— UDP Unicast Enhancement												

Table 3 Cisco IOS Software Feature Sets for the Cisco 3600 Series (Continued)

Feature	Feature Set											
	IP	IP Plus	IP Plus 40	IP Plus 56	IP/ IPX/ AT/ DEC	IP/ IPX/ AT/ DEC Plus	Enterprise Plus	Enterprise Plus 40	Enterprise Plus 56	Enterprise/ APPN Plus	Enterprise/ APPN Plus 40	Enterprise/ APPN Plus 56
FRAS Enhancements, includes: — FRAS Boundary Network Node Enhancement — FRAS Dial Backup over DLSw+ — FRAS DLCI Backup — FRAS Host — FRAS MIB — SRB over Frame Relay	No	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes
RIF Passthrough in DLSw+	No	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes
SRB over FDDI on Cisco 4000, 4500, and 4700 Series Routers	No for all feature sets											
TN3270 LU Nailing	No for all feature sets											
TN3270 Server Enhancements	No for all feature sets											
Token Ring LANE	No for all feature sets											
Tunneling of Asynchronous Security Protocols	No	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Internet												
DRP Server Agent	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
DRP Server Agent Enhancements	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
IP Routing												
Easy IP (Phase 1)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Hot Standby Router Protocol (HSRP) over ISL in Virtual LAN Configurations	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
IP Enhanced IGRP Route Authentication	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
TCP Enhancements, includes: — TCP Selective Acknowledgment — TCP Timestamp	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
LAN Support												
AppleTalk Access List Enhancements	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
DECnet Accounting	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
IPX Named Access Lists	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes

Table 3 Cisco IOS Software Feature Sets for the Cisco 3600 Series (Continued)

Feature	Feature Set											
	IP	IP Plus	IP Plus 40	IP Plus 56	IP/ IPX/ AT/ DEC	IP/ IPX/ AT/ DEC Plus	Enterprise Plus	Enterprise Plus 40	Enterprise Plus 56	Enterprise/ APPN Plus	Enterprise/ APPN Plus 40	Enterprise/ APPN Plus 56
IPX SAP-after-RIP	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
NLSP Enhancements	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes
NLSP Multicast Support	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Management												
Cisco Call History MIB Command Line Interface	No for all feature sets											
Cisco IOS Internationalization	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Entity MIB, Phase 1	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
SNMPv2C	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
SNMP Inform Requests	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes
Virtual Profiles	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
VPDN MIB and Syslog Facility	No	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Multimedia												
IP Multicast Load Splitting across Equal-Cost Paths	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
IP Multicast over ATM Point-to-Multipoint Virtual Circuits	No for all feature sets											
IP Multicast over Token Ring LANs	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
PIM Version 2	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Stub IP Multicast Routing	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Voice over IP	No	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Quality of Service												
RTP Header Compression	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Security												
Additional Vendor-Proprietary RADIUS Attributes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Automated Double Authentication	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Certificate Authority Interoperability	No	No	No	Yes	No	No	No	No	Yes	No	No	Yes
Double Authentication	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Encrypted Kerberized Telnet	No	No	No	No	No	No	No	No	Yes	No	No	Yes
HTTP Security	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes

Table 3 Cisco IOS Software Feature Sets for the Cisco 3600 Series (Continued)

Feature	Feature Set											
	IP	IP Plus	IP Plus 40	IP Plus 56	IP/ IPX/ AT/ DEC	IP/ IPX/ AT/ DEC Plus	Enterprise Plus	Enterprise Plus 40	Enterprise Plus 56	Enterprise/ APPN Plus	Enterprise/ APPN Plus 40	Enterprise/ APPN Plus 56
Internet Key Exchange Security Protocol	No	No	Yes	Yes	No	No	No	Yes	Yes	No	Yes	Yes
IPSec Network Security	No	No	No	Yes	No	No	No	No	Yes	No	No	Yes
MS-CHAP Support	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes
Named Method Lists for AAA Authorization & Accounting	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Per-User Configuration	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Reflexive Access Lists	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
TCP Intercept	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes
Vendor-Proprietary RADIUS Attributes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Switching												
AppleTalk Routing over ISL and IEEE 802.10 in Virtual LANs	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
CLNS and DECnet Fast Switching over PPP	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes
DECnet/VINES/XNS over ISL, includes:	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes
— Banyan VINES Routing over ISL Virtual LANs												
— DECnet Routing over ISL Virtual LANs												
— XNS Routing over ISL Virtual LANs												
Fast-Switched Policy Routing	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
IPX Routing over ISL Virtual LANs	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
VIP Distributed Switching Support for IP Encapsulated in ISL	No for all feature sets											
Terminal Services												
Virtual Templates for Protocol Translation	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes
WAN Optimization												
ATM MIB Enhancements	No for all feature sets											
PAD Enhancements	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes
PAD Subaddressing	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes

Table 3 Cisco IOS Software Feature Sets for the Cisco 3600 Series (Continued)

Feature	Feature Set											
	IP	IP Plus	IP Plus 40	IP Plus 56	IP/ IPX/ AT/ DEC	IP/ IPX/ AT/ DEC Plus	Enterprise Plus	Enterprise Plus 40	Enterprise Plus 56	Enterprise/ APPN Plus	Enterprise/ APPN Plus 40	Enterprise/ APPN Plus 56
WAN Services												
Always On/Dynamic ISDN (AO/DI)							Yes	Yes	Yes	Yes	Yes	Yes
Bandwidth Allocation Control Protocol	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Dialer Watch	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Enhanced Local Management Interface (ELMI)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Frame Relay Enhancements	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Frame Relay MIB Extensions	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Frame Relay Router ForeSight	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
ISDN Advice of Charge	No	No	No	No	No	No	No	No	No	No	No	No
ISDN Caller ID Callback	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
ISDN NFAS	No for all feature sets											
Layer 2 Forwarding—Fast Switching	No	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Leased Line ISDN at 128 kbps	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
MPPC (Microsoft Point-to-point Compression)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
MS Callback	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Multiple ISDN Switch Types	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
National ISDN Switch Types for BRI and PRI Interfaces (NI2)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
PPP over ATM	No for all feature sets											
Stackable Home Gateway		Yes	Yes	Yes		Yes	Yes	Yes	Yes	Yes	Yes	Yes
Telnet Extensions for Dialout	No	No	No	No	No	No	No	No	No	No	No	No
X.25 Enhancements	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
X.25 on ISDN	No for all feature sets											
X.25 Switching between PVCs and SVCs	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
X.28 Emulation	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes

Modem Code Alert

By default, the MICA modems installed on the Cisco 3600 series routers use the modem portware that is bundled with the Cisco IOS software image. Unless you are familiar with the Cisco MICA portware, we recommend that you use the default firmware and do not attempt to download another version.

If you do choose to override the firmware and portware selected by Cisco IOS software, the Flash memory of your router might contain modem code files that should be saved and restored before downloading the new image. Before the image download begins, the Router Software Loader (RSL) will display the Flash Copy Options dialog box, which will allow you to select which files to back up and restore. By default, RSL will back up all files in the selected Flash memory partition, and restore the files you select.

If you want to verify that you are running the latest modem code, use the **show modem version** command to display the current version. Then compare that version to the modem code files available on the feature pack CD-ROM and on Cisco Connection Online (CCO).

Modem Code Information

If you are running Microsoft Windows 95 on a PC, we recommend using the RSL to download modem code. For detailed steps, refer to the RSL online help topic, "Downloading Modem Files." If you are running Windows NT, UNIX, or Macintosh, use TFTP or rcp (remote copy protocol) to download modem code. TFTP server instructions are in the online document titled, "Another Way to Download Modem Code."

Both RSL and TFTP instructions are available from the Software Center at the following URL:

<http://www.cisco.com/public/sw-center/sw-access.shtml>

Click on the link, **Router Software Loader (RSL)**. Follow the steps to download the new modem code.

See the sections "Cisco Connection Online" section on page 20 and "Documentation CD-ROM" section on page 21 for information on accessing customer documentation.

Installing Software Images Using RSL

The Router Software Loader (RSL) application contained on the feature pack CD-ROM is designed to work with a PC running Microsoft Windows 95. Refer to the booklet included with the CD-ROM for instructions to install the software images.

This section describes several solutions to problems you might encounter when using RSL. These solutions are additions to the RSL online help.

Recovering from a Connection Error

This installation tip provides a possible recovery solution in the event that you are unable to connect to your router. You can skip this section unless you are experiencing a connection error.

In some cases, you might receive the following error message while connecting to the target router:

```
"Failed to configure the router to enable the Cisco IOS software image and configuration file upload and download operations. You may want to check the router to make sure that the selected interface exists."
```

If you encounter this message, try increasing the Short Timeout value, which is set to 25 seconds, in the Options dialog box, especially if one of the following situations applies:

Note Increasing the Short Timeout value might increase the time it takes for RSL to connect to the target router.

- You are connecting to a router that has a large configuration file.
- You are connecting to a Cisco AS5200 access server. A Cisco AS5200 requires up to 45 seconds to write a configuration to nonvolatile random-access memory (NVRAM), because of the amount of interfaces that must be checked during this process. Increase the Short Timeout value to 60 seconds.

Restoring the Startup Configuration

In some cases, RSL is unable to restore the startup configuration. If this happens, take the following steps:

- Step 1** Ensure that all cables are properly attached to both the router and the PC.
- Step 2** Restart RSL, and connect using the **Preconfigured router** option.
- Step 3** When asked if you want to overwrite the existing startup configuration file, choose **NO**.
- Step 4** When asked if you want to continue, choose **YES**.
- Step 5** When connected, select **Download Router Configuration** in the Router Software Loader dialog box.
- Step 6** Select the appropriate file, and click **Copy configuration to the router's nonvolatile memory**.

The router should now contain the startup configuration it had before the initial RSL connection. You can now exit RSL.

Note In the previous situation, the router's configuration register (**config-register 0xnnnn**) is not restored.

Note If you enter **Ctrl-Alt-Delete** to terminate RSL, the router's configuration and configuration register are not restored. However, in this case, the configuration file is not deleted from the PC, so it can be restored using the previous steps.

Helpful Hints

The following information about RSL operations can help you with the installation process:

- If you have added any static entries to the PC's Address Resolution Protocol (ARP) table, one of them might be deleted by RSL. This entry will need to be manually reentered into the PC's ARP table.

- If the router's running configuration at connection time is not the same as the router's startup configuration, the exact configuration will not be restored. Any changes that you have made since the last time a **copy running-config startup-config** or **write memory** command was entered will be lost.
- RSL will restore the router's running configuration, but some configuration commands will not be restored. However, the startup configuration will be correct. You can restore the exact running configuration by rebooting the router. Commands not restored to the running configuration include the following interface configuration commands: **no shutdown**, **no ringspeed**, and **media-type aui**.

Alternatives to RSL

The RSL is designed to work with a PC running Microsoft Windows 95 and is the recommended method for downloading software to the router. The booklet included with the CD-ROM explains how to perform this simple install process; however, two alternatives are available for installing router software:

- Use the console or auxiliary port
- Use a TFTP server application

Installing the Router Software Using the Console or Auxiliary Port

This section explains how to use the **copy xmodem flash** command to install the router software from the CD-ROM onto the router.

Note The transfer takes place only on the port at which you issue the command. If you download via the console, all console output is discarded for the duration of the transfer. You can only download files to the router; you cannot copy files from the router. Cisco recommends using the auxiliary port for this type of software download. The auxiliary port has hardware flow control and full modem control. In addition, the transfer does not occupy the system console.

The following example shows how to use the **copy xmodem flash** command on a Cisco 3600 series router.

```
Router# copy xmodem flash
**** WARNING ****
x/modem is a slow transfer protocol limited to the current speed
settings of the auxiliary/console ports. The use of the auxiliary
port for this download is strongly recommended.
During the course of the download no exec input/output will be
available.
-----
Proceed? [confirm]y
Use crc block checksumming? [confirm] y
Max Retry Count [10]:
Perform image validation checks? [confirm] y
Xmodem download using crc checksumming with image validation
Continue? [confirm] y
Partition  Size  Used      Free      Bank-Size  State      Copy Mode
1          4096K  3259K    836K     4096K     Read/Write Direct
2          4096K   0K     4095K    4096K     Read/Write Direct
```

```
[Type ?<no> for partition directory; ? for full directory; q to abort]
Which partition? [default = 1] 2

System flash directory, partition 2:
File Length Name/status
 1 68 TESTFILE
[132 bytes used, 4194172 available, 4194304 total]
Destination file name? c3620-i-mz.0918
Erase flash device before writing? [confirm] y
Flash contains files. Are you sure you want to erase? [confirm] y

Copy '' from server
 as 'c3620-i-mz.0918' into Flash WITH erase? [yes/no] y
Erasing device... eeeeeeeeeeeeeeeeeee ...erased
Ready to receive file.....C
Verifying checksum... OK (0x5DE8)
Flash device copy took 00:12:06 [hh:mm:ss]
```

Installing Software Images Using a TFTP Server Application

This section explains how to use a TFTP server application as an alternative to using the RSL to install the router software from the CD-ROM. You can perform this procedure using a PC (running Microsoft Windows 95 or Microsoft Windows 3.1), a Macintosh, or a UNIX system. You can use either the **copy tftp flash** or **copy rcp flash** command to download the software to the router.

First, obtain a TFTP application or a remote copy protocol (rcp) application to set up your computer as a TFTP server or an rcp server. You can use the RSL or the TFTP server included on the feature pack CD-ROM to install the software only if you are using a PC running Windows 95. For other operating systems, a number of TFTP or rcp applications are available from independent software vendors or as shareware from public sources on the World Wide Web.

Installation Process

This section describes how to use TFTP on a PC to install the router software.

Note To use an rcp application, follow this same procedure, but substitute rcp for TFTP in the instructions; for example, use the **copy rcp flash** command instead of the **copy tftp flash** command.

- Step 1** Install any TFTP server application on the PC. (The PC application included on the feature pack CD-ROM is for Microsoft Windows 95 only.)
- Step 2** Launch the TFTP server application on the PC, usually by double-clicking the application icon or its .exe filename.
- Step 3** Set up the PC as a TFTP server by using the TFTP server application setup or configuration facility.

Most TFTP server applications include a setup facility that allows you to specify the PC as a server. For example, from the TFTP menu of one application, you can select **Settings** to display a panel that includes a checkbox beside the word **Server**. To configure the local PC as a server, click this checkbox.

The TFTP server also allows the selection of a “root” directory. You must select the directory in which the Cisco IOS files reside (for example, d:\cpswinst\images).



Caution Make sure you set up your local PC as a TFTP server. If you overlook this step, you cannot perform the copy procedure. This reminder also applies if you are using rcp instead of TFTP.

Step 4 Establish a console session from your local PC (which is now configured as a TFTP server) to the router by using one of these methods:

- Connect the PC com port to the router console port.

This is the recommended method. When you reload the router with the new image in Step 12, you remain connected to the router. (If you use Telnet, you lose connection to the router.)

- Establish a Telnet session from the PC to the router.

Step 5 Connect your PC Ethernet port to the router Ethernet port. Use an Ethernet crossover cable.

Note Use straight-through cables if you are connecting via a 10BaseT hub or a 100BaseT hub.

For systems without a LAN interface, make sure that the router and the PC have IP connectivity through the available interface (that is, the router and PC can ping each other with IP traffic).

Note We recommend that you back up the router configuration before upgrading the router software.

Step 6 Enter the following commands to enter enable mode and copy the new software image from the PC (set up as a TFTP server) to the router:

```
(boot)> enable
Password: <password>
(boot)#
(boot)# copy tftp flash
```

In the next series of steps, you download the Cisco IOS Release 11.3 images that you want installed on your router.

Step 7 When prompted, enter the IP address of your PC, as in the following example:

```
Address or name of remote host [255.255.255.255]? 172.16.1.1
```

This is the IP address of your local PC, not that of the router.

Step 8 When prompted, enter the filename of the Cisco IOS Release 11.3 image to be copied to the router, as in the following example:

```
Source file name? 80235903.bin
```

This example specifies the DOS image name of the IP feature set for a Cisco 3600 router, as listed in Table 1.

- Step 9** In response to the prompt, enter the destination UNIX image filename, and press **Enter**.

This is the name of the image file on the router, not the full path name of the image on the CD-ROM attached to the PC. Refer to Table 1 in the “Cisco Feature Packs and Memory Requirements” section on page 2 for the UNIX image filename.

```
Destination file name [80180812.bin]? c3640-i-mz.113-3a.T
```

- Step 10** Enter **yes** in response to the prompt asking if you want to erase the existing image copy resident in the router Flash memory before copying the new one:

```
Erase flash device before writing? [confirm] yes
```

The entire copying process takes several minutes and differs from network to network.

During the transfer process, the software displays messages indicating that it has accessed the file you have specified and is loading it.

The exclamation point (!) indicates that the copy process is taking place. Each exclamation point (!) indicates that ten packets have been transferred successfully. A checksum verification of the image occurs after the image is written to Flash memory.

- Step 11** Enter the following commands to change the config-reg to 0x2102. This will force the router to reload to the image running from Flash memory.

```
(boot)# configure terminal
config-reg 0x2102
(boot)(config)#
(boot)(config)# end
(boot)#
```

- Step 12** Enter the **reload** command to reload the router:

```
(boot)# reload
```

After reload is complete, the router should be running the desired Cisco IOS image. Use the **show version** command to verify.

Related Documentation

All documents mentioned in this section are available as printed manuals or electronic documents. (See the “Online Navigation” section on page 19 for more information on accessing electronic documentation.)

The following documentation is related to these release notes:

- Cisco 3600-Specific Documentation
- Cisco IOS Documentation Set and Related Supporting Documents
- Software Configuration Tips on the Cisco TAC Home Page

Cisco 3600-Specific Documentation

The following documents are specific to the Cisco 3600 series routers:

- *Cisco 3600 Series Software Configuration Guide*
- *Cisco 3600 Series Manager Guide*
- *Regulatory Compliance and Safety Information*

Cisco IOS Documentation Set and Related Supporting Documents

The following documents apply to the Cisco 3600 series routers:

- *Release Notes for Cisco IOS Release 11.3*
- Product-Specific Release Notes
- Feature Guide for Cisco IOS Release 11.3 T
- Cisco IOS Release 11.3 T New Feature Documentation
- Cisco IOS Release 11.3 Configuration Guides/Command References
- *Cisco IOS Software Command Summary*
- *Cisco IOS 11.3 System Error Messages*
- *Cisco Management Information Base (MIB) User Quick Reference*
- *Debug Command Reference*
- *Access Services Quick Configuration Guide*
- Cisco IOS Software Release 11.3 and 11.3 T Caveats

The Cisco IOS configuration guides, command references, and chapter topics are as follows:

Books	Chapter Topics
<ul style="list-style-type: none"> • <i>Configuration Fundamentals Configuration Guide</i> • <i>Configuration Fundamentals Command Reference</i> 	Configuration Fundamentals Overview Cisco IOS User Interfaces File Management Interface Configuration System Management
<ul style="list-style-type: none"> • <i>Network Protocols Configuration Guide, Part 1</i> • <i>Network Protocols Command Reference, Part 1</i> 	IP Addressing IP Services IP Routing Protocols
<ul style="list-style-type: none"> • <i>Network Protocols Configuration Guide, Part 2</i> • <i>Network Protocols Command Reference, Part 2</i> 	AppleTalk Novell IPX
<ul style="list-style-type: none"> • <i>Network Protocols Configuration Guide, Part 3</i> • <i>Network Protocols Command Reference, Part 3</i> 	Apollo Domain Banyan VINES DECnet ISO CLNS XNS
<ul style="list-style-type: none"> • <i>Wide-Area Networking Configuration Guide</i> • <i>Wide-Area Networking Command Reference</i> 	ATM Frame Relay SMDS X.25 and LAPB

Books	Chapter Topics
<ul style="list-style-type: none"> • <i>Security Configuration Guide</i> • <i>Security Command Reference</i> 	<ul style="list-style-type: none"> AAA Security Services Security Server Protocols Traffic Filtering Network Data Encryption Passwords and Privileges Neighbor Router Authentication IP Security Options
<ul style="list-style-type: none"> • <i>Dial Solutions Configuration Guide</i> • <i>Dial Solutions Command Reference</i> 	<ul style="list-style-type: none"> Dial Business Solutions and Examples Dial-In Port Setup DDR and Dial Backup Remote Node and Terminal Service Cost-Control and Large-Scale Dial Solutions VPDN
<ul style="list-style-type: none"> • <i>Cisco IOS Switching Services Configuration Guide</i> • <i>Cisco IOS Switching Services Command Reference</i> 	<ul style="list-style-type: none"> Switching Paths for IP Networks Fast Switching Autonomous Switching NetFlow Switching Optimum Switching Virtual LAN (VLAN) Switching and Routing Inter-Switch Link Protocol Encapsulation IEEE 802.10 Encapsulation LAN Emulation
<ul style="list-style-type: none"> • <i>Bridging and IBM Networking Configuration Guide</i> • <i>Bridging and IBM Networking Command Reference</i> 	<ul style="list-style-type: none"> Transparent Bridging Source-Route Bridging Remote Source-Route Bridging DLSw+ STUN and BSTUN LLC2 and SDLC IBM Network Media Translation DSPU and SNA Service Point SNA Frame Relay Access Support APPN NCIA Client/Server Topologies IBM Channel Attach
<ul style="list-style-type: none"> • <i>Cisco IOS Software Command Summary</i> • <i>Dial Solutions Quick Configuration Guide</i> • <i>System Error Messages</i> • <i>Debug Command Reference</i> 	

The *Cisco Management Information Base (MIB) User Quick Reference* publication is no longer being published. For the latest list of MIBs supported by Cisco, see the Cisco Network Management Toolkit on Cisco Connection Online (CCO). On CCO, go to **Software and Support**, select **Software Center**, and click on **Network Management Products**. Next, select **Cisco Network Management Toolkit** and click on **Cisco MIBs**.

Software Configuration Tips on the Cisco TAC Home Page

The following URL contains links to access helpful tips to configure your Cisco products:

http://www.cisco.com/kobayashi/serv_tips.shtml

This URL is subject to change without notice. If it does change, point your web browser to <http://www.cisco.com/> and follow this path: **Software & Support: Technical Tips** (button on left margin).

Hot Tips are popular tips and hints gathered from Cisco's Technical Assistance Center (TAC). Most of these documents are also available from the TAC's Fax-on-Demand service. To access Fax-on-Demand and receive documents at your fax machine, call 888-50-CISCO (888-502-4726). From international areas, call 415-596-4408.

The following sections are provided from the Technical Tips page:

- **Field Notices**—Designed to provide notification of critical issues regarding Cisco products. These include problem descriptions, safety or security issues, and hardware defects.
- **Hardware**—Technical Tips related to specific hardware platforms.
- **Internetworking Features**—Tips on using and deploying Cisco IOS software features and services.
- **Sample Configurations**—Actual configuration examples complete with topology and annotations.
- **Software Products**—MultiNet & Cisco Suite 100, Network Management, Cisco IOS Software bulletins, CiscoPro Configurations.
- **Special Collections**—Other helpful documents. Frequently Asked Questions, Security Advisories, References & RFCs, Case Studies, CiscoPro Documentation CD-ROM.

Online Navigation

You can access Cisco IOS software documentation, such as printed manuals and configuration notes, either at Cisco Connection Online (CCO) on the World Wide Web or on the Cisco Documentation CD-ROM.

Cisco 3600-Specific Documentation

- Using a web browser, follow this path on CCO:
Software & Support: Cisco Documentation: Cisco IOS Software Configuration: Cisco IOS Release 11.3: Product Specific Release Notes: Cisco 3600 Series Routers: Release Notes for Cisco 3600 for Cisco IOS Release 11.3 T.
- On the Documentation CD-ROM, follow this path:
Cisco IOS Software Configuration: Cisco IOS Release 11.3: Product Specific Release Notes: Cisco 3600 Series Routers: Release Notes for Cisco 3600 for Cisco IOS Release 11.3 T.

Cisco IOS Documentation Set and Related Supporting Documents

- Using a web browser, follow this path on CCO:
Software & Support: Cisco Documentation: Cisco IOS Software Configuration: Cisco IOS Release 11.3.
- On the Documentation CD-ROM, follow this path:
Cisco Product Documentation: Cisco IOS Software Configuration: Cisco IOS Release 11.3.

Additional information about CCO and the Documentation CD-ROM is in the “Cisco Connection Online” section on page 20 and “Documentation CD-ROM” section on page 21.

Cisco Connection Online

Cisco Connection Online (CCO) is Cisco Systems’ primary, real-time support channel. Maintenance customers and partners can self-register on CCO to obtain additional information and services.

Available 24 hours a day, 7 days a week, CCO provides a wealth of standard and value-added services to the Cisco customers and business partners. CCO services include product information, product documentation, software updates, release notes, technical tips, the Bug Navigator, configuration notes, brochures, descriptions of service offerings, and download access to public and authorized files.

CCO serves a wide variety of users through two interfaces that are updated and enhanced simultaneously: a character-based version and a multimedia version that resides on the World Wide Web (WWW). The character-based CCO supports Zmodem, Kermit, Xmodem, FTP, and Internet e-mail, and it is excellent for quick access to information over lower bandwidths. The WWW version of CCO provides richly formatted documents with photographs, figures, graphics, and video, as well as hyperlinks to related information.

You can access CCO in the following ways:

- WWW: <http://www.cisco.com>
- WWW: <http://www-europe.cisco.com>
- WWW: <http://www-china.cisco.com>
- Telnet: cco.cisco.com
- Modem: From North America, 408 526-8070; from Europe, 33 1 64 46 40 82. Use the following terminal settings: VT100 emulation; databits: 8; parity: none; stop bits: 1; and connection rates up to 28.8 kbps.

For a copy of CCO's Frequently Asked Questions (FAQ), contact cco-help@cisco.com. For additional information, contact cco-team@cisco.com.

Note If you are a network administrator and need personal technical assistance with a Cisco product that is under warranty or covered by a maintenance contract, contact the Cisco Technical Assistance Center (TAC) at 800 553-2447, 408 526-7209, or tac@cisco.com. To obtain general information about Cisco Systems, Cisco products, or upgrades, contact 800 553-6387, 408 526-7208, or cs-rep@cisco.com.

Documentation CD-ROM

Cisco documentation and additional literature are available in a CD-ROM package, which ships with your product. The Documentation CD-ROM, a member of the Cisco Connection Family, is updated monthly. Therefore, it might be more current than printed documentation. To order additional copies of the Documentation CD-ROM, contact your local sales representative or call customer service. The CD-ROM package is available as a single package or as an annual subscription. You can also access Cisco documentation on the World Wide Web at <http://www.cisco.com>, <http://www-china.cisco.com>, or <http://www-europe.cisco.com>.

If you are reading Cisco product documentation on the World Wide Web, you can submit comments electronically. Click **Feedback** in the toolbar, select **Documentation**, and click **Enter the feedback form**. After you complete the form, click **Submit** to send it to Cisco. We appreciate your comments.

This document is to be used in conjunction with the *Cisco IOS 11.3 Configuration Guides* and *Command References* publications.

AccessPath, AtmDirector, the CCIE logo, CD-PAC, Centri, the Cisco Capital logo, *CiscoLink*, the Cisco NetWorks logo, the Cisco Powered Network logo, the Cisco Press logo, ClickStart, ControlStream, DAGAZ, Fast Step, FireRunner, IGX, JumpStart, Kernel Proxy, LoopRunner, MGX, Natural Network Viewer, NetRanger, NetSonar, *Packet*, PIX, Point and Click Internetworking, Policy Builder, RouteStream, Secure Script, SMARTnet, SpeedRunner, Stratm, StreamView, *The Cell*, TrafficDirector, TransPath, VirtualStream, VlanDirector, Workgroup Director, and Workgroup Stack are trademarks; Changing the Way We Work, Live, Play, and Learn and Empowering the Internet Generation are service marks; and BPX, Catalyst, Cisco, Cisco IOS, the Cisco IOS logo, Cisco Systems, the Cisco Systems logo, Enterprise/Solver, EtherChannel, FastHub, FastPacket, ForeSight, FragmentFree, IPX, LightStream, MICA, Phase/IP, StrataSphere, StrataView Plus, and SwitchProbe are registered trademarks of Cisco Systems, Inc. in the U.S. and certain other countries. All other trademarks mentioned in this document are the property of their respective owners.

Copyright © 1998, Cisco Systems, Inc.
All rights reserved. Printed in USA.
9805R

