

Configuring AppleTalk

AppleTalk is a local-area network system that was designed and developed by Apple Computer, Inc. It can run over Ethernet, Token Ring, and FDDI networks and over Apple's proprietary twisted-pair media access system (LocalTalk). AppleTalk specifies a protocol stack comprising several protocols that direct the flow of traffic over the network.

Apple Computer uses the name *AppleTalk* to refer to the Apple network protocol architecture. Apple Computer refers to the actual transmission media used in an AppleTalk network as LocalTalk (Apple's proprietary twisted-pair transmission medium for AppleTalk), TokenTalk (AppleTalk over Token Ring), EtherTalk (AppleTalk over Ethernet), and FDDITalk (AppleTalk over Fiber Distributed Data Interface).

This chapter describes how to configure AppleTalk and provides configuration examples. For a complete description of the commands mentioned in this chapter, refer to Chapter 12 of the *Router Products Command Reference* publication. For historical background and a technical overview of AppleTalk, see the *Internetworking Technology Overview* publication.

Cisco's Implementation of AppleTalk

Cisco routers support AppleTalk Phase 1 and AppleTalk Phase 2. For AppleTalk Phase 2, Cisco routers support both extended and nonextended networks. Cisco's implementation of AppleTalk can route packets over Ethernet, Token Ring, and FDDI local-area networks, and over X.25, HDLC, Frame Relay, and SMDS wide-area networks.

Standard AppleTalk Services

The Cisco implementation of Appletalk supports the following standard AppleTalk protocols:

- AppleTalk Address Resolution Protocol (AARP)
- Datagram Delivery Protocol (DDP)
- Routing Table Maintenance Protocol (RTMP)
- Name Binding Protocol (NBP)
- Zone Information Protocol (ZIP)
- AppleTalk Echo Protocol (AEP)
- AppleTalk Transaction Protocol (ATP)

AARP, DDP, and RTMP provide end-to-end connectivity between internetworked nodes. AARP maps AppleTalk node addresses to the addresses of the underlying data link, thus making it possible for AppleTalk to run on several data links. DDP provides socket-to-socket delivery of packets. RTMP establishes and maintains routing tables.

NBP and ZIP maintain node name and zone information. NBP maps network names to AppleTalk addresses. ZIP tracks which networks are in which zones.

AEP is an echo, or **ping**-type, protocol. It generates packets that test the reachability of network nodes.

ATP is a reliable transport protocol that provides data acknowledgment and retransmission for transaction-based applications, such as file services provided by the AppleTalk Filing Protocol (AFP) and print services provided by the Printer Access Protocol (PAP).

For more information about the AppleTalk protocols, refer to the *Internetworking Technology Overview* publication.

Enhancements to Standard AppleTalk

The Cisco AppleTalk implementation includes the following enhancements to standard AppleTalk:

- Support for EtherTalk 1.2 and EtherTalk 2.0 without the need for translation or transition routers
- Support for WAN protocols, including SMDS, Frame Relay, X.25, and HDLC
- Configurable protocol constants (examples include controlling the aging of entries in the routing table and controlling the AARP interval and number of retransmissions)
- No software limits on the number of zones or routes
- MacTCP support via a MacIP server
- NBP proxy service, providing compatibility between AppleTalk Phase 1 and AppleTalk Phase 2 networks
- Support of IPTalk, which provides IP encapsulation of AppleTalk, IPTalk, and the Columbia AppleTalk Package (CAP)
- Access control for filtering network traffic by network number, filtering routing table updates, and filtering GetZoneList (GZL) responses
- Integrated node name support to simplify AppleTalk network management
- Interactive access to AEP and NBP provided by the **ping** command
- Configured (seed) and discovered interface configuration
- Support for the AppleTalk Responder, which is used by network monitoring packages such as *Inter•Poll*
- SNMP over AppleTalk
- Encapsulation (tunneling) of AppleTalk RTMP packets over an IP backbone

AppleTalk, like many network protocols, makes no provisions for network security. The design of the AppleTalk protocol architecture requires that security measures be implemented at higher application levels. We support AppleTalk distribution lists, allowing control of routing updates on a per-interface basis. This security feature is similar to those that we provide for other protocols.

AppleTalk Phase 1 and Phase 2

There are two versions, or phases, of AppleTalk. AppleTalk Phase 1 and AppleTalk Phase 2 are implementations of the AppleTalk protocol stack, especially the routing portions of the stack.

AppleTalk Phase 1, the earlier version, supports a single physical network that can have one network number and be in one zone. This network can have up to 254 devices, which can consist of 127 end nodes and 127 servers. *AppleTalk Phase 2*, the more recent version, supports multiple logical networks on a single physical network. This means that one cable segment can have multiple network numbers. Each logical network in Phase 2 can support up to 253 devices, with no restrictions on the type of devices. Also, in AppleTalk Phase 2 a network can be in more than one zone.

AppleTalk Phase 2 introduced the concepts of *extended* and *nonextended* networks. These terms refer to the media-level encapsulation and cable addressing used on a network segment attached to a router interface. While the concepts of extended and nonextended networks do not exist in AppleTalk Phase 1, Phase 1 can be thought of as a nonextended network.

Table 12-1 compares the capabilities of AppleTalk Phase 1 and Phase 2.

Table 12-1 AppleTalk Phase 1 and Phase 2

Capability	AppleTalk Phase 1	AppleTalk Phase 2
Networks, nodes, and zones		
Number of logical networks (cable segments)	1	Unlimited
Maximum number of devices	254 ¹	253 ²
Maximum number of end nodes	127	Does not apply ³
Maximum number of servers	127	Does not apply ³
Number of zones in which a network can be	1 ⁴	1 (nonextended) 255 (extended)
Media-level encapsulation		
Nonextended network	Does not apply	Yes
Extended network	Does not apply	Yes
Cable addressing		
	Does not apply; uses network numbers	Single network number (nonextended) Cable range of 1 or more (extended)

1. The node addresses 0 and 255 are reserved.

2. The node addresses 0, 254, and 255 are reserved.

3. There is no restriction on the types of devices. There can be a total of 253 end nodes and servers.

4. In this sense, an AppleTalk Phase 1 network can be thought of as a nonextended AppleTalk Phase 2 network.

Routers running Software Releases 8.2, 8.3, 9.0, 9.1, 9.21, and later support AppleTalk Phase 1 and Phase 2.

AppleTalk Addresses

An AppleTalk address consists of a network number and a node number expressed in decimal in the format *network.node*.

The *network number* identifies a network, or cable segment. A network is a single logical cable. Although the logical cable is frequently a single physical cable, bridges can be used to interconnect several physical cables. The network number is a 16-bit decimal number that must be unique throughout the entire AppleTalk internetwork. In AppleTalk Phase 1, networks are identified by a single network number that corresponds to a physical network. In AppleTalk Phase 2, networks are identified by a cable range that corresponds to one or more logical networks. In Phase 2, a single cable can have multiple network numbers. A cable range is either one network number or a contiguous sequence of several network numbers in the format *start–end*. For example, the cable range 4096–4096 identifies a logical network that has a single network number, and the cable range 10–12 identifies a logical network that spans three network numbers. In both AppleTalk Phase 1 and Phase 2, the network number 0 is reserved.

The *node number* identifies the node, which is any device connected to the AppleTalk network. The node number is an 8-bit decimal number that must be unique on that network. In AppleTalk Phase 1, node numbers 1 through 127 are for user nodes, node numbers 128 through 254 are for servers, and node numbers 0 and 255 are reserved. In AppleTalk Phase 2, you can use node numbers 1 through 253 for any nodes attached to the network. Node numbers 0, 254, and 255 are reserved.

The following is an example of an AppleTalk network address:

3.45

Here, the network number is 3 and the node number is 45. You enter both numbers in decimal. Our software also displays them in decimal.

A *zone* is a logical group of networks. The networks in a zone can be contiguous or noncontiguous. A zone is identified by a zone name, which can be up to 32 characters long and can include standard characters as well as AppleTalk special characters. To include a special character, type a colon followed by two hexadecimal characters that represent the special character in the Macintosh character set. In AppleTalk Phase 2, an extended network can have up to 255 zones, and a nonextended network can have only one zone. An AppleTalk Phase 1 network can have only one zone.

Configuration Guidelines and Compatibility Rules

AppleTalk Phase 1 and AppleTalk Phase 2 networks are incompatible and cannot run simultaneously on the same internetwork. As a result, all routers in an internetwork must support AppleTalk Phase 2 before the network can use Phase 2 routing. If your internetwork has a combination of AppleTalk Phase 1 and Phase 2 routers, you must observe the compatibility rules described in this section. Note, however, that you do not need to upgrade all end nodes in order to use the features provided by our AppleTalk enhancements.

Follow these guidelines when configuring an extended AppleTalk network on our router if any router in your AppleTalk internetwork supports only nonextended AppleTalk (that is, if any routers are Phase 1 routers). If you do not follow these guidelines, unpredictable behavior may result.

- The cable range must be one (for example, 23–23).
- Each AppleTalk network can be a member of only one zone.

When using Cisco routers with other vendors' implementations of AppleTalk, follow these guidelines:

- In order for a Macintosh with an Ethernet card to support extended AppleTalk, the Macintosh must be running EtherTalk Version 2.0 or later. This restriction does not apply to Macintoshes with only LocalTalk interfaces.
- Shiva FastPath routers must run K-Star Version 8.0 or later and must be explicitly configured for extended AppleTalk.
- Apple's Internet Router software Version 2.0 supports a transition mode for translation between nonextended AppleTalk and extended AppleTalk on the same network. Transition mode requires the Apple upgrade utility and a special patch file from Apple.

AppleTalk Configuration Task List

To configure AppleTalk routing, complete the following tasks. At a minimum, you must enable AppleTalk routing. The remaining tasks are optional.

- Enable AppleTalk routing (page 12-5)
- Control access to AppleTalk networks (page 12-9)
- Configure the name display facility (page 12-16)
- Set up special configurations (page 12-16)
- Tune AppleTalk network performance (page 12-24)
- Configure AppleTalk over WANs (page 12-28)
- Monitor the AppleTalk network (page 12-29)

This chapter describes how to perform these configuration tasks. Configuration examples are provided at the end of the chapter.

Enable AppleTalk Routing

To enable AppleTalk routing, first enable it on the router, then configure each interface for AppleTalk. These are the only two tasks you must perform when configuring AppleTalk routing.

To enable AppleTalk on an interface, assign an AppleTalk address or cable range to the interface and then assign one or more zone names to the interface. You can perform these tasks either manually or dynamically.

You also can enable our routers to perform transition mode routing from nonextended to extended AppleTalk.

Enable AppleTalk Routing on the Router

To enable AppleTalk routing on the router, perform the following task in global configuration mode:

Task	Command
Enable AppleTalk routing.	appletalk routing

For an example of how to enable AppleTalk routing, see the section “Configuring an Extended AppleTalk Network Example” later in this chapter.

Manually Configure an Interface

You can manually configure an interface for nonextended or extended AppleTalk routing.

To manually configure an interface for nonextended AppleTalk routing, perform the following tasks in interface configuration mode:

Task	Command
Step 1 Assign an AppleTalk address to the interface.	appletalk address <i>address</i>
Step 2 Assign a zone name to the interface.	appletalk zone <i>zone-name</i>

For an example of how to configure an interface for nonextended AppleTalk routing, see the section “Configuring a Nonextended AppleTalk Network Example” later in this chapter.

After you assign the address and zone name, the interface will attempt to verify them with another operational router on the connected network. If there are any discrepancies, the interface will not become operational. If there are no neighboring operational routers, the router will assume the interface’s configuration is correct, and the interface will become operational.

To manually configure an interface for extended AppleTalk routing, perform the following tasks in interface configuration mode:

Task	Command
Step 1 Assign a cable range to an interface.	appletalk cable-range <i>start-end</i> [<i>network.node</i>]
Step 2 Assign a zone name to the interface.	appletalk zone <i>zone-name</i>

You can assign more than one zone name to a cable range. If you do so, the first name you assign is considered to be the default zone.

You can define up to 255 zones.

After you assign the address and zone name(s), the interface will attempt to verify them with another operational router on the connected network. If there are any discrepancies, the interface will not become operational. If there are no neighboring operational routers, the router will assume the interface’s configuration is correct, and the interface will become operational.

Dynamically Configure an Interface

If a nonextended or an extended interface is connected to a network that has at least one other operational AppleTalk router, you can dynamically configure the interface using discovery mode. In discovery mode, an interface acquires information about the attached network from an operational router and then uses this information to configure itself.

Using discovery mode to configure interfaces saves time if the network numbers, cable ranges, or zone names change. If this happens, you need to make the changes only on one operational router.

Discovery mode is useful when you are changing a network configuration or when you are adding a router to an existing network.

Note that discovery mode does not run over serial lines.

If there is no operational router on the attached network, you must manually configure the interface as described in the previous sections. Also, if a discovery mode interface is restarted, another operational router must be present before the interface will become operational.

A nondiscovery mode interface (also called a seed router) starts up as follows. The seed router acquires its configuration from memory. If the stored configuration is not completely specified with the **appletalk address** or **appletalk cable-range** command and the **appletalk zone** command, the interface will not start up. If completely specified, the interface will attempt to verify the stored configuration with another router on the attached network. If there is any discrepancy, the interface will not start up. If there are no neighboring operational routers, the router will assume the interface's stored configuration is correct, and the interface will become operational.

Using discovery mode does not affect an interface's ability to respond to configuration queries from other routers on the connected network once the interface becomes operational.

When activating discovery mode, you do not need to assign a zone name. The interface will acquire the zone name from another interface.



Caution Do not enable discovery mode on all routers on a network. If you do and all routers restart simultaneously (for instance, after a power failure), the network will be inaccessible until you manually configure at least one router.

Dynamically Configure a Nonextended Interface

You can activate discovery mode on a nonextended interface in one of two ways, depending on whether you know the network number of the attached network.

In the first method, you immediately place the interface into discovery mode by specifying an AppleTalk address of 0.0. Use this method when you do not know the network number of the attached network. To use this method, perform the following task in interface configuration mode:

Task	Command
Place the interface into discovery mode by assigning it the AppleTalk address 0.0.	appletalk address 0.0

For an example of how to configure discovery mode using this method, see the section “Configuring a Nonextended Network in Discovery Mode Example” later in this chapter.

In the second method, you first assign an address to the interface and then explicitly enable discovery mode. Use this method when you know the network number of the attached network. Note that you are not required to use this method when you know the network number. To use this method, perform the following tasks in interface configuration mode:

Task	Command
Step 1 Assign an AppleTalk address to the interface.	appletalk address <i>network.node</i>
Step 2 Place the interface into discovery mode.	appletalk discovery

Dynamically Configure an Extended Interface

You can activate discovery mode on an extended interface in one of two ways, depending on whether you know the cable range of the attached network.

In the first method, you immediately place the interface into discovery mode by specifying a cable range of 0–0. Use this method when you do not know the network number of the attached network. To use this method, perform the following task in interface configuration mode:

Task	Command
Place the interface into discovery mode by assigning it the cable range 0-0.	appletalk cable-range 0-0

In the second method, you first assign cable ranges and then explicitly enable discovery mode. Use this method when you know the cable range of the attached network. Note, however, that you are not required to use this method if you know the cable range. To use this method, perform the following tasks in interface configuration mode:

Task	Command
Step 1 Assign an AppleTalk address to the interface.	appletalk cable-range <i>start-end</i> [<i>network.node</i>]
Step 2 Place the interface into discovery mode.	appletalk discovery

Configure Transition Mode

Our router can route packets between extended and nonextended AppleTalk networks that coexist on the same cable. This type of routing is referred to as transition mode.

To use transition mode, you must have two router ports connected to the same physical cable. One port is configured as a nonextended AppleTalk network, and the other port is configured as an extended AppleTalk network. Each port must have unique network numbers, because you are routing between two separate AppleTalk networks: the extended network and the nonextended network.

To configure transition mode, you must have two ports on the same router that are connected to the same physical cable. You configure one port as a nonextended AppleTalk network by performing the following tasks in interface configuration mode:

Task	Command
Step 1 Assign an AppleTalk address to the interface.	appletalk address <i>network.node</i>
Step 2 Assign a zone name to the interface.	appletalk zone <i>zone-name</i>

You configure the second port as an extended AppleTalk network by performing the following tasks in interface configuration mode:

Task	Command
Step 1 Assign an AppleTalk cable range to the interface.	appletalk cable-range <i>start-end</i> [<i>network.node</i>]
Step 2 Assign a zone name to the interface.	appletalk zone <i>zone-name</i>

In the two **interface** commands that you specify to enter interface configuration mode, the *type* must be the same (for example, both could be Ethernet) and the *unit* must be different (for example, 0 and 1).

For an example of how to configure transition mode, see the section “Configuring a Nonextended Network in Discovery Mode Example” later in this chapter.

Control Access to AppleTalk Networks

An *access list* is a list of AppleTalk network numbers or zones that is maintained by the router and used to control access to or from specific zones or networks.

The router supports two general types of AppleTalk access lists:

- AppleTalk-style access lists, which are based on AppleTalk zones
- IP-style access lists, which are based on network numbers

AppleTalk-style access lists regulate the internetwork using zone names. Zone names are good control points, because they are the only network-level abstraction that users can access. You can express zones names either explicitly or by using generalized argument keywords. Thus, using AppleTalk access lists simplifies network management and allows for greater flexibility when adding segments, because reconfiguration requirements are minimal.

The main advantage of AppleTalk-style access lists is that they allow you to define access regardless of the existing network topology or any changes in future topologies—because they are based on zones. A zone access list is effectively a dynamic list of network numbers. The user specifies a zone name, but the effect is as if the user had specified all the network numbers belonging to that zone.

IP-style access lists control network access based on network numbers. This feature may useful in defining access lists that control the disposition of networks that overlap, are contained by, or exactly match a specific network number range. One class of problem addressed by the use of network number-based access lists involves the potential assignment of conflicting network numbers to different networks. An access list can be used to restrict the network numbers and zones that a department can advertise, thereby limiting advertisement to an authorized set of networks. In general, zone-based access lists are insufficient for this application.

In general, however, using IP-style access lists is not recommended, because the controls are not optimal: they ignore the logical mapping provided by AppleTalk zones. One problem with IP-style access lists is that when you add networks to a zone, you must reconfigure each secure router. Another problem is that because anyone can add network segments (for example, if one group of users gets a LaserWriter and installs a Cayman GatorBox, this creates a new network segment), the potential for confusion and misconfiguration is significant.

You can combine zone and network entries in a single access list. Network filtering is performed first, then zone filtering is applied to the result. However, for optimal performance, access lists should not include both zones and numeric network entries.

There are three types of filters you can use on AppleTalk networks:

- Data packet filters
- Filters for controlling routing table updates
- GetZoneList (GZL) filters

AppleTalk network access control differs from that of other protocols in that the order of the entries in an access list is unimportant. However, there are still some constraints you need to keep in mind when defining access lists:

- You must design and type access list entries properly to ensure that entries do not overlap each other. An example of an overlap is if you were to enter a “permit network *xxx*” command and then enter a “deny network *xxx*” command. If you do enter entries that overlap, the last one you entered overwrites and removes the previous one from the access list. In the example earlier in this paragraph, this means that the “permit network” statement would be removed from the access list when you typed the “deny network” statement.
- Each access list always has a method for handling packets or routing updates that do not satisfy any of the access control statements in the access list.

To explicitly specify how you want these packets or routing updates to be handled, use the **access-list other-access** command when defining access conditions for networks and cable ranges, and use the **access-list additional-zones** command when defining access conditions for zones. If you use one of these commands, it does not matter where in the list you place it: The router software automatically places the **access-list other-access** or **access-list additional-zones** command at the end of the access list. (With other protocols, you must type the equivalent commands last.)

If you do not explicitly specify how to handle packets or routing updates that do not satisfy any of the access control statements in the access list, the packets or routing updates are automatically denied access and, in the case of data packets, are discarded.

You perform the following tasks to control access to AppleTalk networks. These tasks are described in the sections that follow.

Step 1 Create access lists.

Step 2 Create filters.

Create Access Lists

An access list defines the conditions used to filter packets sent in to or out of the interface. Each access list is identified by a number. All **access-list** commands that specify the same access list number create a single access list.

A single access list can contain any number and any combination of **access-list** commands. You can include network and cable range **access-list** commands and zone **access-list** commands in the same access list. However, you can only specify one each of the commands that specify default actions to take if none of the access conditions are matched (that is, a single access list can include only one **access-list other-access** command to handle networks and cable ranges that do not match the access conditions and only one **access-list additional-zones** command to handle zones that do not match the access conditions).

To create access lists that define access conditions for networks and cable ranges, perform one or more of the following tasks in global configuration mode:

Task	Command
Define access for a single network number.	access-list <i>access-list-number</i> {deny permit} network <i>network</i>
Define access for a single cable range.	access-list <i>access-list-number</i> {deny permit} cable-range <i>start-end</i>
Define access for an extended or a nonextended network that overlaps any part of the specified range.	access-list <i>access-list-number</i> {deny permit} includes <i>start-end</i>
Define access for an extended or a nonextended network that is included entirely within the specified range.	access-list <i>access-list-number</i> {deny permit} within <i>start-end</i>
Define the default action to take for access checks that apply to network numbers or cable ranges.	access-list <i>access-list-number</i> {deny permit} other-access

The access list number can be a decimal value from 600 to 699.

To create access lists that define access conditions for zones, perform one or more of the following tasks in global configuration mode:

Task	Command
Define access for a zone.	access-list <i>access-list-number</i> {deny permit} zone <i>zone-name</i>
Define the default action to take for access checks that apply to zones.	access-list <i>access-list-number</i> {deny permit} additional-zones

The access list number can be a decimal value from 600 to 699.

Create Filters

A filter examines specific packets that pass through an interface and permits or denies them based on the conditions defined in the access lists that have been applied to that interface.

You can filter the following types of AppleTalk packets:

- Data packets
- Routing table updates
- GetZoneList (GZL) requests

Note The three types of filters are completely independent of each other. This means that if, for example, you apply a data packet filter to an interface, that filter has no effect on incoming routing table updates or GZL requests that pass through that interface. The exception to this is that outgoing routing update filters can affect GZL updates.

You can apply one of each type of filter to each interface, for a total of three filters per interface. Each filter can use the same access list or different access lists.

Data packet filters and incoming routing table update filters use access lists that define conditions for networks and cable ranges only. Outgoing routing update filters use access lists that define conditions for networks, cable ranges, and zones. GZL filters use access lists that define conditions for zones only.

The following sections explain the tasks for creating AppleTalk filters.

Create Data Packet Filters

A data packet filter checks data packets being sent out an interface. If the packets' source network or cable range has access denied, these packets are not transmitted but rather, are discarded.

Data packet filters use access lists that define conditions for networks and cable ranges only. They ignore any zone information that may be in the access list.

When you apply a data packet filter to an interface, you should ensure that all networks or cable ranges within a zone are governed by the same filters.

To create a data packet filter, perform the following tasks:

Step 1 Create a network-only access list.

Step 2 Apply a data packet filter to an interface.

To create a network-only access list, perform one or more of the following tasks in global configuration mode:

Task	Command
Define an access list for a single network number.	access-list <i>access-list-number</i> {deny permit} network <i>network</i>
Define an access list for a range of network numbers.	access-list <i>access-list-number</i> {deny permit} cable-range <i>start-end</i>
Define an access list for a range of network numbers.	access-list <i>access-list-number</i> {deny permit} includes <i>start-end</i>
Define an access list for a range of network numbers.	access-list <i>access-list-number</i> {deny permit} within <i>start-end</i>
Define the default action to take for access checks that apply to networks or cable ranges.	access-list <i>access-list-number</i> {deny permit} other-access

Note that several of the commands used to perform the above tasks are functionally equivalent.

To apply the data packet filter to an interface, perform the following task in interface configuration mode:

Task	Command
Apply the data packet filter to the interface.	appletalk access-group <i>access-list-number</i>

For an example of how to create data packet filters, see the section “AppleTalk Access List Examples” later in this chapter.

Create Routing Table Update Filters

Routing table update filters control which updates the local routing table accepts and which routes the local router advertises in its routing updates. You create distribution lists to control the filtering of routing updates.

Filters for incoming routing updates use access lists that define conditions for networks and cable ranges only. Filters for outgoing routing updates use access lists that define conditions for networks and cable ranges, and for zones.

When filtering incoming routing updates, each network number and cable range in the update is checked against the access list. If you have not applied an access list to the interface, all network numbers and cable ranges in the routing update are added to the routing table. If an access list has been applied to the interface, only network numbers and cable ranges that satisfy the following condition are added to the routing table:

- The network number or cable range is not explicitly or implicitly denied.

The following conditions also are applied when filtering routing updates generated by the local router:

- The network number or cable range is not a member of a zone that is explicitly or implicitly denied.
- If partial zone processing is disabled (default), the network number or cable range is not a member of a zone that contains other denied network numbers and/or cable ranges.

To create a filter for routing table updates received on an interface, perform the following tasks:

Step 1 Create an access list.

Step 2 Apply a routing table update filter to an interface.

To create an access list, perform one or more of the following tasks in global configuration mode:

Task	Command
Define an access list for a single network number (for nonextended networks only).	access-list <i>access-list-number</i> {deny permit} network <i>network</i>
Define an access list for a single cable range (for extended networks only).	access-list <i>access-list-number</i> {deny permit} cable-range <i>start-end</i>
Define an access list for an extended or a nonextended network that overlaps any part of a range of network numbers or cable ranges.	access-list <i>access-list-number</i> {deny permit} includes <i>start-end</i>
Define an access list for an extended or a nonextended network whose network number or cable range is included entirely within the specified cable range.	access-list <i>access-list-number</i> {deny permit} within <i>start-end</i>
Define the default action to take for access checks that apply to networks or cable ranges.	access-list <i>access-list-number</i> {deny permit} other-access



Caution Ensure that access list(s) used to filter incoming routing updates do not contain any zone entries. If they do, these entries may cause undefined behavior.

To apply the filter to incoming routing updates on an interface, perform the following task in interface configuration mode:

Task	Command
Apply the routing update filter.	appletalk distribute-list <i>access-list-number</i> in

For an example of how to create a filter for incoming routing table updates, see the section “AppleTalk Access List Examples” later in this chapter.

To create a filter for routing table updates sent out on an interface, perform the following tasks:

Step 1 Create an access list.

Step 2 Apply a routing table update filter to an interface.

To create an access list, perform one or more of the following tasks in global configuration mode:

Task	Command
Define an access list for a single network number (for nonextended networks only).	access-list <i>access-list-number</i> { deny permit } network <i>network</i>
Define an access list for a single cable range (for extended networks only).	access-list <i>access-list-number</i> { deny permit } cable-range <i>start-end</i>
Define an access list for an extended or a nonextended network that overlaps any part of a range of network numbers or cable ranges.	access-list <i>access-list-number</i> { deny permit } includes <i>start-end</i>
Define an access list for an extended or a nonextended network whose network number or cable range is included entirely within the specified cable range.	access-list <i>access-list-number</i> { deny permit } within <i>start-end</i>
Define the default action to take for access checks that apply to networks or cable ranges.	access-list <i>access-list-number</i> { deny permit } other-access
Define access for a zone.	access-list <i>access-list-number</i> { deny permit } zone <i>zone-name</i>
Define the default action to take for access checks that apply to zones.	access-list <i>access-list-number</i> { deny permit } additional-zones

To apply a filter to routing updates sent out on an interface, perform the following task in interface configuration mode:

Task	Command
Apply the routing update filter.	appletalk distribute-list <i>access-list-number</i> out

Create GetZoneList (GZL) Filters

The Macintosh Chooser uses ZIP GetZoneList (GZL) requests to compile a list of zones from which the user can select services. Any router on the same network as the Macintosh can respond to these requests with a GZL reply. You can create a GZL filter on the router to control which zones the router mentions in its GZL replies. This has the effect of controlling the list of zones that are displayed by the Chooser.

When defining GZL filters, you should ensure that all routers on the same network filter GZL replies identically. Otherwise, the Chooser will list different zones depending upon which router responded to the request. Also, inconsistent filters can result in zones appearing and disappearing every few seconds when the user remains in the Chooser. Because of these inconsistencies, you should normally use the **appletalk getzonelist-filter** command only when all routers in the internetwork are our routers, unless the other vendors' routers have a similar feature.

When a ZIP GetZoneList reply is generated, only zones that satisfy the following conditions are included:

- If partial zones are permitted, at least one network number or cable range that is a member of the zone is explicitly or implicitly permitted.
- If partial zones are not permitted (the default), all network numbers or cable ranges that are members of the zone are explicitly or implicitly permitted.
- The zone is explicitly or implicitly permitted.

Replies to GetZoneList requests also are filtered by any **appletalk distribute-list out** filter that has been applied to the same interface. You need to specify an **appletalk getzonelist-filter** command only if you want additional filtering to be applied to GZL replies. This filter is rarely needed except to eliminate zones that do not contain user services.

Using a GZL filter is not a complete replacement for anonymous network numbers. In order to prevent users from seeing a zone, all routers must implement the GZL filter. If there are any routers on the network from other vendors, the GZL filter will not have a consistent effect.

To create a GZL filter, perform the following tasks:

Step 1 Create an access list.

Step 2 Apply a GZL filter to an interface.

To create an access list, perform one or more of the following tasks in global configuration mode:

Task	Command
Define access for a zone.	access-list <i>access-list-number</i> { deny permit } zone <i>zone-name</i>
Define the default action to take for access checks that apply to zones.	access-list <i>access-list-number</i> { deny permit } additional-zones

To apply the GZL filter to an interface, perform the following task in interface configuration mode:

Task	Command
Apply the GZL filter.	appletalk getzonelist-filter <i>access-list-number</i>

Enable Partial Zone Filters

If access to any network in a zone is denied, access to that zone is also denied by default. However, if you enable partial zones, access to other networks in that zone is no longer denied.

The permitting of partial zones provides IP-style access control. If enabled, the access control list behavior associated with prior software releases is restored. In addition, NBP cannot ensure consistency and uniqueness of name bindings.

If you permit partial zones, AppleTalk cannot maintain consistency for the nodes in the affected zones, and the results are undefined. With this option enabled, an inconsistency is created for the zone, and several assumptions made by some AppleTalk protocols are no longer valid.

To enable partial zone filters, perform the following task in global configuration mode:

Task	Command
Permit access to networks in a zone in which access to a network in that zone is denied.	appletalk permit-partial-zones

Permitting partial zones affects the **appletalk distribute-list out** and **appletalk getzonelist-filter** commands.

Configure the Name Display Facility

The AppleTalk Name Binding Protocol (NBP) associates AppleTalk network entity names (that is, AppleTalk network-addressable services) with network addresses. NBP allows you to specify descriptive or symbolic names for entities instead of their numerical addresses. When you specify the name of an AppleTalk device, NBP translates the device's entity name into the entity's network address. The name binding process includes name registration, name confirmation, name deletion, and name lookup.

Node addresses can change frequently, because AppleTalk uses dynamic addresses. Therefore, NBP associates numerical node addresses with aliases that continue to reference the correct addresses if the addresses change. These node addresses do not change very frequently, because each device keeps track of the last node number it was assigned. Typically, node numbers change only if a device is shut down for an extended period of time or if it is moved to another network segment.

To control the router's name display facility, perform one or both of the following tasks in global configuration mode:

Task	Command
Specify which service types are retained in the name cache.	appletalk lookup-type <i>service-type</i>
Set the interval between service pollings by the router on its AppleTalk interfaces.	appletalk name-lookup-interval <i>seconds</i>

Set Up Special Configurations

This section describes the tasks you must perform to set up the following special configurations:

- Configure free-trade zones
- Configure SNMP in AppleTalk networks

- Configure AppleTalk tunneling
- Configure AppleTalk MacIP
- Configure IP Talk
- Configure AppleTalk over WANs

Configure Free-Trade Zones

A free-trade zone is a part of an AppleTalk internet that is accessible by two other parts of the internet, neither of which can access the other. You might want to create a free-trade zone to allow the exchange of information between two organizations that otherwise want to keep their internets isolated from each other or that do not have physical connectivity with one another.

To establish a free-trade zone, perform the following task in interface configuration mode:

Task	Command
Establish a free-trade zone.	appletalk free-trade-zone

Configure SNMP in AppleTalk Networks

SNMP normally uses UDP, IP's connectionless datagram service, to monitor network entities. Our router software lets you run SNMP using DDP, the AppleTalk datagram service. Use DDP if you have SNMP consoles running on a Macintosh.

You must configure AppleTalk routing globally and on an interface basis before you configure SNMP for the router.

To configure SNMP in AppleTalk networks, perform the following tasks:

Task	Command
Step 1 Enter global configuration mode.	See Table 2-1.
Step 2 Disable SNMP on the router.	no snmp server
Step 3 Enable AppleTalk routing on the router.	appletalk routing
Step 4 Enable Appletalk event logging.	appletalk event-logging
Step 5 Enter interface configuration mode	See Table 2-1.
Step 6 Enable IP routing on the interface.	ip address <i>address</i>
Step 7 Enable AppleTalk routing on the interface.	appletalk cable-range <i>start-end</i> [<i>network.node</i>]
Step 8 Set a zone name for the AppleTalk network.	appletalk zone <i>zone-name</i>
Step 9 Enable SNMP server operations.	snmp-server community <i>string</i> [R] [W]

For an example of configuring SNMP, see the section "SNMP-over-DDP Example" later in this chapter.

Refer to Chapter 5 for information about configuring SNMP on the router.

Configure AppleTalk Tunneling

When connecting two AppleTalk networks with a non-AppleTalk backbone, such as IP, the relatively high bandwidth consumed by the broadcasting of Routing Table Maintenance Protocol (RTMP) data packets can severely hamper the backbone's network performance. This problem can be solved by tunneling AppleTalk through a foreign protocol, such as IP. Tunneling encapsulates an AppleTalk packet inside the foreign protocol packet, which is then sent across the backbone to a destination router. The destination router then de-encapsulates the AppleTalk packet and, if necessary, routes the packet to a normal AppleTalk network. Because the tunnel exists between only two points on the network and because the encapsulated AppleTalk packet is sent in a directed manner to a remote IP address, bandwidth usage is greatly reduced. Furthermore, the encapsulated packet benefits from any features normally enjoyed by IP packets, including default routes and load balancing.

There are two ways to tunnel AppleTalk. The first method implements Cayman tunneling as designed by Cayman Systems. This method enables routers to interoperate with Cayman GatorBoxes. The second method is a proprietary tunneling protocol known as generic route encapsulation (GRE).

When you use Cayman tunneling, you can have our routers at either end of the tunnel, or you can have a GatorBox at one end and our router at the other end. When you use GRE tunneling, you must have only our routers at both ends of the tunnel connection.

Multiple tunnels originating from the router are supported.

Logically, tunnels are point-to-point links. This requires that you configure a separate tunnel for each link.

To configure a Cayman tunnel, perform the following tasks.

Task	Command
Step 1	Configure a tunnel interface.
Step 2	Specify the interface out which the encapsulated packets will be sent.
Step 3	Specify the IP address of the router at the far end of the tunnel.
Step 4	Enable Cayman tunneling.



Caution Do not configure a Cayman tunnel with an AppleTalk network address.

To configure a GRE tunnel, perform the following tasks. Note that a GRE tunnel requires an AppleTalk network address and a zone.

Task	Command
Step 1 Enable tunneling on the interface.	interface tunnel <i>n</i>
Step 2 Assign a cable range to an interface.	appletalk cable-range <i>start-end</i> [<i>network.node</i>]
Step 3 Set a zone name for the connected AppleTalk network.	appletalk zone <i>zone-name</i>
Step 4 Specify the interface out which the encapsulated packets will be sent, or specify the router's IP address.	tunnel source [<i>interface</i> <i>ip-address</i>]
Step 5 Specify the IP address of the router at the far end of the tunnel.	tunnel destination <i>ip-address</i>
Step 6 Enable GRE tunneling.	tunnel mode gre ip

Configure AppleTalk MacIP

Our routers implement MacIP, which is a protocol that allows routing of IP datagrams to IP clients using the AppleTalk Datagram Delivery Protocol (DDP) for low-level encapsulation.

Our routers implement the MacIP address management and routing services described in the ANF draft RFC, *A Standard for the Transmission of Internet Packets over AppleTalk Networks*. Our implementation of MacIP conforms to the September 1991 draft RFC with the following exceptions:

- Our routers do not fragment IP datagrams that exceed the DDP MTU and that are bound for DDP clients of MacIP.
- Our routers do not route to DDP clients outside of configured MacIP client ranges.

Some situations require the use of MacIP. For example, if some of your Macintosh users use AppleTalk Remote Access, or are connected to the network using LocalTalk or PhoneNet cabling systems, then MacIP is required to provide access to IP network servers for those users.

MacIP services also can be useful when you are managing IP address allocations for a large, dynamic Macintosh population. There are several advantages to using MacIP in this situation:

- Macintosh TCP/IP drivers can be configured in a completely standard way, regardless of the location of the Macintosh. Essentially, the dynamic properties of AppleTalk address management become available for IP address allocation.
- You can modify all global parameters, such as IP subnet mask, DNS services, and default routers. Macintosh IP users receive the updates by restarting their local TCP/IP drivers.
- The network administrator can monitor MacIP address allocations and packet statistics remotely by using the Telnet application to attach to the router console. This allows central administration of IP allocations in remote locations. For Internet sites, it allows remote technical assistance.

However, there are several disadvantages in implementing MacIP on our routers:

- Each packet from a Macintosh client destined for an IP host or vice versa must pass through the router if the client is using the router as a MacIP server. The router is not always a necessary hop, so this increases traffic through the router. There is also a slight increase in router CPU use that is directly proportional to the number of packets delivered to and from active MacIP clients.

- Memory usage in the router increases in direct proportion to the total number of active MacIP clients (about 80 bytes per client).

To configure MacIP on our routers, AppleTalk must be configured as follows:

- AppleTalk routing must be enabled on at least one interface.
- IP routing must be enabled on at least one interface.
- The MacIP zone name you configure must be associated with a configured or seeded zone name.
- Any IP address specified in configuring a MacIP server using an **appletalk macip** command must be aliasable to a specific IP interface on the router. Because the router is acting as a proxy for MacIP clients, you must use an IP address to which ARP can respond.
- If you are using MacIP to allow Macintoshes to communicate with IP hosts on the same LAN segment (that is, the Macintoshes are on the router interface on which MacIP is configured) and the IP hosts have extended IP access lists, these access lists should include entries to permit IP traffic destined for these IP hosts from the MacIP addresses. If these entries are not present, packets destined for IP hosts on the local segment will be blocked (that is, they will not be forwarded).

When setting up MacIP routing, keep the following address range issues in mind:

- Static and dynamic resource statements are cumulative, and you can specify as many as necessary. However, if possible, you should specify a single all-inclusive range rather than several adjacent ranges. For example, specifying the range 131.108.121.1 to 131.108.121.10 is preferable to specifying the ranges 131.108.121.1 to 131.108.121.5 and 131.108.121.6 to 131.108.121.10.
- Overlapping resource ranges (for example, 131.108.121.1 to 131.108.121.5 and 131.108.121.5 to 131.108.121.10) are not allowed. If it is necessary to change a range in a running server, use the negative form of the resource address assignment command (such as **no appletalk macip dynamic ip-address ip-address zone server-zone**) to delete the original range, followed by the corrected range statement.
- You can add IP address allocations to a running server at any time as long as the new address range does not overlap with one of the current ranges.

To configure MacIP, perform the following tasks:

Step 1 Establish a MacIP server for a specific zone.

Step 2 Allocate IP addresses for Macintosh users by specifying at least one dynamic or static resource address assignment command for each MacIP server.

To establish a MacIP server for a specific zone, perform the following global configuration task:

Task	Command
Establish a MacIP server for a zone.	appletalk macip server ip-address zone server-zone

You can configure multiple MacIP servers for a router, but you can assign only one MacIP server to a zone, and you can assign only one IP interface to a MacIP server. In general, you must be able to establish an alias between the IP address you assign with the **appletalk macip server** command and an existing IP interface. For implementation simplicity, it is suggested that the address you specify in this command match an existing IP interface address.

A server is not registered by NBP until at least one MacIP resource is configured.

Dynamic clients are those that accept any IP address assignment within the dynamic range specified. Dynamic addresses are for users who do not require a fixed address, but can be assigned addresses from a pool.

To allocate IP addresses for Macintosh users if you are using dynamic addresses, perform the following global configuration task:

Task	Command
Allocate an IP address to a MacIP client.	appletalk macip dynamic <i>ip-address</i> [<i>ip-address</i>] zone <i>server-zone</i>

For an example of configuring MacIP with dynamic addresses, see the section “MacIP Examples” later in this chapter.

Static addresses are for users who require fixed addresses for IP DNS services and for administrators who do not want addresses to change so they always know the IP addresses of the devices on their network.

To allocate IP addresses for Macintosh users if you are using static addresses, perform the following global configuration task:

Task	Command
Allocate an IP address to be used by a MacIP client that has reserved a static IP address.	appletalk macip static <i>ip-address</i> [<i>ip-address</i>] zone <i>server-zone</i>

For an example of configuring MacIP with static addresses, see the section “MacIP Examples” later in this chapter.

In general, it is recommended that you do not use fragmented address ranges in configuring ranges for MacIP. However, if this is unavoidable, use the **appletalk macip dynamic** command to specify as many addresses or ranges as required, and use the **appletalk macip static** command to assign a specific address or address range.

Configure IP Talk

IP Talk is a protocol for encapsulating AppleTalk packets in IP datagrams. IP Talk is used to route AppleTalk packets across non-AppleTalk backbones and to communicate with applications on hosts that cannot otherwise communicate via AppleTalk, such as the Columbia AppleTalk Package (CAP). IP Talk also allows serial connections to use IP Talk Serial Line Interface Protocol (SLIP) drivers.

To configure IP Talk on an interface, perform the following tasks:

- Step 1** Configure IP encapsulation of AppleTalk packets.
- Step 2** Specify the User Datagram Protocol (UDP) port number that is the beginning of the range of UDP ports used in mapping AppleTalk well-known DDP socket numbers to UDP ports.

For a description of setting up UNIX-based systems and the router to use CAP IP Talk and other IP Talk implementations, see the section “IP Talk Example” later in this chapter.

The installation instructions for CAP refer to KIP gateways and to the file *atalkatab*. If you use our IP Talk support, it is not necessary nor is it desirable to use *atalkatab*. Our IP Talk support assumes that you want to use the standard AppleTalk routing protocols to perform all wide-area AppleTalk

routing. KIP and *atalkatab* are based on an alternative routing strategy in which AppleTalk packets are transmitted using IP routing. It is possible to use both strategies at the same time; however, the interaction between the two routing techniques is not well defined.

If your network has other vendors' routers that support *atalkatab*, you should disable *atalkatab* support on them to avoid mixing the routing strategies. The installation instructions provided with some of these products encourage you to use *atalkatab* for complex networks. However, with our routers this is not necessary, because our implementation of IPTalk integrates IPTalk into the standard AppleTalk network routing.

The network diagram in Figure 12-1 illustrates how you should set up IPTalk. In this configuration, you enable both standard AppleTalk (EtherTalk) and IPTalk on the Ethernet networks on Router A and Router B. These routers then use EtherTalk to communicate with the LocalTalk routers and Macintosh computers, and IPTalk to communicate with the UNIX systems. On the LocalTalk routers, you also should enable both EtherTalk and IPTalk, making sure you configure IPTalk with *atalkatab* disabled. These routers then use IPTalk to communicate with the UNIX systems adjacent to them and EtherTalk to communicate with the rest of the AppleTalk network. This configuration strategy minimizes the number of hops between routers. If you did not enable IPTalk on the LocalTalk routers, systems on the LocalTalk router that wanted to communicate with the adjacent UNIX system would have to go through Router A or Router B. This creates an unnecessary extra hop.




Figure 12-1 IPTalk Configuration Example

Note In this configuration, all traffic between systems on the left and right sides of the packet-switched network transit via Routers A and B using AppleTalk routing. If you were to enable *atalkatab* support on the LocalTalk routers, this would establish a hidden path between Routers A and B, unknown to the standard AppleTalk routing protocols. In a large network, this could result in traffic taking inexplicable routes.

Configure IP Encapsulation of AppleTalk Packets

To allow AppleTalk to communicate with UNIX hosts running older versions of CAP that do not support native AppleTalk EtherTalk encapsulations, you need to configure IP encapsulation of AppleTalk packets. (Typically, Apple Macintosh users would communicate with these servers by

routing their connections through a Kinetics FastPath router running KIP [Kinetics IP] software.) Newer versions of CAP provide native AppleTalk EtherTalk encapsulations, so the IPTalk encapsulation is not longer required. Our implementation of IPTalk assumes that AppleTalk is already being routed on the backbone, because there is currently no LocalTalk hardware interface for our routers.

You can configure IPTalk on an interface that already has a configured IP address.

Our implementation of IPTalk does not support manually configured AppleTalk-to-IP-address mapping (atab). The address mapping provided is the same as the Kinetics IPTalk implementation when the atab facility is not enabled. This address mapping works as follows: The IP subnet mask used on the router Ethernet interface on which IPTalk is enabled is inverted (one's complement). The result is then masked against 255 (0xFF hexadecimal), and the result of this is then masked against the low-order 8 bits of the IP address to give the AppleTalk node number.

The following example configuration illustrates how the address mapping is done:

```
interface ethernet 0
ip address 131.108.1.118 255.255.255.0
appletalk address 20.129
appletalk zone Native AppleTalk
appletalk iptalk 30.0 UDPZone
```

First, the IP subnet mask of 255.255.255.0 is inverted to give 0.0.0.255. This value then is masked with 255 to give 255. Next, 255 is masked with the low-order 8 bits of the interface IP address (118) to yield an AppleTalk node number of 118. This means that the AppleTalk address of the Ethernet 0 interface seen in the UDPZone zone is 30.118.

You should note the following caveat: If the host field of an IP subnet mask for an interface is longer than 8 bits, it will be possible to obtain conflicting AppleTalk node numbers. For instance, if the subnet mask for the Ethernet 0 interface above is 255.255.240.0, the host field is 12 bits wide.

To configure IP encapsulation of AppleTalk packets, perform the following tasks in interface configuration mode:

Task	Command
Step 1 Configure an IP address on the interface.	ip address <i>address</i> [<i>mask</i>]
Step 2 Enable IPTalk encapsulation on the interface.	appletalk iptalk <i>net.node zone</i>

For an example of configuring IPTalk, see the section “IPTalk Example” later in this chapter.

Specify the UDP Port Ranges

Implementations of IPTalk prior to April 1988 mapped well-known DDP socket numbers to privileged User Datagram Protocol (UDP) ports starting at port number 768. In April 1988, the NIC assigned a range of UDP ports for the defined DDP well-known sockets starting at UDP port number 200 and assigned these ports the names at-nbp, at-rtmp, at-echo, and at-zis. Release 6 and later of the CAP program dynamically decides which port mapping to use. If there are no AppleTalk service entries in the UNIX system's */etc/services* file, CAP uses the older mapping starting at UDP port number 768.

The default UDP port mapping supported by our implementation of IPTalk is 768. If there are AppleTalk service entries in the UNIX system's */etc/services* file, you should specify the beginning of the UDP port mapping range with the **appletalk iptalk-baseport** command.

To specify the UDP port number that is the beginning of the range of UDP ports used in mapping AppleTalk well-known DDP socket numbers to UDP ports, perform the following task in global configuration mode:

Task	Command
Specify the starting UDP port number.	appletalk iptalk-baseport <i>port-number</i>

For an example of configuring IPTalk, see the section “IPTalk Example” later in this chapter.

Tune AppleTalk Network Performance

To tune AppleTalk network performance, you can perform one or more of the following tasks:

- Control routing updates
- Assign proxy network numbers
- Disable checksum generation and verification
- Control the AppleTalk ARP table
- Control the delay between ZIP queries
- Log significant network events
- Disable fast switching
- Enable the recognition of pre-FDDITalk packets

Control Routing Updates

The Routing Table Maintenance Protocol (RTMP) establishes and maintains the AppleTalk routing table. You can perform the following tasks to control packet routing and control routing updates:

- Disable routing of RTMP packets
- Disable the transmission of routing updates
- Prevent the advertisement of routes to networks with no associated zones
- Set routing update timers

Disable the Processing of Routed RTMP Packets

By default, the router performs strict RTMP checking, which discards any RTMP packets sent by routers that are not directly connected to the local router (that is, sent by routers that are not neighbors). This means that the local router does not accept any routed RTMP packets whose source is a remote network.

In almost all situations, you should leave RTMP checking enabled.

To disable RTMP checking and enable the processing of routed RTMP packets, perform the following task in global configuration mode:

Task	Command
Disable strict checking of RTMP updates.	no appletalk strict-rtmp-checking

Disable the Transmission of Routing Updates

By default, routers receive routing updates from their neighboring routers and periodically send routing updates to their neighbors. You can configure a router so that it only receives routing updates, but does not send any. You might want to do this to keep a particular router from sending routing updates to its neighbors because it is unreliable.

To disable the transmission of routing updates, perform the following task in interface configuration mode:

Task	Command
Disable the transmission of routing updates on an interface.	no appletalk send-rtmps

Prevent the Advertisement of Routes to Networks with No Associated Zones

The Name Binding Protocol (NBP) uses the Zone Information Protocol (ZIP) to determine which networks belong to which zones. The router uses ZIP to maintain a table of the AppleTalk internetwork that maps network numbers to zone names.

By default, the router does not advertise routes to networks that have no associated zones. This prevents the occurrence of ZIP protocol storms, which can arise when corrupt routes are propagated and routers broadcast ZIP requests to determine the network-zone associations. Not advertising routes to networks that do not have associated zones limits any ZIP protocol storms to a single network rather than allowing them to spread to the entire internetwork.

To allow the advertisement of routes to networks that have no associated zones, perform the following task in global configuration mode:

Task	Command
Allow the advertisement of routes to networks that have no associated zones.	no appletalk require-route-zones

The user zone lists can be configured to vary from interface to interface. However, this practice is discouraged, because AppleTalk users expect to have the same user zone lists at any end node in the internet. This kind of filtering does not prevent explicit access via programmatic methods, but should be considered a user optimization whereby unused zones are suppressed. Other forms of AppleTalk access control lists should be used to actually secure a zone or network.

Set Routing Table Update Timers

The router sends routing table updates at regular intervals. In rare instances you might want to change this interval, such as when a router is busy and cannot send routing updates every 10 seconds, or when slower routers are incapable of processing received routing updates in a large network. If you do change the routing update interval, be sure to do so for all routers on the network.



Caution Modifying the routing timers can degrade or destroy AppleTalk network connectivity. Many other AppleTalk router vendors provide no facility for modifying their routing timers, so adjusting our router's AppleTalk timers such that routing updates do not arrive at these other routers within the normal interval may result in loss of information about the network or loss of connectivity.

To change the routing table update timers, perform the following task in global configuration mode:

Task	Command
Change the routing update timers.	appletalk timers <i>update-interval valid-interval invalid-interval</i>

Assign Proxy Network Numbers

It is possible to have an AppleTalk internetwork in which some routers support only nonextended AppleTalk and others support only extended AppleTalk. You can enable interoperability between these two types of AppleTalk networks by assigning a proxy network number for each zone in which there is a router that supports only nonextended AppleTalk.

To assign proxy network numbers, perform the following task in global configuration mode:

Task	Command
Assign a proxy network number for each zone in which there is a router that supports only nonextended AppleTalk.	appletalk proxy-nbp <i>network-number zone-name</i>

For an example of configuring proxy network numbers, see the section “Proxy Network Number Example” later in this chapter.



Caution Do not also assign the proxy network number to a router or to a physical network.

You must assign one proxy network number for each zone. You can optionally define additional proxies with different network numbers to provide redundancy. Each proxy network number generates one or more packets for each forward request it receives, but discards all other packets sent to it. Thus, defining redundant proxy network numbers increases the NBP traffic linearly.

Disable Checksum Generation and Verification

By default, the router generates and verifies checksums for all AppleTalk packets (except routed packets). You might want to disable checksum generation and verification if you have older devices, such as LaserWriter printers, that cannot receive packets with checksums.

To disable checksum generation and verification, perform the following task in global configuration mode:

Task	Command
Disable the generation and verification of checksums for all AppleTalk packets.	no appletalk checksum

Control the AppleTalk ARP Table

You can perform the following tasks to control the AppleTalk ARP table:

- Set the timeout for ARP table entries
- Specify the time interval between the retransmission of ARP packets
- Specify the number of ARP retransmissions
- Disable the gleaning of ARP information from incoming packets

By default, entries in the AppleTalk ARP table are removed from the table if no update has been received in the last 4 hours. To change the ARP timeout interval, perform the following task in interface configuration mode:

Task	Command
Set the timeout for ARP table entries.	appletalk arp-timeout <i>interval</i>

The AppleTalk Address Resolution Protocol (AARP, or AppleTalk ARP) associates AppleTalk network addresses with media (data link) addresses. When AppleTalk must send a packet to another network node, the protocol address is passed to AppleTalk ARP, which undertakes a series of address negotiations to associate the protocol address with the media address.

If your AppleTalk network has devices that respond slowly, such as printers and overloaded file servers, you can lengthen the interval between AppleTalk ARP packets in order to allow the responses from these devices to be received. To do this, perform one or both of the following tasks in global configuration mode:

Task	Command
Specify the time interval between retransmission of ARP packets.	appletalk arp [{ probe request }] interval <i>interval</i>
Specify the number of retransmissions that will occur before abandoning address negotiations and using the selected address.	appletalk arp [{ probe request }] retransmit-count <i>number</i>

The router automatically derives ARP table entries from incoming packets. This process is referred to as “gleaning.” Gleaning speeds up the process of populating the ARP table. To disable the gleaning of ARP table entries, perform the following task in interface configuration mode:

Task	Command
Disable the gleaning of ARP information from incoming packets.	no appletalk glean-packets

Control the Delay between ZIP Queries

By default, the router sends ZIP queries every 10 seconds and uses the information received to update its zone table. To change the ZIP query interval, perform the following task in global configuration mode:

Task	Command
Set the ZIP query interval.	appletalk zip-query-interval <i>interval</i>

Log Significant Network Events

You can log information about significant network events performed on the router, including routing changes, zone creation, port status, and address. To do this, perform the following task in global configuration mode:

Task	Command
Log significant events.	appletalk event-logging

Disable Fast Switching

Fast switching allows higher throughput by switching a packet using a cache created by previous packets. Fast switching is enabled by default on all interfaces that support fast switching.

Packet transfer performance is generally better when fast switching is enabled. However, you may want to disable fast switching in order to save memory space on interface cards and to help avoid congestion when high-bandwidth interfaces are writing large amounts of information to low-bandwidth interfaces.

To disable AppleTalk fast switching on an interface, perform the following task in interface configuration mode:

Task	Command
Disable AppleTalk fast switching.	no appletalk route-cache

Enable the Recognition of Pre-FDDITalk Packets

To have the router recognize AppleTalk packets sent on the FDDI ring from routers running Cisco software releases prior to Release 9.0(3) or 9.1(2), perform the following task in interface configuration mode:

Task	Command
Enable the recognition of pre-FDDITalk packets.	appletalk pre-fdditalk

Configure AppleTalk over WANs

You can configure AppleTalk over X.25, Frame Relay, and SMDS networks. To do this, configure the appropriate address mappings as described in Chapters 7, 8, and 9, respectively.

For X.25, you can configure only a nonextended AppleTalk network. Logically, this network is the same as a LocalTalk network, because both are always nonextended networks. All AppleTalk nodes within an X.25 network must be configured with the same AppleTalk network number. Also, the network numbers and zone names on both sides of the serial link must be the same. When mapping the AppleTalk address to the X.121 address of the router with the **x25 map** command, include the keyword **broadcast** to simulate the AppleTalk broadcast capability. This is necessary because X.25 does not support broadcasts, but AppleTalk does. The broadcast simulation is done as follows: If the broadcast flag is set, whenever a broadcast packet is sent, each X.121 address specified will receive it.

Monitor the AppleTalk Network

The router software provides several commands you can use to monitor an AppleTalk network. In addition, you can use network monitoring packages, such as Apple Computer's *Inter•Poll*, to verify that a router is configured and operating properly. Use the commands described in this section to monitor an AppleTalk network using both router commands and network monitoring packages.

Monitor the AppleTalk Network Using Router Commands

To monitor the AppleTalk network, perform one or more of the following tasks at the EXEC prompt:

Task	Command
Delete entries from the AppleTalk ARP (AARP) table.	clear appletalk arp [<i>network.node</i>]
Delete entries from the neighbor table.	clear appletalk neighbor [<i>neighbor-address</i>]
Delete entries from the routing table.	clear appletalk route [<i>network</i>]
Delete entries from the zone name table.	clear appletalk zone [<i>zone-name</i>]
Diagnose basic AppleTalk network connectivity (user-level command).	ping appletalk <i>address</i>
Diagnose basic AppleTalk network connectivity (privileged command).	ping [appletalk] [<i>address</i>]
Display the AppleTalk access lists currently defined.	show appletalk access-lists [<i>access-list-number</i>]
Display the routes to networks that are directly connected or that are one hop away.	show appletalk adjacent-routes [<i>network</i>]
List the entries in the AppleTalk ARP table.	show appletalk arp
Display the contents of the AppleTalk fast-switching cache.	show appletalk cache
Display information about the router's AppleTalk internetwork and other parameters.	show appletalk global
Display AppleTalk-related interface settings.	show appletalk interface [brief] [<i>interface unit</i>]
Display the status of all known MacIP clients.	show appletalk macip-clients
Display the status of a router's MacIP servers.	show appletalk macip-servers
Display statistics about MacIP traffic.	show appletalk macip-traffic
Display a list of NBP services offered by nearby routers and by other devices that support NBP.	show appletalk name-cache

Task	Command
Display the contents of the NBP name registration table.	show appletalk nbp
Display information about the AppleTalk routers directly connected to any network to which this router is directly connected.	show appletalk neighbors [<i>neighbor-address</i>]
Display the contents of the AppleTalk routing table.	show appletalk route [<i>network</i> <i>unit type</i>]
Display the process-level operations in all sockets in an interface.	show appletalk socket [<i>socket-number</i>]
Display the statistics about AppleTalk protocol traffic, including MacIP traffic.	show appletalk traffic
Display the contents of the zone information table.	show appletalk zone [<i>zone-name</i>]

Monitor the AppleTalk Network Using Network Monitoring Packages

The router software supports network monitoring packages, such as Apple Computer's *Inter•Poll*, which are tools that use the AppleTalk responder and listener for verifying the router's configuration and operation. The router answers Appletalk responder requests. These response packets are received by the listener, which is installed on the Appletalk interface name registration socket. The response packets include the bootstrap firmware version string, followed by the router operating software version string. These strings are displayed in the Macintosh System version and the Macintosh printer driver version fields, respectively, in applications such as Apple's *Inter•Poll*. The response packet contains strings similar to those displayed by the **show version** EXEC command.

The router returns the following information in response to responder requests:

- System bootstrap version (ROM version).
- Software version.
- AppleTalk version. This is always 56, which is the first Apple Macintosh version that contained AppleTalk Phase 2 support.
- AppleTalk responder version. This is always 100, which indicates support of Version 1.0 responder packets.
- AppleShare status. This is reported as "not installed."

Figure 12-2 illustrates a typical output display for *Inter•Poll* that lists this information.

The screenshot shows the Inter•Poll output display with the following fields and controls:

- Device:** Net: 4042 Node: 9
router1.Ethernet3-ciscoRouter-Twilight Zone
- Packets:** 20
- Interval:** 2.5 Secs
- Timeout:** 1.5 Secs
- Using:**
 - Echo Pkts
 - Printer Status Packets
 - System Info Packets
- Buttons:** Stop, Done, Clear
- Packets Sent:** Rcvd: 4, Left: 16, Lost: 0, Total: 4
- Table:**

	Current	Average	Minimum	Maximum
Hops Away	3	3.00	3	3
Delay (secs)	0.02	0.02	0.02	0.02
- Status:**

System Bootstrap, Version 4.4(5.0), © 1986-1991 b...
GS Software (GS3), Version 9.21(3110), Development Software © 1991
Responder INIT Version: 100
AppleTalk Driver Version: 56 AppleShare not installed

Figure 12-2 *Inter•Poll* Output

AppleTalk Configuration Examples

Use the following configuration examples to help you configure AppleTalk routing on your router:

- Configuring an extended AppleTalk network example (page 12-31)
- Configuring a nonextended AppleTalk network example (page 12-32)
- Configuring a nonextended network in discovery mode example (page 12-33)
- Transition mode example (page 12-34)
- AppleTalk access list examples (page 12-35)
- MacIP examples (page 12-44)
- SNMP over DDP example (page 12-45)
- Proxy network numbers example (page 12-45)
- IP Talk example (page 12-46)

Configuring an Extended AppleTalk Network Example

The following example configures an extended AppleTalk network. It defines the zones Purgatory and Underworld. The cable range of one allows compatibility with nonextended AppleTalk networks.

```

appletalk routing
interface ethernet 0
appletalk cable-range 69-69 69.128
appletalk zone Purgatory
appletalk zone Underworld

```

Configuring a Nonextended AppleTalk Network Example

The following example configures a nonextended AppleTalk network that allows routing between two Ethernet networks. Ethernet interface 0 is connected to network 1 at node 128, and Ethernet interface 1 is connected to network 2 at node 154. Network 1 is in the Twilight zone, and network 2 is in the No Parking zone. See Figure 12-3.




Figure 12-3 Nonextended AppleTalk Routing between Two Ethernet Networks

```
appletalk routing
!
interface ethernet 0
appletalk address 1.128
appletalk zone Twilight
!
interface ethernet 1
appletalk address 2.154
appletalk zone No Parking
```


Configuring a Nonextended Network in Discovery Mode Example

The following example configures a nonextended network in discovery mode. There are seed routers on both networks to provide the zone and network number information to the interfaces when they start. See Figure 12-4.




Figure 12-4 Routing in Discovery Mode

Use the following commands to configure this nonextended network in discovery mode:

```
appletalk routing
!
interface ethernet 0
appletalk address 0.0
!
interface ethernet 1
appletalk address 0.0
```

Transition Mode Example

When in transition mode, the router can route packets between extended and nonextended AppleTalk networks that exist on the same cable.

To configure transition mode, you must have two ports connected to the same physical cable. One port is configured as a nonextended AppleTalk network, and the other is configured as an extended AppleTalk network. Both ports must have unique network numbers, because they are two separate networks. Figure 12-5 shows an example of the topology of this configuration.




Figure 12-5 Transition Mode Topology and Configuration

Use the following commands to configure this network. Note that networks 2-2 and 4-4 must have a cable range of one and a single zone in their zone lists. This is required to maintain compatibility with the nonextended network, network 3.

```
!This is an extended network.
interface ethernet 0
 appletalk cable-range 2-2
 appletalk zone No Parking
!
!This is a nonextended network.
interface ethernet 1
 appletalk address 3.128
 appletalk zone Twilight
!
!This is an extended network.
interface ethernet 2
 appletalk cable-range 4-4
 appletalk zone Do Not Enter
```

AppleTalk Access List Examples

Our implementation of AppleTalk provides several **access-list** commands that you can use to control access to AppleTalk networks. The examples that follow illustrate how to use these commands and show different approaches in applying access lists.

Defining an Access List to Filter Data Packets

The following commands create access list 601:

```
!Permit packets to be routed from network 55.
access-list 601 permit network 55

!Permit packets to be routed from network 500.
access-list 601 permit network 500

!Permit packets to be routed from networks 900 through 950.
access-list 601 permit cable-range 900-950

!Do not permit packets to be routed from networks 970 through 990.
access-list 601 deny includes 970-990

!Do not permit packets to be routed from networks 991 through 995.
access-list 601 permit within 991-995

!Deny routing to any network and cable range not specifically enumerated.
access-list 601 deny other-access
```

To use this access list to filter data packets, you apply it an interface (here, Ethernet interface 0) using the following commands:

```
appletalk routing
interface ethernet 0
appletalk cable-range 50-50
appletalk zone No Parking
appletalk access-group 601
```

The following examples illustrate how Ethernet interface 0 would handle outgoing data packets:

- Packets sourced from cable range 55–55 would be permitted.
- Packets sourced from any network in the cable range 972–980 are denied by the explicit match in the **access-list deny includes 970-990** command.

Defining an Access List to Filter Incoming Routing Table Updates

The following commands create access list 602. This section uses this example to illustrate how packets are processed by access lists; you would probably never create such a redundant access list.

```
access-list 602 permit network 55
access-list 602 permit cable 55-55
access-list 602 permit includes 55-55
access-list 602 permit within 55-55
```

To use this access list to filter routing table updates received on Ethernet interface 0, apply it to the interface using the following commands:

```

appletalk routing
interface ethernet 0
appletalk cable-range 50-50
appletalk zone No Parking
appletalk distribute-list 602 in
    
```

The following tables illustrate the process for accepting or rejecting routing update information. If the outcome of a test is true, the condition passes the access list specification and the **distribute-list** command specification is then applied.

Routing updates from network 55 would be processed as follows:

Access List Command	Outcome of Test
access-list 602 permit network 55	True
access-list 602 permit cable 55-55	False
access-list 602 permit includes 55-55	True
access-list 602 permit within 55-55	True

Routing updates from cable range 55-55 would be processed as follows:

Access List Command	Outcome of Test
access-list 602 permit network 55	False
access-list 602 permit cable 55-55	True
access-list 602 permit includes 55-55	True
access-list 602 permit within 55-55	True

Routing updates from cable range 55-60 would be processed as follows:

Access List Command	Outcome of Test
access-list 602 permit network 55	False
access-list 602 permit cable 55-55	False
access-list 602 permit includes 55-55	True
access-list 602 permit within 55-55	False

Comparison of Alternative Segmentation Solutions

With the flexibility allowed by our access list implementation, determining the optimal method to segment an AppleTalk environment using access control lists can be unclear. The following scenario and configuration examples illustrate two solutions to a particular problem and point out the inherent advantages of using AppleTalk-style access lists.

Consider a situation in which a company wants to permit customers to have direct access to several corporate file servers. Access is to be permitted to all devices in the zones named MIS and Corporate, but access is restricted to the Engineering zone because the file servers in these zones contain sensitive information. The solution is to create the appropriate access lists to enforce these access policies.

The company's AppleTalk internet consists of the following networks and zones:

Zone	Network Number or Cable Range
Engineering	69–69 3 4160–4160 15
MIS	666–777
Corporate	70–70 55 51004 4262–4262
World	88–88 9 9000–9999 (multiple networks exist in this range)

The router named Gatekeeper is placed between the World zone and the various company-specific zones. There can be an arbitrary number of routers on either side of Gatekeeper. An Ethernet backbone exists on each side of Gatekeeper, connecting these other routers to Gatekeeper. On the router Gatekeeper, Ethernet interface 0 (E0) connects to the World backbone and Ethernet interface 1 (E1) connects to the Corporate backbone.

For the purposes of this configuration, assume Gatekeeper is the only router that needs any access list configuration. There are two solutions, depending on the level of security desired.

A minimal configuration might be as follows. In this configuration, the Engineering zone is secured, but all other zones are publicly accessible.

```

appletalk routing
access-list 603 deny zone Engineering
access-list 603 permit additional-zones
access-list 603 permit other-access

interface ethernet 0
appletalk network 3
appletalk distribute-list 603 out
appletalk access-group 603

```

A more comprehensive configuration might be the following, in which the Corporate and MIS zones are public and all other zones are secured:

```

appletalk routing
access-list 603 permit zone Corporate
access-list 603 permit zone MIS
access-list 603 deny additional-zones
access-list 603 deny other-access

interface ethernet 0
appletalk network 3
appletalk distribute-list 603 out
appletalk access 603
    
```

Both configurations satisfy the basic goal of isolating the engineering servers, but the second example will continue to be secure when more zones are added in the future.

Configuring Partial Zone Advertisement

Figure 12-6 illustrates a configuration in which you might want to allow partial advertisement of a particular zone.




Figure 12-6 Example Topology of Partially Obscured Zone

Assume that Router B includes a router-update filter (applied with the **appletalk distribute-list** interface subcommand) on the Ethernet interface 3 that does not accept routing table updates from network 10, nor does it send routing table updates to that network:

```

access-list 612 deny network 10
access-list 612 permit other-access
interface ethernet 3
appletalk distribute-list 612 out
appletalk distribute-list 612 in
    
```

For Network 30, normal (default) behavior would be for Network 10 and Network 20 to be eliminated from any routing updates sent, although Network 15 would be included in routing updates (same zone as Network 30). Using the **appletalk permit-partial-zones** configuration command has the following effects:

- If permit-partial-zones is enabled (**appletalk permit-partial-zones**), the routing updates exclude Network 10, but *include* Network 15 and Network 20.
- If permit-partial-zones is disabled (**no appletalk permit-partial-zones**), the routing updates exclude both Network 10 and Network 20, but still include Network 15. This is generally considered the preferred behavior and is the default.

Table 12-2 summarizes the associations between the networks shown in Figure 12-6. Table 12-3 details the effects of enabling and disabling partial-zone advertisement with the **appletalk permit-partial-zones** command.

Table 12-2 Zone and Interface Associations for Partial Zone Advertisement Example

	Network 10	Network 15	Network 20	Network 30
Zone	A	B	A	B
Interface(s)	Ethernet 0	Ethernet 4	Ethernet 1 Ethernet 2	Ethernet 3

Table 12-3 Partial Zone Advertisement Control on Network 30

Command Condition	Network 10	Network 15	Network 20	Network 30
Enabled	Not Advertised on Network 30	Advertised on Network 30	Advertised on Network 30	—
Disabled	Not Advertised on Network 30	Advertised on Network 30	Not Advertised on Network 30	—

Hiding and Sharing Resources with Access List Examples

The following examples illustrate the use of AppleTalk access lists to manage access to certain resources.

Establish a Free-Trade Zone

A free-trade zone is a part of an AppleTalk internet that is accessible by two parts of the internet, neither of which can access the other. One such situation, illustrated in Figure 12-7, shows a configuration in which you want to provide access to several AppleShare servers on a network that is directly connected to two routers, but you want to restrict access to other networks that are connected to these routers.

In this example, the goal of configuration is to allow all the users on all the networks connected to Routers A and B to be able to access the AppleShare servers AS1 and AS2 in the zone `FreeAccessZone`. A second requirement is to block cross-access through this zone. In other words, users in the zones `MIS1`, `MIS2`, and `LocalTalk` (which are connected to Ethernet interface 0 on Router A) are not allowed access to any of the resources on networks connected to Ethernet interface 4 on Router B. Similarly, users in the zones `Engineering`, `Test`, and `LocalTalk` (which are connected to Ethernet interface 4 on Router B, interface E4) are not allowed access to any of the resources on networks connected to Ethernet interface 0 on Router A.




Figure 12-7 Controlling Access to Common AppleTalk Network

Note Although there are networks that share the same number on interfaces E0 and E4 and there are zones that have the same name, none have the same network number and zone specification (except FreeAccessZone). The two routers do *not* broadcast information about these networks through FreeAccessZone. The routers only broadcast the cable range 5-5. As configured, FreeAccessZone only sees itself. However, since no other limitations have been placed on advertisements, the FreeAccessZone range of 5-5 propagates out to the networks attached to E0 (RouterA) and E4 (RouterB); thus, resources in FreeAccessZone are made accessible to users on all those networks.

The following commands configure Router A and Router B for this access control. You have to configure only Ethernet interface 1 on Router A and Ethernet interface 2 on Router B to provide the desired access.

Configuration for Router A

```

appletalk routing
!
interface ethernet 1
appletalk cable-range 5-5
appletalk zone FreeAccessZone
appletalk free-trade-zone
    
```


Configuration for Router B

```

appletalk routing
!
interface ethernet 2
 appletalk cable-range 5-5
 appletalk zone FreeAccessZone
 appletalk free-trade-zone

```

When configuring both routers, you do not need to define any access lists to prevent users on networks connected to Router A from accessing resources on networks connected to Router B, and vice versa. The **appletalk free-trade-zone** interface configuration command implements the necessary restrictions.

Restricting Resource Availability

In the preceding example, shared-resource access was granted to all users in the various AppleTalk zones connected to the two routers. At the same time, access between resources on either side of the common zone was completely denied. There may be instances where a greater degree of control is required—possibly where resources in some zones are to be allowed access to resources in certain other zones, but are denied access to other specific zones. Figure 12-8 illustrates such a situation.




Figure 12-8 Controlling Resource Access among Multiple AppleTalk Zones

The following are the objectives of this configuration:

- Users in zones Engineering (E7) and MIS (E0) are to be allowed free access to each other.
- All users in all zones are to be allowed access to FreeAccessZone2 (E6).
- No users in any zone, with the exception of users in Finance, are to be allowed access to resources in Finance.

To meet these specifications, you define the following access lists:

```
access-list 609 permit cable 9-9
access-list 609 deny other-access
!
access-list 610 permit zone Finance
access-list 610 permit zone FreeAccessZone2
access-list 610 deny additional-zones
!
access-list 611 deny cable-range 1000-1000
access-list 611 deny cable-range 9-9
access-list 611 permit cable-range 7000-7010
access-list 611 permit cable-range 22-30
```

The effects of these access lists are as follows:

- Access list 609 is intended to be used to allow access to resources on FreeAccessZone2.
- Access list 610 is intended to be used to control access in and out of the zone Finance.
- Access list 611 is intended to be used to accommodate the requirement to allow users in zones Engineering and MIS to mutually access network resources.

Configuration for Ethernet Interface 0

Ethernet interface 0 is associated with the MIS zone. Use the following commands to configure this interface:

```
interface ethernet 0
  appletalk cable-range 7000-7010
  appletalk zone MIS
  appletalk distribute-list 611 out
  appletalk distribute-list 611 in
```

Specifying access list 611 results in the following filtering:

- Advertisements of Finance are blocked.
- Advertisements between Engineering and MIS are allowed.

Configuration for Ethernet Interface 5

Ethernet interface 5 is associated with the Finance zone. Use the following commands to configure this interface:

```
interface ethernet 5
  appletalk cable-range 1000-1000
  appletalk zone Finance
  appletalk distribute-list 610 out
  appletalk access-group 610
```

The effects of these access lists are as follows:

- With the **distribute-list out** command, Finance is limited to accessing Finance and FreeAccessZone2 only.
- The **access-group** command filters packet traffic. Thus it blocks access to any devices in *Finance* from outside of this zone.

Configuration for Ethernet Interface 6

Ethernet interface 6 is associated with the FreeAccessZone2 zone. Use the following commands to configure this interface:

```
interface ethernet 6
  appletalk cable 9-9
  appletalk zone FreeAccessZone2
  appletalk distribute-list 609 out
  appletalk distribute-list 609 in
```

Configuration for Ethernet Interface 7

Ethernet interface 7 is associated with the Engineering zone. The configuration for this interface mirrors that for Ethernet interface 0, because the users in both the MIS and Engineering zones need to have access to each other's resources. Use the following commands to configure Ethernet interface 7:

```
interface ethernet 7
  appletalk cable-range 22-30
  appletalk zone Engineering
  appletalk distribute-list 611 out
  appletalk distribute-list 611 in
```

Implicit Configuration of the Admin and Test-Lab Zones

Omitted from this configuration example are any specific configuration commands pertaining to the zones Test-Lab (Ethernet interface 9 on Router T) and Admin (Ethernet interface 4 on Router C). No configuration is done for these zones, because there are no requirements relating to them listed in the original objectives. The following access control is implicitly handled with the assignment of the stated access lists:

- Users in the Admin zone can see the Finance zone, but cannot see resources in that zone. However, as for all zones, resources in FreeAccessZone2 are available, but none of the users in any of the other zones can access resources in Admin.
- In the absence of the assignment of access lists on Router T, users in Test-Lab can access the resources in the FreeAccessZone2 and Engineering zones. With the exception of Engineering, no other zones can access resources in Test-Lab.

MacIP Examples

The following example illustrates MacIP support for dynamically addressed MacIP clients with dynamically allocated IP addresses in the range 131.108.0.2 to 131.108.0.10

```
!Specify server address and zone
appletalk macip server 131.108.0.1 zone Snark
!
!Specify dynamically addressed clients
!appletalk macip dynamic 131.108.0.2 131.108.0.10 zone Snark
!
!Assign the address and subnet mask for Ethernet interface 0
interface ethernet 0
ip address 131.108.0.2 255.255.255.0
!
!Enable AppleTalk routing
appletalk routing
!
interface ethernet 0
appletalk cable range 69-69 69.128
appletalk zone Snark
```

The following example illustrates MacIP support for MacIP clients with statically allocated IP addresses:

```
!Specify the server address and zone
appletalk macip server 131.108.0.1 zone Snark
!
Specify statically addressed clients
appletalk macip static 131.108.0.11 131.108.0.20 zone Snark
appletalk macip static 131.108.0.31 zone Snark
appletalk macip static 131.108.0.41 zone Snark
appletalk macip static 131.108.0.49 zone Snark
!
!Assign the address and subnet mask for Ethernet interface 0
interface ethernet 0
ip address 131.108.0.1 255.255.255.0
!
!Enable AppleTalk routing
appletalk routing
!
interface ethernet 0
appletalk cable range 69-69 69.128
appletalk zone Snark
```

SNMP-over-DDP Example

The following example configuration sequence illustrates proper activation of SNMP and AppleTalk on a router:

```

!Disable SNMP on the router.
no snmp-server
!
!Enable AppleTalk routing and event logging on the router.
appletalk routing
appletalk event-logging
!
!Configure IP and AppleTalk on Ethernet interface 0.
interface Ethernet 0
ip address 131.108.29.291 255.255.255.0
appletalk cable-range 29-29 29.180
appletalk zone Zombie
!
!Enable SNMP on the router.
snmp-server community propellerhead RW
snmp-server trap-authentication
snmp server host 131.108.2.160 propellerhead
!

```

Proxy Network Number Example

Assume that your network topology looks like the one in Figure 12-9. Also assume that Router A supports only nonextended AppleTalk, that Router B supports only extended AppleTalk (not in transition mode), and that Router C supports only extended AppleTalk.




Figure 12-9 Example Network Topology

If Router C generates a NBP hookup request for zone A, Router B will convert this request to a forward request and send it to Router A. Since Router A supports only nonextended AppleTalk, it does not handle the forward request and ignores it. Hence, the NBP lookup from Router C fails.

To work around this problem without putting a transition router adjacent to the nonextended-only router (Router A), you could configure Router D with an NBP proxy.

If you configured router D with a NBP proxy as follows, any forward requests received for Zone A are converted into lookup requests, and therefore, the nonextended router for Net 60 can properly respond to NBP hookup requests generated beyond Router C. The following example demonstrates the command needed to describe this configuration:

```
appletalk proxy 60 A
```

IPTalk Example

This example describes how to set up UNIX-based systems and our routers to use CAP IP Talk and other IP Talk implementations.

If your system is a Sun or DEC ULTRIX system, it may be possible to run CAP directly in a mode that supports EtherTalk. In this case, your system would look like any other AppleTalk node and does not need any special IP Talk support. However, other UNIX systems for which EtherTalk support is not available in CAP must run CAP in a mode that depends upon IP Talk.

The following procedure outlines the basic steps for setting up our routers and UNIX hosts for operation using IP Talk implementations.

Note This procedure does not provide full instructions about how to install CAP on the UNIX system. However, it does address the requirements for setting up the UNIX system's configuration file that defines addresses and other network information. Generally, this is the only file that relies on the router's address and configuration information. Refer to your UNIX system and CAP software manuals for information about building the CAP software and setting up the UNIX startup scripts.

- Step 1** Enable AppleTalk routing on all the routers that are going to use IP Talk and any routers between these routers.
- Step 2** Enable IP routing on the interfaces that will communicate with the UNIX system. (Refer to Chapters 15 and 16 of this manual for more information about configuring IP). These interfaces must be on the same subnet as the UNIX system. Also, ensure that IP is enabled on the UNIX system.
- Step 3** Allocate an AppleTalk network number for IP Talk. You need a separate AppleTalk network number for each IP subnet that is to run IP Talk.

There can be a number of UNIX machines on the same subnet. They all use the same AppleTalk network number for IP Talk. However, they must have their own individual node identifiers.

It is possible for the same router to have IP Talk enabled on several interfaces. Each interface must have a different AppleTalk network number allocated to IP Talk, because each interface will be using a different IP subnet.

- Step 4** Determine the CAP format of the AppleTalk network number. The CAP software is based on an older AppleTalk convention that expresses AppleTalk network numbers as two octets (decimal numbers from 0 to 255) separated by a dot. The current AppleTalk convention uses decimal numbers from 1 to 65,279. Use the following formula to convert between the two:

CAP format: $x.y$

Apple format: d

- To convert from AppleTalk to CAP:
 $x = d/256$ (/ represents truncating integer division)
 $y = d\%256$ (% represents the remainder of the division)
- To convert from CAP to AppleTalk: $d = x * 256 + y$

Example

AppleTalk format: 14087

CAP format: 55.7

- Step 5** Choose a zone name for IPTalk. There are no special constraints on zone name choices. You can use the same zone name for several networks, and you can combine IPTalk and normal AppleTalk networks in the same zone.

- Step 6** Decide which UDP ports to use for IPTalk. The default is to use ports beginning with 768. Thus, RTMP uses port 769, NBP port 770, and so on. These are the original AppleTalk ports, and their numbers are hardcoded into older versions of CAP. The only problem with using them is that they are not officially assigned by the Internet's Network Information Center (NIC). NIC has assigned a set of UDP ports beginning with 200. Thus, other applications could use them, possibly causing conflicts—although this is unlikely. With CAP releases 5.0 and later, you can configure CAP to use the officially allocated ports. If you do so, RTMP will use port 201, NBP port 202, and so on. Whichever ports you use, you must configure both CAP and the router to use the same ones.

- Step 7** Enable IPTalk on each interface of the router as required. This is illustrated by the following example:

```
appletalk routing
!
interface ethernet 0
ip address 128.6.7.22 255.255.255.0
appletalk cable 1792-1792 1792.22
appletalk zone MIS-Development
appletalk iptalk 14087.0 MIS-UNIX
```

In this example, AppleTalk routing is enabled on the interface in two ways:

- Via EtherTalk phase 2, using the cable range 1792–1792 and the zone MIS-Development
- Via IPTalk, using the network number 14087 and the zone MIS-UNIX

Note The node identifier is not specified (that is, it is left as 0) in the **appletalk iptalk** command. The IPTalk node identifier is then chosen automatically, based on the IP address. It is normally the host number portion of the IP address. For example, with an IP address of 128.6.7.22 and a subnet mask of 255.255.255.0, the host number is 22. Thus, the IPTalk node identifier would be 22. If the IP host number is larger than 255, the low-order 8 bits are used, although fewer than 8 bits may be available depending on the IP subnet mask. If the mask leaves fewer bits, the node number will be quietly truncated. Be sure to use a node address that is compatible with the subnet mask. In any event, there are likely to be problems using IPTalk with host numbers larger than 255.

If you choose to use the official UDP ports (those beginning with 200), include the following global configuration command in your configuration:

```
appletalk iptalk-baseport 200
```

Step 8 Configure each UNIX host with a network number, zone name, and router.

As an example, the following are the contents of the */etc/atalk.local* file from a UNIX system with the IP address 128.6.7.26 and a network mask of 255.255.255.0:

```
# IPTalk on net 128.6.7.0:
# mynet mynode myzone
55.7 26 MIS-UNIX
# bridgenet bridgenode bridgeIP
55.7 22 128.6.7.22
```

The first noncomment line defines the address of the UNIX system, and the second noncomment line defines the address of the router. In both cases, the first column is 55.7, which is the AppleTalk network number, in CAP format, for use by IPTalk. The second column is the AppleTalk node identifier, which must be the same as the IP host number. The third column on the first line is the zone name, and on the second line it is the IP address of the router.

Note the following about these entries:

- The AppleTalk network number in the first column in both lines must agree with the AppleTalk network number used in the **appletalk iptalk** command. However, in the */etc/atalk.local* file, the number must be in the CAP format, while in the configuration command, it must be in the Apple format.
- The host number in the second column in both lines must agree with the IP host number of the corresponding system. That is, on the first line it must be the IP host number of the UNIX machine, and on the second line it must be the IP host number for the router.
- The zone name in the third column on the first line must agree with the zone name used in the **appletalk iptalk** command.
- The IP address in the third column of the second line must be the IP address of the router.

Step 9 Ensure that your CAP software is using the same UDP port numbers as the router. Currently, the CAP default is the same as the router default, which is port numbers beginning with 768. If you want to use this default, you do not need to take any further action. However, if you want to use the official UDP port numbers (port numbers beginning with 200), ensure that you have included the following command in your router configuration:

```
appletalk iptalk-baseport 200
```


Step 10 On the UNIX system, add the following lines to the */etc/services* file:

```
at-rtmp      201/udp
at-nbp      202/udp
at-3        203/udp
at-echo     204/udp
at-5        205/udp
at-zis     206/udp
at-7        207/udp
at-8        208/udp
```

If you are using Network Information Services (NIS), previously known as Yellow Pages, remember to do a *make* in */var/yp* after changing */etc/services*. If you are using the default ports (those starting with 768), you do not need to modify */etc/services*.

