



## Cisco CTE 1400 Series and Design Studio

- 1 Introduction
- 2 Install the Cisco CTE 1400 Series Hardware
- 3 Configure the CTE for the First Time
- 4 Install Design Studio
- 5 Start Design Studio
- 6 Perform Advanced Configuration

# 1 Introduction

The Cisco Content Transformation Engine (CTE) 1400 Series handles requests for web pages from devices, such as Cisco IP phones, wireless phones, and personal digital assistants, and uses transformation instructions to convert HTML/XML pages into wireless-compatible formats. Transformation instructions are created in the companion PC-based application, Cisco CTE Design Studio.

This document provides instructions to install the CTE and perform the basic configuration procedure. For more advanced configurations, see the *Cisco CTE 1400 Series Configuration Note*.

## 2 Install the Cisco CTE 1400 Series Hardware

This section describes how to install the CTE hardware in your environment.

### Requirements

To set up the CTE, you need the following hardware in addition to the items delivered with the CTE:

- Power cable
- Null-modem cable (9-pin female connector at both ends)
- A computer capable of hosting terminal console communication through a serial port
- One or two network cables to connect the CTE to a LAN

### Procedure

The following steps summarize the installation procedure described in the *Cisco CTE 1400 Series Hardware Installation Guide*:

- 
- Step 1** Install the CTE in a rack (if rack-mounted).
  - Step 2** Use network cables to connect the CTE NIC 1 (e0) port to your network connection. (The CTE NIC 2 (e1) port is used for advanced configuration.)
  - Step 3** Connect a null-modem cable to the 9-pin serial port on the CTE and connect the cable to a computer that is capable of running terminal emulation software.
  - Step 4** On the computer, start a terminal emulation application. For example, start HyperTerminal.



**Step 5** Set the serial connection to 9600 bits per second, 8 data bits, no parity, 1 stop bit; set the Backspace key to issue a Delete character.

Hardware flow control is optional.

**Step 6** Power up the CTE.

After about five minutes, the CTE console appears on the computer terminal.

---

## Next

You are now ready to configure the CTE with your network.

## 3 Configure the CTE for the First Time

This section describes express configuration, and tells you how to configure a CTE the first time you bring up the device.

### Procedure

This section summarizes the procedure for configuring a CTE. For detailed information on more advanced configurations, see the *Cisco CTE 1400 Series Configuration Note*.

To configure a CTE, perform these general steps:

- 
- Step 1** Set the root password when prompted.
    - a. Enter the password. It must be 8 or more characters.
    - b. Verify the password when prompted.
  - Step 2** Enter the IP address for Interface 0 when prompted:  
IP address [x.x.x.x] (Enter 0 to clear): *ip\_address*
  - Step 3** Enter the netmask for Interface 0 when prompted:  
Netmask [x.x.x.x] (Enter 0 to clear): *netmask*
  - Step 4** Enter the IP address of the gateway device when prompted:  
Gateway [x.x.x.x]: *gateway ip\_address*
  - Step 5** The CTE displays the current settings. Verify that the settings you have entered are correct. If they are correct, type yes when asked to commit your changes. If they are not correct, type no when asked to commit your changes, then type 0 (Express Setup) to reenter the settings in Steps 2 through 4.
  - Step 6** Type 5 to log out from the console.
  - Step 7** You may unplug the serial connection.
- 

### Next

Continue configuring the CTE from the Administration interface.



To continue configuring the CTE from the Administration interface, perform these steps:

---

**Step 1** From any browser, enter the following URL:

`https://IP_address:9001`

where:

- IP\_address is the IP address of your CTE.
- 9001 is the administration port of your CTE.

**Step 2** Click Yes on the Security Alert dialog box.

**Step 3** Log in as root, and enter your root password, which you will have defined the first time you opened the CTE console.



---

**Note** You can create additional administrative usernames and passwords from the CTE console. For more information, see the description of the Manage Administrative Users console command in the *CTE 1400 Series Configuration Note*.

---

**Step 4** On the Interfaces screen of the Network tab, define the Masquerade Host for Interface 0. The masquerade host is an IP address that can be used for Network Address Translation (NAT).

**Step 5** Click the Submit button at the bottom of the window to save your changes. You do not need to restart the server at this point.

**Step 6** On the Ports screen of the Network tab, define the Listen on Interface IP address and the ports.

- a. To define the Listen on Interface, select the IP address you have configured for Interface 0 from the Listen on Interface drop-down menu.
- b. Set the Incoming HTTP Port as 80, the Incoming HTTPS port as 443, and the Administration Port as 9001.

**Step 7** Click the Submit button at the bottom of the window to save your changes. You do not need to restart the server.

**Step 8** On the DNS screen of the Network tab, set a minimum of one DNS server.

**Step 9** Click the Submit button at the bottom of the window to save your changes.

**Step 10** Click the Restart Server button.

**Step 11** Click Yes on the Security Alert dialog box.

**Step 12** On the Users screen of the Administration tab, define any Design Studio users you want to add. Enter a username of at least 6 characters and a password of at least 8 characters. Click the Add User button.

**Step 13** From your browser, check network connectivity by entering the following URL:

`http://IP_address/www.cisco.com`

When the Cisco home page appears, the CTE is up and running.

---

## Next

Continue to the next section to install Design Studio.



## 4 Install Design Studio

Design Studio is the application that you use to create the rules that transform website content for delivery to wireless devices.

### Requirements

Design Studio requires the following:

- Windows 95, Windows 98/ME, Windows 2000, or Windows NT 4.0 with Service Pack 6.
- At least 10 MB of disk space.
- At least 128 MB of RAM; 256 MB is recommended.
- Internet Explorer version 5.0 or higher or Netscape version 4.01 or higher.
- Java 2 Runtime Environment (JRE), Standard Edition, version 1.2.2\_08.



---

**Note** JRE is on the CTE Design Studio CD-ROM and is also available from <http://www.javasoft.com>. JRE requires an additional 16 MB of disk space. Design Studio does not work with other versions of JRE or the Java Development Kit (JDK).

---

- VGA color monitor with a graphics card capable of showing 16-bit color or higher. A minimum screen resolution of 640 x 480. Recommended resolution is 1280 x 1024.
- Network connection to the CTE.

The network connection can be through a proxy server, which you specify when you log in to Design Studio.

## Procedure

To install Design Studio, perform these steps:

- 
- Step 1** If JRE 1.2.2 is not already installed on your PC, install it.
- Step 2** Insert the Design Studio CD-ROM into your CD-ROM drive.  
If auto-start is enabled on your computer, the installer starts.  
If auto-start is not enabled on your computer, double-click the drive icon for your CD-ROM, and then double-click `CiscoCTEDesignStudio.exe`.
- Step 3** Follow the instructions in the installer.  
You may be asked to restart your PC during the installation. After you restart your PC, the Design Studio installation wizard continues the installation.  
By default, Design Studio is installed in `C:\Program Files\Cisco\CTE\Design Studio\2.5`.
- 

## Next

Continue to the next section to start Design Studio.





## 5 Start Design Studio

See the *Design Studio Getting Started Guide* for detailed information on installing and starting Design Studio, as well as an overview of the product and a tutorial. For detailed information on using Design Studio to create, preview, and publish transformation rules, see the *Design Studio User Guide*. That information is also available from the Design Studio Help menu.

### Requirements

To start Design Studio, you need the following login information from the administrator who sets up the CTE:

- Your Design Studio username and password
- The IP address of the CTE
- The server upload port number
- HTTP and HTTPS proxy hosts and ports, if Design Studio and the CTE are connected through a proxy server

### Procedure

To start Design Studio, perform these steps:

---

**Step 1** From the Windows Start menu, choose Program Files > Cisco > CTE > Design Studio.

The login dialog box appears.

**Step 2** Enter your username and password.

**Step 3** Enter the IP address of the CTE.

**Step 4** If necessary, change the upload port number.

The default upload port number is 9001. You might need to change the port number if your firewall redirects ports. Contact your CTE administrator if you do not know which port to use.

**Step 5** If the computer on which Design Studio is installed is connected to the CTE through a proxy server, click **Use Proxy** and enter the host and port for HTTP and HTTPS connections.

**Step 6** Click OK.

If you cannot connect to a CTE, verify that your computer has a network connection to a running CTE. Contact your CTE administrator for help.

---

## Next

Continue to the next section for information about advanced configuration.



## 6 Perform Advanced Configuration

After the CTE has been initially configured, you can modify the configuration at any time through the CTE console and CTE Administration screens. Any configuration tasks that you might want to perform are described in the *Cisco CTE 1400 Series Configuration Note (78-13087-04)*.

The following table lists these tasks and the locations where they are described in the Configuration Note:

| Configuration Task  | Section in Configuration Note   |
|---|---|
| Reopening the CTE console   | “Reopening the CTE Console”   |
| Configuring a CTE connected to a web server                                       | “Configuring a CTE Connected Directly to a Web Server”  |
| Configuring a CTE connected to a server load balancer                             | “Configuring a CTE Connected Directly to a Server Load Balancer”  |
| Restarting or shutting down a CTE   | “CTE Console Menu” (See description in Table 4, [4] Restart/Shutdown)   |
| Configuring Interfaces 0 and 1  | “CTE Console Menu” (See description in Table 4, [1] Configure Network Interface) and “Interfaces Screen”        |
| Defining Listen on Interface IP address and HTTP, HTTPS, and Administration ports | “Ports Screen”  |
| Setting up DNS servers and domain   | “DNS Screen”  |
| Creating new administrative users   | “CTE Console Menu” (See description in Table 4, [2] Manage Administrative Users)                                |
| Pinging another machine on the network  | “CTE Console Menu” (See description in Table 4, [5] Ping)   |
| Defining proxy servers and proxy exclusion  | “Proxy Screen” (See command descriptions in Table 9, Proxy Screen Settings)                                     |
| Using session timeout and minimum session time settings                           | “General Screen” (See command descriptions in Table 10, General Screen Settings) and “Sessions and Connections” |
| Creating default usernames and passwords for IP phones                            | “IP Phone Screen”   |
| Setting up SNMP   | “Configure Screen”  |

| <b>Configuration Task</b>                         | <b>Section in Configuration Note</b>                             |
|---|--|
| Enabling the system log                           | “System Log Screen”  |
| Enabling the health log                           | “Health Log Screen”  |
| Adding new Design Studio users                    | “Users Screen” (Administration tab of Administration Interface)  |
| Uploading secure certificates and server upgrades | “Uploads Screen” and “Uploading a Secure Certificate to the CTE” |
| Uploading server upgrades                         | “Uploads Screen”   |
| Configuring Static Routes                         | “Routes Screen” and “Using Static Routes”                        |
| CTE console command summary                       | “CTE Console Menu”   |
| CTE Administration task summary                   | “CTE Administration Interface”                                   |

All of the Design Studio and CTE documentation is available on the Design Studio CD-ROM. You can also obtain the documentation from the Cisco home page (<http://www.cisco.com>) or order a printed copy by calling Cisco corporate headquarters (California, USA) at 408 526-7208 or, elsewhere in North America, by calling 800 553-NETS (6387).









**Corporate Headquarters**  
Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
[www.cisco.com](http://www.cisco.com)  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 526-4100

**European Headquarters**  
Cisco Systems Europe  
11 Rue Camille Desmoulins  
92782 Issy-les-Moulineaux  
Cedex 9  
France  
[www-europe.cisco.com](http://www-europe.cisco.com)  
Tel: 33 1 58 04 60 00  
Fax: 33 1 58 04 61 00

**Americas Headquarters**  
Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
[www.cisco.com](http://www.cisco.com)  
Tel: 408 526-7660  
Fax: 408 527-0883

**Asia Pacific Headquarters**  
Cisco Systems, Inc.  
Capital Tower  
168 Robinson Road  
#22-01 to #29-01  
Singapore 068912  
[www.cisco.com](http://www.cisco.com)  
Tel: +65 317 7777  
Fax: +65 317 7799

Cisco Systems has more than 200 offices in the following countries. Addresses, phone numbers, and fax numbers are listed on the **Cisco Web site at [www.cisco.com/go/offices](http://www.cisco.com/go/offices)**

Argentina • Australia • Austria • Belgium • Brazil • Bulgaria • Canada • Chile • China PRC • Colombia • Costa Rica • Croatia • Czech Republic • Denmark • Dubai, UAE  
Finland • France • Germany • Greece • Hong Kong SAR • Hungary • India • Indonesia • Ireland • Israel • Italy • Japan • Korea • Luxembourg • Malaysia • Mexico  
The Netherlands • New Zealand • Norway • Peru • Philippines • Poland • Portugal • Puerto Rico • Romania • Russia • Saudi Arabia • Scotland • Singapore • Slovakia  
Slovenia • South Africa • Spain • Sweden • Switzerland • Taiwan • Thailand • Turkey • Ukraine • United Kingdom • United States • Venezuela • Vietnam • Zimbabwe

Copyright © 2003 Cisco Systems, Inc. All rights reserved. CCIP, CCSP, the Cisco Arrow logo, the Cisco *Powered* Network mark, Cisco Unity, Follow Me Browsing, FormShare, and StackWise are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn, and iQuick Study are service marks of Cisco Systems, Inc.; and Aironet, ASIST, BPX, Catalyst, CCDA, CCDP, CCIE, CCNA, CCNP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, the Cisco IOS logo, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Empowering the Internet Generation, Enterprise/Solver, EtherChamel, EtherSwitch, Fast Step, GigaStack, Internet Quotient, IOS, IP/TV, IQ Expertise, the IQ logo, IQ Net Readiness Scorecard, LightStream, MGX, MICA, the Networkers logo, Networking Academy, Network Registrar, *Packer*, PIX, Post-Routing, Pre-Routing, RateMUX, Registrar, ScriptShare, SlideCast, SMARTnet, StrataView Plus, Stratm, SwitchProbe, TeleRouter, The Fastest Way to Increase Your Internet Quotient, TransPath, and VCO are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and certain other countries.

All other trademarks mentioned in this document or Web site are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0304R)