



Numerics

2-minute blower failure shutdown

See blower, shutdown

2-minute fan failure shutdown

See fan, shutdown

2-post equipment racks [2-20](#)

A

AC-input

power supply

installation, Cisco 7505 [5-13 to 5-14](#)

installation, Cisco 7507 and Cisco 7507-MX [3-14 to 3-19](#)

installation, Cisco 7513, Cisco 7513-MX, and Cisco 7576 [3-27 to 3-31](#)

LEDs [8-23 to 8-26](#)

removal, Cisco 7507 and Cisco 7507-MX [6-3 to 6-6](#)

removal, Cisco 7513, Cisco 7513-MX, and Cisco 7576 [7-3 to 7-5](#)

specifications

Cisco 7505 [1-5](#)

Cisco 7507 [1-10](#)

Cisco 7507-MX [1-14](#)

Cisco 7513 [1-19](#)

Cisco 7513-MX [1-24](#)

Cisco 7576 [1-30](#)

acronyms, definition [1-2](#)

agency approvals

Cisco 7505 [1-6](#)

Cisco 7507 [1-10](#)

Cisco 7507-MX [1-14](#)

Cisco 7513 [1-19](#)

Cisco 7513-MX [1-24](#)

Cisco 7576 [1-30](#)

airflow

clearance

for circulation around Cisco 7505 [2-17](#)

for circulation around Cisco 7507 and Cisco 7507-MX [2-19](#)

for circulation around Cisco 7513, Cisco 7513-MX, and Cisco 7576 [2-22](#)

considerations

Cisco 7505 [2-13](#)

Cisco 7507 and Cisco 7507-MX [2-14](#)

Cisco 7513, Cisco 7513-MX, and Cisco 7576 [2-14](#)

filter cleaning [6-10](#)

specifications

Cisco 7505 [1-6](#)

Cisco 7507 [1-10](#)

Cisco 7507-MX [1-14](#)

Cisco 7513 [1-19](#)

Cisco 7513-MX [1-24](#)

Cisco 7576 [1-30](#)

altitude specifications, system [2-13](#)

AppleTalk, configuring [4-14](#)

arbiter [1-50](#)

arbitration, CyBus [1-50](#)

AUSTEL agency approvals, Cisco 7505 [1-6](#)

Autoinstall configuration, basic [4-11](#)

auxiliary port

connecting devices to [3-32](#)

description [1-44](#)

pinout [1-45](#)

B

backplane

bandwidth

- Cisco 7505 [1-5](#)
- Cisco 7507 [1-10](#)
- Cisco 7507-MX [1-14](#)
- Cisco 7513 [1-19](#)
- Cisco 7513-MX [1-24](#)
- Cisco 7576 [1-30](#)

cover removal

- Cisco 7505 [5-9](#)
- Cisco 7513, Cisco 7513-MX, and Cisco 7576 [7-13](#)

description, Cisco 7505 [1-4](#)power distribution [5-2, 8-5, 8-13](#)wiring [5-2, 6-2, 7-2](#)backup batteries [1-43](#)banner, system [4-2, 8-6, 8-14](#)batteries, lithium backup for NVRAM [1-43](#)

blower

assembly

- description [1-52](#)
- replacement in the Cisco 7507 and Cisco 7507-MX [6-15](#)

failure [2-31, 2-35, 8-13](#)

module

- description [1-53, 7-10](#)
- operating voltages [8-13](#)
- replacement in the Cisco 7513, Cisco 7513-MX, and Cisco 7576 [7-10](#)

shutdown [2-31, 2-35](#)board racks, using [3-20](#)boot command [4-3](#)booting for the first time [4-8](#)bootload-failure response [4-7](#)boot system command [4-4](#)boot system flash command [4-26](#)

bracket, cable-management

- Cisco 7505 [3-9](#)

- Cisco 7513, Cisco 7513-MX, and Cisco 7576 [3-26](#)

Break key (interrupt) [4-6](#)broadcast address destination, configuration register settings [4-6](#)

bus

- See CyBus

C

cable-management bracket

- Cisco 7505 [3-9](#)
- Cisco 7513, Cisco 7513-MX, and Cisco 7576 [3-26](#)

cables

AC-input power

- Cisco 7505 [1-5](#)
- Cisco 7507 [1-10](#)
- Cisco 7507-MX [1-14](#)
- Cisco 7513 [1-19](#)
- Cisco 7513-MX [1-24](#)
- Cisco 7576 [1-30](#)

attaching

- console and auxiliary [3-32 to 3-33](#)
- power [3-31](#)

auxiliary port [1-45](#)avoiding crossing [3-2](#)console port [1-45](#)

DC-input power

- Cisco 7505 [1-6](#)
- Cisco 7507 [1-10](#)
- Cisco 7507-MX [1-14](#)
- Cisco 7513 [1-19](#)
- Cisco 7513-MX [1-24](#)
- Cisco 7576 [1-30](#)

distance limitations [2-11](#)interference [2-10](#)power [5-13](#)

- Cisco 7505 [2-8](#)
- Cisco 7507 and Cisco 7507-MX [2-8](#)
- Cisco 7513, Cisco 7513-MX, and Cisco 7576 [2-9](#)

- power supply
 - Cisco 7505 1-6
 - Cisco 7507 1-10
 - Cisco 7507-MX 1-14
 - Cisco 7513 1-19
 - Cisco 7513-MX 1-24
 - Cisco 7576 1-30
- retention clip, power 5-13
- safety guidelines 2-3
- swapping power 8-11, 8-15
- ungrounded and uninsulated 2-3
- Y-types for RSP2, RSP4, and RSP8 1-45
- card cage assembly replacement, Cisco 7513, Cisco 7513-MX, and Cisco 7576 7-5
- CD-ROM, ordering documentation 4-32
- chassis
 - airflow considerations
 - Cisco 7505 2-13
 - Cisco 7507 and Cisco 7507-MX 2-14
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 2-14
 - clearance
 - Cisco 7505 2-17
 - Cisco 7507 and Cisco 7507-MX 2-19
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 2-22
 - dimensions
 - Cisco 7505 1-5
 - Cisco 7507 1-10
 - Cisco 7507-MX 1-14
 - Cisco 7513 1-19
 - Cisco 7513-MX 1-24
 - Cisco 7576 1-30
 - environment 2-12
 - feet, Cisco 7505 2-16
 - footprint 2-17, 2-21
 - internal components 5-2, 6-2, 6-11, 7-2
 - lifting safely 2-3, 2-5
 - panels, removing 6-6
 - slot arrangement
 - Cisco 7505 1-3
 - Cisco 7507 1-6
 - Cisco 7507-MX 1-11
 - Cisco 7513 1-15
 - Cisco 7513-MX 1-20
 - Cisco 7576 1-25
 - specifications
 - Cisco 7505 1-5
 - Cisco 7507 1-10
 - Cisco 7507-MX 1-14
 - Cisco 7513 1-19
 - Cisco 7513-MX 1-24
 - Cisco 7576 1-30
 - temperature thresholds 2-24 to 2-25
 - voltage thresholds 2-24 to 2-25
 - weight
 - Cisco 7505 1-5
 - Cisco 7507 1-10
 - Cisco 7507-MX 1-14
 - Cisco 7513 1-19
 - Cisco 7513-MX 1-24
 - Cisco 7576 1-30
- chassis interface
 - description 1-50
 - replacement
 - Cisco 7505 5-11
 - Cisco 7507 and Cisco 7507-MX 6-12
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 7-14
- CI
 - See chassis interface
- Cisco 7505
 - additional information, obtaining 4-32
 - arbiter 1-50
 - cable connections, RSP 3-32 to 3-33
 - chassis airflow 2-13
 - chassis interface
 - description 1-50
 - replacement 5-11
 - common RSP features 1-42
 - fan tray

- description 1-52
- replacement procedures 5-5
- Flash memory, using 4-20 to 4-32
- installation
 - preparation 2-1 to 2-29
 - procedures 3-4 to 3-11
- interface processor description 1-54
- maintenance procedures ?? to 5-14
- overview 1-3 to ??
- power supply
 - connection 3-9
 - descriptions 1-47
 - guidelines 2-7
 - LEDs 8-23
 - removal 5-13
 - replacement 5-15
- rack-mounting
 - guidelines 2-16, 2-18
 - procedure 3-7
- removing
 - backplane cover 5-9
 - chassis interface 5-11
 - cover panels 5-3
 - fan tray 5-5
 - power harness cover 5-7
 - power supply 5-13
- replacing
 - backplane cover 5-10
 - chassis interface 5-12
 - cover panel 5-4
 - fan tray 5-7
 - power harness cover 5-8
 - power supply 5-15
- RSP4
 - description 1-33 to 1-35
 - LEDs 8-22
- RSP4 and RSP8
 - DRAM, upgrading 9-5 to 9-11
- safety recommendations 2-2
- site environment guidelines 2-12 to 2-29
- system software
 - description 1-56
- troubleshooting
 - cooling subsystem 8-7
 - guidelines 8-4
 - power subsystem 8-7
 - startup problems 8-4 to 8-6
 - wiring guidelines 2-10
- Cisco 7507
 - arbiter 1-50
 - overview 1-6 to ??
 - RSP2
 - DRAM, upgrading 9-2 to 9-5
 - RSP4
 - description 1-33 to 1-35
 - RSP4 and RSP8
 - DRAM, upgrading 9-5 to 9-11
- Cisco 7507 and Cisco 7507-MX
 - additional information, obtaining 4-32
 - blower
 - description 1-52
 - replacement 6-15
 - cable connections, RSP 3-32 to 3-33
 - chassis airflow 2-14
 - chassis interface
 - description 1-50
 - replacement 6-12
 - common RSP features 1-42
 - Flash memory, using 4-20 to 4-32
 - installation
 - preparation 2-1 to 2-31
 - procedures 3-11 to 3-19
 - interface processor description 1-54
 - maintenance procedures 6-1 to 6-19
 - power supply
 - connection 3-17
 - descriptions 1-47
 - guidelines 2-8

- installation [3-14](#)
 - LEDs [8-23](#)
- removing
 - air filter [6-10](#)
 - blower [6-15](#)
 - chassis interface [6-12](#)
 - cover panels [6-6](#)
 - LED board [6-13](#)
 - power supplies [6-3](#)
- replacing
 - air filter [6-10](#)
 - blower [6-18](#)
 - chassis interface [6-13](#)
 - cover panels [6-8](#)
 - LED board [6-14](#)
- RSP2
 - LEDs [8-21](#)
- RSP4 and RSP8
 - LEDs [8-22](#)
- safety recommendations [2-2](#)
- site environment guidelines [2-12 to 2-31](#)
- system software
 - description [1-56](#)
- troubleshooting
 - cooling subsystem [8-11](#)
 - guidelines [8-8](#)
 - power subsystem [8-10](#)
 - startup problems [8-9 to 8-10](#)
 - using LEDs [8-20](#)
- wiring guidelines [2-10](#)
- Cisco 7507-MX
 - arbiter [1-50](#)
 - overview [1-11 to ??](#)
- Cisco 7507-MX and Cisco 7513-MX
 - RSP8
 - description [1-36 to 1-39](#)
- Cisco 7513
 - arbiter [1-50](#)
 - overview [1-15 to ??](#)
- RSP2
 - DRAM, upgrading [9-2 to 9-5](#)
- RSP4
 - description [1-34 to 1-35](#)
- RSP4 and RSP8
 - DRAM, upgrading [9-5 to 9-11](#)
- Cisco 7513, Cisco 7513-MX, and Cisco 7576
 - blower
 - replacement [7-10](#)
 - chassis interface
 - replacement [7-14](#)
 - EEPROM exchange, backplane [7-7](#)
 - installation
 - procedures [3-19 to 3-31](#)
 - maintenance procedures [?? to 7-19](#)
 - power supply
 - connection [3-29](#)
 - installation [3-27](#)
 - removing
 - backplane maintenance cover [7-13](#)
 - blower [7-10](#)
 - card cage [7-5](#)
 - chassis interface [7-14](#)
 - cover panels [7-11](#)
 - power supplies [7-3](#)
 - replacing
 - backplane maintenance cover [7-14](#)
 - blower [7-10](#)
 - card cage [7-9](#)
 - chassis interface [7-18](#)
 - cover panels [7-12](#)
- Cisco 7513 and Cisco 7513-MX
 - additional information, obtaining [4-32](#)
 - blower
 - description [1-53](#)
 - cable connections, RSP [3-32 to 3-33](#)
 - chassis airflow [2-14](#)
 - chassis interface
 - description [1-50](#)

- common RSP features [1-42](#)
 - Flash memory, using [4-20 to 4-32](#)
 - installation
 - preparation [2-1 to 2-35](#)
 - interface processor description [1-54](#)
 - overview [1-25 to ??](#)
 - power supply
 - descriptions [1-47](#)
 - guidelines [2-9](#)
 - installation [3-27](#)
 - LEDs [8-25](#)
 - rack-mounting guidelines [2-20](#)
 - RSP2
 - LEDs [8-21](#)
 - RSP4 and RSP8
 - LEDs [8-22](#)
 - safety recommendations [2-2](#)
 - site environment guidelines [2-12 to 2-35](#)
 - system software
 - description [1-56](#)
 - troubleshooting
 - cooling subsystem [8-16](#)
 - guidelines [8-12](#)
 - power subsystem [8-15](#)
 - startup problems [8-13 to 8-14](#)
 - using LEDs [8-20](#)
 - wiring guidelines [2-10](#)
- Cisco 7513-MX
- arbiter [1-50](#)
 - overview [1-20 to ??](#)
- Cisco 7576
- additional information, obtaining [4-32](#)
 - arbiter [1-50](#)
 - blower
 - description [1-53](#)
 - cable connections, RSP [3-32 to 3-33](#)
 - chassis airflow [2-14](#)
 - chassis interface
 - description [1-50](#)
 - common RSP features [1-42](#)
 - Flash memory, using [4-20 to 4-32](#)
 - installation
 - preparation [2-1 to 2-35](#)
 - interface processor description [1-54](#)
 - overview [1-25 to ??](#)
 - power supply
 - descriptions [1-47](#)
 - guidelines [2-9](#)
 - LEDs [8-25](#)
 - rack-mounting guidelines [2-20](#)
 - RSP2
 - DRAM, upgrading [9-2 to 9-5](#)
 - LEDs [8-21](#)
 - RSP4
 - description [1-34 to 1-35](#)
 - RSP4 and RSP8
 - DRAM, upgrading [9-5 to 9-11](#)
 - LEDs [8-22](#)
 - safety recommendations [2-2](#)
 - site environment guidelines [2-12 to 2-35](#)
 - system software
 - description [1-56](#)
 - requirements [1-30](#)
 - troubleshooting
 - cooling subsystem [8-16](#)
 - guidelines [8-12](#)
 - power subsystem [8-15](#)
 - startup problems [8-13 to 8-14](#)
 - using LEDs [8-20](#)
 - wiring guidelines [2-10](#)
- Cisco Extended Bus
- See [CyBus](#)
 - cleaning the air filter [6-10](#)
 - clock generation, arbiter (CyBus) [1-50](#)
 - config-register command [4-7](#)
 - config terminal command [4-18](#)
 - configuration
 - file, saving [4-17, 4-19](#)
 - interfaces [4-15 to 4-18](#)

- modifications [4-19](#)
- notes [5-1, 6-1, 7-1](#)
- register
 - bit meanings [4-5 to 4-7, A-1](#)
 - boot field [4-5, A-2](#)
 - boot filename [4-6, A-3](#)
 - broadcast address settings [4-6, A-4](#)
 - changing settings [4-7](#)
 - configuration [4-4 to 4-7](#)
 - displaying the configuration register while running Cisco IOS [A-5](#)
 - displaying the configuration register while running ROM monitor [A-5](#)
 - setting the configuration register while running Cisco IOS [A-6](#)
 - setting the configuration register while running ROM monitor [A-6](#)
 - transmission rate settings [4-7](#)
- sample [4-13 to 4-15, 4-16 to 4-17](#)
- configuration procedures, basic [4-1 to 4-20](#)
- configure terminal command [4-7](#)
- configuring
 - AppleTalk [4-14](#)
 - global parameters [4-12](#)
 - procedure [4-13](#)
 - sample configuration [4-14 to 4-15](#)
 - interface parameters
 - examples of [4-15, 4-16](#)
 - sample configuration [4-16 to 4-17](#)
- IPX [4-14](#)
- the Cisco 7500 series routers [4-11 to 4-19](#)
 - using AutoInstall [4-11](#)
 - using configuration mode [4-18](#)
 - using setup command facility [4-12](#)
- confreg command [4-9](#)
- connecting
 - auxiliary port [3-32](#)
 - console port [3-32](#)
 - DC-input power
 - Cisco 7505 [3-9](#)
 - Cisco 7507 and Cisco 7507-MX [3-16](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 [3-29](#)
- console port
 - connecting devices to [3-32](#)
 - description [1-44](#)
 - pinout [1-44](#)
 - settings [4-7](#)
 - terminal [8-6, 8-14](#)
- cooling subsystem [8-3, 8-17](#)
- copy command, (Flash memory) [4-29](#)
- copy running-config startup-config command [4-12, 4-19](#)
- copy tftp flash command [4-27](#)
- CPU
 - halt LED on RSP2 [8-21](#)
 - halt LED on RSP4 and RSP8 [8-22](#)
 - system
 - RSP2 [1-32](#)
 - RSP4 [1-35](#)
- critical status level, environmental monitor
 - Cisco 7505 [2-24](#)
 - Cisco 7507 and Cisco 7507-MX [2-25](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 [2-25](#)
- CSA agency approvals
 - Cisco 7505 [1-6](#)
 - Cisco 7507 [1-10](#)
 - Cisco 7507-MX [1-14](#)
 - Cisco 7513 [1-19](#)
 - Cisco 7513-MX [1-24](#)
 - Cisco 7576 [1-30](#)
- current rating, AC and DC [1-19, 1-24, 1-30](#)
- customer service, accessing [4-32](#)
- CxBus description [1-2](#)
- CyBus
 - arbiter clock generation [1-50](#)
 - arbitration [1-50](#)
 - Cisco 7505 [1-4](#)
 - Cisco 7507 [1-8](#)
 - Cisco 7507-MX [1-12](#)
 - Cisco 7513 [1-18](#)

Cisco 7513-MX [1-23](#)

clock [1-50](#)

description [1-2, 1-5](#)

global lock [1-50](#)

traffic [1-50](#)

See also backplane

D

damage from overheating [2-22](#)

data transmission-rate settings [4-7](#)

dBus description [1-2](#)

DC fail LED on power supply

See LEDs

DC-input

power connection

Cisco 7505 [3-9](#)

Cisco 7507 and Cisco 7507-MX [3-17](#)

Cisco 7513, Cisco 7513-MX, and Cisco 7576 [3-29](#)

power supply

installation, Cisco 7505 [5-13 to 5-14](#)

installation, Cisco 7507 and Cisco
7507-MX [3-14 to 3-19](#)

installation, Cisco 7513, Cisco 7513-MX, and Cisco
7576 [3-27 to 3-31](#)

LEDs [8-23 to 8-26](#)

specifications [1-19, 1-24, 1-30](#)

DC OK LED [8-5, 8-13, 8-23](#)

dimensions

chassis

Cisco 7505 [1-5](#)

Cisco 7507 [1-10](#)

Cisco 7507-MX [1-14](#)

Cisco 7513 [1-19](#)

Cisco 7513-MX [1-24](#)

Cisco 7576 [1-30](#)

interface processors [1-54](#)

displays, environmental [2-26 to 2-35](#)

distance limitations, cable transmission [2-11](#)

Documentation CD-ROM, ordering [4-32](#)

DRAM

locations

RSP2 [9-1](#)

RSP4 [9-6](#)

RSP4 and RSP8 configurations [9-8](#)

upgrade procedures [9-1 to 9-11](#)

dual arbiter [1-50](#)

dual CyBus

Cisco 7505 [1-4](#)

Cisco 7507 [1-8](#)

Cisco 7507-MX [1-12](#)

Cisco 7513 [1-17](#)

Cisco 7513-MX [1-22](#)

Cisco 7576 [1-27](#)

description [1-2](#)

See also CyBus

E

EEPROM

description [1-44](#)

exchanging [7-7 to 7-8](#)

electromagnetic pulse

See EMP

electronically erasable programmable read-only memory

See EEPROM

electrostatic discharge precautions [2-6](#)

EMI

agency approvals [1-19, 1-24, 1-30](#)

Cisco 7505 [1-6](#)

Cisco 7507 [1-10](#)

Cisco 7507-MX [1-14](#)

Cisco 7513 [1-19](#)

Cisco 7513-MX [1-24](#)

Cisco 7576 [1-30](#)

prevention [2-11](#)

EMP, avoiding the effects of [2-11](#)

enable command [4-7, 4-10, 4-18](#)

- enable password command [4-8](#)
 - environment, site [2-12](#)
 - environmental
 - displays [2-26 to 2-35](#)
 - monitor descriptions [2-26 to 2-35](#)
 - status
 - Cisco 7505 [2-27 to 2-29](#)
 - Cisco 7507 and Cisco 7507-MX [2-29 to 2-31](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 [2-31 to 2-35, 2-35 to ??](#)
 - environmental reports [2-26 to ??](#)
 - ESD
 - See electrostatic discharge precautions
 - EXEC
 - privileged mode [4-8](#)
- ## F
-
- failure
 - AC or DC source [2-23, 8-5, 8-13, 8-23](#)
 - AC source [8-25](#)
 - blower [8-13](#)
 - fans [8-5](#)
 - power supply, DC section [8-23, 8-25](#)
 - fan
 - control board [5-2](#)
 - failure [2-29, 8-5](#)
 - shutdown [2-29](#)
 - tray
 - description [5-2](#)
 - operating voltages [8-5](#)
 - replacing [5-5](#)
 - fan OK LED [8-25](#)
 - FCC agency approvals
 - Cisco 7505 [1-6](#)
 - Cisco 7507 [1-10](#)
 - Cisco 7507-MX [1-14](#)
 - Cisco 7513 [1-19](#)
 - Cisco 7513-MX [1-24](#)
 - Cisco 7576 [1-30](#)
 - field-replaceable unit
 - See FRU
 - filenames, for booting over the network [4-5](#)
 - filter, cleaning, air [6-10](#)
 - Flash memory
 - additional commands [4-26](#)
 - card installation and removal [4-20 to 4-23](#)
 - commands [4-5](#)
 - copy command [4-29](#)
 - copying between cards [4-28](#)
 - copying bootable images between [4-28](#)
 - copying files [4-27](#)
 - copying files to RSP memory [4-30 to 4-32](#)
 - description [1-43](#)
 - formatting a new PC Card [4-24](#)
 - PC Card replacement [4-21](#)
 - using [4-20 to 4-32](#)
 - format command [4-24, 4-32](#)
 - formatting a new PC Card [4-24](#)
 - frequency specifications, line
 - Cisco 7505 [1-5](#)
 - Cisco 7507 [1-10](#)
 - Cisco 7507-MX [1-14](#)
 - Cisco 7513 [1-19](#)
 - Cisco 7513-MX [1-24](#)
 - Cisco 7576 [1-30](#)
 - front cover panel [7-11](#)
 - FRUs, definition [1-2](#)
- ## G
-
- global parameters, configuring [4-12](#)
 - gravity, maintaining low center
 - Cisco 7505 [2-17](#)
 - Cisco 7507 and Cisco 7507-MX [2-19](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 [2-22](#)

H

Hall Effect signal [2-29](#)

humidity specifications

Cisco 7505 [1-6](#)

Cisco 7507 [1-10](#)

Cisco 7507-MX [1-14](#)

Cisco 7513 [1-19](#)

Cisco 7513-MX [1-24](#)

Cisco 7576 [1-30](#)

system [2-12](#)

I

IGRP

See Interior Gateway Routing Protocol

immunity, agency approvals for interference

Cisco 7505 [1-6](#)

Cisco 7507 [1-10](#)

Cisco 7507-MX [1-14](#)

Cisco 7513 [1-19](#)

Cisco 7513-MX [1-24](#)

Cisco 7576 [1-30](#)

inlet air [2-28, 2-33](#)

installation

cable-management bracket

Cisco 7505 [3-9](#)

Cisco 7513, Cisco 7513-MX, and Cisco 7576 [3-26](#)

Cisco 7513, Cisco 7513-MX, and Cisco 7576 blower module [7-10](#)

Cisco 7513, Cisco 7513-MX, and Cisco 7576 card cage assembly [7-5](#)

general [3-7, 3-24](#)

guidelines

Cisco 7505 [3-4 to 3-6](#)

Cisco 7507 and Cisco 7507-MX [3-11 to 3-13](#)

Cisco 7513, Cisco 7513-MX, and Cisco 7576 [3-19 to 3-23](#)

power supply

Cisco 7505 [5-13 to 5-14](#)

Cisco 7507 and Cisco 7507-MX [3-14 to 3-19, 6-3 to 6-6](#)

Cisco 7513, Cisco 7513-MX, and Cisco 7576 [3-27 to 3-29, 7-3 to 7-5](#)

rack-mounting, Cisco 7505 [3-7 to ??](#)

troubleshooting [8-1](#)

installing

backplane cover, Cisco 7505 [5-9](#)

backplane maintenance cover, Cisco 7513, Cisco 7513-MX, and Cisco 7576 [7-13](#)

blower

Cisco 7507 and Cisco 7507-MX [6-15](#)

Cisco 7513, Cisco 7513-MX, and Cisco 7576 [7-10](#)

card cage, Cisco 7513, Cisco 7513-MX, and Cisco 7576 [7-9](#)

chassis interface

Cisco 7505 [5-11](#)

Cisco 7507 and Cisco 7507-MX [6-12](#)

Cisco 7513, Cisco 7513-MX, and Cisco 7576 [7-14](#)

Cisco 7505 [3-4 to 3-11](#)

Cisco 7507 and Cisco 7507-MX [3-11 to 3-19](#)

Cisco 7513, Cisco 7513-MX, and Cisco 7576 [3-19 to 3-31](#)

cover panels, Cisco 7513, Cisco 7513-MX, and Cisco 7576 [7-11](#)

fan tray, Cisco 7505 [5-5](#)

LED board [6-14](#)

PC Card [4-21](#)

power harness cover, Cisco 7505 [5-7](#)

power supply

Cisco 7505 [5-15](#)

Cisco 7507 and Cisco 7507-MX [3-14](#)

Cisco 7513, Cisco 7513-MX, and Cisco 7576 [3-27](#)

interface

configuration [4-15 to 4-18](#)

parameters [4-15](#)

processors

additional documentation [1-54](#)

description [1-54](#)

dimensions [1-54](#)

LEDs [1-54, 8-19](#)

- overview [1-54 to 1-55](#)
- removing and installing in Cisco 7505 [3-6](#)
- removing and installing in Cisco 7507 and Cisco 7507-MX [3-13](#)
- removing and installing in Cisco 7513, Cisco 7513-MX, and Cisco 7576 [3-23](#)
- troubleshooting [8-19](#)
- types [1-54](#)
- types supported [1-1](#)

Interior Gateway Routing Protocol, configuring [4-14](#)

interior routing protocol, setting [4-14](#)

intermittent power failures, checking for

- Cisco 7505 [2-27](#)
- Cisco 7507 and Cisco 7507-MX [2-30](#)
- Cisco 7513, Cisco 7513-MX, and Cisco 7576 [2-33, 2-36](#)

Internet Package Exchange, configuring [4-13, 4-14](#)

interrupting system with Break key [4-6](#)

IP, setting routing protocols for [4-14](#)

IPX

- See Internet Package Exchange

L

- label, chassis serial number [8-2](#)
- LED board, replacing [6-13](#)
- LEDs
 - AC OK [8-25](#)
 - CPU Halt [8-21](#)
 - DC Fail [8-23](#)
 - DC OK [4-2, 8-5, 8-13, 8-23, 8-25](#)
 - enabled on interface processors [4-2](#)
 - fan OK [8-25](#)
 - front panel [8-20](#)
 - interface processor [1-54, 8-19](#)
 - normal on front panel [8-20](#)
 - normal on power supply [8-20](#)
 - on all RSPs [1-42](#)
 - output fail [8-25](#)
 - PC Card slot 1 and slot 2 [8-21, 8-22](#)

- power A and power B [8-20](#)
- power supply
 - Cisco 7505 [8-23](#)
 - Cisco 7507 and Cisco 7507-MX [8-23](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 [8-25](#)
- RSP [8-6, 8-10, 8-14, 8-18](#)
- system
 - Cisco 7507 and Cisco 7507-MX [8-20](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 [8-20](#)
- troubleshooting with [8-19 to 8-26](#)
- lightning storm, safety during [2-3](#)
- locked blocks, recovering from [4-32](#)

M

- memory
 - DRAM
 - description [1-42](#)
 - replacement procedures [9-1 to 9-11](#)
 - Flash
 - See Flash memory
 - NVRAM
 - description [1-43](#)
 - RSP4 and RSP8 DRAM configurations [9-8](#)
 - SRAM configurations [1-43](#)
- messages
 - blower shutdown [2-31, 2-35](#)
 - environmental [2-26 to ??](#)
 - fan shutdown [2-29](#)
- microcode, downloadable [1-54](#)

N

- nonvolatile random-access memory
 - See NVRAM
- normal LED
 - front panel [8-21](#)
 - RSP2 [8-21](#)
 - RSP4 and RSP8 [8-22](#)

normal status level, environmental monitor

- Cisco 7505 [2-24](#)
- Cisco 7507 and Cisco 7507-MX [2-25, 2-29](#)
- Cisco 7513, Cisco 7513-MX, and Cisco 7576 [2-25, 2-31, 2-35](#)

- number of VIPs supported, 7505 [1-3](#)
- number of VIPs supported, 7507 [1-6](#)
- number of VIPs supported, 7507-MX [1-11](#)
- number of VIPs supported, 7513 [1-15](#)
- number of VIPs supported, 7513-MX [1-20](#)
- number of VIPs supported, 7576 [1-25](#)

NVRAM

- backup batteries [1-43](#)
- description [1-43](#)
- log [2-23](#)
- RSP2 [1-33](#)
- RSP4 [1-36](#)
- saving settings [4-19](#)
- using with Flash memory [4-30, 4-31](#)

O

- operating conditions for chassis [2-12](#)
- operating temperature [1-10, 1-14](#)
- out-of-tolerance condition [2-23, 8-23, 8-25](#)
- overtemperature conditions [8-1](#)

P

passwords

- enabling [4-8](#)
- recovering [4-9 to 4-10](#)

PC Card

- formatting a new card [4-24](#)
- slots
 - RSP2 [1-33](#)
 - RSP4 [1-36](#)
 - RSP8 [1-39](#)
- types [1-36, 1-39](#)

PFC

- all AC-input power supplies [2-7](#)
- Cisco 7505 power supply [2-7](#)
- Cisco 7507 and Cisco 7507-MX power supply [2-8](#)
- Cisco 7513, Cisco 7513-MX, and Cisco 7576 power supply [2-9](#)

port

- auxiliary
 - description [1-44](#)
 - pinout [1-45](#)
- console
 - description [1-44](#)
 - pinout [1-44](#)

power

- backplane harness [5-2](#)
- cable
 - Cisco 7507 and Cisco 7507-MX [2-8](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 [2-9](#)
 - requirements [5-2](#)
 - safety recommendations [2-2](#)

Cisco 7505 [2-7](#)Cisco 7507 and Cisco 7507-MX [2-8](#)Cisco 7513, Cisco 7513-MX, and Cisco 7576 [2-9](#)cord [8-11, 8-15](#)

DC-output status

- Cisco 7505 [2-24](#)
- Cisco 7507 and Cisco 7507-MX [2-25](#)
- Cisco 7513, Cisco 7513-MX, and Cisco 7576 [2-25](#)

disabled [2-23](#)distribution [5-2](#)emergency switch [2-3](#)

factor corrector

See PFC

failures [2-24, 2-30, 2-33, 2-36](#)harness cover [5-2](#)internal DC voltage [8-5, 8-13](#)LED [8-5, 8-13](#)loss [8-23, 8-25](#)normal startup sequence [8-10](#)

- service [3-2](#)
- site guidelines [2-7](#)
- specifications [1-5, 1-10, 1-14, 1-19, 1-24, 1-30](#)
- status [8-5, 8-13](#)
- subsystem for troubleshooting [8-3](#)
- surge suppression [2-11](#)
- troubleshooting
 - Cisco 7505 [8-7](#)
 - Cisco 7507 and Cisco 7507-MX [8-10](#)
 - Cisco 7513 and Cisco 7513-MX [8-15](#)
 - Cisco 7576 [8-15](#)
- ungrounded [2-3](#)
- power factor corrector [1-10, 1-14](#)
- power supply
 - active [8-23](#)
 - bays
 - Cisco 7507 [1-6](#)
 - Cisco 7507-MX [1-11](#)
 - Cisco 7513 [1-15](#)
 - Cisco 7513-MX [1-20](#)
 - Cisco 7576 [1-25](#)
 - cables
 - Cisco 7505 [1-6](#)
 - Cisco 7507 [1-10](#)
 - Cisco 7507-MX [1-14](#)
 - Cisco 7513 [1-19](#)
 - Cisco 7513-MX [1-24](#)
 - Cisco 7576 [1-30](#)
 - DC-input
 - Cisco 7505 connections [3-9](#)
 - Cisco 7507 and Cisco 7507-MX connections [3-17](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 connections [3-29](#)
 - environmental monitor
 - Cisco 7505 [2-24](#)
 - Cisco 7507 and Cisco 7507-MX [2-25](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 [2-25](#)
 - handles [5-14](#)
 - installation
 - Cisco 7505 [5-13 to 5-14](#)
 - Cisco 7507 and Cisco 7507-MX [3-14 to 3-19](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 [3-27 to 3-31](#)
 - LEDs
 - Cisco 7505 [8-23](#)
 - Cisco 7507 and Cisco 7507-MX [8-23](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 [8-25](#)
 - removal
 - Cisco 7505 [5-13 to 5-15](#)
 - Cisco 7507 and Cisco 7507-MX [6-3 to 6-6](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 [7-3 to 7-5](#)
 - safety interlock on Cisco 7507, Cisco 7507-MX, Cisco 7513, Cisco 7513-MX, and Cisco 7576 [2-7](#)
 - shutdown [2-23, 8-23, 8-25, 8-26](#)
 - specifications
 - Cisco 7505 [1-5](#)
 - Cisco 7507 [1-10](#)
 - Cisco 7507-MX [1-14](#)
 - Cisco 7513 [1-19](#)
 - Cisco 7513-MX [1-24](#)
 - Cisco 7576 [1-30](#)
 - status [8-5, 8-13](#)
 - troubleshooting [8-5, 8-9, 8-13](#)
- privileged mode [4-8](#)
- problem solving, system [8-3](#)
- procedures
 - Autoinstall configuration [4-11](#)
 - cable-management brackets, installing
 - Cisco 7505 [3-9](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 [3-26](#)
 - enabling passwords [4-8](#)
 - Ethernet interface configuration [4-15 to 4-16](#)
 - Flash memory
 - card installation and removal [4-20 to 4-23](#)
 - copying files to [4-25](#)
 - copying files to RSP memory [4-30 to 4-32](#)
 - enabling booting from [4-26](#)
 - formatting cards [4-24](#)

- making images bootable [4-25](#)
- using [4-20 to 4-32](#)
- global parameters, configuring [4-12 to 4-15](#)
- installation [3-24](#)
 - Cisco 7505 [3-4 to 3-11](#)
 - Cisco 7507 and Cisco 7507-MX [3-11 to 3-19](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 [3-24 to 3-31](#)
- installing
 - Cisco 7505 cable-management bracket [3-9](#)
 - Cisco 7505 power supplies [5-13 to 5-14](#)
 - Cisco 7507 and Cisco 7507-MX power supplies [3-14 to 3-19](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 cable-management bracket [3-26](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 power supplies [3-27 to 3-31](#)
- interfaces, configuring [4-15 to 4-18](#)
- maintenance
 - Cisco 7505 [5-1 to 5-15](#)
 - Cisco 7507 and Cisco 7507-MX [6-1 to 6-19](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 [7-1 to 7-19](#)
- rack-mounting, Cisco 7505 [3-7 to ??](#)
- recovering from a lost password [4-9 to 4-10](#)
- removing
 - backplane cover, Cisco 7505 [5-9](#)
 - backplane cover, Cisco 7513, Cisco 7513-MX, and Cisco 7576 [7-13](#)
 - Cisco 7505 cover panel [5-3](#)
 - Cisco 7505 fan tray [5-5](#)
 - Cisco 7505 power supply [5-13 to 5-14](#)
 - Cisco 7507 and Cisco 7507-MX power supplies [6-3 to 6-6](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 card cage [7-5 to 7-7](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 power supplies [7-3 to 7-5](#)
 - cover panels [7-11](#)
 - power harness cover [5-7](#)
 - power supply [7-3](#)
- replacing
 - Cisco 7505 cover panel [5-3](#)
 - Cisco 7505 fan tray [5-5](#)
 - Cisco 7505 power supply [5-15](#)
 - Cisco 7507 and Cisco 7507-MX blower [6-15](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 blower [7-10](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 card cage assembly [7-5 to 7-9](#)
 - cover panels [7-11](#)
 - power harness cover [5-7](#)
- replacing processor modules
 - Cisco 7505 [3-6](#)
 - Cisco 7507 and Cisco 7507-MX [3-13](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 [3-23](#)
- router configuration, basic [4-1 to 4-19](#)
- synchronous serial interface configuration [4-16 to 4-18](#)
- system configuration, basic [4-11 to 4-19](#)
- system startup [4-2 to 4-3](#)
- upgrading DRAM [9-1 to 9-11](#)
- using Autoinstall [4-11](#)
- using configuration mode [4-18](#)
- using setup command facility [4-12](#)
- processor
 - modules
 - black cardboard board rack, Cisco 7513, Cisco 7513-MX, and Cisco 7576 [3-20](#)
 - removal and replacement in Cisco 7505 [3-6](#)
 - removal and replacement in Cisco 7507 and Cisco 7507-MX [3-13](#)
 - removal and replacement in Cisco 7513, Cisco 7513-MX, and Cisco 7576 [3-23](#)
 - shutdown [2-23](#)
 - system
 - RSP2 [1-32](#)
 - RSP4 [1-35](#)
- protocols [1-1](#)

R

rack

- recommendations, Cisco 7505 [2-16](#)
- recommendations, Cisco 7507 and Cisco 7507-MX [2-18](#)
- recommendations, Cisco 7513, Cisco 7513-MX, and Cisco 7576 [2-20](#)
- ventilation [2-15](#)

rack-mounting procedure, Cisco 7505 [3-7 to ??](#)

radio frequency interference

See RFI

recovering a lost password [4-9](#)

refresh, environmental display [2-28](#)

reload command [4-7](#)

replaceable system components [5-1, 6-1, 7-1](#)

reports, environmental [2-26](#)

reset switch [8-22](#)

RFI, preventing effects of [2-11](#)

RIP

See Routing Information Protocol

Routing Information Protocol, configuring [4-14](#)

RSP

- console and auxiliary port connections [3-32](#)
- Flash memory card replacement [4-20](#)
- LEDs [8-6, 8-10, 8-14, 8-18](#)
- normal startup [8-6, 8-10, 8-14](#)
- operating voltages [8-5, 8-13](#)
- troubleshooting [8-18](#)

RSP2

description [1-31 to 1-33](#)

DRAM

- location [9-1](#)
- upgrade procedure [9-1 to 9-5](#)
- system CPU [1-32](#)
- Y-cables [1-45](#)

RSP4

- 3.3V DIMM device caution [9-6, 9-7](#)
- description [1-33 to 1-36](#)

DRAM

- location [9-6](#)
- system CPU [1-35](#)
- Y-cables [1-45](#)

RSP4 and RSP8

3.3V DIMM device caution [9-8](#)

DRAM

- DIMM configurations [9-8](#)
- upgrade procedure [9-5 to 9-11](#)

RSP8

- description [1-36 to 1-38](#)
- DRAM DIMM location [9-7](#)
- Y-cables [1-45](#)

S

safety

agency approvals

- Cisco 7505 [1-6](#)
- Cisco 7507 [1-10](#)
- Cisco 7507-MX [1-14](#)
- Cisco 7513 [1-19](#)
- Cisco 7513-MX [1-24](#)
- Cisco 7576 [1-30](#)

cable recommendations [2-2](#)

ESD [2-6](#)

general guidelines [2-2](#)

lifting the chassis [2-3, 2-5](#)

recommendations [2-2, 2-3](#)

Safety Warnings [xv](#)

sample configuration [4-13 to 4-15, 4-16 to 4-17](#)

saving the configuration file [4-17, 4-19](#)

secret passwords, enabling [4-8](#)

sensors, temperature [2-28, 2-30, 2-33, 2-36](#)

setup command facility

example [4-14](#)

script

- banner information (example) [4-12](#)
- interface summary (example) [4-13](#)

- System Configuration Dialog (example) [4-13](#)
- using [4-12](#)
- show environment command [2-26, 2-28](#)
- show environment table command [2-27, 2-29, 2-32, 2-35](#)
- show version command [4-7](#)
- shutdown
 - blower failure [2-31, 2-35](#)
 - environmental [2-22, 8-8, 8-16, 8-17](#)
 - fan failure [2-29](#)
 - power supply [2-23, 8-23, 8-25](#)
 - processor [2-23](#)
 - thresholds [2-22](#)
- SIMM [9-1](#)
- Simple Network Management Protocol, configuring [4-14](#)
- site
 - cabling guidelines [2-10](#)
 - environmental guidelines [2-12 to 2-15](#)
 - power [2-7](#)
- SNMP
 - See Simple Network Management Protocol
- software
 - configuration register functions [4-4 to 4-7](#)
 - minimum system requirements
 - Cisco 7505 [1-6](#)
 - Cisco 7507 [1-10](#)
 - Cisco 7507-MX [1-14](#)
 - Cisco 7513 [1-19](#)
 - Cisco 7513-MX [1-24](#)
 - Cisco 7576 [1-30](#)
- spare parts
 - Cisco 7505
 - chassis interface [5-11](#)
 - fan tray [5-5](#)
 - power supply [5-13](#)
 - Cisco 7507 and Cisco 7507-MX
 - air filter [6-10](#)
 - blower assembly [6-15](#)
 - LED board [6-13](#)
 - power supplies [6-3](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576
 - blower module [7-10](#)
 - card cage assembly [7-5](#)
 - chassis interface [7-14](#)
 - power supplies [7-3](#)
 - spares definition [1-3](#)
- specifications
 - altitude [2-13](#)
 - Cisco 7505 [1-5](#)
 - Cisco 7507 [1-10](#)
 - Cisco 7507-MX [1-14](#)
 - Cisco 7513 [1-19](#)
 - Cisco 7513-MX [1-24](#)
 - Cisco 7576 [1-30](#)
 - humidity [2-12](#)
 - power supply
 - Cisco 7505 [1-5](#)
 - Cisco 7507 [1-10](#)
 - Cisco 7507-MX [1-14](#)
 - Cisco 7513 [1-19](#)
 - Cisco 7513-MX [1-24](#)
 - Cisco 7576 [1-30](#)
 - RSP2 [1-33](#)
 - RSP4 [1-35](#)
 - temperature
 - Cisco 7505 [1-5](#)
 - Cisco 7507 [1-10](#)
 - Cisco 7507-MX [1-14](#)
 - Cisco 7513 [1-19](#)
 - Cisco 7513-MX [1-24](#)
 - Cisco 7576 [1-30](#)
 - system [2-12](#)
 - vibration [2-13](#)
 - voltage
 - Cisco 7505 [1-5](#)
 - Cisco 7507 [1-10](#)
 - Cisco 7507-MX [1-14](#)
 - Cisco 7513 [1-19](#)
 - Cisco 7513-MX [1-24](#)

- Cisco 7576 [1-30](#)
- weight
 - Cisco 7505 [1-5](#)
 - Cisco 7507 [1-10](#)
 - Cisco 7507-MX [1-14](#)
 - Cisco 7513 [1-19](#)
 - Cisco 7513-MX [1-24](#)
 - Cisco 7576 [1-30](#)
- startup, system [4-2, 4-2 to 4-3](#)
- statistics, environmental [2-28, 2-32](#)
- subsystems for troubleshooting
 - cooling [8-17](#)
- switch, emergency power [2-3](#)
- synchronous serial interfaces, configuring [4-16](#)
- system
 - backplane [1-4](#)
 - banner [4-2, 8-6, 8-14](#)
 - booting for the first time [4-8](#)
 - configuration, basic [4-11 to 4-19](#)
 - configuration register
 - configuration [4-4 to 4-7](#)
 - settings [4-3](#)
 - CPU
 - RSP2 [1-32](#)
 - RSP4 [1-35](#)
 - internal components [6-11](#)
 - LEDs
 - Cisco 7507 and Cisco 7507-MX [8-20](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 [8-20](#)
 - power [8-5, 8-13](#)
 - problems at startup [8-2](#)
 - problem solving [8-3](#)
 - processor
 - RSP2 [1-32](#)
 - RSP4 [1-35](#)
 - RSP8 [1-37](#)
 - replaceable components [5-1, 6-1, 7-1](#)
 - shutdown [8-5, 8-13](#)
 - specifications

- Cisco 7505 [1-5](#)
- Cisco 7507 [1-10](#)
- Cisco 7507-MX [1-14](#)
- Cisco 7513 [1-19](#)
- Cisco 7513-MX [1-24](#)
- Cisco 7576 [1-30](#)
- startup [4-2 to 4-3, 8-4, 8-13](#)
- troubleshooting [8-1 to 8-26](#)

T

- telco-type equipment racks [2-16, 2-18](#)
- telephone jacks [2-3](#)
- temperature
 - internal chassis [2-22](#)
 - operating [1-19, 1-24, 1-30](#)
 - parameters for environmental monitor [2-28, 2-33](#)
 - sensors [2-28, 2-30, 2-33, 2-36](#)
 - specifications
 - Cisco 7505 [1-5](#)
 - Cisco 7507 [1-10](#)
 - Cisco 7507-MX [1-14](#)
 - Cisco 7513 [1-19](#)
 - Cisco 7513-MX [1-24](#)
 - Cisco 7576 [1-30](#)
 - system [2-12](#)
 - temperature and voltage thresholds
 - Cisco 7505 [2-24](#)
 - Cisco 7507 and Cisco 7507-MX [2-25](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 [2-25](#)
 - descriptions [2-24 to 2-25](#)
- terminal block cover, removing and replacing
 - Cisco 7505 [3-10](#)
 - Cisco 7507 and Cisco 7507-MX [3-17](#)
 - Cisco 7513, Cisco 7513-MX, and Cisco 7576 [3-30](#)
- thresholds
 - environmental [2-25, 2-26](#)
 - shutdown [2-22](#)
- time-division multiplexing (TDM) [1-3, 1-13, 1-23, 1-28](#)

traffic on CyBus [1-50](#)
 transmission rate settings [A-4](#)

troubleshooting

cooling subsystem [8-17](#)

installation [8-1](#)

power

Cisco 7505 [8-7](#)

Cisco 7507 and Cisco 7507-MX [8-10](#)

Cisco 7513 and Cisco 7513-MX [8-15](#)

Cisco 7576 [8-15](#)

strategy

Cisco 7505 [8-4](#)

Cisco 7507 and Cisco 7507-MX [8-9](#)

Cisco 7513, Cisco 7513-MX, and Cisco 7576 [8-12](#)

using LEDs [8-19 to 8-26](#)

using subsystems

Cisco 7505 [8-4 to 8-8](#)

Cisco 7507 and Cisco 7507-MX [8-8 to 8-12](#)

Cisco 7513, Cisco 7513-MX, and Cisco
7576 [8-12 to 8-17](#)

processors [8-18 to 8-19](#)

turbo arbiter [1-13, 1-23, 1-50](#)

U

UL agency approvals

Cisco 7505 [1-6](#)

Cisco 7507 [1-10](#)

Cisco 7507-MX [1-14](#)

Cisco 7513 [1-19](#)

Cisco 7513-MX [1-24](#)

Cisco 7576 [1-30](#)

upgrades

DRAM

RSP2 [9-1 to 9-5](#)

RSP4 and RSP8 [9-5 to 9-11](#)

V

vacuuming, air filter [6-10](#)

ventilation, rack [2-15](#)

vibration specifications, system [2-13](#)

voltage

out-of-tolerance condition, description of [2-23](#)

specifications

Cisco 7505 [1-5](#)

Cisco 7507 [1-10](#)

Cisco 7507-MX [1-14](#)

Cisco 7513 [1-19](#)

Cisco 7513-MX [1-24](#)

Cisco 7576 [1-30](#)

voltage and temperature thresholds

Cisco 7505 [2-24](#)

Cisco 7507 and Cisco 7507-MX [2-25](#)

Cisco 7513, Cisco 7513-MX, and Cisco 7576 [2-25](#)

descriptions [2-24 to 2-25](#)

W

warnings

warning definition [xv](#)

warnings in environmental reports

Cisco 7505 [2-28](#)

Cisco 7507 [2-29](#)

Cisco 7513, Cisco 7513-MX, and Cisco 7576 [2-33](#)

weight

Cisco 7505 [1-5](#)

Cisco 7507 [1-10](#)

Cisco 7507-MX [1-14](#)

Cisco 7513 [1-19](#)

Cisco 7513-MX [1-24](#)

Cisco 7576 [1-30](#)

wiring

backplane [5-2, 6-2, 7-2](#)

codes

Cisco 7505 [2-8](#)

Cisco 7507 and Cisco 7507-MX [2-8](#)

Cisco7507 and Cisco 7507-MX [2-8, 3-13](#)

Cisco 7513, Cisco 7513-MX, and Cisco 7576 [2-9](#)

Cisco7513, Cisco 7513-MX, and Cisco 7576 [3-23](#)

guidelines [2-10 to 2-11](#)

interference [2-10](#)

plant [2-10](#)

telephone [2-3](#)

See also cables

Y

Y-cables, RSP2, RSP4, and RSP8 [1-45](#)