



---

## Numerics

### 4xflexi

- alarms [5-17](#)
- edge connector key [1-22](#)
- faceplate [1-23](#)
- features [1-22](#)
- hot swapping [2-9](#)
- installing [6-4](#)
- intermixing [1-24, 1-25](#)
- LEDs [1-23](#)
- location [1-2](#)
- removing [6-3](#)
- specifications [A-6](#)
- troubleshooting [5-8](#)

### 4xSDSL

- alarms [5-17](#)
- edge connector key [1-21](#)
- faceplate [1-21](#)
- features [1-20](#)
- hot swapping [2-9](#)
- installing [6-4](#)
- intermixing [1-24](#)
- LEDs [1-21](#)
- location [1-2](#)
- removing [6-3](#)
- specifications [A-6](#)
- troubleshooting [5-8](#)

### 8xDMT

- alarms [5-17](#)
- faceplate [1-19](#)
- features [1-18](#)
- hot swapping [2-9](#)

- installing [6-4](#)
- intermixing [1-24, 1-25](#)
- LEDs [1-19](#)
- location [1-2](#)
- removing [6-3](#)
- specifications [A-5](#)
- troubleshooting [5-8](#)

### 8xG.SHDSL

- alarms [5-17](#)
- faceplate [1-17](#)
- features [1-16](#)
- hot swapping [2-9](#)
- installing [6-4](#)
- intermixing
  - 12.1(7)DA2 [1-25](#)
  - 12.2(1b)DA [1-25](#)
  - 12.2(5)DA [1-25](#)
  - 12.2(7)DA and forward [1-25](#)
- overview [1-24](#)

- LEDs [1-17](#)
- location [1-2](#)
- removing [6-3](#)
- specifications [A-4](#)
- spectral compatibility [1-27](#)
- troubleshooting [5-8](#)

### 8xIDSL

- alarms [5-17](#)
- faceplate [1-15](#)
- features [1-14](#)
- hot swapping [2-9](#)
- installing [6-4](#)
- intermixing [1-24](#)
- LEDs [1-15](#)

location [1-2](#)  
 removing [6-3](#)  
 specifications [A-3](#)  
 troubleshooting [5-8](#)

---

## A

ACO button [1-27](#)

ADSL [1-1](#)

air

exhaust vent [2-12](#)  
 filter  
   cleaning or replacing [6-37](#)  
   description [1-56](#)  
   location [1-2, 1-56](#)  
   maintenance schedule [1-56](#)  
   removing [6-36](#)  
   troubleshooting [5-16](#)  
 intake vent [2-12](#)

alarm

contacts  
   connect [3-14, 4-14](#)  
   wire [2-17](#)

alarm cut-off button

see ACO button

alarms

blower tray [5-20](#)  
 chassis [5-16](#)  
 Cisco IOS [5-19](#)  
 DS3 interfaces [5-17](#)  
 IMA interfaces [5-18](#)  
 line card [5-17](#)  
 OC-3c interfaces [5-17](#)  
 power [5-20](#)  
 redundancy [5-19](#)  
 T1 interfaces [5-18](#)  
 troubleshooting [5-16](#)  
 types [1-57](#)

altitude [2-11](#)

antistatic strap, resistance value [2-8](#)

apply power [3-16, 4-16](#)

asymmetric digital subscriber line

see ADSL

auxiliary port

connect [3-25, 4-25](#)  
 pin assignments [C-5](#)

---

## B

backplane

access [2-15](#)  
 Champ connectors [1-12](#)  
 description [1-11](#)  
 I/O card connectors [1-12](#)  
 illustration [1-11](#)  
 power terminal block connector [1-12](#)  
 terminal block connector for external alarms [1-12](#)

back up software [6-1](#)

basic management setup [3-27, 4-27](#)

BITS clock interface

connect [3-15, 4-15](#)  
 pin mapping [C-3, C-4](#)  
 wire [2-17](#)

blank faceplate

installing [3-5, 4-5, 6-5](#)  
 removing [6-5](#)  
 requirements [6-5](#)

blower tray

alarms [5-20](#)  
 faceplate [1-55](#)  
 features [1-54](#)  
 hot swapping [2-9](#)  
 installing [6-34](#)  
 LEDs [1-55](#)  
 location [1-2](#)  
 removing [6-33](#)  
 specifications [A-13](#)  
 troubleshooting [5-16](#)

ventilation [2-11](#)  
bootflash, copy [6-1](#)

## C

### cables

DS3 [2-17](#)  
Ethernet [2-17](#)  
MDF [2-16](#)  
OC-3c [2-17](#)  
POTS splitter [2-16](#)

### cabling

Cisco 6160 and POTS splitter [3-12](#)  
Cisco 6160 chassis to MDF [4-15](#)  
POTS splitter to cross connect [3-15](#)  
POTS splitter to MDF [3-15](#)

### calculation

power [2-14](#)  
rack space [2-13](#)

### card

compartment [1-13](#)  
hot swapping [2-9](#)  
installation suggestions [2-10](#)  
replacement suggestions [2-10](#)

### caution, definition [xvii](#)

### CDM

definition [1-3](#)  
Element Management Framework [1-3](#)

### Champ connectors

backplane [1-12](#)  
data transfer [1-12](#)  
port mapping table [B-1](#)  
xDSL connector pin locations [C-1](#)

### Cisco 6160 chassis

air filter [1-56](#)  
alarms [5-16](#)  
backplane  
  Champ connectors [1-12](#)  
  description [1-11](#)

I/O card connectors [1-12](#)

illustration [1-11](#)

power terminal block connector [1-12](#)

terminal block connector for external alarms [1-12](#)

blower tray [1-54](#)

cabling to MDF [4-15](#)

cabling to POTS splitter [3-12](#)

card compartment [1-13](#)

components

  list [1-1](#)  
  location [1-2](#)

configuration

  IMA [1-5](#)  
  subtended network [1-6](#)  
  with a POTS splitter [1-4](#)  
  without a POTS splitter [1-4](#)

connect power [3-12, 4-12](#)

ear brackets, installation [3-4, 4-3](#)

ESD jack [2-8](#)

grounding procedures [3-6, 4-6](#)

halves [1-24](#)

hardware components [1-10](#)

I/O cards

  connectors [1-12](#)  
  NI-2 compatibility [1-43](#)

installation [3-4, 4-3](#)

line cards [1-14](#)

network connections [1-3](#)

NI-2 cards [1-27](#)

PEM [1-52](#)

port mapping table [B-1](#)

power distribution [1-52](#)

quadrants [1-24](#)

slot assignment [1-14](#)

ventilation [2-11](#)

### Cisco 6160 system

alarms [5-16](#)  
altitude [2-11](#)  
basic management setup [3-27, 4-27](#)

- configurations 1-4
- configuring 3-31, 4-31
- connect power 3-12, 4-12
- extended setup 3-28, 4-28
- features 1-3
- humidity 2-11
- initial configuration 3-25, 4-25
- interface numbering 3-26, 4-26
- introduction 1-1
- management software 1-3, 1-56
- NI-2 card redundancy 1-41
- racks 2-15
- rack space requirements 2-15
- shipment damage 2-19
- specifications A-2
- subscribers supported 1-1
- system configuration dialog 3-26, 4-26
- technologies 1-1
- temperature 2-11
- unpacking 2-18
- verification 2-19
- Cisco 6160 with a POTS splitter
  - definition 1-4
  - installation
    - checklist 3-2
    - procedures 3-3 to 3-31
  - rack space calculation 2-13
- Cisco 6160 without a POTS splitter
  - definition 1-4
  - installation
    - checklist 4-2
    - procedures 4-2 to 4-31
  - rack space calculation 2-13
- Cisco DSL Manager
  - see CDM
- Cisco IOS
  - alarms 5-19
  - definition 1-3
  - software image, copy 6-1
- cleaning, air filter 6-37
- components, chassis 1-1
- configuration
  - file, copy 6-1
  - initial 3-25, 4-25
- configurations
  - Cisco 6160 with a POTS splitter 1-4
  - Cisco 6160 without a POTS splitter 1-4
  - IMA 1-5
  - subtended network 1-6
- configuring, Cisco 6160 system 3-31, 4-31
- connections
  - alarm 3-14, 4-14
  - attach power 3-12, 4-12
  - auxiliary port 3-25, 4-25
  - console terminal 3-24, 4-24
  - Ethernet 3-24, 4-24
  - external alarm device 3-14, 4-14
  - management network 3-24, 4-24
  - network
    - DS3 3-22, 4-22
    - OC-3c 3-23, 4-23
    - T1 3-23, 4-23
    - T1 IMA 3-23, 4-23
  - NI-2 card to network 3-22, 4-22
  - subtending
    - DS3 3-17, 4-17
    - OC-3c 3-19, 4-19
    - T1 3-20, 4-20
    - T1 IMA 3-20, 4-20
  - subtending host chassis to subtended node chassis 3-16, 4-16
- connectors
  - BITS clock interface 3-15, 4-15
  - Champ for subscribers 1-12
  - I/O cards 1-12
  - power terminal block 1-12
  - terminal block for external alarms 1-12
- console port, pin assignments C-5

console terminal, connect [3-24, 4-24](#)  
 contacting Cisco TAC, see troubleshooting

copy

- bootflash [6-1](#)
- Cisco IOS software image [6-1](#)
- configuration file [6-1](#)

cross connect, cabling to POTS splitter [3-15](#)

## D

damage from shipping [2-19](#)

documentation, related [xvii](#)

DS3

connection

- cable [2-17](#)
- network [3-22, 4-22](#)
- subtending [3-17, 4-17](#)

interfaces, alarms [5-17](#)

DS3+T1/E1 IMA NI-2 card

- alarms [5-17, 5-18](#)
- faceplate [1-30](#)
- features [1-27, 1-29](#)
- hardware configuration [1-28](#)
- hot swapping [2-9](#)
- installing [6-7](#)
- LEDs [1-31](#)
- removing [6-6](#)
- specifications [A-7](#)
- subtended node chassis [1-8](#)
- subtending [1-7](#)
- subtending host chassis [1-8](#)
- troubleshooting [5-12](#)

DS3/2DS3+8xT1 IMA I/O card

- connectors [1-12, 1-45](#)
- EMI cover
  - illustration [1-44](#)
  - installation [6-21](#)
  - removal [6-17](#)
- features [1-43](#)

illustration [1-44](#)

installing [6-19](#)

location [1-46](#)

removing [6-16](#)

specifications [A-12](#)

troubleshooting [5-14](#)

wire-wrap pins

- alarm functions [1-47](#)
- features [1-46](#)
- mapping [C-3](#)
- wiring method [1-48](#)

DS3/2DS3 I/O card

connectors [1-12, 1-50](#)

EMI cover

- illustration [1-49](#)
- installation [6-28](#)
- removal [6-24](#)

features [1-48](#)

illustration [1-49](#)

installing [6-26](#)

location [1-51](#)

removing [6-23](#)

specifications [A-12](#)

troubleshooting [5-14](#)

wire-wrap pins

- alarm functions [1-52](#)
- features [1-51](#)
- mapping [C-4](#)
- wiring method [1-52](#)

DS3/2DS3 NI-2 card

- alarms [5-17](#)
- faceplate [1-33](#)
- features [1-27, 1-32](#)
- hardware configuration [1-28](#)
- hot swapping [2-9](#)
- installing [6-9](#)
- LEDs [1-34](#)
- removing [6-9](#)
- specifications [A-9](#)

subtended node chassis [1-9](#)  
 subtending [1-9](#)  
 subtending host chassis [1-9](#)  
 troubleshooting [5-12](#)

---

## E

### ear brackets

front mount installation [3-5, 4-5](#)  
 location [3-4, 4-3](#)  
 mid-mount installation [3-4, 4-4](#)

### edge connector key

4xflexi [1-22](#)  
 4xSDSL [1-21](#)

### EMI cover

DS3/2DS3+8xT1 IMA I/O card [1-44](#)  
 DS3/2DS3 I/O card [1-49](#)  
 installing [6-21, 6-28](#)  
 removing [6-17, 6-24](#)

### environmental requirements [2-10](#)

### equipment requirements [2-16](#)

### ESD

equipment [2-17](#)  
 guidelines [2-8](#)  
 jack location [2-8](#)  
 prevention [2-8](#)  
 requirements [2-2](#)

### Ethernet

cable [2-17](#)  
 connect [3-24, 4-24](#)  
 pin assignments [C-6](#)

### example

basic management setup [3-27, 4-27](#)  
 extended setup [3-28, 4-28](#)

### extended setup [3-28, 4-28](#)

### external alarm device, connect [3-14, 4-14](#)

### external power requirements [2-13](#)

---

## F

### faceplate

4xflexi [1-23](#)  
 4xSDSL [1-21](#)  
 8xDMT [1-19](#)  
 8xG.SHDSL [1-17](#)  
 8xIDSL [1-15](#)  
 blank, installing [3-5, 4-5](#)  
 blower tray [1-55](#)  
 DS3+T1/E1 IMA NI-2 card [1-30](#)  
 DS3/2DS3 NI-2 card [1-33](#)  
 OC-3c/2DS3 NI-2 card [1-36](#)  
 OC-3c/OC-3c NI-2 card [1-39](#)  
 PEM [1-53](#)

---

## G

### G.SHDSL [1-1](#)

### general maintenance guidelines [2-9](#)

### grounding

Cisco 6160 [3-6, 4-6](#)

ESD jack [2-8](#)

lug, location [3-7, 4-7](#)

POTS splitter [3-11](#)

power source [2-13](#)

### power terminal block connector

closed position [3-10, 4-10](#)

location [3-9, 4-9](#)

open position [3-10, 4-10](#)

using grounding lug [3-6, 4-6](#)

using power terminal block connector [3-8, 4-8](#)

### wire

connecting to power terminal block connector [3-10, 4-10](#)

connecting to rack [3-7, 3-11, 4-7, 4-11](#)

connecting to the Cisco 6160 [3-7, 4-7](#)

type [2-17](#)

### guidelines

ESD 2-8  
 general maintenance 2-9  
 safety 2-1

---

## H

halves, defined 1-24  
 hardware specifications, see specifications  
 hot swapping  
   4xflexi 2-9  
   4xSDSL 2-9  
   8xDMT 2-9  
   8xG.SHDSL 2-9  
   8xIDSL 2-9  
   blower tray 2-9  
   cards 2-9  
   DS3+T1/E1 IMA NI-2 card 2-9  
   DS3/2DS3 NI-2 card 2-9  
   OC-3c/2DS3 NI-2 card 2-9  
   OC-3c/OC-3c NI-2 card 2-9  
   PEM 2-9  
   service impact 5-2  
   troubleshooting 5-2  
 humidity 2-11

---

## I

I/O card  
   connect external alarm device 3-14, 4-14  
   DS3/2DS3+8xT1 IMA I/O card 1-43  
   DS3/2DS3 I/O card 1-48  
   see also DS3/2DS3+8xT1 IMA I/O card  
   see also DS3/2DS3 I/O card  
   troubleshooting 5-14  
   wire-wrap pin mapping C-3, C-4  
 IDSL 1-1  
 IMA  
   alarms 5-18

  configuration, definition 1-5  
   definition 1-5  
   groups 1-5  
 initial configuration 3-25, 4-25  
 inspecting for damage 2-19  
 installation  
   4xflexi 6-4  
   4xSDSL 6-4  
   8xDMT 6-4  
   8xG.SHDSL 6-4  
   8xIDSL 6-4  
   blank faceplate 3-5, 4-5, 6-5  
   blower tray 6-34  
   checklist  
     Cisco 6160 with a POTS splitter configuration 3-2  
     Cisco 6160 without a POTS splitter configuration 4-2  
   Cisco 6160 chassis 3-4, 4-3  
   DS3+T1/E1 IMA NI-2 card 6-7  
   DS3/2DS3+8xT1 IMA I/O card 6-19  
   DS3/2DS3 I/O card 6-26  
   DS3/2DS3 NI-2 card 6-9  
   EMI cover 6-21, 6-28  
   OC-3c/2DS3 NI-2 card 6-12  
   OC-3c/OC-3c NI-2 card 6-14  
   PEM 6-31  
   POTS splitter 3-3  
   procedures  
     Cisco 6160 with a POTS splitter configuration 3-3 to 3-31  
     Cisco 6160 without a POTS splitter configuration 4-2 to 4-31  
   suggestions  
     card 2-10  
     module 2-10  
   xTU-C line card 6-4  
 interface  
   naming 1-6  
   numbering 3-26, 4-26  
 intermixing

## G.SHDSL guidelines

Release 12.1(7)DA2 [1-25](#)Release 12.2(1b)DA [1-25](#)Release 12.2(5)DA [1-25](#)Release 12.2(7)DA [1-25](#)line cards [1-24](#)

## IOS

see Cisco IOS

## ISDN digital subscriber line

see IDSL

## L

## LED

4xflexi [1-23](#)4xSDSL [1-21](#)8xDMT [1-19](#)8xG.SHDSL [1-17](#)8xIDSL [1-15](#)blower tray [1-55](#)DS3+T1/E1 IMA NI-2 card [1-31](#)DS3/2DS3 NI-2 card [1-34](#)OC-3c/2DS3 NI-2 card [1-37](#)OC-3c/OC-3c NI-2 card [1-40](#)PEM [1-54](#)

## line cards

4xflexi [1-22](#)4xSDSL [1-20](#)8xDMT [1-18](#)8xG.SHDSL [1-16](#)8xIDSL [1-14](#)intermixing [1-24, 1-25](#)locking tab [6-3](#)slot assignment [1-14](#)troubleshooting [5-8](#)locking tab [6-3, 6-6](#)

## M

management network, connect [3-24, 4-24](#)

## management software

alarm types [1-57](#)options [1-3](#)specifications [A-14](#)

## MDF

cables [2-16](#)cabling to POTS splitter [3-15](#)cabling to the Cisco 6160 chassis [4-15](#)modem support [1-3](#)

## module

installation suggestions [2-10](#)replacement suggestions [2-10](#)

## N

NEBS compliance [1-3](#)

## network

## clocking

connect [3-15, 4-15](#)overview [1-41](#)

## connections

DS3 [3-22, 4-22](#)OC-3c [3-23, 4-23](#)overview [1-3](#)procedures [3-22, 4-22](#)T1 [3-23, 4-23](#)T1 IMA [3-23, 4-23](#)connect to NI-2 card [3-22, 4-22](#)

## timing signal

BITS clock [1-41](#)internal clock [1-41](#)types [1-41](#)trunk interface [1-41](#)

## NI-2 card

ACO button [1-27](#)

connect



- auxiliary port [3-25, 4-25](#)
- console terminal [3-24, 4-24](#)
- Ethernet [3-24, 4-24](#)
- to network [3-22, 4-22](#)
- features [1-27](#)
- hardware configuration [1-28](#)
- location [1-2](#)
- locking tab [6-6](#)
- network clocking [1-41](#)
- redundancy
  - alarms [5-19](#)
  - APS link [1-42](#)
  - cold [1-41](#)
  - definition [1-41](#)
  - subtended configurations [1-42](#)
- see also DS3+T1/E1 IMA NI-2 card
- see also DS3/2DS3 NI-2 card
- see also OC-3c/2DS3 NI-2 card
- see also OC-3c/OC-3c NI-2 card
- troubleshooting [5-12](#)
- note, definition [xvi](#)

---

## O

### OC-3c

- connections
  - cable [2-17](#)
  - network [3-23, 4-23](#)
  - subtending [3-19, 4-19](#)
- interfaces, alarms [5-17](#)

### OC-3c/2DS3 NI-2 card

- alarms [5-17](#)
- faceplate [1-36](#)
- features [1-27, 1-35](#)
- hardware configuration [1-28](#)
- hot swapping [2-9](#)
- installing [6-12](#)
- LEDs [1-37](#)
- removing [6-11](#)

- specifications [A-10](#)
- subtended node chassis [1-9](#)
- subtending [1-9](#)
- subtending host chassis [1-9](#)
- troubleshooting [5-12](#)

### OC-3c/OC-3c NI-2 card

- alarms [5-17](#)
- faceplate [1-39](#)
- features [1-27, 1-38](#)
- hardware configuration [1-28](#)
- hot swapping [2-9](#)
- installing [6-14](#)
- LEDs [1-40](#)
- removing [6-13](#)
- specifications [A-11](#)
- subtended node chassis [1-10](#)
- subtending [1-10](#)
- subtending host chassis [1-10](#)
- troubleshooting [5-12](#)

### octal-port

#### DMT ATU-C line card

- see [8xDMT](#)

#### ITU-C line card

- see [8xIDSL](#)

#### single-pair high-speed digital subscriber line line card

- see [8xG.SHDSL](#)

#### symmetric high bit rate digital subscriber loop line card

- see [8xG.SHDSL](#)

---

## P

### PEM

- alarms [5-20](#)
- faceplate [1-53](#)
- features [1-52](#)
- hot swapping [2-9](#)
- installing [6-31](#)
- LEDs [1-54](#)
- LED verification [3-16, 4-16](#)

- location [1-2](#)
  - removing [6-30](#)
  - specifications [A-13](#)
  - troubleshooting [5-15](#)
  - pin assignments
    - auxiliary ports [C-5](#)
    - console port [C-5](#)
    - Ethernet port [C-6](#)
  - pins
    - auxiliary port [C-5](#)
    - console port [C-5](#)
    - DS3/2DS3+8xT1 IMA I/O card [C-3](#)
    - DS3/2DS3 I/O card [C-4](#)
    - Ethernet port [C-6](#)
    - RJ-48c receptacles [C-4](#)
    - xDSL connector [C-1](#)
  - polarity, check [3-16, 4-16](#)
  - port mapping table [B-1](#)
  - POTS [2-11](#)
  - POTS splitter
    - cables [2-16](#)
    - cabling to Cisco 6160 [3-12](#)
    - cabling to cross connect [3-15](#)
    - cabling to MDF [3-15](#)
    - definition [1-2](#)
    - grounding procedures [3-11](#)
    - installation [3-3](#)
    - ventilation [2-11](#)
  - power
    - apply [3-16, 4-16](#)
    - connect Cisco 6160 to power source [3-12, 4-12](#)
    - connection, wire [2-17](#)
    - distribution [1-52](#)
    - external [2-13](#)
    - introduction [2-13](#)
    - requirements [2-13](#)
    - source
      - connect to Cisco 6160 [3-12, 4-12](#)
      - grounding [2-13](#)
  - terminal block connector
    - closed position [3-10, 4-10](#)
    - grounding [3-8, 4-8](#)
    - location [1-12](#)
    - open position [3-10, 4-10](#)
  - power entry module
    - see PEM
- 
- ## Q
- quad-port
    - flexi ATU-C line card
      - see 4xflexi
    - STU-C line card
      - see 4xSDSL
  - quadrants
    - defined [1-24](#)
    - intermixing [1-25](#)
- 
- ## R
- rack
    - requirements [2-15](#)
    - stabilize [3-3, 4-3](#)
  - rack space
    - calculation [2-13](#)
    - Cisco 6160 with a POTS splitter [2-13](#)
    - Cisco 6160 without a POTS splitter [2-13](#)
    - measure [3-3, 4-3](#)
    - requirements [2-13](#)
  - redundancy
    - alarms [5-19](#)
    - see NI-2 card redundancy
    - troubleshooting [5-13](#)
  - removal
    - 4xflexi [6-3](#)
    - 4xSDSL [6-3](#)
    - 8xDMT [6-3](#)

- 8xG.SHDSL [6-3](#)
  - 8xIDSL [6-3](#)
  - air filter [6-36](#)
  - blank faceplate [6-5](#)
  - blower tray [6-33](#)
  - DS3+T1/E1 IMA NI-2 card [6-6](#)
  - DS3/2DS3+8xT1 IMA I/O card [6-16](#)
  - DS3/2DS3 I/O card [6-23](#)
  - DS3/2DS3 NI-2 card [6-9](#)
  - EMI cover [6-17, 6-24](#)
  - OC-3c/2DS3 NI-2 card [6-11](#)
  - OC-3c/OC-3c NI-2 card [6-13](#)
  - PEM [6-30](#)
  - xTU-C line card [6-3](#)
  - replacement suggestions
    - card [2-10](#)
    - module [2-10](#)
  - replacing, air filter [6-37](#)
  - requirements
    - altitude [2-11](#)
    - blank faceplate [6-5](#)
    - environmental [2-10](#)
    - equipment [2-16](#)
    - external power [2-13](#)
    - humidity [2-11](#)
    - power [2-13](#)
    - rack [2-15](#)
    - rack space [2-13](#)
    - safety [2-1](#)
    - site [2-10](#)
    - temperature [2-11](#)
    - tool [2-16](#)
  - resistance value, antistatic strap [2-8](#)
  - RJ-48c receptacles, pins [C-4](#)
- 
- S**
- safety
    - guidelines [2-1](#)
  - requirements [2-1](#)
  - SDSL [1-1](#)
  - service interruptions, hot swapping components [5-2](#)
  - settings, terminal [3-24, 4-24](#)
  - SHDSL [1-1](#)
  - shipment
    - damage [2-19](#)
    - unpacking [2-18](#)
    - verification [2-19](#)
  - single-pair high speed digital subscriber line
    - see SHDSL or G.SHDSL
  - site requirements [2-10](#)
  - slot assignment [1-14](#)
  - software
    - back up [6-1](#)
    - specifications
      - see specifications, software
  - specifications
    - 4xflexi [A-6](#)
    - 4xSDSL [A-6](#)
    - 8xDMT [A-5](#)
    - 8xG.SHDSL [A-4](#)
    - 8xIDSL [A-3](#)
    - blower tray [A-13](#)
    - Cisco 6160 system [A-2](#)
    - DS3+T1/E1 IMA NI-2 card [A-7](#)
    - DS3/2DS3+8xT1 IMA I/O card [A-12](#)
    - DS3/2DS3 I/O card [A-12](#)
    - DS3/2DS3 NI-2 card [A-9](#)
    - management software [A-14](#)
    - OC-3c/2DS3 NI-2 card [A-10](#)
    - OC-3c/OC-3c NI-2 card [A-11](#)
    - PEM [A-13](#)
  - spectral compatibility, 8xG.SHDSL [1-27](#)
  - standard telco color chart [B-8](#)
  - stripping wire
    - alarm contacts [3-14, 4-14](#)
    - BITS clock interface [3-15, 4-15](#)
    - grounding [3-6, 3-8, 4-6, 4-8](#)

- subscriber lines 1-3
  - subtended
    - definition 1-6
    - network configuration
      - connecting, Cisco 6160 with a POTS splitter 3-16
      - connecting, Cisco 6160 without a POTS splitter 4-16
      - connecting subtending host chassis to subtended node chassis 3-16, 4-16
      - definition 1-6
      - DS3+T1/E1 IMA NI-2 cards 1-7
      - DS3/2DS3 NI-2 cards 1-9
      - features 1-7
      - OC-3c/2DS3 NI-2 cards 1-9
      - OC-3c/OC-3c NI-2 cards 1-10
      - overview 1-6
      - subtending, definition 1-6
      - types 1-7
    - node chassis
      - connect to subtending host chassis 3-16, 4-16
      - DS3+T1/E1 IMA NI-2 cards 1-8
      - DS3/2DS3 NI-2 cards 1-9
      - OC-3c/2DS3 NI-2 cards 1-9
      - OC-3c/OC-3c NI-2 cards 1-10
  - subtending
    - connections
      - DS3 3-17, 4-17
      - OC-3c 3-19, 4-19
      - T1 3-20, 4-20
      - T1 IMA 3-20, 4-20
    - definition 1-6
    - host chassis
      - connect to subtended node chassis 3-16, 4-16
      - DS3+T1/E1 IMA NI-2 cards 1-8
      - DS3/2DS3 NI-2 cards 1-9
      - OC-3c/2DS3 NI-2 cards 1-9
      - OC-3c/OC-3c NI-2 cards 1-10
  - support, modem 1-3
  - symmetrical digital subscriber line
    - see SDSL
  - system configuration dialog 3-26, 4-26
  - system-wide problems, troubleshooting 5-3
- 
- T
- T1
    - interfaces, alarms 5-18
    - network connections 3-23, 4-23
    - subtending connections 3-20, 4-20
    - subtend wire 2-17
    - trunk wire 2-17
  - T1 IMA
    - alarms 5-18
    - network connections 3-23, 4-23
    - subtending connections 3-20, 4-20
    - subtend wire 2-17
    - trunk wire 2-17
  - temperature
    - operating 2-11
    - short-term operating 2-11
  - terminal
    - block connector for external alarms 1-12
    - block connectors C-2
    - settings 3-24, 4-24
  - tip, definition xvii
  - tool requirements 2-16
  - troubleshooting
    - air filter 5-16
    - alarms 5-16
    - basic checks 5-2
    - blower tray 5-16
    - contacting the Cisco TAC 5-3
    - hot swapping 5-2
    - I/O cards 5-14
    - NI-2 card redundancy 5-13
    - NI-2 cards 5-12
    - PEM 5-15
    - system-wide problems 5-3
    - xTU-C line cards 5-8

---

## U

unpacking [2-18](#)

installing [6-4](#)

locking tab [6-3](#)

removing [6-3](#)

---

## V

VCI connections [1-3](#)

ventilation [2-11](#)

verify

LEDs, PEM [3-16, 4-16](#)

shipment [2-19](#)

VPI connections [1-3](#)

---

## W

warning

definition [xvii, 2-3](#)

translation [2-3](#)

warranty information [2-19](#)

wire

alarm contacts [2-17](#)

BITS clock interface [2-17](#)

grounding [2-17](#)

power connection [2-17](#)

T1 IMA subtend [2-17](#)

T1 IMA trunk [2-17](#)

T1 subtend [2-17](#)

T1 trunk [2-17](#)

wire-wrap pin mapping, I/O cards [C-3, C-4](#)

wire-wrap pins

DS3/2DS3+8xT1 IMA I/O card [1-46](#)

DS3/2DS3 I/O card [1-51](#)

---

## X

xDSL [1-1](#)

xDSL connector pin locations, Champ connectors [C-1](#)

xTU-C line card

