



Numerics

10/100 ports 1-8

cable lengths 2-5

cables and connectors **B-1 to B-2**

connecting to 2-16

described 1-8

groupings 1-8

illustrated 1-6

1000BaseX ports 1-10

cable lengths 2-5

connecting to 2-19 to 2-21

connectors and cables **B-2 to B-3**

illustrated 1-10

19- and 24-inch racks 2-7

A

AC power

connecting to 2-15

connector 1-25

specifications **A-1, A-2, A-3**

adapter pinouts, terminal

RJ-45-to-DB-25 **B-7**

RJ-45-to-DB-9 **B-6**

addresses, assigning IP 2-25

agency approvals **A-3**

altitude **A-1, A-2, A-3**

applications (network examples) 1-28

autonegotiation 1-8

B

bandwidth utilization 1-21, 1-22

BOOTP 2-28

brackets

See mounting brackets

C

cable guide, attaching 2-12

cable lengths 2-5

cabling

10/100 ports **B-1 to B-4**

1000BaseX ports **B-2 to B-3**

GigaStack GBIC ports **B-3**

pinouts **B-4**

See also connectors and cables

cautions xi

CGMP 1-3

chassis warning
 against stacking 2-2
 rack-mounting, servicing C-27
 circuit breaker (15A) warning C-17
 Cisco Access Analog Trunk Gateway 1-36
 Cisco Access Digital Trunk Gateway 1-36
 Cisco CallManager software 1-34, 1-36
 Cisco Cluster Management Suite 1-27
 Cisco Connection Online (CCO) xv
 Cisco Group Management Protocol (CGMP) 1-3
 Cisco IP Phones 1-9, 1-34
 connecting 2-17
 Cisco RPS 1-25
 connecting to 2-15
 LED 1-16
 Cisco SoftPhone software 1-34
 CiscoView 1-27
 Cluster Builder application 1-27
 Cluster Management Suite 1-27
 Cluster Manager application 1-27
 Cluster View application 1-27
 command-line interface (CLI) 1-27
 configuration, default values 2-29
 configuration examples, network 1-28
 connecting
 to 10/100 ports 2-16
 to 1000BaseX ports 2-19
 to console port 2-16, B-3
 to GBICs 2-19
 to GigaStack GBICs 2-21

connection procedures 2-16 to 2-23
 connectivity problems, solving 3-3
 connectors and cables
 10/100 ports B-1 to B-2
 1000BaseX ports B-2 to B-3
 console port B-3 to B-7
 GigaStack GBICs B-3
 power (AC and RPS) 1-25
 SC 2-20
 See also ports
 console port 1-26, B-3
 adapter pinouts
 RJ-45-to-DB-25 terminal B-7
 RJ-45-to-DB-9 terminal B-6
 cable B-5
 connecting to 2-22 to 2-23, B-5 to B-7
 default characteristics 2-22
 conventions, document x
 crossover cable
 connectivity problems 3-5
 pinout B-4

D

default characteristics of the console port 2-22
 default configuration 2-29 to 2-30
 designing your network, examples 1-28
 desk mounting 2-15
 diagnosing problems 3-3

diagnostics 2-30
dimensions A-2
documentation
 CD-ROM xiv
 related publications xiv
document conventions x
duplex LED 1-18, 1-19, 1-20

E

electrical noise, avoiding 2-5
electromagnetic interference (EMI) A-3
EMC regulatory statements 2-4
Enterprise Edition software, switches
 running 1-2
examples, network configuration 1-28

F

features 1-1 to 1-3
feedback to Cisco Systems, web xvii
flooding, traffic control 2-29
front panel 1-6 to 1-22
 10/100 ports 1-8
 1000BaseX ports 1-10
 clearance 2-5
 LEDs 1-12 to 1-15

G

GBICs 1-10, 1-30
 connecting to 2-19
 installing 1-10
 supported 1-10
GigaStack GBIC 1-10, 1-30
 cable lengths 2-5
 connecting to 2-21
 connector B-3
 installing 1-10
ground connection warning C-16
grounded equipment warning C-19

H

half-duplex 1-19, 1-20
HP OpenView 1-27
humidity A-1, A-2, A-3

I

IEEE 802.1p 1-3
inline power 1-9, 2-16 to 2-17
 LED 1-18, 1-20
 troubleshooting 3-6

installation
 guidelines 2-5
 rack-mount 2-7
 See also procedures
 warning C-7
 Inter-Switch Link (ISL) 1-3
 IOS command-line interface 1-27
 IP address procedures 2-24
 IP setup 2-25

J

jewelry removal warning C-8

L

LAN-to-phone jack 2-17
 LEDs
 Catalyst 3508G XL front panel 1-12
 Catalyst 3512 and 3524 XL front panel 1-13
 Catalyst 3548 XL front panel 1-15
 color meanings 1-20
 duplex 1-18, 1-20
 half-duplex 1-19, 1-20
 interpreting 1-18
 LINE PWR 1-18
 port 1-18 to 1-22
 POST results 2-15, 3-2
 RPS 1-16

speed 1-18
 STAT 1-18
 status 1-20
 system 1-15
 UTL 1-18, 1-20
 lightning activity warning C-25
 line power
 See inline power

M

management features and defaults 2-29
 Mode button 1-12, 1-18
 Mode label (on Catalyst 3548 XL only) 1-18
 models, switch 1-2
 mounting, table or desk 2-15
 mounting brackets 2-7
 attaching 2-9, 2-13
 rack-mount 2-11
 wall-mount 2-14

N

network configuration examples 1-28
 network redundancy values 2-29
 noise, electrical 2-5
 no on/off switch warning C-21

O

overtemperature warning **C-13**

P

packing list **2-6**

PC, connecting to switch **2-22**

performance

network design **1-28**

performance problems, solving **3-3**

performance tuning features **2-29**

personnel warning **C-6**

pinouts

10/100 ports **B-2**

adapters **B-5 to B-7**

cable, straight-through and crossover **B-4**

console port **B-5 to B-7**

RJ-45-to-DB-25 terminal adapter **B-7**

RJ-45-to-DB-9 PC adapter **B-6**

RJ-45-to-DB-9 terminal adapter **B-6**

rollover cable **B-5 to B-7**

port LEDs **1-18 to 1-22**

port modes

changing **1-12, 1-18**

LEDs **1-18**

See also Mode button

ports

10/100 **1-6**

1000BaseX **1-10**

See also 10/100, 1000BaseX, inline power

POST

LEDs **3-2**

results **2-15, 3-1, 3-2**

power

connecting to **2-15**

power connectors **1-23 to 1-24, 1-25**

power on **2-15**

power specifications **A-1, A-2, A-3**

power supply

AC power outlet **1-25**

RPS connector **1-25**

warning **C-22**

procedures

connection **2-16 to 2-23**

installation **2-5 to 2-15**

IP address **2-24**

product disposal warning **C-26**

PSTN **1-36**

publications, related **xiv**

Public Switched Telephone Network

See PSTN

Q

qualified personnel warning **C-6**

R

- rack installation 2-7
 - bracket mounting points 2-7
- rack-mounting 2-11
- rear panel 1-23 to 1-24
 - clearance 2-5
- Redundant Power Supply
 - See RPS
- regulatory statements, EMC 2-4
- RJ-45 connector, console port 2-23, B-3
- RJ-45 console port 1-23
- rollover cable 2-23, B-5, B-6
- RPS
 - connecting to 2-15
 - connector 1-25
 - LED 1-16
 - warning C-2, C-3

S

- safety 2-2, C-1
- SC connector 2-20, B-2 to B-3
- security values 2-30
- setup program 2-24 to 2-27
- shelf-mounting 2-15
- slots
 - See ports 1-10
- SNMP network management platforms 1-3, 1-27

- software by model 1-2
- software switch management 1-27
- specifications A-1
- stacking the chassis warning C-10
- standard edition software, switches running 1-2
- startup
 - powering on 2-15
- straight-through cable pinouts B-4
- SunNet Manager 1-27
- supply circuit warning C-20
- switch
 - applications 1-28
 - startup
 - powering on 2-15
- system LED 1-15

T

- table-mounting 2-15
- technical specifications A-1
- Telnet, and accessing the CLI 1-27
- temperature
 - operating A-1
 - warning C-13
- terminal, connecting to switch 2-22
- terminal emulation software 2-22
- TN power warning C-15
- translated warnings C-1
- troubleshooting 3-1 to 3-5

U

URLs, Cisco [xiv](#)

UTL LED [1-18, 1-19](#)

V

Visual Switch Manager (VSM) [1-27](#)

VSM [1-27](#)

W

wall-mounting [2-13 to 2-14](#)

warnings

 defined [xi](#)

 installation [2-2](#)

 translated [C-1](#)

