



---

## Numerics

### 10/100/1000 ports

- cable lengths [2-7, 3-10](#)
- connecting to [2-38 to 2-40, 3-42 to 3-44](#)
- connectors and cables [B-3](#)
- described [1-6 to 1-7](#)

### 10/100 ports

- cable lengths [2-7, 3-10](#)
- connecting to [2-38 to 2-40, 3-42 to 3-44](#)
- connectors and cables [B-1 to B-2](#)
- described [1-6](#)

### 100BASE-FX ports

- cable lengths [2-7, 3-10](#)
- connecting to [2-41 to 2-42, 3-45 to 3-47](#)
- connectors and cables [B-4](#)
- described [1-7](#)
- power levels, fiber-optic [A-2](#)

### 100BASE-LX ports

- cable lengths [2-7, 3-10](#)
- connecting to [2-43 to 2-44, 3-47 to 3-49](#)
- connectors and cables [B-5](#)
- described [1-8](#)
- power levels, fiber-optic [A-3](#)

---

## A

### AC power

- connecting to [2-19 to 2-21](#)

### adapter pinouts, terminal

- RJ-45-to-DB-25 [B-12](#)
- RJ-45-to-DB-9 [B-11](#)

### addresses, assigning IP [2-45, 3-50](#)

### airflow

- required clearance [2-8, 3-10](#)

### alarm relay connections

- power and relay connector [1-8](#)

### alarms and relays

- LEDs [1-16](#)

### altitude [A-1](#)

### autonegotiation

- 10/100/1000 ports [1-7](#)
- 10/100 ports [1-6](#)

---

## C

### cables

- 10/100/1000 ports [1-6 to 1-7](#)
- 10/100 ports [1-6](#)
- 100BASE-FX ports [1-7](#)

- 100BASE-LX ports [1-8](#)
- crossover
  - connecting to [B-2, B-3](#)
  - four twisted-pair pinout, 10/100 ports [B-9](#)
  - four twisted-pair pinout, 1000BASE-T ports [B-10](#)
  - two twisted-pair pinout [B-8](#)
- LC [B-6](#)
- LC patch cables [B-6](#)
- multimode
  - 100BASE-FX ports [1-7](#)
- problems, solving [4-3](#)
- rollover [B-12](#)
- single-mode
  - 100BASE-LX ports [1-8](#)
- straight-through
  - connecting to [B-2, B-3](#)
  - four twisted-pair pinout, 10/100 ports [B-8](#)
  - four twisted-pair pinout, 1000BASE-T ports [B-9](#)
  - two twisted-pair pinout [B-7](#)
- twisted-pair
  - 10/100/1000 ports [1-6 to 1-7](#)
  - 10/100 ports [1-6](#)
- See also connectors and cables
- Catalyst 2955C-12 switch
  - illustrated [1-4](#)
  - LEDs
    - illustrated [1-12](#)
- Catalyst 2955S-12 switch
  - illustrated [1-4](#)
  - LEDs
    - illustrated [1-12](#)
- Catalyst 2955 switch
  - warning labels [1-5](#)
- Catalyst 2955T-12 switch
  - illustrated [1-3](#)
  - LEDs
    - illustrated [1-11](#)
- cautions, defined [xvi](#)
- chassis warnings
  - against stacking [2-3, 3-5](#)
  - rack-mounting, servicing [2-32, 3-36](#)
  - servicing [C-4](#)
- Cisco IE2100 [1-18](#)
- Cisco IE2100 Series Configuration Registrar
  - See Cisco IE2100
- Cisco Intelligent Engine 2100
  - See Cisco IE2100
- CiscoView [1-18](#)
- Class 1 laser product warning [2-4, 3-6, B-5](#)
- class 1 laser product warning [C-14](#)
- Class 1 LED product warning [2-4, 2-41, 3-6, 3-45, B-4](#)
- class 1 LED product warning [C-16](#)
- clearance [2-7, 3-10](#)
- CLI [1-18](#)
- Cluster Builder application [1-17](#)
- Cluster Management Suite
  - See CMS

- Cluster Manager application [1-17](#)
  - Cluster View application [1-17](#)
  - CMS
    - Cluster Builder [1-17](#)
    - Cluster Management [1-17](#)
    - Cluster View [1-17](#)
    - described [1-17](#)
    - Device Manager [1-18](#)
  - command-line interface
    - See CLI
  - configuration examples, network [1-1](#)
  - configuring ports [2-45, 3-50](#)
  - connecting
    - to 10/100/1000 ports [2-38 to 2-40, 3-42 to 3-44](#)
    - to 10/100 ports [2-38 to 2-40, 3-42 to 3-44](#)
    - to 100BASE-FX ports [2-41 to 2-42, 3-45 to 3-47](#)
    - to 100BASE-LX ports [2-43 to 2-44, 3-47 to 3-49](#)
    - to console port [2-9 to 2-10, 3-12 to 3-13](#)
    - to DC power [2-14 to 2-23, 3-18 to 3-26](#)
    - to PC [2-9 to 2-10, 3-12 to 3-13](#)
    - to terminal [2-9 to 2-10, 3-12 to 3-13](#)
    - to the AC/DC converter [2-19 to 2-21](#)
  - connecting to
    - external alarm devices [2-25 to 2-28, 3-28 to 3-31](#)
  - connectivity problems, solving [4-4](#)
  - connectors and cables
    - 10/100/1000 ports [B-3](#)
    - 10/100 ports [B-1 to B-2](#)
    - 100BASE-FX ports [B-4](#)
    - 100BASE-LX ports [B-5](#)
    - console port [B-7](#)
    - See also cables
  - console port
    - adapter pinouts
      - RJ-45-to-DB-25 terminal [B-12](#)
    - cable, rollover [B-12](#)
    - connecting to [2-9 to 2-10, 3-12 to 3-13, B-10 to B-12](#)
    - default characteristics [2-10, 3-13](#)
    - described [1-9](#)
    - RJ-45-to-DB-9 adapter cable pinouts [B-11](#)
  - conventions, document [xvi to xviii](#)
  - crossover cable
    - connecting to
      - 10/100/1000 ports [2-39, 3-43](#)
      - 10/100 ports [2-39, 3-43](#)
    - connectivity problems [4-4](#)
    - pinout
      - four twisted-pair, 10/100 ports [B-9](#)
      - four twisted-pair, 1000BASE-T ports [B-10](#)
      - two twisted-pair [B-8](#)
- 
- D
  - DC power
    - connecting to [2-14 to 2-23, 3-18 to 3-26](#)
    - warnings [2-14, 3-18](#)
  - DC power disconnection warning [2-14](#)

default characteristics of the console port [2-10](#),  
[3-13](#)

Device Manager [1-18](#)

dimensions [A-2](#)

documentation

ordering [xx](#)

related publications [xix](#)

URLs, Cisco [xx](#)

document conventions [xvi to xviii](#)

---

## E

electrical noise, avoiding [2-8](#), [3-11](#)

electromagnetic interface (EMI) [A-3](#)

EMC

agency approvals [A-3](#)

regulatory statements [2-5 to 2-7](#), [3-7 to 3-9](#)

ensure that the switch is grounded warning [2-3](#),  
[3-6](#)

environmental ranges [A-1](#)

ESD

requirements [2-38](#), [3-42](#)

European Zone 2 certification

regulatory statements [3-9](#)

examples, network configuration [1-1](#)

exposed DC power wire warning [2-16](#), [2-20](#), [3-20](#)

---

## F

features [1-1 to 1-2](#)

feedback to Cisco Systems, web [xx](#)

ferrite

attaching [2-21](#), [3-24](#)

fiber-port specifications [A-2](#), [A-3](#)

front panel

10/100/1000 ports [1-6 to 1-7](#)

10/100 ports [1-6](#)

100BASE-FX ports [1-7](#)

100BASE-LX ports [1-8](#)

clearance [2-7](#), [3-10](#)

console port [1-9](#)

described [1-3](#)

illustrated [1-3 to 1-4](#)

LEDs [1-10 to 1-16](#)

power and relay connector [1-8](#)

functional ground lug warning [2-3](#), [2-12](#), [3-6](#), [3-15](#)

---

## G

ground connection warning [2-3](#), [2-12](#), [3-6](#), [3-15](#)

grounded equipment warning [C-29](#)

grounding procedures [2-12 to 2-14](#), [3-15 to 3-18](#)

---

## H

hazardous location warnings

connecting and disconnecting cables [3-5](#)

console cable [1-10](#), [3-5](#), [3-12](#), [3-14](#), [3-26](#)

disconnecting equipment [3-2](#)

power and relay connector [1-8, 3-3](#)  
 relay wires [1-16, 3-3, 3-28](#)  
 safe operating voltage range [3-3](#)  
 suitable enclosure [3-4](#)

hot surface warning label  
 illustrated [1-5](#)

HP OpenView [1-18](#)

humidity [A-1](#)

---

industrial environment warning [2-2, 3-3](#)

installation  
 attaching the ferrite [2-21, 3-24](#)  
 attach the power and relay connector [2-22, 3-25](#)  
 grounding procedures [2-12 to 2-14, 3-15 to 3-18](#)  
 guidelines [2-7, 3-10](#)  
 mounting on a DIN rail [2-29 to 2-31, 3-32 to 3-35](#)  
 package contents [2-8 to 2-9, 3-11 to 3-12](#)  
 POST [2-23 to 2-25, 3-26 to 3-28](#)  
 power on [2-23, 3-26](#)  
 pre-installation information and guidelines [2-2 to 2-7, 3-2 to 3-10](#)  
 rack-mount [2-32 to 2-33, 3-36 to 3-37](#)  
 required clearance [2-8, 3-10](#)  
 verifying switch operation [2-9 to 2-25, 3-12 to 3-28](#)  
 warning [C-2](#)

wiring the relays [2-25 to 2-28, 3-28 to 3-31](#)

invisible laser radiation warning [2-4, 3-7, B-5](#)

IOS command-line interface  
 See CLI

IP address procedures [2-45, 3-50](#)

---

## J

jewelry removal warning [2-4, 3-6, C-11](#)

---

## L

laser beam exposure warning [2-5, 3-7](#)

laser radiation warning [2-4, 3-7, C-20](#)

laser safety warning label  
 illustrated [1-5](#)

laser viewing warning [2-4, 3-7, C-18](#)

LC  
 patch cables [B-6](#)

LED radiation warning [2-4, 2-41, 3-7, 3-45, B-4](#)

LEDs  
 alarm and relay [1-16](#)  
 alarms and relay status [1-16](#)  
 front panel [1-10 to 1-16](#)  
 port [1-13](#)  
 port status [1-13](#)  
 power status [1-12](#)  
 uplink ports [1-14 to 1-15](#)  
 uplink port status [1-14 to 1-15](#)

lightning activity warning [2-4](#), [3-6](#), [C-1](#)

---

## M

main disconnecting device warning [2-3](#), [C-7](#)

management options [1-17 to 1-18](#)

mounting

DIN rail [2-29 to 2-31](#), [3-32 to 3-35](#)

rack [2-32 to 2-33](#), [3-36 to 3-37](#)

MT-RJ

connector [B-4](#)

---

## N

network configuration examples [1-1](#)

noise, electrical [2-8](#), [3-11](#)

notes, defined [xvi](#)

---

## O

obtaining documentation [xx](#)

overtemperature warning [2-3](#), [3-5](#), [C-27](#)

---

## P

package contents [2-8 to 2-9](#), [3-11 to 3-12](#)

patch cables, LC [2-9](#), [3-12](#)

patch cables, MT-RJ [2-9](#), [2-41](#), [2-43](#), [3-11](#), [3-45](#), [3-47](#)

PC, connecting to switch [2-9 to 2-10](#), [3-12 to 3-13](#), [B-10 to B-11](#)

performance problems, solving [4-3](#)

physical dimensions [A-2](#)

pinouts

10/100/1000 ports [B-4](#)

10/100 ports [B-2](#)

adapters

DB-25 [B-12](#)

console port

DB-25 adapter [B-12](#)

RJ-45-to-DB-9 adapter cable [B-11](#)

crossover cables

four twisted-pair, 10/100 ports [B-9](#)

four twisted-pair, 1000BASE-T ports [B-10](#)

two twisted-pair [B-8](#)

RJ-45-to-DB-25 terminal adapter [B-12](#)

RJ-45-to-DB-9 adapter cable [B-11](#)

RJ-45-to-DB-9 PC adapter cable [B-11](#)

straight-through cables

four twisted-pair, 10/100 ports [B-8](#)

four twisted-pair, 1000BASE-T ports [B-9](#)

two twisted-pair [B-7](#)

port

10/100/1000BASE-T

LEDs [1-14](#)

100BASE-FX

LEDs [1-15](#)

100BASE-LX

LEDs [1-15](#)

- LEDs [1-13 to 1-15](#)
  - ports
    - See [10/100 ports](#), [10/100/1000 ports](#), [100BASE-FX ports](#), [100BASE-LX ports](#), and [console ports](#)
  - POST
    - description [2-23, 3-26](#)
    - problems, solving [4-4](#)
    - results [2-23, 3-26](#)
  - power
    - connecting to
      - AC [2-19 to 2-21](#)
      - DC [2-14 to 2-23, 3-18 to 3-26](#)
      - power and relay connector [1-8](#)
    - LEDs [1-12](#)
    - requirements [A-1](#)
  - power and relay connector
    - connecting to the switch [2-22, 3-25](#)
    - described [1-8](#)
    - illustrated [1-9](#)
  - power connection
    - power and relay connector [1-8](#)
  - power on [2-11, 3-14](#)
  - power on the switch [2-23, 3-26](#)
  - procedures
    - connecting to AC power [2-19 to 2-21](#)
    - connecting to DC power [2-14 to 2-23, 3-18 to 3-26](#)
    - installation [2-32 to 2-33, 3-36 to 3-37](#)
    - IP address [2-45, 3-50](#)
    - power on [2-11 to 2-18, 3-14 to 3-23](#)
    - product disposal warning [2-4, 3-6, C-30](#)
    - publications, related [xix](#)
- 
- Q
- qualified personnel warning [C-32](#)
- 
- R
- rack-mounting
    - procedures [2-32 to 2-33, 3-36 to 3-37](#)
    - warning [2-32, 3-36](#)
  - rear panel
    - clearance [2-7, 3-10](#)
  - regulatory statements, EMC [2-5 to 2-7, 3-7 to 3-9](#)
  - regulatory statements, European Zone 2
    - certification [3-9](#)
  - related publications [xix](#)
  - relays
    - connecting to
      - power and relay connector [1-8](#)
    - described [1-8](#)
    - wiring [2-25 to 2-28, 3-28 to 3-31](#)
  - removing the switch from a DIN rail or a rack [2-35 to 2-37, 3-39 to 3-41](#)
  - restricted area warning [C-33](#)
  - rollover cable [B-12](#)

---

**S**

safety agency approvals [A-3](#)  
 safety warnings [2-2 to 2-5, 3-2 to 3-7, C-1 to C-39](#)  
 SELV-IEC 60950 DC power supply  
   warning [C-9](#)  
 service personnel warning [2-2, 3-2](#)  
 SNMP network management platforms [1-18](#)  
 software switch management [1-17 to 1-18](#)  
 specifications [A-1 to A-4](#)  
 stacking the chassis warning [2-3, 3-5, C-5 to C-6](#)  
 straight-through cable  
   connecting to  
     10/100/1000 ports [2-39, 3-43](#)  
     10/100 ports [2-39, 3-43](#)  
   connectivity problems [4-4](#)  
   pinout  
     four twisted-pair, 10/100 ports [B-8](#)  
     four twisted-pair, 1000BASE-T ports [B-9](#)  
     two twisted-pair [B-7](#)  
 SunNet Manager [1-18](#)  
 supply wires warning [2-3, 2-12, 3-4, 3-15](#)  
 switch, power-on [2-11 to 2-23, 3-14 to 3-26](#)

---

**T**

technical assistance [xxii to xxiii](#)  
 technical specifications [A-1 to A-4](#)  
 Telnet, and accessing the CLI [1-18](#)  
 temperature

operating [A-1](#)  
 warning [2-3, 3-5, C-27](#)  
 terminal, connecting to a switch [2-9 to 2-10, 3-12 to 3-13, B-11 to B-12](#)  
 terminal-emulation software [2-9, 3-12](#)  
 translated warnings [C-1 to C-39](#)  
 troubleshooting [4-1](#)  
   diagnosing problems [4-2 to 4-4](#)  
   understanding POST results [4-2](#)

---

**U**

uplink ports  
   LEDs [1-14 to 1-15](#)  
 URLs, Cisco [xx](#)

---

**V**

verifying package contents [2-8 to 2-9, 3-11 to 3-12](#)  
 verifying switch operation [2-9 to 2-25, 3-12 to 3-28](#)

---

**W**

warning labels  
   hot surface [1-5](#)  
   illustrated [1-5](#)  
   laser safety [1-5](#)  
 warnings  
   Class 1 laser product [2-4, 3-6, B-5](#)



- class 1 laser product [C-14](#)
- Class 1 LED product [2-4, 2-41, 3-6, 3-45, B-4](#)
- class 1 LED product [C-16](#)
- DC power [2-14, 3-18](#)
- defined [xvii to xviii](#)
- ensure that the switch is grounded [2-3, 3-6](#)
- functional ground lug [2-3, 2-12, 3-6, 3-15](#)
- ground connection [2-3, 3-6](#)
- grounded equipment [C-29](#)
- hazardous locations
  - connecting and disconnecting cables [3-5](#)
  - console cable [1-10, 3-5, 3-12, 3-14, 3-26](#)
  - disconnecting equipment [3-2](#)
  - power and relay connector [1-8, 3-3](#)
  - relay wires [1-16, 3-3, 3-28](#)
  - safe operating voltage range [3-3](#)
  - suitable enclosure [3-4](#)
- industrial environment [2-2, 3-3](#)
- installation [2-2 to 2-5, 3-2 to 3-7, C-2](#)
- invisible laser radiation [2-4, 3-7, B-5](#)
- jewelry removal [2-4, 3-6, C-11](#)
- laser beam exposure [2-5, 3-7](#)
- laser radiation [2-4, 3-7, C-20](#)
- laser viewing [2-4, 3-7, C-18](#)
- LED radiation [2-4, 2-41, 3-7, 3-45, B-4](#)
- lightning activity [2-4, 3-6, C-1](#)
- main disconnecting device [2-3, C-7](#)
- overtemperature [2-3, 3-5, C-27](#)
- product disposal [2-4, 3-6, C-30](#)
- qualified personnel [C-32](#)
- restricted area [C-33](#)
- SELV-IEC 60950 DC power supply [C-9](#)
- service personnel [2-2, 3-2](#)
- servicing [C-4](#)
- stacking the chassis [2-3, 3-5, C-5 to C-6](#)
- supply wires [2-3, 2-12, 3-4, 3-15](#)
- temperature [2-3](#)
- translated [C-1 to C-39](#)
- wiring the relays [2-25 to 2-28, 3-28 to 3-31](#)

