



TL1 Commands

This chapter describes the TL1 commands used in the Cisco ONS 15540 ESP environment.

Each TL1 command must be less than or equal to 255 characters. Any command larger than 255 characters must be split into multiple commands

**Note**

TL1 commands that are entered incorrectly are not completed.

3.1 ACT-USER: Activate User

Use this command to log into the NE (network element).

Section	ACT-USER Description
Category	Security
Security	Retrieve
Related Messages	3.4 CANC-USER: Cancel User 3.14 DLT-USER-SECU: Delete User Security 3.24 ED-USER-SECU: Edit User Security 3.32 ENT-USER-SECU: Enter User Security 3.73 RTRV-USER-SECU: Retrieve User Security
Input Format	ACT-USER:<tid>:<uid>:<ctag>:<pid>; Where: <ul style="list-style-type: none">• <ctag> is the correlation tag.• <uid> is the user identifier. It is a text string with a maximum length of 16 characters.• <pid> is the user login password. It is a text string with a minimum length of six characters.• <tid> is the target identifier.
Input Example	To log into the NE, use the following: ACT-USER:ons155xx:admin:123::mypswd;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.2 ALW-MSG-ALL: Allow Message All

Use the command to transmit all REPT-ALM, REPT-EVT, and REPT-SW autonomous messages.

Section	ALW-MSG-ALL Description
Category	Alarms and faults
Security	Retrieve
Related Messages	3.34 INH-MSG-ALL: Inhibit Message All
Input Format	ALW-MSG-ALL:[<tid>]::<ctag>; <ul style="list-style-type: none"> • <ctag> is the correlation tag. • <tid> is the target identifier.
Input Example	To transmit all REPT ALM, REPT EVT, and REPT SW autonomous messages, use the following: ALW-MSG-ALL:ons155xx::123;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.3 ALW-Swdx-Eqpt: Allow Switch Duplex Equipment

Use this command to switch between active and standby processor cards.

Section	ALW-Swdx-Eqpt Description
Category	Redundancy configuration
Security	Maintenance
Related Messages	3.35 INH-Swdx-Eqpt: Inhibit Switch Duplex Equipment 3.80 SW-DX-EQPT: Switch Duplex Equipment
Input Format	ALW-Swdx-Eqpt:[<tid>]:<aid>:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. Valid values are SLOT-6 or SLOT-7. • <ctag> is the correlation tag.
Input Example	To switch between active and standby processor cards, use the following: ALW-Swdx-Eqpt:ons155xx:SLOT-6:123;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.4 CANC-USER: Cancel User

Use this command to log out of the NE.

Section	CANC-USER Description
Category	Security
Security	Retrieve
Related Messages	3.1 ACT-USER: Activate User 3.14 DLT-USER-SECU: Delete User Security 3.24 ED-USER-SECU: Edit User Security 3.32 ENT-USER-SECU: Enter User Security 3.73 RTRV-USER-SECU: Retrieve User Security
Input Format	CANC-USER:[<tid>]:<uid>:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <uid> is the user identifier. • <ctag> is the correlation tag.
Input Example	To log out of the NE, use the following: CANC-USER:ons155xx:admin:123;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.5 CPY-MEM: Copy Memory

Use this command to copy the contents from one memory location to another.

The AID of the memory device is specified in the <fromdev> and <todev> fields. Optionally, these fields can be set to NULL and the necessary information can be specified as part of the user defined text string in <frommem> and <tomem>.

Section	CPY-MEM Description
Category	Memory management
Security	Maintenance
Related Messages	3.33 FORMAT-MEM: Format Memory 3.43 RST-MEM: Restore Memory 3.57 RTRV-MEM: Retrieve Memory

Section	CPY-MEM Description
Input Format	<p>CPY-MEM:[<tid>]::<ctag>:<frommem>,[<fromdev>],<tomem>,[<todev>]; [CMDMODE=<mode>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <frommem> specifies the name of the source file to copy. • <tomem> specifies the name of the target file to which to copy the contents of the file specified in <frommem>. • <fromdev> indicates the name of the source device from which a file is copied. • <todev> indicates the name of the target device to which a file is copied. • <mode> indicates the mode of operation. Valid values are FRCD or NORMAL. In FRCD mode of operation, any existing file is overwritten. In NORMAL mode of operation, if a file is already present by the name specified in <tomem>, the copy request is denied. The default mode is NORMAL. <p> Note If this command is used to copy a file to a TFTP location, then the CMDMODE parameter is ignored and any existing file is overwritten.</p>
Input Example	<p>To copy the configuration from running-config to startup-config, use the following:</p> <pre>CPY-MEM:ons155xx::123::“running-config”,“startup-config”;</pre> <p> Note The double quotes are optional in the previous example.</p> <p>To copy the configuration from a TFTP location, use the following:</p> <pre>CPY-MEM:ons155xx::123::“tftp://172.20.46.50/admin/ons15540-i-mz”, “bootflash:ons15540-i-mz”;</pre> <p>To copy an image over from the bootflash memory to the Flash PC card in slot 0, use the following:</p> <pre>CPY-MEM:ons155xx::123::“bootflash:ons15540-i-mz”, “disk0:ons15540-i-mz”;</pre> <p>To use the <fromdev> and <todev> parameters to specify the Flash PC devices involved, use the following:</p> <pre>CPY-MEM:ons155xx::123::“ons15540-i-mz”,BOOTFLASH,“ons15540-i-mz”, DISK-0;</pre>
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.6 DLT-FFP-OCH: Delete Facility Protection OCH

Use this command to delete a facility protection group.

This command behaves as if executed in forced mode. Upon deletion of a protection group, the system switches service to the working line, irrespective of the state of the working line.

Section	DLT-FFP-OCH Description
Category	APS
Security	Retrieve
Related Messages	3.16 ED-FFP-OCH: Edit Facility Protection 3.51 RTRV-FFP-OCH: Retrieve Facility Protection OCH
Input Format	DLT-FFP-OCH:[<tid>]:<wkg_aid>,<prot_aid>:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <wkg_aid> is the working port AID. Valid values are WAVEPATCH-slot-subcard-port or TRANSPARENT-slot-subcard-0. • <prot_aid> is the protection port AID. Valid values are WAVEPATCH-slot-subcard-port or TRANSPARENT-slot-subcard-0. • <ctag> is the correlation tag.
Input Example	To delete a facility protection group, use the following: DLT-FFP-OCH:ons155xx:WAVEPATCH-2-0-0,WAVEPATCH-2-0-1:125;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.7 DLT-IP: Delete IP

Use this command to delete IP related configurations on the network management Ethernet port or the OSC interface.

Section	DLT-IP Description
Category	IP configuration
Security	Retrieve
Related Messages	3.8 DLT-IPROUTE-STATIC: Delete IP Route Static 3.17 ED-IP: Edit IP 3.26 ENT-IP: Enter IP 3.54 RTRV-IP: Retrieve IP 3.55 RTRV-IPROUTE: Retrieve IP Route 3.79 SQUEEZE-MEM: Squeeze Memory
Input Format	DLT-IP:[<tid>]:<aid>:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is FE-0, FE-SBY-0, WAVE-slot, ETHERDCC-slot-subcard-0, or LOOPBACK-[0-255]. • <ctag> is the correlation tag.

Section	DLT-IP Description (continued)
Input Example	To delete IP-related configurations on the active NME port, use the following: DLT-IP:ons155xx:FE-0:123;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.8 DLT-IPROUTE-STATIC: Delete IP Route Static

Use this command to delete IP static routes.

Section	DLT-IPROUTE-STATIC Description
Category	IP configuration
Security	Provisioning
Related Messages	3.7 DLT-IP: Delete IP 3.17 ED-IP: Edit IP 3.26 ENT-IP: Enter IP 3.54 RTRV-IP: Retrieve IP 3.55 RTRV-IPROUTE: Retrieve IP Route 3.79 SQUEEZE-MEM: Squeeze Memory
Input Format	DLT-IPROUTE-STATIC:[<tid>]::<ctag>:::PREFIXADDR=<addr>, PREFIXMASK=<mask>, [ROUTEIF=<interface>],[ROUTEADDR=<routeaddr>]; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <addr> is the IP address. • <mask> is the IP subnet mask. • <interface> is the static route interface AID. • <routeaddr> is the static route IP address.
Input Example	To delete IP static routes, use the following: DLT-IPROUTE-STATIC:ons155xx::123:::PREFIXADDR=10.1.0.0, PREFIXMASK=255.255.0.0, ROUTEIF=WAVE-1;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.9 DLT-MEM: Delete Memory

Use this command to delete a file from memory specified by the AID.

The file is simply marked as deleted but not erased from memory.

Section	DLT-MEM Description
Category	Memory Management
Security	Provisioning
Related Messages	3.5 CPY-MEM: Copy Memory 3.43 RST-MEM: Restore Memory 3.57 RTRV-MEM: Retrieve Memory
Input Format	DLT-MEM:[<tid>]:<aid>:<ctag>:::FILENAME=<filename>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the memory device from which the file is being deleted. Valid values are BOOTFLASH, DISK-[0-1], PCMCIA-[0-1], SBY-BOOTFLASH, SBY-DISK-[0-1], or SBY-PCMCIA-[0-1]. • <ctag> is the correlation tag. • <filename> is the filename.
Input Example	To delete a file from memory specified by the AID, use the following: DLT-MEM:ons155xx:DISK-0:123::“ons15540-i-mz”;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.10 DLT-NBR: Delete Neighbor

Use this command to delete neighbor entries for a port or to disable learning through CDP on a port.

If LINKDIRN is specified, then only the neighbor entry for that particular direction is deleted. Otherwise, all neighbor entries on the port are deleted.



Note

When neighbors are discovered through CDP, LINKDIRN is always both and the value specified in LINKDIRN is ignored.

Section	DLT-NBR Description
Category	Topology neighbor configuration
Security	Maintenance
Related Messages	3.28 ENT-NBR: Enter Neighbor 3.58 RTRV-NBR: Retrieve Neighbor

Section	DLT-NBR Description (continued)
Input Format	<p>DLT-NBR:[<tid>]:<aid>:<ctag>:::[LINKDIRN=<linkdirn>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <aid> identifies the interface and can be one of the following: <ul style="list-style-type: none"> – TRANSPARENT-slot-subcard-0 – WDM-slot-subcard • <linkdirn> is the link direction. Both transmit and receive links of this port are connected to the neighbor specified by the rest of the command. <ul style="list-style-type: none"> – BOTH - The neighbor is on both the transmit and receive link of this port. BOTH is the default. – TX - The neighbor is on the transmit link of this port. – RX - The neighbor is on the receive link of this port. <p>For direct links between nodes, LINKDIRN is set to BOTH because there is only one neighbor connected to the port. For configurations with an EDFA connected in one direction, use TX or RX, as appropriate, for the EDFA or neighboring node connected to the port.</p>
Input Example	To delete a physical neighbor in the transmit direction, use the following: DLT-NBR:ons155xx:WDM-0-0:125::LINKDIRN=TX;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.11 DLT-NTPASSOC: Delete NTP Associations

Use this command to delete an existing NTP association.

Section	DLT-NTPASSOC Description
Category	NTP
Security	Provisioning
Related Messages	3.29 ENT-NTPASSOC: Enter NTP Associations 3.62 RTRV-NTP: Retrieve NTP 3.63 RTRV-NTPASSOC: Retrieve NTP Associations
Input Format	<p>DLT-NTPASSOC:[<tid>]:<ctag>:::ASSOCTYPE=<assoctype>, ASSOCIPADDR=<associpaddr>;</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <assoctype> is the association type. Valid values are PEER or SERVER. • <associpaddr> is the association IP address.
Input Example	To delete an existing NTP association, use the following: DLT-NTPASSOC:ons155xx::123:::ASSOCTYPE=SERVER, ASSOCIPADDR=172.16.246.1;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.12 DLT-PATCH: Delete Patch

Use this command to delete a patch configuration.

The CTYPE value for an existing patch cannot be edited. You must delete the patch and create a new patch with the new CTYPE value.

Section	DLT-PATCH Description
Category	Patch configuration
Security	Provisioning
Related Messages	3.30 ENT-PATCH: Enter Patch 3.65 RTRV-PATCH: Retrieve Patch
Input Example	<p>DLT-PATCH:<tid>:<from_aid>,<to_aid>:<ctag>;</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <from_aid> identifies the port patched from, to the port identified by <to_aid>. Valid values for <from_aid> are as follows: <ul style="list-style-type: none"> – FILTER-slot-subcard-0 – OSCFILTER-slot-subcard – THRU-slot-subcard – WAVE-slot – WAVEPATCH-slot-subcard-port – WDM-slot-subcard • <to_aid> identifies the port patched to, from the port identified by <from_aid>. Valid values for <to_aid> are as follows: <ul style="list-style-type: none"> – FILTER-slot-subcard-0 – OSCFILTER-slot-subcard – THRU-slot-subcard – WAVE-slot – WAVEPATCH-slot-subcard-port – WDM-slot-subcard • <ctag> is the correlation tag.
Input Example	To delete a patch configuration, use the following: DLT-PATCH:ons155xx:WDM-0-0,THRU-0-0:123;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.13 DLT-THR-OCH: Delete Threshold OCH

Use this command to delete either a complete alarm threshold list or particular thresholds within a list.

When deleting particular thresholds from a list, both the ERRTYPE and THRTYPE parameters must be specified.

Section	DLT-THR-OCH Description
Category	Threshold list configuration
Security	Provisioning Maintenance
Related Messages	3.31 ENT-THR-OCH: Enter Thresholds OCH 3.70 RTRV-THR-OCH: Retrieve Thresholds OCH 3.71 RTRV-TH-rr: Retrieve Threshold 3.78 SET-TH-OCH: Set Optical Threshold
Input Format	<p>DLT-THR-OCH:<tid>:<thrlistname>:<ctag>:::[ERRTYPE=<errtype>, THRTYPE=<thrtype>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <thrlistname> specifies the threshold list. • <ctag> is the correlation tag. • <errtype> indicates the type of error counter to which the threshold applies. Valid values are as follows: <ul style="list-style-type: none"> – CVS - SONET/SDH section CV errors – CVRD - 8B/10B code violations and running disparity errors – CDLHEC - CDL HEC errors – CRC - Cyclic redundancy check errors • <thrtype> indicates the threshold type. Valid values are as follows: <ul style="list-style-type: none"> – DEGR - Indicates that a signal degrade condition has been reached. Use this threshold type only when <errtype> is CVS. – FAIL - Indicates that a signal failure condition has been reached. Use this threshold type only when <errtype> is CVS. – EVTTHR - Indicates that a non-service affecting condition has been reached. Use this threshold type when <errtype> is not CVS. – ALMTHR - Indicates that a service affecting condition has been reached. Use this threshold type when <errtype> is not CVS.
Input Example	To delete the threshold list or particular thresholds, use the following: DLT-THR-OCH:ons155xx:sonet-cvs:123;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.14 DLT-USER-SECU: Delete User Security

Use this command to delete an existing user account.

Section	DLT-USER-SECU Description
Category	Security
Security	Retrieve
Related Messages	3.1 ACT-USER: Activate User 3.4 CANC-USER: Cancel User 3.24 ED-USER-SECU: Edit User Security 3.32 ENT-USER-SECU: Enter User Security 3.73 RTRV-USER-SECU: Retrieve User Security
Input Format	DLT-USER-SECU:[<tid>]:<uid>:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <uid> is the user identifier. • <ctag> is the correlation tag.
Input Example	To delete an existing user account, use the following: DLT-USER-SECU:ons155xx:admin:123;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.15 ED-DAT: Edit Date

Use this command to edit the date and time on the NE.

Section	ED-DAT Description
Category	Generic NE configuration
Security	Provisioning
Related Messages	3.53 RTRV-HDR: Retrieve Header 3.72 RTRV-TOD: Retrieve Time of Day
Input Format	ED-DAT:[<tid>]::<ctag>::[<date>],[<time>]; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <date> is the current date. The format is YY-MM-DD. • <time> is the current time. The format is HH-MM-SS.
Input Example	To edit the date and time on the NE, use the following: ED-DAT:ons155xx::123::03-02-11;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.16 ED-FFP-OCH: Edit Facility Protection

Use this command to edit the attributes associated with an already created optical 1+1 protection channel and to put the protection group in-service or out-of-service. When the protection group is put out-of-service, then the currently active path continues to remain as the active path.

Section	ED-FFP-OCH Description
Category	APS
Security	Retrieve
Related Messages	3.6 DLT-FFP-OCH: Delete Facility Protection OCH 3.51 RTRV-FFP-OCH: Retrieve Facility Protection OCH
Input Format	<p>ED-FFP-OCH:[<tid>]:<wkg_aid>,<prot_aid>:<ctag>:::[PROTID=<protid>], [PSDIRN=<psdirn>], [RVRTV=<rvrvtv>],[RVRTM=<rvrtm>], [YCABLE=<ycable>],[ENSWOTM=<enswotm>], [MSGCH=<msgch>], [MSGHOLDTM=<msgholdtm>], [MSGHOLDCOUNT=<msgholdcount>], [MSGMAXINTVTM=<msgmaxintvtm>], [FENDPROTID=<fendprotid>], [FENDIPADDR=<fendipaddr>]: [<pst>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <wkg_aid> is the working port AID. Valid values are WAVEPATCH-slot-subcard-port or TRANSPARENT-slot-subcard-0. • <prot_aid> is the protection port AID. Valid values are WAVEPATCH-slot-subcard-port or TRANSPARENT-slot-subcard-0. • <ctag> is the correlation tag. • <protid> is the protection group identifier. It is a case-sensitive string and can have a maximum of 32 characters. If <protid> is not specified, a protection group name is created with the name of the <wkg_aid>. • <psdirn> is the protection switch direction. Switching mode. Valid values are UNI (unidirectional) and BI (bidirectional). The default is UNI. • <rvrvtv> specifies the revertive mode. This feature applies only to y-cable protection. Valid values are Y or N. The default is N. • <rvrtm> is the revertive timer, which applies only if the revertive mode is enabled. The revertive timer specifies the interval to wait before performing a r revertive switch. The range is 0 to 720 seconds. The default is 300 seconds. • <ycable> specifies the y-cable mode. This parameter indicates whether the type of protection is y-cable or not. Valid values are Y or N. The default is N. • <enswotm> is the switchover enable timer. This timer is used to delay reenabling of auto-failover to prevent rapid switching between the standby and active links. The range of values is 1 to 120 seconds. The default is 2 seconds.

Section	ED-FFP-OCH Description (continued)
Input Format (continued)	<ul style="list-style-type: none"> • <msgch> APS Message Channel. This parameter is used to configure the type of transport channel used to exchange APS protocol messages. Valid values are as follows: <ul style="list-style-type: none"> – DCC - APS messages are transmitted over the data communications channels (DCCs) in the overhead of the associated channels. – OSC - APS messages are transmitted over the Optical Supervisory Channel. – AUTO - APS automatically selects a transport mechanism to send APS messages. The DCC and OSC transport mechanisms are attempted. – IP - APS messages are transmitted over IP. The IP network can consist of any combination of DCCs, OSCs and out-of-band data communication networks (DCNs). <p>The default is AUTO.</p> <ul style="list-style-type: none"> • <msgholdtm> is the APS message channel holddown timer. This parameter specifies the minimum time between successive event-triggered APS messages, in units of milliseconds. The range is 100 to 10,000 milliseconds. The default is 5000 milliseconds. • <msgholdcount> is the APS channel message holddown count. This parameter specifies the maximum number of APS messages that can be sent within one MSGHOLDTM interval. The range is 2 to 10 messages. The default is 2 messages. • <msgmaxintvm> is the APS channel message maximum interval timer. An APS message is sent unconditionally, whenever the interval specified has elapsed since the last transmission of an APS message. The range is 1 to 120 seconds. The default is 15 seconds. • <fendprotid> is the far-end protection ID. This parameter is a case-sensitive string specifying the APS group at the far-end NE to which the message is being sent over DCC, IP, or OSC message channels. • <fendipaddr> is the far-end IP Address. This parameter specifies the IP address of the far-end NE, which is used as destination address when APS messages are transmitted over IP message channel. • <pst> is the primary state, used to administratively control the state of the interface, whether it is IS (in-service) or OOS (out-of-service). It also controls the state of the laser on this interface. The default value is IS. When an interface is administratively shut down, the laser on the interface still sends management and control information. The laser needs to be shut down explicitly. To shut down the interface alone, use OOS-MA as the PST value. To shut down the laser as well, use the PST value of OOS-MA and SST value of LASERSHUT.
Input Example	To enable a previously configured APS group, use the following: ED-FFP-OCH:ons155xx:WAVEPATCH-2-0-0,WAVEPATCH-2-0-1:123::: IS;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.17 ED-IP: Edit IP

Use this command to edit the IP address and mask on the network management Ethernet port or the OSC wave interface.



Note This command cannot be used to change an unnumbered interface configuration. To modify an unnumbered interface configuration, delete the existing configuration using the DLT-IP command and reconfigure using the ENT-IP command.

Section	ED-IP Description
Category	IP configuration
Security	Retrieve
Related Messages	3.7 DLT-IP: Delete IP 3.8 DLT-IPROUTE-STATIC: Delete IP Route Static 3.26 ENT-IP: Enter IP 3.54 RTRV-IP: Retrieve IP 3.55 RTRV-IPROUTE: Retrieve IP Route 3.79 SQUEEZE-MEM: Squeeze Memory
Input Format	ED-IP:[<tid>]:<aid>:<ctag>:::IPADDR=<addr>,IPMASK=<mask>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. Valid values are FE-0, SBY-FE-0, or WAVE-slot. • <ctag> is the correlation tag. • <addr> is the IP address. • <mask> is the IP subnet mask.
Input Example	Assuming that an IP address was previously configured on the FE-0 interface, to change the address and mask values, use the following: ED-IP:ons155xx:FE-0:123:::IPADDR=172.16.30.10, IPMASK=255.255.0.0;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.18 ED-NE-CDP: Edit Network Element CDP

Use this global level CDP command to edit CDP attributes for the entire system.

Section	ED-NE-CDP Description
Category	CDP
Security	Provisioning
Related Messages	3.59 RTRV-NE-CDP: Retrieve Network Element CDP

Section	ED-NE-CDP Description (continued)
Input Format	<p>ED-NE-CDP:[<tid>]::<ctag>:::[CDP=<cdp>],[UPDATETIME=<updatetime>],[HOLDTIME=<holdtime>],[SENDVER=<sendver>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <cdp> enables or disables CDP at the NE level. Valid values are Y or N. The default value is Y. • <updatetime> specifies how often the NE sends CDP packets. Valid values range from 5 to 254 seconds. The default value is 60 seconds. • <holdtime> sets the time for which a received CDP packet must be held before discarding. Valid values range from 10 to 255 seconds. The default value is 180 seconds. <p> Note The holdtime should not be set to a value less than the updatetime value.</p> <ul style="list-style-type: none"> • <sendver> indicates the highest version of CDP packets being sent. Valid values are 1 or 2. If SENDVER is 2, then both CDP version 1 and version 2 are sent by the NE. If SENDVER is 1, then only CDP version 1 packets are sent by the NE. The default is 2.
Input Example	To edit CDP attributes for the NE, use the following: ED-NE-CDP:ons155xx::123::UPDATETIME=30,HOLDTIME=90;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.19 ED-NE-GEN: Edit Network Element General

Use this command for generic NE configurations.

Section	ED-NE-GEN Description
Category	Generic NE configuration
Security	Retrieve
Related Messages	3.60 RTRV-NE-GEN: Retrieve Generic NE Configuration Values
Input Format	<p>ED-NE-GEN:[<tid>]::<ctag>:::[CFGREG=<configregval>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <cfgregval> is the string value that specifies the configuration register setting in hexadecimal.

Section	ED-NE-GEN Description (continued)
Input Example	To edit general NE configurations, use the following: ED-NE-GEN:ons155xx::123:::CFGREG=0x0;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.20 ED-NE-OSCP: Edit Network Element OSCP

Use this command to configure the OSCP protocol.

Section	ED-NE-OSCP Description
Category	OSCP
Security	Provisioning
Related Messages	3.61 RTRV-NE-OSCP: Retrieve Network Element OSCP
Input Format	<p>ED-NE-OSCP:[<tid>]::<ctag>:::[HELLOINTV=<hello_intv>], [HELLOHLDWN=<hldwn_time>],[INACTFCTR=<factor>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <hello_intv> is the Hello interval. It is the time between successive Hello packets in msec. Valid values range from 100 to 10,000 milliseconds. The default value is 200 milliseconds. • <hldwn_time> is the Hello hold down timer. It is the time interval for which no more than one Hello packet can be sent. Valid values range from 150 to 30,000 milliseconds. The default value is 3000 milliseconds. • <factor> is the inactivity factor. It is the number of Hello intervals to wait before declaring a link as down. Valid values range from 1 to 150. The default value is 5.
Input Example	<p>To configure OSCP protocol parameters, use the following:</p> <p>ED-NE-OSCP:ons155xx::123:::HELLOINTV=500,HELLOHLDWN=200,INACTFCTR=10;</p>
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.21 ED-OCH: Edit Optical Channel

Use this command to configure attributes on a transparent interface.

Section	ED-OCH Description
Category	Transparent interface configuration
Security	Provisioning

Section	ED-OCH Description (continued)
Related Messages	<p>3.64 RTRV-OCH: Retrieve Optical Channel</p> <p>3.39 OPR-LPBK-OCH: Operate Loopback OCH</p> <p>3.64 RTRV-OCH: Retrieve Optical Channel</p>
Input Format	<p>ED-OCH:[<tid>]:<aid>:<ctag>:::[ENCAP=<encap>],[RATE=<rate>],[FLC=<flc>],[LSC=<lsc>],[OFC=<ofo>],[THRLISTNAME=<name>],[CDP=<cdp>],[LASERFREQ=<laserfreq>]:[<pst>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the interface configured. Valid values of AID are TRANSPARENT-slot-subcard-0, WAVE-slot-subcard, WAVE-slot, WAVEPATCH-slot-subcard-port and ETHERDCC-slot-subcard-port. • <encap> indicates the protocol encapsulation configured on the transparent interface only. Valid values are as follows: <ul style="list-style-type: none"> - OC3 - OC12 - OC48 - STM1 - STM4 - STM16 - ESCON - FE - FDDI - FICON-1G - FICON-2G - FC-1G - FC-2G - SYSPLEX-CLO - SYSPLEX-ETR - SYSPLEX-ISC-COMP - SYSPLEX-ISC-PEER - GIGE - UNKNOWN <p> Note The default value is UNKNOWN. This parameter can be modified only when the interface is in the OOS state or when it is being brought down to OOS state in the same command.</p> <ul style="list-style-type: none"> • <rate> indicates the clock rate being configured on a transparent interface. This parameter is configured only when the encapsulation is set to UNKNOWN.

Section	ED-OCH Description (continued)
Input Format (continued)	<ul style="list-style-type: none"> • <flc> enables and disables forward laser control. If forward laser control is enabled, the transmit laser is shut down when the cross connect receive port on the switch is in alarm condition. Valid values are Y or N. The default is N. • <lsc> enables or disables laser safety control. The LSC parameter can be configured on wave interfaces only when the carrier boards have no optical splitter. If laser safety control is enabled, the transmit laser on the trunk side is shut down when the receive signal is not available on the fiber. Valid values are Y or N. The default value is N. • <oafc> enables or disables the OFC (open fibre control) safety protocol. The OFC parameter can be modified only when the encapsulation is FC-1G, FC-2G, or FICON and applies to transparent interfaces only. Valid values are Y or N. The default value is N. • <thrlistname> refers to the name entered using the ENT-THR-OCH command. The threshold list sets thresholds for errors monitored on this interface. The ampersand (&) operator associates multiple threshold lists with an interface. To delete a threshold list from an interface, a null value should be passed for that particular list, using the ED-OCH command. • <cdp> enables or disables CDP (Cisco Discovery Protocol) on this port. It applies to the WAVE-slot (OSC) and ETHERDCC ports only. Valid values are Y or N. The default is Y. • <laserfreq> specifies the transmit frequency transponder modules capable of generating more than one laser frequency. The frequency is represented in GHz. This parameter applies only to WAVE-slot-subcard AIDs and can be modified only when the interface is in the OOS (out-of-service) state or when it is brought down to OOS state with this command. The default is the lower frequency for the transponder module. • <pst> is the primary state. The value set in this state determines if the interface is shut down or active. IS (in-service) renders the interface administratively up. OOS is used to administratively shut down the interface. The default value is OOS.

Section	ED-OCH Description (continued)
Input Example	<p>To configure SONET OC-12 service, enable FLC, and associate the threshold list named “sonet-cvs” on the transparent interface in slot 3, subcard 0, use the following:</p> <pre>ED-OCH:ons155xx:TRANSPARENT-3-0-0:123:::ENCAP=OC12,FLC=Y, THRLISTNAME=sonet-cvs;</pre> <p>To configure wave interface in slot 2, subcard 0, with FLC and LSC enabled, use the following:</p> <pre>ED-OCH:ons155xx:WAVE-2-0:123:::THRLISTNAME=sonet-cvs,FLC=Y, LSC=Y, LASERFREQ=159800;</pre> <p>To configure an unknown protocol with a rate of 125,000 Kbps on a transparent interface in slot 2, subcard 0, use the following:</p> <pre>ED-OCH:ons155xx:TRANSPARENT-2-0-0:123:::ENCAP=UNKNOWN, RATE=125000;</pre> <p>To enable or disable OFC safety protocol on a transparent interface in slot 2, subcard 0, use the following:</p> <pre>ED-OCH:ons155xx:TRANSPARENT-2-0-0:123:::ENCAP=FC-1G,OFC=Y;</pre>
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.22 ED-PID: Edit Password

Use this command to edit your own password.

Section	ED-PID Description
Category	Security
Security	Provisioning
Related Messages	3.1 ACT-USER: Activate User, page 3-1
Input Format	<p>ED-PID:[<tid>]:<uid>:<ctag>::<oldpid>,<newpid>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <uid> is the user identifier, a string value with a maximum size of 64 characters. • <ctag> is the correlation tag. • <oldpid> is the old password, which is a string with a maximum size of 25 characters. • <newpid> is the new user login password which is a string with a maximum size of 25 characters.
Input Example	<p>To edit your own password, use the following:</p> <pre>ED-PID:ons155xx:admin:123:::mypasswd,newpasswd;</pre>
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.23 ED-THR-OCH: Edit Thresholds OCH

Use this command to edit the parameters for an existing threshold in a list.

Section	ED-THR-OCH Description
Category	Threshold list configuration
Security	Retrieve
Related Messages	3.70 RTRV-THR-OCH: Retrieve Thresholds OCH 3.78 SET-TH-OCH: Set Optical Threshold
Input Format	<p>ED-THR-OCH:[<tid>:<thrlistname>:<ctag>:::ERRTYPE=<errtype>, THRTYPE=<thrtype>, [VALUE=<value>], [TRGAPS=<trgaps>], [DESCR=<descr>];</p> <p>where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <thrlistname> indicates the name of the threshold list being edited. • <ctag> is the correlation tag. • <errtype> indicates the type of error counter to which the threshold applies. Possible values are as follows: <ul style="list-style-type: none"> – CVS – SONET section CV errors – CVRD – 8B/10B code violations and running disparity errors – CDLHEC – CDL HEC errors – CRC – Cyclic redundancy check errors • <thrtype> indicates the threshold type. Valid values are as follows: <ul style="list-style-type: none"> – DEGR - Indicates that a signal degrade condition has been reached. Use this threshold type only when <errtype> is CVS. – FAIL - Indicates that a signal failure condition has been reached. Use this threshold type only when <errtype> is CVS. – EVTTHR - Indicates that a non-service affecting condition has been reached. Use this threshold type when <errtype> is not CVS. – ALMTHR - Indicates that a service affecting condition has been reached. Use this threshold type when <errtype> is not CVS. • <value> specifies the threshold. If the value assigned here is x, the actual threshold is in the form of 10^{-x}. • <trgaps> is a trigger APS, such as protection switch on threshold exceeding. Valid values are Y or N. The default value is Y when ERRTYPE is CVS and is N for all other ERRTYPE values. • <index> is an integer value used to uniquely identify a particular threshold within a list of thresholds. The range is 1 to 64. When no value is specified for this parameter, the index for the threshold being created defaults to the lowest available index in that threshold list. • <descr> is a string used to assign a description to the threshold that is being configured. The maximum length of this string is 255 characters.

Section	ED-THR-OCH Description (continued)
Input Example	To edit the parameters for an existing threshold in a list, use the following: ED-THR-OCH:ons155xx:sonet-cvs:123:::ERRTYPE=CVS,THRTYPE=DEG, VALUE=5;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.24 ED-USER-SECU: Edit User Security

Use this command to edit the user identifier, password, or privilege levels associated with a user.



Note

Only a superuser can perform this function.

Section	ED-USER-SECU Description
Category	Threshold list configuration
Security	Retrieve
Related Messages	3.1 ACT-USER: Activate User 3.14 DLT-USER-SECU: Delete User Security 3.32 ENT-USER-SECU: Enter User Security 3.73 RTRV-USER-SECU: Retrieve User Security
Input Format	<p>[<tid>]:<uid>:<ctag>::<newuid>,<newpid>,,<uap>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <uid> user identifier, a string value with a maximum size of 64 characters. • <ctag> is the correlation tag. • <newuid> is the new value of the user identifier. It replaces the old value indicated by the <uid>. This field has the same format as the <uid> field. • <uap> is the user access privilege level. Valid values are as follows: <ul style="list-style-type: none"> – MAINT - maintenance level – PROV - provisioning level – RTRV - retrieve level – SUPER - superuser level
Input Example	To edit the user identifier, password, or privilege levels associated with a user, use the following: ED-USER-SECU:ons155xx:admin:123:::sonalm,password,,PROV;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.25 ENT-FFP-OCH: Enter Optical Protection

Use this command to configure splitter protection, line card protection, and trunk fiber based protection.

Section	ENT-FFP-OCH Description
Category	APS
Security	Retrieve
Related Messages	3.6 DLT-FFP-OCH: Delete Facility Protection OCH 3.51 RTRV-FFP-OCH: Retrieve Facility Protection OCH
Input Format	<p>ENT-FFP-OCH:[<tid>]:<wkg_aid>,<prot_aid>:<ctag>:::[PROTID=<protid>], [PSDIRN=<psdirn>], [RVRTV=<rvrtv>],[RVRTM=<rvrtm>], [YCABLE=<ycable>],[ENSWOTM=<enswotm>], [MSGCH=<msgch>],[MSGHOLDTM=<msgholdtm>], [MSGHOLDCOUNT=<msgholdcount>], [MSGMAXINTVTM=<msgmaxintvtm>], [FENDPROTID=<fendprotid>], [FENDIPADDR=<fendipaddr>]: [<pst>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <wkg_aid> is the working port AID. For splitter protection, the AID is in the form WAVEPATCH-slot-subcard-port, where port equals 0 or 1. For y-cable protection, the AID is of the form TRANSPARENT-slot-subcard-0. • <prot_aid> is the protection port AID. For splitter protection, the AID refers to the wavepatch interface. Hence, the AID is of the form wavepatch-slot-subcard-port, where port equals 0 or 1. For the y-cable protection scheme, the AID is of the form TRANSPARENT-slot-subcard-0. • <ctag> is the correlation tag. • <protid> is the protection group identifier or protection group name. The string can have a maximum of 32 characters. If <protid> is not specified, a protection group name is created with the name of the wkg_aid. • <psdirn> is the switching mode. Valid values are UNI (unidirectional) and BI (bidirectional). The default is UNI. • <rvrtv> is the revertive mode that applies only if monitoring in the standby state is supported. Valid values are Y or N. The default is N. If the value is Y, then the protection switching system reverts service to the active line after restoration. • <rvrtm> is the revertive timer that applies only if the mode is revertive and specifies the wait interval for revertive switching. The range is 0 to 720 seconds. The default is 300 seconds. • <ycable> specifies whether the type of protection is y-cable or not. Valid values are Y or N. The default is N. • <enswotm> specifies the switchover-enable timer. The timer delays re-enabling of auto-failover (to prevent rapid switching between standby and active states). The range is 1 to 120 seconds and the default is two seconds.

Section	ENT-FFP-OCH Description (continued)
Input Format (continued)	<ul style="list-style-type: none"> • <msgch> specifies the APS message channel. This parameter configures the type of transport channel used to exchange APS protocol messages. Valid values are as follows: <ul style="list-style-type: none"> – DCC - APS messages are transmitted over the data communications channels (DCCs) in the overhead of the associated channels. – OSC - APS messages are transmitted over the optical supervisory channel. – AUTO - APS automatically selects a transport mechanism to send APS messages. DCC and OSC are attempted. – IP - APS messages are transmitted over IP. The IP network can consist of any combination of DCCs, OSCs and out-of-band Data Communication Networks (DCNs). The default is AUTO. • <msgholdtm> specifies the APS message channel holddown time. This parameter specifies the minimum time between successive event-triggered APS messages in units of milliseconds. The range is 100 to 10000 milliseconds. The default is 5000 milliseconds. • <msgholdcount> specifies APS channel message holddown count. This parameter specifies the maximum number of APS messages that can be sent within one MSGHOLDTM interval. The range is 2 to 10 messages. The default is 2 messages. • <msgmaxintvmt> specifies the APS channel message maximum interval time. An APS message is sent unconditionally whenever the amount of time specified by this object has elapsed since the last transmission of an APS message. The range is 1 to 120 seconds. The default is 15. • <fendprotid> is the far-end protection identifier. This parameter is a case-sensitive string specifying the APS group at the far-end NE to which the message is being sent over DCC, IP, or OSC message channels. • <fendipaddr> specifies the far end IP address. This parameter specifies the IP address of the far end, which is used as the destination address when APS messages are transmitted. • <pst> is the primary state. It sets the protection group to be in service or out of service, upon creation. Valid values are IS (in-service) and OOS (out-of-service). OOS-MA (OOS for maintenance) is implied. The default is IS.
Input Example	<p>To configure splitter protection, use the following:</p> <pre>ENT-FFP-OCH:ons155xx:WAVEPATCH-2-0-0,WAVEPATCH-2-0-1:123::: PROTID=switch1-aps,PSDIRN=BI:OOS;</pre> <p>To configure y-cable protection, use the following:</p> <pre>ENT-FFP-OCH:ons155xx:TRANSPARENT-3-0-0,TRANSPARENT-4-0-0::: PROTID=switch2-aps,RVRTV=Y,RVRTM=6,ENSWOTM=10,YCABLE=Y;</pre>
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.26 ENT-IP: Enter IP

Use this command to configure the network management Ethernet port or the OSC interface.

Section	ENT-IP Description
Category	IP configuration
Security	Retrieve
Related Messages	3.7 DLT-IP: Delete IP 3.8 DLT-IPROUTE-STATIC: Delete IP Route Static 3.17 ED-IP: Edit IP 3.27 ENT-IPROUTE-STATIC: Enter Static Routes 3.54 RTRV-IP: Retrieve IP
Input Format	<p>ENT-IP:[<tid>]:<aid>:<ctag>:::IPADDRTYPE=<addr_type>,[IPADDR=<addr>],[IPMASK=<mask>],[IPUNIF=<interface>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. Valid values are FE-0, FE-SBY-0, WAVE-slot, ETHERDCC-slot-subcard-0, or LOOPBACK-[0-255]. If the AID is LOOPBACK-port, then the loopback interface is created and the parameters are assigned to it. • <ctag> is the correlation tag. • <addr_type> specifies the address type. This parameter has one of the following values: <ul style="list-style-type: none"> – ADDR indicates that the IP address is specified. – UNMBR indicates that the unnumbered interface is specified. • <addr> indicates the IP address. This parameter is mandatory if IPADDRTYPE is set to ADDR. • <mask> indicates the IP address subnet mask and is mandatory if IPADDRTYPE is set to ADDR. • <interface> shows the AID of the unnumbered interface and is mandatory if IPADDRTYPE is set to UNMBR. Applicable interfaces are as explained in the earlier <aid> description. <p> Note If the unnumbered and LOOPBACK-0 combination is used, the AID can be only WAVE-slot or ETHERDCC-slot-subcard-0.</p>
Input Example	<p>To configure an IP address on a network management interface, use the following:</p> <p>ENT-IP:ons155xx:FE-0:123:::IPADDRTYPE=ADDR, IPADDR=172.16.42.110, IPMASK=255.255.255.0;</p> <p>To unnumber WAVE-1-0 to LOOPBACK-0 interface, use the following:</p> <p>ENT-IP:ons155xx:WAVE-1-0:123:::IPADDRTYPE=UNMBR, IPUNIF=LOOPBACK-0;</p>
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.27 ENT-IPROUTE-STATIC: Enter Static Routes

Use this command to create static routes.

Section	ENT-IPROUTE-STATIC Description
Category	IP configuration
Security	Retrieve
Related Messages	3.8 DLT-IPROUTE-STATIC: Delete IP Route Static 3.55 RTRV-IPROUTE: Retrieve IP Route
Input Format	<p>ENT-IPROUTE-STATIC:[<tid>]:<ctag>:::PREFIXADDR=<addr>, PREFIXMASK=<mask>, [ROUTEIF=<interface>], [ROUTEADDR=<routeaddr>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <addr> specifies the prefix IP address for the static route. • <mask> specifies the prefix mask. • <interface> specifies the AID of the routing interface. • <routeaddr> specifies the IP address of the routing interface <p> Note At least one of the two parameters, ROUTEIF or ROUTEADDR, needs to be specified. There is no Edit command associated with the Enter command. If any of the parameters associated with the static route needs to be changed, the entire route needs to be deleted and a new route created.</p>
Input Example	To configure a static route for a particular address through the OSC WAVE-0 port, use the following: ENT-IPROUTE-STATIC:ons155xx::123:::PREFIXADDR=10.1.0.0, PREFIXMASK=255.255.0.0, ROUTEIF=WAVE-0;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.28 ENT-NBR: Enter Neighbor

Use this command to configure a physical neighbor on a port.

Section	ENT-NBR Description
Category	Topology neighbor configuration
Security	Provisioning
Related Messages	3.10 DLT-NBR: Delete Neighbor 3.58 RTRV-NBR: Retrieve Neighbor

Section	ENT-NBR Description (continued)
Input Format	<p>ENT-NBR:[<tid>]:<aid>:<ctag>:::DSCVRY=<dscvry>, [LINKDIRN=<linkdirn>], [NBRNAME=<nbrname>], [NBRPORT=<nbrport>], [NBRAGENTIP=<nbragentip>], [PRXYPORT=<prxyport>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> identifies the interface and can be one of the following: <ul style="list-style-type: none"> – TRANSPARENT-slot-subcard-0 – WDM-slot-subcard • <dscvry> specifies the means of discovery of this neighbor. It could have one of the following values: <ul style="list-style-type: none"> – CDP - The neighbor information learned dynamically through CDP. – MANUAL - The neighbor information manually entered by the user. <p> Note When CDP is specified, LINKDIRN defaults to both and other parameters should not be entered.</p> <ul style="list-style-type: none"> • <linkdirn> is the link direction. Both transmit and receive links of this port are connected to the neighbor specified by the rest of the command. <ul style="list-style-type: none"> – TX - The neighbor is on the transmit link of this port. – RX - The neighbor is on the receive link of this port. <p>For direct links between nodes, the LINKDIRN is both and there can be only one neighbor configured on the port. If an EDFA is connected to one direction of the port, there can be two neighbors, one configured for LINKDIRN = TX and the other for LINKDIRN = RX.</p> <ul style="list-style-type: none"> • <nbrname> is the name of the neighbor NE. The string has a maximum 64 characters and is suggested that this be the <tid> of the neighbor NE. • <nbrport> is the name of the port on the neighbor NE. The string has a maximum 32 characters and is suggested that this be the <aid> of the port to which the local port is connected. • <nbragentip> is the IP address of the management agent on the neighbor. String has a maximum of 32 characters. • <prxyport> specifies the AID of the proxy port. This parameter is valid only when DSCVRY = CDP. In the case of external ports that do not run CDP on their own, but are intranode connected to a port running CDP, then physical topology on the external port can be learned through CDP running on the proxy port specified through this parameter. Valid AIDs are as follows: <ul style="list-style-type: none"> – WAVE-slot (the OSC wave port) – ETHERNETDCC-slot-subcard-port.

Section	ENT-NBR Description (continued)
Input Example	To manually configure a physical neighbor on a port, use the following: ENT-NBR:ons155xx:WDM-0-0:123:::DSCVRY=MANUAL,LINKDIRN=RX, NBRNAME=shelf2,NBRPORT=WDM-0-0, NBRAGENTIP=172.16.20.1; To discover a physical neighbor enabling CDP on a port, use the following: ENT-NBR:ons155xx:WDM-0-0:100:::DSCVRY=CDP, PRXYPORT=WAVE-0;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.29 ENT-NTPASSOC: Enter NTP Associations

Use this command to configure NTP associations for synchronizing system clocks over the network. Two types of associations can be created:

- Peer - The system synchronizes to a peer system and allows the peer to synchronize as well.
- Server - The system synchronizes to the server, but not the other way around.



Note

More than one association can be specified through multiple invocations of this command.

Section	ENT-NTPASSOC Description
Category	NTP
Security	Provisioning
Related Messages	3.11 DLT-NTPASSOC: Delete NTP Associations 3.63 RTRV-NTPASSOC: Retrieve NTP Associations
Input Format	ENT-NTPASSOC:[<tid>]::<ctag>:::ASSOCTYPE=<assoctype>, ASSOCIPADDR=<associpaddr>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <assoctype> indicates the type of association. Valid values are SERVER and PEER. • <associpaddr> specifies the IP address of the server or peer.
Input Example	To configure an NTP server association, use the following: ENT-NTPASSOC:ons155xx::123:::ASSOCTYPE=SERVER, ASSOCIPADDR=172.16.246.1;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.30 ENT-PATCH: Enter Patch

Use this command to configure patches between ports on the same network element.

Section	ENT-PATCH Description
Category	Patch configuration
Security	Provisioning
Related Messages	3.12 DLT-PATCH: Delete Patch 3.65 RTRV-PATCH: Retrieve Patch
Input Format	<p>ENT-PATCH:[<tid>]:<from_aid>,<to_aid>:<ctag>:[<ctype>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <from_aid> identifies the port you patched from to the port identified by <to_aid>. Valid values for <from_aid> are as follows: <ul style="list-style-type: none"> – FILTER-slot-subcard-0 – OSCFILTER-slot-subcard – THRU-slot-subcard – WAVE-slot – WAVEPATCH-slot-subcard-port – WDM-slot-subcard • <to_aid> identifies the port you patched from the port identified by <from_aid>. Valid values for <to_aid> are as follows: <ul style="list-style-type: none"> – FILTER-slot-subcard-0 – OSCFILTER-slot-subcard – THRU-slot-subcard – WAVE-slot – WAVEPATCH-slot-subcard-port – WDM-slot-subcard • <ctag> is the correlation tag. • <ctype> is a position defined parameter and can be either 2WAY or 1WAY. When 1WAY is specified, then the patch is from the <from_aid> port to the <to_aid> port is either transmit or receive. 2WAY implies both transmit and receive patches between the two ports. The default is 2WAY.
Input Example	To create a bidirectional patch between the wavepatch port in slot 2, subcard 0, port 0, and the filter port in slot 0, subcard 0, port 0, use the following: ENT-PATCH:ons155xx:WAVEPATCH-2-0-0,FILTER-0-0-0:123::;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.31 ENT-THR-OCH: Enter Thresholds OCH

Use this command to set thresholds for errors that are being monitored on an interface. This command is used every time a new threshold is added to a threshold list.

Section	ENT-THR-OCH Description
Category	Threshold list configuration
Security	Provisioning
Related Messages	3.13 DLT-THR-OCH: Delete Threshold OCH 3.70 RTRV-THR-OCH: Retrieve Thresholds OCH 3.71 RTRV-TH-rr: Retrieve Threshold 3.78 SET-TH-OCH: Set Optical Threshold

Section	ENT-THR-OCH Description (continued)
Input Format	<p>ENT-THR-OCH:[<tid>]:<THRLISTNAME>:<ctag>:::ERRTYPE=<errtype>, THRTYPE=<thrtype>, VALUE=<value>, [TRGAPS=<trgaps>], [INDEX=<index>], [DESCR=<descr>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <thrlistname> indicates the name of the threshold list being created. • <ctag> is the correlation tag. • <errtype> indicates the type of error counter to which the threshold applies. Valid values are as follows: <ul style="list-style-type: none"> – CVS - SONET section CV errors – CVRD - 8B/10B code violations and running disparity errors – CDLHEC - CDL HEC errors – CRC - Cyclic Redundancy Check errors • <thrtype> indicates the threshold type. Valid values are as follows: <ul style="list-style-type: none"> – DEGR - Indicates that a signal degrade condition has been reached. Use this threshold type only when <errtype> is CVS. – FAIL - Indicates that a signal failure condition has been reached. Use this threshold type only when <errtype> is CVS. – EVTTTHR - Indicates that a non-service affecting condition has been reached. Use this threshold type when <errtype> is not CVS. – ALMTHR - Indicates that a service affecting condition has been reached. Use this threshold type when <errtype> is not CVS. • <value> specifies the threshold value as 10^{-x}, where <value> is x. The range is 3 to 9. • <trgaps> is a trigger APS, such as protection switch on threshold exceeding. Valid values are Y or N. The default value is Y when ERRTYPE is CVS and is N for all other ERRTYPE values. • <index> is an integer value used to uniquely identify a particular threshold within a list of thresholds. The range is 1 to 64. When no value is specified for this parameter, the index for the threshold being created defaults to the lowest available index in that threshold list. • <descr> is a string used to assign a description to the threshold that is being configured. The maximum length of this string is 255 characters.
Input Example	To configure the SONET section CV threshold and add it to the threshold list sonet-cvs, use the command: ENT-THR-OCH:ons155xx:sonet-cvs:123:::ERRTYPE=CVS,THRTYPE=DEGR, VALUE=7, INDEX=1;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.32 ENT-USER-SECU: Enter User Security

Use this command to create a user ID and set security parameters.

Section	ENT-USER-SECU Description
Category	Security
Security	Retrieve
Related Messages	3.1 ACT-USER: Activate User 3.4 CANC-USER: Cancel User 3.14 DLT-USER-SECU: Delete User Security 3.24 ED-USER-SECU: Edit User Security I3.73 RTRV-USER-SECU: Retrieve User Security
Input Format	ENT-USER-SECU:[<tid>]:<uid>:<ctag>::<pid>,,<uap>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <uid> is the user identifier, a string value with a maximum size of 64 characters. • <ctag> is the correlation tag. • <pid> is the user login password, a string value with a maximum length of 25 characters. • <uap> is the user access privilege level. Valid values are as follows: <ul style="list-style-type: none"> – MAINT - Maintenance level – PROV - Provisioning level – RTRV - Retrieve level – SUPER - Superuser level
Input Example	To create a user ID and set security parameters, use the following: ENT-USER-SECU:ons155xx:admin:123::psword,,PROV;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.33 FORMAT-MEM: Format Memory

Use this command to permanently format a Flash PC device.

Section	FORMAT-MEM Description
Category	Memory management
Security	Retrieve
Related Messages	3.5 CPY-MEM: Copy Memory I3.43 RST-MEM: Restore Memory 3.57 RTRV-MEM: Retrieve Memory

Section	FORMAT-MEM Description (continued)
Input Format	<p>FORMAT-MEM:[<tid>]:<aid>:<ctag>:::[CMDMODE=<mode>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the memory device that is being formatted. Valid values are BOOTFLASH, DISK-[0–1], PCMCIA-[0–1], SBY-BOOTFLASH, SBY-DISK-[0–1], or SBY-PCMCIA-[0–1] • <ctag> is the correlation tag. • <mode> indicates the mode of operation. Valid values are FRCD and NORMAL. In FRCD mode, any files that may be present on the Flash PC device, are permanently erased as part of the format operation. If any files are present on the Flash PC device in NORMAL mode, the format request is denied. The default mode is NORMAL.
Input Example	To permanently format a Flash PC device, use the following: FORMAT-MEM:ons155xx:BOOTFLASH:123:::CMDMODE=FRCD;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.34 INH-MSG-ALL: Inhibit Message All

Use this command to disable autonomous messages from being transmitted.

Section	INH-MSG-ALL Description
Category	Alarms and faults
Security	Retrieve
Related Messages	3.2 ALW-MSG-ALL: Allow Message All
Input Format	<p>INH-MSG-ALL:[<tid>]:<ctag>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag.
Input Example	To disable autonomous messages from being transmitted, use the following: INH-MSG-ALL:ons155xx::123;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.35 INH-Swdx-EQPT: Inhibit Switch Duplex Equipment

Use this command to inhibit automatic or manual switching from the active to the standby processor card. It also disables configuration syncs between the two processor cards. This command is usually used when performing software upgrades.

Section	INH-Swdx-EQPT Description
Category	Redundancy configuration
Security	Maintenance
Related Messages	3.3 ALW-Swdx-EQPT: Allow Switch Duplex Equipment 3.80 SW-DX-EQPT: Switch Duplex Equipment
Input Format	INH-Swdx-EQPT:[<tid>]:<aid>:<ctag>; Where: <ul style="list-style-type: none">• <tid> is the target identifier.• <aid> is the access identifier. Valid values are SLOT-6 or SLOT-7.• <ctag> is the correlation tag.
Input Example	To inhibit automatic or manual switching from the active to the standby processor card, or disable configuration syncs between the two processor cards, use the following: INH-Swdx-EQPT:ons155xx:SLOT-6:123;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.36 INIT-REG-ETH: Initialize Register Ethernet

Use this command to clear the counters associated with a specific Ethernet AID.



Note

Issuing this command clears all counters.

Section	INIT-REG-ETH Description
Category	IP configuration
Security	Retrieve
Related Messages	3.17 ED-IP: Edit IP 3.54 RTRV-IP: Retrieve IP
Input Format	INIT-REG-ETH:[<tid>]:<aid>:<ctag>; Where: <ul style="list-style-type: none">• <tid> is the target identifier.• <aid> indicates the interface where counters are being cleared. Valid values are FE-0 and FE-SBY-0.• <ctag> is the correlation tag.

Section	INIT-REG-ETH Description (continued)
Input Example	To clear the counters associated with a specific Ethernet facility, use the following: INIT-REG-ETH:ons155xx:FE-0:123;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.37 INIT-REG-OCH: Initialize Register OCH

Use this command to clear the counters associated with a specific OCH facility.



Note Issuing this command clears all counters.

Section	INIT-REG-OCH Description
Category	Transparent interface configuration
Security	Maintenance
Related Messages	3.64 RTRV-OCH: Retrieve Optical Channel, page 3-62
Input Format	INIT-REG-OCH:[<tid>]:<aid>:<ctag>; Where: <ul style="list-style-type: none">• <tid> is the target identifier.• <aid> indicates interface on which counters are being cleared. Valid values are TRANSPARENT-slot-subcard-0 and WAVE-slot-subcard.• <ctag> is the correlation tag.
Input Example	To clear the counters associated with transparent port in slot 2, subcard 0, use the following: INIT-REG-OCH:ons155xx:TRANSPARENT-2-0-0:123;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.38 INIT-SYS: Initialize System

Use this command to initialize or reset a processor card on the system.

Section	INIT-SYS Description
Category	Generic NE configuration
Security	Retrieve
Related Messages	3.77 SET-SID: Set System Identification

Section	INIT-SYS Description (continued)
Input Format	<p>INIT-SYS:[<tid>]:<aid>:<ctag>::;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> identifies the card that needs to be reset. Valid values are SLOT-6 or SLOT-7. • <ctag> is the correlation tag.
Input Example	To initialize or reset the processor card in slot 6, use the following: INIT-SYS:ons155xx:SLOT-6:123::;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.39 OPR-LPBK-OCH: Operate Loopback OCH

Use this command to operate a specific type of loopback on the port specified by the AID.

Section	OPR-LPBK-OCH Description
Category	Transparent interface configuration
Security	Maintenance
Related Messages	3.41 RLS-LPBK-OCH: Release Loopback OCH
Input Format	<p>OPR-LPBK-OCH:[<tid>]:<aid>:<ctag>::,,<lpbktype>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the interface on which the loopback is being created. Valid values are TRANSPARENT-slot-subcard-0 and WAVE-slot-subcard. • <ctag> is the correlation tag. • <lpbktype> indicates the type of loopback that is being created. Valid values are as follows: <ul style="list-style-type: none"> – FACILITY - The signal from the receive input is looped back to the transmit output. – TERMINAL - The signal bound for the transmit output is looped back to the receive input. This is an internal loopback used for hardware debug and diagnostics.
Input Example	To create a facility loopback on the transparent interface in slot 2, subcard 0, use the following: OPR-LPBK-OCH:ons155xx:TRANSPARENT-2-0-0:123::,,FACILITY;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.40 OPR-PROTNSW-OCH: Operate Protection Switch OCH

Use this command to enable the NE to perform a protection switch or a lockout.

Section	OPR-PROTNSW-OCH Description
Category	APS
Security	Maintenance
Related Messages	3.42 RLS-PROTNSW-OCH: Release Protection Switch OCH
Input Format	<p>OPR-PROTNSW-OCH:[<tid>]:<aid>:<ctag>:<sc></p> <p>Where:</p> <ul style="list-style-type: none"> • <aid> is the working or protection port AID to which a switch request is directed. Valid values are TRANSPARENT-slot-subcard-0 or WAVEPATCH-slot-subcard-port. If the AID identifies the working line, then service is switched from working to protection. If the AID identifies the protection line, then service is switched back to the working line. • <sc> is the switch command. Valid values are as follows: <ul style="list-style-type: none"> – MAN - Switch from working or back to working is done based on the AID specified unless a request of equal or higher priority is in effect. – FRCD - Switch from working or back to working is done based on the AID specified unless a request of equal or higher priority is in effect. – LOCKOUT - Lockout all switchovers to the protection facility. If the protection facility is currently active, then the lockout request is denied. <p>The lockout request has the highest priority and takes effect regardless of signal condition. The forced switch command is the next highest priority.</p> <p>The manual switchover request has the lowest priority and only completes if there is no protection path lockout or forced switchover is in effect, or the signal has failed or degraded.</p>
Input Example	To enable the NE to perform a protection switch or a lockout, use the following: OPR-PROTNSW-OCH:ons155xx:WAVEPATCH-2-0-1:123::FRCD;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.41 RLS-LPBK-OCH: Release Loopback OCH

Use this command to release a specific type of loopback on the port specified by the AID.

Section	RLS-LPBK-OCH Description
Category	Transparent interface configuration
Security	Maintenance
Related Messages	3.39 OPR-LPBK-OCH: Operate Loopback OCH

Section	RLS-LPBK-OCH Description (continued)
Input Format	<p>RLS-LPBK-OCH:[<tid>]:<aid>:<ctag>::,,<lpbktype>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the interface on which the loopback is being released. Valid values are TRANSPARENT-slot-subcard-0 and WAVE-slot-subcard. • <ctag> is the correlation tag. • <lpbktype> indicates the type of loopback that is being released. FACILITY is the valid value, where the signal from the receive input is looped back to the transmit output.
Input Example	To release a facility loopback on the transparent interface in slot 2, subcard 0, use RLS-LPBK-OCH:ons155xx:TRANSPARENT-2-0-0:123::,,FACILITY;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.42 RLS-PROTNSW-OCH: Release Protection Switch OCH

Use this command to clear the previous switchover request.



A lockout or a forced or manual switchover request stays in effect until the system reboots.

Section	RLS-PROTNSW-OCH Description
Category	APS
Security	Maintenance
Related Messages	3.40 OPR-PROTNSW-OCH: Operate Protection Switch OCH
Input Format	<p>RLS-PROTNSW-OCH:[<tid>]:<aid>:<ctag>::;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the port AID to which the switch request is directed. Valid values are TRANSPARENT-slot-subcard-0 or WAVEPATCH-slot-subcard-port.
Input Example	To clear the previous request, use the following: RLS-PROTNSW-OCH:ons155xx:WAVEPATCH-2-0-1:123;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.43 RST-MEM: Restore Memory

Use this command to recover a file that was previously deleted, but not erased, using the DLT-MEM command.

**Note**

A deleted file cannot be recovered if a valid one with the same name exists. The existing file needs to be deleted before the already deleted one can be recovered. If two files with the same name were deleted, the index is used to uniquely identify the file to be recovered.

Section	RST-MEM Description
Category	Memory Management
Security	Retrieve
Related Messages	3.5 CPY-MEM: Copy Memory 3.33 FORMAT-MEM: Format Memory 3.57 RTRV-MEM: Retrieve Memory
Input Format	RST-MEM:[<tid>]:<aid>:<ctag>:::INDEX=<index>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the memory device from which the file is being recovered. Valid values are BOOTFLASH, DISK-[0-1], PCMCIA-[0-1], SBY-BOOTFLASH, SBY-DISK-[0-1], or SBY-PCMCIA-[0-1]. • <ctag> is the correlation tag. • <index> specifies the index number associated with the deleted file. This is an integer value and can be obtained by using the RTRV-MEM command.
Input Example	To recover a file that was previously deleted, but not erased, using the DLT-MEM command, use the following: RST-MEM:ons155xx:BOOTFLASH:123::INDEX=4;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.44 RST-NE-CDP: Restore Global CDP Attributes

Use this command to restore all global CDP attribute settings to their default values.

Section	RST-NE-CDP Description
Category	CDP
Security	Maintenance
Related Messages	3.18 ED-NE-CDP: Edit Network Element CDP 3.59 RTRV-NE-CDP: Retrieve Network Element CDP
Input Format	RST-NE-CDP:[<tid>]:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag.

Section	RST-NE-CDP Description (continued)
Input Example	To restore all global CDP attribute settings to their default values, use the following: RST-NE-CDP:ons155xx::123;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.45 RTRV-ALM-ALL: Retrieve Alarms All

Use this command to retrieve alarms for a given facility, card, or module.



Note Only alarms with severities critical, major, or minor can be retrieved using this command.

Section	RTRV-ALM-ALL Description
Category	Alarms and faults
Security	Retrieve
Related Messages	3.2 ALW-MSG-ALL: Allow Message All
Input Format	<p>RTRV-ALM-ALL:[<tid>]:[<aid>]:<ctag>:[<ntfcncde>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. Valid values are SLOT-slot and SLOT-slot-subcard. • <ctag> is the correlation tag. • <ntfcncde> indicates the type of notification generated on the NE when a threshold is exceeded or cleared. Valid values are CR, MJ, or MN.
Input Example	<p>To retrieve alarms for the module in slot 2, subcard 0, use the following: RTRV-ALM-ALL:ons155xx:SLOT-2-0:123::MJ;</p> <p>To retrieve alarms for the client port in slot 2, subcard 0, use the following: RTRV-ALM-ALL:ons155xx:TRANSPARENT-2-0-0:123::MJ;</p>
Output Format	<p>SID DATE TIME M CTAG COMPLD "<aid>:<severity>,<alarm>,SA,,,:\"<text>\\"" ;</p>

Section	RTRV-ALM-ALL Description (continued)
Output Example	<p>The output if no alarm condition exists:</p> <pre>SID DATE TIME M 123 COMPLD ;</pre> <p>The output if a matching alarm condition exists:</p> <pre>SID DATE TIME M 123 COMPLD "TRANSPARENT-2-0-0:MJ,LOF,SA,,,:\"Loss Of Frame\"" ;</pre>
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.46 RTRV-ALM-ENV: Retrieve Alarms Environmental

Use this command to retrieve environmental alarms on the system.

Section	RTRV-ALM-ENV Description
Category	Alarms and faults
Security	Retrieve
Related Messages	3.45 RTRV-ALM-ALL: Retrieve Alarms All, page 3-39
Input Format	<p>RTRV-ALM-ENV:[<tid>]:[<aid>]:<ctag>::[<ntfcncde>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. • <ctag> is the correlation tag. • <ntfcncde> indicates the type of notification generated on the NE when a threshold is exceeded or cleared. Valid values are CR, MJ, or MN.
Input Example	To retrieve major environmental alarms, use the following: RTRV-ALM-ENV:ons155xx::123::MJ;
Output Format	<pre>SID DATE TIME M CTAG COMPLD ":<severity>,<alarm>,,,\"<text>\" ";</pre>
Output Example	<p>The output if a matching alarm condition exists:</p> <pre>SID DATE TIME M 123 COMPLD "Chassis:MJ,HITEMP,,,\"Chassis temperature too high\" ";</pre>
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.47 RTRV-ATTR-OCH: Retrieve Attributes

Use this command to retrieve the severity levels assigned to the threshold values configured on the wavepatch interfaces.

Section	RTRV-ATTR-OCH Description
Category	Alarms and faults
Security	Retrieve
Related Messages	3.44 RST-NE-CDP: Restore Global CDP Attributes 3.74 SET-ATTR-OCH: Set Attributes
Input Format	<p>RTRV-ATTR-OCH [<tid>]:[<aid>]:<ctag>:[<ntfcncde>],[<condtype>],,, [<dirln>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. The valid value is WAVEPATCH-slot-subcard-port. • <ctag> is the correlation tag. • <ntfcncde> is indicates the type of notification generated on the NE when a threshold is exceeded or cleared. Valid values are CR, MJ, or MN. • <condtype> is monitored condition type. Valid values are as follows: <ul style="list-style-type: none"> – OPRHA - Receive optical power level corresponding to the high alarm threshold. If the optical power level is greater than the threshold associated with this parameter, an alarm is generated. – OPRLA - Receive optical power level corresponding to the low alarm threshold. If the optical power level is less than the threshold associated with this parameter, an alarm is generated. – OPRHW - Receive optical power level corresponding to the high warning threshold. If the optical power level is greater than the threshold associated with this parameter, a warning is generated that may be reported using REPT EVT. – OPRLW - Receive optical power level corresponding to the low warning threshold. If the optical power level is less than the threshold associated with this parameter, a warning is generated that may be reported using REPT EVT. • <dirln> is the direction associated with the information. Valid values are RCV or TRMT. The default is both directions.
Input Example	<p>To retrieve the severity levels assigned to the threshold values configured on wavepatch interfaces on the transponder cards, use the following:</p> <pre>RTRV-ATTR-OCH:ons155xx:WAVEPATCH-8-0-0:123::,OPRHA;</pre>
Output Format	<pre> SID DATE TIME M CTAG COMPLD "<aid>:<severity>,<condtype>,,<dirln>" ;</pre>

Section	RTRV-ATTR-OCH Description (continued)
Output Example	The output for wavepatch interfaces: SID DATE TIME M 123 COMPLD "WAVEPATCH-8-0-0:MJ,OPRHA,,RCV" ;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.48 RTRV-CDPNBR-OCH: Retrieve CDP Neighbor OCH

Use this command to retrieve neighbor information discovered by CDP on a specific port in the NE or on all ports of the NE.

Section	RTRV-CDPNBR-OCH Description
Category	CDP
Security	Retrieve
Related Messages	3.10 DLT-NBR: Delete Neighbor 3.28 ENT-NBR: Enter Neighbor 3.58 RTRV-NBR: Retrieve Neighbor
Input Format	<p>RTRV-CDPNBR-OCH:[<tid>]:[<aid>]:<ctag>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> specifies the port AID to retrieve information for the neighbor on that port only. NULL retrieves information on all neighbors. • <ctag> is the correlation tag.
Input Example	To retrieve neighbor information discovered by CDP on a specific port in the NE or on all ports of the NE, use the following: RTRV-CDPNBR-OCH:ons155xx::123;
Output Format	<p>SID DATE TIME M CTAG COMPLD "<aid>:NBRNAME=<nbrname>,NBRPORT=<nbrport>, CAPABILITY=<capability>,TTL=<ttl>" ;</p>

Section	RTRV-CDPNBR-OCH Description (continued)
Output Example	<p>SID DATE TIME M 123 COMPLD "Wave-1-0:NBRNAME=Switch2,NBRPORT=PORT-0,CAPABILITY=S, TTL=158" ; Where:</p> <ul style="list-style-type: none"> • <NBRNAME> shows the name of the neighboring device, typically, the SID of that device. The maximum size is 255 characters. • <NBRPORT> is the name of the neighboring port. Typically, the AID of that port. • <CAPABILITY> indicates the capability of the neighboring device. It is a string formed by the concatenation of one or more of the following values: <ul style="list-style-type: none"> – R - Router, – T - Trans bridge – B - Source route bridge – S - Switch – H - Host – I - IGMP – r - Repeater • <TTL> Time To Live value. This is the amount of time in seconds before this neighbor information is discarded unless the NE receives another packet on this port with the same information.
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.49 RTRV-COND-ALL: Retrieve Condition All

Use this command to retrieve current standing conditions associated with specified equipment or facility. This command retrieves conditions with all severities.

Section	RTRV-COND-ALL Description
Category	Alarms and faults
Security	Retrieve
Related Messages	3.45 RTRV-ALM-ALL: Retrieve Alarms All 3.46 RTRV-ALM-ENV: Retrieve Alarms Environmental
Input Format	RTRV-COND-ALL:[<tid>]:[<aid>]:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. • <ctag> is the correlation tag.
Input Example	To retrieve current standing conditions associated with specified equipment or facility, use the following: RTRV-COND-ALL:ons155xx:TRANSPARENT-8-0-0:123::;
Output Format	SID DATE TIME M CTAG COMPLD "<aid>,<encap>:<severity>,<condtype>,NSA,,,,"<text>"" ;
Output Example	The output for conditions on the transparent interface: SID DATE TIME M 123 COMPLD "TRANSPARENT-8-0-0,OC3:MN,CVS,NSA, ,,,,"Code Violation- Section - Exceed Degrade"" ;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.50 RTRV-EQPT: Retrieve Equipment

Use this command to retrieve the redundancy configurations. It also retrieves inventory information for the specified module.

The PST and SST values in the last position defined block also indicate the redundancy states, when the AID specified in this command is SLOT-6 or SLOT-7. The values of PST-PSTQ and SST are reported under different operating conditions.

Active processor card states are as follows:

- For normal active, PST=IS-NR.
- For active processor card in fault state, PST=IS-ANR, SST=FLT,ACT.

Standby processor card states are as follows:

- If standby peer has hardware state missing, PST=OOS-AU, SST=UEQ.

- If standby peer has hardware state non-participant, PST=OOS-AU, SST=AINS.
- If standby peer has hardware state of standby, PST=IS-ANR, SST=STBYC.
- If standby is in fault state, PST=IS-ANR, SST=FLT, STBYC or STBYH (depending on software redundancy state.)
- If the standby is normal and in hot standby state, PST=IS-NR, SST=STBYH.

Under maintenance mode (when an INH-SWDX command has been issued for standby processor card):

- If hardware state is missing, PST=OOS-AUMA, SST=UEQ,STBYI.
- If hardware state is non-participant and software redundancy state is disabled, PST=OOS-AURST, SST=AINS,STBYI.

For all other software redundancy states like unknown, negotiating, or standby cold, PST=IS-RST, SST=STBYI.

In addition to these values, two SST values indicate the synchronization status on the running and startup configurations.

- NRCSYNC - Running config is not in sync
- NSCSYNC - Startup config is not in sync

Section	RTRV-EQPT Description
Category	Redundancy configuration
Security	Retrieve
Related Messages	3.35 INH-SWDX-EQPT: Inhibit Switch Duplex Equipment 3.80 SW-DX-EQPT: Switch Duplex Equipment
Input Format	<p>RTRV-EQPT:[<tid>]:[<aid>]:<ctag>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. The value is SLOT-slot. The default is all AIDs. • <ctag> is the correlation tag.
Input Example	<p>To retrieve inventory information for the CPU switch module in slot 6, use the following:</p> <p>RTRV-EQPT:ons155xx,SLOT-6:123;</p> <p>To retrieve inventory information for modules in card in slot 8, use the following:</p> <p>RTRV-EQPT:ons155xx,SLOT-8:123;</p>

Section	RTRV-EQPT Description (continued)
Output Format	<p>Output format for processor cards:</p> <pre> SID DATE TIME M CTAG COMPLD "<aid>:<clei>:PN=<pn>,SN=<sn>,OPN=<opn>,HWVER=<hwver>, SWVER=<swver>,FWVER=<fwver>,BOOTLDR=<bootldr>, ROMMONVER=<rommonver>,HWREDSTATE=<hwredstate>, SWREDSTATE=<swredstate>,:<pst>,<sst>,<sst>";</pre> <p>Output format for 2.5-Gbps transponder modules:</p> <pre> SID DATE TIME M CTAG COMPLD "<aid>:<clei>:PN=<pn>,SN=<sn>,OPN=<opn>,HWVER=<hwver>, FSWVER=<fwver>,,,LASERFREQLOW=<laserfreqlow>, LASERFREQHIGH=<laserfreqhigh>:<pst>,<sst>,<sst>"</pre> <p>;</p> <p>Output format for 10-GE transponder modules:</p> <pre> SID DATE TIME M CTAG COMPLD "<aid>:<clei>:PN=<pn>,SN=<sn>,OPN=<opn>,HWVER=<hwver>, FSWVER=<fwver>,,,LASERFREQ=<laserfreq>:<pst>,<sst>,<sst>"</pre> <p>;</p>

Section	RTRV-EQPT Description (continued)
Output Example	<p>SID DATE TIME</p> <p>M 123 COMPLD</p> <p>"SLOT-5:CLIE:PN=73-5656-03,SN=CAB0516HK2,OPN=N/A, HWVER=2.0,SWVER=12.1,FWVER=1.24, BOOTLDR=12.1(7a)EY2,ROMMONVER=12.1(7r)EY, HWREDSTATE=ACT,SWREDSTATE=ACT :IS-NR,NRCSYNC,NSCSYNC"</p> <p>;</p> <p>Where:</p> <ul style="list-style-type: none"> • PN is a string that shows part number, maximum length is 32 characters. • SN is a string that shows serial number, maximum length is 32 characters. • OPN is a string that shows the orderable product number, maximum length is 32 characters. • HWVER is a string that shows the hardware version number, maximum length is 32 characters. • SWVER is a string that shows the image version running on this processor card, maximum length is 32 characters • FWVER is a string that shows functional software image version running on this module, maximum length is 32 characters. • BOOTLDR is a string that shows the bootloader image version, maximum length is 32 characters. This parameter is applicable to processor card only. • ROMMONVER is a string that shows the ROMMON version and has a maximum length of 32 characters. This parameter is applicable to processor cards only. • SWREDSTATE shows software redundancy state. This parameter is applicable to processor cards only. Valid values are as follows: <ul style="list-style-type: none"> – NK - Not known – DSBL - Disabled – INIT - Initialization – SBYC - StandbyCold – SBYCC - StandbyColdConfig – SBYCF - StandbyColdFileSys – SBYCB - StandbyColdBulk – SBYH - StandbyHot – ACTF - ActiveFast – ACTD - ActiveDrain – ACTPR - ActivePreConfig – ACTPS - ActivePostConfig – ACT - Active

Section	RTRV-EQPT Description (continued)
Output Example (continued)	<ul style="list-style-type: none"> HWREDESTATE shows the hardware redundancy state. This parameter is applicable to processor cards only. Valid values are as follows: <ul style="list-style-type: none"> NP - Nonparticipant ACT - Active SBY - Standby MISS - Missing ERR - Errored <p>To retrieve inventory information for a 2.5-Gbps transponder module in slot 8:</p> <pre> SID DATE TIME M 123 COMPLD "SLOT-8:CLEI:PN=73-5656-03,SN=CAB0516HK2,OPN=N/A,HWVER=2.0, SWVER=12.1,FWVER=1.89,LASERFREQLOW=194500, LASERFREQHIGH=198500:IS-NR,," ;</pre> <p>Where:</p> <ul style="list-style-type: none"> LASERFREQLOW indicates the lower ITU grid laser frequency that this card is capable of generating. This parameter applies only to transponder cards that are capable of generating one or more laser frequencies. LASERFREQHIGH indicates the higher ITU grid laser frequency that this card is capable of generating. This parameter applies only to transponder cards that are capable of generating one or more laser frequencies.
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.51 RTRV-FFP-OCH: Retrieve Facility Protection OCH

Use this command to retrieve optical facility protection information.

Section	RTRV-FFP-OCH Description
Category	APS
Security	Retrieve
Related Messages	3.6 DLT-FFP-OCH: Delete Facility Protection OCH 3.16 ED-FFP-OCH: Edit Facility Protection 3.25 ENT-FFP-OCH: Enter Optical Protection, page 3-22

Section	RTRV-FFP-OCH Description (continued)
Input Format	<p>RTRV-FFP-OCH:[<tid>]:[<wkg_aid>],[<prot_aid>]:<ctag>:::[PROTID=<protid>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <wkg_aid> is the working access identifier. Valid values are WAVEPATCH-slot-subcard-port or TRANSPARENT-slot-subcard-0 • <prot_aid> is the protection access identifier. Valid values are WAVEPATCH-slot-subcard-port or TRANSPARENT-slot-subcard-0 • <ctag> is the correlation tag. • <protid> is the protection group identifier. It is a case-sensitive string and can have a maximum of 32 characters.
Input Example	<p>To retrieve optical facility protection information, use the following:</p> <p>RTRV-FFP-OCH:ons155xx:WAVEPATCH-2-0-0,WAVEPATCH-2-0-1:123;</p>
Output Format	<p>SID DATE TIME M CTAG COMPLD "<wkg_aid>,<prot_aid>:ACTIVE=<active>,STANDBY=<standby>, PROTID=<protid>, PSDIRN=<psdirn>, RVRTV=<rvtv>, RVRTM=<rvtm>, ENSWOTM=<enswotm>, SRCHUPMIN=<srchupmin>, SRCHUPMAX=<srchupmax>, FENDDIRN=<fenddirn>, MSGCH=<msgch>, MSGCHCUR=<msgchcur>, MSGHOLDTM=<msgholdtm>, MSGCHST=<msgchst>, MSGHOLDCOUNT=<msgholdcount>, MSGMAXTM=<msgmaxtm>:<pst>" ;</p>

Section	RTRV-FFP-OCH Description (continued)
Output Example	<p>SID DATE TIME M 123 COMPLD "WAVEPATCH-2-0-0,WAVEPATCH-2-0-1:ACTIVE=WAVEPATCH-2-0-0, STANDBY=WAVEPATCH-2-0-1,PROTID=switch1-aps,PSDIRN=BI, RVRTV=Y,RVRTM=300,ENSWOTM=10,SRCHUPMIN=2, SRCHUPMAX=32,FENDDIRN=UNI,MSGCH=AUTO,MSGCHCUR=DCC, MSGHOLDDTM=1500,MSGCHST=IS,MSGHOLDCOUNT=2, MSGMAXTM=15:IS" ; Where:</p> <ul style="list-style-type: none"> • ACTIVE indicates the AID of the currently active interface. • STANDBY indicates the AID of the interface in standby. • FENDDIRN indicates the switching mode of the remote facility. Valid values are as follows: <ul style="list-style-type: none"> – UNI - Unidirectional – BI - Bidirectional – UNKNOWN - Unknown <p> Note If switching mode of this (near end) facility, that is PSDIRN is configured as UNI, then its active switching mode will always be UNI. If PSDIRN is configured as BI, then the active switching mode is BI only if the FENDDIRN is BI. If FENDDIRN is UNI, then the active switching mode becomes UNI.</p> <ul style="list-style-type: none"> • MSGCHCUR indicates the currently used message channel. This parameter applies only when MSGCH is set to AUTO. • MSGCHST indicates if the message channel is up or down. Valid values are as follows: <ul style="list-style-type: none"> – IS - in service – OOS - out-of-service
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.52 RTRV-FILE: Retrieve File

Use this command to retrieve the contents of the configuration files.

Section	RTRV-FILE Description
Category	Memory Management
Security	Retrieve
Related Messages	3.56 RTRV-LOG: Retrieve Log 3.74 SET-ATTR-OCH: Set Attributes

Section	RTRV-FILE Description (continued)
Input Format	<p>RTRV-FILE:[<tid>]:<aid>:<ctag>:::FILENAME=<filename>,[LINES=<lines>],[OFFSET=<offset>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the memory device from which the file is to be retrieved. Valid values are BOOTFLASH, DISK-[0–1], PCMCIA-[0–1], NVRAM, SBY-NVRAM, SBY-BOOTFLASH, SBY-DISK-[0–1], or SBY-PCMCIA-[0–1]. • <ctag> is the correlation tag. • <filename> is a string that shows the name of the configuration file whose contents are to be retrieved. The maximum string length is 255 characters. • <lines> is an optional parameter. It is an integer value that indicates the number of lines to retrieve at a time. If this parameter is not configured, the entire file is retrieved as is. • <offset> is an optional parameter. It is an integer value that indicates the offset within a file. The contents of the file starting at this offset is retrieved. The default value is zero, which means that the contents from the beginning of the file are retrieved.
Input Example	<p>To retrieve the contents of the configuration files, use the following:</p> <pre>RTRV-FILE:ons155xx::123:::FILENAME=running-config,LINES=24;</pre>
Output Format	<pre>SID DATE TIME M CTAG COMPLD "<text>" ;</pre>

Section	RTRV-FILE Description (continued)
Output Example	<pre> SID DATE TIME M 123 COMPLD "version 12.1 no service pad service timestamps debug uptime service timestamps log uptime no service password-encryption service internal service compress-config ! hostname snmp-man ! boot system bootflash:ons15540-i-mz.tirth redundancy keepalive-threshold 12 associate group bb associate group aa aps working Transparent8/0/0 aps protection Transparent8/1/0 aps y-cable aps enable aps timer switchover min-interval 20 enable password lab ! ! threshold-list abc" ;</pre>
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.53 RTRV-HDR: Retrieve Header

Use this command to request that an NE simply reply with a normal response indicating COMPLD.

The information of interest in the reply is the reply itself, along with information that the NE has about itself, specifically <source_identifier>, <date>, and <time>.

Section	RTRV-HDR Description
Category	Generic NE configuration
Security	Retrieve
Related Messages	3.15 ED-DAT: Edit Date, page 3-11 3.72 RTRV-TOD: Retrieve Time of Day, page 3-74
Input Format	RTRV-HDR:[<tid>]::<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag.

Section	RTRV-HDR Description (continued)
Output Format	SID DATE TIME M CTAG COMPLD ;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.54 RTRV-IP: Retrieve IP

Use this command to retrieve IP configurations.

Section	RTRV-IP Description
Category	IP configuration
Security	Retrieve
Related Messages	3.7 DLT-IP: Delete IP 3.8 DLT-IPROUTE-STATIC: Delete IP Route Static 3.17 ED-IP: Edit IP 3.26 ENT-IP: Enter IP 3.55 RTRV-IPROUTE: Retrieve IP Route
Input Format	RTRV-IP:[<tid>]:[<aid>]:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. • <ctag> is the correlation tag.
Input Example	To retrieve IP configurations, use the following: RTRV-IP:ons155xx:FE-0:123;
Output Format	SID DATE TIME M CTAG COMPLD "<aid>:IPADDRTYPE=<ipaddrtype>,IPADDR=<ipaddr>, IPMASK=<ipmask>" ;
Output Example	SID DATE TIME M 123 COMPLD "FE-0:IPADDRTYPE=ADDR,IPADDR=172.16.42.110, IPMASK=255.255.255.0" ;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.55 RTRV-IPROUTE: Retrieve IP Route

Use this command to retrieve IP routing information.

Section	RTRV-IPROUTE Description
Category	IP configuration
Security	Retrieve
Related Messages	3.8 DLT-IPROUTE-STATIC: Delete IP Route Static 3.17 ED-IP: Edit IP 3.26 ENT-IP: Enter IP
Input Format	RTRV-IPROUTE:[<tid>]::<ctag>:::ROUTETYPE=<routetype>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <routetype> indicates if the route is a static route or is learned dynamically from a routing protocol. Valid values are STATIC and DYNAMIC. The only value currently supported is STATIC.
Input Example	To retrieve IP routing information, use the following: RTRV-IPROUTE:ons155xx::123:::ROUTETYPE=STATIC;
Output Format	SID DATE TIME M CTAG COMPLD "ROUTETYPE=<routetype>,PREFIXADDR=<prefixaddr>, PREFIXMASK=<prefixmask>,ROUTEIF=<routeif>" ;
Output Example	SID DATE TIME M 123 COMPLD "ROUTETYPE=STATIC,PREFIXADDR=10.1.0.0, PREFIXMASK=255.255.0.0, ROUTEIF=WAVE-0-0" ;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.56 RTRV-LOG: Retrieve Log

Use this command to retrieve the console buffer log on the NE.

Section	RTRV-LOG Description
Category	Alarms and faults
Security	Retrieve

Section	RTRV-LOG Description (continued)
Related Messages	<p>3.2 ALW-MSG-ALL: Allow Message All, page 3-2</p> <p>3.3 ALW-Swdx-EQPT: Allow Switch Duplex Equipment, page 3-2</p> <p>3.34 INH-MSG-ALL: Inhibit Message All, page 3-32</p> <p>3.35 INH-Swdx-EQPT: Inhibit Switch Duplex Equipment, page 3-33</p> <p>3.45 RTRV-ALM-ALL: Retrieve Alarms All, page 3-39</p> <p>3.46 RTRV-ALM-ENV: Retrieve Alarms Environmental, page 3-40</p>
Input Format	<p>RTRV-LOG:[<tid>]::<ctag>::[<lognm>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <lognm> specifies the name of the log to be retrieved. Only the value SYSLOG is currently supported. The default is SYSLOG.
Input Example	To retrieve the console buffer log on the NE, use the following: RTRV-LOG:ons155xx::123::;
Output Format	<p>SID DATE TIME M CTAG COMPLD "<text>" ; /* RTRV-LOG */</p>
Output Example	<p>SID DATE TIME M 123 COMPLD "SYSLOG::00:00:23: %LINK-3-UPDOWN: Interface Transparent7/0/0, changed state to down" "SYSLOG::00:00:24: %LINEPROTO-5-UPDOWN: Line protocol on Interface Transparent7/0/0, changed state to down" "SYSLOG::00:00:38: %LCMDC-3-MIB_ICDRLK_ALM: Ingress CDR Locking error CLEAR MAJOR Tran7/0/0" ; /* RTRV-LOG */</p>
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.57 RTRV-MEM: Retrieve Memory

Use this command to retrieve information on all the files that are present on the Flash device.

Section	RTRV-MEM Description
Category	Memory Management
Security	Retrieve

Section	RTRV-MEM Description (continued)
Related Messages	<p>3.9 DLT-MEM: Delete Memory</p> <p>3.5 CPY-MEM: Copy Memory</p> <p>3.43 RST-MEM: Restore Memory</p> <p>3.79 SQUEEZE-MEM: Squeeze Memory</p>
Input Format	<p>RTRV-MEM:[<tid>]:[<aid>]:<ctag>:::[FILENAME=<file>],[STATUS=<status>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the memory device from which the file is being retrieved. Valid values are BOOTFLASH, DISK-[0-1], PCMCIA-[0-1], NVRAM, SBY-NVRAM, SBY-BOOTFLASH, SBY-DISK-[0-1], or SBY-PCMCIA-[0-1]. • <ctag> is the correlation tag. • <file> specifies a filename. This is a string with a maximum of 255 characters. • <status> filters the files that are retrieved. Valid values are ACTIVE, DELETED, or ALL. ACTIVE refers to all the files that are currently undeleted. DELETED refers to files that have been marked deleted. ALL is used to retrieves all files. The default value is ALL.
Input Example	<p>To retrieve information on all the files that are present on the Flash device, use the following:</p> <p>RTRV-MEM:ons155xx:DISK-0:123;</p>
Output Format	<p>SID DATE TIME M CTAG COMPLD "<aid>:INDEX=<index>,ACCESS=<access>,SIZE=<size>,DATE=<date>, TIME=<time>,FILENAME=<filename>,STATUS=<status>" ; ;</p>
Output Example	<p>SID DATE TIME M 123 COMPLD "BOOTFLASH:INDEX=1,ACCESS=RW,SIZE=145678,DATE=12-115.01, TIME=10-22-00,FILENAME=ons15540-i-mz,STATUS=ACTIVE" "BOOTFLASH:INDEX=2,ACCESS=RW,SIZE=146140,DATE=12-115.01, TIME=13-10-00,FILENAME=ons15540-i-mz.temp,STATUS=DELETED" ; ;</p> <p>Where:</p> <ul style="list-style-type: none"> • INDEX shows the index number associated with the deleted file. • ACCESS shows the permissions on that file. Valid values are RW (read/write) and RO (read-only). • SIZE shows the size of the file in bytes. • DATE is the string that shows the date of the file. The format is MM-DD-YY. • TIME is the string that shows the time on the file. The format is HH-MM-SS. • NAME is the string that shows the name of the file. The maximum length is 255 characters.
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.58 RTRV-NBR: Retrieve Neighbor

Use this command to retrieve the neighbor information on port(s).

If the AID value is not provided, then information about all the neighbors discovered (for all of the ports) is retrieved.

Section	RTRV-NBR Description
Category	Topology neighbor configuration
Security	Retrieve
Related Messages	3.10 DLT-NBR: Delete Neighbor 3.28 ENT-NBR: Enter Neighbor
Input Format	RTRV-NBR:[<tid>]:[<aid>]:<ctag>; <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> identifies the interface and can be one of the following: <ul style="list-style-type: none"> – TRANSPARENT-slot-subcard-0 – WDM-slot-subcard • <ctag> is the correlation tag.
Input Example	To retrieve the neighbor information on ports, use the following: RTRV-NBR:ons155xx:WDM-0-0:123;
Output Format	SID DATE TIME M CTAG COMPLD "<aid>:DSCVRY=<dscrvy>,LINKDIRN=<linkdirn>,NBRNAME=<nbrname>, NBRPORT=<nbrport>,NBRAGENTIP=<nbragentip>" ;
Output Example	SID DATE TIME M 123 COMPLD "WDM-0-0:DSCVRY=MANUAL,LINKDIRN=RX, NBRNAME=shelf2,NBRPORT=WDM-0-0, NBRAGENTIP=172.16.20.1" "WDM-0-0:DSCVRY=MANUAL,LINKDIRN=TX, NBRNAME=edfa_box1,NBRPORT=in_port, NBRAGENTIP=172.16.20.9" ;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.59 RTRV-NE-CDP: Retrieve Network Element CDP

Use this command to retrieve global CDP information.

Section	RTRV-NE-CDP Description
Category	CDP
Security	Retrieve
Related Messages	3.18 ED-NE-CDP: Edit Network Element CDP, page 3-14

Section	RTRV-NE-CDP Description (continued)
Input Format	RTRV-NE-CDP:[<tid>]::<ctag>; Where: <ul style="list-style-type: none">• <tid> is the target identifier.• <ctag> is the correlation tag.
Input Example	To retrieve global CDP information, use the following: RTRV-NE-CDP:ons155xx::123;
Output Format	SID DATE TIME M CTAG COMPLD "CDP=<cdp>,UPDATETIME=<updatetime>,HOLDTIME=<holdtime>,SENDVER=<sendver>" ;
Output Example	SID DATE TIME M 123 COMPLD "CDP=Y,UPDATETIME=60,HOLDTIME=180,SENDVER=2" ;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.60 RTRV-NE-GEN: Retrieve Generic NE Configuration Values

Use this command to retrieve generic NE configuration values.

Section	RTRV-NE-GEN Description
Category	Generic NE configuration
Security	Retrieve
Related Messages	3.19 ED-NE-GEN: Edit Network Element General, page 3-15
Input Format	RTRV-NE-GEN:[<tid>]::<ctag>; Where: <ul style="list-style-type: none">• <tid> is the target identifier.• <ctag> is the correlation tag.
Input Example	To retrieve generic NE configuration values, use the following: RTRV-NE-GEN:ons155xx::123;
Output Format	SID DATE TIME M CTAG COMPLD "CURCFGREG=<curcfgreg>,NEWCFGREG=<newcfgreg>,SWVER=<swver>,SWNAME=<swname>,SYSFILE=<sysfile>,CMPLTIME=<cmptime>,CMPLBY=<cmplby>,BOOTLDR=<bootldr>" ;

Section	RTRV-NE-GEN Description (continued)
Output Example	<p>SID DATE TIME</p> <p>M 123 COMPLD</p> <p>"CURCFGREG=0x0,NEWCFGREG=0x2,SWVER=12.1, SWNAME=ONS15540-I-M, SYSFILE=bootflash:ons15540-i-mz, CMPLTIME=01-10-11-19-33,CMPLBY=hqluong" ;</p> <p>Where:</p> <ul style="list-style-type: none"> • CURCFGREG shows the current configuration register setting in hexadecimal. • NEWCFGREG shows the new (the value that takes effect on next reload) configuration register setting in hexadecimal. • SWVER indicates the software version; maximum length is 32 characters • SWNAME indicates the name of the software image, maximum length is 64 characters. • SYSFILE indicates the system image file; maximum length is 255 characters. • CMPLTIME indicates the compiled time. The format of this string is YY-MM-DD-HH-MM. • CMPLBY indicates the username of person who compiled this software image; maximum length is 8 characters.
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.61 RTRV-NE-OSCP: Retrieve Network Element OSCP

Use this command to retrieve the configurations for OSCP.

Section	RTRV-NE-OSCP Description
Category	OSCP
Security	Retrieve
Related Messages	3.20 ED-NE-OSCP: Edit Network Element OSCP
Input Format	<p>RTRV-NE-OSCP:[<tid>]::<ctag>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag.
Input Example	To retrieve the configurations for OSCP, use the following: RTRV-NE-OSCP:ons155xx::123;
Output Format	<p>SID DATE TIME</p> <p>M CTAG COMPLD</p> <p>"HELLOINTV=<hellointv>,HELLOHLDWN=<hellohldwn>, INACTFCTR=<inactfctr>"</p> <p>;</p>

Section	RTRV-NE-OSCP Description (continued)
Output Example	SID DATE TIME M 123 COMPLD "HELLOINTV=500,HELLOHLDWN=200,INACTFCTR=10" ;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.62 RTRV-NTP: Retrieve NTP

Use this command to retrieve the NTP status parameters for the system.

Section	RTRV-NTP Description
Category	NTP
Security	Retrieve
Related Messages	3.11 DLT-NTPASSOC: Delete NTP Associations 3.29 ENT-NTPASSOC: Enter NTP Associations
Input Format	RTRV-NTP:[<tid>]::<ctag>; Where: <ul style="list-style-type: none">• <tid> is the target identifier.• <ctag> is the correlation tag.
Output Format	SID DATE TIME M CTAG COMPLD "SYNCSTATE=<syncstate>,STRATUM=<stratum>, REFIPADDR=<refipaddr>,NOMFREQ=<nomfreq>,ACTFREQ=<actfreq>, PRECISION=<precision>,REFTIME=<reftime>,CLKOFFSET=<clkoffset>, ROOTDELAY=<rootdelay>,ROOTDISP=<rootdisp>,PEERDISP=<peerdisp>" ;

Section	RTRV-NTP Description (continued)
Output Example	<p>SID DATE TIME</p> <p>M 123 COMPLD</p> <p>"SYNCSTATE=Y,STRATUM=4,REFIPADDR=172.16.246.1,NOMFREQ=250, ACTFREQ=249.9999,PRECISION=24, REFTIME=09:09:38.885PSTSunDec302001, CLKOFFSET=7.7674,ROOTDELAY=113.39,ROOTDISP=386.72, PEERDISP=1.57"</p> <p>;</p> <p>Where:</p> <ul style="list-style-type: none"> • SYNCSTATE indicates whether clock is synchronized. Valid values are Y or N. • STRATUM indicates the stratum of the reference clock. This is an integer value from 1 to 16. • REFIPADDR indicates the IP address of the peer/server from where the reference clock is being derived. • NOMFREQ shows the nominal frequency in Hz. • ACTFREQ shows the actual frequency in Hz. • PRECISION indicates the precision of the derived clock. If the value specified here is x, the actual precision is of the form 2^x. • REFTIME indicates the clock reference time. • CLKOFFSET shows the clock offset in msec. • ROOTDELAY shows a string value that shows the root delay in msec. • ROOTDISP shows the root dispersion in msec. • PEERDISP shows the peer dispersion in msec.
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.63 RTRV-NTPASSOC: Retrieve NTP Associations

Use this command to retrieve the NTP parameters for each association that is created.

Section	RTRV-NTPASSOC Description
Category	NTP
Security	Retrieve
Related Messages	3.11 DLT-NTPASSOC: Delete NTP Associations 3.29 ENT-NTPASSOC: Enter NTP Associations 3.62 RTRV-NTP: Retrieve NTP
Input Format	<p>RTRV-NTPASSOC:[<tid>]::<ctag>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag.

Section	RTRV-NTPASSOC Description (continued)
Output Format	<pre> SID DATE TIME M CTAG COMPLD "ASSOCTYPE=<assotype>,ASSOCIPADDR=<associpaddr>, ASSOCSTRATUM=<assocstratum>,ASSOCREFID=<assocrefid>, ASSOCPOLL=<assocpoll>,ASSOCREACH=<assocreach>, ASSOCDELAY=<assocdelay>,ASSOCOFFSET=<assocoffset>, ASSOCDISP=<assocdisp>" ;</pre>
Output Example	<pre> SID DATE TIME M 123 COMPLD "ASSOCTYPE=SERVER,ASSOCIPADDR=172.16.246.1, ASSOCSTRATUM=2,ASSOCREFID=172.16.10.80,ASSOCPOLL=64, ASSOCREACH=377,ASSOCDELAY=1.4,ASSOCOFFSET=-23005, ASSOCDISP=4925" ;</pre> <p>Where:</p> <ul style="list-style-type: none"> ASSOCTYPE shows the association type. The values are SERVER and PEER. ASSOCIPADDR shows the IP address of the server or peer. ASSOCSTRATUM the stratum of the peer's clock, is an integer value from 1 to 16. ASSOCREFID indicates the reference ID of the peer is an IP address ASSOCPOLL indicates the interval at which the local host polls the peer. This is an integer value in seconds. ASSOCREACH indicates the reachability status of the peer. This is an integer value from 0 to 255. ASSOCDELAY shows the estimated round-trip delay of the peer clock with reference to the local clock, in seconds. ASSOCOFFSET shows the estimated offset of the peer clock with reference to the local clock, in seconds. ASSOCDISP shows the estimated error between the peer clock and the local clock, in seconds.
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.64 RTRV-OCH: Retrieve Optical Channel

Use this command to retrieve interface configuration information.

The PST and SST values in the last position defined block indicate the current status of the interface. The values of PST-PSTQ and SST, under different conditions, are listed as follows:

- If the interface is administratively shut down by using the ENT-OCH command, values returned are PST=OOS-MA, SST=MT.
- If the interface and the laser are shut down administratively, values returned are PST=OOS_MA, SST=MT, LASER.

- If the interface is down because of alarms on the link, such as Loss of Signal/Loss of Frame, Loss of Light, values returned are PST=OOS-AU, SST=FAF.
- If the interface is down because of alarms and is also administratively shut down, values returned are PST=OOS-AUMA, SST=FAF, MT.
- If there is an entity failure on the NE because the interface is down, values returned are PST=OOS-AU, SST=SGEO.
- If the transmit laser fails at an interface, values returned is PST=OOS-AU, SST=FLT.
- If only thresholds are exceeded on the interface, values returned are PST=IS-ANR. For wavepatch interfaces only, the SST value also indicates the current state with respect to APS of the interface.
- If the wavepatch is currently active, the SST value of ACT is returned.
- If the wavepatch is currently standby, the value of STBYH is returned.
- Under normal operating conditions, values returned are PST=IS-NR.

Section	RTRV-OCH Description
Category	Transparent interface configuration
Security	Retrieve
Related Messages	3.21 ED-OCH: Edit Optical Channel 3.39 OPR-LPBK-OCH: Operate Loopback OCH 3.64 RTRV-OCH: Retrieve Optical Channel 3.64 RTRV-OCH: Retrieve Optical Channel
Input Format	<p>RTRV-OCH:[<tid>]:[<aid>]:<ctag></p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <AID> indicates the interface that is being configured. Valid values are TRANSPARENT-slot-subcard-0, WAVE-slot-subcard, WAVEPATCH-slot-subcard-port, or ETHERDCC-slot-subcard-port. • <ctag> is the correlation tag.
Input Example	To retrieve interface configuration information, use the following: RTRV-OCH:ons155xx:TRANSPARENT-10-0-0:123; RTRV-OCH:ons155xx:WAVE-8-0:123;
Output Format	<p>SID DATE TIME M CTAG COMPLD "<aid>:THRLISTNAME=<thrlistname>,FLC=<flc>,LSC=<lsc>, LASERFREQ=<laserfreq>,LPBKTYPE=<lpbktype>:<pst>" ;"</p>

Section	RTRV-OCH Description (continued)
Output Example	<pre> SID DATE TIME M 123 COMPLD "TRANSPARENT-10-0-0:ENCAP=OC3,THRLISTNAME=sonet-cvs, FLC=N,LPBKTYPE=FACILITY:IS-NR" ; SID DATE TIME M 123 COMPLD "WAVE-8-0:THRLISTNAME=sonet-cvs,FLC=N,LSC=Y, LASERFREQ=159800, LPBKTYPE=FACILITY:IS-NR" ; </pre> <p>Where:</p> <ul style="list-style-type: none"> • LASERFREQ can be retrieved only on the AID WAVE-slot-subcard. • LPBKTYPE indicates the type of loopback on the interface. Valid values are as follows: <ul style="list-style-type: none"> – FACILITY - where the signal from the receive input is looped back to the transmit output. – TERMINAL - where the signal bound for transmit output is looped back to the receive input. This is an internal loopback and it is used for hardware debug and diagnostics.
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.65 RTRV-PATCH: Retrieve Patch

Use this command to retrieve the patch configuration.

Section	RTRV-PATCH Description
Category	Patch configuration
Security	Retrieve
Related Messages	3.12 DLT-PATCH: Delete Patch 3.30 ENT-PATCH: Enter Patch

Section	RTRV-PATCH Description (continued)
Input Format	<p>RTRV-PATCH:[<tid>]:[<from_aid>],[<to_aid>]:<ctag>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <from_aid> identifies the port patched to the port identified by <to_aid>. Valid values for <from_aid> are as follows: <ul style="list-style-type: none"> – FILTER-slot-subcard-0 – OSCFILTER-slot-subcard – THRU-slot-subcard – WAVE-slot – WAVEPATCH-slot-subcard-port – WDM-slot-subcard • <to_aid> identifies the port patched from the port identified by <from_aid>. Valid values for <to_aid> are as follows: <ul style="list-style-type: none"> – FILTER-slot-subcard-0 – OSCFILTER-slot-subcard – THRU-slot-subcard – WAVE-slot – WAVEPATCH-slot-subcard-port – WDM-slot-subcard • <ctag> is the correlation tag. <p> Note If the AID value is not provided then information for all the patches is retrieved. If both the AIDs are specified, all the patches associated with the specified AIDs is retrieved.</p>
Input Example	To retrieve the patch configuration, use the following: RTRV-PATCH:ons155xx::123;
Output Format	<p>SID DATE TIME M CTAG COMPLD "<from_aid>,<to_aid>:<dirn>" ;</p>
Output Example	<p>SID DATE TIME M 123 COMPLD "WAVEPATCH-2-0-0,FILTER-0-0-0:2WAY" "WDM-0-0,THRU-0-0:2WAY" ;</p>
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.66 RTRV-PM-ENCAP: Retrieve Performance Encapsulation

Use this command to retrieve the performance monitoring parameters related to error counters for transponder and OSC wave interfaces specified by the AID. The parameter is specified by <montype> and the <tmper> specifies the accumulation time period.

Section	RTRV-PM-ENCAP Description
Category	Transparent interface configuration
Security	Retrieve
Related Messages	3.21 ED-OCH: Edit Optical Channel
Input Format	<p>RTRV-PM-ENCAP:[<tid>]:[<aid>]:<ctag>:::<montype>],...,[<tmper>], [<mondat>],[<montm>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates transparent interface or wave interface for which performance monitor data is being retrieved. Valid values are TRANSPARENT-slot-subcard-0, WAVE-slot-subcard, or WAVE-slot. • <ctag> is the correlation tag. • <montype> is monitored parameter type. Valid values are as follows: <ul style="list-style-type: none"> – FC - Indicates the number of times signal failure threshold was exceeded on an interface. – DC - Indicates the number of times signal degrade threshold was exceeded on an interface. – PSC - Shows protection switch count (for APS) on the AID. – ESS - Errorred Second count (Section). – SEFS-S - Severely errored framing seconds count. – SESS - Severely errored second count. – CVRD - Coding violations and running disparity errors. – CDLHEC - CDL header error count. This parameter applies to the OSC WAVE-slot AIDs only. <p>The default is all montypes.</p> <ul style="list-style-type: none"> • <tmper> is the time period for the counts. Valid values are 15-MIN, 24-HR, or TOTAL. The 15-MIN and 24-HR counts are reported only for the SONET-related counters CVS, ESS, SEFS-S, and SESS. For all other counters, only TOTAL counts are reported. • <mondat> is the day the AID was monitored. The format is YY-MM-DD. • <montm> is the time the AID was monitored. The format is HH:SS.
Input Example	To retrieve the performance monitoring parameters for the transparent interface in slot 2, subcard 0, use the following: RTRV-PM-ENCAP:ons155xx:TRANSPARENT-2-0-0:123;

Section	RTRV-PM-ENCAP Description (continued)
Output Format	<p>SID DATE TIME M CTAG COMPLD "<aid>:<error>,<count>,COMPL,,<interval>" ; </p>
Output Example	<p>SID DATE TIME M 123 COMPLD "TRANSPARENT-2-0-0,OC3:CVS,153,COMPL,,15-MIN" "TRANSPARENT-2-0-0,OC3:FC,0,COMPL,,TOTAL" "TRANSPARENT-2-0-0,OC3:DC,5,COMPL,,TOTAL" "TRANSPARENT-2-0-0,OC3:PSC,6,COMPL,,TOTAL" ; Where:<ul style="list-style-type: none"> • FC is the number of times signal failure threshold was exceeded on an interface. • DC is the number of times signal degrade threshold was exceeded on an interface. • PSC is the protection switch count (for APS) on the interface.  Note Valid values for the time period for this command include 15-MIN, 24-HR and TOTAL. The 15-MIN and 24-HR counts are reported only for SONET related counters. That is CVS, ESS, SEFS-S, SESS. For all other counters, only TOTAL counts is reported. </p>
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.67 RTRV-PM-EQPT: Retrieve Performance Monitoring Equipment

Use this command to retrieve performance monitoring data for a processor card.

Section	RTRV-PM-EQPT Description
Category	Redundancy Configuration
Security	Retrieve
Related Messages	3.36 INIT-REG-ETH: Initialize Register Ethernet, page 3-33
Input Format	<p>RTRV-PM-EQPT:[<tid>]:[<aid>]:<ctag>; Where:<ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. Valid values is SLOT-6 or SLOT-7. • <ctag> is the correlation tag. </p>
Input Example	<p>To retrieve performance monitoring parameters for the processor card in slot 6, use the following: RTRV-PM-EQPT:ons155xx:SLOT-6:123;</p>

Section	RTRV-PM-EQPT Description (continued)
Output Format	<p>SID DATE TIME M CTAG COMPLD "<aid>:<montype>,<date>,,,<interval>" ;</p>
Output Example	<p>SID DATE TIME M 123 COMPLD "SLOT-6:SWCT,1,,," "SLOT-6:SWTM,0,,,01-10-11-19-33" "SLOT-6:AVAILUPTM,0,,,00-00-03-04-35" "SLOT-6:INITM,0,,,00-00-00-22-33" "SLOT-6:RCSYNCTM,0,,,00-00-00-02-18" "SLOT-6:SCSYNCTM,0,,,00-00-00-06-01" ; /* RTRV-PM-EQPT */</p> <p>Where:</p> <ul style="list-style-type: none"> • SWCT is an integer and shows switchover counts. • SWTM is a string and shows the last switchover time in YY-MM-DD-HH-MM. • AVAILUPTM shows available uptime such as time since the last event when the entire system was down. The format is YY-MM-DD-HH-MM. • INITM shows the time since this module was initialized. The format is YY-MM-DD-HH-MM. • RCSYNCTM shows the time since last running-config sync. The format is YY-MM-DD-HH-MM. • SCSYNCTM shows the time since the last startup-config sync. The format is YY-MM-DD-HH-MM.
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.68 RTRV-PMMODE-OCH: Retrieve Performance Mode OCH

Use this command to retrieve the configuration for performance monitoring.

Section	RTRV-PMMODE-OCH Description
Category	Transparent interface configuration
Security	Retrieve
Related Messages	3.76 SET-PMMODE-OCH: Set Performance Mode OCH
Input Format	<p>RTRV-PMMODE-OCH:[<tid>]:[<aid>]:<ctag>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. The value is TRANSPARENT-slot-subcard-0. • <ctag> is the correlation tag.

Section	RTRV-PMMODE-OCH Description (continued)
Input Example	To retrieve the configuration for performance monitoring, use the following: RTRV-PMMODE-OCH:ons155xx:TRANSPARENT-10-0-0:123;
Output Format	SID DATE TIME M CTAG COMPLD " <aid>:,<pmmode>" ; SID DATE TIME M 123 COMPLD "TRANSPARENT-10-0-0:,,ON" ;
Output Example	
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.69 RTRV-PM-OCH: Retrieve Performance Monitoring

Use this command to retrieve the performance monitoring information for optical parameters on a transponder module specified by the AID. The parameter is specified by <motype> and <tper> specifies the accumulation time period.



Note

The value returned for all optical power related motype parameters is in the range of -40 to 25 dBm. The value returned for all laser bias current related motype parameters is in hundreds of microamperes and has a range from 0 to 10000. The value returned for all laser temperature related motype parameters is in tenths of degrees centigrade and has a range from -500 to 850.

Section	RTRV-PM-OCH Description
Category	Optical Parameter Monitoring
Security	Retrieve
Related Messages	3.67 RTRV-PM-EQPT: Retrieve Performance Monitoring Equipment 3.66 RTRV-PM-ENCAP: Retrieve Performance Encapsulation

Section	RTRV-PM-OCH Description (continued)
Input Format	<p>RTRV-PM-OCH:[<tid>]:[<aid>]:<ctag>::[<montype>],[<monlev>],,[<dirn>], [<tmper>],[<mondat>],[<montm>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. Valid values are WAVE-slot-subcard or WAVEPATCH-slot-subcard-port. • <ctag> is the correlation tag. • <montype> is the performance monitoring parameter. Valid values are as follows: <ul style="list-style-type: none"> – OPR indicates the current value of the received optical power level. – OPRMIN indicates the minimum value of the received optical power level during a particular interval. – OPRMAX indicates the maximum value of the received optical power level during a particular interval. – OPRAVG indicates the average value of the received optical power level during a particular interval. • <monlev> is the level for the performance monitoring parameter. Valid values are n-UP and n-DN, where n is a decimal number indicating the number of levels in the desired direction. • <dirn> is the direction. Valid values are RCV or TRMT. • <tmper> is the time period for the counts. Valid values are 15-MIN, 24-HR, or TOTAL. The 15-MIN and 24-HR counts are reported only for the SONET-related counters CVS, ESS, SEFS-S, and SESS. For all other counters, only TOTAL counts are reported. • <mond> is the day the AID was monitored. The format is YY-MM-DD. • <montm> is the time the AID was monitored. The format is HH:SS.
Input Example	To retrieve the performance monitor information for the optical parameters monitored on the wavepatch interface in slot 8, subcard 0, port 0, use the following: RTRV-PM-OCH:ons155xx:WAVEPATCH-8-0-0:123;
Output Format	<p>SID DATE TIME M CTAG COMPLD "<aid>:<montype>,<value>,COMPL,,<dirn>,<interval>,<date>,<time>" ;"</p>

Section	RTRV-PM-OCH Description (continued)
Output Example	<p>SID DATE TIME M 123 COMPLD "WAVEPATCH-8-0-0:OPR,11.0,COMPL,,RCV,CURRENT" "WAVEPATCH-8-0-0:OPRMIN,5.0,COMPL,,RCV,15-MIN,05-09,22-45" "WAVEPATCH-8-0-0:OPRMAX,15.0,COMPL,,RCV,15-MIN,05-09,22-45" "WAVEPATCH-8-0-0:OPRAVG,10.0,COMPL,,RCV,15-MIN,05-09,22-45" ; Where:<ul style="list-style-type: none"> • OPR indicates the current value of the received optical power level. • OPRMIN indicates the minimum value of the received optical power level during a particular interval. • OPRMAX indicates the maximum value of the received optical power level during a particular interval. OPRAVG indicates the average value of the received optical power level during a particular interval.</p>
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.70 RTRV-THR-OCH: Retrieve Thresholds OCH

Use this command to retrieve the configurations for thresholds. The complete threshold list or specific thresholds within the list can be retrieved.



Note

When retrieving a particular threshold from a list, both the ERRTYPE and THRTYPE parameters, along with the THRLISTNAME, must be specified.

Section	RTRV-THR-OCH Description
Category	Threshold list configuration
Security	Retrieve
Related Messages	3.13 DLT-THR-OCH: Delete Threshold OCH 3.31 ENT-THR-OCH: Enter Thresholds OCH 3.71 RTRV-TH-rr: Retrieve Threshold 3.78 SET-TH-OCH: Set Optical Threshold

Section	RTRV-THR-OCH Description (continued)
Input Format	<p>RTRV-THR-OCH:[<tid>]:[<thrlistname>]:<ctag>:::[ERRTYPE=<errtype>, THRTYPE=<thrtype>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <thrlistname> specifies the threshold list. • <ctag> is the correlation tag. • <errtype> indicates the type of error counter to which the threshold applies. Valid values are as follows: <ul style="list-style-type: none"> – CVS - SONET/SDH section CV errors – CVRD - 8B/10B code violations and running disparity errors – CDLHEC - CDL HEC errors – CRC - Cyclic redundancy check errors • <thrtype> indicates the threshold type. Valid values are as follows: <ul style="list-style-type: none"> – DEGR - Indicates that a signal degrade condition has been reached. Use this threshold type only when <errtype> is CVS. – FAIL - Indicates that a signal failure condition has been reached. Use this threshold type only when <errtype> is CVS. – EVTTHR - Indicates that a non-service affecting condition has been reached. Use this threshold type only when <errtype> is not CVS. – ALMTHR - Indicates that a service affecting condition has been reached. Use this threshold type only when <errtype> is not CVS.
Input Example	To retrieve the configurations for thresholds, use the following: RTRV-THR-OCH:ons155xx:sonet-cvs:123;
Output Format	<p>SID DATE TIME M CTAG COMPLD "<thrlistname>:ERRTYPE=<errtype>,THRTYPE=<thrtype>,VALUE=<value> , INDEX=<index>,TRGAPS=<trgaps>,DESCR=<descr>" ;</p>
Output Example	<p>SID DATE TIME M 123 COMPLD "sonet-cvs:ERRTYPE=CVS,THRTYPE=DEGR,VALUE=7,INDEX=1, TRGAPS=Y,DESCR=xxx" ;</p>
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.71 RTRV-TH-rr: Retrieve Threshold

Use this command to retrieve the optical power threshold values configured on the wavepatch interfaces.

Section	RTRV-TH-OCH Description
Category	Optical Parameter Monitoring
Security	Retrieve
Related Messages	3.23 ED-THR-OCH: Edit Thresholds OCH 3.78 SET-TH-OCH: Set Optical Threshold
Input Format	<p>RTRV-TH-OCH:[<tid>]:[<aid>]:<ctag>:::<montype>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. The valid values are WAVEPATCH-slot-subcard-port. • <ctag> is the correlation tag. • <montype> is the performance monitoring parameter. Valid values are as follows: <ul style="list-style-type: none"> – OPR indicates the current value of the received optical power level. – OPRMIN indicates the minimum value of the received optical power level during a particular interval. – OPRMAX indicates the maximum value of the received optical power level during a particular interval. – OPRAVG indicates the average value of the received optical power level during a particular interval.
Input Example	<p>To retrieve the threshold values configured on the wavepatch interfaces, use the following:</p> <p>RTRV-TH-OCH:ons155xx:WAVEPATCH-8-0-0:123::OPRHA;</p>
Output Format	<p>SID DATE TIME M CTAG COMPLD "<aid>:<montype>,,<dirn>,<value>" ;</p>
Output Example	<p>SID DATE TIME M 123 COMPLD "WAVEPATCH-8-0-0:OPRHA,,RCV,200" ;</p>
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.72 RTRV-TOD: Retrieve Time of Day

Use this command to retrieve time-of-day (TOD) information for the NE.

Section	RTRV-TOD Description
Category	Generic NE configuration
Security	Retrieve
Related Messages	3.15 ED-DAT: Edit Date
Input Format	<p>RTRV-TOD:[<tid>]::<ctag>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag.
Input Example	<p>To retrieve TOD information for the NE, use the following:</p> <p>RTRV-TOD:ons155xx::123;</p>
Output Format	<p>SID DATE TIME M CTAG COMPLD "<year>,<month>,<day>,<hour>,<minute>, <second>.<thousandths-of-second>,<timezone>" ;</p>
Output Example	<p>SID 2003-02-11 13:30:51 M 123 COMPLD "2003,2,11,13,30,51.879,UTC" ;</p>
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.73 RTRV-USER-SECU: Retrieve User Security

Use this command to retrieve the security parameters associated with a user, except for the password.

Section	RTRV-USER-SECU Description
Category	Security
Security	Retrieve
Related Messages	3.1 ACT-USER: Activate User 3.4 CANC-USER: Cancel User 3.14 DLT-USER-SECU: Delete User Security 3.24 ED-USER-SECU: Edit User Security 3.32 ENT-USER-SECU: Enter User Security

Section	RTRV-USER-SECU Description (continued)
Input Format	RTRV-USER-SECU:[<tid>]:<uid>:<ctag>; Where: <ul style="list-style-type: none">• <tid> is the target identifier.• <uid> is the user identifier.• <ctag> is the correlation tag.
Input Example	To retrieve the security parameters associated with a user, use the following: RTRV-USER-SECU:ons155xx:admin:123;
Output Format	SID DATE TIME M CTAG COMPLD "<uid>:<security>:" ;
Output Example	SID DATE TIME M 123 COMPLD "admin:,PROV:" ;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.74 SET-ATTR-OCH: Set Attributes

Use this command to set the severity associated with the thresholds configured using the SET-TH-OCH command described in the “[3.78 SET-TH-OCH: Set Optical Threshold](#)” section on page 3-78.

Section	SET-ATTR-OCH Description
Category	Optical Parameter Monitoring
Security	Retrieve
Related Messages	3.64 RTRV-OCH: Retrieve Optical Channel 3.71 RTRV-TH-rr: Retrieve Threshold 3.70 RTRV-THR-OCH: Retrieve Thresholds OCH 3.78 SET-TH-OCH: Set Optical Threshold

Section	SET-ATTR-OCH Description (continued)
Input Format	<p>SET-ATTR-OCH:[<tid>]:<aid>:<ctag>::[<ntfcncde>],[<condtype>],,[<dirn>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. The valid value of AID is WAVEPATCH-slot-subcard-port. • <ctag> is the correlation tag. • <ntfcncde> indicates the type of notification generated on the NE when a threshold is exceeded or cleared. When the condtyp parameter corresponds to the high alarm or the low alarm conditions, the notification code can have values CR (critical) or MJ (major) only. The condition is reported through REPT ALM service affect flag is set to SA. When the condtyp parameter corresponds to the high warning or low warning conditions, the notification code can have values MN (minor), NA (not alarmed) or NR (not reported). When the notification code is set to MN, the condition is reported through REPT ALM and the service affect flag is NSA. When the notification code is set to NA, the condition is reported through REPT EVT and the condeff flag is set to SC. When the notification code is set to NR, the condition will not be reported (the information can be retrieved from the NE) and the condeff flag is set to SC. • <condtype> is monitored condition type. Valid values are as follows: <ul style="list-style-type: none"> – OPRHA - Receive optical power level corresponding to the high alarm threshold. If the optical power level is greater than the threshold associated with this parameter, an alarm is generated. – OPRLA - Receive optical power level corresponding to the low alarm threshold. If the optical power level is less than the threshold associated with this parameter, an alarm is generated. – OPRHW - Receive optical power level corresponding to the high warning threshold. If the optical power level is greater than the threshold associated with this parameter, a warning is generated that may be reported using REPT EVT. – OPRLW - Receive optical power level corresponding to the low warning threshold. If the optical power level is less than the threshold associated with this parameter, a warning is generated that may be reported using the REPT EVT. • <dirn> is the direction associated with the information. Valid values are RCV or TRMT. The default is both directions.
Input Example	<p>To configure a severity of MJ on the high alarm threshold on the received optical power, at the wavepatch interface in slot 8, subcard 0, port 0, use the following:</p> <pre>SET-ATTR-OCH:ons155xx:WAVEPATCH-8-0-0:123::MJ,OPRHA,,RCV;</pre>
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.75 SET-NTP: Set NTP

Use this command to configure NTP attributes on the entire system.

Section	SET-NTP Description
Category	NTP
Security	Maintenance
Related Messages	3.62 RTRV-NTP: Retrieve NTP
Input Format	<p>SET-NTP:[<tid>]:<ctag>:::[MASTER=<master>],[MSTRATUM=<mstratum>],[MAXASSOC=<maxassoc>], [CLKPERIOD=<clkperiod>],[UPDCAL=<updcal>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <master> enables or disables this NE to act as NTP master clock. Valid values are Y or N. The default is N. • <mstratum> indicates stratum value to use while acting as NTP master clock. • <maxassoc> sets the maximum number of NTP associations allowed. Valid values are 0 to 4294967295 . • <clkperiod> sets the length of hardware clock tick in 2^{-32} seconds. Valid values are 0 to 4294967295. • <updcal> indicates whether the NE should update its internal hardware clock with clock value obtained from NTP. Valid values are Y or N. The default is N.
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.76 SET-PMMODE-OCH: Set Performance Mode OCH

Use this command to enable and disable performance monitoring on a transparent interface. The <locn> and <modetype> parameters in this command do not apply and are set to NULL.

Section	SET-PMMODE-OCH Description
Category	Transparent interface configuration
Security	Maintenance
Related Messages	3.68 RTRV-PMMODE-OCH: Retrieve Performance Mode OCH
Input Format	<p>SET-PMMODE-OCH:[<tid>]:<aid>:<ctag>::,<pmstate>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. The value is TRANSPARENT-slot-subcard-0. • <ctag> is the correlation tag. • <pmstate> is the performance monitoring state. Valid values are ON or OFF. The default value is OFF.

Section	SET-PMMODE-OCH Description (continued)
Input Example	To enable monitoring on the transparent interface in slot 2, subcard 0, use the following: SET-PMMODE-OCH:ons155xx:TRANSPARENT-2-0-0:123::,ON;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.77 SET-SID: Set System Identification

Use this command to change the NE system identification code to a specific value. The hostname on the device is changed to this value.

Section	SET-SID Description
Category	Generic NE configuration
Security	Retrieve
Related Messages	3.38 INIT-SYS: Initialize System
Input Format	SET-SID:[<tid>]:<ctag>:<SID>; Where: <tid> is the target identifier. <ctag> is the correlation tag. <sid> is the system identifier.
Input Example	To change the NE system identification code to a specific value, use the following: SET-SID:ons155xx::123::ons155xx-tl1;
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.78 SET-TH-OCH: Set Optical Threshold

Use this command to set a threshold level on the monitored optical parameters. Each monitored parameter has a default threshold value assigned to it.

When this command is used with no attributes specified, it restores the default values.

Section	SET-TH-OCH Description
Category	Optical parameter monitoring
Security	Retrieve
Related Messages	3.71 RTRV-TH-rr: Retrieve Threshold 3.70 RTRV-THR-OCH: Retrieve Thresholds OCH 3.31 ENT-THR-OCH: Enter Thresholds OCH

Section	SET-TH-OCH Description (continued)
Input Format	<p>SET-TH-OCH:[<tid>]:[<aid>]:<ctag>::[<montype>],[<thlev>],,[<dirn>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. The valid value is WAVEPATCH-slot-subcard-port. When the second modifier is set to WDM, the AID is WAVEPATCH-slot-subcard-port. Thresholds for Rx parameters only can be configured on the WAVEPATCH-slot-subcard-port. • <montype> specifies one of the following threshold types: <ul style="list-style-type: none"> – OPRHA - Receive optical power level corresponding to the high alarm threshold. If the optical power level is greater than the threshold associated with this parameter, an alarm is generated. – OPRLA - Receive optical power level corresponding to the low alarm threshold. If the optical power level is less than the threshold associated with this parameter, an alarm is generated. – OPRHW - Receive optical power level corresponding to the high warning threshold. If the optical power level is greater than the threshold associated with this parameter, a warning is generated that may be reported using REPT EVT. – OPRLW - Receive optical power level corresponding to the low warning threshold. If the optical power level is less than the threshold associated with this parameter, a warning is generated that may be reported using the REPT EVT.
Input Example	<p>To configure a high alarm threshold of 20.0 dBm on the received optical power at the wavepatch interface in slot 8, port 0, use the following:</p> <p>SET-TH-OCH:ons155xx:WAVEPATCH-8-0-0:123::OPRHA,200,,RCV;</p>
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.79 SQUEEZE-MEM: Squeeze Memory

Use this command to permanently delete files and defragment the file system on a Flash memory device.

Section	SQUEEZE-MEM Description
Category	Memory Management
Security	Retrieve
Related Messages	3.5 CPY-MEM: Copy Memory 3.33 FORMAT-MEM: Format Memory 3.43 RST-MEM: Restore Memory 3.57 RTRV-MEM: Retrieve Memory

Section	SQUEEZE-MEM Description (continued)
Input Format	<p>SQUEEZE-MEM:[<tid>]:<aid>:<ctag>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the memory device that is being defragmented. Valid values are BOOTFLASH, DDISK-[0-1], PCMCIA-[0-1], SBY-BOOTFLASH, SBY-DISK-[0-1], or SBY-PCMCIA-[0-1]. • <ctag> is the correlation tag.
Input Example	<p>To delete files and defragment the file system on a Flash memory device, use the following:</p> <p>SQUEEZE-MEM:ons155xx:BOOTFLASH:123;</p>
Errors	Errors are listed in Table 2-13 on page 2-9 .

3.80 SW-DX-EQPT: Switch Duplex Equipment

Use this command to switch activity from the active to the standby processor card.

Section	SW-DX-EQPT Description
Category	Redundancy configuration
Security	Maintenance
Related Messages	3.3 ALW-SWDX-EQPT: Allow Switch Duplex Equipment 3.35 INH-SWDX-EQPT: Inhibit Switch Duplex Equipment
Input Format	<p>SW-DX-EQPT:[<tid>]:<aid>:<ctag>::[<mode>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the active processor card. Valid values are SLOT-6 or SLOT-7. • <ctag> is the correlation tag. • <mode> indicates the mode of operation. Valid values are FRCD and NORMAL. The default mode is NORMAL.
Input Example	<p>To forcibly make the active processor card in slot 6 switch to standby mode, use the following:</p> <p>SW-DX-EQPT:ons155xx:SLOT-6:123::FRCD;</p>
Errors	Errors are listed in Table 2-13 on page 2-9 .