

User Interface Commands

This chapter describes the commands used to access user and privileged EXEC command modes. It provides a description of the **help** command and features, lists the command editing keys and functions, and details the command history feature.

This chapter also includes the EXEC commands that can be used to set various terminal parameters on a temporary basis (for the duration of a session). It includes the Telnet commands you can use to make a connection from a terminal to a remote router in order to configure the router. The commands to actually configure these parameters on a more permanent basis are provided in the chapter, “Terminal Line and Modem Support Commands.”

You need enter only enough characters of a command to uniquely identify the command, thereby abbreviating the command syntax you type.

For user interface task information and examples, refer to the “Configuring the User Interface” chapter of the *Router Products Configuration Guide*.

clear line

Use the **clear line** EXEC command to return a terminal line to idle state.

clear line *line-number*

Syntax Description

line-number Absolute line number.

Default

None

Command Mode

EXEC

Usage Guidelines

Use this command to log out of a specific session running on another line. If the line uses a modem, the modem will be disconnected.

Example

In the following example, line 3 is reset:

```
clear line 3
```

connect

To make a Telnet connection, enter the **connect** EXEC command at the system prompt.

```
connect host [port] [keyword]
```

Syntax Description

<i>host</i>	Host name or an Internet address.
<i>port</i>	(Optional.) Decimal TCP port number; the default is the Telnet server port (decimal 23) on the host.
<i>keyword</i>	(Optional.) Keyword that can be set with the connection; see Table 1-1 for a list of keywords.

Table 1-1 Telnet Connection Keywords

Keyword	Description
<i>/route: path</i>	Specifies loose source routing. The argument <i>path</i> is a list of host names or Internet addresses that specifies network nodes, ending with the final destination.
<i>/line</i>	Enables Telnet line mode. In this mode, the router does not send any data to the host until you press Return. You can edit the line using the standard router command editing characters (Backspace, Delete, Ctrl-U, Ctrl-W). The <i>/line</i> keyword is a local option; the remote server is not notified of the mode change.
<i>/debug</i>	Enables Telnet debugging mode.
<i>/stream</i>	Turns on stream processing, which enables a raw TCP stream with no Telnet control sequences. A stream connection does not process Telnet options and may be appropriate for connections to ports running UUCP and other non-Telnet protocols.

Command Mode

EXEC

Usage Guidelines

You are not required to enter the command **connect** to establish a Telnet connection. If you prefer, you can just enter the host name. Omit the command word **connect** if the host name you want to use is not the same as a router command word. See the **transport preferred** command to disable this capability.

The router assigns a logical name to each connection; several commands use these names to identify connections. The logical name is the same as the host name, unless that name is already in use or you change the connection name with the EXEC command **name-connection**. If the name is already in use, the router assigns a null name to the connection.

Examples

The following example routes packets from the source system to kl.sri.com, then to 10.1.0.11, and finally to mathom:

```
Router> connect mathom /route:kl.sri.com 10.1.0.11 mathom
```

The following example connects to a host with logical name mathom:

```
Router> mathom
```

Related Commands

A dagger (†) indicates that the command is documented in another chapter.

name-connection

resume

telnet

transport preferred none †

disable

To exit privileged EXEC mode and return to user EXEC mode, enter the **disable** EXEC command.

disable

Syntax Description

This command has no arguments or keywords.

Command Mode

EXEC

Example

In the following example, entering the **disable** command causes the system to exit privileged EXEC mode and return to user EXEC mode as indicated by the angle bracket (>):

```
Router# disable  
Router>
```

Related Command

enable

disconnect

To close a Telnet connection, enter the **disconnect** EXEC command at the system prompt.

disconnect [*connection*]

Syntax Description

connection (Optional.) Connection name or number; the default is the current connection.

Command Mode

EXEC

Usage Guidelines

Do not use the **disconnect** command to end a terminal session. Instead, log off the host, which allows the host to initiate the disconnect, then use **exit** to close the session. If you cannot log off the host using **exit**, use the **disconnect** command.

Example

The following example illustrates how to disconnect a specific session. First use the **where** command to list the current sessions:

```
Router> where

Conn Host      Address          Byte  Idle  Conn Name
*  1  Eng1      192.31.6.22      0    0    my host
   2  Term2     192.33.6.21      0    0    Term2

Router> disconnect my host

Closing connection to Eng1 [confirm]
```

Related Commands

exit
logout

enable

To enter privileged EXEC mode, use the **enable** EXEC command.

enable

Syntax Description

This command has no arguments or keywords.

Command Mode

EXEC

Usage Guidelines

Because many of the privileged commands set operating parameters, privileged access should be password-protected to prevent unauthorized use. If the system administrator has set a password with the **enable password** global configuration command, you are prompted to enter it before being allowed access to privileged EXEC mode. The password is case sensitive.

Example

In the following example, the user enters the **enable** command and is prompted to enter a password. The password is not displayed on the screen. After entering the password, the system enters privileged command mode as indicated by the # symbol.

```
Router> enable  
Password:  
Router#
```

Related Commands

A dagger (†) indicates that the command is documented in another chapter.

disable

enable password †

end

end

To exit configuration mode, use the **end** global configuration command.

end

Syntax Description

This command has no arguments or keywords.

Command Mode

Global configuration

Usage Guidelines

You can also press Ctrl-Z to exit configuration mode.

Example

In the following example, the router name is changed to `alibaba` using the **hostname** global configuration command. Entering the **end** command causes the system to exit configuration mode and return to EXEC mode.

```
router(config)# hostname alibaba
alibaba(config)# end
alibaba#
```

exit

To exit any command mode or close an active terminal session and terminate the EXEC, use the **exit** command at the system prompt.

exit

Syntax Description

This command has no arguments or keywords.

Command Mode

Available in all command modes

Usage Guidelines

When you enter the **exit** command at the EXEC levels, the EXEC mode is ended. Use the **exit** command at the configuration level to return to privileged EXEC mode. Use the **exit** command in interface, line, router, ipx-router, and route-map command modes to return to global configuration mode. Use the **exit** command in subinterface configuration mode to return to interface configuration mode. You can also press Ctrl-Z from any configuration mode to return to privileged EXEC mode.

Examples

In the following example, the user exits subinterface configuration mode to return to interface configuration mode:

```
Router(config-subif)# exit
Router(config-if)#
```

The following example shows how to exit an active session.

```
Router> exit
```

Related Commands

disconnect

logout

full-help

To get help for the full set of user-level commands, use the **full-help** line configuration command.

full-help

Syntax Description

This command has no arguments or keywords.

Command Mode

Line configuration

Example

The following example displays full help:

```
full-help
```

Related Command

terminal full-help

help

To display a brief description of the help system, enter the **help** command.

help

Syntax Description

This command has no arguments or keywords.

Command Mode

Available in all command modes

Usage Guidelines

The **help** command provides a brief description of the context-sensitive help system.

- To list all commands available for a particular command mode, enter a question mark (?) at the system prompt.
- To obtain a list of commands that begin with a particular character string, enter the abbreviated command entry immediately followed by a question mark (?). This form of help is called word help, because it lists only the keywords or arguments that begin with the abbreviation you entered.
- To list a command's associated keywords or arguments, enter a question mark (?) in place of a keyword or argument on the command line. This form of help is called command syntax help, because it lists the keywords or arguments that apply based on the command, keywords, and arguments you have already entered.

Examples

Enter the **help** command for a brief description of the help system:

```
router1# help
Help may be requested at any point in a command by entering
a question mark '?'. If nothing matches, the help list will
be empty and you must backup until entering a '?' shows the
available options.
Two styles of help are provided:
1. Full help is available when you are ready to enter a
   command argument (e.g. 'show ?') and describes each possible
   argument.
2. Partial help is provided when an abbreviated argument is entered
   and you want to know what arguments match the input
   (e.g. 'show pr?'.)
```

The following example shows how to use word help to display all the privileged EXEC commands that begin with the letters "co":

```
Router# co?
configure connect copy
```

The following example shows how to use command syntax help to display the next argument of a partially complete **access-list** command. One option is to add a wild-card mask. The <cr> symbol indicates that the other option is to press Return to execute the command.

```
Router(config)# access-list 99 deny 131.108.134.234 ?  
  A.B.C.D Mask of bits to ignore  
<cr>
```

history size

To change the command history buffer size for a particular line, use the **history size** line configuration command. To disable the command history feature, use the **no** form of this command.

```
history size number-of-lines
no history size
```

Syntax Description

number-of-lines Number of command lines that the system will record in its history buffer. The range is 0 to 256.

Default

10 lines

Command Mode

Line configuration

Usage Guidelines

The command history feature provides a record of EXEC commands you have entered. This feature is particularly useful for recalling long or complex commands or entries, including access lists.

Table 1-2 lists the keys and functions you can use to recall commands from the command history buffer.

Table 1-2 History Keys

Key	Function
Ctrl-P or Up Arrow ¹	Recalls commands in the history buffer in a backward sequence, beginning with the most recent command. Repeat the key sequence to recall successively older commands.
Ctrl-N or Down Arrow ¹	Returns to more recent commands in the history buffer after recalling commands with Ctrl-P or the Up Arrow. Repeat the key sequence to recall successively more recent commands.

1. The arrow keys function only with ANSI-compatible terminals such as VT100s.

Example

In the following example, virtual terminal line 4 is configured with a history buffer size of 35 lines:

```
line vty 4
 history size 35
```

Related Commands

```
terminal history size
show history
```

lock

To prevent access to your session while keeping your connection open, enter the **lock EXEC** command at the system prompt.

lock

Syntax Description

This command has no arguments or keywords.

Command Mode

EXEC

Usage Guidelines

This command locks the keyboard. The global configuration command **lockable** must be included in the system configuration file for this command to work. The **lock EXEC** command remains in effect until the **clear line** privileged EXEC command is executed.

When this command is entered, the system prompts for a password, which can be any arbitrary string. The screen clears and displays the message “Locked.” To regain access to the session, reenter the password.

Example

The following example shows how to lock a session. The system prompts for a password, then verifies it. Once the “Locked” message displays, it will not be possible to use the terminal until the correct password is entered.

```
Router# lock

Password:
Again:

                Locked
```

Related Commands

A dagger (†) indicates that the command is documented in another chapter.

clear line †

lockable †

login (EXEC)

To log in to a server, enter the **login** EXEC command at the system prompt.

login

Syntax Description

This command has no arguments or keywords.

Command Mode

EXEC

Usage Guidelines

When you enter this command, the server prompts for a username and password. If you enter both correctly, the session becomes associated with the specified username. If there is no match, the connection reverts to the username with which the **login** command attempt was made, if applicable. If no login name and password were originally required, the connection reverts to a session that is not associated with any name.

When using the **login** command to access a system with TACACS security, you can type your name or specify a TACACS server *user@hostname*, *user@IP address*. The server must be one defined in a configuration with the **tacacs-server host** command.

If you do not specify a host, the router will try each of the TACACS servers in the list until it receives a response.

If you specify a host and that host does not respond, the router does not query another TACACS server. The router either denies access or behaves according to the action specified by the **tacacs-server last-resort** command if there is one configured.

If you specify a TACACS server host with *user@hostname*, the TACACS server specified will be used for all subsequent authentication or notification queries, with the possible exception of SLIP address queries.

Examples

In the following example, a user wants to change the login name to sloan. The user enters the **login** command, the new name, and an incorrect password. The system rejects the attempt to change the username. Then the user attempts to change the login name to klaus. The user enters the correct password and is allowed access to the EXEC at the user-level under the username of klaus.

```
Router> login
Username: sloan
Password:
% Access denied
Still logged in as "usera"
```

```
Router> login
Username: klaus
Password:
Router>
```

In the following example, user bob specifies TACACS host1 to authenticate his password:

```
Router> login
Username: bob@host1
Translating "HOST1"...domain server (131.108.1.111) [OK]
```

Related Commands

A dagger (†) indicates that the command is documented in another chapter.

logout

tacacs-server host †

tacacs-server last-resort †

username †

logout

To close an active terminal session and terminate the EXEC, enter the **logout** EXEC command at the system prompt.

logout

Syntax Description

This command has no arguments or keywords.

Command Mode

EXEC

Usage Guidelines

This command has the same function as the **exit** EXEC command.

Example

The following example shows how to exit an active session:

```
Router> logout
```

Related Commands

disconnect

exit

login (EXEC)

name-connection

To assign a logical name to a connection, enter the **name-connection** EXEC command at the system prompt.

name-connection

Syntax Description

This command has no arguments or keywords.

Command Mode

EXEC

Usage Guidelines

Use this command to assign a logical name to a physical connection. The EXEC prompts for the connection number and name to assign when you enter this command. The **where** command displays a list of the assigned logical connection names.

Example

The following example checks the connection number for the host Eng1, assigns the logical name “my host” to it, and then confirms the assignment:

```
Router> where

Conn Host      Address          Byte  Idle  Conn  Name
*  1  Eng1      192.31.6.22      0    0    Eng1
   2  Term2     192.33.6.21      0    0    Term2

Router> name-connection

Connection number: 1
Enter logical name: my host
Connection 1 to Eng1 will be named "my host" [confirm]

Router> where

Conn Host      Address          Byte  Idle  Conn  Name
*  1  Eng1      192.31.6.22      0    0    my host
   2  Term2     192.33.6.21      0    0    Term2
```

Related Commands

connect

telnet

where

resume

To return to a previous Telnet connection, enter the **resume** EXEC command at the system prompt.

```
resume [connection] [keyword]
```

Syntax Description

connection (Optional.) Connection name or number; the default is the most recent connection.

keyword (Optional.) Keyword that can be set; see Table 1-3 for a list of keywords.

Table 1-3 Resume Keywords

Keyword	Description
/line	Enables Telnet line mode. In this mode, the router does not send any data to the host until the user presses Return. The user can edit the line using the standard router command editing characters (Backspace, Delete, Ctrl-U, Ctrl-W). The /line keyword is a local switch; the remote server is not notified of the mode change.
/noline	Disables Telnet line mode and enables character-at-a-time mode (default).
/debug	Enables Telnet debugging mode.
/nodebug	Disables Telnet debugging mode (default).
/stream	Turns on stream processing, which enables a raw TCP stream with no Telnet control sequences. A stream connection does no processing of Telnet options and may be appropriate for connections to ports running UUCP and other non-Telnet protocols.
/nostream	Turns off stream processing, which enables the Telnet protocol (default).
/echo	Enables local echoing of characters (default). The /echo keyword is a local switch; the remote server is not notified of the state change.
/noecho	Disables local echoing of characters.
/set	Sets X3 connection options.

Command Mode

EXEC

Usage Guidelines

Use this command after you have escaped out of a session to move to another open connection. You can omit the command word **resume** and simply type the connection number to resume a connection. You can also return to the most recent session by simply pressing the Return key.

Note The router supports Telnet line mode, also called local editing; you can request line mode with the **connect** command. If a remote host responds with “WONT SUPPRESS-GA,” the router assumes the host wants line-at-a-time input along with line mode. You can also put a Telnet session into line mode by using the **/line** keyword with the **resume** command.

Examples

The following example resumes connection 2 in Telnet line mode:

```
Router> resume 2 /line
```

The following example resumes Telnet connection 3:

```
Router> 3
```

Related Commands

connect

telnet

service finger

To allow Finger protocol requests (defined in RFC 742) to be made of the network server, use the **service finger** global configuration command. This service is equivalent to issuing a remote **show users** command. The **no service finger** command removes this service.

```
service finger  
no service finger
```

Syntax Description

This command has no arguments or keywords.

Default

Enabled

Command Mode

Global configuration

Example

The following is an example of how to disable the Finger protocol:

```
no service finger
```

show history

To list the commands you have entered in the current EXEC session, use the **show history** EXEC command.

show history

Syntax Description

This command has no arguments or keywords.

Command Mode

EXEC

Usage Guidelines

The command history feature provides a record of EXEC commands you have entered. The number of commands the history buffer will record is determined by the **history size** line configuration command or the **terminal history size** EXEC command.

Table 1-4 lists the keys and functions you can use to recall commands from the command history buffer.

Table 1-4 History Keys

Key	Function
Ctrl-P or Up Arrow	Recalls commands in the history buffer in a backward sequence, beginning with the most recent command. Repeat the key sequence to recall successively older commands.
Ctrl-N or Down Arrow	Returns to more recent commands in the history buffer after recalling commands with Ctrl-P or the Up Arrow. Repeat the key sequence to recall successively more recent commands.

Sample Display

The following is sample output from the **show history** command, which lists the commands the user has entered in EXEC mode for this session:

```
Router# show history
help
  where
  show hosts
  show history
Router#
```

Related Commands

history size

terminal history size

show line

To display a terminal line's parameters, use the **show line** EXEC command.

```
show line [line-number]
```

Syntax Description

line-number (Optional.) Absolute line number of the line for which you want to list parameters.

Command Mode

EXEC

Sample Display

The following sample output from the **show line** command shows that line 2 is a virtual terminal with a transmit and receive rate of 9600 bps. Also shown is the modem state, terminal screen width and length, and so on.

```
Router# show line 2

  Tty Typ   Tx/Rx   A Modem  Roty AccO AccI  Uses   Noise  Overruns
    2 VTY  9600/9600 -   -     -   -   -    0      0      0/0

Line 2, Location: "", Type: ""
Length: 24 lines, Width: 80 columns
Baud rate (TX/RX) is 9600/9600
Status: No Exit Banner
Capabilities: none
Modem state: Idle
Special Chars: Escape  Hold  Stop  Start  Disconnect  Activation
                ^^x   none  -     -     none
Timeouts:      Idle EXEC  Idle Session  Modem Answer  Session  Dispatch
                0:10:00  never        0:00:15      not imp  not set
Session limit is not set.
Editing is enabled.
History is enabled, history size is 10.
Allowed transports are telnet mop. Preferred is telnet.
No output characters are padded
Characters causing immediate data dispatching:
  Char  ASCII
```

show sessions

Use the **show sessions** EXEC command to show the active Telnet sessions.

show sessions

Syntax Description

This command has no arguments or keywords.

Command Mode

EXEC

Sample Display

The following is sample output from the **show sessions** command:

```
Router# show sessions

Conn Host          Address           Byte  Idle Conn Name
  1 MATHOM          192.31.7.21      0     0 MATHOM
*  2 CHAFF          131.108.12.19    0     0 CHAFF
```

In the display, an asterisk (*) indicates your current terminal session.

Table 1-5 describes the fields shown in the display.

Table 1-5 Show Sessions Field Descriptions

Field	Description
Conn	Name or address of the remote host to which the connection is made.
Host	Remote host to which the router is connected through a Telnet session.
Address	IP address of the remote host.
Byte	Number of unread bytes that are waiting for the user to see on the connection.
Idle	Interval (in minutes) since data was last sent on the line.
Conn Name	Assigned name of the connection.

show tcp

Use the **show tcp** EXEC command to display the status of TCP connections.

```
show tcp [line-number]
```

Syntax Description

line-number (Optional.) Absolute line number of the line for which you want to display Telnet connection status.

Command Mode

EXEC

Sample Display

The following is sample output from the **show tcp** command:

```
Router# show tcp

con0 (console terminal), connection 1 to host MATHOM
Connection state is ESTAB, I/O status: 1, unread input bytes: 1
Local host: 192.31.7.18, 33537 Foreign host: 192.31.7.17, 23
Enqueued packets for retransmit: 0, input: 0, saved: 0
Event Timers (current time is 2043535532):
Timer:          Retrans  TimeWait  AckHold    SendWnd    KeepAlive
Starts:          69      0         69         0          0
Wakeups:         5       0         1         0          0
Next:           2043536089  0         0         0          0
iss: 2043207208 snduna: 2043211083 sndnxt: 2043211483  sndwnd: 1344
irs: 3447586816 rcvnxt: 3447586900 rcvwnd: 2144 delrcvwnd: 83
RTTO: 565 ms, RTV: 233 ms, KRTT: 0 ms, minRTT: 68 ms, maxRTT: 1900 ms
ACK hold: 282 ms
Datagrams (max data segment is 536 bytes):
Rcvd: 106 (out of order: 0), with data: 71, total data bytes: 83
Sent: 96 (retransmit: 5), with data: 92, total data bytes: 4678
```

Table 1-6 describes the following lines of output shown in the display:

```
con0 (console terminal), connection 1 to host MATHOM
Connection state is ESTAB, I/O status: 1, unread input bytes: 1
Local host: 192.31.7.18, 33537 Foreign host: 192.31.7.17, 23
Enqueued packets for retransmit: 0, input: 0, saved: 0
```

Table 1-6 Show TCP Field Descriptions—First Section of Output

Field	Description
con0	Identifying number of the line.
(console terminal)	Location string.
connection 1	Number identifying the TCP connection.
to host MATHOM	Name of the remote host to which the connection has been made.
Connection state is ESTAB	<p>A connection progresses through a series of states during its lifetime. These states follow in the order in which a connection progresses through them.</p> <ul style="list-style-type: none"> • LISTEN—Waiting for a connection request from any remote TCP and port. • SYNSENT—Waiting for a matching connection request after having sent a connection request. • SYNRCVD—Waiting for a confirming connection request acknowledgment after having both received and sent a connection request. • ESTAB—Indicates an open connection; data received can be delivered to the user. This is the normal state for the data transfer phase of the connection. • FINWAIT1—Waiting for a connection termination request from the remote TCP or an acknowledgment of the connection termination request previously sent. • FINWAIT2—Waiting for a connection termination request from the remote TCP host. • CLOSEWAIT—Waiting for a connection termination request from the local user. • CLOSING—Waiting for a connection termination request acknowledgment from the remote TCP host. • LASTACK—Waiting for an acknowledgment of the connection termination request previously sent to the remote TCP host. • TIMEWAIT—Waiting for enough time to pass to be sure the remote TCP host has received the acknowledgment of its connection termination request. • CLOSED—Indicates no connection state at all. <p>For more information, see RFC 793, <i>Transmission Control Protocol Functional Specification</i>.</p>
I/O status: 1	Number describing the current internal status of the connection.
unread input bytes: 1	Number of bytes that the lower-level TCP processes have read, but the higher level TCP processes have not yet processed.
Local host: 192.31.7.18	Internet address of the network server.
33537	Local port number, as derived from the following equation: $line-number + (512 * random-number)$. (The line number uses the lower nine bits; the other bits are random.)
Foreign host: 192.31.7.17	Internet address of the remote host to which the TCP connection has been made.
23	Destination port for the remote host.

Field	Description
Enqueued packets for retransmit: 0	Number of packets waiting on the retransmit queue. These are packets on this TCP connection that have been sent but have not yet been acknowledged by the remote TCP host.
input: 0	Number of packets that are waiting on the input queue to be read by the user.
saved: 0	Number of received out-of-order packets that are waiting for all packets comprising the message to be received before they enter the input queue. For example, if packets 1, 2, 4, 5, and 6 have been received, packets 1 and 2 would enter the input queue, and packets 4, 5, and 6 would enter the saved queue.

The following line of output shows the current time according to the system clock of the local host.

```
Event Timers (current time is 2043535532):
```

The time shown is the number of milliseconds since the system started.

The following lines of output display the number of times that various local TCP timeout values were reached during this connection. In this example, the router retransmitted 69 times because it received no response from the remote host, and it transmitted an ACK many more times because there was no data on which to piggyback.

```
Timer:      Retrans  TimeWait  AckHold  SendWnd  KeepAlive
Starts:           69         0         69         0         0
Wakeups:           5         0         1         0         0
Next:    2043536089         0         0         0         0
```

Table 1-7 describes the fields in the preceding lines of output.

Table 1-7 Show TCP Field Descriptions—Second Section of Output

Field	Description
Timer:	This line of output indicates the names of the timers in the display.
Starts:	The number of times the timer has been started during this connection.
Wakeup:	The Wakeups row of the KeepAlives column shows how many keepalives have been transmitted without receiving any response. (This field is reset to zero when a response is received.)
Next:	The system clock setting that will trigger the next time this timer will go off.
Retrans	The Retransmission timer is used to time TCP packets that have not been acknowledged and are waiting for retransmission.
TimeWait	The TimeWait timer is used to ensure that the remote system receive a request to disconnect a session.
AckHold	The Acknowledgment timer is used to delay the sending of acknowledgments to the remote TCP in an attempt to reduce network use.
SendWnd	The Send Window is used to ensure that there is no closed window due to a lost TCP acknowledgment.
KeepAlive	The KeepAlive timer is used to control the transmission of test messages to the remote TCP to ensure that the link has not been broken without the local TCP's knowledge.

The following lines of output display the sequence numbers that TCP uses to ensure sequenced, reliable transport of data. The router and remote host each use these sequence numbers for flow control and to acknowledge receipt of datagrams. Table 1-8 describes the specific fields in these lines of output:

```
iss: 2043207208 snduna: 2043211083 sndnxt: 2043211483 sndwnd: 1344
irs: 3447586816 rcvnxt: 3447586900 rcvwnd: 2144 delrcvwnd: 83
```

Table 1-8 Show TCP Field Descriptions—Sequence Number

Field	Description
iss: 2043207208	Initial send sequence number.
snduna: 2043211083	Last send sequence number the router has sent but has not received an acknowledgment for.
sndnxt: 2043211483	Sequence number the router will send next.
sndwnd: 1344	TCP window size of the remote host.
irs: 3447586816	Initial receive sequence number.
rcvnxt: 3447586900	Last receive sequence number the router has acknowledged.
rcvwnd: 2144	Router's TCP window size.
delrcvwnd: 83	Delayed receive window—data the router has read from the connection, but has not yet subtracted from the receive window the router has advertised to the remote host. The value in this field gradually increases until it is larger than a full-sized packet, at which point it is applied to the rcvwnd field.

The following lines of output display values that the router uses to keep track of transmission times so that TCP can adjust to the network it is using. Table 1-9 describes the fields in the following line of output:

```
RTTO: 565 ms, RTV: 233 ms, KRTT: 0 ms, minRTT: 68 ms, maxRTT: 1900 ms
ACK hold: 282 ms
```

Table 1-9 Show TCP Field Descriptions—Line Beginning with RTTO

Field	Description
RTTO: 565 ms	Round trip timeout.
RTV: 233 ms	Variance of the round trip time.
KRTT: 0 ms	New round trip timeout (using the Karn algorithm). This field separately tracks the round trip time of packets that have been retransmitted.
minRTT: 68 ms	Smallest recorded round trip timeout (hard wire value used for calculation).
maxRTT: 1900 ms	Largest recorded round trip timeout.
ACK hold: 282 ms	Time the router will delay an acknowledgment in order to piggyback data on it.

For more information on these fields, refer to “Round Trip Time Estimation,” P. Karn & C. Partridge, ACM SIGCOMM-87, August 1987.

Table 1-10 describes the fields in the following lines of output:

```
Datagrams (max data segment is 536 bytes):
Rcvd: 106 (out of order: 0), with data: 71, total data bytes: 83
Sent: 96 (retransmit: 5), with data: 92, total data bytes: 4678
```

Table 1-10 Show TCP Field Descriptions—Last Section of Output

Field	Description
Rcvd: 106 (out of order: 0)	Number of datagrams the local host has received during this connection (and the number of these datagrams that were out of order).
with data: 71	Number of these datagrams that contained data.
total data bytes: 83	Total number of bytes of data in these datagrams.
Sent: 96 (retransmit: 5)	Number of datagrams the local host sent during this connection (and the number of these datagrams that had to be retransmitted).
with data: 92	Number of these datagrams that contained data.
total data bytes: 4678	Total number of bytes of data in these datagrams.

show terminal

Use the **show terminal** EXEC command to obtain information about the terminal configuration parameter settings for the current terminal line.

show terminal

Syntax Description

This command has no arguments or keywords.

Command Mode

EXEC

Sample Display

The following is sample output from the **show terminal** command:

```
Router# show terminal

Line 2, Location: "", Type: ""
Length: 24 lines, Width: 80 columns
Baud rate (TX/RX) is 9600/9600
Status: Ready, Active, No Exit Banner
Capabilities: Enabled
Modem state: Ready
Special Chars: Escape Hold Stop Start Disconnect Activation
                ^x   none - - none
Timeouts:      Idle EXEC Idle Session Modem Answer Session Dispatch
                never      never      0:00:15 not imp not set

Session limit is not set.
Allowed transports are telnet rlogin. Preferred is telnet
No output characters are padded
```

Table 1-11 describes the fields in the first three lines of **show terminal** output.

Table 1-11 Show Terminal Field Descriptions—First Three Lines of Output

Field	Description
Line 2	Current terminal line.
Location: ""	Location of the current terminal line, as specified using the location line configuration command.
Type: " "	Type of the current terminal line, as specified using the line global configuration command.
Length: 24 lines	Length of the terminal display.
Width: 80 columns	Width of the terminal display, in character columns.
Baud rate (TX/RX) is 9600/9600	Transmit rate/receive rate of the line.

The following line of output indicates the status of the line:

```
Status: Ready, Active, No Exit Banner
```

Table 1-12 describes possible values for the Status field.

Table 1-12 Show Terminal Field Description—Status Field

Field	Description
Active	A process is actively using the line.
Autobauding	The line is running the autobaud process.
Carrier Dropped	Some sense of “carrier” has been dropped, so the line process should be killed.
Connected	The line has at least one active connection.
Dialing Out	A DDR async interface is dialing a remote site on this line.
Echo Off	The line is not echoing what the user types in (because a password must be entered, for example).
Escape Started	The first character of the escape sequence has been typed.
Escape Typed	Both characters of the escape sequence have been typed.
Hanging Up	The line state is “hanging up.”
Hardware XON/XOFF	The line uses a UART that supports XON/XOFF flow control in hardware. (This does not mean that the line is currently using software flow control.)
Hold Typed	The user typed the “hold character” (and the line is paused).
Idle	The line modem state is “idle” (see modem state diagrams).
Idle Timeout	An idle timeout has occurred.
Input Stopped	The input has been turned off due to hardware flow control or overflow.
No Exit Banner	The normal exit banner will not be displayed on this line.
PSI Enabled	The line is paying attention to typed escape characters.
Rcvd BREAK	A BREAK sequence has been received on the line.
Rcvd Command	The line has received a special command sequence (for example, ^B for send break).
Rcvd CR	The last character received was a carriage return.
Ready	The line state is “ready.”
Ring Transition	There has been a transition on the RING signal of the line.
Send Break Soon	You need to send a BREAK on the line soon.
Send XOFF Soon	Your buffers are full and you should send an XOFF soon.
Sending Break	You are in the process of sending a BREAK sequence on the line.
Sent XOFF	Your buffers were full, so we sent an XOFF.
SLIP Mode	The line is running SLIP or PPP.

The following line of output indicates the status of the capabilities of the line; these capabilities correspond closely to configurable parameters that can be set using configuration commands.

```
Capabilities: Enabled
```

Table 1-13 describes possible values for the Capabilities field.

Table 1-13 Show Terminal Field Descriptions—Capabilities Field

Field	Description
Autobaud Full Range	Corresponds to the autobaud command.
Character Padding	At least one pad c x configuration command has been used.
Enabled	The user has “enabled” successfully.
EXEC Suppressed	Corresponds to the no exec command.
Hangup on Last Close	Corresponds to the autohangup command.
Hardware Flowcontrol In	Corresponds to the flowcontrol hardware in command.
Hardware Flowcontrol Out	Corresponds to the flowcontrol hardware out command.
Insecure	Corresponds to the insecure command.
Lockable	Corresponds to the lockable command.
Modem Callin	Corresponds to the modem callin command.
Modem Callout	Corresponds to the modem callout command.
Modem CTS-Required	Corresponds to the modem cts-required command.
Modem DTR-Active	Corresponds to the modem dtr-active command.
Modem RI is CD	Corresponds to the modem ri-is-cd command.
No Login Banner	Corresponds to the no exec-banner command.
Notification Set	Corresponds to the notify command.
Output Non-Idle	Corresponds to the session-timeout N output command.
Permanent SLIP	Corresponds to the slip-dedicated command.
Private Line	Corresponds to the private command.
Refuse Suppress-GA	Corresponds to the telnet refuse command.
Receives Logging Output	Corresponds to the monitor command.
Refuse Telnet Echo	Corresponds to the telnet refuse command.
Send BREAK on IP	Corresponds to the telnet break-on-ip command.
SLIP allowed	Corresponds to the slip address xxxx command.
Software Flowcontrol In	Corresponds to the flowcontrol software in command.
Software Flowcontrol Out	Corresponds to the flowcontrol software out command.
Telnet Transparent Mode	Corresponds to the telnet transparent command.

The following line of output indicates the modem state. Possible values include Autobauding, Carrier Dropped, Hanging Up, Idle, and Ready.

```
Modem state: Ready
```

The following lines of output indicate the special characters that can be entered to activate various terminal operations. The none or hyphen (-) values imply that no special characters are set.

```
Special Chars: Escape Hold Stop Start Disconnect Activation
                ^^x none - - none
```

The following lines of output indicate the timeout values that have been configured for the line:

```
Timeouts:      Idle EXEC      Idle Session  Modem Answer  Session  Dispatch
              never          never          0:00:15      not imp   not set
```

Table 1-14 describes the fields in the preceding lines of output.

Table 1-14 Show Terminal Field Descriptions—Timeouts Fields

Field	Description
Idle EXEC	Interval that the EXEC command interpreter waits for user input before resuming the current connection; or if no connections exist, returning the terminal to the idle state and disconnecting the incoming session. This interval is set using the exec-timeout command.
Idle Session	Interval that the router waits for traffic before closing the connection to a remote computer and returning the terminal to an idle state. This interval is set using the session-timeout command.
Modem Answer	Interval during which the router raises DTR in response to RING and the modem response to CTS. This interval is set using the modem answer-timeout command.
Session	Not implemented in this release.
Dispatch	Number of milliseconds the router waits after putting the first character into a packet buffer before sending the packet. This interval is set using the dispatch-timeout command.

The following lines of output indicate how various options have been configured:

```
Session limit is not set.
Allowed transports are telnet rlogin. Preferred is telnet
No output characters are padded
```

show users

Use the **show users** EXEC command to display information about the active ports of the router. The information displayed includes the line number, connection name, idle time, and terminal location.

```
show users [all]
```

Syntax Description

all (Optional.) Specifies that all lines, whether or not anyone is using them, be displayed.

Command Mode

EXEC

Sample Display

The following is sample output from the **show users** command:

```
Router# show users

      Line           User           Host(s)       Idle Location
      0 con 0
*    2 vty 0        rdoe          idle          0 ABC.CISCO.COM
```

Table 1-15 describes the fields shown in the display.

Table 1-15 Show Users Field Descriptions

Field	Description
Line	Contains three subfields. The asterisk (*) identifies the line of the user entering the show command. The first subfield (2, in this case) is the absolute line number. The second subfield (vty, in this case) indicates the type of line. Possible values follow: <ul style="list-style-type: none"> • con—Console • aux—Auxiliary port • vty—Virtual terminal The third subfield (0, in this case) indicates the relative line number within type.
User	Name of user using the line. If this field is blank, no user is using the line.
Host(s)	Host to which the user is connected (outgoing connection). A value of idle indicates no outgoing connection to a host.
Idle	Interval (in minutes) since the user has typed something.
Location	Either the hardwired location for the line or, if there is an incoming connection, the host the incoming connection is from.

The following is sample output from the **show users all** command:

```
Router> show users all
  Line      User      Host(s)           Idle Location
  0 con 0
  1 aux 0
  * 2 vty 0           idle              0 USER.COMPANY.COM
  3 vty 1
  4 vty 2
  5 vty 3
  6 vty 4
```

Related Commands

A dagger (†) indicates that the command is documented in another chapter.

line †

location †

systat

To display information about the active ports of the router, use the **systat** EXEC command.

```
systat [all]
```

Syntax Description

all (Optional.) Displays information for both active and inactive ports.

Command Mode

EXEC

Usage Guidelines

This command is a synonym for the **show users** command.

Example

The following example shows how to use the **systat** command:

```
Router> systat all

      Line      User      Host(s)              Idle Location
      0 con 0
      1 aux 0
      * 2 vty 0   cma         idle                 0 USER-MAC.COMPANY.COM
      3 vty 1
      4 vty 2
      5 vty 3
      6 vty 4
      0 NAME.COMPANY.COM
```

Table 1-16 describes the fields shown in the display.

Table 1-16 Systat Field Descriptions

Field	Description
Line	<p>Contains three subfields. The asterisk (*) identifies the line of the user entering the command.</p> <p>The first subfield (2, in this case) is the absolute line number.</p> <p>The second subfield (vty, in this case) indicates the type of line. Possible values follow:</p> <ul style="list-style-type: none"> con—Console aux—Auxiliary port vty—Virtual terminal <p>The third subfield (0, in this case) indicates the relative line number within type.</p>
User	Name of user using the line. If this field is blank, no user is using the line.
Host(s)	Host to which the user is connected (outgoing connection). A value of idle indicates no outgoing connection to a host.
Idle	Interval (in minutes) since the user has typed something.
Location	Either the hardwired location for the line or, if there is an incoming connection, the host the incoming connection is from.

telnet (EXEC)

To start a Telnet connection, enter the **telnet** EXEC command.

```
telnet host [port] [keyword]
```

Syntax Description

<i>host</i>	A host name or an Internet address.
<i>port</i>	(Optional.) Decimal TCP port number; the default is the Telnet server port (decimal 23) on the host.
<i>keyword</i>	(Optional.) Keyword that can be set with the connection; see Table 1-17 for a list of keywords.

Table 1-17 Telnet (EXEC) Keywords

Keyword	Description
/route: <i>path</i>	Specifies loose source routing. The argument <i>path</i> is a list of host names or Internet addresses that specifies network nodes, ending with the final destination.
/line	Enables Telnet line mode. In this mode, the router does not send any data to the host until you press Return. You can edit the line using the standard router command editing characters (Backspace, Delete, Ctrl-U, Ctrl-W). The /line keyword is a local switch; the remote server is not notified of the mode change.
/debug	Enables Telnet debugging mode.
/echo	Enables local echoing of characters (default). The /echo keyword is a local switch; the remote server is not notified of the state change.
/stream	Turns on stream processing, which enables a raw TCP stream with no Telnet control sequences. A stream connection does not process Telnet options and may be appropriate for connections to ports running UUCP and other non-Telnet protocols.

Command Mode

EXEC

Usage Guidelines

The router assigns a logical name to each connection; several commands use these names to identify connections. The logical name is the same as the host name, unless that name is already in use or you change the connection name with the EXEC command **name-connection**. If the name is already in use, the router assigns a null name to the connection.

To obtain an onscreen list of Telnet special sequence commands, enter the **Ctrl-^?** sequence at the EXEC prompt. The system administrator can change the escape character portion of this sequence; use the **show terminal** EXEC command to check the current setting for the escape character. To enter the escape sequence, press and hold the Ctrl, Shift, and 6 keys, then let go and press the X key.

Examples

The following example routes packets from the source system to kl.sri.com, then to 10.1.0.11, and finally to mathom:

```
Router> connect mathom /route:kl.sri.com 10.1.0.11 mathom
```

The following example connects to a host with logical name mathom:

```
Router> mathom
```

The following example shows the online table displayed when the **Ctrl-^?** sequence is entered. (Note that the sequence will not appear on your terminal.)

```
Router> <Ctrl-^ ?>

[Special telnet escape help]
^^B  sends telnet BREAK
^^C  sends telnet IP
^^H  sends telnet EC
^^O  sends telnet AO
^^T  sends telnet AYT
^^U  sends telnet EL
```

Related Commands

connect

name-connection

terminal data-character-bits

To set the number of data bits per character that are interpreted and generated by software for the current line, use the **terminal data-character-bits** EXEC command.

terminal data-character-bits {7 | 8}

Syntax Description

7 Seven data bits per character.

8 Eight data bits per character.

Default

8 data bits per character

Command Mode

EXEC

Usage Guidelines

The **terminal data-character-bits** command is used primarily to strip parity from X.25 connections on IGS or Cisco 3000 routers with the protocol translation software option. The **terminal data-character-bits** command does not work on hardwired lines.

Example

The following example shows how to change the data bits per character to 7:

```
terminal data-character-bits 7
```


terminal databits

To set the number of data bits per character that are interpreted and generated by hardware for the current terminal line, use the **terminal databits** EXEC command.

terminal databits {5 | 6 | 7 | 8}

Syntax Description

- 5** Five databits per character.
- 6** Six databits per character.
- 7** Seven databits per character.
- 8** Eight databits per character.

Default

8 data bits per character

Command Mode

EXEC

Usage Guidelines

The **terminal databits** command can be used to mask the high bit on input from devices that generate 7 data bits with parity. If parity is being generated, specify 7 data bits per character. If no parity generation is in effect, specify 8 data bits per character. The other keywords are supplied for compatibility with older devices and generally are not used.

Example

The following example shows how to change the data bits per character to 7:

```
terminal databits 7
```

terminal dispatch-character

To define a character that causes a packet to be sent for the current terminal line, use the **terminal dispatch-character EXEC** command. Use the **terminal no dispatch-character** command to remove the dispatch characters.

```
terminal dispatch-character ASCII-number1 [ASCII-number2 . . . ASCII-number]  
terminal no dispatch-character
```

Syntax Description

ASCII-number ASCII decimal representation of the character, such as Return (ASCII character 13) for line-at-a-time transmissions. The command can take multiple arguments, so you can define any number of characters as the dispatch character.

Default

None

Command Mode

EXEC

Usage Guidelines

This command defines a dispatch character that causes packets to be sent even if the dispatch timer has not expired. It causes the router to attempt to buffer characters into larger-sized packets for transmission to the remote host. The router normally dispatches each character as it is typed. See Appendix D, "ASCII Character Set," for a list of ASCII characters.

Example

The following example defines the characters Ctrl-D and Ctrl-Y as the dispatch characters:

```
terminal dispatch-character 4 25
```

Related Command

terminal dispatch-timeout

terminal dispatch-timeout

To set the character dispatch timer for the current terminal line, use the **terminal dispatch-timeout** EXEC command. The **terminal no dispatch-timeout** command removes the timeout definition.

```
terminal dispatch-timeout milliseconds  
terminal no dispatch-timeout
```

Syntax Description

milliseconds An integer that specifies the number of milliseconds the router waits after putting the first character into a packet buffer before sending the packet. During this interval, more characters may be added to the packet, thus increasing the processing efficiency of the remote host.

Default

None

Command Mode

EXEC

Usage Guidelines

The **terminal dispatch-timeout** command causes the router to buffer characters into packets for transmission to the remote host. The router sends a packet a specified amount of time after the first character is put in the buffer. The router normally dispatches each character as it is entered. You can use the **terminal dispatch-timeout** and **terminal dispatch-character** commands together. In this case, the router dispatches a packet each time the dispatch character is entered, or after the specified dispatch timeout interval, depending on which condition is met first.

Note The router's response may appear intermittent if the timeout interval is greater than 100 milliseconds and remote echoing is used.

Example

The following example sets the dispatch timer to 80 milliseconds:

```
terminal dispatch-timeout 80
```

Related Command

terminal dispatch-character

terminal download

To temporarily set the ability of a line to act as a transparent pipe for file transfers, use the **terminal download** EXEC command. Use the **terminal no download** command to remove this ability.

terminal download
terminal no download

Syntax Description

This command has no arguments or keywords.

Default

Disabled

Command Mode

EXEC

Usage Guidelines

Use the **terminal download** command when running a program such as Kermit, Xmodem, or CrossTalk that downloads a file across a router line.

Example

The following example shows how to set up the current line for a Kermit file transfer:

```
terminal download
```

terminal editing

To enable the enhanced editing mode on the local line, use the **terminal editing** EXEC command. To disable the enhanced editing mode on the current line, use the **no** form of this command.

terminal editing
terminal no editing

Syntax Description

This command has no arguments or keywords.

Default

Enabled

Command Mode

EXEC

Usage Guidelines

Table 1-18 provides a description of the keys used to enter and edit commands. Ctrl indicates the Control key. It must be pressed simultaneously with its associated letter key. Esc indicates the Escape key. It must be pressed first, followed by its associated letter key. Keys are *not* case sensitive.

Table 1-18 Command Editing Keys and Functions

Keys	Function
Tab	Completes a partial command name entry. When you enter a unique set of characters and press the Tab key, the system completes the command name. If you enter a set of characters that could indicate more than one command, the system beeps to indicate an error. Enter a question mark (?) immediately following the partial command (no space). The system provides a list of commands that begin with that string.
Delete or Backspace	Erases the character to the left of the cursor.
Return	At the command line, pressing the Return key performs the function of processing, or carrying out, a command. At the “---More---” prompt on a terminal screen, pressing the Return key scrolls down a line.
Space Bar	Scrolls down a page on the terminal screen. Press the space bar when you see the line “---More---” on the screen to display the next screen.
Left Arrow ¹	Moves the cursor one character to the left. When you enter a command that extends beyond a single line, you can continue to press the left arrow key at any time to scroll back toward the system prompt and verify the beginning of the command entry.
Right Arrow ¹	Moves the cursor one character to the right.
Up Arrow ¹ or Ctrl-P	Recalls commands in the history buffer, beginning with the most recent command. Repeat the key sequence to recall successively older commands.
Down Arrow ¹ or Ctrl-N	Return to more recent commands in the history buffer after recalling commands with the Up Arrow or Ctrl-P. Repeat the key sequence to recall successively more recent commands.
Ctrl-A	Moves the cursor to the beginning of the line.
Ctrl-B	Moves the cursor back one character.
Ctrl-D	Deletes the character at the cursor.

Keys	Function
Ctrl-E	Moves the cursor to the end of the command line.
Ctrl-F	Moves the cursor forward one character.
Ctrl-K	Deletes all characters from the cursor to the end of the command line.
Ctrl-L and Ctrl-R	Redisplays the system prompt and command line.
Ctrl-T	Transposes the character to the left of the cursor with the character located at the cursor.
Ctrl-U and Ctrl-X	Deletes all characters from the cursor back to the beginning of the command line.
Ctrl-V and Esc Q	Inserts a code to indicate to the system that the key stroke immediately following should be treated as a command entry, <i>not</i> as an editing key.
Ctrl-W	Deletes the word to the left of the cursor.
Ctrl-Y	Recalls the most recent entry in the delete buffer. The delete buffer contains the last ten items you have deleted or cut. Ctrl-Y can be used in conjunction with Esc Y.
Ctrl-Z	Ends configuration mode and returns you to the EXEC prompt.
Esc B	Moves the cursor back one word.
Esc C	Capitalizes the word at the cursor.
Esc D	Deletes from the cursor to the end of the word.
Esc F	Moves the cursor forward one word.
Esc L	Changes the word at the cursor to lowercase.
Esc U	Capitalizes from the cursor to the end of the word.
Esc Y	Recalls the next buffer entry. The buffer contains the last ten items you have deleted. Press Ctrl-Y first to recall the most recent entry. Then press Esc Y up to nine times to recall the remaining entries in the buffer. If you bypass an entry, continue to press Esc Y to cycle back to it.

1. The arrow keys function only with ANSI-compatible terminals.

The editing keys and functions of the earlier software release are listed in Table 1-19.

Table 1-19 Editing Keys and Functions for Software Release 9.1 and Earlier

Key	Function
Delete or Backspace	Erases the character to the left of the cursor.
Ctrl-W	Erases a word.
Ctrl-U	Erases a line.
Ctrl-R	Redisplays a line.
Ctrl-Z	Ends configuration mode and returns to the EXEC prompt.
Return	Executes single-line commands.

Example

In the following example, enhanced mode editing is reenabled for the current terminal session:

```
terminal editing
```

Related Command

A dagger (†) indicates that the command is documented in another chapter.

editing †

terminal escape-character

To set the escape character for the current terminal line, use the **terminal escape-character EXEC** command. The **terminal no escape-character** command sets the escape character to Break.

terminal escape-character *ASCII-number*
terminal no escape-character

Syntax Description

ASCII-number Either the ASCII decimal representation of the desired escape character or a control sequence (Ctrl-P, for example).

Default

Ctrl-^

Command Mode

EXEC

Usage Guidelines

Typing the escape character followed by the X key returns you to the EXEC when you are connected to another computer. See Appendix D, “ASCII Character Set,” for a list of ASCII characters.

Note The Break key cannot be used as an escape character on the console terminal because the operating software interprets Break as an instruction to halt the system.

Example

The following example sets the escape character to Ctrl-P (ASCII decimal 16).

```
terminal escape-character 16
```


terminal exec-character-bits

To change the ASCII character widths for characters entered for the current terminal line, use the **terminal exec-character-bits** EXEC command.

```
terminal exec-character-bits {7 | 8}
```

Syntax Description

- | | |
|----------|--|
| 7 | Selects the 7-bit ASCII character set. |
| 8 | Selects the full 8-bit character set. |

Default

7-bit ASCII character set

Command Mode

EXEC

Usage Guidelines

This EXEC command overrides the **default-value exec-character-bits** global configuration command. Configuring the EXEC character width to 8 bits allows you to add special graphical and international characters in banners, prompts, and so forth.

When the user exits the system, the character width is reset to the default value established by the global configuration command. However, setting the EXEC character width to 8 bits can also cause failures. If a user on a terminal that is sending parity enters the command **help**, an “unrecognized command” message appears because the system is reading all 8 bits, although the eighth bit is not needed for the **help** command.

Example

The following example temporarily configures a router to use a full 8-bit user interface for system banners and prompts. This allows the use of additional graphical and international characters.

```
terminal exec-character-bits 8
```

Related Commands

A dagger (†) indicates that the command is documented in another chapter.

default-value exec-character-bits †
default-value special-character-bits †
exec-character-bits †
special-character-bits †
terminal special-character-bits

terminal flowcontrol

To set up the method of data flow control for the current terminal line, use the **terminal flowcontrol EXEC** command.

terminal flowcontrol { none | software [in | out] | hardware }

Syntax Description

- | | |
|-----------------|--|
| none | Prevents flowcontrol. |
| software | Sets software flow control. An optional keyword specifies the direction: in causes the router to listen to flow control from the attached device, and out causes the router to send flow control information to the attached device. If you do not specify a direction, both directions are assumed. |
| hardware | Sets hardware flow control. For information about setting up the RS-232 line, see the hardware manual for your product. |

Default

By default, no flow control method is set. This default is returned with the **none** keyword. For software flow control, the default stop and start characters are Ctrl-S and Ctrl-Q (XOFF and XON). You can change them with the **terminal stop-character** and **terminal start-character** commands.

Command Mode

EXEC

Usage Guidelines

This command pertains to the auxiliary port only.

Example

The following example sets incoming software flow control:

```
terminal flowcontrol software in
```

Related Commands

terminal start-character
terminal stop-character

terminal full-help

To get help for the full set of user-level commands, use the **terminal full-help** EXEC command.

terminal full-help

Syntax Description

This command has no arguments or keywords.

Command Mode

EXEC

Example

The following example displays full help:

```
terminal full-help
```

Related Command

full-help

terminal history size

To change the command history buffer size for the current terminal session, use the **terminal history size** EXEC command. To revert to the default value, use the **no** form of this command.

terminal history size *number of lines*
terminal no history size

Syntax Description

number of lines Number of command lines that the system will record in its history buffer. The range is 0 to 256.

Default

10 lines

Command Mode

EXEC

Usage Guidelines

The command history feature provides a record of EXEC commands you have entered. This feature is particularly useful to recall long or complex commands or entries, including access lists.

Table 1-20 lists the keys and functions you can use to recall commands from the history buffer.

Table 1-20 History Keys

Key	Function
Ctrl-P or Up Arrow ¹	Recalls commands in the history buffer in a backward sequence, beginning with the most recent command. Repeat the key sequence to recall successively older commands.
Ctrl-N or Down Arrow ¹	Returns to more recent commands in the history buffer after recalling commands with Ctrl-P or the Up Arrow. Repeat the key sequence to recall successively more recent commands.

1. The arrow keys function only with ANSI-compatible terminals such as VT100s.

Example

In the following example, the number of command lines recorded is set to 15 for the local line:

```
terminal history size 15
```

Related Commands

history size
show history

terminal hold-character

To set the hold character, use the **terminal hold-character** EXEC command. Use the **terminal no hold-character** command to restore the default.

terminal hold-character *ASCII-number*
terminal no hold-character

Syntax Description

ASCII-number Either the ASCII decimal representation of the hold character or a control sequence (for example, Ctrl-P).

Default

None

Command Mode

EXEC

Usage Guidelines

Typing the hold character temporarily halts the output at the terminal. To continue the output, type any other character. To send the hold character to the host, precede it with the escape character.

The Break character is represented by zero; NULL cannot be represented.

See Appendix D, “ASCII Character Set,” for a list of ASCII characters.

Note You cannot suspend output on the console terminal.

Example

The following example removes the previously set hold character:

```
terminal no hold-character
```

Related Command

A dagger (†) indicates that the command is documented in another chapter.

hold-character †

terminal length

To set the number of lines on the current terminal screen, use the **terminal length** EXEC command. The **terminal no length** command is the same as entering a value of zero.

terminal length *screen-length*
terminal no length

Syntax Description

screen-length The desired number of lines. The router uses this value to determine when to pause during multiple-screen output. The default length is 24 lines. A value of zero disables pausing between screens of output.

Default

24 lines

Command Mode

EXEC

Usage Guidelines

The screen length specified can be learned by remote hosts.

Example

The following example disables pausing between screen output:

```
terminal length 0
```

terminal monitor

To set the ability to display **debug** command output and system error messages to the current terminal, use the **terminal monitor** EXEC command. Use the **terminal no monitor** command to disable this ability.

terminal monitor
terminal no monitor

Syntax Description

This command has no arguments or keywords.

Default

Disabled

Command Mode

EXEC

Usage Guidelines

To use this command, you must first issue the **enable** command and enter the password to access the privileged EXEC command mode.

Example

The following example illustrates how to enable the system debugging messages on the local terminal screen:

```
terminal monitor
```

terminal notify

To enable terminal notification about pending output from other connections, use the **terminal notify** EXEC command. Use the **terminal no notify** command to end such notifications.

terminal notify
terminal no notify

Syntax Description

This command has no arguments or keywords.

Default

Disabled

Command Mode

EXEC

Usage Guidelines

This command sets a line to inform a user who has multiple, concurrent Telnet connections when output is pending on a connection other than the current one. When you have multiple concurrent connections, you might want to know when output is pending on a connection other than the current connection. For example, you might want to know when another connection receives mail or a message. The **terminal notify** command causes the router to notify you of pending output.

Example

The following example sets up notification to the current line of e-mail messages on the other open connection:

```
terminal notify
```


terminal padding

To set the padding on a specific output character for the current terminal line, use the **terminal padding** EXEC command. The **terminal no padding** command removes padding for the specified output character.

terminal padding *ASCII-number count*

terminal no padding *ASCII-number*

Syntax Description

ASCII-number ASCII decimal representation of the character.

count Number of NULL bytes sent after the ASCII character, up to 255 padding characters in length.

Default

None

Command Mode

EXEC

Usage Guidelines

See Appendix D, “ASCII Character Set,” for a list of ASCII characters.

Example

The following example pads Ctrl-D (ASCII 4) with 164 NULL bytes:

```
terminal padding 4 164
```

terminal parity

To define the generation of the parity bit for the current terminal line, use the **terminal parity EXEC** command.

terminal parity { none | even | odd | space | mark }

Syntax Description

- none** No parity.
- even** Even parity.
- odd** Odd parity.
- space** Space parity.
- mark** Mark parity.

Default

No parity

Command Mode

EXEC

Example

The following example shows how to set the parity bit to odd:

```
terminal parity odd
```

terminal rxspeed

To set the terminal baud rate receive (from terminal) speed for the current terminal line, use the **terminal rxspeed** EXEC command.

```
terminal rxspeed bps
```

Syntax Description

bps Baud rate in bits per second (bps); see Table 1-21 for settings.

Default

9600 bps

Command Mode

EXEC

Usage Guidelines

Use Table 1-21 as a guide for setting the line speeds.

Table 1-21 Router Line Speeds in Bits per Second

Router Model	Baud Rates
Cisco 7000, AGS, CGS, MGS	50, 75, 110, 134, 150, 200, 300, 600, 1050, 1200, 2000, 2400, 4800, 9600, 19200, 38400
IGS, Cisco 2000, Cisco 3000, Cisco 4000	75, 110, 134, 150, 300, 600, 1200, 1800, 2000, 2400, 4800, 9600, 19200, 38400

Example

The following example sets the current auxiliary line receive speed to 2400 bps:

```
terminal rxspeed 2400
```

Related Commands

terminal speed

terminal txspeed

terminal special-character-bits

To change the ASCII character widths to accept special characters for the current terminal line, use the **terminal special-character-bits** EXEC command.

```
terminal special-character-bits {7 | 8}
```

Syntax Description

- | | |
|----------|--|
| 7 | Selects the 7-bit ASCII character set. |
| 8 | Selects the full 8-bit character set. |

Default

7-bit ASCII character set

Command Mode

EXEC

Usage Guidelines

The **terminal special-character-bits** command temporarily allows the server to support international character sets. It overrides the **default-value special-character-bits** global configuration command and is used to compare character sets typed by the user with the special character available during a data connection, which includes software flow control and escape characters. Configuring the width to 8 allows you to use twice as many special characters as with the 7-bit setting. When the user exits the system, the command is reset to the default value established by the global configuration command.

Example

The following example temporarily configures full 8-bit comparisons of flow control and interrupt characters to allow more special characters to be accepted. When you exit the system, character width will be reset to the width established by the global configuration command.

```
terminal special-character-bits 8
```

Related Commands

A dagger (†) indicates that the command is documented in another chapter.

default-value exec-character-bits †
default-value special-character-bits †
exec-character-bits †
special-character-bits †
terminal exec-character-bits

terminal speed

To set the terminal baud rate for the current terminal line, use the **terminal speed** EXEC command. The command sets both the transmit (to terminal) and receive (from terminal) speeds.

terminal speed *bps*

Syntax Description

bps Baud rate in bits per second (bps), see Table 1-22 for settings.

Default

9600 bps

Command Mode

EXEC

Usage Guidelines

Set the speed to match the baud rate of whatever device you have connected to the port. Some baud rates available on devices connected to the port might not be supported on the router. The router will indicate if the speed you select is not supported. Use Table 1-22 as a guide for setting the line speeds.

Table 1-22 Router Line Speeds in Bits per Second

Router Model	Baud Rates
Cisco 7000, AGS, CGS, MGS	50, 75, 110, 134, 150, 200, 300, 600, 1050, 1200, 2000, 2400, 4800, 9600, 19200, 38400
IGS, Cisco 2000, Cisco 3000, Cisco 4000	75, 110, 134, 150, 300, 600, 1200, 2000, 2400, 4800, 1800, 9600, 19200, 38400

Example

The following example sets the current auxiliary line receive and transmit speed to 2400 bps:

```
terminal speed 2400
```

Related Commands

terminal rxspeed

terminal txspeed

terminal start-character

To set the flow control stop character for the current terminal line, use the **terminal start-character** EXEC command. The command defines the character that signals the start of data transmission when software flow control is in effect. Use the **terminal no start-character** command to remove the start character.

```
terminal start-character ASCII-number  
terminal no start-character
```

Syntax Description

ASCII-number ASCII decimal representation of the start character.

Default

Ctrl-Q (ASCII character 17)

Command Mode

EXEC

Usage Guidelines

See Appendix D, “ASCII Character Set,” for a list of ASCII characters.

Example

The following example changes the start character to Ctrl-O (ASCII decimal 15):

```
terminal start-character 15
```

Related Command

A dagger (†) indicates that the command is documented in another chapter.

```
start-character †
```

terminal stop-character

To set the flow control stop character for the current terminal line, use the **terminal stop-character EXEC** command. The command defines the character that signals the end of data transmission when software flow control is in effect. The **terminal no stop-character** command removes the character.

```
terminal stop-character ASCII-number  
terminal no stop-character
```

Syntax Description

ASCII-number ASCII decimal representation of the stop character.

Default

Ctrl-S (ASCII character 19)

Command Mode

EXEC

Usage Guidelines

See Appendix D, “ASCII Character Set,” for a list of ASCII characters.

Example

The following example changes the stop character to Ctrl-E, which is ASCII decimal 5:

```
terminal stop-character 5
```

Related Command

A dagger (†) indicates that the command is documented in another chapter.

```
stop-character †
```

terminal stopbits

To set the number of stop bits transmitted per byte by the current terminal line, use the **terminal stopbits** EXEC command.

```
terminal stopbits {1 | 1.5 | 2}
```

Syntax Description

- 1** One stop bit.
- 1.5** One and a half stop bits.
- 2** Two stop bits.

Default

2 stop bits

Command Mode

EXEC

Example

The following example illustrates how to change the stop bits to 1:

```
terminal stopbits 1
```

Related Command

A dagger (†) indicates that the command is documented in another chapter.

stopbits †

terminal telnet break-on-ip

To cause the system to generate a hardware Break signal on the RS-232 line that is associated with a reverse Telnet connection for the current line, use the **terminal telnet break-on-ip EXEC** command.

terminal telnet break-on-ip

Syntax Description

This command has no arguments or keywords.

Default

None

Command Mode

EXEC

Usage Guidelines

Occurs when a Telnet Interrupt-Process (IP) command is received on that connection. This command can be used to control the translation of Telnet IP commands into X.25 Break indications.

This command is also a useful workaround in the following situations:

- Several user Telnet programs send an IP command, but cannot send a Telnet break signal.
- Some Telnet programs implement a Break signal that sends an IP command.
- Some RS-232 hardware devices use a hardware Break signal for various purposes. A hardware Break signal is generated when a Telnet Break command is received.

Example

The following example shows how to generate a Break signal on the RS-232 line:

```
line aux 0
terminal telnet break-on-ip
```

Related Commands

A dagger (†) indicates that the command is documented in another chapter.

telnet (EXEC) †

telnet break-on-ip †

terminal telnet refuse-negotiations

To set the current line to refuse to negotiate full duplex, remote echo options on incoming connections, use the **terminal telnet refuse-negotiations** EXEC command.

terminal telnet refuse-negotiations

Syntax Description

This command has no arguments or keywords.

Default

None

Command Mode

EXEC

Usage Guidelines

This command is used on reverse Telnet connections to allow the router to refuse these requests from the other end. This command suppresses negotiation of the Telnet Remote Echo and Suppress Go Ahead options.

Example

The following example shows how to set the auxiliary port to refuse full duplex, remote echo requests:

```
line aux 0
terminal telnet refuse-negotiations
```

Related Commands

A dagger (†) indicates that the command is documented in another chapter.

telnet (EXEC) †

telnet refuse-negotiations †

terminal telnet speed

To allow the router to negotiate transmission speed for the current line, use the **terminal telnet speed** EXEC command.

terminal telnet speed *default-speed maximum-speed*

Syntax Description

default-speed Line speed (in bps) that the router will use if the device on the other end of the connection has not specified a speed.

maximum-speed Maximum speed (in bps) that the device on the port will use.

Default

None

Command Mode

EXEC

Usage Guidelines

You can match line speeds on remote systems in reverse Telnet, on host machines hooked up to a router to access the network, or on a group of console lines hooked up to the router, when disparate line speeds are in use at the local and remote ends of the connection. Line speed negotiation adheres to the Remote Flow Control option, defined in RFC 1080.

Example

The following example allows the router to negotiate a bit rate on the line using the Telnet option. If no speed is negotiated, the line will run at 2400 bps. If the remote host requests a speed of greater than 9600 bps, then 9600 bps will be used.

```
line aux 0
terminal telnet speed 2400 9600
```

Related Commands

A dagger (†) indicates that the command is documented in another chapter.

telnet (EXEC) †

telnet speed †

terminal telnet sync-on-break

To cause the router to send a Telnet Synchronize signal when it receives a Telnet Break signal on the current line, use the **terminal telnet sync-on-break** EXEC command.

terminal telnet sync-on-break

Syntax Description

This command has no arguments or keywords.

Default

None

Command Mode

EXEC

Example

The following example shows how to set the auxiliary port to cause the router to send a Telnet synchronize signal:

```
line aux 0
terminal telnet sync-on-break
```

Related Commands

A dagger (†) indicates that the command is documented in another chapter.

telnet (EXEC) †

telnet sync-on-break †

terminal telnet transparent

To cause the router to send a Return (CR) as a CR followed by a NULL instead of a CR followed by a Line Feed (LF) on the current line, use the **terminal telnet transparent EXEC** command.

terminal telnet transparent

Syntax Description

This command has no arguments or keywords.

Default

None

Command Mode

EXEC

Usage Guidelines

This command is useful for coping with different interpretations of end-of-line handling in the Telnet protocol specification.

Example

The following example sets the router, when sending a CR, to send a CR followed by a NULL character:

```
terminal telnet transparent
```

Related Commands

A dagger (†) indicates that the command is documented in another chapter.

telnet (EXEC) †

telnet transparent †

terminal terminal-type

To specify the type of terminal connected to the current line, use the **terminal terminal-type** EXEC command. The command records the type of terminal connected to the line. The **terminal no terminal-type** command removes any information about the type of terminal and resets the line to the default terminal emulation.

terminal terminal-type *terminal-name*
terminal no terminal-type

Syntax Description

terminal-name Terminal name and type.

Default

VT100

Command Mode

EXEC

Usage Guidelines

The argument *terminal-name* provides a record of the terminal type and allows terminal negotiation of display management by hosts that provide that type of service.

Example

The following example defines the terminal as a type VT220 during the current session:

```
terminal terminal-type VT220
```

Related Command

A dagger (†) indicates that the command is documented in another chapter.

terminal-type †

terminal transport

To specify a default transport protocol for the router to use for the current session (if the user does not specify a protocol), use the **terminal transport** EXEC command. Also use to prevent any connection attempts.

```
terminal transport {telnet | none}
```

Syntax Description

telnet Specifies all types of incoming TCP/IP connections.

none Prevents any protocol selection on the line. This makes the port unusable by incoming connections.

Default

telnet

Command Mode

EXEC

Example

The following example illustrates how to configure the console to not try to connect when an unrecognized command is entered:

```
terminal transport none
```

Related Command

A dagger (†) indicates that the command is documented in another chapter.

transport preferred[†]

terminal txspeed

To set the terminal transmit baud rate (to terminal) on the current terminal line, use the **terminal txspeed EXEC** command.

```
terminal txspeed bps
```

Syntax Description

bps Baud rate in bits per second (bps); see Table 1-23 for settings.

Default

9600 bps

Command Mode

EXEC

Usage Guidelines

Set the speed to match the baud rate of whatever device you have connected to the port. Some baud rates available on devices connected to the port might not be supported on the router. The router will indicate if the speed you select is not supported. Use the following table as a guide for setting the line speeds.

Table 1-23 Router Line Speeds in Bits per Second

Router Model	Baud Rates
Cisco 7000, AGS, CGS, MGS	50, 75, 110, 134, 150, 200, 300, 600, 1050, 1200, 2000, 2400, 4800, 9600, 19200, 38400
IGS, Cisco 2000, Cisco 3000, Cisco 4000	75, 110, 134, 150, 300, 600, 1200, 2000, 2400, 4800, 1800, 9600, 19200, 38400

Example

The following example sets the current auxiliary line transmit speed to 2400 bps:

```
terminal txspeed 2400
```

Related Commands

terminal rxspeed

terminal speed

terminal width

To set the number of character columns on the terminal screen for the current line, use the **terminal width** EXEC command.

terminal width *characters*

Syntax Description

characters Number of character columns displayed on the terminal.

Default

80 character columns

Command Mode

EXEC

Usage Guidelines

The width specified can be learned by remote hosts.

Example

The following example sets the terminal character columns to 132:

```
terminal width 132
```

Related Command

A dagger (†) indicates that the command is documented in another chapter.

width †

where

To display information about all open Telnet connections associated with the current terminal line, enter the **where** EXEC command at the system prompt.

where

Syntax Description

This command has no arguments or keywords.

Command Mode

EXEC

Example

The following example shows output from the **where** command:

```
Router> where

Conn Host          Address           Byte  Idle Conn Name
  1 MIS1           131.108.19.50    0     0   MIS1
*  2 OTTER         192.31.7.24      0     0   OTTER
```

The information displayed includes the host name, address, number of characters waiting to be sent to the terminal, idle time, and connection name. An asterisk (*) indicates the current connection.

Related Commands

connect

name-connection

telnet (EXEC)