

Cisco BPX 8600 Series Reference

Release 9.1
May 1998

Corporate Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA

<http://www.cisco.com>

Tel: 408 526-4000
800 553-NETS (6387)

Fax: 408 526-4100

Customer Order Number: DOC-785391=
Text Part Number: 78-5391-01

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The following information is for FCC compliance of Class A devices: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to correct the interference at their own expense.

The following information is for FCC compliance of Class B devices: The equipment described in this manual generates and may radiate radio-frequency energy. If it is not installed in accordance with Cisco's installation instructions, it may cause interference with radio and television reception. This equipment has been tested and found to comply with the limits for a Class B digital device in accordance with the specifications in part 15 of the FCC rules. These specifications are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation.

You can determine whether your equipment is causing interference by turning it off. If the interference stops, it was probably caused by the Cisco equipment or one of its peripheral devices. If the equipment causes interference to radio or television reception, try to correct the interference by using one or more of the following measures:

- Turn the television or radio antenna until the interference stops.
- Move the equipment to one side or the other of the television or radio.
- Move the equipment farther away from the television or radio.
- Plug the equipment into an outlet that is on a different circuit from the television or radio. (That is, make certain the equipment and the television or radio are on circuits controlled by different circuit breakers or fuses.)

Modifications to this product not authorized by Cisco Systems, Inc. could void the FCC approval and negate your authority to operate the product.

The following third-party software may be included with your product and will be subject to the software license agreement:

CiscoWorks software and documentation are based in part on HP OpenView under license from the Hewlett-Packard Company. HP OpenView is a trademark of the Hewlett-Packard Company. Copyright © 1992, 1993 Hewlett-Packard Company.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

Network Time Protocol (NTP). Copyright © 1992, David L. Mills. The University of Delaware makes no representations about the suitability of this software for any purpose.

Point-to-Point Protocol. Copyright © 1989, Carnegie-Mellon University. All rights reserved. The name of the University may not be used to endorse or promote products derived from this software without specific prior written permission.

The Cisco implementation of TN3270 is an adaptation of the TN3270, curses, and termcap programs developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981-1988, Regents of the University of California.

Cisco incorporates Fastmac and TrueView software and the RingRunner chip in some Token Ring products. Fastmac software is licensed to Cisco by Madge Networks Limited, and the RingRunner chip is licensed to Cisco by Madge NV. Fastmac, RingRunner, and TrueView are trademarks and in some jurisdictions registered trademarks of Madge Networks Limited. Copyright © 1995, Madge Networks Limited. All rights reserved.

XRemote is a trademark of Network Computing Devices, Inc. Copyright © 1989, Network Computing Devices, Inc., Mountain View, California. NCD makes no representations about the suitability of this software for any purpose.

The X Window System is a trademark of the X Consortium, Cambridge, Massachusetts. All rights reserved.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

AccessPath, AtmDirector, the CCIE logo, CD-PAC, Centri, Changing the Way We Work, Live, Play, and Learn, the Cisco Capital logo, *CiscoLink*, the Cisco NetWorks logo, the Cisco Powered Network logo, the Cisco Press logo, ClickStart, ControlStream, DAGAZ, Fast Step, FireRunner, IGX, JumpStart, Kernel Proxy, LoopRunner, MGX, Natural Network Viewer, NetRanger, NetSonar, *Packet*, PIX, Point and Click Internetworking, Policy Builder, RouteStream, Secure Script, SMARTnet, SpeedRunner, Stratum, StreamView, *The Cell*, TrafficDirector, TransPath, VirtualStream, VlanDirector, Workgroup Director, and Workgroup Stack are trademarks; Empowering the Internet Generation is a service mark; and BPX, Catalyst, Cisco, Cisco IOS, the Cisco IOS logo, Cisco Systems, the Cisco Systems logo, Enterprise/Solver, EtherChannel, FastHub, FastPacket, ForeSight, FragmentFree, IPX, LightStream, MICA, Phase/IP, StrataSphere, StrataView Plus, and SwitchProbe are registered trademarks of Cisco Systems, Inc. in the U.S. and certain other countries. All other trademarks mentioned in this document are the property of their respective owners.

Cisco BPX 8600 Series Reference
Copyright © 1998, Cisco Systems, Inc.
All rights reserved. Printed in USA.
9804R

About This Manual **xxv**

- Objectives xxv
- Audience xxv
- Cisco WAN Switching Product Name Change xxv
- Organization xxvi
- Related Documentation xxviii
- Conventions xxviii

Chapter 1 **Introduction** **1-1**

- General Description 1-1
 - BPX Capabilities 1-1
 - Extended Services Processor 1-2
- New with Release 9.1 1-3
 - BPX Switch 1-3
 - MGX 8220 1-3
 - IGX Switch 1-3
- Continuing Features with Release 9.1 1-3
 - Cisco StrataView Plus Network Management 1-3
 - Network 1-4
 - BPX Switch 1-4
 - MGX 8220 1-6
 - IGX Switch 1-6
 - Access Products 1-6
- BPX Switch Operation 1-6
 - BPX Switch Operation 1-6
 - The BPX Switch with MGX 8220 Shelves 1-7
 - Tag Switching 1-7
 - The BPX Switch with Extended Services Processor 1-7
 - Frame Relay to ATM Interworking 1-7
 - Network Interworking 1-7
 - Service Interworking 1-9
 - Additional Information 1-9
 - Tiered Networks 1-9
 - Routing Hubs and Interface Shelves 1-10
 - BPX Switch Routing Hubs 1-11
 - Inverse Multiplexing ATM 1-12
 - Virtual Trunking 1-13
- Traffic and Congestion Management 1-14
 - FairShare™ 1-14
 - OptiClass™ 1-15
 - AutoRoute 1-15
 - Cost-Based AutoRoute 1-15
 - PNNI 1-16
 - Congestion Management, VS/VD 1-16
 - Congestion Management, ForeSight 1-16

	Network Management	1-17
	Network Interfaces	1-17
	Service Interfaces	1-18
	Statistical Alarms and Network Statistics	1-18
	Node Synchronization	1-18
	Switch Software Description	1-19
	Connections and Connection Routing	1-19
	Connection Routing Groups	1-20
	Cost-Based Connection Routing	1-21
	Major Features of Cost-Based AutoRoute	1-21
	Cost-Based AutoRoute Commands	1-23
	Network Synchronization	1-23
	Switch Availability	1-24
	Node Redundancy	1-24
	Node Alarms	1-24
Chapter 2	General Description	2-1
	Physical Description	2-1
	BPX Switch Enclosure	2-1
	Node Cooling	2-3
	Node DC Powering	2-3
	Optional AC Power Supply Assembly	2-4
	Card Shelf Configuration	2-5
	Functional Description	2-7
	ATM	2-7
	Physical Layer	2-7
	ATM Layer	2-7
	IPX and IGX Switch Trunk Interfaces to ATM	2-12
	BAM	2-13
	SAM	2-13
	CAM	2-13
	FastPacket Adaptation to ATM	2-14
	BPX Switch Major Groups	2-16
	Optional Peripherals	2-18
Chapter 3	BPX Switch Common Core	3-1
	BPX Switch Common Core Group	3-1
	Broadband Controller Card (BCC-32, BCC-3, BCC-4)	3-2
	Features	3-3
	Functional Description	3-4
	Front Panel Description	3-6
	19.2 Gbps Operation with the BCC-4	3-8
	Back Cards for the BCC-3 and BCC-32	3-8
	Alarm/Status Monitor Card	3-12
	Features	3-12
	Functional Description	3-12

	Front Panel Description	3-12
	Line Module for the Alarm/Status Monitor Card	3-15
	BPX Switch StrataBus 9.6 and 19.2 Gbps Backplanes	3-17
Chapter 4	Network Interface (Trunk) Cards	4-1
	BPX Switch Network Interface Group	4-1
	BXM Cards, Trunk Mode Summary	4-1
	Broadband Network Interface Cards (BNI-T3 and BNI-E3)	4-2
	Features	4-3
	Functional Description	4-3
	Egress	4-3
	Ingress	4-4
	Bandwidth Control	4-5
	Loopbacks and Diagnostics	4-6
	Front Panel Indicators	4-6
	T3 and E3 Line Modules (LM-3T3 and LM-3E3)	4-8
	Broadband Network Interface Cards, BNI-155	4-11
	Features	4-11
	Overview	4-11
	Functional Description	4-12
	Front Panel Indicators	4-13
	OC3, Line Modules (SMF, SMFLR, & MMF)	4-16
	Y-Cabling of BNI Backcard, SMF-2-BC	4-19
Chapter 5	Service Interface (Line) Cards	5-1
	BPX Switch Service Interface Group Summary	5-1
	BXM Cards, Port (UNI) Mode Summary	5-1
	ASI-1, ATM Service Interface Card	5-2
	Features	5-3
	Functional Description	5-3
	Configuring Connections (ATM over ASI Example)	5-4
	Monitoring Statistics	5-5
	Front Panel Description	5-5
	LM-2T3 Module	5-8
	LM-2E3 Module	5-10
	ASI-155, ATM Service Interface Card	5-12
	Features	5-12
	Overview	5-12
	Configuring Connections	5-13
	Functional Description	5-13
	Monitoring Statistics	5-14
	Front Panel Indicators	5-14
	ASI-155 Line Module, LM-2OC3-SMF	5-17

ASI-155 Line Module, LM-2OC3-SMFLR 5-17
 ASI-155 Line Module, LM-2OC3-MMF 5-17
 Y-Cabling of ASI Backcard, SMF-2-BC 5-17
 BXM Cards, Access (UNI) Mode 5-17

Chapter 6 BXM T3/E3, 155, and 622 6-1

Tag Switching 6-1
 Dynamic Resource Partitioning for SPVCs 6-2
 BXM Cards 6-2
 BXM Capabilities 6-5
 Features 6-5
 ATM Layer 6-6
 Service Types 6-7
 Card Operation 6-8
 BXM Front Card Indicators 6-8
 BXM, Backcard Connectors 6-12
 Y-Cabling of SMF-622 Series Backcards 6-16
 BXM Functional Description 6-17
 Overview, Port (UNI) Mode 6-17
 Ingress 6-17
 Egress 6-19
 Overview, Trunk Mode 6-20
 Ingress 6-20
 Egress 6-21
 Detailed Description, Port (UNI) and Trunk Modes 6-22
 DRSIU 6-22
 SONET/SDH UNI (SUNI) 6-22
 DeMux/Mux 6-22
 RCMP 6-22
 SABRE 6-23
 Ingress and Egress Queue Engines 6-23
 SIMBA 6-23
 ACP Subsystem Processor 6-23
 Fault Management and Statistics 6-24
 Fault Management and Statistics, Port (UNI) Mode 6-24
 Fault Management and Statistics, Trunk Mode 6-25
 Technical Specifications 6-26
 Physical Layer 6-26
 General Information 6-26
 General SONET Notes 6-27
 User Commands 6-28
 Connection Provisioning 6-28
 Diagnostics 6-28
 Test 6-28

	Statistics	6-28
	Configuring Connections	6-29
	Configuration Management	6-29
	Command Line Interface Examples	6-31
	Configuring the BPX Switch for SVCs	6-40
	Configuring the MGX 8220	6-40
	Resource Partitioning	6-41
	Tag Switching	6-41
	Dynamic Resource Partitioning for SPVCs	6-41
	Summary	6-41
	ASI SVC Resource Partitioning	6-42
	BXM SVC Resource Partitioning	6-44
	NNI Trunk SVC Resource Partitioning	6-45
	BNI Trunk SVC Resource Partitioning	6-46
	BXM Trunk SVC Resource Partitioning	6-47
Chapter 7	ATM Connections	7-1
	ATM Connection Services	7-1
	SVCs	7-2
	Traffic Management Overview	7-3
	Standard ABR notes:	7-4
	VSVD Description	7-4
	BXM Connections	7-4
	ForeSight Congestion Control	7-5
	ATM Connection Requirements	7-5
	Connection Routing	7-6
	Addcon Command Syntax	7-6
	ATM Connection Configuration	7-7
	CBR Connections	7-13
	VBR and ATFR Connections	7-14
	VBR Connections	7-14
	ATFR Connections	7-15
	ABR Notes	7-17
	ABR and ATFST Connections	7-17
	ABR Connections	7-17
	ATFST Connections	7-20
	UBR Connections	7-22
	Traffic Policing Examples	7-23
	Dual-Leaky Bucket (An Analogy)	7-23
	CBR Traffic Policing Examples	7-23
	VBR Dual-Leaky Bucket Policing Examples	7-26
	Leaky Bucket 1	7-28
	Leaky Bucket 2	7-28
	Examples	7-29
	ABR Connection Policing	7-35

	UBR Connection Policing	7-35
	Leaky Bucket 1	7-35
	Leaky Bucket 2	7-35
	Traffic Shaping for CBR, VBR, and UBR	7-37
	Configuration	7-37
	Traffic Shaping Rates	7-38
	LMI and ILMI Parameters	7-38
Chapter 8	ATM and Frame Relay SVCs, and SPVCs	8-1
	ATM and Frame Relay SVCs and SPVCs	8-1
	PVCs and SVCs	8-2
	PVCs	8-2
	SPVCs	8-2
	SVCs	8-3
	BPX Switch and ESP Interfaces	8-4
	Interim Inter-switch Protocol Routing	8-4
	PNNI	8-4
	Signaling Plane	8-5
	UNI Signaling Channel	8-5
	NNI Signaling Channel	8-6
	Network Interworking Between Frame Relay and ATM	8-7
	Extended Services Processor	8-8
	ESP Interfaces	8-8
	Stand-Alone ESP	8-9
	Redundant ESPs	8-9
	Y-Cable Redundancy	8-10
	Other Redundancy Options	8-11
	Network Management	8-11
	Resource Partitioning	8-11
Chapter 9	Tag Switching	9-1
	Introduction	9-1
	Tag Switching Benefits	9-2
	Tag Switching Overview	9-2
	Elements in a Tag Switching Network	9-3
	Tag Switching Operation at Layer 3	9-3
	Forwarding	9-3
	Control	9-4
	Tag Switching in an ATM WAN	9-4
	Forwarding	9-4
	Control	9-5
	Tag Switching and the BPX 8650	9-7

Virtual Switch Interfaces	9-9
Tag Switching Resource Configuration Parameters	9-11
Summary	9-11
Configuring VSI LCNS	9-12
Useful Default Allocations	9-13
Details of More Rigorous Allocations	9-14
Requirements	9-15
List of Terms	9-15
Related Documents	9-16
Configuration Management	9-16
Configuration Criteria	9-17
The cnfqbin Command	9-17
The cnfrsrc Command	9-17
Configuration Example	9-19
Checking and Troubleshooting	9-25
Provisioning and Managing Connections	9-29
Statistics	9-29
Command Reference	9-30
BPX Switch Commands	9-30
TSC Commands	9-30
addshelf	9-31
cnfqbin	9-34
cnfrsrc	9-36
Useful Default Allocations	9-38
Details of More Rigorous Allocations	9-39
Example 1, 8-Port OC3 BXM Configured in Trunk Mode	9-40
Example 2, 8-Port OC3 BXM Configured in Port Mode	9-43
dspcd	9-46
dspcds	9-47
dspnode	9-49
dspqbin	9-51
dsprsrc	9-53
dsptrks	9-54
resetcd	9-56
upport	9-57
uptrk	9-59

Chapter 10 BME Multicasting 10-1

Introduction	10-1
--------------	------

	Standards	10-2
	Multicasting Benefits	10-2
	Multicasting Overview	10-2
	BME Features:	10-2
	BME Requirements	10-2
	BME Restrictions	10-3
	Address Criteria	10-3
	Connection Management Criteria	10-3
	Connection Management with Cisco StrataView Plus	10-3
	BME Operation	10-4
	BME Cell Replication	10-4
	Cell Replication Stats	10-5
	Adding Connections	10-5
	Multi-Segment Multicast Connections	10-6
	Multicast Statistics	10-6
	Policing	10-7
	Alarms	10-7
	OAM cells	10-7
	AIS cells	10-8
	Hot Standby Backup	10-8
	Configuration	10-9
	Connection Diagnostics	10-9
	List of Terms	10-9
	Related Documents	10-9
	Configuration Management	10-9
Chapter 11	Repair and Replacement	11-1
	Preventive Maintenance	11-1
	Troubleshooting the BPX Switch	11-1
	General Troubleshooting Procedures	11-1
	Displaying the Status of Cards in the Node	11-4
	Replacing Parts	11-5
	Replacing a Front Card	11-5
	Replacing a Line Module	11-7
	Replacing a DC Power Entry Module	11-9
	Replacing an AC Power Supply	11-11
	Field-Installing a Second AC Power Supply	11-12
	Replacing the Fan Assembly	11-13
	Replacing the Temperature Sensing Unit	11-14
	Replacing Card Slot and Fan Fuses on the System Backplane	11-14

Chapter 12	Frame Relay to ATM Network and Service Interworking	12-1
	Service Interworking	12-3
	Networking Interworking	12-4
	ATM Protocol Stack	12-7
	AIT/BTM Interworking and the ATM Protocol Stack	12-8
	AIT/BTM Control Mapping, Frames and Cells	12-10
	Management, OAM Cells	12-11
	Functional Description	12-11
	ATF Summary	12-11
	Features	12-11
	Limitations	12-11
	Some ATF Connection Criteria	12-12
	Connection Management	12-12
	Port Management	12-12
	Structure	12-13
	Channel Statistics	12-13
	OAM Cell Support	12-14
	Diagnostics	12-14
	User Commands	12-15
	Virtual Circuit Features	12-15
	User Commands	12-16
	AUser Commands	12-16
	Management	12-16
	Connection Management	12-16
	Routing	12-17
	Bandwidth Management	12-17
	User Interface	12-17
	Port Management	12-17
	Connection Management	12-18
	Signaling	12-18
	Alarms	12-18

Chapter 13	Tiered Networks	13-1
	Routing Hubs and Interface Shelves	13-1
	BPX and IGX Routing Hubs	13-1
	BPX Routing Hubs in a Tiered Network	13-3
	Tiered Network Implementation	13-3
	General	13-4
	Definitions	13-4
	Upgrades	13-4
	Co-locating Routing Hubs and Interface Shelves	13-5
	Network Management	13-5
	ForeSight	13-6
	Preferred Routing	13-6
	Local and Remote Loopbacks	13-6

	Testcon and Testdly	13-6
	IPX Interface Shelf Description	13-6
	Configuration and Management	13-7
	Interface Shelf Management	13-7
	Alarm Management of Interface Shelf on the BPX Hub Node	13-7
	Alarm Management on the IPX Interface Shelf	13-8
	Port Management	13-8
	Connection Management	13-8
	Bandwidth Management	13-8
	Statistics	13-8
	IGX Routing Hubs in a Tiered Network	13-9
	Tiered Network Implementation	13-10
	General	13-11
	Definitions	13-12
	Upgrades	13-12
	Co-locating Routing Hubs and Shelves	13-12
	Network Management	13-12
	Preferred Routing	13-13
	Local and Remote Loopbacks	13-13
	Testcon and Testdly	13-13
	IGX Interface Shelf Description	13-13
	Configuration and Management	13-14
	Shelf Management	13-14
	13-14	
	Alarm Management of Interface Shelf on the IGX Hub Node	13-15
	Alarm Management on the IGX Interface Shelf	13-15
	Port Management	13-15
	Connection Management	13-15
	Bandwidth Management	13-15
	Bandwidth Efficiency	13-15
	Statistics	13-15
	User Interface Commands	13-15
	Shelf	13-15
	Data Connection Commands	13-16
	Data Channel Commands	13-16
	Voice Connection Commands	13-16
	Voice Channel Commands	13-16
	Cisco StrataView Plus NMS	13-17
Chapter 14	BPX SNMP Agent	14-1
	Introduction	14-1
	SNMP Overview	14-1
	SNMP Functions	14-3
	Responses to Get (Get-Next) Requests	14-4
	ATM Set Requests	14-4
	Responses to Set Requests	14-5
	MIB II Support	14-5

	Cisco WAN Switching Proprietary MIB Structure	14-6
	Switch Service Objects	14-6
	Switch Connections	14-6
	Bandwidth Class	14-7
	Endpoint Statistics	14-7
	Endpoint Mapping	14-7
Appendix A	BPX Node Specifications	A-1
	General	A-1
	ATM Trunk Interface (BXM-T3/E3 Cards)	A-3
	ATM Trunk Interface (BXM-155 Cards)	A-3
	ATM Trunk Interface (BXM-622 Cards)	A-5
	ATM T3 Trunk Interface (BNI-T3, LM-3T3)	A-6
	ATM E3 Trunk Interface (BNI-E3, LM-3E3)	A-7
	ATM OC3 Trunk Interface (BNI-OC3, LM-OC3)	A-8
	ATM Service Interface (BXM-T3/E3 Cards)	A-9
	ATM Service Interface (BXM-155 Cards)	A-9
	ATM Service Interface (BXM-622 Cards)	A-9
	ATM Service Interface (ASI-1, LM-2T3)	A-10
	ATM Service Interface (ASI-1, LM-2E3)	A-10
	ATM Service Interface (ASI-2, LM-OC3)	A-11
Appendix B	BPX Switch Cabling Summary	B-1
	Trunk Cabling	B-1
	Power Cabling	B-1
	AC Powered Nodes	B-1
	DC Powered Nodes	B-2
	LM-BCC Cabling	B-2
	Auxiliary and Control Port Cabling	B-2
	LAN Port Cabling	B-3
	Modem Cabling	B-3
	External Clock Input Cabling	B-4
	T1 Clock Cabling	B-4
	E1 Clock Cabling	B-5
	External Alarm Cabling	B-6
	Standard BPX Switch Cables	B-6
	Redundancy “Y” Cable	B-7
Appendix C	BPX Switch Peripherals	C-1
	Network Management	C-1
	Cisco StrataView Plus Terminal	C-1

	Control Port, Local Control	C-1
	Printer	C-2
	DIP Switch Settings for Okidata 184	C-2
	Modems, Dial-In and Dial-Out	C-4
	Motorola V.34R BPX Switch Dial-In Configuration	C-4
	BPX Switch Auto-Answer (Dial-In to BPX switch)	C-4
	IPX Auto-Dial to Customer Service	C-6
Appendix D	AT3-6ME Interface Adapter	D-1
	Application	D-1
	General Description	D-1
	Equipment Description	D-2
	Interface Connectors	D-2
	Front Panel Indicators	D-4
	DIP Switches	D-4
	Installation	D-6
	System Connections	D-6
	AT3-6ME Configuration	D-6
	BPX, IGX, or IPX Port Configuration	D-7
	Operation	D-7
	Power-Up Sequence	D-7
	Normal Operation	D-8
	Remote Loop Operation	D-8
	Terminal Operation	D-8
	Commands	D-9
	Specifications	D-10
	T3 interface	D-10
	T2 Interface	D-11
	Power	D-11
	Mechanical	D-11
	Terminal Interface	D-11
Appendix E	Glossary	E-1
	Index	

- Figure 1-1** BPX Switch General Configuration Example 1-2
- Figure 1-2** Frame Relay to ATM Network Interworking 1-8
- Figure 1-3** Frame Relay to ATM Service Interworking 1-9
- Figure 1-4** Tiered Network with BPX Switch and IGX Switch Routing Hubs 1-12
- Figure 1-5** Virtual Trunking Example 1-13
- Figure 2-1** BPX Switch Exterior Front View 2-2
- Figure 2-2** BPX Switch Exterior Rear View 2-3
- Figure 2-3** DC Power Entry Module Shown with Conduit Box Removed 2-4
- Figure 2-4** AC Power Supply Assembly Front View 2-5
- Figure 2-5** BPX Switch Card Shelf Front View 2-6
- Figure 2-6** B-ISDN Model 2-7
- Figure 2-7** ATM Cell Format 2-8
- Figure 2-8** UNI Header 2-9
- Figure 2-9** NNI Header 2-9
- Figure 2-10** STI Header 2-10
- Figure 2-11** SAR Adaptation Process 2-12
- Figure 2-12** BAM, CAM, and SAM Configurations 2-14
- Figure 2-13** Simple and Complex Gateway Formats 2-15
- Figure 2-14** Optional Peripherals Connected to BPX Switch 2-18
- Figure 3-1** Common Core Group Block Diagram 3-2
- Figure 3-2** BCC-32 and BCC-3 Block Diagram 3-5
- Figure 3-3** BCC-4 Block Diagram 3-6
- Figure 3-4** BCC Front Panel 3-7
- Figure 3-5** BCC-3-bc or BCC-c Face Plate Connectors 3-11
- Figure 3-6** ASM Front Panel Controls and Indicators 3-14
- Figure 3-7** LMI-ASM Face Plate 3-16
- Figure 4-1** BPX Switch Network Interface Group 4-2
- Figure 4-2** Simplified BNI-T3, BNI-E3 Block Diagram 4-4
- Figure 4-3** BNI-3T3 Front Panel (BNI-3E3 appears the same except for name) 4-7
- Figure 4-4** LM-3T3 Face Plate, Typical 4-9
- Figure 4-5** LM-3E3 Face Plate, Typica 4-10
- Figure 4-6** Simplified BNI-155 Block Diagram 4-13
- Figure 4-7** BNI-155 Front Panel 4-15
- Figure 4-8** LM-2OC3-SMF Face Plate 4-17

- Figure 4-9** LM-2OC3-MMF Face Plate 4-18
- Figure 4-10** Y-Cable (Model SMFY), LC-OC3-SMF (Model SMF-2-BC) 4-19
- Figure 5-1** BPX Switch Service Interface Group 5-2
- Figure 5-2** ASI-1 Simplified Block Diagram 5-3
- Figure 5-3** ATM Connection via ASI Ports 5-5
- Figure 5-4** ASI-1 Front Panel 5-7
- Figure 5-5** Line Module, ASI, 2T3 5-9
- Figure 5-6** Line Module, ASI, 2E3 5-11
- Figure 5-7** ASI-155 Simplified Block Diagram 5-14
- Figure 5-8** ASI-155 Front Panel 5-16
- Figure 6-1** A BPX Switch Network with BXM Cards 6-2
- Figure 6-2** BXM-622 Front Panel, Two-Port Card Shown 6-9
- Figure 6-3** BXM-155 Front Panel, Eight-Port Card Shown 6-10
- Figure 6-4** BXM-T3/E3 Front Panel, 12-Port Card Shown 6-11
- Figure 6-5** SMF-622-2, SMFLR-622-2, and SMFXLR-622-2 Back Card 6-13
- Figure 6-6** BXM-155-8 Port Backcard, MMF, SMF, or SMFLR 6-14
- Figure 6-7** BPX-T3/E3 Back Card, 12-Port Option Shown 6-15
- Figure 6-8** Y-Cabling of SMF-622 Series Backcards 6-16
- Figure 6-9** BXM Port (Access UNI) Ingress Operation 6-18
- Figure 6-10** BXM Port (Access, UNI) Egress Operation 6-19
- Figure 6-11** BXM Trunk Ingress Operation 6-20
- Figure 6-12** BXM Trunk Egress Operation 6-21
- Figure 6-13** SONET Section, Line, and Path 6-27
- Figure 7-1** ATM Connections over a BPX Switch Network 7-2
- Figure 7-2** ABR VSVD Flow Control Diagram 7-5
- Figure 7-3** CBR Connection Prompt Sequence 7-13
- Figure 7-4** VBR Connection Prompt Sequence 7-14
- Figure 7-5** ATFR Connection Prompt Sequence 7-16
- Figure 7-6** ABR Standard Connection Prompt Sequence 7-18
- Figure 7-7** Meaning of VSVD and Flow Control External Segments 7-19
- Figure 7-8** ABR ForeSight Connection Prompt Sequence 7-20
- Figure 7-9** ATFST Connection Prompt Sequence 7-21
- Figure 7-10** UBR Connection Prompt Sequence 7-22
- Figure 7-11** CBR Connection, UPC Overview 7-24

- Figure 7-12** CBR.1 Connection with Bucket Compliant 7-25
- Figure 7-13** CBR.1 Connection, with Bucket Discarding non-Compliant Cells 7-25
- Figure 7-14** VBR Connection, UPC Overview 7-27
- Figure 7-15** VBR Connection, Policing = 4, Leaky Bucket 1 Compliant 7-29
- Figure 7-16** VBR Connection, Policing = 4, Leaky Bucket 1 Non-Compliant 7-30
- Figure 7-17** VBR.2 Connection, Policing = 2, with Buckets 1 and 2 Compliant 7-31
- Figure 7-18** VBR.2 Connection, Leaky Bucket 2 Discarding CLP (0) Cells 7-32
- Figure 7-19** VBR.1 Connection, Policing = 1, with Buckets 1 and 2 Compliant 7-33
- Figure 7-20** VBR.3 Connection, Policing = 3, with Bucket 2 non-compliant 7-34
- Figure 7-21** UBR Connection, UPC Overview 7-36
- Figure 7-22** Traffic Shaping Example 7-37
- Figure 8-1** Wide Area Network with BPX Switch and ESP 8-2
- Figure 8-2** BPX Switch with ESP Network Signaling Plane 8-5
- Figure 8-3** UNI Signaling Channels 8-6
- Figure 8-4** ESP Signaling PVC 8-7
- Figure 8-5** ESP Physical Interfaces 8-8
- Figure 8-6** ESP Redundant Pair 8-10
- Figure 8-7** ESP Y-Cable Redundancy 8-10
- Figure 9-1** Tag Forwarding Information Base (TFIB) in an IP Packet Environment 9-4
- Figure 9-2** Tag Forwarding Information Base (TFIB) in an ATM Environment 9-5
- Figure 9-3** Downstream on Demand Tag Allocation, Conservative Mode Shown 9-6
- Figure 9-4** BPX Tag Switching 9-8
- Figure 9-5** BPX Switch VSI Interfaces 9-9
- Figure 9-6** Connection Setup, End Points on same VSI Slave 9-10
- Figure 9-7** Connection Setup, End Points on Different VSI Slaves 9-10
- Figure 9-8** Port VSI Partition LCN Allocation Elements 9-14
- Figure 9-9** BPX Tag Switching Router with BXM in Slot 4 9-19
- Figure 9-10** Port VSI Partition LCN Allocation Elements 9-39
- Figure 9-11** LCN Allocations for Ports 1-4, Ports Configured in Trunk Mode Example 9-42
- Figure 9-12** LCN Allocations for Ports 1-4, Ports Configured in Port Mode Example 9-45
- Figure 10-1** Replication of a Root Connection into Three Leaves 10-4
- Figure 10-2** Example of Traffic, one root and two leaves 10-5
- Figure 10-3** Adding Multicasting Connections 10-6
- Figure 10-4** Multi-Segment Multicast Connections 10-6

- Figure 10-5** Statistics Collection 10-7
- Figure 10-6** OAM Cells 10-7
- Figure 10-7** Alarms 10-8
- Figure 11-1** Unlatching the Air Intake Grille 11-7
- Figure 11-2** Removing a Line Module 11-9
- Figure 11-3** DC Power Entry Module with Conduit Box 11-10
- Figure 11-4** AC Power Supply Assembly 11-11
- Figure 11-5** Removing Blank Filler Panel (B side shown) 11-12
- Figure 11-6** Card Slot and Fan Fuse Locations on System Backplane 11-15
- Figure 12-1** Frame Relay to ATM Network Interworking 12-2
- Figure 12-2** Frame Relay to ATM Service Interworking 12-2
- Figure 12-3** Frame Relay to ATM Interworking Examples with AIT Card on IPX Switch 12-3
- Figure 12-4** Frame Relay to ATM Service Interworking Detail 12-4
- Figure 12-5** Frame Relay to ATM NW Interworking Detail 12-5
- Figure 12-6** ATF Connections, Simplified Example 12-6
- Figure 12-7** ATM Layers 12-7
- Figure 12-8** Protocol Stack Operation 12-9
- Figure 13-1** Tiered Network with BPX and IGX Routing Hubs 13-2
- Figure 13-2** Tiered Network with BPX Routing Hubs 13-3
- Figure 13-3** IGX Shelves and Routing Hubs, Voice and Data Connections 13-9
- Figure 13-4** IGX Shelves and Routing Hubs, Frame Relay Connections 13-10
- Figure 13-5** SV+ Connection Manager 13-17
- Figure 14-1** SNMP Manager and Agents in a BPX Domain 14-2
- Figure C-1** Dial-Modem Cabling for Auto Answer (Dial-In to BPX) C-5
- Figure C-2** Dial Modem Cabling for Auto Dial (dial-out to customer service) C-7
- Figure D-1** Network Application D-1
- Figure D-2** Front and Rear Panel Features D-5

Table 1-1	Routing Group Configuration Example	1-21
Table 2-1	Classes of Traffic and Associated AAL Layers	2-11
Table 2-2	ATM Cell Addressing Modes	2-14
Table 2-3	BPX Switch Plug-In Card Summary	2-16
Table 3-1	BCC Front Panel Indicators	3-6
Table 3-2	Backcard (Line Module) for BCC-32, Connectors	3-9
Table 3-3	Back Card (Line Module) for BCC-3 & 4, Connectors	3-10
Table 3-4	ASM Front Panel Controls and Indicators	3-13
Table 3-5	LM-ASM Face Plate Connectors	3-15
Table 4-1	BNI Front Panel Status Indicators	4-6
Table 4-2	BNI Front Panel Card Failure Indications	4-8
Table 4-3	LM-3T3 and LM-3E3 Connectors	4-8
Table 4-4	BNI-155 Front Panel Status Indicators	4-14
Table 4-5	BNI Front Panel Card Failure Indications	4-14
Table 4-6	LM-OC3-SMF and LM-OC3-SMFLR Connectors	4-16
Table 4-7	LM-OC3-MMF Connectors	4-16
Table 5-1	ASI-1 Status Indicators	5-6
Table 5-2	ASI-155 Status Indicators	5-15
Table 6-1	BXM T3/E3, BXM-155, and BXM 622 Front Card Options	6-4
Table 6-2	BXM-T3/E3, BXM-155, and BXM-622 Back Cards	6-5
Table 6-3	BXM Front Panel Status Indicators	6-8
Table 6-4	BXM Front Panel Card Failure indicators	6-8
Table 6-5	BXM-622 Backcards	6-12
Table 6-6	BXM-155 Backcards	6-12
Table 6-7	BXM-T3/E3 Backcards	6-12
Table 6-8	Fiber Optic Characteristics OC-12	6-26
Table 6-9	Fiber Optic Characteristics OC-3	6-26
Table 6-10	SONET Section, Line, and Path Descriptions	6-27
Table 6-11	Digital Hierarchies	6-27
Table 7-1	Standard ATM Traffic Classes	7-3
Table 7-2	Traffic Policing Definitions	7-8
Table 7-3	Connection Parameters with Default Settings and Ranges	7-9
Table 7-4	Connection Parameter Descriptions	7-11
Table 7-5	CBR Policing Definitions	7-13

Table 7-6	VBR Policing Definitions	7-15
Table 7-7	UBR Policing Definitions	7-22
Table 7-8	Traffic Shaping Rates	7-38
Table 7-9	ILMI Parameters	7-38
Table 7-10	LMI Parameters	7-38
Table 9-1	BXM Port Groups	9-12
Table 9-2	Port Connection Allocations	9-13
Table 9-3	Port Connection Allocations, Useful Default Values	9-13
Table 9-4	cnfrsrc Parameter Summary	9-18
Table 9-5	Port Connection Allocations, Useful Default Values	9-38
Table 9-6	LCN Allocations for 8-port OC3 BXM, Ports Configured in Trunk Mode	9-42
Table 9-7	LCN Allocations for 8-Port OC3 BXM, Ports Configured in Port Mode	9-45
Table 11-1	Troubleshooting the BPX Switch	11-2
Table 11-2	Card Status for the BPX Switch	11-4
Table A-1	Ambient Temperature and Humidity Limits	A-2
Table B-1	Trunk Cables	B-1
Table B-2	AC Power Cables	B-2
Table B-3	DC Power Wiring	B-2
Table B-4	Auxiliary and Control Port Cabling	B-2
Table B-5	Auxiliary and Control Port Pin Assignments	B-3
Table B-6	LAN Port Cabling	B-3
Table B-7	LAN Port Pin Assignments	B-3
Table B-8	External Clock Cabling	B-4
Table B-9	T1 Connection to XFER TMG on BCC-bc	B-4
Table B-10	T1 Connection to EXT TMG on BCC-bc	B-4
Table B-11	T1 Connection to EXT 1 or EXT 2 on BCC-3-bc	B-4
Table B-12	E1 Connector Pin Assignments for External Clock	B-5
Table B-13	E1 Connection 75 Ohm to EXT TMG on BCC-bc or BCC-3-bc	B-5
Table B-14	E1 Connection 100/120 Ohm to EXT TMG on BCC-bc	B-5
Table B-15	E1 Connection 100/120 Ohm to EXT 1 or EXT 2 on BCC-3-bc	B-5
Table B-16	External Alarm Cabling	B-6
Table B-17	Network Alarm Pin Assignments	B-6
Table B-18	Standard Cables Available from Cisco	B-7
Table B-19	Redundancy Y-Cables	B-7

Table C-1	Control Port Parameters for Local Control (pc or workstation)	C-2
Table C-2	Auxiliary Port Parameters for OkiData 184 Printer	C-2
Table C-3	Switch A Settings—Okidata 184 Printer	C-2
Table C-4	Switch 1 Settings—Okidata 184 Printer	C-3
Table C-5	Switch 2 Settings—Okidata 184 Printer	C-3
Table C-6	Modem Interface Requirements	C-4
Table C-7	V.34R Modem Configuration for Auto-Answer (Dial-in to BPX)	C-5
Table C-8	V.34R Auto-Dial Configuration (dial-out to customer service)*	C-6
Table C-9	V.34R with talk/data, Auto-Dial Configuration (dial-out to customer service)*	C-7
Table D-1	Rear Panel Connectors	D-3
Table D-2	Front Panel Indicators	D-4
Table D-3	DIP Switch SW-1 Selection Guide	D-6
Table D-4	DIP Switch SW-2 Selection Guide	D-7
Table D-5	Alarm Handling	D-8
Table D-6	DIP Switch Settings	D-9
Table D-7	Command Summary	D-9
Table D-8	Status Display	D-10



About This Manual

This publication provides an overview of the operation of the BPX 8600 Series wide-area switches which include the BPX 8620 switch and the BPX 8650 tag switch.

Cisco documentation and additional literature are available in a CD-ROM package, which ships with your product. The Documentation CD-ROM, a member of the Cisco Connection Family, is updated monthly. Therefore, it might be more current than printed documentation. To order additional copies of the Documentation CD-ROM, contact your local sales representative or call customer service. The CD-ROM package is available as a single package or as an annual subscription. You can also access Cisco documentation on the World Wide Web at <http://www.cisco.com>, <http://www-china.cisco.com>, or <http://www-europe.cisco.com>.

If you are reading Cisco product documentation on the World Wide Web, you can submit comments electronically. Click **Feedback** in the toolbar, select **Documentation**, and click **Enter the feedback form**. After you complete the form, click **Submit** to send it to Cisco. We appreciate your comments.

Objectives

This publication is intended to provide reference information useful during installation, configuration, operation, and maintenance of the BPX 8600 Series.

Audience

This publication is intended for installers, operators, network designers, and system administrators.

Cisco WAN Switching Product Name Change

The Cisco WAN Switching products have new names. A switch in the BPX family is now part of the Cisco BPX® 8600 Series wide area switch family. The AXIS shelf is now called the Cisco MGX™ 8220 edge concentrator. Any switch in the IGX switch family (IGX 8, IGX 16 and IGX 32 wide-area switches) is now called the Cisco IGX™ 8400 series-wide area switch. The IGX 8 switch is now called the Cisco IGX™ 8410 wide-area switch. The IGX 16 switch is now called the Cisco IGX™ 8420 wide-area switch, and the IGX 32 switch is now called the Cisco IGX™ 8430 wide-area switch.

Organization

This publication is organized as follows:

- | | |
|------------------|---|
| Chapter 1 | Introduction

Describes the overall operation of the BPX 8600 Series wide-area switches and associated peripherals. |
| Chapter 2 | General Description

Provides an overall physical and functional description of the BPX switch. The physical description includes the BPX enclosure, power, and cooling subsystems. The functional description includes an overview of BPX switch operation. |
| Chapter 3 | BPX Switch Common Core

Describes the common core group, comprising the Broadband Controller Cards (BCCs), the Alarm/Status Monitor (ASM) card, associated backcards, and the StrataBus backplane. |
| Chapter 4 | Network Interface (Trunk) Cards

Describes the BPX switch network interface (trunk) cards, including the Broadband Network Interface (BNI) and associated backcards. The BXM card trunk operation is briefly described in this chapter with additional information provided in Chapter 6. |
| Chapter 5 | Service Interface (Line) Cards

This chapter contains a description of the BPX service interface (line) cards, including the ATM Service Interface (ASI) and associated backcards. The BXM card service (port UNI) operation is briefly described in this chapter with additional information provided in Chapter 6. |
| Chapter 6 | BXM T3/E3, 155, and 622

Describes the BXM card group which includes the BXM-T3/E3, BXM-155, and BXM-622 card sets. Describes the operation of these cards in either trunk or service (port UNI) mode. |
| Chapter 7 | ATM Connections

Describes how ATM connection services are established by adding ATM connections between ATM service interface ports in the network using ATM standard UNI 3.1 and Traffic Management 4.0. It describes BXM and ASI card operation and summarizes ATM connection parameter configuration. |
| Chapter 8 | ATM and Frame Relay SVCs, and SPVCs

Provides a summary of switched virtual circuits and soft permanent virtual circuits with respect to the BPX switch and co-located Extended Services Processor. For additional information, refer to the <i>Cisco WAN Service Node Extended Processor Installation and Operation Release 2.2</i> document. |

-
- Chapter 9** **Tag Switching**
- Provides a summary of tag switching on the BPX 8650 where the BPX switch and associated series 7200 or 7500 router comprise a BPX 8650 Tag Switch. Also provides configuration examples.
- Chapter 10** **BME Multicasting**
- Provides a description of BME multicasting and configuration examples.
- Chapter 11** **Repair and Replacement**
- Describes periodic maintenance procedures, troubleshooting procedures, and the replacement of major BPX switch components.
- Chapter 12** **Frame Relay to ATM Network and Service Interworking**
- Describes frame relay to ATM interworking which allows users to retain their existing Frame Relay services, and as their needs expand, migrate to the higher bandwidth capabilities provided by BPX ATM networks. Frame Relay to ATM Interworking enables frame relay traffic to be connected across high-speed ATM trunks using ATM standard Network and Service Interworking.
- Chapter 13** **Tiered Networks**
- Describes the tiered network configuration that provides the capability of adding interface shelves/feeders (non-routing nodes) to an IPX/IGX/BPX routing network.
- Chapter 14** **BPX SNMP Agent**
- Introduces the functions of the Simple Network Management Protocol (SNMP) agent and MIBs that are embedded in each BPX switch.
- Appendix A** **BPX Node Specifications**
- Lists the BPX switch specifications.
- Appendix B** **BPX Switch Cabling Summary**
- Provides details on the cabling required to install the BPX switch.
- Appendix C** **BPX Switch Peripherals**
- Provide details on the specifications for peripherals used with the BPX switch.
- Appendix D** **AT3-6ME Interface Adapter**
- Describes the AT3-6M Interface Adapter, sometimes referred to as the T3-T2 Interface Adapter, that may be used with the BPX switch to provide a 6 Mbps ATM network interface to T2 transmission facilities.
- Glossary**

Related Documentation

The following Cisco WAN Switching publications contain additional information related to the installation and operation of the BPX switch and associated equipment in a BPX, IGX, IPX network:

- *Cisco StrataView Plus Operations Guide* provides procedures for using the Cisco StrataView Plus network management system.
- *Cisco WAN Design Tools User Guide* provides procedures for modeling networks.
- Release 9.1 of the IGX/IPX/BPX Documentation Set, includes:
 - *Cisco BPX 8600 Series Installation and Configuration* provides installation and configuration instructions for the BPX broadband node.
 - *Cisco WAN Service Node Extended Services Processor Installation and Operation Release 2.2* provides detailed information about the Extended Services Processor (ESP).
 - *Cisco IPX Reference* provides a general description and technical details of the IPX narrowband switch.
 - *Cisco IPX Installation* provides installation instructions for the IPX narrowband switch.
 - *Cisco IGX 8400 Series Reference* provides a general description and technical details of the IGX multiband switch.
 - *Cisco IGX 8400 Series Installation* provides installation instructions for the IGX multiband switch.
 - *Cisco MGX 8220 Reference* provides a general description and technical details of the MGX 8220.
 - *Cisco MGX 8220 Command Reference* provides detailed information for MGX 8220 command line usage.
 - *Cisco WAN Switching Command Reference* provides detailed information on operating the BPX, IGX, and IPX systems through their command line interfaces.
 - *Cisco WAN Switching SuperUser Command Reference* provides detailed information on the command line interface special commands requiring SuperUser access authorization.

Conventions

This publication uses the following conventions to convey instructions and information.

Command descriptions use these conventions:

- Commands and keywords are in **boldface**.
- Arguments for which you supply values are in *italics*.
- Elements in square brackets ([]) are optional.
- Alternative but required keywords are grouped in braces ({ }) and are separated by vertical bars (|).
- Examples use these conventions:
- Terminal sessions and information the system displays are in `screen font`.
- Information you enter is in **boldface screen font**.
- Nonprinting characters, such as passwords, are in angle brackets (<>).
- Default responses to system prompts are in square brackets ([]).

Note Means *reader take note*. Notes contain helpful suggestions or references to materials not contained in this manual.



Caution Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.



Warning This warning symbol means *danger*. You are in a situation that could cause bodily injury. Before you work on any equipment, you must be aware of the hazards involved with electrical circuitry and familiar with standard practices for preventing accidents. (To see translated versions of this warning, refer to the *Regulatory Compliance and Safety Information* that accompanied your equipment.)

Waarschuwing Dit waarschuwingssymbool betekent gevaar. U verkeert in een situatie die lichamelijk letsel kan veroorzaken. Voordat u aan enige apparatuur gaat werken, dient u zich bewust te zijn van de bij elektrische schakelingen betrokken risico's en dient u op de hoogte te zijn van standaard maatregelen om ongelukken te voorkomen.

Varoitus Tämä varoitusmerkki merkitsee vaaraa. Olet tilanteessa, joka voi johtaa ruumiinvammaan. Ennen kuin työskentelet minkään laitteiston parissa, ota selvää sähkökytkentöihin liittyvistä varoista ja tavanomaisista onnettomuuksien ehkäisykeinoista.

Attention Ce symbole d'avertissement indique un danger. Vous vous trouvez dans une situation pouvant causer des blessures ou des dommages corporels. Avant de travailler sur un équipement, soyez conscient des dangers posés par les circuits électriques et familiarisez-vous avec les procédures couramment utilisées pour éviter les accidents.

Warnung Dieses Warnsymbol bedeutet Gefahr. Sie befinden sich in einer Situation, die zu einer Körperverletzung führen könnte. Bevor Sie mit der Arbeit an irgendeinem Gerät beginnen, seien Sie sich der mit elektrischen Stromkreisen verbundenen Gefahren und der Standardpraktiken zur Vermeidung von Unfällen bewußt.

Avvertenza Questo simbolo di avvertenza indica un pericolo. La situazione potrebbe causare infortuni alle persone. Prima di lavorare su qualsiasi apparecchiatura, occorre conoscere i pericoli relativi ai circuiti elettrici ed essere al corrente delle pratiche standard per la prevenzione di incidenti.

Advarsel Dette varselsymbolet betyr fare. Du befinner deg i en situasjon som kan føre til personskada. Før du utfører arbeid på utstyr, må du være oppmerksom på de faremomentene som elektriske kretser innebærer, samt gjøre deg kjent med vanlig praksis når det gjelder å unngå ulykker.

Aviso Este símbolo de aviso indica perigo. Encontra-se numa situação que lhe poderá causar danos físicos. Antes de começar a trabalhar com qualquer equipamento, familiarize-se com os perigos relacionados com circuitos eléctricos, e com quaisquer práticas comuns que possam prevenir possíveis acidentes.

¡Atención! Este símbolo de aviso significa peligro. Existe riesgo para su integridad física. Antes de manipular cualquier equipo, considerar los riesgos que entraña la corriente eléctrica y familiarizarse con los procedimientos estándar de prevención de accidentes.

Warning! Denna varningssymbol signalerar fara. Du befinner dig i en situation som kan leda till personskada. Innan du utför arbete på någon utrustning måste du vara medveten om farorna med elkretsar och känna till vanligt förfarande för att förebygga skador.



Timesaver Means *the described action saves time*. You can save time with this action.

Introduction

This chapter contains an overall description of the BPX 8600 Series. For installation information, refer to the *Cisco BPX 8600 Series Installation and Configuration* publication. Also, refer to the *Cisco WAN Switching Command Reference* publications.

This chapter contains the following:

- General Description
- New with Release 9.1
- Continuing Features with Release 9.1
- BPX Switch Operation
- Traffic and Congestion Management
- Network Management
- Switch Availability

General Description


The Cisco BPX® 8600 Series wide-area switches are standards based high-capacity broadband ATM switches that provides backbone ATM switching and deliver a wide range of user services (see Figure 1-1). The BPX 8600 Series includes the BPX 8620 switch and the BPX 8650 tag switch.

BPX Capabilities

Fully integrated with the Cisco MGX™ 8220 edge concentrator, Cisco IPX® wide-area switch, and Cisco IGX™ 8400 series wide-area switch, the BPX switch is a scalable, standards-compliant unit. Using a multi-shelf architecture, the BPX switch supports both narrowband and broadband user services. The modular, multi-shelf architecture enables users to incrementally expand the capacity of the system as needed. The BPX switch consists of the BPX shelf with fifteen card slots which may be co-located with the MGX 8220 and Extended Services Processor (ESP), as required.

Three of the slots on the BPX switch shelf are reserved for common equipment cards. The other twelve are general purpose slots used for network interface cards or service interface cards. The cards are provided in sets, consisting of a front card and associated back card. The BPX shelf can be mounted in a rack enclosure which provides mounting for a co-located ESP and the MGX 8220 interface shelves.

Figure 1-1 BPX Switch General Configuration Example



S6416

Extended Services Processor

With a co-located Extended Services Processor (ESP), the BPX switch adds the capability to support ATM and frame relay switched virtual circuits (SVCs), and soft permanent virtual circuits (SPVCs).

New with Release 9.1

BPX Switch

- Tag Switching with the BXM
- BME Multicasting
- Release 9.1 adds traffic shaping for BXM for UBR, VBR, and CBR per VC scheduling policies. This was previously supported for ABR only.
- Extended Services Processor (ESP) Release 2.2
 - Support for SPVCs, including auto-grooming of SPVCs
 - Dynamic resource partitioning for migration of PVCs to SPVCs
 - Interworking with the LS1010 ATM switch to provide point-to-multipoint SVC connections.Continued ESP features that were available in Release 2.0 including:
 - ATM switched virtual circuits (ATM SVCs)
 - Frame Relay switched virtual circuits (Frame Relay SVCs)
 - ESP redundancy
 - Call billing and call detail records (for ATM, Frame Relay, and SVCs only)

MGX 8220

- MGX 8220, Rel. 4.1, supported

IGX Switch

- UXM adds native ATM trunks and ports (UNI)

Continuing Features with Release 9.1

The following is a list of previously provided features that are included in this release along with the new features previously listed:

Cisco StrataView Plus Network Management

- NMS enhancements including additional management and provisioning capabilities including support of IGX switch tiered network voice and data applications
- Support for 12 Cisco StrataView Plus workstations
- Multi-network Cisco StrataView Plus capability
- Frame relay connection and MGX 8220 equipment management by the Cisco StrataView Plus Connection Manager and Equipment Manager

- SNMP Enhancements for connection management and monitoring
- Support for Solaris 2.5.1

Network

- Support for IGX switch hubs and associated interface shelves in tiered network
- The number of nodes supported in a network is increased to over 1100, of which 223 can be routing nodes.
- Inverse Multiplexing ATM (IMA)
- Frame Relay to ATM Network Interworking (Supported by FRP on IPX switch, FRM on IGX switch, and FRSM on MGX 8220)
- Frame Relay to ATM Service interworking (Supported by FRSM on MGX 8220)
- Tiered networks
- Automatic end-to-end routing of virtual connections (AutoRoute)
- Closed-loop, rate-based congestion management (using ForeSight for ABR)
- Effective management of quality of service (OptiClass)
- Per -VC queueing and per-VC scheduling (FairShare)

BPX Switch

- The BXM cards provide a range of trunk and service interfaces and support ATM Forum Standards UNI 3.1 and ATM Traffic Management 4.0 including ABR connections with VS/VD congestion control. The BXM cards are implemented with Stratm technology which uses a family of custom Application Specific Integrated Circuits (ASICs) to provide high-density, high-speed operation. The three types of BXM cards are:
 - The BXM T3/E3 is available as an eight or twelve port card that provides T3/E3 interfaces at 44.376 or 34.368 Mbps rates, respectively. The BXM-T3/E3 can be configured for either trunk or access applications.
 - The BXM 155 is available as a four or eight port card that provides OC-3/STM-1 interfaces at 155.52 Mbps rates. The BXM-155 can be configured for either trunk or access applications.
 - The BXM 622 is available as a one or two port card that provides OC-12/STM-4 interfaces at 622.08 Mbps rates. The BXM-622 can be configured for either trunk or access applications.
- Enhanced network scaling:
 - 50/64 trunks per BPX switch equipped with BCC-32 or BCC-64, respectively
 - 72/144 lines per node equipped with BCC-32 or BCC-64, respectively
 - 223 routing nodes (with BPX switch or IGX switch)
 - trunk based loading
 - BCC-3-64 supported on BPX switch
 - 7000 virtual connections (BCC-3-32)
 - 12000 virtual connections (BCC-3-64)

- de-route delay timer
- connection routing groups by cell loading
- ATM and Frame Relay SVCs, and Soft Permanent Virtual Circuits (SPVCs) with Extended Services Processor

ESP is an adjunct processor that is co-located with a BPX switch shelf. The ESP provides the signaling and Private Network to Network Interface (PNNI) routing for ATM and Frame Relay SVCs via BXM cards in the BPX switch and AUSM and FRSM cards in the MGX 8220.
- Cisco StrataView Plus NMS enhancements including additional management and provisioning capabilities.
- BCC-3-64
- BCC-4 supporting 19.2 Gbps switching with the BXM cards supporting egress at up to 1600 Mbps and ingress at up to 800 Mbps.
- Hot Standby Redundancy
- MGX 8220 Release 4.1, which will include:
 - BNM-155 interface to BXM on BPX switch
 - FRSM support for both SVC and PVC frame relay connections with ESP
 - AUSM support for both SVC and PVC ATM connections with ESP
 - FRSM-8 with ELMI
 - IMATM-B
 - AUSM-8
 - CESM/4T1E1
 - FRSM-HS1 (HSSI and X.21 interfaces)
 - SRM 3T3
- Access Products
 - FastPAD MM and MP
 - Cisco 3810
- Virtual Trunking.
- Inverse Multiplexing ATM (IMA).
- Enhanced Ingress buffers for ASI-155 and BNI-155 to 8K cells for Release 8.1 and up.
- BPX switch OC3 network and service interfaces on the BNI and ASI cards.
- High-speed switching capacity.
- Powerful crosspoint switching architecture.
- 53-byte cell-based ATM transmission protocol.
- Twelve 800 Mbps switch ports for network or access interfaces with BNI and ASI cards.
- Three DS3 or E3 ATM network interface ports per card (BNI).
- Totally redundant common control and switch fabric.
- Up to 20 million point-to-point cell connections per second between slots.
- Switches individual connections rather than merely serving as a virtual path switch.

- Easy integration into existing IPX switch and IGX switch networks.
- Internal diagnostics and self-test routines on all cards and backplane, status indication on each card.
- Collection of many ATM and other network statistics and transfer of the data collected to Cisco StrataView Plus over high-speed Ethernet LAN interface.
- Integration with the Cisco StrataView Plus Network Management System to provide configuration, control, and maintenance.
- Conformation to recommendations from all current ATM standards bodies: ATM Forum, ITU, ETSI, and ANSI.
- Compliant with all applicable safety, emissions, and interface regulations. Meets requirements of NEBS for Central Office equipment.

MGX 8220

- Inverse Multiplexing ATM (IMA) support for the BPX switch with Rel. 3 MGX 8220
- CES T1/E1
- MGX 8220 T1/E1 frame relay and T1/E1 ATM service interfaces
- FUNI (Frame Based UNI over ATM)

IGX Switch

- The IGX switch is configurable as a tiered network routing hub supporting voice and data over IGX switch interface shelves.

Access Products

- Cisco 3810
- FastPAD MM and MP products

BPX Switch Operation

BPX Switch Operation

With the BCC-4, the BPX switch employs a redundant 19.2 Gbps non-blocking crosspoint switch matrix for cell switching. The switch matrix can establish up to 20 million point-to-point connections per second between ports. A single BPX switch provides twelve card slots, with each card capable of operating at 800 Mbps for ASI and BNI cards. The BXM cards support egress at up to 1600 Mbps and ingress at up to 800 Mbps. Access to and from the crosspoint switch is through multi-port network and user access cards. It is designed to easily meet current requirements with scalability to higher capacity for future growth.

A BPX switch shelf is a self-contained chassis which may be rack-mounted in a standard 19-inch rack or open enclosure. All control functions, switching matrix, backplane connections, and power supplies are redundant, and non-disruptive diagnostics continuously monitor system operation to detect any system or transmission failure. Hot-standby hardware and alternate routing capability combine to provide maximum system availability.

The BPX Switch with MGX 8220 Shelves

Many network locations have increasing bandwidth requirements due to emerging applications. To meet these requirements, users can overlay their existing narrowband networks with a backbone of BPX switches to utilize the high-speed connectivity of the BPX switch operating at 19.2 Gbps with its T3/E3/OC3/OC12 network and service interfaces. The BPX switch service interfaces include BXM and ASI ports on the BPX switch and service ports on MGX 8220 shelves. The MGX 8220 shelves may be co-located in the same cabinet as the BPX switch, providing economical port concentration for T1/E1 Frame Relay, T1/E1 ATM, CES, and FUNI connections.

Tag Switching

For multi-service networks, the BPX 8650 tag switch provides ATM, frame relay, and IP Internet service all on a single platform in a highly scalable way. Support of all these services on a common platform provides operational cost savings and simplifies provisioning for multi-service providers.

By integrating the switching and routing functions, tag switching combines the reachability information provided by the router function with the traffic engineering optimizing capabilities of the switch. The BPX 8650 tag switch combines a BPX switch with a separate router controller (Cisco Series 7200 or 7500 router).

The BPX Switch with Extended Services Processor

With a co-located ESP, the BPX Switch adds the capability to support ATM and Frame Relay switched virtual circuits (SVCs), and also soft permanent virtual circuits (SPVCs). Refer to the *Cisco WAN Service Node Extended Services Processor Installation and Operation* document for detailed information about the ESP.

Frame Relay to ATM Interworking

Interworking allows users to retain their existing services, and as their needs expand, migrate to the higher bandwidth capabilities provided by BPX switch networks. Frame Relay to ATM Interworking enables frame relay traffic to be connected across high-speed ATM trunks using ATM standard Network and Service Interworking

Two types of Frame Relay to ATM interworking are supported, Network Interworking (see Figure 1-2) and Service Interworking (see Figure 1-3). The Network Interworking function is performed by the AIT card on the IPX switch, the BTM card on the IGX switch, and the FRSM card on the MGX 8220. The FRSM card on the MGX 8220 and the UFM cards on the IGX switch also support Service Interworking.

The frame relay to ATM network and service interworking functions are available as follows:

Network Interworking

Part A of Figure 1-2 shows typical frame relay to network interworking. In this example, a frame relay connection is transported across an ATM network, and the interworking function is performed by both ends of the ATM network. The following are typical configurations:

- IGX switch or IPX switch frame relay (shelf/feeder) to IGX switch or IPX switch frame relay (either routing node or shelf/feeder)
- MGX 8220 frame relay to MGX 8220 frame relay

- MGX 8220 frame relay to IGX switch or IPX switch frame relay (either routing node or shelf/feeder)

Part B of Figure 1-2 shows a form of network interworking where the interworking function is performed by only one end of the ATM network, and the CPE connected to the other end of the network must itself perform the appropriate service specific convergence sublayer function. The following are example configurations:


- IGX switch or IPX switch frame relay (either routing node or shelf/feeder) to BPX switch or MGX 8220 ATM port.
- MGX 8220 frame relay to BPX switch or MGX 8220 ATM port.

Network Interworking is supported by the FRP on the IPX switch, the FRM, UFM-C, and UFM-U on the IGX switch, and the FRSM on the MGX 8220. The Frame Relay Service Specific Convergence Sublayer (FR-SSCS) of AAL5 is used to provide protocol conversion and mapping.

Figure 1-2 Frame Relay to ATM Network Interworking


Part A

Network interworking connection from CPE Frame Relay port to CPE Frame Relay port across an ATM Network with the interworking function performed by both ends of the network.



Part B

Network interworking connection from CPE Frame Relay port to CPE ATM port across an ATM network, where the network performs an interworking function only at the Frame Relay end of the network. The CPE receiving and transmitting ATM cells at its ATM port is responsible for exercising the applicable service specific convergence sublayer, in this case, (FR-SSCS).



H8225

Service Interworking

Figure 1-3 shows a typical example of Service Interworking. Service Interworking is supported by the FRSM on the MGX 8220 and the UFM-C and UFM-U on the IGX switch. Translation between the Frame Relay and ATM protocols is performed in accordance with RFC 1490 and RFC 1483.


In Service Interworking, for example, for a connection between an ATM port and a frame relay port, unlike Network Interworking, the ATM device does not need to be aware that it is connected to an interworking function.

The frame relay service user does not implement any ATM specific procedures, and the ATM service user does not need to provide any frame relay specific functions. All translational (mapping functions) are performed by the intermediate IWF.

The following is a typical configuration for service interworking:

- MGX 8220 Frame Relay (FRSM card) to BPX switch or MGX 8220 ATM port.
- IGX switch Frame Relay (FRM-U or FRM-C) to BPX switch or MGX 8220 ATM port.

Figure 1-3 Frame Relay to ATM Service Interworking



Additional Information

For additional information about interworking, refer to *Chapter 12, Frame Relay to ATM Network and Service Interworking*.

Tiered Networks

Networks may be configured as flat (all nodes perform routing and communicate fully with one another), or they may be configured as tiered. In a tiered network interface shelves are connected to routing hubs, where the interface shelves are configured as non-routing nodes.

By allowing CPE connections to connect to a non-routing node (interface shelf), a tiered network is able to grow in size beyond that which would be possible with only routing nodes comprising the network.

Starting with Release 8.5, in addition to BPX switch routing hubs, tiered networks now support IGX switch routing hubs. Voice and data connections originating and terminating on IGX switch interface shelves (feeders) are routed across the routing network via their associated IGX switch routing hubs. Intermediate routing nodes must be IGX switches, and IGX switch interface shelves are the only interface shelves that can be connected to an IGX switch routing hub. With this addition, a tiered network can now provide a multi-service capability (frame relay, circuit data, voice, and ATM).

Routing Hubs and Interface Shelves

In a tiered network, interface shelves at the access layer (edge) of the network are connected to routing nodes via feeder trunks (Figure 1-4). Those routing nodes with attached interface shelves are referred to as routing hubs. The interface shelves, sometimes referred to as feeders, are non-routing nodes. The routing hubs route the interface shelf connections across the core layer of the network.

The interface shelves do not need to maintain network topology nor connection routing information. This task is left to their routing hubs. This architecture provides an expanded network consisting of a number of non-routing nodes (interface shelves) at the edge of the network that are connected to the network by their routing hubs.

For detailed information about tiered networks, refer to *Chapter 13, “Tiered Networks”*.


BPX Switch Routing Hubs

T1/E1 Frame Relay connections originating at IPX switch and IGX switch interface shelves and T1/E1 Frame Relay, T1/E1 ATM, CES, and FUNI connections originating at MGX 8220 interface shelves are routed across the routing network via their associated BPX switch routing hubs.

The following requirements apply to BPX switch routing hubs and their associated interface shelves:

- Only one feeder trunk is supported between a routing hub and interface shelf.
- No direct trunking between interface shelves is supported.
- No routing trunk is supported between the routing network and interface shelves.
- The feeder trunks between BPX switch hubs and IPX switch or IGX switch interface shelves are either T3 or E3.
- The feeder trunks between BPX switch hubs and MGX 8220 interface shelves are T3, E3, or OC3-c/STM-1.
- Frame Relay connection management to an IPX switch or IGX switch interface shelf is provided by Cisco StrataView Plus.
- Frame Relay and ATM connection management to an MGX 8220 interface shelf is provided by Cisco StrataView Plus.
- Telnet is supported to an interface shelf; the vt command is not.
- Frame Relay connections originating at IGX switch interfaces shelves connected to IGX switch routing hubs may also be routed across BPX switch intermediate nodes.
- Remote printing by the interface shelf via a print command from the routing network is not supported.

Figure 1-4 Tiered Network with BPX Switch and IGX Switch Routing Hubs



56396

Inverse Multiplexing ATM

Where greater bandwidths are not needed, the Inverse Multiplexing ATM (IMA) feature provides a low cost trunk between two BPX switches. The IMA feature allows BPX switches to be connected to one another over any of the 8 T1 or E1 trunks provided by an AIMNM module on an MGX 8220 shelf. A BNI port on each BPX switch is directly connected to an AIMNM module in an MGX 8220 by a T3 or E3 trunk. The AIMNM modules are then linked together by any of the 8 T1 or E1 trunks. Refer to the *Cisco MGX 8220 Reference* and the *Cisco WAN Switching Command Reference* publications for further information.


Virtual Trunking

Virtual trunking provides the ability to define multiple trunks within a single physical trunk port interface. Virtual trunking benefits include the following:

- Reduced cost by configuring the virtual trunks supplied by the public carrier for as much bandwidth as needed instead of at full T3, E3, or OC3 bandwidths.
- Utilization of the full mesh capability of the public carrier to reduce the number of leased lines needed between nodes in the Cisco WAN switching networks.
- Choice of keeping existing leased lines between nodes, but using virtual trunks for backup.
- Ability to connect BNI trunk interfaces to a public network using standard ATM UNI cell format.
- Virtual trunking can be provisioned via either a Public ATM Cloud or a Cisco WAN switching ATM cloud.

A virtual trunk may be defined as a “trunk over a public ATM service”. The trunk really doesn’t exist as a physical line in the network. Rather, an additional level of reference, called a **virtual trunk number**, is used to differentiate the virtual trunks found within a physical trunk port. Figure 1-5 shows four Cisco WAN switching networks, each connected to a Public ATM Network via a physical line. The Public ATM Network is shown linking all four of these subnetworks to every other one with a full meshed network of virtual trunks. In this example, each physical line is configured with three virtual trunks.

Figure 1-5 Virtual Trunking Example



H6227

Traffic and Congestion Management

The BPX switch provides ATM standard traffic and congestion management per ATM Forum TM 4.0 using BXM cards.

The Traffic Control functions include:

- Usage Parameter Control (UPC)
- Traffic Shaping
- Connection Management Control:
- Selective Cell Discarding
- Explicit Forward Congestion Indication (EFCI)

In addition to these standard functions, the BPX switch provides advanced traffic and congestion management features including:

- Support for the full range of ATM service types per ATM Forum TM 4.0 by the BXM-T3/E3, BXM-155, and BXM-622 cards on the BPX Service Node.
- FairShare, dedicated queue, and rate controlled servers for each VPC/VCC at the network ingress.
- OptiClass, guarantees QoS for individual connections by providing up to 16 queues with independent service algorithms for each trunk in the network.
- AutoRoute, end-to-end connection management that automatically selects the optimum connection path based upon the state of the network and assures fast automatic alternate routing in the event of intermediate trunk or node failures.
- PNNI, a standards based routing protocol for ATM and Frame Relay SVCs.
- Frame Based Traffic Control (FBTC) for AAL5 connections, including early and partial frame discard.
- ForeSight, an end-to-end closed loop rate based congestion control algorithm that dynamically adjusts the service rate of VC queues based on network congestion feedback.
- ABR Standard with VSVD congestion control using RM cells and supported by BXM cards on the BPX Switch.

FairShare™

Fairshare provides per-VC queueing and per-VC scheduling. Fairshare provides fairness between connections and firewalls between connections. Firewalls prevent a single non-compliant connection from affecting the QoS of compliant connections. The non-compliant connection simply overflows its own buffer.

The cells received by a port are not automatically transmitted by that port out to the network trunks at the port access rate. Each VC is assigned its own ingress queue that buffers the connection at the entry to the network. With ABR with VSVD or with ForeSight, the service rate can be adjusted up and down depending on network congestion.

Network queues buffer the data at the trunk interfaces throughout the network according to the connections class of service. Service classes are defined by standards-based QoS. Classes can consist of the four broad service classes defined in the ATM standards as well as multiple sub-classes to each of the four general classes. Classes can range from constant bit rate services with minimal cell delay variation to variable bit rates with less stringent cell delay.

When cells are received from the network for transmission out a port, egress queues at that port provide additional buffering based on the service class of the connection.

OptiClass™

OptiClass provides a simple but effective means of managing the quality of service defined for various types of traffic. It permits network operators to segregate traffic to provide more control over the way that network capacity is divided among users. This is especially important when there are multiple user services on one network.

Rather than limiting the user to the four broad classes of service initially defined by the ATM standards committees, OptiClass can provide up to 16 classes of service (service subclasses) that can be further defined by the user and assigned to connections. Some of the COS parameters that may be assigned include:

- Minimum bandwidth guarantee per subclass to assure that one type of traffic will not be preempted by another.
- Maximum bandwidth ceiling to limit the percentage of the total network bandwidth that any one class can utilize.
- Queue depths to limit the delay.
- Discard threshold per subclass.

These class of service parameters are based on the standards-based Quality of Service parameters and are software programmable by the user. The BPX switch provides separate queues for each traffic class.

AutoRoute

With AutoRoute, connections in Cisco WAN switching networks are added if there is sufficient bandwidth across the network and are automatically routed when they are added. The user only needs to enter the endpoints of the connection at one end of the connection and the IPX switch, IGX switch, and BPX switch software automatically set up a route based on a sophisticated routing algorithm. This feature is called *AutoRoute*. It is a standard feature on the IPX switch, IGX switch, BPX switch, and MGX 8220.

System software automatically sets up the most direct route after considering the network topology and status, the amount of spare bandwidth on each trunk, as well as any routing restrictions entered by the user (e.g. avoid satellite links). This avoids having to manually enter a routing table at each node in the network. AutoRoute simplifies adding connections, speeds rerouting around network failures, and provides higher connection reliability.

Cost-Based AutoRoute

Cost-based route selection can be selectively enabled by the user as the route selection per node. With this feature a trunk cost is assigned to each trunk (physical and virtual) in the network. The routing algorithm then chooses the lowest cost route to the destination node. The lowest cost routes are stored in a cache to reduce the computation time for on-demand routing.

Cost-based routing can be enabled or disabled at anytime, and there can be a mixture of cost-based and hop-based nodes in a network.

The section, Cost-Based Connection Routing, contains more detailed information about cost-based AutoRoute.

PNNI

The Private Network to Network Interface (PNNI) protocol provides a standards-based dynamic routing protocol for ATM and frame relay SVCs. PNNI is an ATM-Forum-defined interface and routing protocol which is responsive to changes in network resources, availability, and will scale to large networks. PNNI is available on the BPX switch when an ESP is installed. For further information about PNNI and the ESP, refer to the *Cisco WAN Service Node Series Extended Services Processor Installation and Operation* publication.

Congestion Management, VS/VD

The BPX/IGX/IPX switch networks provide a choice of two dynamic rate based congestion control methods, ABR with VS/VD and ForeSight. This section describes Standard ABR with VSVD.

Note ABR with VSVD is an optional feature that must be purchased and enabled on a single node for the entire network.

When an ATM connection is configured between BXM cards for Standard ABR with VSVD per ATM Forum TM 4.0, Resource Management (RM) cells are used to carry congestion control feedback information back to the connection's source from the connection's destination.

The ABR sources periodically interleave RM cells into the data they are transmitting. These RM cells are called forward RM cells because they travel in the same direction as the data. At the destination these cells are turned around and sent back to the source as backward RM cells.

The RM cells contain fields to increase or decrease the rate (the CI and NI fields) or set it at a particular value (the explicit rate ER field). The intervening switches may adjust these fields according to network conditions. When the source receives an RM cell, it must adjust its rate in response to the setting of these fields.

When spare capacity exists with the network, ABR with VSVD permits the extra bandwidth to be allocated to active virtual circuits.

Congestion Management, ForeSight

The BPX/IGX/IPX switch networks provide a choice of two dynamic rate based congestion control methods, ABR with VS/VD and ForeSight. This section describes ForeSight.

Note ForeSight is an optional feature that must be purchased and enabled on a single node for the entire network.

ForeSight may be used for congestion control across BPX/IGX/IPX switches for connections that have one or both end points terminating on other than BXM cards, for example ASI cards. The ForeSight feature is a dynamic closed-loop, rate-based, congestion management feature that yields bandwidth savings compared to non-ForeSight equipped trunks when transmitting bursty data across cell-based networks.

ForeSight permits users to burst above their committed information rate for extended periods of time when there is unused network bandwidth available. This enables users to maximize the use of network bandwidth while offering superior congestion avoidance by actively monitoring the state of shared trunks carrying frame relay traffic within the network.

ForeSight monitors each path in the forward direction to detect any point where congestion may occur and returns the information back to the entry to the network. When spare capacity exists with the network, ForeSight permits the extra bandwidth to be allocated to active virtual circuits. Each PVC is treated fairly by allocating the extra bandwidth based on each PVC's committed bandwidth parameter.

If the network reaches full utilization, ForeSight detects this and quickly acts to reduce the extra bandwidth allocated to the active PVCs. ForeSight reacts quickly to network loading in order to prevent dropped packets. Periodically, each node automatically measures the delay experienced along a frame relay PVC. This delay factor is used in calculating the ForeSight algorithm.

With basic frame relay service, only a single rate parameter can be specified for each PVC. With ForeSight, the virtual circuit rate can be specified based on a minimum, maximum, and initial transmission rate for more flexibility in defining the frame relay circuits.

ForeSight provides effective congestion management for PVC's traversing broadband ATM as well. ForeSight operates at the cell-relay level that lies below the frame relay services provided by the IPX switch and IGX switch. With the queue sizes utilized in the BPX switch, the bandwidth savings is approximately the same as experienced with lower speed trunks. When the cost of these lines is considered, the savings offered by ForeSight can be significant.

Network Management

BPX switches provide one high-speed and two low-speed data interfaces for data collection and network management. The high-speed interface is an Ethernet 802.3 LAN interface port for communicating with a Cisco StrataView Plus NMS workstation. TCP/IP provides the transport and network layer, Logical Link Control 1 is the protocol across the Ethernet port.

The low-speed interfaces are two RS-232 ports, one for a network printer and the second for either a modem connection or a connection to an external control terminal. These low-speed interfaces are the same as provided by the IPX switch and IGX switch.

A Cisco StrataView Plus NMS workstation connects via the Ethernet to the LAN port on the BPX and provides network management via SNMP. Statistics are collected by Cisco StrataView Plus using the TFTP protocol. On IPX switch and IGX switch shelves, frame relay connections are managed via the Cisco StrataView Plus Connection Manager. On MGX 8220 shelves, the Cisco StrataView Plus Connection Manager manages frame relay and ATM connections, and the Connection Manager is used for MGX 8220 shelf configuration.

Each BPX switch can be configured to use optional low-speed modems for inward access by the Cisco Technical Response Team for network troubleshooting assistance or to autodial Customer Service to report alarms remotely. If desired, another option is remote monitoring or control of customer premise equipment through a window on the Cisco StrataView Plus workstation.

Network Interfaces

Network interfaces connect the BPX switch to other BPX, IGX, or IPX switches to form a wide-area network.

The BPX switch provides T3, E3, OC3/STM-1, and OC12/STM-4 trunk interfaces. The T3 physical interface utilizes DS3 C-bit parity and the 53-byte ATM physical layer cell relay transmission using the Physical Layer Convergence Protocol. The E3 physical interface uses G.804 for cell delineation and HDB3 line coding. The BNI-155 card supports single-mode fiber (SMF), single-mode fiber long reach (SMF-LR), and multi-mode fiber (MMF) physical interfaces. The BXM-155 cards support SMF, SMFLR, and MMF physical interfaces. The BXM-622 cards support SMF and SMFLR physical interfaces.

The design of the BPX switch permits it to support network interfaces up to 622 Mbps in the current release while providing the architecture to support higher broadband network interfaces as the need arises.

Optional redundancy is on a one-to-one basis. The physical interface can operate either in a normal or looped clock mode. And as an option, the node synchronization can be obtained from the DS3 extracted clock for any selected network trunk.

Service Interfaces

Service interfaces connect ATM customer equipment to the BPX switch. ATM User-to-Network Interfaces (UNI) and ATM Network-to-Network Interfaces (NNI) terminate on the ATM Service Interface (ASI) cards and on BXM T3/E3, OC-3, and OC-12 cards configured for as service interfaces (UNI access mode). The ASI-1 card provides two T3 or E3 ports. The ASI-155 card OC3/STM-1 trunk interfaces are single-mode fiber (SMF), single-mode fiber long reach (SMF-LR), and multi-mode fiber (MMF) physical interfaces. The BXM T3/E3 card supports the standard T3/E3 interfaces. The BXM-155 cards support SMF, SMFLR, and MMF physical interfaces. The BXM-622 cards support SMF and SMFLR physical interfaces. The ASI and BXM cards support cell relay connections that are compliant with both the physical layer and ATM layer standards.

The MGX 8220 interfaces to a BNI or BXM card on the BPX, via a T3, E3, or OC3 interface. The MGX 8220 provides a concentrator for T1 or E1 frame relay and ATM connections to the BPX switch with the ability to apply ForeSight across a connection from end-to-end. The MGX 8220 also supports CES and FUNI (Frame Based UNI over ATM) connections.

Statistical Alarms and Network Statistics

The BPX Switch system manager can configure alarm thresholds for all statistical type error conditions. Thresholds are configurable for conditions such as frame errors, out of frame, bipolar errors, dropped cells, and cell header errors. When an alarm threshold is exceeded, the NMS screen displays an alarm message.

Graphical displays of collected statistics information, a feature of the Cisco StrataView Plus NMS, are a useful tool for monitoring network usage. Statistics collected on network operation fall into two general categories:

- Node statistics
- Network trunk statistics
- Network Service, line statistics
- Network Service, port statistics

These statistics are collected in real-time throughout the network and forwarded to the StrataView Plus workstation for logging and display. The link from the node to the Cisco StrataView Plus workstation uses a protocol to acknowledge receipt of each statistics data packet. Refer to the *Cisco StrataView Plus Operations* publication, for more details on statistics and statistical alarms.

Node Synchronization

A BPX Service switch network provides network-wide, intelligent clock synchronization. It uses a fault-tolerant network synchronization architecture recommended for Integrated Services Digital Network (ISDN). The BPX switch internal clock operates as a Stratum 3 clock per ANSI T1.101.

Since the BPX switch is designed to be part of a larger communications network, it is capable of synchronizing to higher-level network clocks as well as providing synchronization to lower-level devices. Any network access input can be configured to synchronize the node. Any external T1 or E1 input can also be configured to synchronize network timing. A clock output allows synchronizing an adjacent IPX or IGX switch or other network device to the BPX switch and the network. In nodes equipped with optional redundancy, the standby hardware is locked to the active hardware to minimize system disruption during system switchovers.

The BPX switch does not accept clock from an IPX switch. The BPX Service Node can be configured to select clock from the following sources:

- External (T1/E1)
- Line (DS3/E3)
- Internal

Switch Software Description

The Cisco WAN switching cell relay system software shares most core system software, as well as a library of applications, between platforms. System software provides basic management and control capabilities to each node.

IPX, IGX, and BPX node system software manages its own configuration, fault-isolation, failure recovery, and other resources. Since no remote resources are involved, this ensures rapid response to local problems. This distributed network control, rather than centralized control, provides increased reliability.

Software among multiple nodes cooperates to perform network-wide functions such as trunk and connection management. This multi-processor approach ensures rapid response with no single point of failure. System software applications provide advanced features that may be installed and configured as required by the user.

Some of the many software features are:

- Automatic routing of connections (AutoRoute feature).
- Various classes of service that may be assigned to each connection type (OptiClass feature).
- Bandwidth reservation on a time-of-day basis.
- Detection and control of network congestion with ABR with VSVD or ForeSight algorithms.
- Automatic self-testing of each component of the node.
- Automatic collecting and reporting of many network-wide statistics, such as trunk loading, connection usage, and trunk error rates, as specified by the user.

The system software, configuration database, and the firmware that controls the operation of each card type is resident in programmable memory and can be stored off-line in the Cisco StrataView Plus NMS for immediate backup if necessary. This software and firmware is easily updated remotely from a central site or from Customer Service, which reduces the likelihood of early obsolescence.

Connections and Connection Routing

The routing software supports the establishment, removal and rerouting of end-to-end channel connections. There are three modes:

- Automatic Routing—the system software computes the best route for a connection.
- Manual Routing—the user can specify the route for a connection.

- Alternate Routing—the system software automatically reroutes a failed connection.

The system software uses the following criteria when it establishes an automatic route for a connection:

- Selects the most direct route between two nodes.
- Selects unloaded lines that can handle the increased traffic of additional connections.
- Takes into consideration user-configured connection restrictions (for example whether or not the connection is restricted to terrestrial lines or can include satellite hops or routes configured for route diversity).

When a node reroutes a connection, it uses these criteria and also looks at the priority that has been assigned and any user-configured routing restrictions. The node analyzes trunk loading to determine the number of cells or packets the network can successfully deliver. Within these loading limits, the node can calculate the maximum combination allowed on a network trunk of each type of connection: synchronous data, ATM traffic, frame relay data, multi-media data, voice, and compressed voice.

Network-wide T3, E3, OC3, or OC12 connections are supported between BPX switches terminating ATM user devices on the BPX switch UNI ports. These connections are routed using the virtual path and/or virtual circuit addressing fields in the ATM cell header.

Narrowband connections can be routed over high-speed ATM backbone networks built on BPX broadband switches. FastPacket addresses are translated into ATM cell addresses that are then used to route the connections between BPX switches, and to ATM networks with mixed vendor ATM switches. Routing algorithms select broadband links only, avoiding narrowband nodes that could create a choke point.

Connection Routing Groups

The re-routing mechanism is enhanced so that connections are presorted in order of cell loading when they are added. Re-routing takes place by rerouting the group containing the connections with the largest cell loadings first on down to the last group which contains the connections with the smallest cell loadings. These groups are referred to as routing groups. Each routing group contains connections with loading in a particular range,

There are three configurable parameters for configuring the rerouting groups,

- total number of rerouting groups
- starting load size of first group
- load size range of each group

The three routing group parameters are configured with the **cnfcmparm** command.

For example, there might be 10 groups, with the starting load size of the first group at 50, and the incremental load size of each succeeding group being 10 cells. Then group 0 would contain all connections requiring 0-59 cell load units, group 1 would contain all connections requiring from 60-69 cell load units, on up through group 9 which would contain all connections requiring 140 or more cell load units.

Table 1-1 Routing Group Configuration Example

Routing group	Connection cell loading
0	0-59
1	60-69
2	70-79
3	80-89
4	90-99
5	101-109
6	110-119
7	120-129
8	130-139
9	140 and up

Cost-Based Connection Routing

Release 9.1 includes a cost-based route selection method to Cisco StrataCom's standard AutoRoute. This feature is referred to as cost-based AutoRoute. In standard AutoRoute, the path with the fewest number of hops to the destination node is chosen as the best route. The new cost-based route selection uses an administrative trunk cost routing metric. The path with the lowest total trunk cost is chosen as the best route. Cost-based route selection is based on Dijkstra's Shortest Path Algorithm, which is widely used in network routing environments. You can use cost-based route selection (that is, cost-based AutoRoute) to give preference to slower privately owned trunks over faster public trunks which charge based on usage time. This gives network operators more control over the usability of their network trunks, while providing a more standard algorithm for route selection.

Major Features of Cost-Based AutoRoute

The following list gives a short description of the major functional elements of Cost-Based Route Selection.

- **Enabling Cost-Based Route Selection**—cost-based route selection is selectively enabled by the user as the route selection algorithm per node. The feature is not a chargeable feature and does not require special password access. The default algorithm is the hop-based algorithm. cost-based route selection can be enabled or disabled at any time.
- **Configuring Trunk Cost**—A trunk cost is assigned by the user to each trunk (physical and virtual) in the network. One cost is assigned per trunk - no separate costs are used for different connection or service types. The valid range of trunk costs is 1 (lowest cost) to 50 (highest cost). A trunk has a default cost of 10 upon activation. The cost of a trunk can be changed before or after the trunk has been added to the network topology.

The cost can also be changed after connections have been routed over the trunk. Such a change does not initiate automatic connection rerouting, nor does it cause any outage to the routed connections. If the new trunk cost causes the allowable route cost for any connections to be exceeded, the connections must be manually rerouted to avoid the trunk. This avoids large-scale simultaneous network-wide rerouting and gives the user control over the connection reroute outage.

- **Cache vs. On-Demand Routing**—In previous releases Hop-Based Route Selection always requires on-demand routing. On-demand routing initiates an end-to-end route search for every connection. Due to the computation time required for Dijkstra's algorithm in cost-based route selection, a route cache is used to reduce the need for on-demand routing.

This cache contains lowest cost routes as they are selected. Subsequent routing cycles use these existing routes if the routing criteria are met. Otherwise on-demand routing is initiated. This caching greatly benefits environments where routing criteria is very similar among connections.

Enabling cost-based route selection automatically enables cache usage. Enabling Hop-Based Route Selection automatically disables cache usage. Cache usage can also be independently enabled or disabled for both types of route selection.

- **On-Demand Lowest Cost Route Determination**—On-demand routing chooses the current lowest cost route to the destination node. This lowest cost route is bounded by the maximum route length of 10 hops. If more than one route of similar cost and distance is available, the route with most available resources is chosen. No route grooming occurs after the initial routing. A connection does not automatically reroute if its route cost changes over time. A connection also does not automatically reroute if a lower cost route becomes available after the initial routing. However, a forced reroute or a preferred route can be used to move the connection to a lower cost route.
- **Delay Sensitive Routes**—Delay sensitive IPX/IGX connection types (Voice and Non-Timestamped Data) may be configured to use the worst case queueing delay per trunk, rather than the configured trunk cost, in the lowest-cost route determination. The trunk delay acts as the cost attribute in the Dijkstra algorithm. The default mode for the delay sensitive connections is to use the trunk cost. All other connection types always use the trunk cost in the route determination.

AutoRoute currently does not use the worst case end-to-end queueing delay in route selection for delay sensitive BPX connection types (ATM CBR). cost-based route selection does not change this.

- **Cost Cap**—A maximum allowable cost value (cost cap) is used during route determination to prevent selection of a route which exceeds an acceptable cost. For routing based on delay, the cost cap is the acceptable end-to-end delay for the connection type. This cap is configured network-wide per delay sensitive connection type.

For routing based on trunk cost, the cost cap is the acceptable end-to-end cost. This cap is configured per connection. The default cost cap is 100, which is derived from the maximum hops per route (10) and default cost per trunk (10). The cost cap can be changed at any time. If the cost cap is decreased below the current route cost, the connection is not automatically rerouted. A manual reroute is required to route the connection to fit under the new cost cap. This gives the user more control over the connection reroute outage.

- **Software Upgrades**—A software upgrade to Release 9.0 sets AutoRoute to use Hop-Based Route Selection. The cost of all trunks is set to the default cost (10). The cost cap of all connections is set to the maximum allowable cost (100). All other new cost-based routing parameters are set to regular default values.
- **AutoRoute Interoperability**—Since AutoRoute is source-based, nodes can interoperate using different route selection algorithms. The originating node computes the full end-to-end route based on its own knowledge of the network topology. The route is then passed to the subsequent nodes on the route. This source routing allows a mix of Cost-Based and Hop-Based Route Selection to run in a network.

Cost-Based AutoRoute Commands

The following switched software Command Line Interface (CLI) commands are used for cost-based route selection:

- **cnfcmparm** - enables cost-based route selection. This is a super-user command used to configure all AutoRoute parameters. By default cost-based route selection is disabled. Enabling or disabling cost-based route selection can be done at any time. Each connection routing cycle uses whichever algorithm is enabled when the cycle begins. The configuration is node-based, not network-based, which allows each node to have its own route selection algorithm.

Enabling cost-based route selection automatically enables cache usage. Disabling cost-based route selection automatically disables cache usage. Cache usage may also be independently enabled or disabled.

- **cnftrk** - configures the administrative cost for a trunk. Both physical and virtual trunks have the cost attribute. Each trunk has a cost ranging from 1 (lowest) to 50 (highest). The default cost is 10 upon trunk activation.

The cost can be configured from either end of the trunk. The cost can be changed before or after the trunk has been added to the network. The cost can also be changed after connections have been routed over the trunk. Any cost change is updated network-wide. Every node in the network stores the cost of every trunk in the network. This knowledge is required for successful source-based routing.

- **cnftrcost** - new command which configures the cost cap for a connection. This command is valid only at the node where the connection is added.
- **cnfsysparm** - configures the delay cost cap for all delay sensitive connections in the network. This command was not modified in Release 9.0.
- **dspon** - displays the maximum and current costs for a connection route
- **dspload** - displays the administrative cost and queue delay for a network trunk
- **dsprts** - displays the current costs for all connection routes
- **dsptrknf** - displays the configured cost of a trunk

The *Cisco WAN Switching Command Reference* contains detailed information about the use of BPX switch commands.

Network Synchronization

Cisco WAN switching cell relay networks use a fault-tolerant network synchronization method of the type recommended for Integrated Services Digital Network (ISDN). Any circuit line, trunk, or an external clock input can be selected to provide a primary network clock. Any line can be configured as a secondary clock source in the event that the primary clock source fails.

All nodes are equipped with a redundant, high-stability internal oscillator that meets Stratum 3 (BPX) or Stratum 4 requirements. Each node keeps a map of the network's clocking hierarchy. The network clock source is automatically switched in the event of failure of a clock source.

There is less likelihood of a loss of customer data resulting from re-frames that occur during a clock switchover or other momentary disruption of network clocking with cell-based networks than there is with traditional TDM networks. Data is held in buffers and packets are not sent until a trunk has regained frame synchronism to prevent loss of data.

Switch Availability

Hardware and software components are designed to provide a switch availability in excess of 99.99%. Network availability will be impacted by link failure, which has a higher probability of occurrence, than equipment failure.

Because of this, Cisco WAN network switches are designed so that connections are automatically rerouted around network trunk failures often before users detect a problem. System faults are detected and corrective action taken often before they become service affecting. The following paragraphs describe some of the features that contribute to network availability.

Node Redundancy

System availability is a primary requirement with the BPX switch. The designed availability factor of a BPX switch is (99.99%) based on a node equipped with optional redundancy and a network designed with alternate routing available. The system software, as well as firmware for each individual system module, incorporates various diagnostic and self-test routines to monitor the node for proper operation and availability of backup hardware.

For protection against hardware failure, a BPX switch shelf can be equipped with the following redundancy options:

- Redundant common control modules
- Redundant crosspoint switch matrixes
- Redundant high-speed data and control lines
- Redundant power supplies
- Redundant high-speed network interface cards
- Redundant service interface cards

If redundancy is provided for a BPX switch, when a hardware failure occurs, a hot-standby module is automatically switched into service, replacing the failed module. All cards are hot-pluggable, so replacing a failed card in a redundant system can be performed without disrupting service.

Since the power supplies share the power load, redundant supplies are not idle. All power supplies are active; if one fails, then the others pick up its load. The power supply subsystem is sized so that if any one supply fails, the node will continue to be supplied with adequate power to maintain normal operation of the node. The node monitors each power supply voltage output and measures cabinet temperature to be displayed on the NMS terminal or other system terminal.

Node Alarms

Each BPX switch shelf within the network runs continuous background diagnostics to verify the proper operation of all active and standby cards, backplane control, data, and clock lines, cabinet temperature, and power supplies. These background tests are transparent to normal network operation.

Each card in the node has front-panel LEDs to indicate active, failed, or standby status. Each power supply has green LEDs to indicate proper voltage input and output. An Alarm, Status, and Monitor card collects all the node hardware status conditions and reports it using front panel LED indicators and alarm closures. Indicators are provided for major alarm, minor alarm, ACO, power supply status, and alarm history. Alarm relay contact closures for major and minor alarms are available from each node through a 15-pin D-type connector for forwarding to a site alarm system.

BPX switches are completely compatible with the network status and alarm display provided by the Cisco StrataView Plus NMS workstation. In addition to providing network management capabilities, it displays major and minor alarm status on its topology screen for all nodes in a network. The Cisco StrataView Plus NMS also provides a maintenance log capability with configurable filtering of the maintenance log output by node name, start time, end time, alarm type, and user specified search string.

General Description

This chapter contains an overall physical and functional description of the BPX switch. The physical description includes the BPX switch enclosure, power, and cooling subsystems. The functional description includes an overview of BPX switch operation.

This chapter contains the following:

- Physical Description
- Functional Description
- BPX Switch Major Groups
- Optional Peripherals

Physical Description

The BPX switch is supplied as a stand-alone assembly. It may be utilized as a stand-alone ATM switch, or it may be integrated at customer sites with one or more narrowband IPX switches, multi-band IGX switches, MGX 8220 shelves, and other access devices to provide network access to broadband backbone network links for narrowband traffic. Cisco and CPE service interface equipment can also be co-located with the BPX switch and connect to its ATM service interfaces.

BPX Switch Enclosure

The BPX switch enclosure is a self-contained chassis which may be rack mounted in any standard 19 inch rack or enclosure with adequate ventilation. It contains a single shelf which provides fifteen slots for vertically mounting the BPX switch cards front and rear. Refer to Figure 2-1 which illustrate the front view of the BPX switch Shelf.

At the front of the enclosure (see Figure 2-1) are 15 slots for mounting the BPX switch front cards. Once inserted, the cards are locked in place by the air intake grille at the bottom of the enclosure. A mechanical latch on the air intake grille must be released by using a screwdriver and the grille must be tilted forward in order to remove or insert cards.

At the rear of the enclosure (illustrated in Figure 2-2) is another series of card slots for mounting the rear plug-in cards. These are held in place with two thumbscrews, top and bottom. A mid-plane, located between the two sets of plug-in cards, is used for interconnect and is visible only when the cards are removed.

To provide proper cooling, it is essential that blank faceplates be installed in all unused slots. Failure to do so will degrade node cooling and circuit card damage will result. The blank faceplates also provide RFI shielding.

Figure 2-1 BPX Switch Exterior Front View





Figure 2-2 BPX Switch Exterior Rear View



H8017

Node Cooling


A fan assembly, with three six-inch 48 VDC fans is mounted on a tray at the rear of the BPX switch shelf (see Figure 2-2). Air for cooling the cards is drawn through an air intake grille located at the bottom in the front of the enclosure. Air passes up between the vertically-mounted cards and exhausts at the top, rear of the chassis. All unused slots in the front are filled with blank faceplates to properly channel airflow.

Node DC Powering

The primary power for a BPX switch node is -48 VDC which is bused across the backplane for use by all card slots. DC-to-DC converters on each card convert the 48V to lower voltages for use by the card. The 48 VDC input connects directly to the DC Power Entry Module (PEM). The DC Power Entry Module (see Figure 2-3) provides a circuit breaker and line filter for the DC input.

Nodes may be equipped with either a single PEM or dual PEMs for redundancy. They are mounted at the back of the node below the backplane. A conduit hookup box or an insulated cover plate is provided for terminating conduit or wire at the DC power input. It is recommended that the source of DC for the node be redundant and separately fused.


Figure 2-3 DC Power Entry Module Shown with Conduit Box Removed



Optional AC Power Supply Assembly

For applications requiring operation from an AC power source, an optional AC Power Supply Assembly and shelf is available. It provides a source of -48 VDC from 208/240 VAC input. A shelf, separate from the BPX switch shelf, houses one or two AC Power Supplies and mounts directly below the node cabinet. This provides a secure enclosure for the power supply assemblies (supplies cannot be removed without the use of tools).


Two of these supplies are usually operated in parallel for fail-safe redundant operation. The front of the AC Power Supplies for the BPX switch includes two green LEDs to indicate correct range of the AC input and the DC output for each individual supply (see Figure 2-4).

Figure 2-4 AC Power Supply Assembly Front View

Card Shelf Configuration

There are fifteen vertical slots in the front of the BPX switch enclosure to hold plug-in cards (see Figure 2-5). The middle two slots, slots number 7 and number 8, are used for the primary and secondary Broadband Controller Cards (BCC). The right-most slot, number 15, is used to hold the single Alarm/Status Monitor Card. The other twelve slots, number 1 through number 6 and number 8 through number 14, can be used for the Network Interface and Service Interface cards.

Figure 2-5 BPX Switch Card Shelf Front View




Functional Description

ATM

ATM transmits broadband information using fixed length, relatively small, 53-byte cells which are suitable for carrying both constant rate data (e.g., voice and video) as well as bursty data.

ATM evolved from the Broadband Integrated Services Digital Network (B-ISDN) standard, which in turn is an extension of ISDN. ISDN defines service and interfaces for public telecommunications networks. B-ISDN utilizes a 7-layer reference model similar to the Open Systems Interconnection (OSI) 7-layer architecture. ATM redefines the lower three levels as shown in Figure 2-6. These are the Physical Layer, the ATM layer, and the ATM Adaptation Layer (AAL).

Figure 2-6 B-ISDN Model



Physical Layer

The physical layer is divided into two parts, the Transmission Convergence sub-layer and the Physical Medium sub-layer.


The Physical Medium sub-layer (PMD) handles processing specific to a particular physical layer, such as transmission rate, clock extractions, etc.

The Transmission Convergence sub-layer (TC) extracts the information content from the physical layer data format. This includes HEC generation and checking, extraction of cells from the data stream, processing of idle cells, etc.

ATM Layer

The ATM layer processes ATM cells. The ATM cell consists of a 5-byte header and a 48-byte payload. The header contains the ATM cell address and other management information Figure 2-7.

Figure 2-7 ATM Cell Format



ATM Cell Headers

There are two basic header types defined by the standards committees, a UNI header and a NNI header; both are quite similar. Cisco has expanded on these header types to provide additional features beyond those proposed for basic ATM service. Usage of each of the various cell header types is described as follows:

- The UNI header (see Figure 2-8) must be specified for each *User-to-Network Interface*. A UNI is any interface between a user device, such as an ATM router, and an ATM network.
- The NNI header (see Figure 2-9) must be specified for each *Network-to-Network Interface*. This is used, for example, at the interface between a user's private ATM network and a service provider's public ATM network.
- The STI header (see Figure 2-10) is an extension of these two header types and is used between Cisco switching nodes to provide advanced network features, including ForeSight, that improve performance, efficiency, and congestion control.

Figure 2-8 UNI Header




Figure 2-9 NNI Header





Figure 2-10 STI Header

STI Header



HCF: Header Control Field, a 01 indicates an STI Cell
 VPI/VCI: Virtual Path/Virtual Channel Identifiers, same as UNI and NNI.

Payload Class:

- 0001 Non-Timestamped Data/Constant Bit Rate
- 0010 High Priority/Variable Bit Rate
- 0011 Voice/Constant Bit Rate
- 0100 Bursty Data A/Variable Bit Rate
- 0101 Time-Stamped Data/Constant Bit Rate
- 0110 Bursty Data B/Variable Bit Rate

CC: Congestion Control

- 00: No report 10: Congestion
- 01: Uncongested 11: Severe Congestion

F: ForeSight Forward Congestion Indication (FFCI).

Set to 1 if FECN in Frame is a 1, or if incoming cell FFCI is a 1, or egress queue experiences congestion.

R: Reserved

PTI: Payload Type Indicator

CLP: Cell Loss Priority. Same as for UNI or NNI. The CLP bit is set to 1 if the DE is set for a frame, or if the first FastPacket in a frame has its CLP set.

PTI, bits 4,3, and 2: bit 4 = 0, user data cell; bit 4 = 1, connection management cell bit 3 = 0, No congestion experienced bit 3 = 1, Congestion experienced bit 2 = 0, for user data cell, indicates CPE information bit 2 = 1, not used			
PTI	Bits	Description	
	432		
000	User Data Cell	no congestion experienced	SDU Type 0 (CPE information)
001	User Data Cell	no congestion experienced	SDU Type 1
010	User Data Cell	congestion experienced,	SDU Type 0 (CPE information)
011	User Data Cell	congestion experienced,	SDU Type 1
100	Connection Management Cell, OAM F5 Segment Flow Related cell		
101	Congestion Management Cell, OAM F5 End-to-End Flow related cell		
110	Connection Management Cell, reserved for future use.		
111	Connection Management Cell, reserved for future use.		

H8149

The most important fields in all three ATM cell header types are the *Virtual Path Identifier (VPI)* and a *Virtual Circuit Identifier (VCI)*. The VPI identifies the route (path) to be taken by the ATM cell while the VCI identifies the circuit or connection number on that path. The VPI and VCI are translated at each ATM switch, they are unique only for a given physical link.

A 4-bit *Generic Flow Control (GFC)* field in the UNI header is intended to be used for controlling user access and flow control. At present, it is not defined by the standards committees and is generally set to all zeros.

A 3-bit *Payload Type Indicator (PTI)* field indicates the type of data being carried in the payload. The first bit is a “0” if the payload contains user information and is a “1” if it carries connection management information. The second bit indicates if the cell experienced congestion over a path. If the payload is user information, the third bit indicates if the information is from Customer Premises Equipment. The PTI field is identical for UNI/NNI/STI.

In the STI header (see Figure 2-10), the *Payload Class* is used to indicate various classes of service and BPX switch queues, e.g., Opticlass, the enhanced class of service feature of the BPX switch. The *ForeSight Forward Congestion Indication*, the F bit, is used by ForeSight for congestion status.

The *Cell Loss Priority (CLP)* bit follows the PTI bits in all header types. When set, it indicates that the cell is subject to discard if congestion is encountered in the network. For frame relay connections, depending on mapping considerations, the frame Discard Eligibility status is carried by the CLP bit in the ATM Cell. The CLP bit is also set at the ingress to the network for all cells carrying user data transmitted above the minimum rate guaranteed to the user.

ATM Cell Addressing

Each ATM cell contains a two-part address, VPI/VCI, in the cell header. This address uniquely identifies an individual ATM virtual connection on a physical interface. VCI bits are used to identify the individual circuit or connection. Multiple virtual circuits that traverse the same physical layer connection between nodes are grouped together in a virtual path. The virtual path address is given by the VPI bits. The Virtual Path can be viewed as a trunk that carries multiple circuits all routed the same between switches

The VPI and VCI addresses may be translated at each ATM switch in the network connection route. They are unique only for a given physical link. Therefore, they may be reused in other parts of the network as long as care is taken to avoid conflicts.

The VCI field is 16 bits wide with UNI and NNI header types described earlier. This allows for a total possible 65, 535 unique circuit numbers. The UNI header reserves 8 bits for VPI (256 unique paths) while the NNI reserves 12 bits (4,096 unique paths) as it is likely that more virtual paths will be routed between networks than between a user and the network. The STI header reserves 8 bits for VCI and 10 bits for VPI addresses.

ATM Adaptation Layer

The purpose of the ATM Adaptation Layer (AAL) is to receive the data from the various sources or applications and convert, or adapt, it to 48-byte segments that will fit into the payload of an ATM cell. Since ATM benefits from its ability to accommodate data from various sources with differing characteristics, the Adaptation Layer must be flexible.

Traffic from the various sources have been categorized by the standards committees into four general classifications, Class A through Class D, as indicated in Table 2-1. This categorization is somewhat preliminary and initial developments have indicated that it may be desirable to have more than these initial four classes of service.

Table 2-1 Classes of Traffic and Associated AAL Layers

Traffic Class	Class A	Class B	Class C	Class D
Adaptation Layer (AAL)	AAL-1	AAL-2	AAL-3/4 AAL-5	AAL-3/4
Connection Mode	Connection-oriented	Connection-oriented	Connection-oriented	Connectionless
End-to-End Timing Relationship	Yes	Yes	No	No
Bit Rate	Constant	Variable	Variable	Variable
Examples	Uncompressed voice, constant bit-rate video	Compressed voice and video	Frame relay, SNA, TCP-IP, E-mail	SMDS

Initially, four different adaptation layers (AAL1 through AAL4) were envisioned for the four classes of traffic. However, since AAL3 and AAL4 both could carry Class C as well as Class D traffic and since the differences between AAL3 and AAL4 were so slight, the two have been combined into one AAL3/4.

AAL3/4 is quite complex and carries a considerable overhead. Therefore, a fifth adaptation layer, AAL5, has been adopted for carrying Class C traffic, which is simpler and eliminates much of the overhead of the proposed AAL3/4. AAL5 is referred to as the Simple and Efficient Adaptation Layer, or SEAL, and is used for frame relay data.

Since ATM is inherently a connection-oriented transport mechanism and since the early applications of ATM will be heavily oriented towards LAN traffic, many of the initial ATM products are implemented supporting the Class C Adaptation Layer with AAL5 Adaptation Layer processing for carrying frame relay traffic.


Referring back to Figure 2-6, the ATM Adaptation Layer consists of two sub-layers:

- Convergence Sub-Layer (CS)
- Segmentation and Reassembly Sub-Layer (SAR)

Data is received from the various applications layers by the Convergence Sub-Layer and mapped into the Segmentation and Reassembly Sub-Layer. User information, typically of variable length, is packetized into data packets called Convergence Sublayer Protocol Data Units (CS-PDUs). Depending on the Adaptation Layer, these variable length CS-PDUs will have a short header, trailer, a small amount of padding, and may have a checksum.

The Segmentation and Reassembly Sub-Layer receives the CS-PDUs from the Convergence Sub-Layer and segments them into one or more 48-byte SAR-PDUs, which can be carried in the 48-byte ATM information payload bucket. The SAR-PDU maps directly into the 48-byte payload of the ATM cell transmitted by the Physical Layer. Figure 2-11 illustrates an example of the Adaptation Process.

Figure 2-11 SAR Adaptation Process



IPX and IGX Switch Trunk Interfaces to ATM

The IPX switch connects to a BPX switch or other ATM switch via an AIT/BTM T3 or E3 trunk. The IGX switch also connects to an ATM trunk via the UXM card. The AIT(IPX switch) or BTM (IGX switch) can operate in several different addressing modes selected by the user (see Table 2-2 and

Figure 2-12). To allow the IPX switch or IGX switch to be used in mixed networks with other ATM switches, there are two other addressing modes available, Cloud Addressing Mode (CAM) and Simple Addressing Mode (SAM).

BAM

In the BPX switch Addressing Mode (BAM), used for all Cisco WAN switching networks, the system software determines VPI and VCI values for each connection that is added to the network. The user enters the beginning and end points of the connection and the software automatically programs routing tables in each node that will carry the connection to translate the VPI/VCI address. The user does not need to enter anything more. This mode uses the STI header format and can support all of the optional Cisco WAN switching features.

SAM

In the Simple Addressing Mode (SAM), the user must manually program the path whole address, both VPI and VCI values.


CAM

The Cloud Addressing Mode (CAM) is used in mixed networks where the virtual path addresses are programmed by the user and the switch decodes the VCI address. Both CAM and SAM utilize the UNI header type.

Table 2-2 ATM Cell Addressing Modes

Addressing Mode	Hdr. Type	Derivation of VPI/VCI	Where Used
BAM-BPX switch Addressing Mode	STI	VPI/VCI = Node Derived Address	Between IPX switch (or IGX switch) and BPX switches, or between IPX switch (or IGX switch) nodes.
CAM—Cloud Addressing Mode	UNI	VPI = User Programmed VCI = Node Derived Address	IPX switch to IPX switch (or IGX switch) connections over networks using ATM switches that switch on VPI only. VPI is manually programmed by user. Terminating IPX switch converts VCI address to FastPacket address.
SAM—Simple Addressing Mode	UNI	VPI/VCI = User Programmed	IPX switch to IPX switch (or IGX switch) connections over networks using ATM switches that switch where all routing is manually programmed by user, both VPI and VCI.

Figure 2-12 BAM, CAM, and SAM Configurations



Note: IPX with AIT card are interchangeable with IGX with BTM card in this diagram.

FastPacket Adaptation to ATM

A specialized adaptation that is of particular interest to users of Cisco equipment is the adaptation of IPX switch FastPackets to ATM cells. There are a large number of narrowband IPX switch networks currently in existence that are efficiently carrying voice, video, data, and frame relay. A means must be provided to allow these networks to grow by providing a migration path to broadband.

Since FastPackets are already a form of cell relay, the adaptation of FastPackets to ATM cells is relatively simple.

Simple Gateway

With the Simple Gateway protocol, the AIT card in the IPX switch (or BTM in the IGX switch) loads 24-byte FastPacket cells into ATM cells in ways that are consistent with each application. (Each of the two FastPacket cells loaded into the ATM Cell is loaded in its entirety, including the FastPacket header.) For example, two FastPackets can be loaded into one ATM cell provided they both have the same destination. This adaptation is performed by the IPX switch AIT card or the IGX switch BTM card.


The AIT (or BTM) is configured to wait a given interval for a second FastPacket to combine in one ATM cell for each FastPacket type. The cell is transmitted half full if the wait interval expires. High priority and non-time stamped packets are given a short wait interval. High priority FastPackets will not wait for a second FastPacket. The ATM trunk interface will always wait for frame relay data (bursty data) to send two packets. NPC traffic will always have two FastPackets in an ATM cell.

Complex Gateway, Frame Relay to ATM Network Interworking


Starting with Release 8.1, with the Complex Gateway capability, the FRSM card in the MGX 8220, the AIT card in the IPX switch (or BTM card in the IGX switch) streams the frame relay data into ATM cells, cell after cell, until the frame has been completely transmitted. Since only the data from the FastPacket is loaded, the Complex Gateway is an efficient mechanism. Also, discard eligibility information carried by the frame relay bit is mapped to the ATM cell CLP bit, and vice versa. See Chapter 13 for further information on frame relay to ATM interworking. A comparison of the simple gateway and complex gateway formats is shown in Figure 2-13.

Figure 2-13 Simple and Complex Gateway Formats

Simple gateway (AIT card) :



Complex gateway (AIT Card) :



BPX Switch Major Groups

There are four major groups in the BPX switch. These are listed in Table 2-3.

- Common Core
- Network Interface
- Service Interface
- Power Supplies

Table 2-3 lists these groups and their components along with a brief description of each.

Table 2-3 BPX Switch Plug-In Card Summary

Card	Card Name	Where
Common Core Group		
BCC-32	Broadband Controller Card, operates with all versions of System Software Rel. 7.0 and above, and requires 32 Mbyte RAM for 8.1 and later software. For redundancy configuration, installed as a pair of BCC-32s. (System operation equivalent to BCC-3.)	Front
BCC-bc	Back card (also known as LM-BCC) used only with the BCC-32.	Back
BCC-3	Broadband Controller Card, operates with 7.X software versions 7.2.84 and above, and with 8.X System Software versions 8.1.12 and above. For redundancy configuration, installed as a pair of BCC-3s. (System operation equivalent to BCC-32.)	Front
BCC-4	Broadband Controller Card, operates with 8.4 software and above. For redundancy configuration, installed as a pair of BCC-4s. Provides 64 Mbyte of RAM and above. Supports 19.2 Gbps performance of BXM cards.	Front
BCC-3-bc	Back card (also known as LM-BCC) used with BCC-3 or BCC-4.	Back
ASM	Alarm/Status Monitor Card.	Front
LM - ASM	Line Module - Alarm/Status Monitor.	Back
Network Interface Group		
BXM-T3/E3-8/12	T3/E3 card with 8 or 12 ports. Card is configured for use in either network interface or service access (UNI) mode and with either a T3 or E3 interface.	Front
BPX-T3/E3-8	Backcard for use with a BXM-T3/E3-8.	Back
BPX-T3/E3-12	Backcard for use with a BXM-T3/E3-12.	Back
BXM-155-4 BXM-155-8	BXM OC-3 cards with 4 or 8 OC-3/STM-1 ports, respectively. Card is configured for use in either network interface or service access (UNI) mode.	Front
MMF-155-4 SMF-155-4 SMFLR-155-4	Backcards for BXM-155-4.	Back
MMF-155-8 SMF-155-8 SMFLR-155-8	Backcards for BXM-155-8.	Back


Table 2-3 BPX Switch Plug-In Card Summary (Continued)

Card	Card Name	Where
BXM-622 BXM-622-2	OC-12 card with 1 or 2 OC-12/STM-4 ports. Card is configured for use in either network interface or service access (UNI) mode.	Front
BME	Used for multicast connections. Used with SMF-622-2 backcard with port 1 looped to port 2, transmit to receive, and receive to transmit.	
SMF-622 SMFLR-622	Backcards for BXM-622.	Back
SMF-622-2 SMFLR-622-2	Backcards for BXM-622-2 and BME (BME typically would use SMF-622-2)	Back
SMFXLR		Back
BNI - T3	Broadband Network Interface Card (with 3 T3 Ports).	Front
LM - 3T3	Line Module - used with BNI-T3 for 3 physical T3 ports. (Configured for 3 ports)	Back
BNI - E3	Broadband Network Interface Card (with 3 E3 Ports).	Front
LM - 3E3	Line Module - used with BNI-E3 for 3 physical E3 ports. (Configured for 3 ports).	Back
BNI-155	Broadband Network Interface Card (with 2 OC3c/STM-1 ports).	Front
LM-2OC3-SMF	OC3/STM-1 Interface Card, single mode fiber optic, used with either BNI-155 or ASI-155 front card.	Back
LM-2OC3-SMFLR	OC3/STM-1 Interface Card, single mode fiber optic long range, used with either BNI-155 or ASI-155.	Back
LM-2OC3-MMF	OC3/STM-1 Interface Card, multi-mode fiber optic (1 x 9 LED), used with either BNI-155 or ASI-155 front card.	Back
Service Interface Group		
ASI-1-2T3	ATM Service Interface Card (with 2 usable T3 ports).	Front
LM - 3T3	Line Module - used with ASI-1-2T3 for 2 physical T3 ports. (Configured for 2 ports)	Back
ASI-1-2E3	ATM Service Interface Card (with 2 usable E3 ports).	Front
LM - 3E3	Line Module - used with BNI-E3 for 2 physical E3 ports. (Configured for 2 ports)	Back
ASI-155	ATM Service Interface Card (with 2 OC3c/STM-1 ports).	Front
LM-2OC3-SMF	OC3/STM-1 Interface Card, SMF (single mode fiber optic) MMF (1x9 LED), used with either BNI-155 or ASI-155 front card.	Back
LM-2OC3-MMF	OC3/STM-1 Interface Card, multi-fiber mode (1 x 9 LED), used with BNI-155 or ASI-155.	Back
LM-2OC3-SMFLR	OC3/STM-1 Interface Card, single mode fiber optic long range, used with either BNI-155 or ASI-155.	Back
Power Supply Group		
48 Volt DC Power Supply		
Optional AC Power Supply		

Optional Peripherals

At least one node in the network (or network domain if a structured network) must include a Strata-View Plus network management station (see Figure 2-14). A Y-cable may be used to connect the LAN ports on the primary and secondary BCC Line Modules, through an AUI to the LAN network, as only one BCC is active at a time. The serial Control port may be connected to a dial-in modem for remote service support or other dial-up network management access. The serial Auxiliary port is used for outgoing data only, for example, for connection to a printer.

Figure 2-14 Optional Peripherals Connected to BPX Switch



Two ports on BCC-LM can be used to connect up to two (2) of the peripherals shown.

BPX Switch Common Core

This chapter contains a description of the common core group, comprising the Broadband Controller Cards (BCCs), the Alarm/Status Monitor (ASM) card, associated backcards, and the StrataBus backplane.

This chapter contains the following:

- BPX Switch Common Core Group
- Broadband Controller Card (BCC-32, BCC-3, BCC-4)
- Alarm/Status Monitor Card
- BPX Switch StrataBus 9.6 and 19.2 Gbps Backplanes

BPX Switch Common Core Group

The BPX switch Common Core group includes the Broadband Controller Card (BCC-3 and associated BCC-3-bc backcard, or BCC-32 and associated BCC-b backcard), or BCC-4 and associated BCC-3-c backcard, the Alarm/Status Monitor (ASM), a Line Module for the ASM card (LM-ASM), and the StrataBus backplane (see Figure 3-1). The BCC-3 and BCC-32 are functionally equivalent and support 9.6 Gbps operation, but use different backcards. The BCC-4 supports the 19.2 Gbps operation of the BXM cards and provides 32M or 64M.

- ATM cell switching.
- Internal node communication.
- Remote node communication.
- Node synchronization.
- Network management communications (Ethernet), local management (RS-232).
- Alarm and status monitoring functions.


Broadband Controller Card (BCC-32, BCC-3, BCC-4)

The Broadband Controller Card is a microprocessor-based system controller and is used to control the overall operation of the BPX switch. The controller card is a front card that is usually equipped as a redundant pair. Slots number 7 and number 8 are reserved for the primary and secondary (standby) broadband controller cards. Each broadband controller front card requires a corresponding back card.

- For non-redundant nodes, a single BCC is used in front slot number 7 with its appropriate backcard.
- For redundant nodes, a pair of BCCs of matching type, are used in front slot numbers 7 and 8.

Note The three types of BCCs with their proper backcards may be operated together temporarily for maintenance purposes, e.g., replacing a failed controller card. Throughout a network, individual BPX switches may have either a single BCC-32, BCC-3, or BCC-4 controller card or a pair of BCC-32 cards, a pair of BCC-3 cards, or a pair of BCC-4 cards.

Figure 3-1 Common Core Group Block Diagram



H8023

The BCC-3 and BCC-32 are functionally equivalent and the BCC-4 is similar except for some additional features such as support of 19.6 Gbps operation. The term BCC is used in this manual to refer to the functional operation of the Broadband Controller Card. When a difference in operation does occur, the specific type of BCC is specified. This card group (see Figure 3-1) provides the following functions:

Features

The Broadband Controller Card performs the following major system functions:

- Runs the system software for controlling, configuring, diagnosing, and monitoring the BPX switch.
- Contains the crosspoint switch matrix operating at 800 Mbps per serial link (BCC-32 or BCC-3) or up to 1600 Mbps (BCC-4).
- Contains the arbiter which controls the polling each high-speed data port and grants the access to the switch matrix for each port with data to transfer.
- Generates Stratum 3 system clocking and can synchronize it to either a selected trunk or an external clock input.
- Communicates configuration and control information to all other cards in the same node over the backplane communication bus.
- Communicates with all other nodes in the network.
- Provides a communications processor for an Ethernet LAN port plus two low-speed data ports. The BCC-bc provides the physical interface for the BCC-32, and the BCC-3-bc provides the physical interface for the BCC-3 and BCC-4.

Each Broadband Controller Card includes the following:

- 68EC040 processor operating at 33 MHz.
- 32 Mb of DRAM for running system software (BCC-32 and BCC-3), 32 Mb or 64 MB option for BCC-4.
- 4 Mb of Flash EEPROM for downloading system software.
- 512 Kbps of BRAM for storing configuration data.
- EPROM for firmware routines.
- 68302 Utility processor.
- SAR engine processor operating at 33 MHz.
- Communication bus interface.
- HDLC processor for the LAN connection interface.
- Two RS-232 serial port interfaces.

Functional Description

The BPX switch is a space switch. It employs a crosspoint switch for individual data lines to and from each port. The switching fabric in each BPX switch consists of three elements for the BCC-32, BCC-3 and for the BCC-4 (see Figure 3-2 and Figure 3-3):

- Central Arbiter on each BCC.
- Crosspoint Switch.
 - 16 X 16 Crosspoint Switching Matrix on each BCC (12 X 12 used) for BCC-32 and BCC-3.
 - 16 X 32 Crosspoint Switching Matrix on each BCC (2 X [12 X 12]) used for BCC-4.
- Serial Interface and LAN Interface Modules on each BCC and on each Function Module.

The arbiter polls each card to see if it has data to transmit. It then configures the crosspoint switching matrix to make the connection between the two cards. Each connection is unidirectional and has a capacity of 800 Mbps (616.7 Mbps for cell traffic plus the frame overhead).

Since there are 16 X 16 (BCC-32 or BCC-3) or 16 X 32 (BCC-4) independent crosspoints and only 15 cards, the switch fabric is non-blocking. However, only one connection at a time is allowed to an individual card. The BPX switch cell switching is not synchronized to any external clocks; it runs at its own rate. No switch fabric clocks are used to derive synchronization nor are these signals synchronized to any external sources.

Each card contains a Switch Interface Module (SIM) which merely provides a standardized interface between the card and the data lines and polling buses. The SIM responds to queries from the BCC indicating whether it has data ready to transmit.

With the BPX switch equipped with two BCCs, the cell switching is completely redundant in that there are always two arbiters, two crosspoint switches, two completely independent data buses, and two independent polling buses.

The BCC incorporates non-volatile flash EEPROM which permits new software releases to be downloaded over the network and battery-backup RAM (BRAM) for storing user system configuration data. These memory features maintain system software and configuration data even during power failures, eliminating the need to download software or reconfigure after the power returns.

Node clocking is generated by the BCC. Since the BPX switch resides as an element in a telecommunications network, it is capable of synchronizing to higher-stratum clocking devices in the network and providing synchronization to lower stratum devices. The BCC can be synchronized to any one of three different sources under software control:

- An internal, high-stability oscillator
- Derived clock from a BNI module (no IPX clock sources allowed)
- An external clock source connected directly to the BPX

The BCC clock circuits provide clocking signals to every other card slot. If a function card needs to synchronize its physical interface to the BPX switch clock, it can use this timing signal to derive the proper reference frequency. These reference frequencies include DS1, E1, DS3, and E3.

Figure 3-2 BCC-32 and BCC-3 Block Diagram





Figure 3-3 BCC-4 Block Diagram




Front Panel Description

The BCC front panel has four Led, three card status LEDs, and a LAN LED. (See Figure 3-4 and Table 3-1.)

Table 3-1 BCC Front Panel Indicators

No	Indicator	Function
1	LAN	Indicates there is data activity over the Ethernet LAN port.
2	card - act	Card active LED indicates this BCC is on-line and actively controlling the node.
3	card - stby	Card standby LED indicates this BCC is off-line but is ready to take over control of the node at a moments notice.
4	card - fail	Card fail LED indicates this BCC has failed the internal self-test routine and needs to be reset or replaced.

Figure 3-4 BCC Front Panel



The BCC runs self-tests continuously on internal functions in the background and if a failure is detected, the **fail** LED is lighted. If the BCC is configured as a redundant pair, the off-line BCC is indicated by the lighted **stby** LED. The **stby** LED also flashes when a software download or standby update is in progress. The LAN LED indicates activity on the Ethernet port.

19.2 Gbps Operation with the BCC-4

In order to operate the BPX switch at 19.2 Gbps the following is required:

- A 19.2 Gbps backplane
- BCC-4 or later controller cards
- One or more BXM cards
- Release 8.4.00 or later switch software
- A backplane NOVRAM that is programmed to identify the backplane as a 19.2 Gbps backplane.

Switch software will not allow node operation at 19.2 Gbps unless it can read the backplane NOVRAM to verify that the backplane is a 19.2 Gbps backplane.

The 19.2 backplane can be visually identified by the small white card slot fuses at the bottom rear of the backplane. These fuses are approximately 1/4 inch high and 1/8 inch wide. The 9.6 Gbps backplane does not have these fuses. If the BPX switch is a late model, then a 19.2 Gbps backplane is installed. This can be verified by running the **despond** command which will display “Word #2 =0001” if the backplane NOVRAM has been programmed. If anything else is displayed, visually check the backplane for the fuses.

If the backplane is a 19.2 Gbps backplane, but the backplane NOVRAM has not been set to display Word #2 =0001, then the **cnfbpnv** command may be used to program the NOVRAM as follows:

Step 1 Enter **cnfbpnv**, and the response should be:

```
Are you sure this is a new backplane (y/n).
```

Step 2 Enter **y**

Step 3 Confirm that the change has been made by entering **dspbpnv** to confirm the response:

```
Word #2 =0001
```

Note If for some reason the change does not take place, it will be necessary to change the backplane NOVRAM. Contact Customer Service.

Step 4 Enter **switchcc** in order for the change to be recognized by the switch software.

If the backplane is not a 19.2 Gbps backplane, then it will be necessary to install a 19.2 Gbps backplane to obtain 19.2 Gbps operation. Contact Customer Service.

Back Cards for the BCC-3 and BCC-32

The backcards for the Broadband Controller Card serve as an interface between the BPX switch and the BPX switch network management system. For the BCC-32, the backcard is the BCC-bc. For the BCC-3 and BCC-4, the backcard is the BCC-3-bc. (These cards are also known as the BCC

backcards). The BCC-3 and the BCC-32 are functionally interchangeable, while the BCC-4 provides additional features such as support for 19.2 Mbps operation by the BXM cards. Both BCCs in a node should be of the same type. The backcard provides the following interfaces:

- An 802.3 AIU (Ethernet) interface for connecting the node to a StrataView Plus NMS.
- A serial RS-232 Control Port for connecting to a VT100-compatible terminal or modem.
- A serial RS-232 Auxiliary Port for connecting to an external printer.
- External clock inputs at T1 or E1 rates, output at 8 kHz.

The face plate connectors are described in Table 3-2 and Table 3-3 and shown in Figure 3-5. For information on cabling, refer to Appendix B, BPX Switch Cabling Summary.


Table 3-2 Backcard (Line Module) for BCC-32, Connectors

BCC-C Connector	BCC-C Function
CONTROL	A DB25 connector for a VT100 or equivalent terminal for a basic terminal connection using command line interface commands. Can also be connected to a dial-in modem for remote service support or other network management dial-up access. This is a bidirectional RS232 communications port. This is not used for SV+ Network Management; the LAN connector is used for SV+ Network Management.
AUXILIARY	A DB25 connector for a system printer. This is a one-way, RS232 outgoing port.
XFER TMG	DB15 connector that supplies an 8-kHz timing signal (RS422 type output that is synchronized to the BPX switch system clock.) This signal can be used to synchronize a co-located IPX.
EXT TMG	A 75-ohm BNC connection for clock input. An E1 source with 75 ohm impedance typically uses this connector. If the shield on the cable needs grounding, slide the BCC back card out and jumped connector JP1 across its two pins.
EXT TMG	DB15 connector for a primary and optional redundant external source of system clock. A T1 source with 100 ohm impedance or an E1 source with 100/120 ohm impedance typically use this connector.
LAN	A DB15 Ethernet LAN connection for connecting to a StrataView Plus NMS. A terminal or NMS other than SV+ can also be connected to the BPX switch LAN port via Ethernet. However, only the SV+ NMS provides full management configuration and statistics capabilities via SNMP and TFTP.

Table 3-3 Back Card (Line Module) for BCC-3 & 4, Connectors

BCC-3-C Connector	BCC-3-C Function
CONTROL	A DB25 connector for a VT100 or equivalent terminal for a basic terminal connection using command line interface commands. Can also be connected to a dial-in modem for remote service support or other network management dial-up access. This is a bidirectional RS232 communications port. This is not used for SV+ Network Management; the LAN connector is used for SV+ Network Management.
AUXILIARY	A DB25 connector for a system printer. This is a one-way, RS232 outgoing port.
LAN	A DB15 Ethernet LAN connection for connecting to a StrataView Plus NMS. A terminal or NMS other than SV+ can also be connected to the BPX switch LAN port via Ethernet. However, only the SV+ NMS provides full management configuration and statistics capabilities via SNMP and TFTP.
EXT TMG	A 75-ohm BNC connection for clock input. An E1 source with 75 ohm impedance typically uses this connector. If the shield on the cable needs grounding, slide the BCC back card out and jumped connector JP1 across its two pins.
EXT 1 TMG	DB15 connector for a primary and optional redundant external source of system clock. A T1 source with 100 ohm impedance or an E1 source with 100/120 ohm impedance typically use this connector.
EXT 2 TMG	Provides for an external clock source redundant to the EXT 1 TMG source.

Figure 3-5 BCC-3-bc or BCC-c Face Plate Connectors



Another function of the line module back card is to provide two low-speed, serial communications ports. (Refer to Table 3-3.) The first port (CONTROL) is a bidirectional port used for connecting the BPX switch to a local terminal or to a modem for a remote terminal “dial-in” connection. The second port (AUXILIARY) is an output only and is typically used to connect to a log printer.

The SV+ NMS is connected to the LAN port on the BCC backcards. When control is provided via an Ethernet interface, the node IP address is configured with the **cnflan** command for the BPX switch, and the back cards are Y-cable connected to an AUI adapter (individual cables and AUIs may also be used for each LAN port). The LAN port of the primary Broadband Control Card is active. If

the secondary Broadband Control Card becomes primary (active), then its LAN port becomes active. The SV+ workstation will automatically try to restore communications over the LAN and will interface with the newly active Broadband Controller Card.

For small networks, one SV+ workstation is adequate to collect statistics and provide network management. For larger networks additional SV+ workstations may be required. Refer to the *Cisco StrataView Plus Operations Guide* for more information.

Alarm/Status Monitor Card

The Alarm/Status Monitor (ASM) card is a front card and a member of the BPX switch Common Core group. Only one is required per node and it is installed in slot 15 of the BPX switch. It is used in conjunction with an associated back card, the Line Module for the ASM (LM-ASM) card. The ASM and LM-ASM cards are non-critical cards used for monitoring the operation of the node and not directly involved in system operation. Therefore, there is no provision or requirement for card redundancy.

Features

The ASM card provides a number of support functions for the BPX switch including:

- Telco compatible alarm indicators, controls, and relay outputs.
- Node power monitoring (including provision for optional external power supplies).
- Monitoring of shelf cooling fans.
- Monitoring of shelf ambient temperature.
- Sensing for the presence of other cards that are installed in the BPX switch.

Functional Description

There are four significant circuits controlled by the ASM processor: alarm, power supply monitor, fan and temperature monitor, and card detection. The alarm monitor controls the operation of the front panel alarm LEDs and ACO and history pushbuttons as well as the alarm relays which provide dry contact closures for alarm outputs to customer connections. BPX switch system software commands the ASM card to activate the major and minor alarm indicators and relays.

The power supply monitor circuit monitors the status of the -48V input to the shelf on each of the two power buses, A and B. The status of both the A bus and B power bus is displayed on the ASM front panel.

Each of the three cooling fans is monitored by the fan monitor circuit which forwards a warning to the BPX switch system software if any fan falls below a preset RPM. Cabinet internal temperature is also monitored by the ASM which sends the temperature to the system software so it may be displayed on the NMS terminal. The range that can be displayed is 0 degrees to 60 degrees Centigrade.


Front Panel Description

The front panel displays the status of the node and any major or minor alarms that may be present. Figure 3-6 illustrates the front panel of the ASM card. Each front panel feature is described in Table 3-4.

Table 3-4 ASM Front Panel Controls and Indicators

No	Controls/ Indicator	Function
1	alarms LEDs	A red major alarm and a yellow minor alarm indicator to display the status of the local node. In general, a major alarm is service-affecting whereas a minor alarm is a non-service affecting failure.
2	dc LEDs	Two green LEDs displaying the status of the two dc power busses on the Stratabus backplane. On—indicates voltage within tolerance. Off—indicates an out-of-tolerance voltage.
3	ACO/hist LEDs	ACO LED (yellow) lights when the front panel ACO pushbutton is operated. History LED (green) indicates an alarm has been detected by the ASM at some time in the past but may or may not be clear at present time.
4	ACO switch	When operated, releases the audible alarm relay.
5	history clear switch	Extinguishes the history LED if the alarm condition has cleared. If the alarm is still present when the history clear switch is thrown, the history LED will stay lit.
6	card status LEDs	Active (green) indicates card is on-line and clear of alarms. Standby (yellow) indicates card is off-line. Fault (red) indicates a card failure is detected by the card self-test diagnostics.

Figure 3-6 ASM Front Panel Controls and Indicators



Line Module for the Alarm/Status Monitor Card


The Line Module for the Alarm/Status Monitor Card (LM-ASM) is a back card to the ASM card. It provides a simple connector panel for interfacing to the customer alarm system. It is not required for system and ASM operation and must be installed in back slot number 15.

Figure 3-7 illustrates the face plate of the LM-ASM which contains a single subminiature connector (see Table 3-5). The Alarm Relay connector provides dry-closure (no voltage) relay contact outputs.

Table 3-5 LM-ASM Face Plate Connectors

No	Connector/ Indicator	Function
1	ALARM RELAYS	A DB15 connector for alarm relay outputs. Refer to Chapter 3 or Appendix C for pinouts.

Figure 3-7 LMI-ASM Face Plate



BPX Switch StrataBus 9.6 and 19.2 Gbps Backplanes

The BPX switch may be equipped with a backplane that supports either a 9.6 or 19.2 Gbps operation. The 19.2 Gbps backplane can physically be identified by the card slot fuses on the bottom rear of the backplane. Further information is provided in the *Cisco BPX 8600 Series Reference*.

All BPX switch modules are interconnected by the BPX switch StrataBus backplane physically located between the front card slots and the back card slots. Even though the ATM data paths to/from the switching fabric and the interface modules are individual data connections, there are also a number of system bus paths used for controlling the operation of the BPX switch. The StrataBus backplane, in addition to the 15 card connectors, contains the following signal paths:

- ATM crosspoint wiring—individual paths used to carry ATM trunk data between both the network interface and service interface module(s) and the crosspoint switching fabric.
- Polling bus—used to carry enable signals between the BCC and all network interface modules.
- Communications bus—used for internal communications between the BCC and all other cards in the node.
- Clock bus—used to carry timing signals between the BCC and all other system cards.
- Control bus—enables either the A bus wiring or B bus wiring.

All StrataBus wiring is completely duplicated and the two sets of bus wiring operate independently to provide complete redundancy. Either the A side wiring or B side wiring is enabled at any particular time by signals on the Control bus.

Network Interface (Trunk) Cards

This chapter contains a description of the BPX switch network interface (trunk) cards, including the Broadband Network Interface (BNI) and associated backcards. The BXM cards are briefly described in this chapter and covered in full in a later chapter.

This chapter contains the following:

- BPX Switch Network Interface Group
- BXM Cards, Trunk Mode Summary
- Broadband Network Interface Cards (BNI-T3 and BNI-E3)
- T3 and E3 Line Modules (LM-3T3 and LM-3E3)
- Broadband Network Interface Cards, BNI-155
- OC3, Line Modules (SMF, SMFLR, & MMF)
- Y-Cabling of BNI Backcard, SMF-2-BC9

BPX Switch Network Interface Group

The BPX switch network interface group of cards provides the interface between the BPX switch and the ATM network (see Figure 4-1). The BNI series of cards (DS3, E3, and OC3) are described in this chapter. The BXM card trunk operation is briefly described in this chapter with additional information provided in a later chapter. The BXM cards may be configured for either trunk or service (port UNI) mode. In trunk mode they provide BPX switch network interfaces.


BXM Cards, Trunk Mode Summary

The BXM card sets supports T3/E33, OC-3/STM-1 or OC-12/STM-4 interfaces, and provide the capacity to meet the needs of emerging bandwidth driven applications. The BXM cards provide high speed ATM connectivity, flexibility, and scalability. The card sets are comprised of a front card that provides the processing, management, and switching of ATM traffic and a back card that provides the physical interface for the card set.

A BXM port may be configured to operate as either a trunk or UNI port. The BXM OC-12 back cards support either Single Mode Fiber (SMF) or Single Mode Fiber Long Reach (SMFLR). The BXM OC-3 back cards support either Multi-Mode Fiber (MMF), Single Mode Fiber (SMF), or Single Mode Fiber Long Reach (SMFLR). The BXM-T3/E3 supports T3 1.544 Mbps and E3 34.368 Mbps interfaces.

For a further description of the BXM cards refer to Chapter 6, BXM T3/E3, 155, and 622.

Figure 4-1 BPX Switch Network Interface Group



Broadband Network Interface Cards (BNI-T3 and BNI-E3)

The BNI-T3 and BNI-E3 interface the BPX switch with ATM T3 and E3 broadband trunks, respectively. These ATM trunks may connect to either another BPX, an IPX switch equipped with an AIT card, or an MGX 8220.

The BNI-3T3 back card provides three DS3 interfaces on one card while the BNI-E3 back card provides three E3 interface ports. The BNI back card types are very similar differing only in the electrical interface and framing. Any of the 12 general purpose slots can be used to hold these cards. Each BNI operates as a pair with a corresponding Line Module back card.

Features

A summary of features for the BNI cards include:

- BNI-T3 provides three broadband data ports operating at 44.736 Mbps.
BNI-E3 provides three broadband data ports operating at 34.368 Mbps.
- BNI T3 trunks can transmit up to 96,000 cells per second.
BNI E3 trunks can transmit up to 80,000 cells per second.
- BNI-T3 utilizes the Switched Megabit Data Service (SMDS) Physical Layer Convergence Protocol (PLCP).
- BNI-E3 utilizes the CCITT G.804 framing format.
- T3 and E3 provide up to 32 class-based queues for each port.
- 24,000 cell transmit buffer per port.
- 800 Mbps backplane speed.
- Two-stage priority scheme for serving cells.
- Synchronize the electrical interface to either the line or the BPX switch system timing.
- Recover timing from the line for synchronizing the BPX switch timing.
- Accumulates trunk statistics for T3, E3, and OC3.
- Optional 1:1 card redundancy using Y-cable configuration for BNI T3 and E3.

Functional Description

The BNI T3 and E3 cards are functionally alike except for the two different electrical interfaces. Refer to Figure 4-2 illustrating the main functional blocks in the BNI-3T3 card.

The DS3 port interface on the BNI-T3 card is the DS3 Function Block, a Physical Layer Protocol Processor (PLPP) custom semiconductor device, which implements the functions required by the DS3 PLCP as defined in various AT&T™ technical advisories. This VLSI device operates as a complete DS3 transmitter/receiver. Each BNI-3T3 has three of these devices, one for each of the DS3 ports on the card.

Egress

In the transmit direction (from the BPX switching matrix towards the transmission facility, referred to as egress), the BNI performs the following functions:


- Software controlled line buildout to match up to 900 feet (275 meters) of ABAM cable.
- Receives incoming cells from the switch matrix on the BCC.
- Queues and serves the cells based on the class-of-service algorithm.
- Sets congestion indication (EFCN) in cell header when necessary.
- Adds frame sync pattern and PLCP or G.804 overhead and transmits cells onto the T3 or E3 trunk.

Ingress

In the receive direction (from the transmission facility towards the BPX switching matrix, sometimes referred to as ingress), the BNI performs the following functions:

- Receives incoming ATM cells from the DS3 transmission facility, stripping the framing and overhead from the received bit stream.
- Determines the address of the incoming cells by scanning the Virtual Path Identifier (VPI)/Virtual Circuit Identifier (VCI) in the cell header.
- Queues the cells for transmission through the switch matrix.
- Extracts receive timing from the input framing and makes it available for node timing. Line can operate in looped timing mode.
- Recovers clock and data from the bipolar B3ZS (T3) or HDB3 (E3) line signal and converts data to unipolar.

Figure 4-2 Simplified BNI-T3, BNI-E3 Block Diagram



Some of the functions performed by the PLPP in the BNI-3T3 include:

- PLPP— Receiver Side
 - Provides frame sync for either the M23 or C-bit parity frame format.
 - Provides alarm detection and accumulates B3ZS code violations, framing errors, parity errors, C-bit parity errors, and far end bit error (FEBE) events.
 - Detects far end alarm channel codes, yellow alarm, and loss of frame.
 - Provides optional cell descrambling, header check sequence (HCS) error detection, and cell filtering.
 - Small receive FIFO buffer for incoming cells.
- PLPP—Transmitter Side
 - Inserts proper frame bit sequence into outgoing bit stream.
 - Inserts proper alarm codes to be transmitted to the far end.
 - Provides optional ATM cell scrambling, HCS generation and insertion, and programmable null cell generation.
 - Small transmit FIFO for outgoing cells.

In the BNI-3E3 the PLPP is replaced by a G.804 framer. The E3 framer obtains end-to-end synchronization on the Frame Alignment bytes. And a E3 transmitter/receiver replaces the DS3 transmitter/receiver for the BNI-3E3.

Another major BNI function is queuing of the ATM cells waiting to be transmitted to the network trunk. This is controlled by the Queue Service Engine. There are 32 queues for each of the three ports to support 32 classes of service, each with its programmable parameters such as minimum bandwidth, maximum bandwidth, and priority. Queue depth is constantly monitored to provide congestion notification (EFCN) status. The Queue Service Engine also implements a discard mechanism for the cells tagged with Cell Loss Priority.

The destination of each cell is contained in the Virtual Path Identifier/Virtual Circuit Identifier (VPI/VCI) field of the cell header. This is translated to a Logical Connection Number via table lookup in the Network Address Table. Both terminating and through connections can coexist on a port.

A Serial Interface Module (SIM) provides cell interface to the StrataBus backplane. This operates at 800 Mbps. It provides a serial-to-parallel conversion of the data and loopback and pseudo-random bit generation for test purposes.

Both BNI-T3 and BNI-E3 cards support two clock modes that are selected by the system operator through software control. Normal clocking uses receive clock from the network or user device for incoming data and supplies transmit clock for outgoing data. The clock obtained can be used to synchronize the node if desired. Loop timing uses receive clock from the network for the incoming data and turns that same clock around for timing the transmit data to the network or connecting CSU.

Bandwidth Control

The transmit bandwidth can be throttled down for certain applications. For example, when interfacing with an IPX switch E3 ATM Trunk Card, the trunk transmit rate is limited to 40,000 cells/second. If a T2 trunk adapter is used, the trunk transmit rate is limited to 14,000 cells/second.

Loopbacks and Diagnostics

There are two types of self-tests that may be performed. A non-disruptive self test is automatically performed on a routine basis. A more complete, disruptive test may be initiated manually when a card failure is suspected. If the card self-test detects a failure, the card status LEDs displays an indication of the failure type.

Several loopback paths are provided. A digital card loopback path, used by the node for self-test, loops the data at the serial DS3 or E3 interface back towards the node. A digital line loopback loops the data at the electrical transmitter/receiver at the card output. Internally, the PLPP circuit in the BNI-T3 has several loopbacks for use by diagnostic routines.

There are several loopback paths within the BNI for testing. A digital loopback at the DS3 or E3 transmitter/receiver to check both the transmit and receive signal paths in the near-end BNI card. These loopbacks loop the signal in both directions, towards the StrataBus as well as towards the output. Therefore, they can be used to support both near end and far end maintenance loopback testing. On the BNI-3T3, there is a digital loopback capability to the PLPP processor used for the internal self test to basically check the operation of the signal processor.

Once a trunk has been assigned to a BNI card but before it is made active (upped), it is put in a loopback mode and a diagnostic test is continuously performed. This loopback is disruptive so it cannot be performed on a card that has an active trunk. This diagnostic test checks the data path through the BNI out to the BCC, through the switch matrix, and back to the BNI. Active trunks are constantly checked by the Communications Fail test routine which is part of system software.


Front Panel Indicators

The lower section of the BNI front panel (see Figure 4-3) has a three-section, multicolored LED to indicate the card status. The card status LED is color-coded as indicated in Table 4-1. At the upper portion of the front panel, there is a three-section multicolored LED to indicate the status of the three ports on the BNI. Types of failures are indicated by various combinations of the card status indicators as indicated in Table 4-2.

Table 4-1 BNI Front Panel Status Indicators

Status	LED color	Status Description
Port	off	Trunk is inactive and not carrying data.
	green	Trunk is actively carrying data.
	yellow	Trunk is in remote alarm.
	red	Trunk is in local alarm.
Card	green (act)	Card is on-line and one or more trunks on the card have been upped. If off, card may be operational but is not carrying traffic.
	yellow (stby)	Card is off-line and in standby mode (for redundant card pairs). May not have any upped trunks. If blinking, indicates card firmware or configuration data is being updated.
	red (fail)	Card failure; card has failed self-test and/or is in a reset mode.

Figure 4-3 BNI-3T3 Front Panel (BNI-3E3 appears the same except for name)



H8028

Table 4-2 BNI Front Panel Card Failure Indications

act	stby	fail	Failure Description
on	off	on	Non-fatal error detected; card is still active.
off	on	on	Non-fatal error detected; card is in standby mode.
off	blinking	on	Fatal error detected; card is in a reboot mode.
on	on	on	Card failed boot load and operation is halted.

T3 and E3 Line Modules (LM-3T3 and LM-3E3)

The Line Modules for the BNI-T3 and BNI-E3 front cards are back cards used to provide a physical interface to the transmission facility. The LM-3T3 is used with the BNI-T3 and the LM-3E3 with the BNI-3E3. The Line Module connects to the BNI through the StrataBus midplane. Two adjacent cards of the same type can be made redundant by using a Y-cable at the port connectors. All three ports on a card must be configured the same.

Refer to Figure 4-4, Figure 4-5, and Table 4-3 which describe the faceplate connectors of the LM-3T3 and LM-3E3. There are no controls or indicators.

The LM-3T3 provides the following features:

- BNC connectors for 75-ohm unbalanced signal connections to the transmit and receive of each of the three ports.
- Transformer isolation from the trunk lines.
- Metallic relays for line loopback when in standby mode.

A final node loopback is found at the end of the LM-3T3 or LM-3E3 card. This is a metallic loopback path that uses a relay contact closure. It is a near-end loopback path only; the signal is looped at the final output stage back to circuits in the node receive side. It is only operated when the corresponding front card is in standby.

Table 4-3 LM-3T3 and LM-3E3 Connectors

No	Connector	Function
1	PORT 1 RX - TX	BNC connectors for the transmit and receive T3/E3 signal to/from ATM trunk 1.
2	PORT 2 RX - TX	BNC connectors for the transmit and receive T3/E3 signal to/from ATM trunk 2.
3	PORT 3 RX - TX	BNC connectors for the transmit and receive T3/E3 signal to/from ATM trunk 3.

Figure 4-4 LM-3T3 Face Plate, Typical





Figure 4-5 LM-3E3 Face Plate, Typica



Broadband Network Interface Cards, BNI-155

The BNI-155 interfaces the BPX switch with ATM OC3/STM-1 broadband trunks. The ATM trunk may connect to either another BPX switch or customer CPE equipped with an ATM OC3/STM-1 interface.

There are three BNI-155 back cards, the LM-2OC3-SMF for single-mode fiber intermediate range, the LM-2OC3-SMFLR for single-mode fiber long range, and the LM-2OC3-MMF for multi-mode fiber. Any of the 12 general purpose slots can be used to hold these cards. These backcards may also be used with the ASI-155.

Features

A summary of features for the BNI-155 cards include:

- LM-OC3-SMF and LM-OC3-MMF cards provide two ports, each operating at 155.52 Mbps.
- Up to 353,208 cells per second.
- Up to 12 class-based queues for each port.
- 8 K cell ingress (receive) VBR buffer.
- 32 K cell egress (transmit) buffers.
- 800 Mbps backplane speed.
- Two-stage priority scheme for serving cells.
- Accumulates trunk statistics for OC3/STM-1.
- Optional 1:1 card redundancy using Y-cable configuration for BNI-155.

Overview

Egress

In the transmit direction (from the BPX switching matrix towards the transmission facility, referred to as egress), the BNI performs the following functions (see Figure 4-6):

- Receives incoming cells from the switch matrix on the BCC.
- Serves the cells based on the class-of-service algorithm.
- Sets congestion indication (EFCN) in cell header when necessary.

Ingress

In the receive direction (from the transmission facility towards the BPX switching matrix, referred to as ingress), the BNI performs the following functions (see Figure 4-6):

- Receives incoming ATM cells from the OC3 transmission facility, stripping the framing and overhead from the received bit stream.
- Determines the address of the incoming cells by scanning the Virtual Path Identifier/Virtual Circuit Identifier (VPI/VCI) in the cell header.

Functional Description

In the egress direction, the BNI-155 has 2 Queue Service Engine (QSEs) which provide each of the ports with 12 programmable queues with selectable parameters such as minimum bandwidth, priority, and maximum bandwidth. The BNI queues are based on a class of service algorithm. The BNI supports the following trunk queues:

- Voice
- Non-Time Stamped
- Time Stamped
- Bursty Data A
- Bursty Data B
- High Priority (Network Management Traffic)
- CBR
- VBR

In the ingress direction, the BNI-155 has 2 Cell Input Engines (CIEs) that convert the incoming cell headers to the appropriate connection ID based on input from a Network Address Table.

The Serial Interface Unit (SIU) provides the BNI with an 800 Mbps cell interface to the StrataBus. It provides serial-to-parallel conversion of data, along with loopback and test signal generation capabilities.


The Line Interface Unit (LIU) performs the following ingress functions:

- Provides framing detection and synchronization.
- Provides the ability to extract timing from the incoming signal, and use it as a receive clock for incoming data, while providing transmit clock in the other direction. Alternatively, loop timing can be used to turn the receive clock back around to be used as a transmit clock. The receive clock may also be used to synchronize the node.
- Detects alarms, frame errors, and parity errors.
- Detects far end errors, including framing errors, and yellow alarm indications.
- Provides optional cell descrambling, header error check (HEC), and idle cell filtering.
- Provides a small FIFO buffer for incoming cells.
- Provides optical to electrical conversion.

The Line Interface Unit (LIU) performs the following egress functions:

- Inserts the appropriate framing into the outgoing bit stream.
- Inserts any alarm codes for transmission to the far end.
- Provides optional cell scrambling, HEC generation, and idle cell insertion.
- Provides a small FIFO buffer outing cells.
- Provides electrical to optical conversion.

Figure 4-6 Simplified BNI-155 Block Diagram



Front Panel Indicators

The BNI-155 front panel (see Figure 4-7) has a three-section, multicolored “card” LED to indicate the card status. The card status LED is color-coded as indicated in Table 4-4. A three-section multicolored “port” LED indicates the status of the two ports on the BNI-155. Types of failures are indicated by various combinations of the card status indicators as indicated in Table 4-5.


Table 4-4 BNI-155 Front Panel Status Indicators

Status	LED color	Status Description
port	off	Trunk is inactive and not carrying data.
	green	Trunk is actively carrying data.
	yellow	Trunk is in remote alarm.
	red	Trunk is in local alarm.
card	green (act)	Card is on-line and one or more trunks on the card have been upped. If off, card may be operational but is not carrying traffic.
	yellow (stby)	Card is off-line and in standby mode (for redundant card pairs). May not have any upped trunks. If blinking, indicates card firmware or configuration data is being updated.
	red (fail)	Card failure; card has failed self-test and/or is in a reset mode.

Table 4-5 BNI Front Panel Card Failure Indications

act	stby	fail	Failure Description
on	off	on	Non-fatal error detected; card is still active.
off	on	on	Non-fatal error detected; card is in standby mode.
off	blinking	on	Fatal error detected; card is in a reboot mode.
on	on	on	Card failed boot load and operation is halted.

Figure 4-7 BNI-155 Front Panel



H8032

OC3, Line Modules (SMF, SMFLR, & MMF)

The Line Modules for the OC3 BNI cards are back cards used to provide a physical interface to the transmission facility. There are three types, a single-mode fiber intermediate range, single-mode fiber long range, and a multi-mode fiber backcard. The Line Modules connect to the BNI through the StrataBus midplane.

For connector information, refer to Figure 4-8 and Table 4-6 for the LM-OC3-SMF and to Figure 4-9 and Table 4-7 for the LM-OC3-MMF. The LM-OC3-SMFLR uses the same type of connectors as the LM-OC3-SMF.

Table 4-6 LM-OC3-SMF and LM-OC3-SMFLR Connectors

No	Connector	Function
1	PORT	FC-PC connectors for the transmit and receive OC3 signal to/from ATM trunk 1.
2	PORT	FC-PC connectors for the transmit and receive OC3 signal to/from ATM trunk 2.

Table 4-7 LM-OC3-MMF Connectors

No	Connector	Function
1	PORT	Duplex SC connectors for the transmit and receive OC3 signal to/from ATM trunk 1.
2	PORT	Duplex SC connectors for the transmit and receive OC3 signal to/from ATM trunk 2.

Figure 4-8 LM-2OC3-SMF Face Plate






Figure 4-9 LM-2OC3-MMF Face Plate



Y-Cabling of BNI Backcard, SMF-2-BC

The LM-OC3-SMF (Model SMF-2-BC) backcards may be Y-cabled for redundancy using the Y-Cable splitter shown in Figure 4-10. The cards must be configured for Y-Cable redundancy using the **addyred** command.

Figure 4-10 Y-Cable (Model SMFY), LC-OC3-SMF (Model SMF-2-BC)



H8009

Service Interface (Line) Cards

This chapter contains a description of the BPX switch service interface (line) cards, including the ATM Service Interface (ASI) and associated backcards. The BXM cards are briefly described in this chapter and covered in full in a later chapter.

This chapter contains the following:

- BPX Switch Service Interface Group Summary
- BXM Cards, Port (UNI) Mode
- ASI-1, ATM Service Interface Card
- LM-2T3 Module
- LM-2E3 Module
- ASI-155, ATM Service Interface Card
- ASI-155 Line Module, LM-2OC3-SMF
- ASI-155 Line Module, LM-2OC3-SMFLR
- ASI-155 Line Module, 2OC3-MMF
- Y-Cabling of ASI Backcard, SMF-2-BC
- BXM Cards, Access (UNI) Mode

BPX Switch Service Interface Group Summary

The BPX switch service interface group of cards provides an ATM interface between the BPX switch and CPE (see Figure 5-1). The ASI series of cards (DS3, E3, and OC3) are described in this chapter. The BXM card service operation is briefly described in this chapter with additional information provided in a later chapter. The BXM cards may be configured for either trunk or port (service access UNI) mode. In service (port UNI) mode they provide ATM service interfaces to CPE.


BXM Cards, Port (UNI) Mode Summary

The BXM card sets supports OC-12/STM-4 or OC-3/STM-1 interfaces, and provide the capacity to meet the needs of emerging bandwidth driven applications. The BXM provides high speed ATM connectivity, flexibility, and scalability. The card sets are comprised of a front card that provides the processing, management, and switching of ATM traffic and of a back card that provides the physical interface for the card set.

A BXM port may be configured to operate as either a trunk or UNI port. The BXM OC-12 back cards support Single Mode Fiber (SMF), Single Mode Fiber Long Reach (SMFLR), or Single Mode Fiber Extra Long Range (SMFXLR). The BXM OC-3 back cards support either Multi-Mode Fiber (MMF), Single Mode Fiber (SMF), or Single Mode Fiber Long Reach (SMFLR).

For a further description of the BXM cards refer to Chapter 6, BXM T3/E3, 155, and 622.

Figure 5-1 BPX Switch Service Interface Group



ASI-1, ATM Service Interface Card

The ATM Service Interface Card for T3 and E3 interfaces (ASI-1) is a front card for use in the BPX switch to interface an ATM user device e.g., Customer Premise Equipment (CPE). The ASI provides an industry-standard ATM User-to-Network Interface (UNI) or ATM Network-to-Network Interface (NNI) to the BPX switching fabric.

Features


A summary of features for the ASI card include:

- Two 45 Mb T3 ATM UNI/NNI ports per card for connection of user devices.
- Allows connections between UNI ports on a single node, between nodes, and NNI connections between networks.
- Maximum of 1000 connections per card.
- Aggregate transport rate of 96,000 cps per port (T3) or 80,000 cps (E3).
- VCC and/or VPC addressing.
- Ingress to ASI, each PVC is assigned a separate input queue.
- Egress from ASI, sixteen fixed queues per line, including CBR, VBR, and ABR queues.
- Optional 1:1 card redundancy using Y-cable configuration.

Functional Description

Each ASI-1 card provides two ATM UNI/NNI ports, each operating at DS3 rates or E3 rates (see Figure 5-2). Any of the 12 general purpose slots can be used to hold these cards. The ASI-1 operates with a corresponding T3 or E3 Line Module back card LM-2T3 or LM-2E3, respectively. Only the first two connectors on the back card are active; the lower port is not used.

Figure 5-2 ASI-1 Simplified Block Diagram



Each port provides an aggregate ATM connection bandwidth of 96,000 cells/second (T3) or 80,000 cells/sec (E3), or 353,208 cells/sec (OC3).

Connections are added using the **addcon** command.

Some of the functions performed by the PLPP in the ASI-1 include:

PLPP—Receiver Side

- Provides frame sync for the C-bit parity frame format.
- 1 Provides alarm detection and accumulates B3ZS code violations framing errors, parity errors, C-bit parity errors, and far end bit error (FEBE) events.
- Detects far end alarm channel codes, yellow alarm, and loss of frame.
- Provides optional cell descrambling, header check sequence (HCS) error detection, and cell filtering.
- Small receive FIFO buffer for incoming cells.

Connections are routed using the VPI and VCI address fields in the UNI header. The allowable range for VPI is from 0 to 255 (UNI) and 0 to 1023 (NNI), while VCI can range from 1 to 65535. A total of 1000 combinations of these can be used per ASI card at any one time.

A total of 1000 logical connections (ungrouped) may be configured for the node at any one time. On the BPX switch, 5000 grouped connections can be configured. The ASI-1 supports 1000 connections per card.

Two connection addressing modes are supported. The user may enter a unique VPI/VCI address in which case the BPX switch functions as a virtual circuit switch. Or the user may enter only a VPI address in which case all circuits are switched to the same destination port and the BPX switch functions as a virtual path switch in this case.

There are sixteen egress queues per line (port), including CBR, VBR, and ABR. When a connection is added, the user selects either constant bit rate (CBR), variable bit rate (VBR), or available bit rate (ABR, which uses ForeSight). The CBR queue has higher priority. Queue depth is specified when configuring a line. Maximum depth that can be specified for any one queue is 11,000 cells. Total queue depth cannot exceed 22,000 cells.

Configuring Connections (ATM over ASI Example)


Connections are routed between CPE connected to ASI ports (see Figure 5-3). Before adding connections, an ASI line is upped with the **upln** command and configured with the **cnfln** command. Then the associated port is configured with the **cnfport** command and upped with the **upport** command. Following this, the ATM connections are added via the **addcon** command with the syntax: `slot.port.vpi.vci`. The example shows a connection between alpha 4.1.1.1 and gamma 6.1.1.1.

The slot number is the ASI card slot on the BPX switch. The port number is one of two ports on the ASI, the VPI is the virtual path identifier, and the VCI is the virtual circuit identifier. (The top two ports on the LM-2T3 card are used, the bottom one is not.)

The VPI and VCI fields have significance only to the local BPX switch, and are translated by tables in the BPX switch to route the connection. Connections are automatically routed by the AutoRoute feature once the connection endpoints are specified.

Connections can be either Virtual Path Connections (VPC) or Virtual Circuit Connections (VCC). Virtual Path Connections are identified by an * in the VCI field. Virtual Circuit Connections specify both the VPI and VCI fields. Refer to the *Cisco WAN Switching Command Reference* for further information.

Figure 5-3 ATM Connection via ASI Ports



at alpha: addcon 4.1.1.1 gamma 6.1.1.1 [connection parameters...]

Monitoring Statistics

Port, line, and channel statistics are collected by the ASI-1. Refer to the *Cisco StrataView Plus Operations Guide* for a listing and description of these statistics.


Front Panel Description

The ASI front panel (see Figure 5-4) has a three-section, multicolored “card” LED to indicate the card status. The card status LED is color-coded as indicated in Table 5-1. A two-section multicolored “port” LED indicates the status of the two ports on the ASI. The port status LED display is color-coded as indicated in Table 5-1.

Table 5-1 ASI-1 Status Indicators

Status	LED color	Status Description
port	off	Line is inactive and not carrying data.
	green	Line is actively carrying data.
	yellow	Line is in remote alarm.
	red	Line is in local alarm.
card	green (act)	Card is on-line and one or more ports on the card have been upped. If off, card may be operational but is not carrying traffic.
	yellow (stby)	Card is off-line and in standby mode (for redundant card pairs). May not have any upped ports. If blinking, indicates card firmware or configuration data is being updated.
	red (fail)	Reserved for card failure.

Figure 5-4 ASI-1 Front Panel




LM-2T3 Module

The T3 Line Module for the ASI-1 Front Card is a backcard used to provide a physical interface to the service interface (see Figure 5-5). The Line Module connects to the ASI-1 through the StrataBus midplane. Two adjacent cards of the same type can be made redundant by using a Y-cable at the port connectors.

Except for using two ports instead of three, the LM-2T3 back card operates similarly to the BNI back cards, described previously.

Figure 5-5 Line Module, ASI, 2T3




LM-2E3 Module

The E3 Line Module for the ASI-1 Front Card is a backcard used to provide a physical interface to the service interface (see Figure 5-6). The Line Module connects to the ASI-1 through the StrataBus midplane. Two adjacent cards of the same type can be made redundant by using a Y-cable at the port connectors.

Except for using two ports instead of three, the LM-2E3 back card operates similarly to the BNI back cards, described previously.

Figure 5-6 Line Module, ASI, 2E3



ASI-155, ATM Service Interface Card

The ATM Service Interface Card for OC3/STM-1, the ASI-155, is a BPX switch front card used to interface with an ATM user device e.g., CPE. The ASI provides an industry-standard ATM User-to-Network Interface (UNI) or ATM Network-to-Network Interface (NNI) over OC3 lines to the BPX switching fabric.

There are three ASI-155 back cards, the LM-2OC3-SMF for single-mode fiber intermediate range, the LM-2OC3-SMFLR for single-mode fiber long range, and the LM-2OC3-MMF for multi-mode fiber. Any of the 12 general purpose slots can be used to hold these cards. These backcards may also be used with the BNI-155

Features

A summary of features for the ASI-155 card include:

- Virtual Path (VP) as well as Virtual Circuit (VC) connections.
- Support for 1000 connections per port for each of the two ports on the ASI-155 card.
- Two port OC3 SONET/SDH ATM with each port operating at a 155.52 Mbps rate (353,208 cells per second).
- Allows connections between UNI ports on a single node, between nodes, and NNI connections between networks.
- Usage Parameter Control using leaky bucket algorithm to control admission to the network.
- Selective Cell Discard.
- 8 K cell ingress (receive) VBR buffer.
- 32 K cell egress (transmit) buffers.
- 2 connection types: CBR and VBR.
- ATM cell structure and format per ATM Forum UNI v3.1.
- End-to-end OAM flows and end-to-end loopback per ATM Forum UNI v3.1.
- External segment flows consisting of segment loopback cells per ATM Forum UNI v3.1.
- Egress from ASI, twelve fixed queues per line, including CBR and VBR queues.
- Optional 1:1 card redundancy using Y-cable configuration.

Overview

Connections are routed using the VPI and VCI address fields in the UNI header. The allowable range for VPI is from 0 to 255 (UNI) and 0 to 1023 (NNI), while VCI can range from 1 to 65535. A total of 1000 combinations of these can be used per ASI card at any one time. Future releases will support the full ATM address range.

There are two connection addressing modes supported. The user may enter a unique VPI/VCI address in which case the BPX switch functions as a virtual circuit switch. Or the user may enter only a VPI address in which case all circuits are switched to the same destination port and the BPX switch functions as a virtual path switch in this case.

There are 12 egress queues per line (port), two of which are used. These are for CBR and VBR. When a connection is added, the user selects either a constant bit rate (CBR) or variable bit rate (VBR) connection class.

Configuring Connections

Connections are routed between CPE connected to ASI ports. Before adding connections, an ASI line is upped with the **upln** command and configured with the **cnfln** command. Then the associated port is configured with the **cnfport** command and upped with the **upport** command. Following this, the ATM connections are added via the **addcon** command with the syntax: slot.port.vpi.vci.

The slot number is the ASI card slot on the BPX switch. The port number is one of two ports on the ASI, the VPI is the virtual path identifier, and the VCI is the virtual circuit identifier.

The VPI and VCI fields have significance only to the local BPX switch and are translated by tables in the BPX switch to route the connection. Connections are automatically routed by the AutoRoute feature once the connection endpoints are specified.

Connections can be either Virtual Path Connections (VPC) or Virtual Circuit Connections (VCC). Virtual Path Connections are identified by an * in the VCI field. Virtual Circuit Connections specify both the VPI and VCI fields.

ATM to Frame Relay Network and Service Interworking connections to the ASI are also supported. In the case of Network Interworking, the user CPE must be aware of the interworking function and provide the appropriate protocol mapping.

Refer to the *Cisco WAN Switching Command Reference* for further information.

Functional Description

For ingress traffic, the ATM Layer Interface (ALI) provides traffic management and admission controls (UPC) for the ASI-155 (see Figure 5-7). The ASI-155 supports CBR and VBR connections and employs a single leaky bucket GCRA mechanism for policing cell streams seeking entrance to the network. Each PVC (VPC.VCC) is policed separately, providing firewalling between connections, and assuring that each connection uses only a fair share of network bandwidth. The ALI also performs ingress OAM functions.

The single leaky bucket policing function is implemented using a GCRA (Generic Rate Algorithm) defined by two parameters:

- Rate (where I, expected arrival interval is defined as 1/Rate)
- Deviation (L)

In the ingress direction, the ASI-155 has 2 Cell Input Engines (CIEs) that convert the incoming cell headers to the appropriate connection ID based on input from a Network Address Table.

For egress traffic, the Supervisory Cell Filter (SCF) provides routing and direction of non-data cells, such as test cells and OAM cells.

The Serial Interface Unit (SIU) provides the ASI with an 800 Mbps cell interface to the StrataBus. It provides serial-to-parallel conversion of data, along with loopback and test signal generation capabilities.

The Line Interface Unit (LIU) performs the following ingress functions:


- Provides framing detection and synchronization.
- Provides the ability to extract timing from the incoming signal, and use it as a receive clock for incoming data, while providing transmit clock in the other direction. Alternatively, loop timing can be used to turn the receive clock back around to be used as a transmit clock. The receive clock may also be used to synchronize the node.
- Detects alarms, frame errors, and parity errors.
- Detects far end errors, including framing errors, and yellow alarm indications.

- Provides optional cell descrambling, header error check (HEC), and idle cell filtering.
- Provides a small FIFO buffer for incoming cells.
- Provides optical to electrical conversion.

The Line Interface Unit (LIU) performs the following egress functions:

- Inserts the appropriate framing into the outgoing bit stream.
- Inserts any alarm codes for transmission to the far end.
- Provides optional cell scrambling, HEC generation, and idle cell insertion.
- Provides a small FIFO buffer outgoing cells.
- Provides electrical to optical conversion.

Figure 5-7 ASI-155 Simplified Block Diagram



Monitoring Statistics

Port, line, and channel statistics are collected by the ASI-155. The StrataView Plus workstation is used to collect and monitor these statistics. For additional information regarding ASI-155 statistics refer to the *Cisco StrataView Plus Operations Guide*.


Front Panel Indicators

The ASI-155 front panel (see Figure 5-8) has a three-section, multicolored “card” LED to indicate the card status. The card status LED is color-coded as indicated in Table 5-2. A two-section multicolored “port” LED indicates the status of the two ports on the ASI-155. The port status LED display is color-coded as indicated in Table 5-2.

Table 5-2 ASI-155 Status Indicators

Status	LED color	Status Description
port	off	Line is inactive and not carrying data.
	green	Line is actively carrying data.
	yellow	Line is in remote alarm.
	red	Line is in local alarm.
card	green (act)	Card is on-line and one or more ports on the card have been upped. If off, card may be operational but is not carrying traffic.
	yellow (stby)	Card is off-line and in standby mode (for redundant card pairs). May not have any upped ports. If blinking, indicates card firmware or configuration data is being updated.
	red (fail)	Reserved for card failure.

Figure 5-8 ASI-155 Front Panel



ASI-155 Line Module, LM-2OC3-SMF

The LM- 2OC3 -SMF (Model SMF-2-BC) line module for the ASI-155 Front Card is a backcard that provides a SMF intermediate range service interface. The line module connects to the ASI-155 through the StrataBus midplane. Two adjacent cards of the same type can be made redundant by using a Y-cable at the port connectors. This is the same LM-2OC3-SMF backcard (Figure 4-8) that is used for the BNI-155.

ASI-155 Line Module, LM-2OC3-SMFLR

The LM- 2OC3 -SMFLR (Model SMFLR-2-BC) line module for the ASI-155 Front Card is a backcard that provides a SMF long range service interface. The line module connects to the ASI-155 through the StrataBus midplane. This is the same LM-2OC3-SMFLR backcard that is used for the BNI-155.

ASI-155 Line Module, LM-2OC3-MMF

The LM-2OC3 -MMF (Model MMF-2-BC) line module for the ASI-155 Front Card is a backcard that provides a MMF service interface (Figure 4-9). The line module connects to the ASI-155 through the StrataBus midplane. This is the same LM-2OC3-SMF backcard that is used for the BNI-155.

Y-Cabling of ASI Backcard, SMF-2-BC

The LM-OC3-SMF (Model SMF-2-BC) backcards may be Y-cabled for redundancy using the Y-Cable splitter (Model SMFY) as shown in Figure 4-10. The cards must be configured for Y-Cable redundancy using the **addyred** command

BXM Cards, Access (UNI) Mode

The BXM card sets support OC-12c/STM-4 or OC-3C/STM-1 interfaces, and provide the capacity to meet the needs of emerging bandwidth driven applications. The BXM provides high speed ATM connectivity, flexibility, and scalability. The card sets are comprised of a front card that provides the processing, management, and switching of ATM traffic and of a back card that provides the physical interface for the card set.

A BXM port may be configured to operate as either a trunk or UNI port. The BXM OC-12 back cards support either Single Mode Fiber (SMF) or Single Mode Fiber Long Reach (SMFLR). The BXM OC-3 back cards support either Multi-Mode Fiber (MMF), Single Mode Fiber (SMF), or Single Mode Fiber Long Reach (SMFLR).

For a further description of the BXM cards refer to, Chapter 6, BXM T3/E3, 155, and 622.

BXM T3/E3, 155, and 622

This chapter describes the BXM card sets which include the BXM T3/E3, BXM-155, and BXM-622. The BXM cards may be configured for either trunk or service (port UNI) mode. In trunk mode they provide BPX network interfaces and in service (port UNI) mode they provide service access to CPE.

The chapter includes the following:

- Tag Switching
- Dynamic Resource Partitioning for SPVCs
- BXM Cards
- BXM Capabilities
- Card Operation
- BXM Functional Description
- Fault Management and Statistics
- Technical Specifications
- General SONET Notes
- User Commands
- Configuring Connections
- Command Line Interface Examples
- Configuring the BPX Switch for SVCs
- Configuring the MGX 8220
- Resource Partitioning

Tag Switching

Starting with switch software release 9.1, the BXM also supports tag switching. Partitions for the BXM can be allocated either between:

- SVCs and PVCs, or
- Tag switching virtual circuits (TVCs) and PVCs.

For information on Tag Switching, refer to *Chapter 9, Tag Switching*.

Dynamic Resource Partitioning for SPVCs

Also, for switch software Release 9.1, the BXM card supports dynamic resource partitioning to support the conversion of PVCs to soft permanent virtual circuits (SPVCs). This feature is described in the:

Cisco WAN Service Node Extended Services Processor Installation and Operations for Release 2.2 document.


BXM Cards

A BXM card set, using Application Specific Integrated Circuit (ASIC) technology, provides high speed ATM connectivity, flexibility, and scalability. The card set is comprised of a front card that provides the processing, management, and switching of ATM traffic and of a back card that provides the physical interface for the card set. An example of a BPX switch network provisioned with BXM-622 cards is shown in Figure 6-1.

The BXM card group includes the BXM-T3/E3, BXM-155, and BXM-622. These cards may be configured to support either trunk (network) or port (service access) interfaces. The BXM T3/E3 is available in 8 or 12 port versions with T3/E3 interfaces. The BXM-155 is available in 4 or 8 port versions with OC3/STM-1 interfaces. The BXM-622 is available in 1 or 2 port versions with OC-12/STM-4 interfaces. The BXM card sets are compliant with ATM UNI 3.1 and Traffic Management 4.0 including ABR VS/VD and provide the capacity to meet the needs of emerging bandwidth driven applications.

For additional information on ATM Connections, refer to *Chapter 7, ATM Connections*.

Figure 6-1 A BPX Switch Network with BXM Cards



The BXM cards are designed to support all the following service classes: Constant Bit Rate (CBR), Variable Bit Rate (VBR), Available Bit Rate (ABR with VS/VD, ABR without VS/VD, and ABR using Foresight), and Unspecified Bit Rate (UBR). ABR with VS/VD supports explicit rate marking and Congestion Indication (CI) control.

All software and administration firmware for the BXM card is downloadable from the BCC and is operated by the BXM on-board sub-system processor.

A BXM card set consists of a front and back card. The BXM T3/E3 is available with a universal BPX-T3/E3 backcard in 8 or 12 port versions. The BXM-OC3 is available with 4 or 8 port multi-mode fiber (MMF), single mode fiber (SMF), or single mode fiber long reach (SMFLR) back cards. The BXM-OC12 is available with 1 or 2 port SMF or SMFLR back cards,

Any of the 12 general purpose slots can be used for the BXM cards. The same backcards are used whether the BXM ports are configured as trunks or lines. Table 6-1 and Table 6-2 list the available front and back card options for the BXM-T3/E3, BXM-155, and BXM-622.

Table 6-1 BXM T3/E3, BXM-155, and BXM 622 Front Card Options

Front Card Model Number	No. of Ports	Cell Buffer (ingress/egress)	Connections per card	Back Cards
T3/E3 (45 Mbps/34Mbps)				
BXM-T3-8	8	100k/130k	16k/32k	BPX-T3/E3-BC
BXM-E3-8	8	100k/130k	16k/32k	BPX-T3/E3-BC
BXM-T3-12	12	100k/230k	16k/32k	BPX-T3/E3-BC
BXM-E3-12	12	100k/230k	16k/32k	BPX-T3/E3-BC
OC3/STM-1 (155.52 Mbps)				
BXM-155-8	8	230k/230k	16k	MMF-155-8 SMF-155-8 SMFLR-155-8
BXM-155-4	4	100k/230k	16K	MMF-155-4 SMF-155-4 SMFLR-155-4
OC12/STM-4 (622.08 Mbps)				
BXM-622-2	2	230k/230k	16K	SMF-622-2 SMFLR-622-2 SMFXLR-622-2
BXM-622	1	130k/230k	16K/32K	SMF-622 SMFLR-622 SMFXLR-622

*The BXM cards can be configured for either, but not both, trunk or service access (UNI) on a card by card basis. Once a card is so configured, all ports are either trunk or service interfaces until the card is reconfigured.

**The BPX-T3/E3-BC universal backcard supports 8 or 12 ports.

Table 6-2 BXM-T3/E3, BXM-155, and BXM-622 Back Cards

Back Card Model Number	No. of Ports	Description	Optical Range (less than or equal to)
T3/E3 (45 Mbps/34 Mbps)			
BPX-T3/E3-BC	8/12	Universal T3/E3 backcard for 8 or 12 port card configurations	n/a
OC3/STM-1 (155.520 Mbps)			
MMF-155-8	8	Multi-Mode Fiber	2km
MMF-155-4	4	Multi-Mode Fiber	2km
SMF-155-8	8	Single-Mode Fiber	20km
SMF-155-4	4	Single-Mode Fiber	20km
SMFLR-155-8	8	Single-Mode Fiber Long Reach	40km
SMFLR-155-4	4	Single-Mode Fiber Long Reach	40km
OC12/STM-4 (622.08 Mbps)			
SMF-622-2	2	Single-Mode Fiber	20km
SMF-622	1	Single-Mode Fiber	20km
SMFLR-622-2	2	Single-Mode Fiber Long Range	40km
SMFLR-622	1	Single-Mode Fiber Long Range	40km

BXM Capabilities

The following lists some of the major capabilities of the BXM cards:

Features

- Virtual Path (VP) as well as Virtual Circuit (VC) connections.
- Support both PVC and SVC connections.
- Connections supported per card:
 - 16,000 to 32,000 connections per card depending on configuration.
- BXM, T3/E3 ATM with 8 or 12 ports, either T3 at a 44.736 Mbps rate, or E3 at a 34.368 rate.
- BXM, OC-3/STM-1 ATM: four or eight ports, with each port operating at a 155.52 Mbps rate, 353,208 cells per second (full OC-3 rate).
- BXM, OC-12/STM-4 ATM: one or two ports, with each port operating at a 622.08 Mbps rate, 1,412,830 cells per second (full OC-12 rate).
- Selective Cell Discard.
- Up to 228,300 cell ingress (receive) buffers depending on card configuration.
- Up to 228,300 cell egress (transmit) buffers depending on card configuration.
- CBR, VBR, ABR, and UBR service classes.

- ATM cell structure and format per ATM Forum UNI v3.1.
- Loopback support.
- 1:1 card redundancy using Y-cable configuration.
- A BXM card may be configured for either network or port (access) operation.

ATM Layer

- UNI port option conforming to ATM Forum UNI v3.1 specification.
- ATM cell structure and format supported per ATM UNI v3.1 and ITU I.361.
- Header Error Correction (HEC) field calculation and processing supported per ITU I.432.
- Usage Parameter Control using single and dual leaky bucket algorithm, as applicable, to control admission to the network per ATM Forum 4.0 Traffic Management.
- Provides up to 16 CoS's with the following configurable parameters:
 - Minimum service rate.
 - Maximum queue depth.
 - Frame discard enable.
 - Cell Loss Priority (CLP) High and Low thresholds.
 - Service priority level.
 - Explicit Forward Congestion Indication (EFCI) threshold.
- Per VC Queuing.
- Support for UBR CoS with Early Packet Discard.
- Failure alarm monitoring per T1.64b.
- ATM layer OAM functionality.
- Congestion control mechanisms:
 - ABR with Virtual Source Virtual Destination (VSVD).
 - ABR with Explicit Rate (ER) stamping/EFCI tagging.
 - ABR with ForeSight.
- Self-test and diagnostic facility.

Service Types

The BXM cards support the full range of ATM service types per ATM Forum TM 4.0.

CBR Service:

- Usage Parameter Control (UPC) and Admission Control.
- UPC: Ingress rate monitoring and discarding per I.371 for:
 - Peak Cell Rate (PCR).
 - Cell Transfer Delay Variation (CTDV).

VBR Service:

- Usage Parameter Control (UPC) and Admission Control.
- UPC: Ingress rate monitoring and cell tagging per ITU-T I.371 for:
 - Sustained Cell Rate (SCR).
 - Peak Cell Rate (PCR).
 - Burst Tolerance (BT).
- CLP tagging, enabled or disabled on a per VC basis at the Ingress side.

ABR Service:

- Based on Virtual Source Virtual Destination (VSVD) per ATM Forum TM4.0.
- VSVD.
 - VSVDs provide Resource Management (RM) cell generation and termination to support congestion control loops.
 - A virtual connection queue (VCQ) is assigned to a VC in the ingress direction.
 - VCQ configurable parameters:
 - CLP Hi and Lo thresholds.
 - Maximum queue depth.
 - Reserved queue depth.
 - Congestion threshold.
- ABR congestion control.
 - Based on Explicit rate stamping/EFCI cell tagging and ingress rate monitoring per ITU-T I.371.
 - ABR with Virtual Source Virtual Destination (VSVD).
 - ABR with Explicit Rate (ER) stamping/EFCI tagging.
 - ABR with ForeSight.

UBR Service:

- Based on UPC and admission control including EPD.
- Based on Explicit Rate Marking/EFCI cell tagging and ingress rate monitoring per ITU-T I.371.

Virtual Interfaces

- VPI/VCI used to identify virtual connection.
- Support for up to 32 virtual interfaces per card, each with 16 CoS queues.
- Virtual Interface parameters:
 - Physical port (trunk or access).
 - Peak Service Rate (PSR).
 - Minimum Service Rate (MSR).
 - Maximum resource allocation.

Card Operation

BXM Front Card Indicators

The BXM front panel has a three-section, multi-colored “card” LED to indicate the card status. A two-port BXM-622, an 8-port BXM-155 front card, and a 12-port BXM-T3/E3 are shown in Figure 6-2, Figure 6-3, and Figure 6-4. The card status LED is color-coded as indicated in Table 6-3. A three-section multi-colored “port” LED indicates the status of the ports. Types of failures are indicated by various combinations of the card status indicators as indicated in Table 6-4.

Table 6-3 BXM Front Panel Status Indicators

Status	LED color	Status Description
port	off	Trunk/line is inactive and not carrying data.
	green	Trunk/line is actively carrying data.
	yellow	Trunk/line is in remote alarm.
	red	Trunk/line is in local alarm.
card	green (act)	Card is on-line and one or more trunks/lines on the card have been upped. If off, card may be operational but is not carrying traffic.
	yellow (stby)	Card is off-line and in standby mode (for redundant card pairs). May not have any upped trunks/lines. If blinking, indicates card firmware or configuration data is being updated.
	red (fail)	Card failure; card has failed self-test and/or is in a reset mode.

Table 6-4 BXM Front Panel Card Failure indicators

act	stby	fail	Failure Description
on	off	on	Non-fatal error detected; card is still active.
off	on	on	Non-fatal error detected; card is in standby mode.
off	blinking	on	Fatal error detected; card is in a reboot mode.
on	on	on	Card failed boot load and operation is halted.

Figure 6-2 BXM-622 Front Panel, Two-Port Card Shown






Figure 6-3 BXM-155 Front Panel, Eight-Port Card Shown



H9876

Figure 6-4 BXM-T3/E3 Front Panel, 12-Port Card Shown



H9885

BXM, Backcard Connectors

The BXM backcards connect to the BXM front cards through the StrataBus midplane.

The BXM-622 is available in one or two port versions in either a single-mode fiber intermediate range (SMF) or a single-mode fiber long range (SMFLR) backcard. Connector information is listed in Table 6-5 and a 2-port SMF card is shown in Figure 6-5.

Table 6-5 BXM-622 Backcards

No.	Connector	Function
1 or 2	PORT	Two FC connectors per port, one each for the transmit and receive signal.

The BXM-155 is available in four or eight port versions in a choice of multi-mode fiber (MMF), single-mode fiber intermediate range (SMF), or single-mode fiber long range (SMFLR) backcards. Connector information is listed in Table 6-6 and an 8-port SMF card is shown in Figure 6-6.

Table 6-6 BXM-155 Backcards


No.	Connector	Function
4 or 8	PORT	One SC connector per port, accommodates both the transmit and receive signals.

The BXM-T3/E3 is available in eight or twelve port versions. Connector information is listed in Table 6-7 and a 12-port T3/E3 card is shown in Figure 6-7.

Table 6-7 BXM-T3/E3 Backcards


No.	Connector	Function
8 or 12	PORT	Two SMB connectors per port, one each for the transmit and receive signals.

Figure 6-5 SMF-622-2, SMFLR-622-2, and SMFXLR-622-2 Back Card




H9891

Figure 6-6 BXM-155-8 Port Backcard, MMF, SMF, or SMFLR



H9875


Figure 6-7 BPX-T3/E3 Back Card, 12-Port Option Shown



Y-Cabling of SMF-622 Series Backcards

The SMF-622 series backcards may be Y-cabled for redundancy using the Y-Cable splitter shown in Figure 6-8. The cards must be configured for Y-Cable redundancy using the **addyred** command.

Figure 6-8 Y-Cabling of SMF-622 Series Backcards



HB009

BXM Functional Description

This functional description provides an overview of BXM operation.

Overview, Port (UNI) Mode

The following provides an overview of the operation of the BXM card when the ports are configured in port (access) mode for connection to customer equipment (CPE).


Ingress

The ingress flow of ATM cells into the BXM when the card is configured for port (access) operation is shown in Figure 6-9.

ATM cells from the CPE are processed at the physical interface level by the SUNI (OC3/OC12) or Mux/Demux (T3/E3), policed per individual VC by the RCMP and routed to applicable ingress queues. In addition, for ABR cells, additional functions are performed by the SABRE ABR connection controller, including: VS/VD, Foresight, and virtual connection queueing. The cells are served out via the BPX Backplane to the BPX crosspoint switch in an order of priority based on their connection type.

Figure 6-9 BXM Port (Access UNI) Ingress Operation

SABRE	Scheduling and ABR Engine	SUNI	SONET/SDH UNI ASIC
SIMBA	Serial I/F and Multicast Buffer ASIC	ACP	Sub-system Processor
RCMP	Routing Ctl, Monitoring, & Policing ASIC	ASIC	Application Specific Integrated Ckt
DRSIU	Dual Receiver Serial I/F Unit		



56167


Egress

The egress flow of ATM cells out of the BXM when the card is configured for port (access) operation is shown in Figure 6-10.

ATM cells are routed to the BXM-622 via the BPX Backplane/Stratabus from the BPX crosspoint switch, applied to the DRSIU, then to an egress queue per class of service, and then served out to the SUNI (OC3/OC12) or Mux/Demux (T3/E3) which processes the ATM cells into frames, processing the cells from the ATM layer to the physical and on out to the CPE connected to the port(s) on the BXM backcard. For ABR cells, additional functions are performed by the SABRE ABR connection controller, including: VS/VD, Foresight, and virtual connection queuing.

Figure 6-10 BXM Port (Access, UNI) Egress Operation

SABRE	Scheduling and ABR Engine	SUNI	SONET/SDH UNI ASIC
SIMBA	Serial I/F and Multicast Buffer ASIC	ACP	Sub-system Processor
RCMP	Routing Ctl, Monitoring, & Policing ASIC	ASIC	Application Specific Integrated Ckt
DRSIU	Dual Receiver Serial I/F Unit		



S6168

Overview, Trunk Mode

This provides an overview of the operation of the BXM when the card is configured in the trunk mode for connection to another node or network.


Ingress

The ingress flow of ATM cells into the BXM when the card is configured for trunk operation is shown in Figure 6-11.

ATM cells from a node or network are processed at the physical interface level by the SUNI (OC3/OC12) or Demux/Mux (T3/E3), routed to applicable ingress slot queues, and served out to the BPX crosspoint switch via the BPX Backplane.

Figure 6-11 BXM Trunk Ingress Operation

SABRE	Scheduling and ABR Engine	SUNI	SONET/SDH UNI ASIC
SIMBA	Serial I/F and Multicast Buffer ASIC	ACP	Sub-system Processor
RCMP	Routing Ctl, Monitoring, & Policing ASIC	ASIC	Application Specific Integrated Ckt
DRSIU	Dual Receiver Serial I/F Unit		



69195


Egress

The egress flow of ATM cells out of the BXM when the card is configured for trunk operation is shown in Figure 6-12.

ATM cells are routed to the BXM from the BPX crosspoint switch, applied to the DRSIU, then to an egress queue per class of service, and then served out to the SUNI (OC3/OC12) or Demux/Mux (T3/E3). The SUNI or Demux/Mux, as applicable, processes the ATM cells into frames, processing the cells from the ATM layer to the physical and on out to the backcard trunk interface connecting to another node or network.

Figure 6-12 BXM Trunk Egress Operation

SABRE	Scheduling and ABR Engine	SUNI	SONET/SDH UNI ASIC
SIMBA	Serial I/F and Multicast Buffer ASIC	ACP	Sub-system Processor
RCMP	Routing Ctl, Monitoring, & Policing ASIC	ASIC	Application Specific Integrated Ckt
DRSIU	Dual Receiver Serial I/F Unit		



S6170

Detailed Description, Port (UNI) and Trunk Modes

The following provides a summary of the principal functions performed by the major functional circuits of the BXM.

DRSIU

The DRSIU provides a total egress capacity from the BPX switch fabric of 1.6 Gbps.

SONET/SDH UNI (SUNI)

The SUNI ASIC implements the BXM physical processing for OC3 and OC12 interfaces. The SUNI provides SONET/SDH header processing, framing, ATM layer mapping and processing functions for OC12/STM-4 (622.08 Mbps) or OC3/STM1 (155.52 Mbps).

For ingress traffic, the BXM physical interface receives incoming SONET/SDH frames, extracts ATM cell payloads, and processes section, line, and path overhead. For egress traffic ATM cells are processed into SONET/SDH frames.

Alarms and statistics are collected at each level: section, line, and path.

DeMux/Mux

The Demux/Mux and associated circuits implement the BXM physical layer processing for T3/E3 interfaces, providing header processing, framing, ATM layer mapping, and processing functions for T3 at a 44.736 Mbps rate or E3 at a 34.368 rate.

RCMP

Usage Parameter Control (UPC) is provided by the RCMP. Each arriving ATM cell header is processed and identified on a per VC basis. The policing function utilizes a leaky bucket algorithm.

In addition to UPC and traffic policing, the RCMP provides route monitoring and also terminates OAM flows to provide performance monitoring on an end-to-end per VC/VP basis.

Traffic policing and UPC functionality is in accordance with the GCRA as specified by ATM Forum's UNI 3.1 using dual leaky buckets.

- Leaky Bucket 1 utilizes:
 - Peak Cell Rate (PCR)
 - Cell Delay Variation Tolerance: CDVT
- Leaky Bucket 2 utilizes:
 - Sustainable Cell Rate (SCR)
 - Maximum Burst Size (MBS)

In addition, two selective cell discard thresholds are supported for all queues for discard of CLP=1 cells should congestion occur.

SABRE

The Scheduling and ABR Engine (SABRE) includes both VS/VD and Foresight dynamic traffic transfer rate control and other functions:

- ATM Forum Traffic Management 4.0 compliant ABR Virtual Source/Virtual Destination (VS/VD).
- Terminates ABR flows for VS/VD and Foresight control loops.
- Performs explicit rate (ER) and EFCI tagging if enabled.
- Supports Foresight congestion control and manages the designated service classes on a per VC basis with OAM processing.
- Supports OAM flows for internal loopback diagnostic self-tests and performance monitoring.
- Provides service queue decisions to the Ingress and Egress Queue Engines for per VC queues for ABR VCs.

Ingress and Egress Queue Engines

The overall function of the queue engines is to manage the bandwidth of trunks or ports (UNI) via management of the ingress and egress queues.

In addition to the ABR VS queues, the ingress queues include 15 slot servers, one for each of 14 possible BPX destination slots, plus 1 for multicast operation. Each of the 15 slot servers contains 16 Qbins, supporting 16 classes of service per slot server.

In addition to the ABR VS queues, the egress queues include 32 Virtual Interfaces (VIs). Each of the 32 VIs supports 16 Qbins.

SIMBA

This serial interface and multicast buffer ASIC provides the following:

- ATM cell header translation.
- Directs ATM cells to the Egress Queue Engine with a 2 x OC-12c throughput capacity.
- Implements the multi-cast function in the egress direction, providing up to 4000 multicast connections.
- Translates standard OAM flows and Foresight cells.
- Optimizes backplane bandwidth by means of a polling mechanism.

ACP Subsystem Processor

The ACP performs the following localized functions:

- Initializes BXM at power up
- Manages local connection databases
- Collects card, port, and connection statistics
- Manages OAM operation
- Controls alarm indicators (active, standby, fail)

All basic configuration data on the card is copied to the battery backup memory (BRAM) on the card so that in the event of a power outage, the card will retain its main configuration.

Fault Management and Statistics

Note This is a preliminary listing.

Fault Management and Statistics, Port (UNI) Mode

Compliant to Bellcore GR-253-CORE

Alarms:

- Loss Of Signal (LOS)
- Loss Of Pointer (LOP)
- Loss Of Frame (LOF)
- Loss Of Cell delineation (LOC)
- Alarm Indication Signal (AIS)
- Remote Defect Indication (RDI)
- Alarm Integration Up/down Count

Performance Monitoring:

- Performance monitoring provided for Line, Section, and Path
- Bit Interleaved Parity (BIP) error detection
- Far End Block Error (FEBE) count
- Unavailable Seconds (UAS)
- Errored Seconds (ES)
- Severely Errored Seconds (SES)
- Header Error Checksum (HCS) monitoring

Statistics:

- ATM statistics collected on a per VC basis
 - Two modes of statistics collection:
 - Basic: collection of 4 statistics per VC per direction
 - Enhanced: collection of 12 statistics per VC per direction

OAM

- Loopback support
- Generation and detection of AIS and RDI OAM cells
- Termination and processing of OAM cells

Fault Management and Statistics, Trunk Mode

Compliant to Bellcore GR-253-CORE

Alarms:

- Loss Of Signal (LOS)
- Loss Of Pointer (LOP)
- Loss Of Frame (LOF)
- Loss Of Cell delineation (LOC)
- Alarm Indication Signal (AIS)
- Remote Defect Indication (RDI)
- Alarm Integration Up/down Count

Performance Monitoring:

- Performance monitoring provided for Line, Section and Path
- Bit Interleaved Parity (BIP) error detection
- Far End Block Error (FEBE) count
- Unavailable Seconds (UAS)
- Errored Seconds (ES)
- Severely Errored Seconds (SES)
- Header Error Checksum (HCS) monitoring

Statistics:

Process Monitoring for ATM Header Cell Processing

- Cells discarded due to Header Errors (LCN mismatch)

Miscellaneous ATM Layer Statistics

- Number of cell arrivals from port
- Number of cell arrivals with CLP = 1
- Number of cells transmitted to port
- Number of cells transmitted with CLP = 1

Technical Specifications

Physical Layer

- Trunk or port (access) interface mode.
- Compliant to SONET standards.
 - *Bellcore GR-253-CORE, TR-TSY-000020
 - *ANSI T1.105, T1E1.2/93-020RA
- Compliant to SDH standards.
 - *ITU-T G.707, G.708 and G.709
 - *ITU-T G.957, G.958
- 1:1 BXM redundancy supported using 'Y' redundancy.
- Fiber optic interface characteristics are listed in Table 6-8 and Table 6-9.

Table 6-8 Fiber Optic Characteristics OC-12

Back card	Source	Tx Power (dBm)		Rx Power (dBm)		Connection Type	Range (km)
		Min	Max	Min	Max		
SMF (IR)	Laser	-15	-8	-28	-8	FC	20
SMF (LR)	Laser	-3	+2	-28	-8	FC	40
SMF (XLR)	Laser						

Table 6-9 Fiber Optic Characteristics OC-3

Back card	Source	Tx Power (dBm)		Rx Power (dBm)		Connection Type	Range (km)
		Min	Max	Min	Max		
MMF	LED	-22	-15	-343	-10	SC	2
SMF (IR)	Laser 1310 nm	-15	-8	-34	-10	FC	20
SMF (LR)	Laser 1310 nm	-5	0	-34	-10	FC	40

General Information

- Card dimensions: 19”(H) x 1.1“(W) x 27”(D)
- Weight: 6 lb (2.7kg)
- Power -48 V DC at 85 W
- EMI/ESD: FCC Part 15, Bellcore GR1089-CORE

- IEC 801-2, EN55022
- Safety: EN 60950, UL 1950
- Bellcore NEBS:Level 3 compliant
- Optical Safety:
 - Intermediate Reach IEC 825-1 (Class 1)
 - Long Reach IEC 825-1 (Class 36)

General SONET Notes

SONET is defined across three elements, section, line, and path as shown in Figure 6-13 and described in Table 6-10. An advantage of this tiered approach is that management control can be exercised at each level, for example at the section level independent of the line or path level.

Figure 6-13 SONET Section, Line, and Path




Table 6-10 SONET Section, Line, and Path Descriptions

Unit	Description
Section	A section is the fiber optic cable between two active elements such as simple repeaters. The active element terminating these sections is called Section Terminating Equipment (STE).
Line	A line is a physical element that contains multiple sections and repeaters and is terminated by line terminating equipment (LTE) at each end.
Path	A path includes sections and lines and terminates at the customer premises equipment (CPE).

Table 6-11 provides a cross-reference between OC-n optical carrier levels and the equivalent STS-n and SDH-n levels. It also includes the associated line rates.

Table 6-11 Digital Hierarchies

OC-n Optical Carrier	STS-n Synchronized Transport Signal	Line Rates (Mbps)	SDH-n Synchronized Digital Hierarchy	STM-n Synchronous Transport Module
OC-1	STS-1	51.84		
OC-3	STS-3	155.52	SDH-1	STM-1
OC-12	STS-12	622.08	SDH-4	STM-4
OC-48	STS-48	2488.32	SDH-16	STM-12

User Commands

This section provides a preliminary summary of configuration, provisioning, and monitoring commands associated with the BXM cards. These commands apply to initial card configuration, line and trunk configuration and provisioning, and connection configuration and provisioning.

New or modified commands include but are not limited to:

Connection Provisioning

- **addcon**-add connection
- **cnfcon**-configure connection
- **dspcon**-display connection

Diagnostics

- **addlnloclp**-add local loopback to line
- **addlnlocrmtlp**-add local remote loopback to line
- **dellnlp**-delete local or remote loopback

Test

- **tstconseg**-test connection externally with OAM segment loopback cells
- **tstdelay**-test connection round trip delay

Statistics

- Line and Trunk statistics
 - **cnflnstats**-configure line statistics collection
 - **dsplnstatcnf**-display statistics enabled for a line
 - **dsplnstathist**-display statistics data for a line
 - **cnftrkstats**-configure trunk statistics collection
 - **dsptrkstatcnf**-display statistics enabled for a trunk
 - **dsptrkstathist**-display statistics data for a trunk
- Channel Statistics
 - **cnfchstats**-configure channel statistics collection
 - **dspchstatcnf**-display statistics configuration for a channel
 - **dspchstathist**-display statistics data for a channel
 - **dspchstats**-display channel statistics (multisession permitted)
- Line Statistics
 - **cnfslotalm**-configure slot alarm threshold
 - **dspslotalms**-display slot alarms

- **clrslotalm**-clear slot alarm
- **dspsloterrs**-display slot errors
- Statistical Trunk/Line Alarms
 - **cnflnalm**-configure line alarm threshold
 - **dsplnerrs**-display line errors
 - **dsplnalmcnf**- display line alarm configuration
 - **clrlnalm**-clear line alarm

Configuring Connections

Connections are typically provisioned and configured using Cisco StrataView Plus. However, the connections can also be added using the BPX switch command line interface (CLI). This may be appropriate during initial local node setup and when a Strata View Plus workstation is not available.

There are two connection addressing modes supported. The user may enter a unique VPI/VCI address in which case the BPX switch functions as a virtual circuit switch. Or the user may enter only a VPI address in which case all circuits are switched to the same destination port and the BPX switch functions as a virtual path switch in this case. The full ATM address range for VPI and VCI is supported.

Connections are routed between CPE connected to BXM ports. Before adding connections, the BXM is configured for port mode.

Note The initial command to up a trunk (**uptrk**) or to up a line (**upln**) on the BXM card configures all the ports of the card to be either trunks or lines (UNI port access). Following the **uptrk** command at each port, the **addtrk** command is used to activate a trunk for network access.

A line is upped with the **upln** command and configured with the **cnfln** command. Then the associated port is configured with the **cnfport** command and upped with the **upport** command. Following this, the ATM connections are added via the **addcon** command.

The slot number is the BXM card slot on the BPX switch. The port number is one of the ports on the BXM, the VPI is the virtual path identifier, and the VCI is the virtual circuit identifier.

The VPI and VCI fields have significance only to the local BPX switch, and are translated by tables in the BPX switch to route the connection. Connections are automatically routed by the AutoRoute feature once the connection endpoints are specified.

Connections can be either Virtual Path Connections (VPC) or Virtual Circuit Connections (VCC). Virtual Path Connections are identified by an * in the VCI field. Virtual Circuit Connections specify both the VPI and VCI fields.

Configuration Management

The following parameters are entered for the BXM **addcon** command. Depending upon the connection type, the user is prompted with appropriate parameters as shown below.

Syntax:

addcon local_addr node remote_addr traffic_type ...extended parameters

Field	Value	Description
local/remote_addr	slot.port.vpi.vci	card slot, port, and desired VCC or VPI connection identifier
node		slave end of connection
traffic_type		type of traffic, chosen from CBR, VBR, ABR, and UBR
extended parameters		parameters associated with each connection type

Note The range of VPIs and VCIs reserved for PVC traffic and SVC traffic is configurable using the **cnfport** command. While adding connections, the system checks the entered VPI/VPC against the range reserved for SVC traffic. If there is a conflict, the **addcon** command fails with the message “VPI/VCI on selected port is reserved at local/remote end”.

Command Line Interface Examples

The following pages have a number of command examples, including configuring BXM lines and trunks and adding connections terminating on BXM cards.

An example of the **uptrk** command for trunk 1 on a BXM in slot 4 of a BPX switch follows:

```
pubsbpx1      TN      SuperUser      BPX 15      9.1      Jan. 11 1998 18:52 GMT

TRK      Type      Current Line Alarm Status      Other End
1.1      T3      Clear - OK      pubsax11 (AXIS)
1.3      T3      Clear - OK      pubsipx1/8
4.1      OC3      Clear - OK      -
```

Last Command: uptrk 4.1

Next Command:

Note The initial command to up a trunk (**uptrk**) or to up a line (**upln**) on the BXM card configures all the ports of the card to be either trunks or lines (UNI port access). Following the **uptrk** command at each port, the **addrk** command is used to activate a trunk for network access.

An example of the **cnftrk** command for trunk 4.1 of a BXM card follows:

```
pubsbpx1      TN      SuperUser      BPX 15      9.1      Jan. 11 1998 18:50 GMT

TRK 4.1 Config OC3 [353207cps]      BXM slot:      4
Transmit Rate:      353208      Restrict CC traffic: No
Subrate interface:  --      Link type:      Terrestrial
Subrate data rate:  --      Line framing:   STS-3C
Line DS-0 map:      --      coding:         --
Pass sync:          Yes      CRC:            --
Loop clock:         No      recv impedance: --
Statistical Reserve: 1000 cps      cable type:     --
Idle code:          7F hex      length:         --
Max Channels/Port:  256      HCS Masking:    Yes
Connection Channels: 256      Payload Scramble: Yes
Valid Traffic Classes:      Frame Scramble:  Yes
      V,TS,NTS,FR,FST,CBR,VBR,ABR      Virtual Trunk Type: --
SVC Channels:       --      Virtual Trunk VPI: --
SVC Bandwidth:     -- cps      Deroute delay time: 0

This Command: cnftrk 4.1

Transmit Rate [T2=14490, E3=80000, T3=96000, OC3 = 353208, OC12=1412830](353208)
```

An example of the **addrk** command follows:

```
pubsbpx1      TN      SuperUser      BPX 15      9.1      Jan. 11 1998 18:54 GMT

TRK   Type   Current Line Alarm Status      Other End
1.1   T3     Clear - OK                      pubsaxil(Axis)
1.3   T3     Clear - OK                      pubsipx1/8
4.1   OC3    Clear - OK                      -

Last Command: dsptrks

Next Command: addrk 4.1
```

An example of the **upln** command for UNI port access on a BXM card follows:

```
pubsbsp1      TN      YourID:1      BPX 15      9.1      Jan. 11 1998 02:18 GMT

Line   Type   Current Line Alarm Status
3.1    OC3    Clear - OK
3.2    OC3    Clear - OK
3.3    OC3    Clear - OK
5.1    T3     Clear - OK
5.2    T3     Clear - OK
```

Last Command: upln 3.3

Next Command:

Note The initial command to up a trunk (**uptrk**) or to up a line (**upln**) on the BXM card configures all the ports of the card to be either trunks or lines (UNI port access). Following the **upln** command at each port, the **upport** command is used to activate a port for UNI access.

An example of the **cnfln** command follows:

```
pubsbsp1      TN      YourID:1      BPX 15      9.1      Jan. 11 1998 02:24 GMT

LN   3.3 Config   OC3   [353208cps]      BXM slot:   3
Loop clock:           No           Idle code:           7F hex

Line framing:         --
coding:               --
CRC:                  --
recv impedance:      --
E1 signalling:        --
encoding:             --
T1 signalling:        --
                    cable type:      --
                    length:          --
                    HCS Masking:      Yes
                    Payload Scramble:  Yes
                    Frame Scramble:    Yes
                    Cell Framing:     STS-3C

56KBS Bit Pos:       --
pct fast modem:      --
```

This Command: cnfln 3.3

Loop clock (N):

An example of the **cnfport** command for port 3 of a BXM card in slot 3 follows:

```
pubsbpx1      TN      YourID:1      BPX 15      9.1      Jan. 11 1998 02:25 GMT

Port:         3.3      [ INACTIVE ]
Interface:    LM-BXM
Type:         UNI
Speed:        353208 (cps)
Shift:        SHIFT ON HCF (Normal Operation)
VBR Queue Depth: 5000

%Util Use:    Disabled

Protocol:     NONE
SVC Channels: 0
SVC VPI Min: 0
SVC VPI Max: 0
SVC Bandwidth: 0 (c/s)
```

This Command: cnfport 3.3

NNI Cell Header Format? [N]:

An example of the **cnfportq** command follows:

```
pubsbpx1      TN      YourID:1      BPX 15      9.1      Jan. 11 1998 02:27 GMT

Port:         3.3      [ INACTIVE ]
Interface:    LM-BXM
Type:         UNI
Speed:        353208 (cps)

SVC Queue Pool Size: 0
CBR Queue Depth: 600
CBR Queue CLP High Threshold: 80%
CBR Queue CLP Low Threshold: 60%
CBR Queue EFCI Threshold: 80%
VBR Queue Depth: 5000
VBR Queue CLP High Threshold: 80%
VBR Queue CLP Low Threshold: 60%
VBR Queue EFCI Threshold: 80%
ABR Queue Depth: 20000
ABR Queue CLP High Threshold: 80%
ABR Queue CLP Low Threshold: 60%
ABR Queue EFCI Threshold: 80%
```

This Command: cnfportq 3.3

SVC Queue Pool Size [0]:

An example of the **upport** command follows:

```
pubsbpx1      TN      YourID:1      BPX 15      9.1      Jan. 11 1998 02:28 GMT

Port:        3.3      [ACTIVE  ]
Interface:    LM-BXM
Type:        UNI      %Util Use:      Disabled
Speed:       353208 (cps)
Shift:       SHIFT ON HCF (Normal Operation)
VBR Queue Depth: 5000

Protocol:    NONE
SVC Channels:      0
SVC VPI Min:      0
SVC VPI Max:      0
SVC Bandwidth:    0 (c/s)
```

Last Command: upport 3.3

Next Command:

An example of the **cnfcls** command for class 1 follows:

```
pubsbpx1      TN      YourID:1      BPX 15      9.1      Jan. 11 1998 02:31 GMT

                        ATM Connection Classes
Class: 1
  PCR(0+1)  % Util      MCR      CDVT(0+1)      AAL5 FBTC FST  VSVD
96000/96000  100/100 96000/96000  10000/10000      n      n      n

Description: "Default ABR 96000"
```

This Command: cnfcls 1

Enter class type (VBR, CBR, UBR, ABR, ATFR):

An example of the **cnfcls** command for class 2 follows:

```
pubsbpx1      TN      YourID:1      BPX 15      9.1      Jan. 11 1998 02:33 GMT

                ATM Connection Classes
Class: 2
  PCR(0+1)    % Util    CDVT(0+1)    AAL5 FBTC    SCR    Type: VBR
1000/1000    100/100    10000/10000    n    1000/1000

  MBS      Policing
1000/1000      3

  Description: "Default VBR 1000 "
```

This Command: cnfcls 2

Enter class type (VBR, CBR, UBR, ABR, ATFR):

An example of the **addcon** command for a VBR connection 3.1.105.55 that originates at port 1 of a BXM card in slot 3 follows:

```
pubsbpx1      TN      YourID:1      BPX 15      9.1      Jan. 11 1998 02:39 GMT

From      Remote      Remote      State  Type      Route
3.1.105.55  NodeName    Channel      Ok     vbr      Avoid COS 0
3.1.105.55  pubsbpx1    3.2.205.65   Ok     vbr
3.2.201.61  pubsbpx1    3.1.101.51   Ok     abr
3.2.201.62  pubsbpx1    3.1.101.52   Ok     abr
3.2.203.63  pubsbpx1    3.1.103.53   Ok     abr
3.2.204.64  pubsbpx1    3.1.104.54   Ok     abr
3.2.205.65  pubsbpx1    3.1.105.55   Ok     vbr
5.1.30.120  pubsbpx1    5.2.60.240   Ok     abr
5.1.31.121  pubsbpx1    5.2.61.241   Ok     abr
5.1.32.122  pubsbpx1    5.2.62.242   Ok     abr
5.1.33.123  pubsbpx1    5.2.63.242   Ok     abr
5.2.60.240  pubsbpx1    5.1.30.120   Ok     abr
5.2.61.241  pubsbpx1    5.1.31.121   Ok     abr
5.2.62.242  pubsbpx1    5.1.32.122   Ok     abr
```

Last Command: addcon 3.1.105.55 pubsbpx1 3.2.205.65 v * * * * *

Next Command:

An example of the **cnfcon** command for a VBR connection 3.1.105.55 follows.

```
pubsbpx1      TN      YourID:1      BPX 15      9.1      Jan. 11 1998 02:41 GMT

Conn:  3.1.105.55      pubsbpx1      3.2.205.65      vbr
Description:

      PCR(0+1)      % Util      CDVT(0+1)      AAL5 FBTC      SCR
      50/50      100/100      250000/250000      n      50/50

      MBS      Policing
      1000/1000      3
```

This Command: `cnfcon 3.1.105.55`

PCR(0+1) [50/50]:

An example of the **addcon** command for an ABR connection follows. In this case, the choice to accept the default parameters was not accepted, and individual parameters were configured for a connection using ABR standard VSVD flow control.

```
pubsbpx1      TN      YourID      BPX 15      9.1      Jan. 11 1998 01:10 GMT

From      Remote      Remote      State      Type      Route
3.1.104.54      RemoteName      Channel      State      Type      Avoid COS O
3.1.104.54      pubsbpx1      3.2.204.64      Ok      abr
3.2.201.61      pubsbpx1      3.1.101.51      Ok      abr
3.2.201.62      pubsbpx1      3.1.101.52      Ok      abr
3.2.203.63      pubsbpx1      3.1.103.53      Ok      abr
3.2.204.64      pubsbpx1      3.1.104.54      Ok      abr
5.1.30.120      pubsbpx1      5.2.60.240      Ok      abr
5.1.31.121      pubsbpx1      5.2.61.241      Ok      abr
5.1.32.122      pubsbpx1      5.2.62.242      Ok      abr
5.1.33.123      pubsbpx1      5.2.63.242      Ok      abr
5.2.60.240      pubsbpx1      5.1.30.120      Ok      abr
5.2.61.241      pubsbpx1      5.1.31.121      Ok      abr
5.2.62.242      pubsbpx1      5.1.32.122      Ok      abr
5.2.63.242      pubsbpx1      5.1.33.123      Ok      abr
```

This Command: `addcon 3.1.104.54 pubsbpx1 3.2.204.64 abr 100/100 95/95 50/50 * e d e d 70/70 * 3 * 80/80 60/60 30/30 65/65 * 100 16 16 32 10 *`

Add these connections (y/n)? `y`

Command Line Interface Examples

An example of the **cnfcon** command for an ABR connection follows:

```
pubsbpx1      TN      YourID:1      BPX 15      9.1      Jan. 11 1998 01:10 GMT
Conn: 3.1.104.54      pubsbpx1      3.2.204.64      abr
Description:
      PCR(0+1)      % Util      MCR      CDVT(0+1)      AAL5 FBTC FST      VSVD
      100/100      95/95      50/50      250000/250000      y      n      y
FCES      SCR      MBS      Policing      VC Qdepth      CLP Hi      CLP Lo      EFCI
n      70/70      1000/1000      3      16000/16000      80/80      60/60      30/30
      ICR      ADTF Trm      RIF      RDF      Nrm      FRTT      TBE
      65/65      1000 100      16      16      32      10      1048320
```

This Command: cnfcon 3.1.104.54

PCR(0+1) [100/100]:

An example of the **cnfabrparm** command follows:

```
pubsbpx1      TN      YourID:1      BPX 15      9.1      Feb. 8 1998 00:21 GMT
ABR Configuration for BXM in slot 3
Egress CI Control : N
ER Stamping      : N
Weighted Queueing : N
```

Last Command: cnfabrparm 3

Next Command:

An example of the **dsplns** command follows:

```
pubsbpx1      TN      YourID      BPX 15      9.1      Feb. 8 1998  00:22 GMT
```

```
Line   Type   Current Line Alarm Status
3.1    OC3    Clear - OK
3.2    OC3    Clear - OK
3.3    OC3    Clear - OK
3.4    OC3    Clear - OK
5.1    T3     Clear - OK
5.2    T3     Clear - OK
```

Last Command: dsplns

Next Command:

Configuring the BPX Switch for SVCs

During the configuration of BPX switch interfaces, you must make sure that the BPX switch IP address, SNMP parameters, and Network IP address are set consistent with your local area network (Ethernet LAN). Use the following BPX switch commands to set these parameters:

- **cnflan**—This is a Super User level command and must be used to configure the BPX switch BCC LAN port IP address and subnet mask.
- **cnfsnmp**—This command is used to configure the SNMP Get and Set community strings for the BPX switch as follows:
 - Get Community String = public
 - Set Community String = private
 - Trap Community String = public.
- **cnfnwip**—This is a Super User level command which is used to configure the virtual IP network (IP relay) among BPX switches.
- **cnfstatmast**—This command is used to define the IP address for routing messages to and from the Statistics Manager in Cisco StrataView Plus.

The use of these commands is covered in the *Cisco WAN Switching Command Reference* or the *Cisco WAN Switching Super User Command Reference*. Super User commands must be used only by authorized personnel, and must be used carefully.

Configuring the MGX 8220

MGX 8220 installation and configuration are covered in the *Cisco MGX 8220 Reference*. During the configuration of BPX switch interfaces, you must make sure that the MGX 8220 IP address is set up consistent with your local area network (Ethernet LAN). Use the following MGX 8220 command to set the proper IP addresses:

cnfifip -ip <ip address> -if <interface type> -msk <subnet mask address> -bc <broadcast address>

The use of this command is covered in the *Cisco MGX 8220 Command Reference*.

Resource Partitioning

Starting with switch software Release 8.4, resources on BPX switch UNI ports and NNI trunks can be divided between SVCs and PVCs. This is known as resource partitioning and is done through the Command Line Interface for the BPX switch and the MGX 8220.

These resources for BXM, ASI, and BNI cards can be partitioned appropriately between SVCs or PVCs.

Tag Switching

Starting with switch software release 9.1, the BXM also supports tag switching. Partitions for the BXM can be allocated either between:

- SVCs and PVCs, or
- Tag switching virtual circuits (TVCs) and PVCs.

For information on Tag Switching, refer to *Chapter 9, Tag Switching*.

Dynamic Resource Partitioning for SPVCs

Also, for switch software Release 9.1, the BXM card supports dynamic resource partitioning to support the conversion of PVCs to soft permanent virtual circuits (SPVCs). This feature is described in the *Cisco WAN Service Node Extended Services Processor Installation and Operations for Release 2.2* document.

Summary

This section provides procedures for:

- UNI Port Resource Partitioning, BXM and ASI
- NNI or Trunk Resource Partitioning, BXM and BNI

Note Resource partitioning also has to be done for the line between the ESP ATM NIC and the BXM in the BPX switch. Refer to the *Cisco WAN Service Node Extended Services Processor Installation and Operation for Release 2.2* document.

ASI SVC Resource Partitioning

A BPX switch ATM Service Interface (ASI) card which will support ATM SVCs will have to be added and upped like a standard PVC port. Before adding connections, an ASI line is upped with the **upln** command and configured with the **cnfport** command and upped with the **upport** command. Complete details on using the BPX switch command line interface and applicable commands are described in the *Cisco WAN Switching Command Reference* manuals. Also, refer to the *Cisco WAN Service Node Extended Services Processor Installation and Operations for Release 2.2* document.

These procedures will concentrate on those commands that are specific to SVC resource partitioning.

Before partitioning SVC resources, you must have determined which ASI will support ATM SVCs. The ASI will have to have its resources partitioned to support SVCs. The following resources must be partitioned for each ASI UNI port:

- SVC Channels
- SVC VPI Min
- SVC VPI Max
- SVC Bandwidth
- SVC Queue Depth

To partition the ASI UNI port, follow these steps:

- Step 1** Log in to the BPX switch
- Step 2** Using the **upln** and **upport** commands, up the line and port which are going to be connected to ATM CPE.
- Step 3** Make sure the port is configured as UNI.
- Step 4** Enter the **cnfport <port num>** command, as illustrated in the following example:

Example: ASI cnfport Command

```

spvc21          VT      SuperUser          BPX 15    9.1    Sep. 24 1997 07:49 GMT

Port:          2.1      [ FAILED ]
Interface:     MMF-2
Type:          UNI                      %Util Use:      Disabled
Speed:         353208 (cps)
Shift:         SHIFT ON HCF (Normal Operation)
SIG Queue Depth: 10

Protocol:      NONE
  SVC Channels:          500
  SVC VPI Min:           0
  SVC VPI Max:           10
  SVC Bandwidth:        300000 (cps)

This Command:  cnfport 2.1

NNI Cell Header Format? [N]:

Virtual Terminal

```

Note The preceding example displays a screen with the Protocol parameter set to None. If Protocol had been set to LMI or ILMI, the LMI parameters would also appear on the screen. The SVC parameters that need to be configured will remain the same, however.

Step 5 Configure the desired SVC Channels, SVC VPI Min, SVC VPI Max, and SVC Bandwidth as desired.

Step 6 Next configure the SVC Port Queue depth with the **cnfportq** <port num> command shown in the following example:

Example: ASI cnfportq Command

```

spvc21          VT      SuperUser      BPX 15      9.1      Sep. 24 1997 07:50 GMT

Port:           2.1      [ FAILED ]
Interface:      MMF-2
Type:           UNI
Speed:          353208 (cps)

SVC Queue Pool Size:          400
CBR Queue Depth(64-cell blks):16
CBR Queue CLP High Threshold: 80%
CBR Queue CLP Low Threshold:  60%
CBR Queue EFCI Threshold:     80%
VBR Queue Depth(64-cell blks):50      UBR/ABR Queue Depth(64-cells blks):28
VBR Queue CLP High Threshold: 80%      UBR/ABR Queue CLP High Threshold:  80%
VBR Queue CLP Low Threshold:  60%      UBR/ABR Queue CLP Low Threshold:   60%
VBR Queue EFCI Threshold:     80%      UBR/ABR Queue EFCI Threshold:     80%

```

This Command: cnfportq 2.1

SVC Queue Pool Size [400]:

Virtual Terminal

Step 7 Configure the SVC Queue Pool Size with this menu. Other parameters are for PVCs.

Step 8 Repeat SVC resource partitioning for every ASI port that you want to support SVCs in the BPX Switch.

BXM SVC Resource Partitioning

A BXM card used as a UNI port can be configured to support ATM SVCs. The BXM will have to be added and upped like a standard PVC port. The BXM port will have to be upped as a line (upln) to function as a UNI port.

Note The initial command to up a trunk (**uptrk**) or to up a line (**upln**) on the BXM configures all the physical ports on a BXM card to be either trunks or ports. They can not be inter-mixed.

For additional information on using the BPX switch command line interface and applicable commands, refer to the *Cisco WAN Switching Command Reference* manual. These procedures will concentrate on those commands that are specific to SVC resource partitioning.

Before partitioning SVC resources, you must determine which BXM UNI ports will support ATM SVCs. The BXM must have its resources partitioned to support SVCs. The following resources must be partitioned:

- SVC Channels
- SVC VPI Min
- SVC VPI Max
- SVC Bandwidth
- SVC Queue Pool Size.

To partition the BXM port, follow these steps:

- Step 1** Log in to the BPX switch.
- Step 2** Using the upln and upport commands, up the line and port which is going to be connected to ATM CPE.
- Step 3** Make sure the port is configured as UNI.
- Step 4** Enter the **cnfport <port num>** command, shown in the following example:

Example: BXM cnfport Command

```

ins-bpx6      TN      SuperUser      BPX 15      9.1      Sep. 24 1997 07:37 GMT

Port:         13.1      [ACTIVE  ]
Interface:    LM-BXM
Type:         UNI                      %Util Use:      Disabled
Speed:        353208 (cps)
Shift:        SHIFT ON HCF (Normal Operation)
SIG Queue Depth: 640

Protocol:     NONE
SVC Channels: 1000
SVC VPI Min:  0
SVC VPI Max:  10
SVC Bandwidth: 300000 (cps)
    
```

This Command: cnfport 13.1

NNI Cell Header Format? [N]:

Step 5 Configure the SVC Channels, SVC VPI Min, SVC VPI Max, and SVC Bandwidth as desired.

Step 6 Next you need to configure the SVC Port Queue depth with the `cnfportq <portnum>` command shown in the following example.

Example: BXM `cnfportq` Command

```

ins-bpx6      TN      SuperUser      BPX 15      9.1      Sep. 24 1997 07:39 GMT

Port:         13.1      [ACTIVE ]
Interface:    LM-BXM
Type:         UNI
Speed:        353208 (cps)

SVC Queue Pool Size:      5000
CBR Queue Depth:         600
CBR Queue CLP High Threshold: 80%
CBR Queue CLP Low Threshold: 60%
CBR Queue EFCI Threshold: 80%
VBR Queue Depth:         5000
VBR Queue CLP High Threshold: 80%
VBR Queue CLP Low Threshold: 60%
VBR Queue EFCI Threshold: 80%
UBR/ABR Queue Depth:      20000
UBR/ABR Queue CLP High Threshold: 80%
UBR/ABR Queue CLP Low Threshold: 60%
UBR/ABR Queue EFCI Threshold: 30%

```

This Command: `cnfportq 13.1`

SVC Queue Pool Size [5000]:

Step 7 Configure the SVC Queue Pool Size parameter to a value greater than 0 (zero); the default is 0 and needs to be changed for SVCs to operate.

Step 8 Partition the SVC resources for every BXM which is to support ATM SVCs in the BPX switch.

NNI Trunk SVC Resource Partitioning

The BPX switch has two types of trunk cards which may have their resources partitioned to support SVCs.

- BNI
- BXM

Note It is important to reserve the maximum number of channels before SVCs or PVCs are in use, because SVC partitioning parameters may not be changed if any SVC or PVC is in use on the entire card.

BNI Trunk SVC Resource Partitioning

When the BNI is used as a trunk in a BPX switch network, it will have to have its resources partitioned to support SVCs. Complete details on using the BPX switch command line interface and applicable commands are described in the *Cisco BPX 8600 Series Reference and WAN Switching Command Reference manuals*. These procedures will concentrate on those commands that are specific to SVC resource partitioning.

The following BNI trunk resources must be partitioned for SVCs:

- SVC Channels
- SVC VPI Min
- SVC VPI Max
- SVC Bandwidth
- SVC Queue Pool Size.

To partition the BNI trunk resources, follow these steps:

- Step 1** Log in to the BPX switch
- Step 2** Up the trunk with **uptrk <trunk_num>** command.
- Step 3** Enter the **cnftrk <trk num>** command as shown in the following example:

Example: BNI cnftrk Command

```

swongl35      VT      SuperUser      BPX 15      9.1      Sep. 24 1997 07:42 GMT

TRK 5.1 Config T3      [96000 cps]      BNI-T3 slot: 5
Transmit Rate:      96000      Line framing:      PLCP
Subrate data rate:  --      coding:      --
Line DS-0 map:      --      CRC:      --
Statistical Reserve: 1000 cps      recv impedance:  --
Idle code:      7F hex      cable type:
Max Channels/Port:  --      length:      0-225 ft.
Connection Channels: 1771      Pass sync:      Yes
Traffic: V,TS,NTS,FR,FST,CBR,VBR,ABR      Loop clock:      No
SVC Vpi Min:      --      HCS Masking:      Yes
SVC Channels:      --      Payload Scramble:  No
SVC Bandwidth:      -- cps      Frame Scramble:  --
Restrict CC traffic: No      Virtual Trunk Type:  --
Link type:      Terrestrial      Virtual Trunk VPI:  --
Routing Cost:      10      Deroute delay time: 0 seconds
    
```

This Command: cnftrk 5.1

Stat Reserve (1000):

Virtual Terminal

- Step 4** Configure the SVC Vpi Min, SVC Channels, and SVC Bandwidth as desired.
- Step 5** Next configure the SVC Queue depth with **cnftrkparms <trunk_num>** command shown in the following example:

Example: BNI cnftrkparm Command

```

swongl35      VT      SuperUser      BPX 15      9.1      Sep. 24 1997 07:44 GMT

TRK 5.1 Parameters
 1 Q Depth - Voice      [ 242] (Dec)      15 Q Depth - CBR      [ 600] (Dec)
 2 Q Depth - Non-TS     [ 360] (Dec)      16 Q Depth - VBR      [ 1000] (Dec)
 3 Q Depth - TS         [ 1000] (Dec)     17 Q Depth - ABR      [ 9070] (Dec)
 4 Q Depth - BData A    [ 1000] (Dec)     18 Low CLP - CBR      [ 100] (%)
 5 Q Depth - BData B    [ 8000] (Dec)     19 High CLP - CBR     [ 100] (%)
 6 Q Depth - High Pri   [ 1000] (Dec)     20 Low CLP - VBR      [ 100] (%)
 7 Max Age - Voice      [ 20] (Dec)       21 High CLP - VBR     [ 100] (%)
 8 Red Alm - I/O (Dec)  [ 2500 / 15000]  22 Low CLP - ABR      [ 60] (%)
 9 Yel Alm - I/O (Dec) [ 2500 / 15000]  23 High CLP - ABR     [ 80] (%)
10 Low CLP - BData A    [ 100] (%)        24 EFCN - ABR         [ 30] (%)
11 High CLP - BData A  [ 100] (%)        25 SVC Queue Pool Size [ 0] (Dec)
12 Low CLP - BData B   [ 25] (%)
13 High CLP - BData B  [ 75] (%)
14 EFCN - BData B      [ 30] (Dec)

```

This Command: cnftrkparm 5.1

Which parameter do you wish to change:

Virtual Terminal

- Step 6** Configure the SVC Queue Pool Size as desired.
- Step 7** Partition the SVC resources for all the other BNIs in your BPX switch. This includes the BNI that is used to connect an MGX 8220 shelf to a BPX switch when they are to be used for SVC connections.

BXM Trunk SVC Resource Partitioning

When the BXM is used as a trunk in a BPX switch network, it needs to have its resources partitioned to support SVCs. The BXM card will have to be upped as a trunk (**uptrk**).

Note The initial command to up a trunk (**uptrk**) or to up a line (**upln**) on the BXM configures all the physical ports on the card to be either lines or trunks. They can not be inter-mixed.

For additional information on using the BPX switch command line interface and applicable commands refer to the *Cisco WAN Switching Command Reference* manual. These procedures concentrate on those commands that are specific to SVC resource partitioning.

The following BXM trunk resources must be partitioned for SVCs:

- SVC Channels
- SVC Bandwidth
- SVC Queue Pool Size.

To partition the BXM trunk resources for SVCs, follow these steps:

- Step 1** Log in to the BPX switch
- Step 2** Make sure the BXM has been upped as a trunk with **uptrk <trunk_num>** command.
- Step 3** Enter the **cnftrk <trk num>** command, shown in the following example:

Example: BXM cnftrk Command

```

ins-bpx6      TN      SuperUser      BPX 15      9.1      Sep. 24 1997 07:45 GMT

TRK 3.1 Config  OC3  [304301cps]      BXM slot:      3
Transmit Rate:      353208      Line framing:      STS-3C
Subrate data rate:  --      coding:      --
Line DS-0 map:      --      CRC:      --
Statistical Reserve: 1000 cps      recv impedance:  --
Idle code:      7F hex      cable type:      --
Max Channels/Port:  256      length:      --
Connection Channels: 256      Pass sync:      Yes
Traffic:  V,TS,NTS,FR,FST,CBR,VBR,ABR  Loop clock:      No
SVC Vpi Min:      0      HCS Masking:      Yes
SVC Channels:      2000      Payload Scramble:  Yes
SVC Bandwidth:      30000 cps      Frame Scramble:      Yes
Restrict CC traffic: No      Virtual Trunk Type:  --
Link type:      Terrestrial      Virtual Trunk VPI:  --
Routing Cost:      10      Deroute delay time: 0 seconds
    
```

This Command: cnftrk 3.1

Stat Reserve (1000):

- Step 4** Configure the SVC Vpi Min, SVC Channels and SVC Bandwidth as desired.
- Step 5** Next configure the SVC Queue depth with cnftrkparms <trunk_num> command shown in the following example:

Example: BXM cnftrkparm Command

```

ins-bpx6      TN      SuperUser      BPX 15      9.1      Sep. 24 1997 07:46 GMT

TRK 3.1 Parameters
 1 Q Depth - Voice      [ 885] (Dec)      15 Q Depth - CBR      [ 600] (Dec)
 2 Q Depth - Non-TS     [ 1324] (Dec)     16 Q Depth - VBR      [ 5000] (Dec)
 3 Q Depth - TS         [ 1000] (Dec)     17 Q Depth - ABR      [20000] (Dec)
 4 Q Depth - BData A    [10000] (Dec)     18 Low CLP - CBR      [ 100] (%)
 5 Q Depth - BData B    [10000] (Dec)     19 High CLP - CBR     [ 100] (%)
 6 Q Depth - High Pri   [ 1000] (Dec)     20 Low CLP - VBR      [ 100] (%)
 7 Max Age - Voice      [ 20] (Dec)       21 High CLP - VBR     [ 100] (%)
 8 Red Alm - I/O (Dec)  [ 2500 / 10000]  22 Low CLP - ABR      [ 60] (%)
 9 Yel Alm - I/O (Dec) [ 2500 / 10000]  23 High CLP - ABR     [ 80] (%)
10 Low CLP - BData A    [ 100] (%)        24 EFCN - ABR         [ 30] (%)
11 High CLP - BData A   [ 100] (%)        25 SVC Queue Pool Size [ 5000] (Dec)
12 Low CLP - BData B    [ 25] (%)
13 High CLP - BData B   [ 75] (%)
14 EFCN - BData B      [ 30] (Dec)
    
```

This Command: cnftrkparm 3.1

- Step 6** Configure the SVC Queue Pool Size as desired.
- Step 7** Partition the SVC resources for all the other BXMs in the BPX switch.

ATM Connections

This chapter describes how ATM connection services are established by adding ATM connections between ATM service interface ports in the network using ATM standard UNI 3.1 and Traffic Management 4.0. It describes BXM and ASI card operation and summarizes ATM connection parameter configuration

The chapter contains the following:


- ATM Connection Services
- SVCs
- Traffic Management Overview
- ATM Connection Requirements
- ATM Connection Configuration
- Traffic Policing Examples
- Traffic Shaping for CBR, VBR, and UBR
- LMI and ILMI Parameters

ATM Connection Services

ATM connection services are established by adding ATM connections between ATM service interface ports in the network. ATM connections can originate and terminate on the ASI (ATM Service Interface) cards, on BXM-T3/E3, BXM-155 (OC-3), and BXM-622 (OC-12) cards configured for port (service access) operation on the BPX switch, or on the MGX 8220 (using the AUSM card for the MGX 8220). Frame relay to ATM network interworking connections are supported between either BXM or ASI cards to the IPX, IGX, or MGX 8220. Frame relay to ATM service interworking connections are supported between either BXM or ASI cards to FRSM cards on the MGX 8220.

Figure 7-1 is a depiction of ATM connections over a BPX switch network. It shows ATM connections via BXM-T3/E3, BXM-155, BXM-622, ASI-1, and ASI-155 cards, as well as over MGX 8220 switches. It also shows frame relay to ATM interworking connections over the MGX 8220, IPX, and IGX shelves. For further information on the MGX 8220, refer to the *MGX 8220 Reference* document.

Figure 7-1 ATM Connections over a BPX Switch Network



SVCs

When an Extended Services Processor (ESP) is co-located with a BPX switch, ATM and Frame Relay Switched Virtual Circuits (SVCs) are supported in addition to Permanent Virtual Circuits (PVCs). For further information on ATM SVCs, refer to the *CiscoWAN Service Node Extended Services Processor Installation and Operation* document.

Traffic Management Overview

The ATM Forum Traffic Management 4.0 Specification defines five basic traffic classes:

- CBR (Constant Bit Rate)
- rt-VBR (Real-Time Variable Bit Rate)
- nrt-VBR (Non-Real Time Variable Bit Rate)
- UBR (Unspecified Bit Rate)
- ABR (Available Bit Rate)

Table 7-1 summarizes the major attributes of each of the traffic management classes:

Table 7-1 Standard ATM Traffic Classes

Attribute	CBR	rt-VBR	nrt-VBR	UBR	ABR
Traffic Parameters					
PCR & CDVT	x	x	x	x	x
SCR & MBS		x	x		
MCR					x
QoS Parameters					
Pk-to-Pk CDV	x	x			
Max CTD	x	x			
CLR	x	x	x		nw specific
Other Attributes					
Congestion Control Feedback					x

Traffic parameters are defined as:

- PCR (Peak Cell Rate in cells/sec): the maximum rate at which a connection can transmit
- CDVT (Cell Delay Variation Tolerance in usec): establishes the time scale over which the PCR is policed. This is set to allow for jitter (CDV) that is introduced for example, by upstream nodes.
- MBS (Maximum Burst Size in cells): is the maximum number of cells that may burst at the PCR but still be compliant. This is used to determine the BT (Burst Tolerance) which controls the time scale over which the SCR (Sustained Cell Rate) is policed.
- MCR (Minimum Cell Rate in cells per second): is the minimum cell rate contracted for delivery by the network.

QoS (Quality of Service) parameters are defined as:

- CDV (Cell Delay Variation): a measure of the cell jitter introduced by network elements
- Max CTD (Cell Transfer Delay): is the maximum delay incurred by a cell (including propagation and buffering delays).
- CLR (Cell Loss Ratio): is the percentage of transmitted cells that are lost.

Congestion Control Feedback:

- With ABR, provides a means to control flow based on congestion measurement.

Standard ABR notes:

Standard ABR uses RM (Resource Management) cells to carry feedback information back to the connection's source from the connection's destination.

ABR sources periodically interleave RM cells into the data they are transmitting. These RM cells are called forward RM cells because they travel in the same direction as the data. At the destination these cells are turned around and sent back to the source as Backward RM cells.

The RM cells contain fields to increase or decrease the rate (the CI and NI fields) or set it at a particular value (the explicit rate ER field). The intervening switches may adjust these fields according to network conditions. When the source receives an RM cell it must adjust its rate in response to the setting of these fields.

VSVD Description

ABR sources and destinations are linked via bi-directional connections, and each connection termination point is both a source and a destination; a source for data that it is transmitting, and a destination for data that it is receiving. The forward direction is defined as from source to destination, and the backward direction is defined as from destination to source. Figure 7-2 shows the data cell flow in the forward direction from a source to its destination along with its associated control loop. The control loop consists of two RM cell flows, one in the forward direction (from source to destination) and the other in the backward direction (from destination to source).

The data cell flow in the backward direction from destination to source is not shown, nor are the associated RM cell flows. However, these flows are just the opposite of that shown in the diagram for forward data cell flows.


A source generates forward RM cells which are turned around by the destination and returned to the source as backward RM-cells. These backward RM-cells may carry feedback information from the network elements and/or the destination back to the source.

The parameter *Nrm* is defined as the maximum number of cells a source may send for each forward RM cell, i.e., one RM cell must be sent for every *Nrm*-1 data cells. Also, in the absence of *Nrm*-1 data cells, as an upper bound on the time between forward RM cells for an active source, an RM cell must be sent at least once every *Trm* msecs.

BXM Connections

The BXM-T3/E3, BXM-155, and BXM-622 cards support ATM Traffic Management 4.0. The BXM cards are designed to support all the following service classes: Constant Bit Rate (CBR), Variable Bit Rate (VBR), Available Bit Rate (ABR with VS/VD, ABR without VS/VD, and ABR using Foresight), and Unspecified Bit Rate (UBR). ABR with VS/VD supports explicit rate marking and Congestion Indication (CI) control.

Figure 7-2 ABR VSVD Flow Control Diagram



Only the flows for forward data cells and their associated RM cell control loop are shown in this diagram. The flows for backward flow data cells (destination to source) and their associated RM cell control loop are just the opposite of that shown for the forward flow data cells.

NE = Network element

S6156

ForeSight Congestion Control

ForeSight may be used for congestion control across BPX/IGX/IPX switches for connections that have one or both end points terminating on ASI-T3/E3 or BXM cards. The ForeSight feature is a proprietary dynamic closed-loop, rate-based, congestion management feature that yields bandwidth savings compared to non-ForeSight equipped trunks when transmitting bursty data across cell-based networks. The BXM cards also support the VSVD congestion control mechanism as specified in the ATM Traffic Management 4.0 standards.

ATM Connection Requirements

There are two connection addressing modes supported. The user may enter a unique VPI/VCI address in which case the BPX switch functions as a virtual circuit switch. Or the user may enter only a VPI address in which case all circuits are switched to the same destination port and the BPX switch functions as a virtual path switch in this case. The full ATM address range for VPI and VCI is supported. Virtual Path Connections are identified by an * in the VCI field. Virtual Circuit Connections specify both the VPI and VCI fields.

The VPI and VCI fields have significance only to the local BPX switch, and are translated by tables in the BPX switch to route the connection. Connections are automatically routed by the AutoRoute feature once the connection endpoints are specified.

ATM connections can be added using either the Cisco StrataView Plus Connection Manager or a node's command line interface (CLI). Typically, the Cisco StrataView Plus Connection Manager is the preferred method as it has an easy to use GUI interface. The CLI may be the method of choice in some special cases or during initial node setup for local nodes.

When adding ATM connections, first the access port and access service lines connecting to the customer CPE need to be configured. Also, the trunks across the network need to be configured appropriately for the type of connection. Following that the **addcon** command may be used to add a connection, first specifying the service type and then the appropriate parameters for the connection.

For example, when configuring a BXM for CPE connections, the BXM is configured for port mode, a line is upped with the **upln** command and configured with the **cnfln** command. Then the associated port is configured with the **cnfport** command and upped with the **upport** command. Following this, the ATM connections are added via the **addcon** command with the syntax.

Connection Routing

ATM connections for a BXM or ASI card are identified as follows:

- slot number (in the BPX switch shelf where the BXM or ASI is located)
- port number (one of the ATM ports on the BXM or ASI)
- Virtual Path Identifier (VPI)
- Virtual Circuit Identifier (VCI) – (* for virtual path connections)

The slot and port are related to the BPX switch hardware. Virtual path connections (VPCs) are identified by a "*" for the VCI field. Virtual circuit connections (VCCs) are identified by both a VPI and VCI field.

Connections added to the network are automatically routed once the end points are specified. This AutoRoute feature is standard with all BPX, IGX, and IPX switches. The network automatically detects trunk failures and routes connections around the failures.

Addcon Command Syntax

The following parameters are entered for BXM **addcon** command. Depending upon the connection type, the user is prompted for the appropriate parameters as shown in the following:

```
addcon local_addr node remote_addr traffic_type...extended parameters
```

Field	Value	Description
local/remote_addr	slot.port.vpi.vci	desired VCC or VPI connection identifier
node		slave end of connection
traffic_type		Type of traffic, chosen from CBR, VBR, ABR, and UBR
extended parameters		The traffic management and performance parameters associated with an ATM connection.

Note The range of VPIs and VCIs reserved for PVC traffic and SVC traffic is configurable using the **cnfport** command. While adding connections, the system checks the entered VPI/VPC against the range reserved for SVC traffic. If there is a conflict, the **addcon** command fails with the message "VPI/VCI on selected port is reserved at local/remote end".

ATM Connection Configuration

The following figures and tables describe the parameters used to configure ATM connections:

- Table 7-2, Traffic Policing Definitions.
 - This table describes the policing options that may be selected for ATM connection types: CBR, UBR, and VBR. The policing options for ABR are the same as for VBR.
- Table 7-3, Connection Parameters with Default Settings and Ranges
 - This table specifies the ATM connection parameter ranges and defaults. Not all the parameters are used for every connection type. When adding connections, you are prompted for the applicable parameters, as specified in the prompt sequence diagrams included in Figure 7-3 through Figure 7-10.
- Table 7-4, Connection Parameter Descriptions
 - This table defines the connection parameters listed in Table 7-3.

The following figures list the connection parameters in the same sequence as they are entered when a connection is added:

- Figure 7-3, CBR Connection Prompt Sequence
- Figure 7-4, VBR Connection Prompt Sequence
- Figure 7-5, ATFR Connection Prompt Sequence
- Figure 7-6, ABR Standard Connection Prompt Sequence

The following figure shows the VSVD network segment and external segment options available when ABR Standard or ABR ForeSight is selected. ForeSight congestion control is useful when both ends of a connection do not terminate on BXM cards. At present, FCES (Flow Control External Segment) as shown in Figure 7-7 is not available for ABR with ForeSight.

- Figure 7-7, Meaning of VSVD and Flow Connection External Segments

The following figures list the connection parameters in the same sequence as they are entered when a connection is added:

- Figure 7-8, ABR ForeSight Connection Prompt Sequence
- Figure 7-9, ATFST Connection Prompt Sequence
- Figure 7-10, UBR Connection Prompt Sequence

Table 7-2 Traffic Policing Definitions

Connection Type	ATM Forum TM spec. 4.0 conformance definition	PCR Flow (1st leaky bucket)	CLP tagging (for PCR flow)	SCR Flow (2nd leaky bucket)	CLP tagging (for SCR flow)
CBR	CBR.1 when policing set to 4 (PCR Policing only)	CLP(0+1)	no	off	n/a
CBR	When policing set to 5 (off)	off	n/a	off	n/a
UBR	UBR.1 when CLP setting = no	CLP(0+1)	no	off	n/a
UBR	UBR.2 when CLP setting = yes	CLP(0+1)	no	CLP(0)	yes
VBR, ABR, ATFR, ATFST	VBR.1 when policing set to 1	CLP(0+1)	no	CLP(0+1)	no
VBR, ABR, ATFR, ATFST	VBR.2 when policing set to 2	CLP(0+1)	no	CLP(0)	no
VBR, ABR, ATFR, ATFST	VBR.3 when policing set to 3	CLP(0+1)	no	CLP(0)	yes
VBR, ABR, ATFR, ATFST	when Policing set to 4	CLP(0+1)	no	off	n/a
VBR, ABR, ATFR, ATFST	when Policing set to 5 for off)	off	n/a	off	n/a

Note 1: - For UBR.2, SCR = 0

Note 2:

- CLP = Cell Lost Priority
- CLP(0) means cells that have CLP = 0
- CLP(1) means cells that have CLP = 1
- CLP(0+1) means both types of cells: CLP = 0 & CLP = 1
- CLP(0) has higher priority than CLP(1)
- CLP tagging means to change CLP = 0 to CLP = 1, where CLP= 1 cells have lower priority

Table 7-3 Connection Parameters with Default Settings and Ranges

PARAMETER WITH [DEFAULT SETTING]	BXM T3/E3, OC3 & OC12 RANGE	ASIT3/E3 RANGE	ASI-155 RANGE
PCR(0+1)[50/50]	50- T3/E3 cells/sec 50 - OC3 50 - OC12	T3: MCR – 96000 E3: MCR – 80000 Limited to MCR – 5333 cells/sec for ATFR connections.	OC3 (STM1): 0 – 353200
%Util [100/100] for UBR [1/1]	0 - 100%	1 - 100%	1 - 100%
MCR[50/50]	cells/sec 6 - T3/E3OC3/OC12	T3: 0 – 96000 cells/sec E3: 0 – 80000 cells/sec	N/A
FBTC (AAL5 Frame Base Traffic Control): for VBR [disable] for ABR/UBR [enable] for Path connection [disable]	enable/disable	enable/disable	enable/disable
CDVT(0+1): for CBR [10000/10000], others [250000/250000]	0 - 5,000,000 usec	T3/E3 1 – 250,000 usecs.	OC3/STM1: 0 – 10000 usecs.
VSVD[disable]	enable/disable	enable/disable	Select disable, as only ABR w/o VSVD is supported.
FCES (Flow Control External Segment) [disable]	enable/disable	enable/disable	N/A
Default Extended Parameters[enable]	enable/disable	enable/disable	N/A
CLP Setting[enable]	enable/disable	enable/disable	enable/disable
SCR [50/50]	cells/sec 50 - T3/E3OC3/OC12	T3: MCR – 96000:T3 E3: MCR – 80000: E3 Limited to MCR – 5333 cells/sec for ATFR connections.	OC3/STM1: 0 – 353200
MBS [1000/1000]	1 - 5,000,000cells	T3/E3: 10 – 24000 cells	OC3 (STM1): 10 – 1000 cells
Policing[3] For CBR: [4]	1 - VBR.1 2 - VBR.2 3 - VBR.3 4 - PCR policing only 5 - off	1 - VBR.1 2 - VBR.2 3 - VBR.3 4 - PCR policing only 5 - off	1 - VBR.1 2 - VBR.2 3 - VBR.3 4 - PCR policing only 5 - off

ATM Connection Configuration

Table 7-3 Connection Parameters with Default Settings and Ranges (Continued)

PARAMETER WITH [DEFAULT SETTING]	BXM T3/E3, OC3 & OC12 RANGE	ASIT3/E3 RANGE	ASI-155 RANGE
ICR: max[MCR, PCR/10]	MCR - PCR cells/sec	MCR - PCR cells/sec	N/A
ADTF[1000]	62 - 8000 msec	1000 – 255000 msec.	N/A
Trm[100]	ABRSTD: 1 - 100 msec ABRFST: 3 - 255 msec	20 – 250 msec.	N/A
VC QDepth [16000/16000] For ATFR/ATFST [1366/1366]	0 - 61440 cells	Applies to T3/E3 only ABR: 1 – 64000 cells ATFR: 1 – 1366 cells	ATFR: 1 – 1366 cells
CLP Hi [80/80]	1 - 100%	1 – 100%	N/A
CLP Lo/EPD [35/35]	1 - 100%	1 – 100%	N/A
EFCI [30/30] For ATFR/ATFST [100/100]	1 - 100%	1 – 100%	0 - 100%
RIF: For ForeSight: max[PCR/128, 10]	If ForeSight, then in absolute (0 - PCR)	If ForeSight, then in absolute (0 – PCR)	N/A
For ABR STD[128]	If ABR then 2 ⁿ (1 - 32768)	If ABR, then 2 ⁿ (1 – 32768)	
RDF: For ForeSight [93]	If ForeSight, then % (0% - 100%)	If ForeSight, then % (0% – 100%)	N/A
For ABR STD [16]	If ABR then 2 ⁿ (1 - 32768)	If ABR, then 2 ⁿ (1 – 32768)	
Nrm[32], BXM only	2 - 256 cells	N/A	N/A
FRTT[0], BXM only	0 - 16700 msec	N/A	N/A
TBE[1,048,320], BXM only	0 - 1,048,320 cells (different max range from TM spec. but limited by firmware for CRM(4095 only) where CRM=TBE/Nrm)	N/A	N/A
IBS[1/1]	0 - 24000 cells	T3/E3 ABR: 0 - 24000 cells ATFR: 1 - 107 cells	0 - 999 cells
Trunk cell routing restrict (Y/N) [Y]	Y/N	Y/N	Y/N

Table 7-4 Connection Parameter Descriptions

Parameter	Description
PCR	Peak cell rate: The cell rate which the source may never exceed
%Util	% Utilization; bandwidth allocation for: VBR, CBR, UBR it's PCR*%Util, for ABR it's MCR*%Util
MCR	Minimum Cell Rate: A minimum cell rate committed for delivery by network
CDVT	Cell Delay Variation Tolerance: Controls time scale over which the PCR is policed
FBTC (AAL5 Frame Basic Traffic Control)	To enable the possibility of discarding the whole frame, not just one non-compliant cell. This is used to set the Early Packet Discard bit at every node along a connection.
VSVD	Virtual Source Virtual Destination: (see Meaning of VSVD and Flow Control External Segments, Figure 7-7)
FCES (Flow Control External Segments)	(see Meaning of VSVD and Flow Control External Segments, Figure 7-7)
SCR	Sustainable Cell Rate: Long term limit on the rate a connection can sustain
MBS	Maximum Burst Size: Maximum number of cells which may burst at the PCR but still be compliant. Used to determine the Burst Tolerance (BT) which controls the time scale over which the SCR is policed
Policing	(see definitions of Traffic Policing, Table 7-2)
VC QDepth	VC Queue Depth
CLP Hi	Cell Loss Priority Hi threshold (% of VC QMax)
CLP Lo/EPD	Cell Loss Priority Low threshold (% of VC QMax)/Early Packet Discard. If AAL5 FBTC = yes, then for the BXM card this is the EPD threshold setting. For ASI cards, regardless of the FBTC setting, this is the CLP Lo setting.
EFCI	Explicit Forward Congestion Indication threshold (% of VC QMax)
ICR	Initial Cell Rate: The rate at which a source should send initially and after an idle period
ADTF (ATM Forum TM 4.0 term)	The Allowed-Cell-Rate Decrease Factor: Time permitted between sending RM-cells before the rate is decreased to ICR
Trm (ATM Forum TM 4.0 term)	An upper bound on the time between forward RM-cells for an active source, i.e., RM cell must be sent at least every Trm msec
RIF (ATM Forum TM 4.0 term)	Rate Increase Factor: Controls the amount by which the cell transmission rate may increase upon receipt of an RM cell
RDF (ATM Forum TM 4.0 term)	Rate Decrease Factor: Controls the amount by which the cell transmission rate may decrease upon receipt of an RM cell

ATM Connection Configuration

Table 7-4 Connection Parameter Descriptions (Continued)

Parameter	Description
Nrm (ATM Forum TM 4.0 term), BXM only.	Nrm Maximum number of cells a source may send for each forward RM cell, i.e. an RM cell must be sent for every Nrm-1 data cells
FRTT (ATM Forum TM 4.0 term), BXM only.	Fixed Round Trip Time: the sum of the fixed and propagation delays from the source to a destination and back
TBE (ATM Forum TM 4.0 term), BXM only.	Transient Buffer Exposure: The negotiated number of cells that the network would like to limit the source to sending during start-up periods, before the first RM-cell returns.
IBS	Initial Burst Size
Trunk cell routing restriction (Y/N) [Y]	The default (Y) restricts ATM connection routes to include only ATM trunks. Selecting (N) allows the network to route these connections over non-ATM trunks (e.g., Fastpacket trunks).

CBR Connections

The **CBR** (constant bit rate) category is a fixed bandwidth class. CBR traffic is more time dependent, less tolerant of delay, and generally more deterministic in bandwidth requirements. CBR is used by connections that require a specific amount of bandwidth to be available continuously throughout the duration of a connection. Voice, circuit emulation, and high-resolution video are typical examples of traffic utilizing this type of connection. A CBR connection is allowed to transmit cells at the peak rate, below the peak rate, or not at all. CBR is characterized by peak cell rate (PCR).

The parameters for a CBR connection are shown in Figure 7-3 in the sequence in which they occur during the execution of the **addcon** command. The CBR policing definitions are summarized in Table 7-5.

Figure 7-3 CBR Connection Prompt Sequence




Table 7-5 CBR Policing Definitions

Connection Type	ATM Forum TM spec. 4.0 conformance definition	PCR Flow (1st leaky bucket)	CLP tagging (for PCR flow)	SCR Flow (2nd leaky bucket)	CLP tagging (for SCR flow)
CBR	CBR.1 when policing set to 4 (PCR Policing only)	CLP(0+1)	no	off	n/a
CBR	When policing set to 5 (off)	off	n/a	off	n/a

VBR and ATFR Connections

VBR Connections

VBR (variable bit rate) connections may be classified as rt-VBR or nrt-VBR connections.


The rt-VBR (real-time variable bit rate) category is used for connections that transmit at a rate varying with time and that can be described as bursty, often requiring large amounts of bandwidth when active. The rt-VBR class is intended for applications that require tightly constrained delay and delay variation. An example of rt-VBR is video conferencing which requires real-time data transfer with bandwidth requirements that can vary in proportion to the dynamics of the video image at any given time. The rt-VBR category is characterized in terms of PCR, SCR (sustained cell rate), and MBS (maximum burst size).

The nrt-VBR (non-real time variable bit rate) category is used for connections that are bursty but are not constrained by delay and delay variation boundaries. For those cells in compliance with the traffic contract, a low cell loss is expected. Non-time critical data file transfers are an example of an nrt-VBR connection. A nrt-VBR connection is characterized by PCR, SCR, and MBS.

Configuring VBR connections. The characteristics of rt-VBR or nrt-VBR are supported by appropriately configuring the parameters of the VBR connection.

The parameters for a VBR connection are shown in Figure 7-4 in the sequence in which they occur during the execution of the **addcon** command. The VBR policing definitions are summarized in Table 7-6.

Figure 7-4 VBR Connection Prompt Sequence



- ① For policing prompt:
- 1 = VBR.1
 - 2 = VBR.2
 - 3 = VBR.3
 - 4 = PCR policing only
 - 5 = policing off

Note: BW allocation = (PCR)x(%Util)

10225

Table 7-6 VBR Policing Definitions


Connection Type	ATM Forum TM spec. 4.0 conformance definition	PCR Flow (1st leaky bucket)	CLP tagging (for PCR flow)	SCR Flow (2nd leaky bucket)	CLP tagging (for SCR flow)
VBR, ABR, ATFR, ATFST	VBR.1 when policing set to 1	CLP(0+1)	no	CLP(0+1)	no
VBR, ABR, ATFR, ATFST	VBR.2 when policing set to 2	CLP(0+1)	no	CLP(0)	no
VBR, ABR, ATFR, ATFST	VBR.3 when policing set to 3	CLP(0+1)	no	CLP(0)	yes
VBR, ABR, ATFR, ATFST	when Policing set to 4	CLP(0+1)	no	off	n/a
VBR, ABR, ATFR, ATFST	when Policing set to 5 for off	off	n/a	off	n/a

ATFR Connections

An **ATFR** (ATM to Frame Relay) connection is a frame relay to ATM connection and is configured as a VBR connection, with a number of the ATM and frame relay connection parameters being mapped between each side of the connection.

The parameters for an ATFR connection are shown in Figure 7-5 in the sequence in which they occur during the execution of the **addcon** command.

Figure 7-5 ATFR Connection Prompt Sequence



- ① For policing prompt:
 - 1 = VBR.1
 - 2 = VBR.2
 - 3 = VBR.3
 - 4 = PCR policing only
 - 5 = policing off
- ② VC QDepth maps to VC Queue Max for frame relay
EFCI maps to ECN for frame relay
IBS maps to Cmax for frame relay

Note: FBTC (Frame based traffic control - AAL5, same as FGCR) is automatically set to yes.

56161

ABR Notes

The term ABR is used to specify one of the following:

- ABR standard without VSVD (This is ABR standard without congestion flow control.)
 - Supported by BXM, ASI-T3 (& ASI-E3), and ASI OC3 cards.
- ABR standard with VSVD. (This is ABR standard with congestion flow control as specified by the ATM Traffic Management, Version 4.0)
 - Also, referred to as ABR.1
 - Supported only by BXM cards
 - Feature must be ordered.
- ABR with ForeSight congestion control
 - Also, referred to as ABR.FST
 - Supported by BXM and ASI-T3 (& ASI-E3) cards
 - Feature must be ordered.

ABR and ATFST Connections

ABR Connections

The **ABR** (available bit rate) category utilizes a congestion flow control mechanism to control congestion during busy periods and to take advantage of available bandwidth during less busy periods. The congestion flow control mechanism provides feedback to control the connections flow rate through the network in response to network bandwidth availability. The ABR service is not restricted by bounding delay or delay variation and is not intended to support real-time connections. ABR is characterized by: PCR and MCR.

Policing for ABR connections is the same as for VBR connections which are summarized in Table 7-6.


The ABR connections are configured as either ABR Standard (**ABRSTD**) connections or as ABR ForeSight (**ABRFST**) connections.

The parameters for an ABRSTD connection are shown in Figure 7-6 in the sequence in which they occur during the execution of the **addcon** command.

The ABRSTD connection supports all the features of ATM Standards Traffic Management 4.0 including VSVD congestion flow control.


VSVD and flow control with external segments are shown in Figure 7-7.

Figure 7-6 ABR Standard Connection Prompt Sequence




10226

Figure 7-7 Meaning of VSVD and Flow Control External Segments



VS and VD shown below are for traffic flowing in direction of arrow. For the other direction of traffic, VS and VD are in the opposite direction.




ATFST Connections

The **ABRFST** connection uses the propriety ForeSight congestion control and is useful when configuring connections on which both ends do not terminate on BXM cards.

The parameters for an ABRFST connection are shown in Figure 7-8 in the sequence in which they occur during the execution of the **addcon** command.

Figure 7-8 ABR ForeSight Connection Prompt Sequence



① At present, FCES is not available for ABR with ForeSight


② For policing prompt:
 1 = VBR.1
 2 = VBR.2
 3 = VBR.3
 4 = PCR policing only
 5 = policing off

Note: Bandwidth allocation
 = (MCR)x(%Util)

An **ATFST** connection is a frame relay to ATM connection that is configured as an ABR connection with ForeSight. ForeSight congestion control is automatically enabled when connection type ATFST is selected. A number of the ATM and frame relay connection parameters are mapped between each side of the connection.

The parameters for an ATFST connection are shown in Figure 7-9 in the sequence in which they occur during the execution of the **addcon** command.

Figure 7-9 ATFST Connection Prompt Sequence



- ① For policing prompt:
 - 1 = VBR.1
 - 2 = VBR.2
 - 3 = VBR.3
 - 4 = PCR policing only
 - 5 = policing off

- ② VC QDepth maps to VC Queue max for frame relay.
EFCI maps to ECN for frame relay.
IBS maps to C max for frame relay.

Note: FBTC (Frame based traffic control - AAL5, same as FGCR) is automatically set to yes.

86164

UBR Connections

The unspecified bit rate (**UBR**) connection service is similar to the ABR connection service for bursty data. However, UBR traffic is delivered only when there is spare bandwidth in the network. This is enforced by setting the CLP bit on UBR traffic when it enters a port.

Therefore, traffic is served out to the network only when no other traffic is waiting to be served first. The UBR traffic does not affect the trunk loading calculations performed by the switch software.

The parameters for a UBR connection are shown in Figure 7-10 in the sequence in which they occur during the execution of the **addcon** command.

The UBR policing definitions are summarized in Table 7-7.

Figure 7-10 UBR Connection Prompt Sequence




Table 7-7 UBR Policing Definitions

Connection Type	ATM Forum TM spec. 4.0 conformance definition	PCR Flow (1st leaky bucket)	CLP tagging (for PCR flow)	SCR Flow (2nd leaky bucket)	CLP tagging (for SCR flow)
UBR	UBR.1 when CLP setting = no	CLP(0+1)	no	off	n/a
UBR	UBR.2 when CLP setting = yes	CLP(0+1)	no	CLP(0)	yes

Traffic Policing Examples

Traffic Policing, also known as Usage Parameter Control (UPC), is implemented using either an ATM Forum single or dual-leaky bucket algorithm. The buckets represent a GCRA (Generic Cell Rate Algorithm) defined by two parameters:

- Rate (where I , expected arrival interval is defined as $1/\text{Rate}$)
- Deviation (L)

If the cells are clumped too closely together, they are non-compliant and are tagged or discarded as applicable. If other cells arrive on time or after their expected arrival time, they are compliant, but there is no accrued credit.

Dual-Leaky Bucket (An Analogy)

A GCRA viewpoint is as follows:

- For a stream of cells in an ATM connection, the cell compliance is based on the theoretical arrival time (TAT).
- The next TAT should be the time of arrival of the last compliant cell plus the expected arrival interval (I) where $I = 1/\text{rate}$.
- If the next cell arrives before the new TAT, it must arrive no earlier than new TAT - CDVT to be compliant.
- If the next cell arrives after the new TAT, it is compliant, but there is no accrued credit.

CBR Traffic Policing Examples

CBR traffic is expected to be at a constant bit rate, have low jitter, and is configured for a constant rate equal to Peak Cell Rate (PCR). The connection is expected to be always at peak rate.


When a connection is added, a VPI.VCI address is assigned, and the UPC parameters are configured for the connection. For each cell in an ATM stream seeking admission to the network, the VPI.VCI addresses are verified and each cell is checked for compliance with the UPC parameters. The CBR cells are not enqueued, but are processed by the policing function and then sent to the network unless discarded.

For CBR, traffic policing is based on:


- Bucket 1
 - PCR(0+1), Peak Cell Rate
 - CDVT(0+1), Cell Delay Variation

The CBR connection may be configured with policing selected as either 4 or 5. With policing set to 5, there is no policing. With policing set to 4, there is single leaky bucket PCR policing as shown in Figure 7-11. The single leaky bucket polices the PCR compliance of all cells seeking admission to the network, both those with CLP = 0 and those with CLP = 1. Cells seeking admission to the network with CLP set equal to 1 may have either encountered congestion along the user's network or may have lower importance to the user and have been designated as eligible for discard in the case congestion is encountered. If the bucket depth CDVT (0+1) limit is exceeded, it discards all cells seeking admission. It does not tag cells. If leaky bucket 1 is not full, all cells (CLP = 0 and CLP = 1) are admitted to the network.


Figure 7-11 CBR Connection, UPC Overview



Policing: 4 = PCR Policing only
5 = off



Example: Policing = 4



Discards incoming CLP(0+1) cells if Bkt 1 depth > CDVT(0+1). Does not tag cells.
If Bkt 1 depth < CDVT(0+1), passes CLP=0 and CLP=1 cells on to network.

Note: The notation 0, 1, and 0+1 refers to the types of cell being specified: cells with CLP set to 0, CLP set to 1, or both types of cells, respectively. For example, CLP(0), CLP(1), and CLP(0+1).


S6341

Figure 7-12 shows a CBR.1 connection policing example, with policing set to 4, where the CDVT depth of the single leaky bucket is not exceeded, and all cells, CLP(0) and CLP(1) are admitted to the network.

Figure 7-12 CBR.1 Connection with Bucket Compliant

Connection setup and compliance status:

CBR.1
 policing=4
 Bkt 1 depth < CDVT (0+1)




S6342

Figure 7-13 shows a CBR connection policing example, with policing =4, where the CDVT(0+1) of the single leaky bucket is exceeded and non-compliant cells are discarded. The leaky bucket only discards cells; it does not tag them

Figure 7-13 CBR.1 Connection, with Bucket Discarding non-Compliant Cells

Connection setup and compliance status:

CBR.1
 policing=4
 Bkt 1 depth > CDVT (0+1)



Two CLP(0) cells, 1 and 2, and one CLP(1) cell, 5, are shown as non-compliant at the single Leaky Bkt and are discarded in this example.

S6343

VBR Dual-Leaky Bucket Policing Examples

The contract for a variable bit rate connection is set up based on an agreed upon sustained cell rate (SCR) with allowance for occasional data bursts at a Peak Cell Rate (PCR) as specified by maximum burst size MBS.

When a connection is added, a VPI.VCI address is assigned, and UPC parameters are configured for the connection. For each cell in an ATM stream, the VPI.VCI addresses are verified and each cell is checked for compliance with the UPC parameters as shown in Figure 7-14.

The VBR cells are not enqueued, but are processed by the policing function and then sent to the network unless discarded.

For VBR, traffic policing, depending on selected policing option, is based on:


- Leaky bucket 1, PCR and CDVT
- Leaky bucket 2, SCR, CDVT, and MBS

The policing options, selected by entering 1-5 in response to the policing choice prompt, are as follows for VBR connections:


VBR.1 VBR with policing set to 1.	CLP(0+1) cells compliant with leaky bucket 1 are passed to leaky bucket 2; non-compliant cells are discarded. CLP(0+1) cells compliant with leaky bucket 2 are admitted to the network; non-compliant cells are discarded.
VBR.2 VBR with policing set to 2.	CLP(1) cells compliant with leaky bucket 1 are admitted to the network; non-compliant CLP(0+1) cells are dropped. CLP(0) cells compliant with leaky bucket 1 are applied to leaky bucket 2; non-compliant cells are dropped. CLP(0) cells compliant with leaky bucket 2 are admitted to the network; non-compliant cells are dropped.
VBR.3 VBR with policing set to 3.	CLP(1) cells compliant with leaky bucket 1 are admitted to the network; non-compliant CLP(0+1) cells are dropped. CLP(0) cells compliant with leaky bucket 1 are applied to leaky bucket 2; non-compliant cells are dropped. CLP(0) cells compliant with leaky bucket 2 are admitted to the network; non-compliant cells are tagged and admitted to the network.
VBR with policing set to 4.	CLP(0+1) cells compliant with leaky bucket 1 are admitted to the network; non-compliant cells are dropped. Leaky bucket 2 is not active.
VBR with policing set to 5.	Policing is off, so there is no policing of cells on ingress.

Figure 7-14 VBR Connection, UPC Overview


VBR Traffic



For VBR connections, the first bucket polices PCR compliance within the CDVT(0+1) limits. The second bucket polices compliance in terms of sustained cell rate and data bursts within the BT + CDVT limits.



Example: VBR.2
Policing = 2



S6344

Leaky Bucket 1

Leaky bucket 1 polices for the PCR compliance of all cells seeking admission to the network, both those with CLP = 0 and those with CLP = 1. For example, cells seeking admission to the network with CLP set equal to 1 may have either encountered congestion along the user's network or may have lower importance to the user and have been designated as eligible for discard in the case congestion is encountered. If the bucket depth in the first bucket exceeds CDVT (0+1), it discards all cells seeking admission. It does not tag cells.

With policing set to 1 (VBR.1), all cells (CLP=0 and CLP=1) that are compliant with leaky bucket 1, are sent to leaky bucket 2. With policing set to 2 (VBR.2) or to 3 (VBR.3), all CLP=1 cells compliant with leaky bucket 1 are admitted directly to the network, and all CLP=0 cells compliant with leaky bucket 1 are sent to leaky bucket 2.

Leaky Bucket 2

For VBR connections, the purpose of leaky bucket 2 is to police the cells passed from leaky bucket 1 for conformance with maximum burst size MBS as specified by BT and for compliance with the SCR sustained cell rate. The types of cells passed to leaky bucket 2 depend on how policing is set:

- For policing set to 5, cells bypass both buckets.
- For policing set to 4, leaky bucket 2 sees no traffic.
- For policing set to 2 or 3, the CLP(0) cells are admitted to the network if compliant with BT + CDVT of leaky bucket 2. If not compliant, cells may either be tagged (policing set to 3) or discarded (policing set to 2).
- For policing set to 1, the CLP(0) and CLP(1) cells are admitted to the network if compliant with BT + CDVT of leaky bucket 2. If not compliant, the cells are discarded. There is no tagging option.


Examples

Figure 7-15 shows a VBR connection policing example, with policing set to 4, leaky bucket 1 compliant, and all cells being admitted to the network

Figure 7-15 VBR Connection, Policing = 4, Leaky Bucket 1 Compliant

Connection setup and compliance status:

VBR
 Policing = 4
 Bkt 1 depth < CDVT(0+1)



S6345

Figure 7-16 shows a VBR connection policing example, with the policing set to 4, and leaky bucket 1 non-compliant which indicates that the connection has exceeded the PCR for a long enough interval to exceed the CDVT (0+1) limit. Non-compliant cells with respect to leaky bucket 1 are discarded.

Figure 7-16 VBR Connection, Policing = 4, Leaky Bucket 1 Non-Compliant

Connection setup
and compliance status:

VBR
Policing = 4
Bkt 1 depth > CDVT(0+1)





Figure 7-17 shows a VBR.2 connection policing example, with policing = 2, and both buckets compliant. Leaky bucket two is policing the CLP(0) cell stream for conformance with maximum burst size MBS (as specified by BT), and for compliance with the SCR sustained cell rate.

Figure 7-17 VBR.2 Connection, Policing = 2, with Buckets 1 and 2 Compliant

Connection setup
and compliance status:

VBR.2
Policing = 2
Bkt 1 depth < CDVT(0+1)
Bkt 2 depth < BT + CDVT




S6347

Figure 7-18 shows a VBR.2 connection policing example, with policing set to 2, and leaky bucket 2 non-compliant. Leaky bucket 2 is shown policing the CLP(0) cell stream for conformance with maximum burst size MBS (as specified by BT), and for compliance with SCR (sustained cell rate). In this example (policing set to 2), CLP tagging is not enabled, so the cells that have exceeded the BT + CDVT limit are discarded. In the example, either the sustained cell rate could have been exceeded for an excessive interval, or a data burst could have exceeded the maximum allowed burst size.

Figure 7-18 VBR.2 Connection, Leaky Bucket 2 Discarding CLP (0) Cells

Connection setup and compliance status:

VBR.2
 Policing = 2
 Bkt 1 depth < CDVT(0+1)
 Bkt 2 depth > BT + CDVT



S6348

Figure 7-19 shows a VBR.1 connection policing example, with policing set to 1, and both buckets compliant. Leaky bucket 1 is policing the CLP (0+1) cell stream for conformance with the PCR limit. Leaky bucket 2 is policing the CLP (0+1) cell stream for conformance CDVT plus maximum burst size MBS (as specified by BT), and for compliance with SCR sustained cell rate.

Figure 7-19 VBR.1 Connection, Policing = 1, with Buckets 1 and 2 Compliant

Connection setup
and compliance status:

VBR.1
Policing = 1
Bkt 1 depth < CDVT(0+1)
Bkt 2 depth < BT + CDVT





Figure 7-20 shows a VBR.3 connection policing example, with policing set to 3, and Leaky bucket 2 shown as non-compliant. Leaky bucket 2 is shown policing the CLP(0) cell stream for conformance with maximum burst size MBS (as specified by BT), and for compliance with SCR sustained cell rate. For the policing = 3 selection, CLP tagging is enabled, so the cells that have exceeded the BT + CDVT(0+1) limit are tagged as CLP=1 cells and admitted to the network. In this example, either the sustained cell rate could have been exceeded for an excessive interval, or a data burst could have exceeded the maximum burst size allowed.

Figure 7-20 VBR.3 Connection, Policing = 3, with Bucket 2 non-compliant

Connection setup
and compliance status:

VBR.3
Policing = 3
Bkt 1 depth < CDVT(0+1)
Bkt 2 depth > BT + CDVT



S6350

ABR Connection Policing

Available Bit Rate (ABR) connections are policed the same as the VBR connections, but in addition use either the ABR Standard with VSVD congestion flow control method or the ForeSight option to take advantage of unused bandwidth when it is available.

UBR Connection Policing

The contract for a unspecified bit rate connection is similar to the ABR connection service for bursty data. However, UBR traffic is delivered only when there is spare bandwidth in the network.

When a connection is added, a VPI.VCI address is assigned, and UPC parameters are configured for the connection. For each cell in an ATM stream, the VPI.VCI addresses are verified and each cell is checked for compliance with the UPC parameters as shown in Figure 7-21.



Leaky Bucket 1

Leaky bucket 1 polices the UBR connection for PCR compliance. When CLP=No (UBR.1), all cells that are compliant with leaky bucket 1 are applied to the network. However, these cells are treated with low priority in the network with % utilization default of 1%.


Leaky Bucket 2

When CLP=Yes (UBR.2), CLP(0) cells that are compliant with leaky bucket 1 are sent to leaky bucket 2. Since SCR=0 for leaky bucket 2, the bucket is essentially always full, and all the CLP(0) cells sent to leaky bucket 2 are therefore tagged with CLP being set to 1. This allows the network to recognize these UBR cells as lower priority cells and available for discard in the event of network congestion.

Figure 7-21 UBR Connection, UPC Overview



CLP(0+1) cells to Leaky Bkt 1



Note: The notation 0, 1, and 0+1 refers to the types of cell being specified: cells with CLP set to 0, CLP set to 1, or both types of cells, respectively. For example, CLP(0), CLP(1), and CLP(0+1)

For CLP = Yes, (i.e., UBR.2), CLP(0) cells that were compliant with Leaky Bkt 1 are sent to Leaky Bkt 2. Since SCR = 0 for Leaky Bkt 2, the bucket is essentially always full, and all cells are therefore tagged with CLP being set to 1. This allows the network to recognize these UBR cells as lower priority and available for discard in the event of network congestion.

S6351


Traffic Shaping for CBR, VBR, and UBR

With the introduction of traffic shaping for CBR, VBR, and UBR, the user has the option to provide traffic shaping for these connections types on the BXM. Previously, only ABR utilized traffic shaping. Traffic shaping involves passing CBR, VBR, or UBR traffic streams through VC queues for scheduled rate shaping.

Traffic shaping is performed on a per port basis. When traffic shaping is enabled, all traffic exiting the port (out to the network) is subject to VC scheduling based on the parameters configured by the user for the connection.

Figure 7-22 shows an example of traffic shaping. In this example, port 1 is configured to perform traffic shaping. Note that all the ATM cells regardless of class of service pass through the VC queues before leaving the card when traffic shaping is enabled. In the example, port 2 is not configured for traffic shaping, and only the ABR traffic with FCES (flow control external segment) passes through the VC queues.

Figure 7-22 Traffic Shaping Example



Configuration

Traffic shaping is disabled by default. The **cnfport** command is used to enable and disable the function on a per port basis. No connections should be enabled on the port prior to changing the port traffic shaping parameter. If there are existing connections when the port is toggled, then these connections will not be updated unless the card is reset, connections are rerouted, a switchcc occurs, or the user modifies the connection parameters.

Traffic Shaping Rates

Traffic shaping rates are listed in Table 7-8.

Table 7-8 Traffic Shaping Rates

Service Type	MCR	PCR
CBR	PCR	PCR
VBR	SCR * %Util	PCR
UBR	0	PCR
ABR	MCR * % Util	PCR

LMI and ILMI Parameters

The following is a listing of the LMI and ILMI parameters for the ASI and BXM:

For ILMI information, refer to Table 7-9.

Table 7-9 ILMI Parameters

Parameter	Description
VPI.VCI	VCCI for ILMI signaling channel equal 0.16
Polling Enabled	Keep-alive polling
Trap Enabled	VCC change of state traps
Polling Interval	Time between GetRequest polls
Error Threshold	Number of failed entries before ILMI link failure is declared.
Event Threshold	Number of successful polls before ILMI link failure is cancelled.
Addr Reg Enab	SVC Address Registration procedures enabled.

For the LMI information, refer to Table 7-10.

Table 7-10 LMI Parameters

Parameter	Description
VPI.VCI	VCCI for LMI signaling channel equal 0.31
Polling Enable	Keep-alive polling
T393	Status Enquiry timeout value
T394	Update Status timeout value
T396	Status Enquiry polling timer
N394	Status Enquiry retry count
N395	Update Status retry count

ATM and Frame Relay SVCs, and SPVCs

This chapter provides a brief overview of switched virtual circuits and soft permanent virtual circuits with respect to the BPX switch and co-located Extended Services Processor. For additional information, refer to the *Cisco WAN Service Node Extended Services Processor Installation and Operation Release 2.2* document.

This chapter contains the following:

- ATM and Frame Relay SVCs and SPVCs
- BPX Switch and ESP Interfaces
- Signaling Plane
- Network Interworking Between Frame Relay and ATM
- Extended Services Processor
- Network Management
- Resource Partitioning

ATM and Frame Relay SVCs and SPVCs

With a co-located Extended Services Processor (ESP), the BPX switch adds the capability to support ATM and Frame Relay switched virtual circuits (SVCs) in addition to support for permanent virtual circuits (PVCs) as shown in Figure 8-1.

The Private Network to Network Interface (PNNI) protocol is used to route SVCs across the network. PNNI provides a dynamic routing protocol which is responsive to changes in network availability and will scale to large networks.


BPX switch resources, such as port VPI range and trunk bandwidth are partitioned between SVCs and PVCs. This provides a firewall between the two types of connections so that any SVCs that come on-line and off-line do not affect the availability of existing PVC services.

The following connections are supported with Release 9.1:

- Frame Relay SVC connections between Frame Relay end users over an ATM network (Network Interworking)
- ATM SVC connections between ATM end users
- SPVCs

The ESP provides the BPX switch with the ATM or Frame Relay signaling function. It interprets industry-standard signaling messages from ATM or Frame Relay CPE to provide the call setup and tear down for switched virtual circuits across the ATM network. In addition to SVC signaling, the ESP also performs PNNI routing, collects statistics, and processes alarms and billing records for SVC connections through the BPX switch.

Figure 8-1 Wide Area Network with BPX Switch and ESP



PVCs and SVCs

Both permanent virtual circuits and switched virtual circuits are defined by ATM and Frame Relay standards groups.

PVCs

After being added to a network, permanent virtual circuits (PVCs) remain relatively static. The PVC only allocates a physical circuit and consumes bandwidth when there is data to send. However, the permanent virtual circuit remains in place, always available for use, and is similar to a dedicated private line in this respect.

SPVCs

Soft permanent virtual circuits (SPVCs) are PVCs which are routed using the Private Network-Network Interface (PNNI) routing protocol. The “permanent” qualifier indicates that the virtual connection is established administratively, through an operator’s command, rather than on demand by signaling. A soft PVC is one where the establishment within the network is done by the ESP signaling (in this case, PNNI signaling), just as it is done for Frame Relay and ATM switched virtual circuits.

In the PNNI network, SPVC connections are established using the best available route. During a network failure, SPVC connections could be rerouted and the newly selected path may not be the optimal route. The ESP’s SPVC feature provides for auto-grooming of SPVCs. Auto-grooming is a background management process that evaluates SPVC connections; if a better path for the connection is found, the SPVC will be released and rerouted to the optimized path.

Refer to the *Cisco WAN Service Node Extended Services Processor Installation and Operation for Release 2.2* document for detailed information about SPVCs.

SVCs

A switched virtual circuit (SVC) only exists when there is data to send and a calling process has been initiated. With a switched virtual circuit, there must be some signaling mechanism to build a connection each time the user (ATM or Frame Relay device in this case) needs it. In addition, when the call is disconnected, there must be a mechanism for the orderly disconnection of the call, and the network's resources must be relinquished. During a disconnect, the Cisco StrataCom network sweeps through its connection tables and removes the connection.

ATM SVCs are ATM connections setup and maintained by a standardized signaling mechanism between ATM CPE (ATM user end systems) across a Cisco StrataCom network. ATM SVCs are created on user demand and removed when the call is over, thus freeing up network resources.

Frame Relay SVCs are Frame Relay connections setup and maintained by a standardized signaling mechanism between Frame Relay CPE (Frame Relay user end systems) across a Cisco StrataCom network. Frame Relays SVCs are created on user demand and removed when the call is over, thus freeing up network resources.

BPX Switch and ESP Interfaces

The BPX switch supports the UNI and NNI interfaces for SVC operations as described in the following:

- UNI, that is the User Network Interface, is the interface for either ATM or Frame Relay customer premise equipment (CPE) to the BPX switch. The UNI is defined as any interface between a user device and an ATM network (i.e., an ATM switch). The UNI defines the signaling method which the CPE must use to request and setup SVCs through the wide-area ATM network. In addition, the UNI is used to send messages from the network to the CPE (i.e., user device) on the status of the circuit and rate control information to prevent network congestion.

For ATM SVCs, the UNI supports either the ATM Forum 3.0 or 3.1 signaling standards as well as traditional ATM PVCs. (Remember the BPX switch also supports high-speed ATM UNI ports.)

For Frame Relay, the UNI supports Frame Relay Forum Frame Relay User-to-Network SVC Implementation Agreement (FRF.4), which specifies the Frame Relay SVC signaling protocols. BPX switch Frame Relay UNIs (FRSMs) also support traditional Frame Relay PVCs.

- Network-to-Network Interface (NNI). The NNI is the interface to other BPX switch or foreign ATM Switches. The BPX switch supports Interim Inter-switch Protocol (IISP) 3.0 /3.1 or the Private Network to Network Interface (PNNI). These NNI interfaces provide the switching and routing functions between Cisco StrataCom wide-area networks and other networks. Information passing across a NNI is related to circuit routing and status of the circuit in the adjacent network. (Note that NNI could refer to both a connection between a BPX switch with ESP, and a connection between a BPX switch with ESP and a foreign switch.)

Interim Inter-switch Protocol Routing

Interim Inter-switch Protocol (IISP) is an interim static routing protocol defined by the ATM Forum to provide base level capability until the Private Network to Network Interface (PNNI) was specified. The IISP provides users with some level of multi-vendor switch interoperability based on the existing ATM Forum UNI 3.1 specifications. IISP assumes no exchange of routing information between switching systems. It uses a fixed routing algorithm with static routes. Routing is done on a hop-by-hop basis by making a best match of the destination address in the call setup with address entries in the next hop routing table at a given switching system. Entries in the next hop routing table are configured by the user.

PNNI

The Private Network to Network Interface standards essentially define two protocols:

- Topology

The Private Network to Network Interface (PNNI) defines a protocol for distributing topology information between switches and clusters of switches. This information is used to compute paths through the network. A key feature of the PNNI mechanism is its ability to automatically configure itself in networks in which the address structure reflects the topology. PNNI topology and routing are based on the well-known link-state routing technique.


- Signaling

PNNI also defines a second protocol for signaling, that is message flows used to establish point-to-point connections across the ATM network. This protocol is based on the ATM Forum UNI signaling, with mechanisms added to support source routing, crankback, and alternate routing of call setup requests in case of connection setup failure.

Signaling Plane

To support ATM and Frame Relay SVCs, the BPX switches essentially overlay a signaling network over a traditional (that is PVC-based) network. This signaling network, indicated by the dashed lines in Figure 8-2, connects all of the BPX switches with ESP and extends to the CPE. The signaling plane establishes and maintains SVCs between the CPE, that is, end users, across a Cisco StrataCom wide-area ATM network.

Figure 8-2 BPX Switch with ESP Network Signaling Plane



The signaling plane is created out of two basic types of signaling channels:

- User to Network Interface (UNI) signaling channels.
- Network to Network Interface (NNI) signaling channels.


The signaling VCCs are normally configured during the provisioning of UNI ports and NNI trunks.

UNI Signaling Channel

There is an internal signaling VCC established between every UNI port on the BPX switch which will support ATM or Frame Relay SVCs and the ESP in the BPX switch. There are two types of UNI signaling channels supported by the BPX switch as shown in Figure 8-3.

- **ATM UNI**—For ATM CPE, these UNI VCCs extend from an ATM UNI port to the ESP. This is either a one segment cross-connect between the BXM (or ASI) attached to the ATM CPE and the BXM attached to the ESP within the BPX switch, or a two segment VCC from the MGX 8220 AUSM port connected to ATM CPE and the BXM attached to the ESP within the BPX switch. (Note that VPI 0 and VCI 5 are reserved on the ATM UNI port for ATM SVC signaling channels. The ILMI signaling channel will use VPI 0 and VCI 16, and the PNNI signaling channel will use VPI 0 and VCI 18.)
- **Frame Relay UNI**—For Frame Relay CPE, there will always be a two segment VCC between the MGX 8220 FRSM port connected to the ATM CPE and the BXM attached to the ESP within the BPX switch. (Note that DLCI 0 is reserved on the Frame Relay UNI port for Frame Relay SVC signaling channels.)


Figure 8-3 UNI Signaling Channels



NNI Signaling Channel

There is also a signaling channel established between each adjacent pair of BPX switches. This NNI signaling channel shown in Figure 8-4 is configured for either IISP or PNNI protocol. During IISP configuration, one side of the NNI signaling connection is configured as the user side and a weight is assigned. In the figure, the direct line between the ATN NICs indicates a logical connection; the physical connection is configured through BPX switch 1 and BPX switch 2.

Figure 8-4 ESP Signaling PVC



Network Interworking Between Frame Relay and ATM

Because the BPX switch is an ATM switch, Frame Relay SVCs that are setup and established across the Cisco StrataCom network must be translated into an ATM format to be carried across the network. At the far end, where typically the connection is terminated on another Frame Relay CPE, the ATM cells will have to be converted back to Frame Relay format. This is referred to as Network Interworking. Network Interworking can be performed between Frame Relay CPE and ATM CPE when the ATM CPE recognizes that it is connected to an interworking function (Frame Relay, in this case). The ATM CPE must then exercise the appropriate service specific convergence sublayer (SSCS). The SSCS will then convert the ATM cells to Frame Relay traffic.

In this release of the BPX switch with ESP, all Frame Relay SVC connections must be between Frame Relay CPE (that is, Frame Relay end users) or ATM CPE that is aware that it is performing Network Interworking, and all ATM SVC connections must be between ATM CPE (that is ATM end users). In other words, Service Interworking between ATM and Frame Relay SVCs is not supported in this release. (ATM and Frame Relay Service Interworking for PVCs is supported by the BPX switch.)

Extended Services Processor

The Extended Services Processor (ESP) is an adjunct processor shelf integrated into the BPX switch.

The basic ESP features include:

- 140 MIPS CPU, with a 143Mhz clock
- 128 Megabytes of memory
- 4 Gigabyte hard disk


Available in either AC- or DC-powered models (ESP-AC or ESP-DC), the ESP is an orderable option for the BPX switch. The ESP can be configured in both non-redundant and redundant configurations. For the redundant configuration, two ESPs are installed in the BPX switch.

ESP Interfaces

The ESP uses three main physical interfaces, as shown in Figure 8-5:

- **Terminal port** for the direct connection of a terminal, such as a VT-100, to provide access for local configuration and to act as a console.
- **10Base-T Ethernet port** for connection to the Cisco StrataView Plus Workstation and to the BPX switch. Telnet or XTERM sessions can be established through the Ethernet port, and perform the same functions as can be performed with a directly connected terminal.
- **ATM Network Interface Card (ATM NIC)** for connection to the BPX switch. The ATM NIC is typically connected to a BPX switch BXM card using OC-3 multimode fiber connection with SC connectors. There are optional cables with built-in optical attenuation that allow BXM single mode fiber (SMF) backcards to be connected to the ESP ATM NIC.

Figure 8-5 ESP Physical Interfaces



The ESP also provides the following application interfaces:

- **SNMP** to configure and monitor the ESP.
- **TFTP** (trivial file transfer protocol) for uploading statistics, Call Detail Records (CDRs), and downloading configuration files and new software releases and revisions.
- **Telnet** for accessing the ESP remotely, such as from the Cisco StrataView Plus Workstation.

Stand-Alone ESP

A single ESP controlling a WAN Service Node, such as is shown in Figure 8-5, operates in the StandAlone mode. In the StandAlone mode there is no redundancy for a failed ESP. During the initial installation of a ESP, it can be configured as either Primary or Secondary but must be configured to operate in StandAlone mode.

When a second ESP is added to a single ESP operating in StandAlone mode, you must change the operating mode of a StandAlone ESP to Active or Standby mode.

Redundant ESPs

As shown in Figure 8-6, ESPs can be installed in redundant pairs in the WAN Service Node. In a redundant pair, one ESP is active, that is it controls the switched services in the WAN Service Node, and the other ESP is standby. The redundant ESPs are known as peers. The ESPs will switch roles from active to standby and vice versa under the following conditions:


- Controlled switchover invoked from the active ESP Configuration Interface.
- The active ESP detects a major service affecting failure, such as a BPX switch polling failure or an ATM NIC card failure, and relinquishes the active role, by going Out of Service.
- The standby ESP detects that the inter-ESP paths have failed and assumes the active role.

Note During a switchover, all SVC connections will be torn down and the ATM or Frame Relay CPE will have to initiate another SVC call to reestablish them. During a switchover, all SPVC calls when be released, but when the standby ESP becomes active, it will reestablish the SPVCs.

Each ESP determines its role by means of Role Resolution protocol, which exchanges messages between the two units at startup. Both the active ESP and the standby ESP monitor its role and connectivity, and if appropriate, automatically switchover (that is, switch roles from active to Out of Service and from standby to active) with the peer ESP.

The redundant ESPs need to synchronize their database so that when the active ESP has gone out of service, the standby unit can take over and resume the service. There are two types of update mechanisms for synchronizing ESP databases. These are the bulk and real-time updates. The bulk update is used to synchronize a standby ESP with an active unit whenever it is restarted. The real-time updates are those messages that are exchanged after ESPs are synchronized and while both the active and standby ESPs are communicating.


Figure 8-6 ESP Redundant Pair



Y-Cable Redundancy

The WAN Service Node provides another form of ESP redundancy protection through the use of Y-cables. With Y-cables, the ESP ATM NIC can be connected to two BXM cards or two BXM ports, as shown in Figure 8-7. This prevents the failure of a BXM card or port from disabling the ESP.

Figure 8-7 ESP Y-Cable Redundancy



Other Redundancy Options

Figure 8-7 illustrates only a single ESP-to-BXM redundancy option. There are four ESP-to-BXM redundancy options possible:

- 1 A single ESP with a Y-cable to redundant BXMs.
- 2 Two ESPs (a redundant pair), each attached to a single port on a single BXM.
- 3 Two ESPs (a redundant pair), each attached to a single port on two separate (redundant) BXMs.
- 4 Two ESPs (a redundant pair), each attached to different ports with Y-cables on two separate (redundant) BXMs.

Y-cables are for connecting the ESP's ATM Network Interface Card to redundant BXMs. They do not necessarily indicate that the ESP is connected in the redundant pair configuration (that is, an active and standby ESP). The Cisco WAN Service Node Extended Services Processor Installation and Operation document contains further information about ESP Y cables.

Network Management

As shown in Figure 8-5, the BPX switch can have an Ethernet LAN connection to a Cisco StrataView Plus Workstation. Cisco StrataView Plus discovers and monitors the ESP similarly to the way it does an MGX 8220 interface shelf. Cisco StrataView Plus discovers the existence of the ESP when it is added to the BPX switch with the **addshelf** command. After discovery, the ESP will be displayed on the Cisco StrataView Plus topology map as a shelf attached to the BPX switch.

Cisco StrataView Plus manages the BPX switch by providing:

- Telnet access to the ESP Configuration Interface.
- Configuration backup and restore
- Image download allows the user to select an ESP from the topology map and then select Image Download from a pull-down menu. A dialog screen displays the list of available image files and prompts the user to select a file. The selected file is sent to the ESP.

Resource Partitioning

During provisioning, resources on all UNI ports (both ATM and Frame Relay) are partitioned between SVCs and PVCs. Partitioning is performed using the BPX switch and MGX 8220 command line interfaces. This partitioning information is retrieved from the BPX switch by reading its port and trunk tables and from the MGX 8220 by reading the resource partitioning tables in the AUSM and FRSM MIBs.

The BPX switch line and routing or feeder trunk resources to be partitioned are:

- LCN range
- VPI range
- Port Queues
- Egress Queue pool size
- Bandwidth

MGX 8220 Feeder Trunk (BXM/BNI) resources to be partitioned are:

- LCN range
- Bandwidth

MGX 8220 AUSM port resources to be partitioned are:

- LCN range
- VPI range

MGX 8220 FRSM port resources to be partitioned are:

- LCN range
- DLCI range

Tag Switching

This chapter contains an overview of tag switching and instructions for configuring the BPX 8650 for the tag switching feature:

This chapter contains the following:

- Introduction
- Tag Switching Benefits
- Tag Switching Overview
- Elements in a Tag Switching Network
- Tag Switching Operation at Layer 3
- Tag Switching in an ATM WAN
- Tag Switching and the BPX 8650
- Tag Switching Resource Configuration Parameters
- Requirements
- List of Terms
- Related Documents
- Configuration Management
- Configuration Example
- Checking and Troubleshooting
- Provisioning and Managing Connections
- Statistics
- Command Reference

Introduction

Tag switching enables routers at the edge of a network to apply simple tags to packets (frames), allowing devices in the network core to switch packets according to these tags with minimal lookup activity. Tag switching in the network core can be performed by switches, such as ATM switches, or by existing routers.

Tag Switching Benefits

For multi-service networks, tag switching enables the BPX switch to provide ATM, frame relay, and IP Internet service all on a single platform in a highly scalable way. Support of all these services on a common platform provides operational cost savings and simplifies provisioning for multi-service providers.

For internet service providers (ISPs) using ATM switches at the core of their networks, tag switching enables the Cisco BPX 8600 series and the Lightstream 1010 ATM switches to provide a more scalable and manageable networking solution than just overlaying IP over an ATM network. Tag switching avoids the scalability problem of too many router peers and provides support for a hierarchical structure within an ISP's network, improving scalability and manageability.

By integrating the switching and routing functions, tag switching combines the reachability information provided by the router function with the traffic engineering optimizing capabilities of the switches.

When integrated with ATM switches, tag switching takes advantage of switch hardware that is optimized to take advantage of the fixed length of ATM cells, and to switch these cells at wire speeds.

Tag Switching Overview

Tag switching is a high-performance, packet (frame) forwarding technology. It integrates the performance and traffic management capabilities of data link layer 2 with the scalability and flexibility of network layer 3 routing.

Tag switching enables switch networks to perform IP forwarding. It is applicable to networks using any layer 2 switching, but has particular advantages when applied to ATM networks. It integrates IP routing with ATM switching to offer scalable IP-over-ATM networks.

Tag switching is based on the concept of label switching, in which packets or cells are assigned short, fixed length labels. Switching entities perform table lookups based on these simple labels to determine where data should be forwarded.

In conventional layer 3 forwarding, as a packet traverses the network, each router extracts all the information relevant to forwarding from the layer 3 header. This information is then used as an index for a routing table lookup to determine the packet's next hop. This is repeated at each router across a network.

In the most common case, the only relevant field in the header is the destination field. However, as other fields could be relevant, a complex header analysis must be done at each router through which the packet travels.

In tag switching the complete analysis of the layer 3 header is performed just once, at the tag edge router at each edge of the network. It is here that the layer 3 header is mapped into a fixed length label, called a tag.

At each router across the network, only the tag needs to be examined in the incoming cell or packet in order to send the cell or packet on its way across the network. At the other end of the network, a tag edge router swaps the label out for the appropriate header data linked to that label.

Elements in a Tag Switching Network

The basic elements in a tag switching network are tag edge routers, tag switches, and a tag distribution protocol as defined in the following:

- Tag edge routers

Tag edge routers are located at the boundaries of a network, performing value-added network layer services and applying tags to packets. These devices can be either routers, such as the Cisco 7500, or multilayer LAN switches, such as the Cisco Catalyst 5000.

- Tag switches

These devices switch tagged packets or cells based on the tags. Tag switches may also support full Layer 3 routing or Layer 2 switching in addition to tag switching. Examples of tag switches include the Cisco LightStream 1010, Cisco BPX 8650, Cisco 7500, and future gigabit router systems from Cisco.

- Tag distribution protocol

The tag distribution protocol (TDP) is used in conjunction with standard network layer routing protocols to distribute tag information between devices in a tag switched network.

Tag Switching Operation at Layer 3

Tag switching operation comprises two major components:

- Forwarding
- Control

Forwarding

The forwarding component is based on label swapping. When a tag switch (or router in a packet context) receives a packet with a tag, the tag is used as an index in a Tag Forwarding Information Base (TFIB). Each entry in the TFIB consists of an incoming tag and one or more sub-entries of the form

`<outgoing tag, outgoing interface, outgoing link level information>`

For each sub-entry, the tag switch replaces the incoming tag with the outgoing tag and sends the packet on its way over the outgoing interface with the corresponding link level information.


Figure 9-1 shows an example of tag switching. It shows an untagged IP packet with destination 128.89.25.4 arriving at Router A (RTA). RTA checks its TFIB and matches the destination with prefix 128.89.0.0/16. (The /16 denotes 16 network masking bits per the Classless Interdomain Routing (CIDR) standard.) The packet is tagged with an outgoing tag of 4 and sent toward its next hop RTB. RTB receives the packet with an incoming tag of 4 that it uses as an index to the TFIB. The incoming tag of 4 is swapped with outgoing tag 9, and the packet is sent out over interface 0 with the appropriate layer 2 information (e.g., MAC address) according to the TFIB. RTB did not have to do any prefix IP lookup based on the destination as was done by RTA. Instead, RTB used the tag information to do the tag forwarding. When the packet arrives at RTC, it removes the tag from the packet and forwards it as an untagged IP packet.

Control

The control component consists of tag allocation and maintenance procedures. The control component is responsible for creating tag bindings between a tag and IP routes, and then distributing these tag bindings to the tag switches.

The tag distribution protocol (TDP) is a major part of the control component. TDP establishes peer sessions between tag switches and exchanges the tags needed by the forwarding function.

Figure 9-1 Tag Forwarding Information Base (TFIB) in an IP Packet Environment



Tag Switching in an ATM WAN


With tag switching over an ATM network, the forwarding and control components can be described as follows:

- **Forwarding:** In an ATM environment, the tag switching forwarding function is carried out identically to normal switching. The tag information needed for tag switching can be carried in the VCI field within one or a small number of VPs. The tags are actually the VCIs.
- **Control:** For the control component over ATM networks, a tag distribution protocol is used to bind VCIs to IP routes. The switch also has to participate in IP routing protocols such as OSPF, BGP, and RSVP.

Forwarding

Figure 9-2 shows the forwarding operation of an ATM switch in which the tags are designated VCIs. In Figure 9-2, an untagged IP packet with destination 128.89.25.4 arrives at router A (RTA). RTA checks its TFIB and matches the destination with prefix 128.89.0.0/16. RTA converts the AAL5 frame to cells, and sends the frame out as a sequence of cells on VCI 40. RTB, which is an ATM Tag Switch Router (TSR) controlled by a routing engine, performs a normal switching operation by switching incoming cells on interface 2/VCI 40 to interface 0/VCI 50

Figure 9-2 Tag Forwarding Information Base (TFIB) in an ATM Environment



Control

ATM-TSRs use the downstream-on-demand allocating mechanism. Each ATM-TSR maintains a forwarding information base (FIB) that contains a list of all IP routes that the ATM-TSR uses. This function is handled by the routing engine function which is either embedded in the switch or runs on an outside controller. For each route in its forwarding information base, the ATM Edge TSR identifies the next hop for a route. It then issues via TDP a request to the next hop for a tag binding for that route.

When the next hop ATM-TSR receives the route, it allocates a tag, creates an entry in its TFIB with the incoming tag changed to the allocated outgoing tag. The next action depends on whether the tag allocation is in an optimistic mode or a conservative mode. In optimistic mode, it will immediately return the binding between the incoming tag and the route to the TSR that sent the request. However, this may mean that it is not immediately able to forward tagged packets which arrive, as the ATM-TSR may not yet have an outgoing tag/VCI for the route. In conservative mode, it does not immediately return the binding, but waits until it has an outgoing tag.

In optimistic mode, the TSR that initiated the request receives the binding information, it creates an entry in its TFIB, and sets the outgoing tag in the entry to the value received from the next hop. The next hop ATM TSR then repeats the process, sending a binding request to its next hop, and the process continues until all tag bindings along the path are allocated.


In conservative mode, the next hop TSR sends a new binding request to its next hop, and the process repeats until the destination ATM edge TSR is reached. It then returns a tag binding to the previous ATM-TSR, causing it to return a tag binding, and so on until all the tag bindings along the path are established.

Figure 9-3 shows an example of conservative allocation. ATM edge TSR RTA is an IP routing peer to ATM-TSR RTB. In turn, ATM-TSR RTB is an IP routing peer to ATM-TSR-RTC. IP routing updates are exchanged over VPI/VCI 0/32 between RTA-RTB and RTB-RTC. For example:

- 1 RTA sends a tag binding request toward RTB in order to bind prefix 128.89.0.0/16 to a specific VCI.
- 2 RTB allocates VCI 40 and creates an entry in its TFIB with VCI 40 as the incoming tag.
- 3 RTB then sends a bind request toward RTC.
- 4 RTC issues VCI 50 as a tag.
- 5 RTC sends a reply to RTB with the binding between prefix 128.89.0.0/16 and the VSI 50 tag.
- 6 RTB sets the outgoing tag to VCI 50.
- 7 RTB sends a reply to RTA with the binding between prefix 128.89.0.0/16 and the VCI 40 tag.
- 8 RTA then creates an entry in its TFIB and sets the outgoing tag to VCI 40.

Optimistic mode operation is similar to that shown in Figure 9-3, except that the events labeled 7 and 8 in the figure may occur concurrently with event 3.

Figure 9-3 Downstream on Demand Tag Allocation, Conservative Mode Shown



S6675

Tag Switching and the BPX 8650

With tag switching the router function can be accomplished by either integrating the routing engine into the switch or by using a separate routing controller (associated router). The BPX 8650 tag switch combines a BPX switch with a separate router controller (Cisco Series 7200 or 7500 router). This has the advantage of separating the various services (e.g., AutoRoute, SVCs and tag switching) into separate logical spaces that do not interfere with one another. Figure 9-4 shows two scenarios, one in which the IP packets are applied to the network via the edge routers (either part of the BPX 8650 Tag Switches or independent 7500 Tag Edge Routers), and the other where IP packets are routed via a BPX 8620 to a BPX 8650 via Frame Relay permanent virtual circuits (PVCs).


Example 1: An IP packet is applied to the network via BPX 8650s on the edge of the network and then tag switching is used to forward the packet across the network via BPX 8650s. In this example the shortest path is not used, but rather the tag switch connection is routed across BPX 8650 TS-A, BPX 8650 TS-B, BPX 8650 TS-C, BPX 8650 TS-D, and 7500 TER-S. This particular routing path might, for example, have been selected with administrative weights set by the network operator. The designated tags for the cells transmitted across the network in this example are shown as 40, 60, 70, and 50, respectively. The router component of the tag switches that are located at the boundaries of the network (BPX 8650 TS-A, BPX 8650 TS-C, BPX 8650 TS-H), perform edge-routing network layer services including the application of tags to incoming packets. The tag edge routers, 7500 TER-S, 7500 TER-T, and 7500 TER-U, perform the same edge-routing network layer services in this example.

Example 2: An IP packet is routed to BPX 8650 TS-H at the interior of the network via BPX 8620 switch-F, using a Frame Relay PVC. The BPX switch interface for a Frame Relay PVC might be an MGX 8220 as shown. The applicable Frame Relay interface for BPX 8650 TS-H is connected via cable to a Frame Relay interface on its TSC where tag switching is performed on the incoming IP packet. The designated tag switching cells are shown with an tag designation of 12. These tag switching cells are then forwarded to BPX 8650 TS-D where they are converted back to an IP packet and routed to the CPE at the edge of the network as a Frame Relay PVC via an MGX 8220.


Tag Edge Router functionality is necessary to add and remove tags from IP packets, but not to switch tagged packets. Figure 9-4 shows 3 stand-alone Tag Edge Routers (TERs). These would typically be co-located with BPX 8650 Tag Switches in Points of Presence. However the Tag Switch Controller in a BPX 8650 can also act as a TER if required.

In Figure 9-4, Tag Switches A, C, D and H use this combined Tag Switch/Tag Edge Router functionality. Only Tag Switch B acts purely as a Tag Switch. Note also that the Tag Edge Router performance of a BPX 8650 Tag Switch is significantly lower than its Tag Switching performance. Typically there will be several Tag Edge Routers (or combined TSC/TERs) for each BPX Tag Switch.


Figure 9-4 BPX Tag Switching



Note 1:




Tag Switch Controller (7200 or 7500)



BPX switch

BPX 8650 Tag Switch

Note 2:



BPX 8620 switch

Note 3:



MGX 8220

Note 4:




7500 Tag edge router

Virtual Switch Interfaces

Figure 9-5 shows how virtual switch interfaces are implemented by the BPX switch in order to facilitate tag switching. A virtual switch interface (VSI) provides a standard interface so that a resource in the BPX switch can be controlled by additional controllers other than the BPX controller card such as a tag switch controller.

The tag switch controller is connected to the BPX switch using ATM T3/E3/OC3 interfaces on the TSC device (a 7200 or 7500 series router) and on a BXM card. The ATM OC3 interface on the 7200 router is provided by an ATM port adapter, on the 7500 router by an AIP or a VIP with ATM Port Adapter, and for the BXM front card by an ATM OC3 4-port or 8-port back card.

Figure 9-5 BPX Switch VSI Interfaces



A distributed slave model is used for implementing VSI in a BPX switch. Each BXM in a BPX switch is a VSI slave and communicates with the controller and other slaves, if needed when processing VSI commands. The VSI master sends a VSI message to one slave. Depending on the command, the slave either handles the command entirely by itself, or communicates with a remote slave to complete the command. For example, a command to obtain configuration information would be processed by one slave only. A command for connection setup would cause the local slave to communicate with the remote slave in order to coordinate with both endpoints of the connection.

Figure 9-6 shows a simplified example of a connection setup with endpoints on the same slave (BXM VSI), and an example of a connection setup with endpoints on different slaves (BXM VSIs) is shown in Figure 9-7.

Figure 9-6 Connection Setup, End Points on same VSI Slave





Figure 9-7 Connection Setup, End Points on Different VSI Slaves



Tag Switching Resource Configuration Parameters

This section describes resource partitioning for tag switching. It includes the following:

- Summary
- Configuring VSI LCNS
- Useful Default Allocations
- Details of More Rigorous Allocations

Summary

Most tag switching configuration, including the provisioning of connections, is performed directly by the Tag Switch Controller. This is discussed separately; refer to the *Tag Switching for the Cisco 7500/7200 Series Routers* documentation. Configuration for tag switching on the BPX 8650 itself, consists of basic VSI configuration, including resource partitioning.

The following items need to be configured or checked on the BPX 8650:

- Partitioning

On each interface (port or trunk) on the BXM cards used for tag switching, two sets of resources must be divided up between traditional PVC connections and tag switching connections. The traditional PVC connections are configured directly on the BPX platform, and tag switching connections are set up by the TSC using the VSI. The following resources are partitioned on each interface:

- Bandwidth
- Connections

As with all ATM switches, the BPX switch supports up to a specified number of connections. On the BPX switch, the number of connections supported depends on the number of port/trunk cards installed. On each interface, space for connections is divided up between traditional BPX switch permanent virtual circuit (PVC) connections, and Tag Switching VCs (TVCs). The details of connection partitioning using the **cnfrsrc** command are discussed later in this section.

- Queues for Tag Switching traffic

These should be automatically configured correctly, but it is possible to change the configuration manually. Consequently, the configuration of the queues should be checked as part of the process of enabling tag switching. Configuration of these parameters using the **cnfqbin** command is discussed later in this chapter.

- VSI Control Interface

A trunk must be enabled as VSI control interface, to allow a TSC to be connected. This is done using the **addshelf** command and selecting the VSI option.

Configuring VSI LCNS

In the first release of tag switching, each BXM card supports 16k connections in total, including PVCs, tag switching VSI connections, and connections used for internal signaling.

On the BXM, the ports are grouped into port groups, and a certain number of connections is available to each port group. For example, an 8-port-OC3 BXM has two port groups, consisting of ports 1-4 and 5-8, respectively.

Each port group for the various versions of the BXM cards has a separate connection pool as specified in Table 9-1.

Table 9-1 BXM Port Groups

BXM Card Type	Number of Port Groups	Port Group Size	LCN Limit per Port Group	Average Connections per Port
8-T3/E3	1	8 ports	16k	2048
12-T3/E3	1	12 ports	16k	1365
4-OC3	2	2 ports	8k	4096
8-OC3	2	4 ports	8k	2048
1-OC12	1	1 port	16k	16384
2-OC12	2	1 port	8k	8192

For tag switching, connections are allocated to VSI partitions. On the BPX 8650, for Release 9.1, only one VSI partition is used. In the future, other VSI partitions may be used to support controllers other than the Tag Switch Controller (e.g., 7200 and 7500 series routers). Also, currently there is only one VSI partition per port, but in the future multiple VSI partitions may be assigned to a given port.

When configuring connection partitioning for a BXM card, with one VSI partition per port, a number of connection spaces (LCNs) are assigned to each port as listed in Table 9-2. The **cnfrsrc** command is used to configure partition resources.

Note When the configuring the port using the **cnfrsrc** command, the term LCN is used in place of connection.

Table 9-2 Port Connection Allocations

Connection Type	cnfrsrc cmd parameter	Variable	Description
AutoRoute LCNs	maxpvc lens	a(x)	Represents the number of AutoRoute (PVC) LCNs configured for a port.
Minimum VSI LCNs for partition 1	minvsilcns	n ₁ (x)	Represents the guaranteed minimum number of LCNs configured for the port VSI partition. This value is not necessarily always available. Reaching it is dependent on FIFO access to the unallocated LCNs in the port group common pool.
Maximum VSI LCNs for partition 1	maxvsilcns	m ₁ (x)	Represents the maximum number of LCNs configured for the port VSI partition. This value is not necessarily reached. It is dependent on FIFO access to the unallocated LCNs in the port group common pool.

(where x is the port number, and subscript “1” is the partition number)

AutoRoute is guaranteed to have its assigned connection spaces (LCNs) available. Tag switching, uses one connection space (LCN) per Tag VC (TVC). This is usually one connection space (LCN) per source-destination pair using the port where the sources and destinations are tag edge routers.

Beyond the guaranteed minimum number of connection spaces (LCNs) configured for a port VSI partition, a tag switching partition uses unallocated LCNs on a FIFO basis from the common pool shared by all ports in the port group. These unallocated LCNs are accessed only after a port partition has reached its guaranteed minimum limit, “minvsilcns”, as configured by the **cnfrsrc** command.

Useful Default Allocations

Reasonable default values for all ports on all cards are listed in Table 9-3. If these values are not applicable, then other values may be configured using the **cnfrsrc** command.

Table 9-3 Port Connection Allocations, Useful Default Values

Connection Type	Variable	Useful Default Value	cnfrsrc cmd parameter
AutoRoute LCNs	a(x)	256	maxpvc lens
Minimum VSI LCNs for partition 1	n ₁ (x)	512	minvsilcns
Maximum VSI LCNs for partition 1	m ₁ (x)	16384	maxvsilcns

Different types of BXM cards support different maximums. If you enter a value greater than the allowed maximum, a message is displayed with the allowable maximum.

Here, a(x) = 256, n₁(x) = 512, and m₁(x) = 16384.

The next section describes more rigorous allocations which may be configured in place of using these default allocations.

Details of More Rigorous Allocations

More rigorous allocations are possible as may be desired when the default values are not applicable. For example, the LCN allocations for a port group must satisfy the following limit:


$$\text{sum} (a (x)) + \text{sum} (n_1 (x)) + t * 270 \leq g$$

In this expression, “a (x)” represents AutoRoute LCNs, “n₁ (x)” represents the guaranteed minimum number of VSI LCNs, “t” is the number of ports in the port group that are configured as AutoRoute trunks, and “g” is the total number of LCNs available to the port group. Figure 9-8 shows the relationship of these elements.

The “270” value reflects the number of LCNs which are reserved on each AutoRoute trunk for internal purposes. If the port is configured in port rather than trunk mode, “t” = 0, and t*270 drops out of the expression.

For detailed information on the allocation of resources for VSI partitions, refer to the **cnfrsrc** command description in the section, *Command Reference* in this chapter.

Figure 9-8 Port VSI Partition LCN Allocation Elements



Note Tag switching can operate on a BXM card configured for either trunk (network) or port (service) mode. If a BXM card is configured for port (service) mode, all ports on the card are configured in port (service) mode. If a BXM card is configured for trunk (network) mode, all ports on the card are configured for trunk (network) mode. When the card is configured for trunk mode, the trunks reserve some connection bandwidth.

Requirements

- BCC cards of one of the following versions:
 - BCC-3-64
 - BCC-4-64
 - BCC-4-128
- BPX switches require BXM cards to originate, terminate, or transfer tag switching connections.

List of Terms

The following terms are defined for a tag switching context only, not for general situations:

ATM edge TSR—A tag switching router that is connected to the ATM-TSR cloud through TC-ATM interfaces. The ATM edge TSR adds tags to untagged packets and strips tags from tagged packets.

ATM-TSR—A tag switching router with a number of TC-ATM interfaces. The router forwards the cells from these interfaces using tags carried in the VPI and/or VCI field.

BPX switch—The BPX switch is a carrier quality switch, with trunk and CPU hot standby redundancy.

BPX-TSR—An ATM tag switch router consisting a tag switch controller (series 7200 or 7500 router) and a tag controlled switch (BPX switch).

BXM—Broadband Switch Module. ATM port and trunk card for the BPX switch.

CLI—Command line interface.

extended tag ATM interface—A new type of interface supported by the remote ATM switch driver and a particular switch-specific driver that supports tag switching over an ATM interface on a remotely controlled switch.

external ATM interface—One of the interfaces on the slave ATM switch other than the slave control port. It is also referred to as an exposed ATM interface, because it is available for connections outside of the tag controlled switch.

LCNs—A common pool of logical connection numbers is defined per port group. The partitions in the same port group share these LCNs. New connections are assigned LCNs from the common pool.

master control port—A physical interface on a TSC that is connected to one end of a slave control link.

Ships in the Night (SIN)—The ability to support both tag switching procedures and ATM Forum protocols on the same physical interface, or on the same router or switch platform. In this mode, the two protocol stacks operate independently.

slave ATM switch—An ATM switch that is being controlled by a TSC.

slave control link—A physical connection, such as an ATM link, between the TSC and the slave switch, that runs a slave control protocol such as VSI.

slave control port—An interface that uses a TSC to control the operation of a slave ATM switch (for example, VSI). The protocol runs on the slave control link.

remote ATM switch driver—A set of interfaces that allow IOS software to control the operation of a remote ATM switch through a control protocol, such as VSI.

tag controlled switch—The tag switch controller and slave ATM switch that it controls, viewed together as a unit.

Tag switch controller (TSC)—An IOS platform that runs the generic tag switching software and is capable of controlling the operation of an external ATM (or other type of) switch, making the interfaces of the latter appear externally as TC-ATM interfaces.

tag switching router (TSR)—A Layer 3 router that forwards packets based on the value of a tag encapsulated in the packets.

TC-ATM interface—A tag switching interface where tags are carried in the VPI/VCI bits of ATM cells and where VC connections are established under the control of tag switching control software.

TFIB—Tag Forwarding Information Base (TFIB). A data structure and way of managing forwarding in which destinations and incoming tags are associated with outgoing interfaces and tags.

TVC—Tag switched controlled virtual circuit (TVC). A virtual circuit (VC) established under the control of tag switching. A TVC is not a PVC or an SVC. It must traverse only a single hop in a tag-switched path (TSP), but may traverse several ATM hops only if it exists within a VP tunnel.

VP tunnel—In the context of ATM tag switching, a VP tunnel is a TC-ATM interface that traverses one or more ATM switches that do not act as ATM-TSRs.

VSI—Virtual Switch Interface. The protocol that enables a TSC to control an ATM switch over an ATM link.

VSI slave—In a hardware context, a switch or a port card that implements the VSI. In a software context, a process that implements the slave side of the VSI protocol.

VSI master—In a hardware context, a device that controls a VSI switch (for example, a VSI tag switch controller). In a software context, a process that implements the master side of the VSI protocol.

Related Documents

- *Tag Switching for the Cisco 7500/7200 Series Routers*
- *Cisco BPX 8600 Series Installation and Configuration*
- *Cisco BPX 8600 Series Reference*
- *Cisco WAN Switching Command Reference*

Configuration Management

The BPX switch must be initially installed, configured, and connected to a network. Following this, connections can be added to the BPX switch.

For tag switching, the BPX node must be enabled for tag switching. The BXM cards that will be used to support tag switching connections must also be configured properly, including setting up resources for the tag switching VSIs. In addition, a Tag Switch Controller (7200 or 7500 series router) must be connected to one of the BXM cards configured for tag switching.

Instructions for configuring the BPX switch and BXM cards for tag switching are provided in the next section.

Instructions for configuring the router are provided in the applicable tag switch controller documents, such as the:

- *Tag Switch Controller Documentation*

Configuration Criteria

Tag switching for VSIs on a BXM card is configured using the **cnfrsrc** and **cnfqbin** commands. Qbin 10 is assigned to tag switching.

The cnfqbin Command

The **cnfqbin** command is used to adjust the threshold for the traffic arriving in Qbin 10 of a given VSI interface as away of fine tuning traffic delay.

If the **cnfqbin** command is used to set an existing Qbin to disabled, the egress of the connection traffic to the network is disabled. Re-enabling the Qbin restores the egress traffic.

The cnfrsrc Command

The **cnfrsrc** command is used to enable a VSI partition and to allocate resources to the partition. An example of a **cnfrsrc** command is shown in the following example. If the **cnfrsrc** command is used to disable a partition, those connections are deleted.

```
n4          TN      SuperUser      BPX 15      9.1      Apr. 4 1998 16:40 PST

Port/Trunk : 4.1

Maximum PVC LCNS:          256      Maximum PVC Bandwidth:26000

Min Lcn(1) : 0 Min Lcn(2) : 0
Partition 1

Partition State :          Enabled
Minimum VSI LCNS:          512
Maximum VSI LCNS:          7048
Start VSI VPI:             2
End VSI VPI :              15
Minimum VSI Bandwidth :    26000      Maximum VSI Bandwidth :      100000

Last Command: cnfrsrc 4.1 256 26000 1 e 512 7048 2 15 26000 100000

Next Command:
```

A detailed description of the **cnfrsrc** parameters is provided later in this chapter in the *Command Reference* section under the heading **cnfrsrc**. A brief summary of the parameters and their use is provided in Table 9-4.

Table 9-4 cnfrsrc Parameter Summary


Parameter (cnfrsrc)	Example Value	Description
slot.port	4.1	Specifies the slot and port number for the BXM
maxpvclicns	256	The maximum number of LCNs allocated for AutoRoute PVCs for this port.
maxpvcbw	26000	The maximum bandwidth of the port allocated for AutoRoute use.
partition	1	Partition number
e/d	e	enables or disables the VSI partition
minvsilcns	512	The minimum number of LCNs guaranteed for this partition.
maxvsilcns	7048	The total number of LCNs the partition is allowed for setting up connections. Cannot exceed the port group max shown by The dspcd command.
vsistartvpi	2	Should be set to “2” or higher for ports in trunk mode because “1” is reserved for AutoRoute. For ports in port mode it should be set to “1”. By default the TSC (e.g. 7200 or 7500 series router) will use either a starting VSI VPI of 1 or 2 for tag switching, whichever is available. They default to 1.
vsientdvp	15	Two VPIs are sufficient for the current release, although it may be advisable to reserve a larger range of VPIs for later expansion, for example, VPIs 2-15.
vsiminbw	26000	The minimum port bandwidth allocated to this partition in cells/sec. Not used in this release. Entered values are ignored.
vsimaxbw	100000	The maximum port bandwidth guaranteed to this partition. The actual bw may be as high as the line rate. This value is used for VSI QBIN bandwidth scaling.

Configuration Example

The following initial configuration example for a BPX tag switching router is with respect to a BXM OC3 card located in slot 4 of the BPX switch, a Tag Switch Controller (e.g., 7500 or 7200 series router) connected to BXM port 4.1, and with connections to two tag switching routers in the network at BXM ports 4.2 and 4.3, respectively, as shown in Figure 9-9.

Note Whether a BXM card operates in trunk or port mode is determined by how the first port is brought up. Once the first port is upped, the following ports can only be upped in the same mode, that is by using either the **upport** or **uptrk** command, as applicable. For tag switching, the BXM may operate in either trunk or port mode.

Figure 9-9 BPX Tag Switching Router with BXM in Slot 4



- Step 1** Log in to the BPX switch.
- Step 2** Check the card status by entering the command:
- ```
dspcds
```
- The card status, for card in slot 4 in this example, should be “standby”.  
If the card status is OK, proceed to step 4, otherwise, proceed to step 3.
- Step 3** If the card does not come up in standby, perform the following actions as required:
- Enter the command
 

```
resctcd 4 h
```
  - If the `resctcd` command does not work, pull the card and re-insert it.
  - If reseating the card does not work, call Customer Service.

**Step 4** Enter the **dspcd** command to check the port group max that can be entered for the **maxvsilcn** parameter of the **cnfrsrc** command. In this example, the maximum value for a port group is 7048.

```
n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:40 PST
```

```
Detailed Card Display for BXM-155 in slot 4
```

```
Status: Active
Revision: CD18
Serial Number: 693313
Fab Number: 28-2158-02
Queue Size: 228300
Support: FST, 4 Pts, OC3, Vc
Chnls:16320, PG[1]:7048, PG[2]:7048
PG[1]:1,2,
PG[2]:3,4,
```

```
Backcard Installed
```

```
Type: LM-BXM
Revision: BA
Serial Number: 688284
Supports: 8 Pts, OC3, MMF Md
```

```
Last Command: dspcd 4
```

```
Next Command:
```



**Step 5** On the BXM in slot 4, bring up the ports 4.1, 4.2, and 4.3, as follows:

**Note** The following example enables ports 4.1, 4.2, and 4.3 in trunk mode with the `uptrk` command, they could also all be upped in port mode using the `upport` command. This is because tag switching and the VSI make no distinction between a “port” and a “trunk”.

**uptrk 4.1**

**uptrk 4.2**

**uptrk 4.3**

Sample Display:

```
n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:39 PST

TRK Type Current Line Alarm Status Other End
2.1 OC3 Clear - OK j4a/2.1
3.1 E3 Clear - OK j6c (AXIS)
5.1 E3 Clear - OK j6a/5.2
5.2 E3 Clear - OK j3b/3
5.3 E3 Clear - OK j5c (IPX/AF)
6.1 T3 Clear - OK j4a/4.1
6.2 T3 Clear - OK j3b/4
4.1 OC3 Clear - OK VSI (VSI)
```

Last Command: `uptrk 4.1`

Next Command:

**Step 6** Port 4.1 is the slave interface to the tag switch controller. Configure the VSI partitions for port 4.1 as follows:

**cnfrsrc 4.1**

**PVC LCNs: [256]** {accept default value}

**max PVC bandwidth: 26000**

**partition: 1**

**enabled: e**

**VSI min LCNs: 512**

**VSI max LCNs: 7048** {varies with BXM type}

**VSI start VPI: 2**

**VSI end VPI: 15**

**VSI min b/w: 26000**

**VSI max b/w: 100000**

or with one entry as follows:

**cnfrsrc 4.1 256 26000 1 e 512 7048 2 15 26000 100000**

### Sample Display:

```
n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:40 PST

Port/Trunk : 4.1

Maximum PVC LCNS: 256 Maximum PVC Bandwidth:26000

Min Lcn(1) : 0 Min Lcn(2) : 0
Partition 1

Partition State : Enabled
Minimum VSI LCNS: 512
Maximum VSI LCNS: 7048
Start VSI VPI: 2
End VSI VPI : 15
Minimum VSI Bandwidth : 26000 Maximum VSI Bandwidth : 100000

Last Command: cnfrsrc 4.1 256 26000 1 e 512 7048 2 15 26000 100000

Next Command:
```

---

**Note** It is possible to have PVCs terminating on the Tag Switch Controller itself, as shown in Figure 9-4. This example reserves approximately 10 Mbps (26000 cells/sec) for PVCs, and allows up to 256 PVCs on the switch port connected to the TSC.

---

---

**Note** The VSI max and min logical connections (LCNs) will determine the maximum number of tag virtual connections (TVCs) that can be supported on the interface. The number of TVCs required on the interface depends on the routing topology of the tag switch.

---

---

**Note** By default the TSC will use either a starting VSI VPI of 1 or 2 for tag switching, whichever is available. If both are available, a starting VSI VPI of 1 is used. The VPI range should be 2-3 on a BPX VSI connected to a 7200 or 7500 AIP. If VPI 2 is not to be used, the tag switching VPI interface configuration command can be used on the TSC to override the defaults

---

---

**Note** The VSI range for tag switching on the BPX switch is configured as a VSI partition, usually VSI partition number 1. VSI VPI 1 is reserved for autoroute, so the VSI partition for tag switching should start at VPI 2. Two VPIs are sufficient for the current release, although it may be advisable to reserve a larger range of VPIs for later expansion, for example, VPIs 2-15.

---

**Step 7** Ports 4.2 and 4.3 are connected to other tag switch router ports in this example and support TVCs across the network. Configure the VSI partitions for ports 4.2 and 4.3 by repeating the procedures in the previous step, but entering 4.2 and 4.3, where applicable.

Maximum VSILCNs (logical connection numbers) determine the number of connections that can be made to each port. For a description of how the LCNs may be assigned to a port, refer to *Configuring VSI LCNS on page 12*.

If the interfaces require other than a max PVC bandwidth of 10 Mbps or require other than a PVC LCN configuration of 256, adjust the configuration accordingly.

**Step 8** For this release, Class of Service buffer 10 is used for tag switching connections. Check the queue buffer 10 configurations for port 4.1 as follows:

**dspqbin 4.1 10**

The qbin configuration should be as shown in the following example:

---

**Note** VC connections are grouped into large buffers called qbins. (per-VC queues can be specified on a connection-by-connection basis also). In this release, all VSI connections use qbin 10 on each interface.

---

Sample Display:

```

Sample Display:
n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:41 PST
Qbin Database 4.1 on EXM qbin 10
Qbin State: Enabled
Minimum Bandwidth: 0
Qbin Discard threshold: 65536
Low CLP/EPD threshold: 95%
High CLP/EPD threshold: 100%
EFCI threshold: 40%

This Command: cnfqbin 4.1 10
'E' to Enable, 'D' to Disable [E]:

Next Command:

```

If the qbin is not configured as shown in the example, configure the queues on the ports using the cnfqbin command:

**cnfqbin 4.1 10**

**enable/disable: e**

For all other parameters, accept the (default).

The previous parameters can also be set for qbin 10 as follows:

**cnfqbin 4.1 10 e 0 65536 95 100 40**

Sample Display:

```
Sample Display:

n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:41 PST

Qbin Database 4.1 on BXM qbin 10

Qbin State: Enabled
Minimum Bandwith: 0
Qbin Discard threshold: 65536
Low CLP/EPD threshold: 95%
High CLP/EPD threshold: 100%
EFCI threshold: 40%

Last Command: cnfqbin 4.1 10 e 0 65536 95 100 40

Next Command:
```

**Step 9** Configure the Qbin 10 for ports 4.2 and 4.3 by performing the procedures in the previous step, but entering port 4.2 and 4.3 where applicable.

**Step 10** 5. Add a VSI controller to port 4.1, controlling partition 1

**addshelf 4.1 vsi 1 1**

---

**Note** The second “1” in the addshelf command is a controller ID. Controller IDs must be in the range 1-32, and must be set identically on the TSC and in the addshelf command. A controller id of 1 is the default used by the TSC.

---

Sample Display:

```
n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:42 PST

 BPX Interface Shelf Information

Trunk Name Type Alarm
 3.1 j6c AXIS MIN
 5.3 j5c IPX/AF MIN
 4.1 VSI VSI OK

Last Command: addshelf 4.1 vsi 1 1

Next Command:
```

## Checking and Troubleshooting

Use the following procedure as a quick checkout of the tag switching configuration and operation with respect to the BPX switch.

**Step 1** Wait a while, and check whether the controller sees the interfaces correctly; on the TSC, enter the following command:

```
tsc# show controllers VSI descriptor
```

and the an example output is:

---

**Note** Check the TSC on-line documentation for the most current information.

---

```
Phys desc: 4.1
Log intf: 0x00040100 (0.4.1.0)
Interface: slave control port
IF status: n/a IFC state: ACTIVE
Min VPI: 0 Maximum cell rate: 10000
Max VPI: 10 Available channels: 999
Min VCI: 0 Available cell rate (forward): 100000
Max VCI: 65535 Available cell rate (backward): 100000
```

```
Phys desc: 4.2
Log intf: 0x00040200 (0.4.2.0)
Interface: ExtTagATM2
IF status: up IFC state: ACTIVE
Min VPI: 0 Maximum cell rate: 10000
Max VPI: 10 Available channels: 999
Min VCI: 0 Available cell rate (forward): 100000
Max VCI: 65535 Available cell rate (backward): 100000
```

```
Phys desc: 4.3
Log intf: 0x00040300 (0.4.3.0)
Interface: ExtTagATM3
IF status: up IFC state: ACTIVE
Min VPI: 0 Maximum cell rate: 10000
Max VPI: 10 Available channels: 999
Min VCI: 0 Available cell rate (forward): 100000
Max VCI: 65535 Available cell rate (backward): 100000
```

-----

**Step 2** If there are no interfaces present, first check that card 4 is up, with, on the BPX switch:

```
dspcds
```

and, if the card is not up:

```
resetcd 4 h
```

and/or remove the card to get it to reset if necessary.

---

**Note** This example assumes that the controller is connected to card 4 on the switch. Substitute a different card number, as applicable.

---

**Step 3** Check the trunk status with the following command:

**dsptrks**

The dsptrks screen should show 4.1, 4.2 and 4.3, with the “Other End” of 4.1 reading “VSI (VSI)”. A typical dsptrks screen example follows:

Sample Display

```
n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:45 PST

TRK Type Current Line Alarm Status Other End
2.1 OC3 Clear - OK j4a/2.1
3.1 E3 Clear - OK j6c (AXIS)
5.1 E3 Clear - OK j6a/5.2
5.2 E3 Clear - OK j3b/3
5.3 E3 Clear - OK j5c (IPX/AF)
6.1 T3 Clear - OK j4a/4.1
6.2 T3 Clear - OK j3b/4
4.1 OC3 Clear - OK VSI (VSI)
4.2 OC3 Clear - OK VSI (VSI)
4.3 OC3 Clear - OK VSI (VSI)
```

Last Command: dsptrks

Next Command:

**Step 4** Enter the dspnode command.

**dspnode**

The resulting screens should show trunk 4.1 as type VSI. A typical dspnode screen follows:

Example of dspnode screen.

```
n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:46 PST

 BPX Interface Shelf Information

Trunk Name Type Alarm
3.1 j6c AXIS MIN
5.3 j5c IPX/AF MIN
4.1 VSI VSI OK
4.2 VSI VSI OK
4.3 VSI VSI OK
```

Last Command: dspnode

Next Command:

**Step 5** Enter the dsprsrc command as follows:

**dsprsrc 4.1 1**

The resulting screen should show the settings shown in the following example:

Sample Display:

```
n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:47 PST

Port/Trunk : 4.1

Maximum PVC LCNS: 256 Maximum PVC Bandwidth:26000

Min Lcn(1) : 0 Min Lcn(2) : 0
Partition 1

Partition State : Enabled
Minimum VSI LCNS: 512
Maximum VSI LCNS: 7048
Start VSI VPI: 2
End VSI VPI : 15
Minimum VSI Bandwidth : 26000 Maximum VSI Bandwidth : 100000

Last Command: dsprsrc 4.1 1

Next Command:
```

**Step 6** Enter the dspqbin command as follows:

**dspqbin 4.1 10**

The resulting screen should show the settings shown in the following example:

Sample Display:

```
n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:48 PST

Qbin Database 4.1 on EXM qbin 10

Qbin State: Enabled

Minimum Bandwidth: 0
Qbin Discard threshold: 65536
Low CLP threshold: 95%
High CLP threshold: 100%
EFCI threshold: 40%

Last Command: dspqbin 4.1 10

Next Command:
```

**Step 7** If interfaces 4.2 and 4.3 are present, but not enabled, perform the previous debugging steps for interfaces 4.2 and 4.3 instead of 4.1, except for the dspnode command which does not show anything useful pertaining to ports 4.2 and 4.3.

**Step 8** Try a ping on the tag switch connections. If the ping doesn't work, but all the tag switching and routing configuration looks correct, check that the TSC has found the VSI interfaces correctly by entering the following command at the TSC:

**tsc# show tag int**

**Step 9** If the interfaces are not shown, re-check the configuration of port 4.1 on the BPX switch as described in the previous steps.

**Step 10** If the VSI interfaces are shown, but are down, check whether the TSRs connected to the BPX switch show that the lines are up. If not, check such items as cabling and connections.

**Step 11** If the TSCs and BPX switch show the interfaces are up, but the TSC doesn't, enter the following command on the TSC:

**tsc# reload**

**Step 12** If the "show tag int" shows that the interfaces are up, but the ping doesn't work, enter the follow command at the TSC:

**tsc# sho tag tdp disc**

The resulting display should show something similar to the following:

```
Local TDP Identifier:
 30.30.30.30:0
TDP Discovery Sources:
 Interfaces:
 ExtTagATM2.1: xmit/recv
 ExtTagATM3.1: xmit/recv

```

**Step 13** If the interfaces on the display show "xmit" and not "xmit/recv", then the TSC is sending TDP messages, but not getting responses. Enter the following command on the neighboring TSRs.

**tsc# sho tag tdp disc**

If resulting displays also show "xmit" and not "xmit/recv", then one of two things is likely:

- (a) The TSC is not able to set up VSI connections
- (b) The TSC is able to set up VSI connections, but cells won't be transferred because they can't get into a queue

**Step 14** Check the VSI configuration on the switch again, for interfaces 4.1, 4.2, and 4.3, paying particular attention to:

- (a) maximum bandwidths at least a few thousands cells/sec
- (b) qbins enabled
- (c) all qbin thresholds non-zero

---

**Note** VSI partitioning and resources must be set up correctly on the interface connected to the TSC, interface 4.1 in this example, as well as interfaces connected to other tag switching devices.

---



## Provisioning and Managing Connections

Instructions for configuration of the BPX switch including the setting of VSI partitions for tag switching are provided in this document. Adding (provisioning) and administering connections is performed from the Tag Switch Controller. For further information on the Tag Switch Controller, refer to:

*Tag Switching for the Cisco 7500/7200 Series Routers*

## Statistics

Statistics are monitored via the Tag Switch Controller. Refer to the *Cisco StrataView Plus Operations Guide* for information on monitoring statistics.

## Command Reference

This section provides a description of the BPX switch and TSC commands referenced in this chapter on tag switching. They are presented in the following order:

### BPX Switch Commands

A summary of the following commands is provided in this section. For complete descriptions of user and Suppressor commands, refer to the *Cisco WAN Switching Command Reference* and the *Cisco WAN Switching SuperUser Command Reference* documents.

- addshelf
- cnfqbin
- cnfrsrc
- dspcd
- dspcds
- dspnode
- dspqbin
- dsprsrc
- dsptrks
- resetcd
- upport
- uptrk

### TSC Commands

tsc# show controller vsi descriptor

tsc# show tag int

tsc# reload

tsc# sho tag tdp disc

For the TSC command reference information, refer to the appropriate router 7200 or 7500 source documentation.

## addshelf

Adds an ATM link between a hub node and an interface shelf such as an MGX 8220, IPX shelf, or IGX shelf in a tiered network, or an ATM link between a BXM card on a BPX node and a tag switch controller such as a series 7200 or 7500 router.

### Syntax

Tag switch controller:

**addshelf** <slot.port> <device-type> <control partition> <control ID>

Interface shelf:

**addshelf** <slot.port> <shelf-type> <vpi> <vci>

### Examples

Tag switch controller: **addshelf 4.1 vsi 1 1**

Interface shelf: **addshelf 12.1 A 21 200**

### Attributes

| Privilege | Jobs | Log | Node                                                                                                                          | Lock |
|-----------|------|-----|-------------------------------------------------------------------------------------------------------------------------------|------|
| 1-4       | Yes  | Yes | BPX switch for tag switch controller,<br>BPX switch and IGX switch for IPX<br>and IGX shelves,<br>BPX switch for the MGX 8220 | Yes  |

### Related Commands

delshelf, dspnode, dsptrk, dspport

### Description for Tag Switching

For tag switching, before it can carry traffic, the link to a tag switch controller must be “upped” (using either **uptrk** or **upport**) at the BPX node. The link can then be “added” to the network (using **addshelf**). Also, the link must be free of major alarms before you can add it with the **addshelf** command.

---

**Note** Once a port on the BXM is upped in either trunk or port mode by either the uptrk or upport commands, respectively, all other ports can only be “upped” in the same mode.

---

### Tag Switching Parameters-addshelf

| Parameter         | Description                                                                                                                                                                            |
|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| slot.port         | Specifies the BXM slot and port number. (The port may be configured for either trunk (network) or port (service) mode.)                                                                |
| device-type       | vsi, which is “virtual switch interface” and specifies a virtual interface to a tag switch controller (TSR) such as a 7200 or 7500 series router.                                      |
| control partition |                                                                                                                                                                                        |
| control ID        | Control IDs must be in the range 1-32, and must be set identically on the TSC and in the addshelf command. A control ID of “1” is the default used by the tag switch controller (TSC). |

### Example for Tag Switching

Add a tag switch controller link to a BPX node, by entering the addshelf command at the desired BXM port as follows:

```
addshelf 4.1 vsi 1 1
```

Sample Display:

```
n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:40 PST

 BPX Interface Shelf Information

Trunk Name Type Alarm
5.1 j6c AXIS MIN
5.3 j5c IPX/AF MIN
4.1 VSI VSI OK
```

```
Last Command: addshelf 4.1 vsi 1 1
```

```
Next Command:
```

## Description for Interface Shelves

An interface shelf can be one of the following:

- An MGX 8220 connected to a BPX node
- An IPX or IGX node connected to a BPX node that serves as a hub for the IPX/AF or IGX/AF.
- An IGX node connected to an IGX routing node that serves as a hub for the IGX/AF

The signaling protocol that applies to the trunk on an interface shelf is Annex G.

Each IPX/AF, IGX/AF, or MGX 8220 has one trunk that connects to the BPX or IGX node serving as an access hub. A BPX hub can support up to 16 T3 trunks to the interface shelves. An IGX hub can support up to 4 trunks to the interface shelves.

Before it can carry traffic, the trunk on an interface shelf must be “upped” (using **uptrk**) on both the interface shelf and the hub node and “added” to the network (using **addshelf**). Also, a trunk must be free of major alarms before you can add it with the **addshelf** command.

### Interface Shelf Parameters-addshelf

| Parameter  | Description                                                                                                                                                                                                                                                          |
|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| slot.port  | slot.port,<br>Specifies the slot and port number of the trunk                                                                                                                                                                                                        |
| shelf type | I or A,<br>On a BPX node, <i>shelf type</i> specifies the type of interface shelf when you execute <b>addshelf</b> . The choices are I for IPX/AF or IGX/AF or A for the MGX 8220. On an IGX hub, only the IGX/AF is possible, so <i>shelf type</i> does not appear. |
| vpi vci    | Specifies the vpi and vci (Annex G vpi and vci used). For the MGX 8220 only, the valid range for vpi is 5–14 and for vci is 16–271. For an IPX/AF interface shelf, the valid range for both vpi and vci is 1–255.                                                    |

## Example for Interface Shelves

Add an MGX 8220 at trunk 11.1. After you add the shelf, the screen displays a confirmation message and the name of the shelf. Add the MGX 8220 (may be referred to in screen as AXIX) as follows:

### **addshelf 11.1 a**

The sample display shows the partial execution of the command with the prompt requesting that the I/F type be entered:

Sample Display:

```

n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:40 PST

 BPX Interface Shelf Information

Trunk Name Type Alarm
 1.3 AXIS240 AXIS OK
 11.2 A242 AXIS OK

```

```
This Command: addshelf 11.1
```

```
Enter Interface Shelf Type: I (IPX/AF), A (AXIS)
```

## cnfqbin

Tag switched VC connections are grouped into large buffers called Qbins. This command configures the Qbins. For the EFT release of tag switching, Qbin 10 is used for tagged switch connections.

### Syntax

```
cnfqbin <slot.port> <Qbin_#> <e/d> <BWmin> <discard_thr> <CLPlo> <CLPhi> <EFCI_thr>
```

### Example

```
cnfqbin 13.4 10 E 0 65536 6095 80100 40
```

### Attributes

| Privilege | Jobs | Log | Node       | Lock |
|-----------|------|-----|------------|------|
|           |      |     | BPX switch |      |

### Related Commands

dspqbin

### Parameters-cnfqbin

| Parameter              | Description                                                                                                                                                                                    |
|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| slot.port              | slot.port<br>Specifies the slot and port number for the BXM                                                                                                                                    |
| Qbin number            | Specifies the number of the Qbin to be configured                                                                                                                                              |
| e/d                    | Enables or disables the Qbin.                                                                                                                                                                  |
| Minimum bandwidth      | Bandwidth allocated to the VCs                                                                                                                                                                 |
| Qbin discard threshold |                                                                                                                                                                                                |
| Low CLP threshold      | Specifies a percentage of the Qbin depth such that, when the Qbin level falls below this level, the node stops discarding CLP=1 cells.                                                         |
| High CLP threshold     | Specifies a percentage of the Qbin depth. When the threshold is exceeded, the node discards cells with CLP=1 in the connection until the Qbin level falls below the depth specified by CLP Lo. |
| EFCI threshold         | Explicit Forward Congestion Indication. The percentage of Qbin depth that causes EFCI to be set.                                                                                               |

## Description

The following example shows the configuration of a BXM Qbin on port 4.1 for tag switching

## Example

Configure a Qbin by enabling it and accepting the defaults for the other parameters:

```
cnfqbin 4.1 10 e 0 65536 95 100 40
```

Sample Display:

```
n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:40 PST
```

```
Qbin Database 4.1 on BXM qbin 10
```

```
Qbin State: Enabled
Minimum Bandwidth: 0
Qbin Discard threshold: 65536
Low CLP/EPD threshold: 95%
High CLP/EPD threshold: 100%
EFCI threshold: 40%
```

```
Last Command: cnfqbin 4.1 10 e 0 65536 95 100 40
```

```
Next Command:
```

## cnfrsrc

This command configures resources among AutoRoute PVCs and VSI partitions.

### Syntax

```
cnfrsrc slot.port maxpvcLens maxpvcbw partition e/d minvslens maxvslens vsistartypi
 vsiendvpi vsiminbw vsimaxbw
```

### Example

```
cnfrsrc 4.1 256 26000 1 e 512 7048 2 15 26000 100000
```

### Attributes

| Privilege | Jobs | Log | Node       | Lock |
|-----------|------|-----|------------|------|
|           |      |     | BPX switch |      |

### Related Commands

#### Parameters-cnfrsrc

| Parameter (cnfrsrc) | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|---------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| slot.port           | Specifies the slot and port number for the BXM                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| maxpvcLens          | The maximum number of LCNs allocated for AutoRoute PVCs for this port. For trunks there are additional LCNs allocated for AutoRoute that are not configurable. The <b>dspecd</b> <slot> command displays the maximum number of LCNs configurable via the <b>cnfrsrc</b> command for the given port. For trunks, "configurable LCNs" represent the LCNs remaining after the BCC has subtracted the "additional LCNs" needed. For a port card, a larger number is shown, as compared with a trunk card. Setting this field to zero would enable configuring all of the configurable LCNs to the VSI. |
| maxpvcbw            | The maximum bandwidth of the port allocated for AutoRoute use.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| partition           | Partition number                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| e/d                 | enables or disables the VSI partition                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |



| Parameter (cnfrsrc) | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|---------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| minvsilcns          | <p>The minimum number of LCNs guaranteed for this partition. The VSI controller guarantees at least this many connection endpoints in the partition, provided that there are sufficient free LCNs in the common pool to satisfy the request at the time the partition is added. When a new partition is added or the value is increased, it may be that existing connections have depleted the common pool so that there are not enough free LCNs to satisfy the request. The BXM gives priority to the request when LCNs are freed. The net effect is that the partition may not receive all the guaranteed LCNs (min LCNs) until other LCNs are returned to the common pool.</p> <p>This value may not be decreased dynamically. All partitions in the same port group must be deleted first and reconfigured in order to reduce this value.</p> <p>The value may be increased dynamically. However, this may cause the “deficit” condition described above.</p> <p>The command line interface warns the user when the action is invalid, except for the “deficit” condition.</p> <p>To avoid this deficit condition which could occur with maximum LCN usage by a partition or partitions, it is recommended that all partitions be configured ahead of time before adding connections. Also, it is recommended that all partitions be configured before adding a VSI controller via the <b>addshelf</b> command.</p> |
| maxvsilcns          | <p>The total number of LCNs the partition is allowed for setting up connections. The min LCNs is included in this calculation. If max LCNs equals min LCNs, then the max LCNs are guaranteed for the partition.</p> <p>Otherwise, (max - min) LCNs are allocated from the common pool on a FIFO basis.</p> <p>If the common pool is exhausted, new connection setup requests will be rejected for the partition, even though the max LCNs has not been reached.</p> <p>This value may be increased dynamically when there are enough unallocated LCNs in the port group to satisfy the increase.</p> <p>The value may not be decreased dynamically. All partitions in the same port group must be deleted first and reconfigured in order to reduce this value.</p> <p>Different types of BXM cards support different maximums. If you enter a value greater than the allowed maximum, a message is displayed with the allowable maximum.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| vsistartvpi         | <p>By default the TSC (e.g, 7200 or 7500 series router) will use either a starting VSI VPI of 1 or 2 for tag switching, whichever is available. If both are available, a starting VSI VPI of 1 is used. The VPI range should be 2-15 on a BPX 8620 VSI. The VSI range for tag switching on the BPX 8620 is configured as a VSI partition, usually VSI partition number 1. VSI VPI 1 is reserved for AutoRoute PVCs, so the VSI partition for tag switching should start at VPI 2. If VPI 2 is not to be used, the tag switching VPI interface configuration command can be used on the TSC to override the defaults</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| vsieendvpi          | <p>Two VPIs are sufficient for the current release, although it may be advisable to reserve a larger range of VPIs for later expansion, for example, VPIs 2-15.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| vsiminbw            | <p>The minimum port bandwidth allocated to this partition in cells/sec. (Multiply by 400 based on 55 bytes per ATM cell to get approximate bits/sec.)</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| vsimaxbw            | <p>The maximum port bandwidth allocated to this partition. This value is used for VSI QBIN bandwidth scaling.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |

### Description

The following paragraphs describe various configurations of BXM port resources for tag switching. The first allocation example is using default allocations. The second allocation example describes more rigorous allocations where default allocations are not applicable.

## Useful Default Allocations

Reasonable default values for all ports on all cards are listed in Table 9-5. If these values are not applicable, then other values may be configured using the **cnfrsrc** command.

**Table 9-5 Port Connection Allocations, Useful Default Values**

| Connection Type                  | Variable           | Useful Default Value | cnfrsrc cmd parameter |
|----------------------------------|--------------------|----------------------|-----------------------|
| AutoRoute LCNs                   | a(x)               | 256                  | maxpvclens            |
| Minimum VSI LCNs for partition 1 | n <sub>1</sub> (x) | 512                  | minvsilcns            |
| Maximum VSI LCNs for partition 1 | m <sub>1</sub> (x) | 7048                 | maxvsilcns            |

Different types of BXM cards support different maximums. If you enter a value greater than the allowed maximum, a message is displayed with the allowable maximum

Here, a(x) = 256, n<sub>1</sub>(x) = 512, and m<sub>1</sub>(x) = 16384.

### Example:

Configure the VSI partition for port 4.1 by entering the following command:

```
cnfrsrc 4.1 256 26000 1 e 512 16384 2 15 26000 100000
```

Sample Display:

```
n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:40 PST

Port/Trunk : 4.1

Maximum PVC LCNS: 256 Maximum PVC Bandwidth:26000

Min Lcn(1) : 0 Min Lcn(2) : 0
Partition 1

Partition State : Enabled
Minimum VSI LCNS: 512
Maximum VSI LCNS: 7048
Start VSI VPI: 2
End VSI VPI : 15
Minimum VSI Bandwidth : 26000 Maximum VSI Bandwidth : 100000
```

```
Last Command: cnfrsrc 4.1 256 26000 1 e 512 7048 2 15 26000 100000
```

Next Command:

## Details of More Rigorous Allocations


More rigorous allocations are possible when default values are not applicable. For example, the LCN allocations for a port group must satisfy the following limit:

$$\text{sum} ( a ( x ) ) + \text{sum} ( n_1 ( x ) ) + t * 270 \leq g$$

In this expression, “a (x)” represents AutoRoute LCNs, “n<sub>1</sub> (x)” represents the guaranteed minimum number of VSI LCNs, “t” is the number of ports in the port group that are configured as AutoRoute trunks, and “g” is the total number of LCNs available to the port group. Figure 9-10 shows the relationship of these elements.

The “270” value reflects the number of LCNs which are reserved on each AutoRoute trunk for internal purposes. If the port is configured in port rather than trunk mode, “t” = 0, and t\*270 drops out of the expression.

**Figure 9-10** Port VSI Partition LCN Allocation Elements



**Note** Tag switching can operate on a BXM card configured for either trunk (network) or port (service) mode. If a BXM card is configured for port (service) mode, all ports on the card are configured in port (service) mode. If a BXM card is configured for trunk (network) mode, all ports on the card are configured for trunk (network) mode. When the card is configured for trunk mode, the trunks reserve some connection bandwidth.

In the following expression, “z<sub>1</sub>” equals the number of unallocated LCNs in the common pool of LCNs available for use by the port VSI partitions. The value of “z<sub>1</sub>” is the number of LCNs available after subtracting the AutoRoute LCNs [sum ( a ( x ) ], VSI LCNs [sum ( n<sub>1</sub> ( x ) )], and LCNs for trunk use [t\*270] from the total number of LCNs “g” available at the port. For a BXM card with ports configured in “port” mode, “t” = 0.

$$z_1 = ( g - \text{sum} ( a ( x ) ) - \text{sum} ( n_1 ( x ) ) - t * 270 )$$

When a port partition has exhausted its configured guaranteed LCNs (min LCNs), it may draw LCNs for new connections on a FIFO basis from the unallocated LCNs, “z<sub>1</sub>”, until its maximum number of LCNs, “m<sub>1</sub>(x)”, is reached or the pool, “z<sub>1</sub>”, is exhausted.

No limit is actually placed on what may be configured for “m<sub>1</sub>(x)”, although “m<sub>1</sub>(x)” is effectively ignored if larger than “z<sub>1</sub> + n<sub>1</sub>”. The value “m<sub>1</sub>(x)” is a non-guaranteed maximum value of connection spaces that may be used for a new connection or shared by a number of connections at a given time if there are a sufficient number of unallocated “LCNs available in “z<sub>1</sub>”. The value m<sub>1</sub>(x) typically is not used in Release 9.1, but in future releases allows more control over how the LCNs are shared among multiple VSI partitions.

The following two examples, one for a BXM in port mode and the other for a BXM in trunk mode, provide further detail on the allocation of connections.

### Example 1, 8-Port OC3 BXM Configured in Trunk Mode

This example is for an 8-port OC3 BXM configured for trunk mode and therefore, in Release 9.1, with all ports configured as trunks. Table 9-6 lists the configured connection space (LCN) allocations for each port of “a(x)”, “n<sub>1</sub>(x)”, and “m<sub>1</sub>(x)”. It also shows the unallocated LCN pool, “z<sub>1</sub>” for each port group and the total common pool access, “g”.

---

**Note** LCN is the variable affected when configuring connection space allocations using the **cnfrsrc** command.

---

The port groups in the example are ports 1-4 and 5-8, and the maximum number of connection spaces (LCNs) per port group is 8192 for this 8-port-OC3 BXM card. The allocations for ports 1-4 are shown in Figure 9-11. The allocations for ports 5-8 are similar to that shown in Figure 9-11, but with correspondingly different values.

As shown in Figure 9-11, “g” is the total number of connection spaces (LCNs) available to port group 1-4 and is equal to 8192 LCNs in this example. To find the number of unallocated LCNs available for use by port partitions that exhaust their assigned number of LCNs, proceed as follows:

From “g”, subtract the sum of the AutoRoute connections, “a(x)”, and the sum of minimum guaranteed LCNs, “n<sub>1</sub>(x)”. Also, since the ports in this example are configured in trunk mode, 270 LCNs per port are subtracted from “g”. Since there are four ports, “t” equals “4” in the expression “t\*270”. The resulting expression is as follows:

$$z_1 = (g - \text{sum}(a(x)) - \text{sum}(n_1(x)) - t*270)$$

The remaining pool of unallocated LCNs is “z<sub>1</sub>” as shown. This pool is available for use by ports 1-4 that exceed their minimum VSI LCN allocations “n<sub>1</sub>(x)” for partition 1.

The maximum number of LCNs that a port partition can access on a FIFO basis from the unallocated pool “z<sub>1</sub>” for new connections can only bring its total allocation up to either “(z<sub>1</sub> + n<sub>1</sub>(x)) or m<sub>1</sub>(x)”, whichever value is smaller. Also, since “z<sub>1</sub>” is a shared pool, the value of “z<sub>1</sub>” will vary as the common pool is accessed by other port partitions in the group.

The values shown in Table 9-6 are obtained as follows:

- For ports 1-4:

$$z_1 = (g - \text{sum}(a(x)) - \text{sum}(n_1(x)) - 4*270)$$

and factoring in the sum of a(x) and the sum of n<sub>1</sub>(x), the above expression evaluates to:

$$= (8192 - (185) - (3100) - 4*270) = 3827 \text{ unallocated LCNs}$$

The values shown in Table 9-6 for the port group containing ports 1-4 may be summarized as follows:

- Port 1 is guaranteed to be able to support 120 AutoRoute connections (PVCs) and 3000 tag VCs (TVCs). It will not support more than 120 PVCs. It may be able to support up to 3500 TVCs, subject to availability of unallocated LCNs “z<sub>1</sub>” on a FIFO basis. Since “m<sub>1</sub>(1)” of 3500 is less than “z<sub>1</sub>” of 3827, the most TVCs that can be supported are 3500.
- Port 2 will support up to 50 PVCs, and no more. It will support no TVCs, as “m<sub>1</sub>(2)” = 0.
- Port 3 is guaranteed to support up to 15 PVCs, and no more. It is not guaranteed to support any TVCs, but will support up to:  
3827 TVCs, subject to availability of unallocated LCNs “z<sub>1</sub>” on a FIFO basis. The configured maximum limit “m<sub>1</sub>(3)” of 7048 LCNs is ignored, as it is greater than the unallocated LCNs, “z<sub>1</sub>”, of 3827.
- Port 4 supports no PVCs. It is guaranteed to support 100 TVCs, and no more.

- For ports 5-8:

$$z_1 = (g - \sum (a(x)) - \sum (n_1(x) - 4*270))$$

and factoring in the sum of a (x) and the sum of n<sub>1</sub> (x), the above expression evaluates to:

$$= (8192 - (6100) - (310) - 4*270) = 702 \text{ unallocated LCNs}$$


The values shown in Table 9-6 for the port group containing ports 5-8 may be summarized as follows:

- Port 5 will support 6000 PVCs, and at least 10 TVCs. It will support up to 712 TVCs, subject to availability of the 702 unallocated LCNs “z<sub>1</sub>” on a FIFO basis. The configured maximum limit “m<sub>1</sub>(5)” of 7048 is ignored, as it is greater than 712 (the unallocated 702 LCNs in the “z<sub>1</sub>” pool plus the 10 LCN guaranteed minimum already allocated from the common pool “g” of 8192 LCNs).
- Port 6 will support no PVCs. It will support up to 100 TVCs subject to available LCNs, but is not guaranteed to be able to support any TVCs.
- Port 7 is guaranteed to be able to support 100 PVCs and 200 TVCs. It will not support any more.
- Port 8 will support no PVCs. It is not guaranteed to be able to support more than 100 TVCs, but will support up to 802 TVCs, subject to the availability of the 702 unallocated LCNs “z<sub>1</sub>” on a FIFO basis. The configured maximum limit “m<sub>1</sub>(8)” of 2100 TVCS is ignored, as it is greater than 802 (the number of unallocated 702 LCNs in the “z<sub>1</sub>” pool plus the 100 LCN guaranteed minimum already allocated from the common pool “g” of 8192 LCNs).

**Table 9-6 LCN Allocations for 8-port OC3 BXM, Ports Configured in Trunk Mode**

| Port (x)                 | a(x) | n <sub>1</sub> (x) | m <sub>1</sub> (x) | z <sub>1</sub> = unallocated LCNs | Total LCNS available to Port VSI Partition = min ( z <sub>1</sub> + n <sub>1</sub> (x), max m <sub>1</sub> (x) ) |
|--------------------------|------|--------------------|--------------------|-----------------------------------|------------------------------------------------------------------------------------------------------------------|
| <b>Port Group 1</b>      |      |                    |                    |                                   |                                                                                                                  |
| 1                        | 120  | 3000               | 3500               | 3827                              | 3500                                                                                                             |
| 2                        | 50   | 0                  | 0                  | 3827                              | 0                                                                                                                |
| 3                        | 15   | 0                  | 7048               | 3827                              | 3827                                                                                                             |
| 4                        | 0    | 100                | 100                | 3827                              | 100                                                                                                              |
| Sum, for x = 1 through 4 | 185  | 3100               | N/A                | N/A                               |                                                                                                                  |
| <b>Port Group 2</b>      |      |                    |                    |                                   |                                                                                                                  |
| 5                        | 6000 | 10                 | 7048               | 702                               | 712                                                                                                              |
| 6                        | 0    | 0                  | 100                | 702                               | 100                                                                                                              |
| 7                        | 100  | 200                | 200                | 702                               | 200                                                                                                              |
| 8                        | 0    | 100                | 2100               | 702                               | 802                                                                                                              |
| Sum for x = 5 through 8  | 6100 | 310                | N/A                | N/A                               |                                                                                                                  |

**Figure 9-11 LCN Allocations for Ports 1-4, Ports Configured in Trunk Mode Example**



12145

## Example 2, 8-Port OC3 BXM Configured in Port Mode

BXM ports configured for port mode rather than trunk mode have more connection spaces available for use by the TVC connections as it is not necessary to provide connection spaces for use by the AutoRoute trunks. This example is for an 8-port OC3 BXM configured for port mode and therefore, in Release 9.1, with all ports configured as ports. Table 9-7 lists the configured connection space (LCN) allocations for each port of “a (x)”, “n<sub>1</sub> (x)”, and “m<sub>1</sub> (x)”. It also shows the unallocated LCN pool, “z<sub>1</sub>” for each port group and the total common pool access, “g”.

---

**Note** LCN is the variable affected when configuring connection space allocations using the **cnfrsrc** command.

---

The port groups in the example are ports 1-4 and 5-8, and the maximum number of connection spaces (LCNs) per port group is 8192 for this 8-port-OC3 BXM card. The allocations for ports 1-4 are shown in Figure 9-12. The allocations for ports 5-8 are similar to that shown in Figure 9-12, but with correspondingly different values.

As shown in Figure 9-12, “g” is the total number of connection spaces (LCNs) available to port group 1-4 and is equal to 8192 LCNs in this example. To find the number of unallocated LCNs available for use by port partitions that exhaust their assigned number of LCNs, proceed as follows:

From “g”, subtract the sum of the AutoRoute connections, “a (x)”, and the sum of minimum guaranteed LCNs, “n<sub>1</sub> (x)”. Also, since the ports in this example are configured in port mode, “t” equals zero in the expression “t\*270”. This is indicated as follows:

$$z_1 = (g - \text{sum} ( a (x) ) - \text{sum} ( n_1 (x) ) - t*270 )$$

The remaining pool of unallocated LCNs is “z<sub>1</sub>” as shown. This pool is available for use by ports 1-4 that exceed their minimum VSI LCN allocations “n<sub>1</sub> (x)” for partition 1.

The maximum number of LCNs that a port partition can access on a FIFO basis from the unallocated pool “z<sub>1</sub>” for new connections can only bring its total allocation up to either “(z<sub>1</sub> + n<sub>1</sub> (x) ) or m<sub>1</sub>(x)”, whichever value is smaller. Also, since “z<sub>1</sub>” is a shared pool, the value of “z<sub>1</sub>” will vary as the common pool is accessed by other port partitions in the group.

The values shown in Table 9-7 are obtained as follows:

- For ports 1-4:

$$z_1 = (g - \text{sum} ( a(x) ) - \text{sum} ( n_1(x) ) - 0*270)$$

which simplifies to:

$$z_1 = (g - \text{sum} ( a(x) ) - \text{sum} ( n_1(x) ) )$$

and factoring in the sum of a (x) and the sum of n<sub>1</sub> (x), the above expression evaluates to:

$$= (8192 - (185) - (3100) ) = 4907 \text{ unallocated LCNs}$$

The values shown in Table 9-7 for the port group containing ports 1-4 may be summarized as follows:

- Port 1 is guaranteed to be able to support 120 AutoRoute connections (PVCs) and 3000 tag VCs (TVCs). It will not support more than 120 PVCs. It may be able to support up to 3500 TVCs, subject to availability of unallocated LCNs “z<sub>1</sub>” on a FIFO basis. Since “m<sub>1</sub> (1)” of 3500 is less than “z<sub>1</sub>” of 4907, the most TVCs that can be supported are 3500.
- Port 2 will support up to 50 PVCs, and no more. It will support no TVCs, as “m<sub>1</sub>(2)” = 0.

- Port 3 is guaranteed to support up to 15 PVCs, and no more. It is not guaranteed to support any TVCs, but will support up to:  
4907 TVCs, subject to availability of unallocated LCNs “z<sub>1</sub>” on a FIFO basis. The configured maximum limit “m<sub>1</sub>(3)” of 7588 LCNs is ignored, as it is greater than the unallocated LCNs, “z<sub>1</sub>”, of 4907.
- Port 4 supports no PVCS. It is guaranteed to support 100 TVCs, and no more.
- For ports 5-8:  
$$z_1 = (g - \sum (a(x)) - \sum (n_1(x) - 0 * 270))$$

which simplifies to:

$$z_1 = (g - \sum (a(x)) - \sum (n_1(x)))$$

and factoring in the sum of a (x) and the sum of n<sub>1</sub> (x), the above expression evaluates to:

$$= (8192 - (6100) - (310)) = 1782 \text{ unallocated LCNs}$$

The values shown in Table 9-7 for the port group containing ports 5-8 may be summarized as follows:


- Port 5 will support 6000 PVCs, and at least 10 TVCs. It will support up to 1792 TVCs, subject to availability of the 1782 unallocated LCNs “z<sub>1</sub>” on a FIFO basis. The configured maximum limit “m<sub>1</sub>(5)” of 7588 is ignored, as it is greater than 1792 (the unallocated 1782 LCNs in the “z<sub>1</sub>” pool plus the 10 LCN guaranteed minimum already allocated from the common pool “g” of 8192 LCNs).
- Port 6 will support no PVCs. It will support up to 100 TVCs subject to available LCNs, but is not guaranteed to be able to support any TVCs.
- Port 7 is guaranteed to be able to support 100 PVCs and 200 TVCs. It will not support any more.
- Port 8 will support no PVCs. It is not guaranteed to be able to support more than 100 TVCs, but will support up to 1882 TVCs, subject to availability of the 1782 unallocated LCNs “z<sub>1</sub>” on a FIFO basis. The configured maximum limit “m<sub>1</sub>(8)” of 2100 TVCS is ignored, as it is greater than 1882 (the number of unallocated 1782 LCNs in the “z<sub>1</sub>” pool plus the 100 LCN guaranteed minimum already allocated from the common pool “g” of 8192 LCNs).



**Table 9-7 LCN Allocations for 8-Port OC3 BXM, Ports Configured in Port Mode**

| Port (x)                | a(x) | n <sub>1</sub> (x) | m <sub>1</sub> (x) | z <sub>1</sub> = unallocated LCNs | Total LCNS available to Port VSI Partition = min ( z <sub>1</sub> + n <sub>1</sub> (x), max m <sub>1</sub> (x) ) |
|-------------------------|------|--------------------|--------------------|-----------------------------------|------------------------------------------------------------------------------------------------------------------|
| <b>Port Group 1</b>     |      |                    |                    |                                   |                                                                                                                  |
| 1                       | 120  | 3000               | 3500               | 4907                              | 3500                                                                                                             |
| 2                       | 50   | 0                  | 0                  | 4907                              | 0                                                                                                                |
| 3                       | 15   | 0                  | 7588               | 4907                              | 4907                                                                                                             |
| 4                       | 0    | 100                | 100                | 4907                              | 100                                                                                                              |
| Sum, for x =1 through 4 | 185  | 3100               | N/A                | N/A                               |                                                                                                                  |
| <b>Port Group 2</b>     |      |                    |                    |                                   |                                                                                                                  |
| 5                       | 6000 | 10                 | 7588               | 1782                              | 1792                                                                                                             |
| 6                       | 0    | 0                  | 100                | 1782                              | 100                                                                                                              |
| 7                       | 100  | 200                | 200                | 1782                              | 200                                                                                                              |
| 8                       | 0    | 100                | 2100               | 1782                              | 1882                                                                                                             |
| Sum for x = 5 through 8 | 6100 | 310                | N/A                | N/A                               |                                                                                                                  |

**Figure 9-12 LCN Allocations for Ports 1-4, Ports Configured in Port Mode Example**



12146

## dspcd

Displays the status, revision, and serial number of a card. If a back card is present, its type, revision, and serial number appear. The displayed information can vary with different card types.

### Syntax

**dspcd** <slot>

Example

**dspcd 5**

### Attributes

| Privilege | Jobs | Log | Node                               | Lock |
|-----------|------|-----|------------------------------------|------|
| 1-6       | No   | No  | IPX switch, IGX switch, BPX switch | No   |

### Related Commands

dncd, dspcds, resetcd, upcd

### Parameters-dspcd

| Parameter | Description          |
|-----------|----------------------|
| slot      | slot number of card. |

### Description

The following shows an example of the dspcd command for a BXM card.

#### Sample Display:

```
n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:40 PST

Detailed Card Display for BXM-155 in slot 4
Status: Active
Revision: CD18
Serial Number: 693313
Fab Number: 28-2158-02
Queue Size: 228300
Support: FST, 4 Pts,OC3,Vc
Chnls:16320,PG[1]:7588,PG[2]:7588
PG[1]:1,2,
PG[2]:3,4,
Backcard Installed
Type: LM-BXM
Revision: BA
Serial Number: 688284
Supports: 8 Pts, OC3, MMF Md

Last Command: dspcd 4

Next Command:
```

## dspcds

Displays the cards in a shelf, front and back, with their type, revision, and status.

### Syntax

**dspcds** [1]

Example

**dspcds**

### Attributes

| Privilege | Jobs | Log | Node                               | Lock |
|-----------|------|-----|------------------------------------|------|
| 1-6       | No   | No  | IPX switch, IGX switch, BPX switch | No   |

### Related Commands

dncd, dspcd, resetcd, upcd

### Parameters-dspcds

| Parameter | Description                                                                                                                                                   |
|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1         | Directs the system to display status of the cards on just the lower shelf of an IPX 32 or IGX 8430. If not entered, dspcds displays the top shelf by default. |

### Description

For front and back card sets, the status field applies to the cards as a set. A letter “T” opposite a card indicates that it is running self-test. A letter “F” opposite a card indicates that it has failed a test. If lines or connections have been configured for a slot, but no suitable card is present, the display will list the missing cards at the top of the screen. If a special backplane is installed or if a card was previously installed, empty slots are identified as “reserved”.

For an IPX 32 or IGX 8430, the screen initially displays only the upper shelf with a “Continue?” prompt. Typing “y” to the prompt displays the cards in the lower shelf. The command **dspcds** followed by the letter “L” (for lower shelf) displays card status for just the lower shelf. For an IPX 8 or IGX 8410, the card information appears in only the left column. The status and update messages are as follows:

- Active                      Card in use, no failures detected.
- Active—F                    Card in use, failure(s) detected.
- Active—T                    Card active, background test in progress.
- Active—F-T                 Card active, minor failures detected, background test in progress.
- Standby                      Card idle, no failures.
- Standby—F                 Card idle, failure(s) detected.

- Standby—T            Card idle, background test in progress.
- Standby—F-T        Card idle, failure(s) detected, background test in progress.
- Failed                Card failed.
- Down                 Card downed by user.
- Down—F             Card downed, failure(s) detected.
- Down—T             Card downed, failure(s) detected, background test in progress.
- Mismatch            Mismatch between front card and back card.
- Update \*             Configuration RAM being updated from active control card.
- Locked\*             Incompatible version of old software is being maintained in case it is needed.
- Dnldng\*             Downloading new system software from the active BCC (BPX switch), or NPC (IPX switch or IGX switch), adjacent node, or from StrataView Plus.
- Dnlldr\*             Looking to adjacent nodes or StrataView Plus for either software to load or other software needs you have not specifically requested.

In the preceding messages, an asterisk (\*) means an additional status designation for BCC, NPC, or NPM cards. "F" flag in the card status indicates that a non-terminal failure was detected. Cards with an "F" status are activated only when necessary (for example, when no other card of that type is available). Cards with a "Failed" status are never activated.

### Example

Sample Display:

```
n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:40 PST
```

| FrontCard |         |      |      |        |         | BackCard  |          |      |           |     |         |
|-----------|---------|------|------|--------|---------|-----------|----------|------|-----------|-----|---------|
| Type      | Rev     | Type | Rev  | Status |         | FrontCard | BackCard |      | Status    |     |         |
| 1         | Empty   |      |      |        |         | 9         | ASI-155  | BE02 | MMF-2     | AB  | Standby |
| 2         | BXM-155 | BB16 | MM-8 | BA     | Active  | 10        | BME-622  | KDJ  | MM-2      | FH  | Active  |
| 3         | Empty   |      |      |        |         | 11        | BXM-E3   | BB16 | TE3-12P04 |     | Active  |
| 4         | BNI-E3  | CE08 | E3-3 | JY     | Active  | 12        | BXM-155  | BB16 | MM-8      | BA  | Active  |
| 5         | BNI-E3  | CE08 | E3-3 | EY     | Active  | 13        | BXM-155  | AC30 | SM-4      | P05 | Active  |
| 6         | BNI-T3  | CF08 | T3-3 | FH     | Active  | 14        | Empty    |      |           |     |         |
| 7         | BCC-3   | DJL  | LM-2 | AA     | Active  | 15        | ASM      | ACB  | LMASM     | P01 | Active  |
| 8         | BCC-3   | DJL  | LM-2 | AA     | Standby |           |          |      |           |     |         |

Last Command: dspcds

Next Command:

## dspnode

Displays a summary of interface devices connected to a routing node, or when executed from an IPX or IGX interface shelve shows the name of its hub node and trunk number.

### Syntax:

dspnode

### Related Commands

addshelf, delshelf, dsptrk

### Attributes

| Privilege | Jobs | Log | Node                   | Lock |
|-----------|------|-----|------------------------|------|
| 1-6       | No   | No  | BPX switch, IGX switch | Yes  |

### Description

The command displays tag switch controller devices connected to a BPX node and interface shelves connected to an IGX switch or BPX node. The command can be used to isolate the shelf or tag switch controller where an alarm has originated.

The routing nodes in a network do not indicate the interface shelf or tag switch controller where an alarm condition exists, so **dspnode** may be executed at a hub node to find out which interface device originated the alarm.

When executed on an IPX or IGX interface shelve, **dspnode** shows the name of the hub node and the trunk number. Note that to execute a command on an IPX or IGX interface shelf, you must either use a control terminal directly attached to the IPX or IGX switch or telnet to the IPX/AF, as the **vt** command is not applicable.

### Example

Displays information about tag switch controllers and interface shelves (executed on the BPX hub node).

Sample Display:

```
n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:40 PSTT
```

BPX Interface Shelf Information

| Trunk | Name | Type   | Alarm |
|-------|------|--------|-------|
| 3.1   | j6c  | AXIS   | MIN   |
| 5.3   | j5c  | IPX/AF | MIN   |
| 4.1   | VSI  | VSI    | OK    |
| 4.2   | VSI  | VSI    | OK    |
| 4.3   | VSI  | VSI    | OK    |

Last Command: dsnode

Next Command:

## dspqbin

Displays the configuration of the specified Qbin on a BXM.

### Syntax

**dspqbin** <slot.port> <qbin number>

### Example

**dspqbin 4.1 10**

### Attributes

| Privilege | Jobs | Log | Node       | Lock |
|-----------|------|-----|------------|------|
|           |      |     | BPX switch |      |

### Related Commands

cnfqbin

### Parameters-dspqbin

| Parameter   | Description                                                     |
|-------------|-----------------------------------------------------------------|
| slot.port   | The slot and port number of interest                            |
| qbin number | The qbin number. For EFT tag switching, this is Qbin number 10. |

### Description

The following example shows configuration of Qbin 10 on port 4.1 of a BXM card.

**Example**  
**dspqbin 4.1 10**

Sample Display:

```
n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:40 PST
```

```
Qbin Database 4.1 on EXM qbin 10
```

```
Qbin State: Enabled
Minimum Bandwidth: 0
Qbin Discard threshold: 65536
Low CLP/EPD threshold: 95%
High CLP/EPD threshold: 100%
EFCI threshold: 40%
```

```
This Command: dspqbin 4.1 10
```

```
Next Command:
```



## dsprsrc

Displays the tag switching resource configuration of the specified partition on a BXM card.

### Syntax

**dsprsrc** <slot.port> <partition>

### Example

**dsprsrc 4.1 1**

### Attributes

| Privilege | Jobs | Log | Node       | Lock |
|-----------|------|-----|------------|------|
|           |      |     | BPX switch |      |

### Related Commands

cnfrsrc

### Parameters-dspcds

| Parameter | Description                     |
|-----------|---------------------------------|
| slot.port | Specifies the BXM slot and port |
| partition | Specifies the vsi partition.    |

### Description

The following example shows configuration of vsi resources for partition 1 at BXM port 4.1.

#### Example Display:

```

n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:40 PST

Port/Trunk : 4.1

Maximum PVC LCNS: 256 Maximum PVC Bandwidth:26000

Min Lcn(1) : 0 Min Lcn(2) : 0
Partition 1

Partition State : Enabled
Minimum VSI LCNS: 512
Maximum VSI LCNS: 7048
Start VSI VPI: 2
End VSI VPI : 15
Minimum VSI Bandwidth : 26000 Maximum VSI Bandwidth : 100000

Last Command: dsprsrc 4.1 1

Next Command:

```

## dsptrks

Display information on the trunk configuration and alarm status for the trunks at a node. The trunk numbers with three places represent virtual trunks.

### Syntax

dsptrks

### Related Commands

addtrk, deltrk, dntrk, uptrk

### Attributes

| Privilege | Jobs | Log | Node                               | Lock |
|-----------|------|-----|------------------------------------|------|
| 1-6       | No   | No  | IPX switch, IGX switch, BPX switch | No   |

### Description

Displays basic trunk information for all trunks on a node. This command applies to both physical only and virtual trunks. The displayed information consists of:

- Trunk number, including the virtual trunk number (three places such as 4.1.10)
- Line type (E1, T3, or OC3, for example)
- Alarm status
- Device type at other end of trunk, such as node, interface shelf, tag switch controller.

For trunks that have been added to the network with the **addtrk** or **addshelf** command, the information includes the device name and trunk number at the other end. Trunks that have a “-” in the Other End column have been upped with **uptrk** but not yet added. For disabled trunks, the trunk numbers appear in reverse video on the screen. Virtual trunk numbers contain three parts, for example, 4.1.1.

## Example

Enter the dsptrks command as follows to display the trunks on a BPX switch:

### dsptrks

Sample Display:

```
n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:40 PST

TRK Type Current Line Alarm Status Other End
 2.1 OC3 Clear - OK j4a/2.1
 3.1 E3 Clear - OK j6c(Axis)
 5.1 E3 Clear - OK j6a/5.2
 5.2 E3 Clear - OK j3b/3
 5.3 E3 Clear - OK j5c(IPX/AF)
 6.1 T3 Clear - OK j4a/4.1
 6.2 T3 Clear - OK j3b/4
 4.1 OC3 Clear - OK VSI(VSI)
 4.2 OC3 Clear - OK VSI(VSI)
 4.3 OC3 Clear - OK VSI(VSI)
```

Last Command: dsptrks

Next Command:

## resetcd

The reset card command resets the hardware and software for a specified card.

### Syntax

```
resetcd <slot_num> <reset_type>
```

### Example

```
resetcd 5 H
```

### Attributes

| Privilege | Jobs | Log | Node                               | Lock |
|-----------|------|-----|------------------------------------|------|
| 1-3       | Yes  | Yes | IPX switch, IGX switch, BPX switch | Yes  |

### Related Commands

dspcd

Parameters-resetcds

| Parameter   | Description                                                                                                                                 |
|-------------|---------------------------------------------------------------------------------------------------------------------------------------------|
| slot number | Specifies the card number to be reset.                                                                                                      |
| H/F         | Specifies whether the hardware or failure history for the card is to be reset. An “H” specifies hardware; an “F” specifies failure history. |

### Description

A hardware reset is equivalent to physically removing and reinserting the front card of a card group and causes the card’s logic to be reset. When you reset the hardware of an active card other than a controller card (an NPC, NPM, or BCC), a standby card takes over if one is available. A failure reset clears the card failures associated with the specified slot. If a slot contains a card set, both the front and back cards are reset.

Do not use the reset command on an active NPC, NPM, or BCC because this causes a temporary interruption of all traffic while the card is re-booting. (Resetting a controller card does not destroy configuration information.) Where a redundant NPC, NPM, or BCC is available, the **switchcc** command is used to switch the active controller card to standby and the standby controller card to active. If a standby card is available, resetting an active card (except for a NPC, NPM, or BCC) does not cause a system failure. H/F Resetting of an active card that has no standby does disrupt service until the self-test finishes.

### Example 1

```
resetcd 3 H
```

### Sample Display:

No display is generated.

## upport

Displays the cards in a shelf, front and back, with their type, revision, and status.

### Syntax

**upport** <slot.port>

### Example

**upport 4.2**

### Attributes

| Privilege | Jobs | Log | Node       | Lock |
|-----------|------|-----|------------|------|
| 1-2       | Yes  | Yes | BPX switch | Yes  |

### Related Commands

dnport, cnfport, upln

### Parameters-dspcds

| Parameter | Description                                                            |
|-----------|------------------------------------------------------------------------|
| slot.port | Specifies the slot number and port number of the port to be activated. |

### Related Commands

dnport, cnfport, upln

### Description

The following example shows the screen that is displayed when the following command is entered to up a port on an ASI card:

upport 4.2

### System Response

Sample Display:

```
n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:40 PST

Port: 4.2 [ACTIVE]
Interface: T3-2
Type: UNI
Speed: 96000 (cps)

CBR Queue Depth: 200
CBR Queue CLP High Threshold: 80%
CBR Queue CLP Low Threshold: 60%
CBR Queue EFCI Threshold: 80%
VBR Queue Depth: 1000
VBR Queue CLP High Threshold: 80%
VBR Queue CLP Low Threshold: 60%
VBR Queue EFCI Threshold: 80%
ABR Queue Depth: 9800
ABR Queue CLP High Threshold: 80%
ABR Queue CLP Low Threshold: 60%
ABR Queue EFCI Threshold: 80%
```

Last Command: upport 4.2

Next Command:

## uptrk

Activates (or “ups”) a trunk.

### Syntax

```
uptrk <slot.port>[.vtrk]
```

### Example

```
uptrk 4.1
```

### Related Commands

addtrk, dntrk

### Attributes

| Privilege | Jobs | Log | Node                               | Lock |
|-----------|------|-----|------------------------------------|------|
| 1-2       | Yes  | Yes | IPX switch, IGX switch, BPX switch | Yes  |

### Parameters-uptrk

| Parameter | Description                                                                                                                                                         |
|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| slot.port | Specifies the slot and port of the trunk to activate. If the card has only one port, the <i>port</i> parameter is not necessary. An NTM, for example, has one port. |

### Optional Parameters-uptrk

| Parameter | Description                                                                                                                                                                                                  |
|-----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| vtrk      | Specifies the virtual trunk number. The maximum on a node is 32. The maximum on a T3 or E3 line is 32. The maximum for user traffic on an OC3/STM1 trunk is 11 (so more than one OC3/STM1 may be necessary). |

### Description

After you have upped the trunk but not yet *added* it, the trunk carries line signaling but does not yet carry live traffic. The node verifies that the trunk is operating properly. When the trunk is verified to be correct, the trunk alarm status goes to clear. The trunk is then ready to go into service, and can be added to the network.

If you need to take an active trunk between nodes out of service, the **dntrk** command may be used. However, this will result in temporary disruptions in service as connections are rerouted. The **dntrk** command causes the node to reroute any existing traffic if sufficient bandwidth is available.

Interface Shelves and Tag Switch Controllers: For interface shelves or tag switch controllers connected to a node, connections from those devices will also be disrupted when the links to them are deleted. For an interface shelf, the **delshelf** command is used to deactivate the trunk between the IGX or BPX routing node and the shelf.

Tag Switch Controller: For a tag switch controller, the **delshelf** command is also used to deactivate the link between the BPX routing node and the tag switch controller. In the case of tag switching, this is a link between a port on the BXM card and the tag switch controller. This link can be connected to a port that has been upped by either the **upport** or **uptrk** command, as the tag switching operation does not differentiate between these modes on the BXM.

Virtual Trunks: If you include the optional *vrk* parameter, **uptrk** activates the trunk as a *virtual* trunk. If the front card is a BXM (in a BPX switch), **uptrk** indicates to the BXM that it is supporting a trunk rather than a UNI port. (See the **upln** description for the BXM in port mode.)

You cannot mix physical and virtual trunk specifications. For example, after you up a trunk as a standard trunk, you cannot add it as a virtual trunk when you execute **addtrk**. Furthermore, if you want to change trunk types between standard and virtual, you must first down the trunk with **dntrk** then up it as the new trunk type.

You cannot up a trunk if the required card is not available. Furthermore, if a trunk is executing self-test, a “card in test” message may appear on-screen. If this message appears, re-enter **uptrk**.

### Example 1

Activate (up) trunk 21—a single-port card, in this case, so only the slot is necessary.

**uptrk 21**

### Example 2

This example shows the screen when BXM trunk 4.1 connected to a Tag Switch Controller is upped with the following command:

**uptrk 4.1**

Sample Display:

```

n4 TN SuperUser BPX 15 9.1 Apr. 4 1998 16:40 PST

TRK Type Current Line Alarm Status Other End
2.1 OC3 Clear - OK j4a/2.1
5.1 E3 Clear - OK j6c (AXIS)
5.1 E3 Clear - OK j6a/5.2
5.2 E3 Clear - OK j3b/3
5.3 E3 Clear - OK j5c (IPX/AF)
6.1 T3 Clear - OK j4a/4.1
6.2 T3 Clear - OK j3b/4
4.1 OC3 Clear - OK VSI (VSI)

```

Last Command: uptrk 4.1

Next Command:

### Example 3

Activate (up) trunk 6.1.1—a virtual trunk, in this case, which the third digit indicates.

**uptrk 6.1.1**



# BME Multicasting

---

This chapter contains an overview of multicasting and a description of the BME card used on the BPX switch for multicasting.

This chapter contains the following:

- Introduction
- Standards
- Multicasting Benefits
- Multicasting Overview
- Connection Management Criteria
- Connection Management with Cisco StrataView Plus
- BME Operation
- Alarms
- Hot Standby Backup
- Configuration
- Connection Diagnostics
- List of Terms
- Related Documents
- Configuration Management

## Introduction

The BME provides multicast services in the BPX switch. It is used in conjunction with a two-port OC-12 backcard.

Multicasting point-to-multipoint services meets the demands of users requiring virtual circuit replication of data (frame relay and ATM) performed within the network. Some examples of functions benefiting from multicasting are:

- Retail — point-of-sale updates
- Router topology updates
- Desktop multimedia
- Video conferencing

- Video distribution, e.g., IP multicast video networks to the desktop
- Remote learning
- Medical imaging

## Standards

- UNI 3.1 Multicast Server
- UNI 4.0 Leaf Initiated Joins and related standards

## Multicasting Benefits

Multicasting point-to-multipoint connections benefits include:

- Decreased delay in receiving data
- Near simultaneous reception of data by all leaves

## Multicasting Overview

### BME Features:

- The BME is a two-port OC12 card
- Supports up to 1000 multicast groups
- Supports up to 8064 connections, at 4032 per port. It can support the following combinations:
  - 1000 roots with 8 leaves in each multicast group
  - 100 roots with 80 leaves in each multicast group
  - 2 roots with 4000 leaves in each multicast group
  - or any other such combination.
- Supports CBR, UBR, VBR, and ATFR connections
- Hot standby

### BME Requirements

- Firmware of type BMEMK, where K is the model number for BME
- **upln** is used to bring up line 1 and line 2.
- **upport** is used to bring up port 1 and port 2, respectively.

## BME Restrictions

- BMEs can function in the following two BPX node configurations:
  - BCC-4s and BXMs only
  - BCC-3 control cards and legacy cards only, including BNIs and ASIs
- VC frame merge is not currently supported

## Address Criteria

- The VPI of a multicast connection indicates the multicast group to which it belong.
- The VPI.VCI assigned to a multicast connection is unique for that card.
- If the VCI = 0 for a multicast connection, this indicates a root connection.
- If the VCI is not = 0 for a multicast connection, this indicates a leaf connection.
- If the root connection of a given multicast group is added to port 1 of the two port card, then the leaves belonging to that multicast group must be added to port 2, and vice versa.

For example, if 12.1.50.0 is added on port 1, then the leaves should be 12.2.50.50, 12.2.50.100, 12.2.50.101 etc. Similarly, if a root 12.2.60.0 is added on port 2, then the leaves should be 12.1.60.101, 12.1.60.175, etc.

## Connection Management Criteria

Root connections and leaf connections can be added in any order:

- Add root first and then leaves
- Add leaves first and then root
- Add root in between adding leaves.

Root and leaf connections can be deleted in any order.

Root can be deleted and replaced with a new root.

## Connection Management with Cisco StrataView Plus

- Cisco StrataView Plus management includes the following functions:
  - Connection filtering by multicast type (root/leaf)
  - Multicast connection addition, deletion, and modification
  - Multicast view of multicast group of a selected connection
  - No multicast specific statistics support
  - No service MIB support

## BME Operation

Cables are connected between port 1 and port 2 of the backcard, transmit to receive and receive to transmit.

---


**Note** Removing the physical loopback cables or placing line 1 or 2 into loopback will prevent the cells from the root reaching the leaves.

---

## BME Cell Replication

Figure 10-1 shows a BME with a single root input multicasting with 3 leaves. The root connection can be added at a BPX switch (BPX switch A) distant from where the traffic is replicated by the BME card (BPX switch F) and routed through a number of BPX nodes. Similarly, the leaves can be routed from the multicasting node through a number of nodes before reaching their destination.

**Figure 10-1** Replication of a Root Connection into Three Leaves




11735

## Cell Replication Stats

As an example of how traffic appears on the BME, if there is one root at port 1 with two leaves at port 2, and traffic is passed on the root at 500 cells/sec, then one should see an egress port stat of 1000 cell/sec on port 1 and an ingress port stat of 1000 cells/sec on port 2, as shown in Figure 10-2.

**Figure 10-2 Example of Traffic, one root and two leaves**




## Adding Connections

Figure 10-3 shows two multicasting groups. For purposes of the illustration only a few leaves are shown for each connection. However, as described previously, each multicasting group could contain up to 8064 connections. Also, in this example, the two connections with a VCI of 0 each define a multicasting root connection. Their VPI defines a broadcasting group. For example, one group is defined by 2.1.70.0, where the VCI of zero defines the root connection to a BME, and the VPI of 70 defines a group. All the leaves in that group are of the form 2.2.70.x. The other group is defined by 2.2.80.0, where the VCI of zero defines the root connection to a BME, and the VPI of 80 defines a group. All the leaves in that group are of the form 2.1.80.x.

| Group 2.1.70.x   | Action            | Command                                                 |
|------------------|-------------------|---------------------------------------------------------|
| at bpx switch_F, | add input to root | addcon 2.1.70.0 bpx switch_A 1.1.80.100 c 500 * * *     |
| at bpx switch_F, | add leaf 1        | addcon 2.2.70.101 bpx switch_D 6.1.100.50 c 500 * * *   |
| at bpx switch_F, | add leaf 2        | addcon 2.2.70.100 bpx switch_C 4.3.50.60 c 500 * * *    |
| at bpx switch_F, | add leaf 3        | addcon 2.2.70.102 bpx switch_G 3.4.55.75 c 500 * * *    |
| Group 2.2.80.x   |                   |                                                         |
| at bpx switch_F, | add input to root | addcon 2.2.80.0 bpx switch_B 10.1.233.400 v 4000 * * *  |
| at bpx switch_F, | add leaf 1        | addcon 2.1.80.201 bpx switch_E 13.1.78.900 v 4000 * * * |
| at bpx switch_F, | add leaf 2        | addcon 2.1.80.100 bpx switch_E 14.1.100.40 v 4000 * * * |

Figure 10-3 Adding Multicasting Connections




11736

## Multi-Segment Multicast Connections

Figure 10-4 shows an example of a multi-segment multicast connection where a leaf connection from one BME can become a root connection for another BME. This capability allows the users to configure multi-segment multicast tree topologies.

Figure 10-4 Multi-Segment Multicast Connections



12140

## Multicast Statistics


Channel statistics are available for leaf connections on the BME end. However, channel statistics are not available for the root connection on the BME end.

For the example in Figure 10-5:

- **dspchstats** 12.1.50.75 on BPX switch 1 (available)
- **dspchstats** 5.1.75.0 on BPX switch 2 (not available)

- **dspchstats** 5.2.75.40 on BPX switch 2 (available)
- **dspchstats** 11.9.123.432 on BPX switch 3 (available)

**Figure 10-5 Statistics Collection**



## Policing

Policing is supported on all leaf connections on the BME end.

All policing types available on the BXM are available on the BME leaves


No policing functionality is available on the root connection on the BME end.

## Alarms

## OAM cells

OAM cells coming into the root are multicast into the leaves along with data, as shown in Figure 10-6.

**Figure 10-6 OAM Cells**




## AIS cells

AIS cells are automatically generated on the leaves, as shown in Figure 10-7, when:

- There is a loss of signal (LOS) on the far end of the root
- There is a trunk failure
- When the root connection is downed using the **dncon** command.

**Figure 10-7 Alarms**



12143

## Hot Standby Backup

BME cards can be set up to provide hot standby backup. Both cards are set up with port 1 connected to port 2 on the same card to provide the multicasting connection, transmit to receive and receive to transmit. There is no Y-cabling connection between the cards, and they do not have to be adjacent to each other.

The **addyred** command is used to enable hot standby backup between the cards. *The **addyred** command must be used before any connections are added to the active card.* The command will be rejected if used after connections have been added to the active card.



## Configuration

If the multicast tree has a large number of leaf connections, for example, 3000, then the **cnfportq** command should be used to configure the Qbin threshold to be greater than needed for half the number of leaves so as to assure that the multicast group will have no discards. The Qbin default depth is about 1200 cells.

Qbin example using **cnfportq** command:

```
j4b VT SuperUser ~ BPX 15 9.1.sj Feb. 24 1998 16:59 PST
Port: 3.2 [ACTIVE]
Interface: LM-BXM
Type: NNI
Speed: 1412830 (cps)
SVC Queue Pool Size: 0
CBR Queue Depth: 1200
CBR Queue CLP High Threshold: 80%
CBR Queue CLP Low Threshold: 60%
CBR Queue EFCI Threshold: 80%
VBR Queue Depth: 10000 UBR/ABR Queue Depth: 40000
VBR Queue CLP High Threshold: 80% UBR/ABR Queue CLP High Threshold: 80%
VBR Queue CLP Low Threshold: 60% UBR/ABR Queue CLP Low Threshold: 60%
VBR Queue EFCI Threshold: 80% UBR/ABR Queue EFCI Threshold: 30%
```

This Command: cnfportq 3.2  
SVC Queue Pool Size [0]:  
Virtual Terminal CD

## Connection Diagnostics

- **tstconseq** and **tsdelay** commands may be used to troubleshoot a leaf connection both from the BME end point as well as on the other end point
- **tstconseq** is available on the root connection only on the non-BME end point
- **tstconseq** is not supported from the BME end of the root connection
- **tsdelay** is not supported on root connections.

## List of Terms

BME

The card used in the BPX switch to provide multicasting.

## Related Documents

- *Cisco WAN Switching Command Reference Manual*

## Configuration Management

The BPX switch must be initially installed, configured, and connected to a network.

Following this, multi-casting connections can be added to the BPX switch.



# Repair and Replacement

---

This chapter describes periodic maintenance procedures, troubleshooting procedures, and the replacement of major BPX switch components.

The chapter contains the following:

- Preventive Maintenance
- Troubleshooting the BPX switch
- Replacing Parts

## Preventive Maintenance

Most monitoring and maintenance of the BPX switch is done via the BPX switch operating system software. Preventive maintenance of the BPX switch hardware is minimal and requires only the following:

- 1 Periodically check the node supply voltage and internal cabinet temperature with the **dspasm** command. It should not exceed 50°C.
- 2 Periodically check the event log with the **dsplog** command.
- 3 Periodically check the network alarm status with the **dspalms** command.

## Troubleshooting the BPX Switch

This section describes basic troubleshooting steps to be taken for some of the more obvious node failures (refer to Table 11-1). This is not an exhaustive set of procedures, and does not take into account any of the diagnostic or network tools available to troubleshoot the BPX switch. Refer to the *Cisco WAN Switching Command Reference* for information on commands and command usage.



**Caution** Do not perform any disruptive tests or repairs to the BPX switch on your own. Before proceeding with troubleshooting, call Customer Service so they can provide you with assistance in locating the fault and provide repair information.

## General Troubleshooting Procedures

The BPX switch runs self tests continuously to ensure proper function. When the node finds an error condition that affects its operation, it downs the card or trunk affected. It then selects a standby card or alternate trunk if one is available.

The FAIL indicators on the cards indicate that the system has found these cards defective in some mode, and now considers them as failed cards. Use Table 11-1 to find the cause and obtain the information on replacing the failed component.



**Caution** When using Table 11-1 for troubleshooting, call Customer Service before performing any disruptive testing or attempting to repair the BPX switch. This ensures that you have isolated the correct problem area. It also enables Customer Service to provide assistance in performing the necessary procedures.



**Warning** Contact Customer Service before attempting to replace fuses on backplane and refer to instructions in Replacing Card Slot and Fan Fuses on the System Backplane.

**Table 11-1 Troubleshooting the BPX Switch**

| Symptom                                                   | Probable Cause                                                                                                                                                                                         | Remedy                                                                                                                                                                                                                                    |
|-----------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Front panel LED on individual card not lighted.           | Card Fuse.                                                                                                                                                                                             | Check card fuse. Replace if defective.<br><br>Try another card of the same type. If still no LED lighted, backplane card slot fuse may be defective. Refer to Replacing Card Slot and Fan Fuses on the System Backplane.                  |
| No front panel LEDs are lighted.                          | AC Systems:<br>Circuit Breakers on AC Power Supply Tray.<br><br>DC Systems:<br>Circuit breakers on Power Entry Module(s) switched off.<br><br>BPX switch power cord plug dislodged from AC receptacle. | Switch on circuit breakers. If problem persists, pull all cards and power supplies out to see if a shorted card or supply exists.<br><br>Check that no one is working on the system, shut off source breaker, then reconnect power cord.  |
| Power supply <b>ac</b> LED lit but <b>dc</b> LED not lit. | Power supply defective.                                                                                                                                                                                | Check DC ok LEDs on ASM. If out, remove and replace power supply. If on, PS LED probably defective.                                                                                                                                       |
| Card front panel <b>fail</b> LED lit.                     | Card failed self-test.                                                                                                                                                                                 | Check status of card at NMS terminal using <b>dspcds</b> screen. If alarm confirmed, try card reset ( <b>resetcd</b> command). Finally, remove and replace the card.                                                                      |
| Card <b>stby</b> LED on.                                  | Card is off-line.                                                                                                                                                                                      | Not a problem as long as primary card is active.                                                                                                                                                                                          |
| ASM <b>major</b> or <b>minor</b> LED on.                  | Service-affecting (major) or non-service affecting (minor) system fault.<br><br>Failed card in local node.<br><br>Network trunk failed.                                                                | Check NMS event log to identify problem reported.<br><br>See remedy for card <b>fail</b> LED indication.<br><br>Observe <b>Port</b> LEDs on each BNI or BXM (ports configured in trunk mode).<br>Use NMS <b>dsptrk to</b> locate failure. |
|                                                           | Failure in remote node. May be another BPX switch or an IPX switch.                                                                                                                                    | Use NMS <b>dspnw</b> screen to locate node in alarm. Refer to <i>Cisco WAN Switching Command Reference</i> for additional information.                                                                                                    |
|                                                           | Internal temperature is higher than normal resulting from blocked air flow or defective fan.                                                                                                           | Check front and back of node cabinet for freedom of air flow. Replace any fan that may have failed or slowed. Use NMS <b>dspwr</b> screen to check node temperature.                                                                      |
| ASM <b>hist</b> LED lit.                                  | If no other alarm indications, a fault occurred in the past but has been cleared.                                                                                                                      | Press ASM <b>history clear</b> button. Check NMS event log to determine cause.                                                                                                                                                            |

**Table 11-1 Troubleshooting the BPX Switch (Continued)**

| Symptom                                                               | Probable Cause                                                                                                                          | Remedy                                                                                                                                                                       |
|-----------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| BXM <b>Port</b> LED is red or orange (BXM configured for trunk mode). | Trunk is in local or remote alarm.                                                                                                      | Use NMS <b>dsptrk</b> screen to confirm trouble.                                                                                                                             |
| BNI <b>Port</b> LED is red or orange.                                 | Trunk is in local or remote alarm.                                                                                                      | Use NMS <b>dsptrk</b> screen to confirm trouble. Use short BNC loopback cable at LM-BNI connectors for local test of trunk. Loop trunk at DSX-3 crossconnect to check cable. |
| No BXM <b>card</b> or <b>port</b> LED on.                             | No trunks or lines, as applicable on card are upped. Card has not necessarily failed.                                                   | Up at least one of the trunks or lines, as applicable, associated with the card (Trunks if BXM configured for trunk mode, lines if BXM configured for port mode).            |
| No BME <b>card</b> or <b>port</b> LED on.                             | No lines are upped. Card has not necessarily failed.                                                                                    | Up at least one of lines, as applicable, associated with the card.                                                                                                           |
| No BNI <b>card</b> or <b>port</b> LED on.                             | No trunks on card are upped. Card not necessarily failed.                                                                               | Up at least one of the trunks associated with the card.                                                                                                                      |
| BXM <b>Port</b> LED is red or orange (BXM configured for port mode)   | Line is in local or remote alarm.                                                                                                       | Use NMS <b>dsplns</b> screen to confirm trouble.                                                                                                                             |
| BME <b>Port</b> LED is red or orange                                  | Line is in local or remote alarm.                                                                                                       | Use NMS <b>dsplns</b> screen to confirm trouble.                                                                                                                             |
| ASI <b>Port</b> LED is red or orange.                                 | Line is in local or remote alarm.                                                                                                       | Use NMS <b>dsplns</b> screen to confirm trouble.                                                                                                                             |
| No ASI <b>card</b> or <b>port</b> LED on.                             | No lines on card are upped. Card not necessarily failed.                                                                                | Up at least one of the two lines associated with the card.                                                                                                                   |
| BCC <b>fail</b> LED flashing                                          | Downloading system software or configuration data.                                                                                      | Wait for download to complete.                                                                                                                                               |
| BCC <b>LAN</b> LED flashing                                           | Normal for node connected to NMS terminal over Ethernet. If it does <b>not</b> flash, there may be problems with node to NMS data path. | Check that the cabling to the NMS is firmly connected to the LAN port on the LM-BCC back card. An alternate connection is to the control port.                               |
| No BCC card LED on.                                                   | Preparing to download new software (momentary condition).                                                                               | Wait for download to begin.                                                                                                                                                  |
|                                                                       | Command issued to run a software rev. that was not available in the network.                                                            | Check that proper s/w rev. is available on another node or on NMS.                                                                                                           |

## Displaying the Status of Cards in the Node

When a card indicates a failed condition on the alarm summary screen, use the Display Cards (**dspecds**) command to display the status of the circuit cards on a node. The information displayed for each card type includes the card slot number, software revision level, and the status of the card. The possible status description for each card type are listed in Table 11-2. Refer to the *Cisco WAN Switching Command Reference* for more information on the Display Cards command.

**Table 11-2 Card Status for the BPX Switch**

| Card Type      | Status <sup>1</sup>                      | Description                                                                                                                                      |
|----------------|------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
| All card types | Active                                   | Active card.                                                                                                                                     |
|                | Active - F                               | Active card with no terminal failure.                                                                                                            |
|                | Standby                                  | Standby card.                                                                                                                                    |
|                | Standby - F                              | Standby card with no terminal failure.                                                                                                           |
|                | Standby - T                              | Standby card performing diagnostics.                                                                                                             |
|                | Standby - F -T                           | Standby card with no terminal failure performing diagnostics.                                                                                    |
|                | Failed                                   | Card with terminal failure.                                                                                                                      |
|                | Unavailable                              | Card is present but it may be in one of the following states:<br>a. The node does not recognize the card.<br>b. The card is running diagnostics. |
|                | Down                                     | Downed card.                                                                                                                                     |
|                | Empty                                    | No card in that slot.                                                                                                                            |
| BCC            | Same status as for all card types, plus: |                                                                                                                                                  |
|                | Updating                                 | Standby BCC downloading the network configuration from an active BCC.<br>Note: Red FAIL LED flashes during updating.                             |
|                | Cleared                                  | BCC is preparing to become active.                                                                                                               |
|                | Downloading Software                     | There are downloader commands that appear when the system is down- loading software to the BCC.                                                  |
|                | Minor                                    | BCC Redundancy alarm indicates node is configured for redundancy but no standby BCC is equipped.                                                 |

1. Cards with an F status (no terminal failure) are activated only when necessary. Cards with a failed status are never activated.

## Replacing Parts

After an alarm occurs, use the BPX switch software to isolate the problem. If an BPX switch part has failed, then it must be replaced.



**Caution** Only authorized personnel should remove and replace parts on the BPX switch system.

Parts should be replaced only by qualified personnel who have taken the Cisco training courses or been trained by a qualified system manager. For assistance in diagnosing or replacing a failed part, call Customer Service.

When replacing a part, save the electrostatic bag, foam, and carton that the new part comes in. These packaging materials are needed for returning the failed part to Cisco. Contact Customer Service for information on returning parts.

## Replacing a Front Card

The BPX switch front cards are as follows:

- Broadband Controller Card (BCC)
- BXM-T3/E3, BXM-155, BXM-622
- Broadband Network Interface Card (BNI)
- Alarm and Status Monitor (ASM)
- Access Service Interface (ASI-1)



**Caution** Ground yourself before handling BPX switch cards by placing a wrist strap on your wrist and clipping the wrist strap lead to the cabinet.

When a card has failed, the red FAIL indicator for that card turns on. Before replacing it, check to see if the card only needs to be reseated. After reseating the card, wait for it to run its self-tests to see if the ACTIVE light comes on. If the card is seated correctly, but the FAIL light is still on, replace the card.

To remove a front card, perform the following steps:

- Step 1** If the front panel **fail** lamp is on, remove the card and go to Step 3. Otherwise, go to Step 2.
- Step 2** Check the status of the card using the **dspcd** or **dspcds** commands. It should be failed or standby if the node is actively carrying traffic.
- Step 3** If an active card (ASI, BNI) needs to be replaced, “down” it first with the **dncd** command. Removing an active card affects operation only slightly if there is a standby card.
- Step 4** If a BCC has failed, the other BCC will switch from standby mode to active. Use the **dspcd** command to verify that the standby BCC has entered the active mode. Then you can remove the failed BCC.



**Caution** Never remove the active BCC until the standby BCC has entered the “active” mode. Using the **dspcd** command is the only reliable way to determine that the standby BCC has finished updating and has entered the “active” mode.

- Step 5** Unlatch the Air Intake Grille. Locate the small access hole in the top, center of the Air Intake Grille.
- Step 6** Fully insert a medium, flat-bladed screwdriver in the access hole.
- Step 7** Rotate the screwdriver to release the spring latch holding the grille. (Figure 11-1). The top of the grille should pop out.
- Step 8** Tilt the grille forward to approximately a 45° angle.
- Step 9** Put on a wrist strap to discharge any static.
- Step 10** Rotate the top and bottom card extractors on the front of the card.
- Step 11** Hold the card at the top and bottom and gently slide it out of the slot.

To install a front card in the BPX switch, perform the following steps:

- Step 1** Unlatch the Air Intake Grille as described in Step 5 through Step 8 of the previous procedure for removing the front card.
- Step 2** Remove the replacement card from the antistatic shipping container.
- Step 3** Hold the replacement card at top and bottom and gently insert it over the guides, and slide it all the way to the rear of the cabinet.

---


**Note** The card should slide in easily with a light sliding friction from the EMI gaskets on adjacent cards. If it does not, check to see if there is anything restricting it—do not use excessive force.

---

- Step 4** Rotate the top and bottom latches on the card and push the card into the rear connector. You will feel the card seat itself as you push it in.
- Step 5** Press firmly on the top and bottom extractors to complete the card seating process. The extractor should snap back to a vertical position after the card is properly seated.
- Step 6** Replace the air intake grille by swinging it up and pressing in at the top until the latch snaps into place.



Figure 11-1 Unlatching the Air Intake Grille



## Replacing a Line Module

The configuration of the back card may be slightly different depending on whether it is a single card or redundant card configuration. A standby card in a redundant card configuration may be removed without disrupting system operation even if it is a BCC. Removing a single card, however, will cause a system outage.



**Caution** Removing an active, single back card disrupts service on the node.

To remove a line module, perform the following steps:

- Step 1** Check the status of the card using the **dspcd** or **dspcds** command. It should be failed or standby or replacement will affect operation of the node.
- Step 2** If an active card needs to be replaced, “down” it first with the **dncd** command. Removing an active card affects operation only slightly if there is a standby card.
- Step 3** Before removing a LM-BCC, make sure the standby BCC **stby** indicator is on steady. A flashing **stby** indicator indicates it is in the process of downloading either configuration data or software and is not ready to accept a transfer.
- Step 4** For a single card configuration, disconnect the cables from the back card face plate. Make a note of the location of each cable so that it can be replaced correctly.
- Step 5** For a redundant card configuration, disconnect the appropriate leg of the Y-cable connecting to the back card to be replaced. **DO NOT REMOVE THE OTHER LEG GOING TO THE BACKUP CARD.**

**Step 6** Loosen the two captive screws on the back card faceplate and, pulling on the top and bottom card extractors, slide the card straight out of the shelf slot. (See Figure 11-2.)

To install a line module, perform the following steps:


**Step 1** Insert the line module (e.g., LM-3T3) into the slot from which the defective card was removed (see Figure 11-2).

**Step 2** Tighten the two captive screws. (Tighten securely, but do not overtighten.)

**Step 3** Reconnect the T3 trunk cables to the LM-3T3 connectors from which they were disconnected.

**Step 4** Perform the appropriate steps to bring the lines that were disconnected back on line.

Figure 11-2 Removing a Line Module




## Replacing a DC Power Entry Module

DC Power Entry Modules (PEMs) contain few active components so they should rarely need replacement. Access is from the back of the node. To remove a PEM, proceed as follows:

- Step 1** Check the node system voltage by using the Display Power (**dsppwr**) command. Note which input has failed, A or B. Power Supply A is the unit on the right side facing the rear of the node.
- Step 2** Turn off the primary source of power to the PEM to be replaced.
- Step 3** Turn off the circuit breaker on the PEM to be replaced.
- Step 4** Remove the two screws holding the conduit box cover (see Figure 11-3). Or, remove the plastic cover plate over the input terminal block.
- Step 5** Remove the power input wiring at the PEM terminal block.

Figure 11-3 DC Power Entry Module with Conduit Box



- Step 6** If a conduit box is used, remove it. Remove the ground screw above the middle terminal block connector (see Figure 11-3).
- Step 7** Remove the two standoffs on each side of the terminal block and pull the conduit box straight back. Set it aside. Do not try to remove the terminal block.
- Step 8** Loosen the two captive screws (at the bottom corners) holding the PEM. Loosen the two connector jackscrews adjacent to the finger pull.
- Step 9** Grasp the finger pull lip at the top of the PEM and pull the unit straight out.
- Step 10** Replacement is the reverse of removal.


## Replacing an AC Power Supply

BPX switches are powered by redundant power supplies; either power supply can supply the current requirements of the node. The AC Power Supply is part of an assembly which is replaced as a single unit. Access to the AC Power Supply assembly is from the front, but first, the Air Intake Grille must be removed.

To remove a power supply, proceed as follows:

- Step 1** If you haven't already done so, check the status and output voltage of the power supplies at the node using the `dspasm` command. Note which power supply is failed, A or B. Power supply A is on the right side facing the rear of the node.
- Step 2** Remove the Air Intake Grille. Locate the small access hole in the top, center of the Air Intake Grille.
- Step 3** Fully insert a flat-bladed screwdriver (with a 1/4 in. blade) in the access hole.
- Step 4** Rotate the screwdriver to release the spring latch holding the Air Intake Grille (see Figure 11-4). The grille should pop out.

**Figure 11-4 AC Power Supply Assembly**



- Step 5** Tilt the grille forward approximately a 45° angle, then lift it out and set it aside. This exposes the power supply retainer bracket.
- Step 6** With a flat-bladed screwdriver, loosen the retainer bracket hold-down screw in the center of the bracket and tilt the bracket.
- Step 7** Identify which power supply needs replacement. Power supply A is the unit on the left, B is on the right. In most cases, the failed unit will be identified by a front panel lamp indication.


- Step 8** There are two power supply securing fasteners, one on each side of the power supply assembly (Figure 11-4). The one on the left of each supply is a spring-loaded pin, the one on the right of each supply is a normal thumb-screw. Loosen the thumb-screw on the right.
- Step 9** With the right hand, grip the power supply under the front panel. With the left hand, pull out the spring-loaded pin on the left side of the supply and hold it out as you pull out the power supply assembly.
- Step 10** The power supply assembly weighs approximately 15 pounds (33 Kgs.). Support the bottom of the power supply as you pull it straight out, until it is free of the shelf.

## Field-Installing a Second AC Power Supply

To field-install a redundant power supply, perform the following steps:

- Step 1** If the front Air Intake Grille has already been removed, go to the next step. If not, remove it using Step 2 through Step 6 of the previous procedure.
- Step 2** If converting a node from single to redundant powering, first remove the blank filler panel over position B (right side). With Air Intake Grille open, remove three screws attaching the filler panel to the retainer bracket (see Figure 11-5).

**Figure 11-5** Removing Blank Filler Panel (B side shown)



- Step 3** Slide a replacement power supply assembly into the tracks of the power supply shelf.
- Step 4** When the power supply is completely seated, the spring-loaded pin will snap into place to assure that the power supply has mated with its connector.

- Step 5** Screw in the thumb-screw on the right side of the power supply assembly until it is finger tight.
- Step 6** Flip the retaining bracket up and tighten its thumbscrew.
- Step 7** Reinstall the Air Intake Grille and press firmly on the top, center of the Air Intake Grille until the latch snaps into place.
- Step 8** Check the status and output voltage of the replacement power supply using the **dspasm** command. Make sure the status is OK and the output voltage is 48V.

## Replacing the Fan Assembly

The Fan Assembly provides the primary cooling for the BPX switch and is located at the top, rear of the BPX switch cabinet. There are three fans in the Fan Assembly. The fan on the right (number 1) and the one on the left (number 3) can be changed out individually with very little effort or interruption in the operation of the node. The fan in the middle (number 2) requires powering down the node and removing the Fan Assembly to replace.



**Caution** You must work quickly but carefully to prevent heat buildup in the node which could damage the cards.

To replace fan number 1 or number 3 in the Fan Assembly, perform the following steps:

- Step 1** Use the **dspasm** command to check the status of the three fans.
- Step 2** From the rear of the BPX switch, visually check that the fan(s) is indeed not turning or turning slowly.
- Step 3** From the back of the cabinet, unplug the small fan power cord from its appropriate receptacle on the Fan Assembly.
- Step 4** Remove the two screws holding the fan and the fan shield to the-fan housing. Be careful not to drop the hardware into the rear of the cabinet.
- Step 5** Remove the fan. Replace the fan in reverse order. Use the existing fan grille.

To replace fan number 2 requires powering down the node and replacing the whole Fan Assembly. Under normal ambient room temperatures, this can be scheduled for the next available quiet time. Perform the following steps:

- Step 1** Use the **dspasm** command to check the status of the three fans.
- Step 2** From the rear of the BPX switch, visually check that fan number 2 is not turning or turning slowly.
- Step 3** At the rear of the BPX switch, turn the circuit breaker(s) OFF to power down the node.
- Step 4** Loosen the eight captive screws holding the Fan Assembly in place.
- Step 5** With one hand, pull the Fan Assembly back just far enough to gain access to the Fan Assembly power cord. This cord connects to the Fan Assembly to the backplane.
- Step 6** Unplug the power cord and remove the Fan Assembly.
- Step 7** Plug the power cord in the replacement Fan Assembly into the backplane connector.
- Step 8** Install the replacement Fan Assembly.
- Step 9** Tighten the eight screws holding the Fan Assembly in place.

### Replacing the Temperature Sensing Unit

The temperature sensing unit is located on the ASM card. If the temperature indication using the `dspasm` command does not appear to be correct, try a replacement ASM card.

### Replacing Card Slot and Fan Fuses on the System Backplane

There is a separate fuse provided on the System Backplane for each card slot. These fuses are numbered F4 through F18, corresponding to card slots F15 down through F1 (see Figure 11-6). There are three separate fan fuses provided on the System Backplane. These fuses are numbered F1 through F3, corresponding to Fans 1 through 3 (see Figure 11-6).




**Warning** For both personnel safety and to prevent equipment damage, power down the BPX switch before replacing fan fuses F1 through F3, or card slot fuses F4 through F18 on the System Backplane. For continued protection against risk of fire, replace only with same type and rating of fuse.

Backplane fuses rarely need replacement. Backplane fuses are intended to prevent catastrophic damage to the backplane in the event of accidental shorting of -48VDC on the backplane to chassis ground. This type of event could be caused by bent backplane pins, inadvertent contact of conductive elements (EMI Cans, EMI Gaskets, etc.) to power pins, or (in the case of a fan fuse) a pinched wire harness.

These fuses are located in sockets on the backplane and are therefore not readily accessible. A special tool and a special set of instructions are required for fuse replacement. It is recommended that only factory-trained personnel perform the procedure. Contact Customer Service for further information.



Figure 11-6 Card Slot and Fan Fuse Locations on System Backplane





# Frame Relay to ATM Network and Service Interworking

---

This chapter describes Frame Relay to ATM interworking. Frame Relay to ATM Interworking allows users to retain their existing Frame Relay services, and as their needs expand, migrate to the higher bandwidth capabilities provided by BPX switch ATM networks.

This chapter contains the following:

- Service Interworking
- Networking Interworking
- ATM Protocol Stack
- AIT/BTM Interworking and the ATM Protocol Stack
- AIT/BTM Control Mapping, Frames and Cells
- Management, OAM Cells
- Functional Description
- Management


Frame Relay to ATM Interworking enables frame relay traffic to be connected across high-speed ATM trunks using ATM standard Network and Service Interworking (see Figure 12-1 and Figure 12-2).

Two types of Frame Relay to ATM interworking are supported, Network Interworking and Service Interworking. The Network Interworking function is performed by the AIT card on the IPX switch and by the BTM card on the IGX switch. The FRSM card on the MGX 8220 supports both Network and Service Interworking. See Figure 12-3 for some examples of ATM to Frame Relay Interworking.

**Figure 12-1 Frame Relay to ATM Network Interworking**


**Part A**

Network interworking connection from CPE Frame Relay port to CPE Frame Relay port across an ATM Network with the interworking function performed by both ends of the network.



**Part B**

Network interworking connection from CPE Frame Relay port to CPE ATM port across an ATM network, where the network performs an interworking function only at the Frame Relay end of the network. The CPE receiving and transmitting ATM cells at its ATM port is responsible for exercising the applicable service specific convergence sublayer, in this case, (FR-SSCS).



**Figure 12-2 Frame Relay to ATM Service Interworking**





Figure 12-3 Frame Relay to ATM Interworking Examples with AIT Card on IPX Switch



AIT Interworking Examples

S5239


## Service Interworking

In Service Interworking, for example, for a connection between an ATM port and a frame relay port, unlike Network Interworking, the ATM device does not need to be aware that it is connected to an interworking function. The ATM device uses a standard service specific convergence sublayer, instead of using the Frame Relay FR-SSCS (see Figure 12-4).

The frame relay service user does not implement any ATM specific procedures, and the ATM service user does not need to provide any frame relay specific functions. All translational (mapping functions) are performed by the intermediate IWF. The ATM endpoints may be any ATM UNI/NNI

interface supported by the MGX 8220, e.g., ASI, AUSM. Translation between the Frame Relay and ATM protocols is performed in accordance with RFC 1490 and RFC 1483.

Figure 12-4 Frame Relay to ATM Service Interworking Detail





## Networking Interworking

In Network Interworking, in most cases, the source and destination ports are frame relay ports, and the interworking function is performed at both ends of the connection as shown in Part A of Figure 12-5.

If a frame relay port is connected across an ATM network to an ATM device, network interworking requires that the ATM device recognize that it is connected to an interworking function (frame relay, in this case). The ATM device must then exercise the appropriate service specific convergence sublayer (SSCS), in this case the frame relay service specific convergence sublayer (FR-SSCS) as shown in Part B of Figure 12-5.

Figure 12-5 Frame Relay to ATM NW Interworking Detail




The frame relay to ATM networking interworking function is available as follows:

- IPX switch frame relay (shelf/feeder) to IPX switch frame relay (either routing node or shelf/feeder).
- MGX 8220 frame relay to MGX 8220 frame relay.
- MGX 8220 frame relay to IPX switch frame relay (either routing node or shelf/feeder).
- IPX switch frame relay (either routing node or shelf/feeder) to BPX switch or MGX 8220 ATM port.
- MGX 8220 frame relay to BPX switch or MGX 8220 ATM port.
- In the items listed above, an IGX switch can be substituted for each instance of an IPX switch.

On the IPX switch, interworking is performed by the AIT card, and on the IGX switch by the BTM card. A simplified example of the connection paths is shown in Figure 12-6. In interworking, the AIT card receives FastPackets from the FRP, rebuilds the frames, and converts between frames and ATM cells. Data is removed from one package and placed in the other. Congestion information from the header is mapped to the new package. This processing by the AIT trunk card is called Complex Gateway. AIT trunk cards are required on every BPX switch to IPX switch hop in a Frame Relay to ATM connection's path.

**Figure 12-6 ATF Connections, Simplified Example**



The cells within the frame are expected to possess the standard ATM Access Interface cell header. The traffic is assumed to have AAL-5 PDUs, and will not function properly otherwise (framing errors will result). Within the AAL-5 PDUs, the data must be packaged in standard frame relay frames, one frame per PDU (with respect to the AAL-5 layer).

The UPC and ForeSight algorithms are applied according to their configured values. The cell headers are converted into the proprietary Cisco WAN switching STI format before entering the network. The cells are delivered to their destination according to the configured route of the connection. Cells can be lost due to congestion.



Discard selection is based upon the standard CLP bit in the cells. When the routing path enters an IPX/IGX switch, an AIT/BTM card which supports Interworking traffic is required to convert the connection data from cells to frames (frames to fastpackets out onto MuxBus to FRP/cell bus to FRM), and visa versa. Additionally, the AAL-5 framing is removed upon conversion to frames, and added upon conversion to cells. At the destination (FRP), FastPackets are placed in the port queue and, when a complete frame has been assembled, the frame is played out the remote port in the original format (as provided in the frames delivered inside AAL-5 PDUs).


For each connection, only a single dlcI can be played out for all traffic exiting the port, and is inserted into the frame headers. The standard LAPD framing format is played out the port on the FRP/FRM.

At the AIT/FRM card, several additional protocol mappings take place. First, the Interworking Unit acts as a pseudo endpoint for the purposes of ATM for all constructs which have no direct mapping into Frame Relay, such as loopbacks and FERF indications. Thus, end-to-end loopback OAM cells which come to AIT/FRM cards are returned to the ATM network without allowing them to proceed into the Frame Relay network, which has no equivalent message construct. Further, AIS and supervisory cells and FastPackets (from the Frame Relay direction) are converted into their counterparts within the other network.

## ATM Protocol Stack

A general view of the ATM protocol layers with respect to the Open Systems Interconnection model is shown in Figure 12-7. In this example, a large frame might be input into the top of the stacks. Each layer performs a specific function before passing it to the layer below. A protocol data unit (PDU) is the name of the data passed down from one layer to another and is the Service Data Unit (SDU) of the layer below it. For Frame Relay to ATM interworking, a specific convergent sublayer, Frame Relay Service Specific Convergent Sublayer, FR-SSCS is defined. This is also referred to as FR-CS, in shortened notation.

Figure 12-7 ATM Layers



## AIT/BTM Interworking and the ATM Protocol Stack


ATM to Frame Relay interworking (ATF) performs various tasks including the following:

- Conversion of PDUs between the frame relay and ATM virtual circuits of the frame relay and ATM user devices.
- Conversion between frame relay traffic service and ATM quality of service parameters.
- Mapping of management status, including connection, port, line, and trunk status and events.

Figure 12-8 depicts the function of the protocol stack layers in the interworking between ATM and Frame Relay PDUs. Interworking by the AIT/BTM card in the IPX/IGX switch includes the following functions:

- Translating the ATM pvc identifier (vpi.vci) to the frame relay pvc identifier (dlci) and vice versa.
- Mapping the Protocol Data Unit (PDU), which is essentially the data, between the Frame Relay Service Specific Convergence Sublayer (FR-SSCS) and the Frame Relay Q.922 core protocol, and vice versa.
- On the IPX switch, Incoming Frames are converted to FastPackets by the FRP card. The FastPackets are then routed to the AIT card via the IPX switch MUX bus and converted back into Frame Relay Q.922 frames by the AIT card. The AIT card interworking function executes four layers to convert the Frame PDU to ATM cells:
  - FRCS layer (Frame Relay Service Specific Convergence Sublayer, FRSSCS, or FRCS for in shortened notation) which uses a PDU format identical to the Q.922 core (without CRC-16 or flags).
  - CPCS layer (Common Part Convergence Sublayer) which appends a CS-PDU trailer to the FR-PDU to create a CS-PDU.
  - Segmentation and Reassembly layer (SAR) which segments the CS-PDU (Protocol Data Unit) into SAR-PDUs (48 byte data entities).
  - ATM layer which attaches an ATM header to each SAR-PDU to create an ATM-SDU (Service Data Unit). The same process is performed in the reverse order by the AIT card when transforming cells to frames.

Figure 12-8 Protocol Stack Operation



## AIT/BTM Control Mapping, Frames and Cells

In addition to performing DLCI to PVC/VCC conversion, the network interworking feature provided by the AIT card in the IPX switch or BTM in the IGX switch maps cell loss priority, congestion information, and management information between frame relay and ATM formats as follows:

### CELL LOSS PRIORITY, Frame Relay to ATM Direction

Each frame relay to ATM network interworking connection can be configured as one of the following DE to CLP mapping choices:

- The DE bit in the frame relay frame is mapped to the CLP bit of every ATM cell generated by the segmentation process.

The following 2 choices are not available on IPX/IGX switch NIW (network interworking):

- CLP is always 0.
- CLP is always 1.

### CELL LOSS PRIORITY, ATM to Frame Relay Direction

Each frame relay to ATM network interworking connection can be configured as one of the following CLP to DE mapping choices:

- If one or more ATM cells belonging to a frame has its CLP field set, the DE field of the frame relay frame will be set.

The following choice is not available:

- Choosing no mapping from CLP to DE.

### CONGESTION INDICATION, Frame Relay to ATM direction

- EFCI is always set to 0.

### CONGESTION INDICATION, ATM to Frame Relay Direction

- If the EFCI field in the last ATM cell of a segmented frame is set, then FECN of the frame relay frame will be set.

### For PVC Status Management

The AIT/BTM does convert OAM cells to OAM fastpackets, and vice-versa, including the AIS OAM. Also, "A-bit" status is now propagated via software messaging.

The ATM layer and frame relay PVC Status Management can operate independently. The PVC status from the ATM layer will be used when determining the status of the FR PVCs. However, no direct actions of mapping LMI A bit to OAM AIS will be performed.

## Management, OAM Cells

OAM cell processing:

- F5 OAM loopback
- AIS
- FERF
- Cisco WAN switching Internal OAM

## Functional Description

### ATF Summary

#### Features

- Interworking: ATM to Frame Relay connections
- Connection Statistics
- Round Trip Delay measurements incorporated into the ForeSight algorithm
- Frame Based GCRA (FGCRA). This is an enhancement of the Generic Cell Rate Algorithm
- IBS (Initial Burst Size)
- cnfportq: 3 egress port queues are configurable CBR, VBR and VBR w/Foresight. (Queue Bin numbers and algorithm types are NOT user selectable.)
- BCM (Backward Congestion Messages)
- ILMI and associated configuration options and statistics
- Loopback functions: **tstdly**, **tstconseg**, **addrmtlp**, **addloclp**
- Selftest/ Background tests
- OAM flows: AIS, FERF, OAM loopback
- ASI/2 E3 support
- End-to-end status updates (per FR/ATM interworking)
- Annex G and associated configuration options and statistics
- ASI-1 as a clock source is supported.

#### Limitations

- Priority Bumping is not supported across the interface shelves, but is supported across the routing network.
- Statistical Line Alarms per Software Functional Specification (i.e., Bellcore standards).
- Programmable Opti Class: although 4 connection classes are supported: CBR, VBR, VBR with Foresight, ATF, and ATF with ForeSight. Configuration of egress port queues and BNI trunk queues for these connection classes is available.
- Port loopback **tstport**

- Test **tstcon** not supported at BPX switch endpoints; it is supported at IPX switch endpoints
- Gateway terminated inter-domain connections
- Via connections through IPX switch

### Some ATF Connection Criteria

ATF connections are allowed between any combination of ATM and Frame Relay UNI and NNI ports. Virtual circuit connections are allowed. Virtual path connections are not.

ATF connections can be mastered by the IPX switch or BPX switch end.

ATF bundled connections and ATF point-to-point connections are not supported.

ATF connections use the frame relay trunk queues: bursty data A for non-ForeSight, bursty data B for ForeSight.

Bandwidth related parameters are defined using cells per second (cps) on the BPX switch and bits per second (bps) on the IPX/IGX switch. On a given endpoint node, the bandwidth parms for both ends of the ATF connection are changed/displayed using this end's units. This saves the user from having to convert from cps to bps repeatedly.

ATF connections use the VBR egress queue on the ASI-1 card. ATF with ForeSight connections use the ABR egress queue.

### Connection Management

The following user commands are used to provision and modify ATF connections:

- **addcon**
- **cnfcls**
- **cnfcon**
- **delcon**
- **dspcls**
- **dspcon**
- **dspcons**

### Port Management

The following features are added to the ASI-1 at the port level:

- An ASI-1 card can be configured to use the network-network interface (NNI) addressing format. This feature is only available on a per-card level. Changing one port to or from NNI changes the other one with appropriate warnings to the user.
- ILMI activation/configuration/statistics
- LMI Annex G activation/configuration/statistics
- Port egress queue configuration
- Backward congestion management

## Structure

- NNI

The NNI format supports a 12-bit VPI. A-bit status changes are passed to the remote end of the connection.

- ILMI

The ILMI MIB and protocol was implemented in release 7.2. The additional support in consists of an activation and configuration interface, collection of statistics, and end-to-end status updates.

- LMI Annex G

The LMI Annex G protocol was implemented in release 7.2. The additional support consists of an activation and configuration interface, collection of statistics, and end-to-end status updates.

- Port egress queue configuration

Each of the pre-defined ASI-1 port egress queues can be configured by the user. These queues consist of CBR, VBR, and VBR with ForeSight (ABR). The configurable parameters are queue depth, EFCN threshold, and CLP thresholds.

- Backward congestion management

Backward congestion management cells indicate congestion across the UNI or NNI. Transmission of these cells is enabled on a per-port basis. Software allows BCM to be configured on a UNI or NNI port for maximum flexibility should BCM over UNI be standards-defined.

The following user commands are used to configure ASI-1 port features:

- **cnfport**
- **cnfportq**

## Channel Statistics

Statistics are supported on a per-channel basis. A range of traffic and error statistics are available. ASI-1 channel statistics are enabled by StrataView+ or by the BPX switch control terminal using the existing statistics mechanism. The existing collection intervals apply.

Channel statistics of the following general types are supported:

- Cells received/transmitted, dropped, tagged as non-compliant or congested
- Cell errors
- AAL-5 frame counts, errors

The following user commands are used to configure and display channel statistics:

- **clrchstats**
- **cnfchstats**
- **dspchstats**
- **dspchstatcnf**
- **dspchstathist**

### OAM Cell Support

OAM cells are detected and transmitted by the ASI-1 firmware. System software displays alarm indications detected by the firmware. Additionally, loopbacks between the ATM-UNI and the ATM-CPE can be established. ForeSight round-trip delay cells are generated by firmware upon software request.

System software deals with the following OAM cell flows:

- End-to-End AIS/FERF—software displays on a per-connection basis.
- External segment loopbacks—software initiates loopback of ATM-CPE via user command. The SAR creates the loopback OAM cell. External loopback cells received from the ATM-CPE are processed by the SAR.
- Internal ForeSight round trip delay—software commands the ASI-1 to measure the RTD excluding trunk queuing delay on each ForeSight connection. Software displays the result.
- Internal loopback round trip delay—software commands the ASI-1 to measure the RTD including trunk queuing delay on each ForeSight connection. Software displays the result.
- Internal Remote Endpoint Status—these cells are generated by one end of a connection due to remote network connection failure (A-bit = 0). The other end ASI-1 detects these cells and reports the connection status to software, which displays it.

The following user commands are associated with OAM cell status changes:

- **dspalms**
- **dspcon**
- **dspport**
- **tstconseg**
- **tstdly**

### Diagnostics

#### Loopbacks

- Local loopbacks loop data back to the local ATM-TE, via the local BPX switch. Remote loopbacks loop data back to the local ATM-TE, via the whole connection route up to and including the remote terminating card.
- Local and remote connection loopbacks, and local port loopbacks, are destructive.

#### Card Tests

- The generic card selftest mechanism on the BPX switch is modified to include the ASI-1 card.
- The card background test that exists for the FRP card on the IPX switch is modified to work for the ASI-1 card.

#### Connection Tests

- The `tstcon` command is not supported. The `tstdly` command is used for connection continuity testing. ASI-1 `tstdly` is non-destructive, as compared with the IPX switch `tstdly`.



## User Commands

The following user commands are associated with diagnostics changes:

- **addloclp**
- **addrmtlp**
- **cnftstparm**
- **dellp**
- **dspalms**
- **dspcd**
- **dspcds**
- **tstdly**

## Virtual Circuit Features

The following virtual circuit features are supported by the ASI-1:

- Connection Groups

Connection groups are supported for ASI-1 ATM and interworking connection types, allowing termination of up to 5000 (grouped) virtual circuits per BPX switch. The connection grouping feature currently available on frame relay connections is expanded to include ASI-1 ATM and interworking connections.

- FGCRA

Frame-Based Generic Cell Rate Algorithm is an ASI-1 firmware feature that controls admission of cells to the network. It is configurable on a per-connection basis. It is a Cisco WAN switching enhancement of the ATM-UNI standard Generic Cell Rate Algorithm. System software allows configuration of FGCRA on a per-connection basis.

- IBS

Initial Burst Size is an ATM bandwidth parameter that is used by firmware to allow short initial bursts, similar to the Cmax mechanism on the IPX switch. It is configurable on a per-connection basis.

- Full VPI/VCI addressing range

The entire range of VPI and VCI on both UNI and NNI interfaces is supported. For ATM-UNI, 8 bits of VPI and 16 bits of VCI are supported. For ATM-NNI, 12 bits of VPI and 16 bits of VCI are supported. In either case, VPC connections only pass through the lower 12 bits of the VCI field.

- Connection Classes

ATM and interworking connection classes are defined with appropriate bandwidth parameter defaults. These classes only apply at addcon time. They are templates to ease the user's task of configuring the large number of bandwidth parameters that exist per connection.

### User Commands

The following user commands are associated with virtual circuit feature changes:

- **addcon**
- **addcongrp**
- **cnfcon**
- **cnfatmcls**
- **delcon**
- **delcongrp**
- **dspatmcls**
- **dspcongrps**
- **grpcon**

### AUser Commands

The following user commands are modified to support ASI-1 E3:

- **cnfln**
- **cnflnstats**
- **dspcd**
- **dspcds**
- **dsplncnf**
- **dsplns**
- **dsplnstatcnf**
- **dsplnsthathist**
- **dspyred**
- **prtyred**

## Management

### Connection Management

Interworking connections may be added from either the BPX switch, the IPX switch, the IGX switch, or the MGX 8220. Intra- and inter-domain interworking connections are supported.

Connection configuration parameters are endpoint-specific. Thus, the ATM-only parameters are only configurable on the BPX switch end. The IPX switch does not know about these parameters, so they cannot be configured or displayed at the IPX switch end. Parameter units are endpoint-specific also. Units on the BPX switch are cells per second, units on the IPX switch are bits per second.

Bundled interworking connections are not supported.

Virtual path interworking connections are not supported.

## Routing

Interworking connections use the complex gateway feature of the AIT trunk card to repackage data from frames to ATM cells, and vice-versa. All BPX switch-IPX switch hops these connections route over must provide the complex gateway function. IPX switch-IPX switch hops (frame relay connections) can be any trunk card type. This requirement simplifies the routing mechanism when dealing with structured networks, as software does not know the type of trunks in remote domains.

## Bandwidth Management

Bandwidth calculations for interworking connections assume a large frame size, which minimizes the loading inefficiency of packets vs. cells. In other words, the translation between packets and cells assumes 100 percent efficiency, so the conversion is simply based on 20 payload bytes per fastpacket vs. 48 payload bytes per ATM cell.

This mechanism keeps the fastpacket/cell conversion consistent with the bits per second/cells per second conversion. Thus, conversion of endpoint rates to trunk loading is straightforward.

## User Interface

ATM connection classes are added for convenience. Classes can be configured as interworking or regular ATM. The **cnfcls** command is used to configure a class. The class is specified as part of the **addcon** command. ATM connection classes are maintained on all BPX switch. IPX switch nodes do not know about these classes.

A special ATM class is defined as the default interworking class. When an interworking connection is added from the frame relay end, the ATM-only parameters for this connection are taken from this default class.

Network-wide ForeSight parameters are supported for the frame relay end of interworking connections. The **cnfstparm** command is used to configure these parameters. Since the ATM end of interworking connections has per-virtual circuit ForeSight parameter configurability, the network-wide ForeSight parameters do not apply.

Note that the default ATM ForeSight parameters will match the default frame relay ForeSight parameters, with appropriate units conversion.

## Port Management

The **cnfport** command supports the following new features:

- An ASI-1 card can be configured to be UNI or NNI.
- An ASI-1 UNI or NNI port can be configured to transmit Backwards Congestion Messages (BCM) to indicate congestion to the foreign ATM network.
- An ASI-1 UNI or NNI port can be configured for LMI, ILMI or no local management.

The **cnfportq** command supports configuration of queue depth, EFCN threshold, and CLP thresholds for all port egress queues (CBR, VBR, VBR w/ForeSight).

### Connection Management

The NNI cell format has 12 bits for the VPI, so **addcon** allows specification of VPI 0-4095 on NNI ports.

### Signaling

System software supports the following LMI/ILMI signaling actions:

- Internal network failure: software informs LMI/ILMI to set A bit = 0 for failed connections. Software informs ASI-1 to transmit AIS to port for failed connections.
- Port failure/LMI Comm Failure: software informs remote nodes terminating all affected connections. Remote node BCC informs LMI/ILMI to set A bit = 0, and ASI-1 to transmit AIS.
- LMI A = 0: software polls ILMI agent periodically for A-bit status. Status changes are reflected in the 'dspcon' screen.

### Alarms

LMI communication failure on an ASI-1 causes declaration of a minor alarm. The **dspport** screen shows the failure, as does the **dspalms** screen.

A-bit = 0 on an NNI port causes declaration of a minor alarm. The **dspcon**, **dspcons**, and **dspalms** screens show this failure.

# Tiered Networks

---

This chapter describes the tiered network architecture that supports interface shelves (non-routing nodes) connected to an IPX/IGX/BPX routing network.

The chapter contains the following:

- Routing Hubs and Interface Shelves
- BPX Routing Hubs in a Tiered Network
- IGX Routing Hubs in a Tiered Network
- User Interface Commands
- Cisco StrataView Plus NMS

With Release 8.5, tiered networks now support voice and data connections as well as frame relay connections. With this addition, a tiered network can now provide a multi-service capability (frame relay, circuit data, voice, and ATM). By allowing CPE connections to connect to a non-routing node (interface shelf), a tiered network is able to grow in size beyond that which would be possible with only routing nodes comprising the network.

## Routing Hubs and Interface Shelves

In a tiered network, interface shelves at the access layer (edge) of the network are connected to routing nodes via feeder trunks (Figure 13-1). Those routing nodes with attached interface shelves are referred to as routing hubs. The interface shelves, sometimes referred to as feeders, are non-routing nodes. The routing hubs route the interface shelf connections across the core layer of the network.

The interface shelves do not need to maintain network topology nor connection routing information. This task is left to their routing hubs. This architecture provides an expanded network consisting of a number of non-routing nodes (interface shelves) at the edge of the network that are connected to the network by their routing hubs.


## BPX and IGX Routing Hubs

Voice and data connections originating and terminating on IGX interface shelves (feeders) are routed across the routing network via their associated IGX routing hubs. Intermediate routing nodes must be IGX nodes.

Frame relay connections originating at IPX interface shelves and frame relay, ATM, CESM, and FUNI connections originating at MGX 8220 interface shelves are routed across the routing network via their associated BPX routing hubs.

**Note** The IGX switch may also be configured as an interface shelf feeding frame relay connections to a BPX routing hub.

Figure 13-1 Tiered Network with BPX and IGX Routing Hubs




S6396

## BPX Routing Hubs in a Tiered Network

Tiered networks with BPX routing hubs have the capability of adding interface shelves/feeders (non-routing nodes) to an IPX/IGX/BPX routing network (Figure 13-2). The MGX 8220 interface shelf, and IPX or IGX nodes configured as interface shelves are connected to BPX routing hubs. Interface shelves allow the network to support additional connections without adding additional routing nodes.

The MGX 8220 supports frame T1/E1, X.21 and HSSI frame relay, ATM T1/E1, and CES, and is designed to support additional interfaces in the future. The IPX interface shelf supports frame relay ports, as does the IGX switch (option is available to configure as an interface shelf).

**Figure 13-2 Tiered Network with BPX Routing Hubs**



55278

## Tiered Network Implementation

The following requirements apply to BPX routing hubs and their associated interface shelves:

- MGX 8220 Release 4 level is required on all MGX 8220 interface shelves.
- Only one feeder trunk is supported between a routing hub and interface shelf.
- No direct trunking between interface shelves is supported.
- No routing trunk is supported between the routing network and interface shelves.
- The feeder trunks between BPX hubs and IPX or IGX interface shelves are either T3 or E3.
- The feeder trunks between BPX hubs and MGX 8220 interface shelves are T3, E3, or OC3-c/STM-1.
- Frame Relay Connection management to an IPX interface shelf is provided by Cisco StrataView Plus

- Frame Relay and ATM connection management to an MGX 8220 interface shelf is provide by Cisco StrataView Plus
- Telnet is supported to an interface shelf; the vt command is not.
- Remote printing by the interface shelf via a print command from the routing network is not supported.

## General

Annex G, a bi-directional protocol, defined in Recommendation Q.2931, is used for monitoring the status of connections across a UNI interface. Tiered Networks use the Annex G protocol to pass connection status information between a Hub Node and attached interface shelf.

## Definitions

|                          |                                                                                                                                                                                         |
|--------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| BPX Routing Hub          | A BPX node in the routing network which has attached interface shelves. Also referred to as a hub node or BPX hub.                                                                      |
| MGX 8220 Interface Shelf | A standards based service interface shelf that connects to a BPX routing hub, aggregates and concentrates traffic, and performs ATM adaption for transport over broadband ATM networks. |
| IPX Interface Shelf      | A special configuration of the IPX narrow band node designated as a interface shelf that supports frame relay connections.                                                              |
| IGX Interface Shelf      | A special configuration of the IGX multi-band node designated as a interface shelf that supports frame relay connections.                                                               |
| Feeder Trunk             | Refers to a trunk which interconnects an interface shelf with the routing network via a BPX routing hub. A feeder trunk is sometimes referred to as an interface shelf trunk.           |
| IPX/AF                   | Another name for the IPX interface shelf                                                                                                                                                |
| IGX/AF                   | Another name for the IGX interface shelf                                                                                                                                                |
| Routing Network          | The portion of the tiered network which performs automatic routing between connection endpoints.                                                                                        |
| VPI                      | Virtual Path Identifier                                                                                                                                                                 |
| VCI                      | Virtual Connection Identifier                                                                                                                                                           |

## Upgrades

Converting an IPX or IGX node to an interface shelf requires re-configuring connections on the node, as no upgrade path is provided in changing a routing node to an interface shelf.

A BPX node, acting as a Hub Node, is not restricted from providing any other feature which is normally available on BPX nodes. A BPX Hub supports up to 16 interface shelves.



Connections within tiered networks consist of distinct segments within each tier. A routing segment traverses the routing network, and an interface shelf segment provides connectivity to the interface shelf end-point. Each of these segments are added, configured and deleted independently of the other segments. The SV+ Connection manager provides management of these individual segments as a single end-to-end connection.

Interface shelves are attached to the routing network via a BPX routing hub using a BXM trunk (T3/E3 or OC3) or BNI trunk (T3/E3). The connection segments within the routing network are terminated on the BNI feeder trunks.

All frame relay connection types which can terminate on the BPX ASI card are supported on the BNI feeder trunk (currently VBR, CBR, ABR, and ATF types). No check is made by the routing network to validate whether the connection segment type being added to a BNI feeder trunk is actually supported by the attached interface shelf.

### Co-locating Routing Hubs and Interface Shelves

The trunk between an interface shelf and the routing network is a single point of failure, therefore, the interface shelves should be co-located with their associated hub node. Card level redundancy is supported by the Y-Cable redundancy for the BXM, BNI, AIT, and BTM.

### Network Management

Communication between CPE devices and the routing network is provided in accordance with Annex G of Recommendation Q.2931. This is a bidirectional protocol for monitoring the status of connections across a UNI interface. (Note: the feeder trunk uses the STI cell format to provide the ForeSight rate controlled congestion management feature.)

Communication includes the real time notification of the addition or deletion of a connection segment and the ability to pass the availability (active state) or unavailability (inactive state) of the connections crossing this interface.

A proprietary extension to the Annex G protocol is implemented which supports the exchange of node information between an interface shelf and the routing network. This information is used to support the IP Relay feature and the Robust Update feature used by network management.

Network Management access to the interface shelves is through the IP Relay mechanism supported by the SNMP and TFTP projects or by direct attachment to the interface shelf. The IP Relay mechanism relays traffic from the routing network to the attached interface shelves. No IP Relay support is provided from the interface shelves into the routing network.

The BPX routing hub is the source of the network clock for its associated feeder nodes. Feeders synchronize their time and date to match their routing hub.

Robust Object and Alarm Updates are sent to a network manager which has subscribed to the Robust Updates feature. Object Updates are generated whenever an interface shelf is added or removed from the hub node and when the interface shelf name or IP Address is modified on the interface shelf. Alarm Updates are generated whenever the alarm state of the interface shelf changes between Unreachable, Major, Minor and OK alarm states.

An interface shelf is displayed as a unique icon in the SV+ Network Management topology displays. The colors of the icon and connecting trunks indicate the alarm state of each. Channel statistics are supported by FRP, FRM, ASI, and MGX 8220 endpoints. BNIs, AITs, and BTMs do not support channel statistics. Trunk Statistics are supported for the feeder trunk and are identical to the existing BNI trunk statistics.

### ForeSight

Foresight for an IPX interface shelf terminated Frame Relay connections is provided end-to-end between Frame Relay ports, regardless as to whether these ports reside on an IPX interface shelf or within the routing network.

### Preferred Routing

Preferred routing within the routing network can be used on all connections. Priority bumping is supported within the routing network, but not in the interface shelves. All other connection features such as conditioning, **rrtcon**, **upcon**, **dncon**, etc. are also supported.

### Local and Remote Loopbacks

Connection local and remote loopbacks are managed at the user interface of the FRP endpoint routing node or interface shelf. The existing IPX Frame Relay port loopback feature is supported on the IPX interface shelf. Remote loopbacks are not supported for DAX connections. A new command **addlocrmtlp** is added to support remote loopbacks at FRP DAX endpoints.

### Testcon and Testdly

Tstcon is supported at the FRP endpoints in a non-integrated fashion and is limited to a pass/fail loopback test. Fault isolation is not performed. This is the same limitation currently imposed on inter-domain connections. Intermediate endpoints at the AIT and BNI cards do not support the tstcon feature. Tstdelay is also supported for the FRP and ASI in a non-integrated fashion similar to that of the tstcon command.

## IPX Interface Shelf Description

The IPX interface shelf supports the termination of Frame Relay connection segments to an AIT. DAX voice and low speed data connections are also supported, but they can't terminate on an AIT. The IPX interface shelf connects to the routing network via an AIT card on the IPX switch and a BNI card on the BPX routing hub.

Admission control and ForeSight rate control for IPX interface shelf terminated Frame Relay connections is performed at the FRP port on the IPX interface shelf. Only a single trunk line is supported between the IPX interface shelf and the routing network. Trunks on the IPX interface shelf linking other nodes are not supported.

Frame Relay type connections, remotely or locally terminated are supported on IPX interface shelves. Interface shelf connections for which both endpoints reside on the same interface shelf are not known to the routing network and will not route through the routing network.

IPX interface shelves support the following network management features:

- Interval Statistics enable/disable/collection
- IP Relay
- Robust Object Updates
- Robust Alarm Updates
- Real-time Counters
- Event Logging
- Software/Firmware Downloads

- Configuration Save/Restore
- SNMP

## Configuration and Management

The interface shelves attached to each hub must have unique names. Each interface shelf must also be assigned a unique IP address.

An interface shelf communicates with a routing hub over a new type of NNI. It is similar to the existing Frame Relay NNI in purpose and function, and is based on the ATM LMI message set described by Recommendation 2931, Annex G. A routing hub and interface shelf use this NNI to maintain a control session with each other. Any change to the status of the feeder trunk affects this control session.

Feeder trunks are the communication path between the routing hub and the Feeder. These feeder trunks are supported by the AIT trunk card on the IPX interface shelf and the BNI trunk card on the BPX routing hub. Feeder trunks are upped using the “**uptrk**” command. Feeder trunks must be upped on both the routing hub and the interface shelf before it can be joined to the routing network.

Once an IPX switch has been converted to an interface shelf, it can be joined to the BPX routing hub, by executing the **addshelf** command at the BPX routing hub. The **addshelf** command has the following syntax:

### Interface Shelf Management

**addshelf** <trunk> <shelf\_type>

trunk                    slot.port

shelf\_type            I (IPX/AF) or A (MGX 8220)

**delshelf** <trunk> | <shelf\_name> deletes interface shelf

**dspnode:**            Displays feeder trunk status. BPX Hub nodes display the status of all attached Interface shelves. IPX interface shelves display a single status item, that of the attached BPX Hub node.

### Alarm Management of Interface Shelf on the BPX Hub Node

**dspalms**            A new field, interface shelf alarms, shows a count of the number of interface shelves which are Unreachable, in Minor Alarm, or in Major Alarm. The nnn-A bit status failures for shelf connections are also shown.

### Alarm Management on the IPX Interface Shelf

- dspalms**            A new field, routing network Alarms, shows a count of major and minor alarms in the routing network. Feeder A-bit connection status reported by Feeder NNI is shown in the “Connection A-Bit Alarms” field.
- dspnode:**            Shows if the routing network is reachable and the attached BPX hub node.

### Port Management

Uses existing commands

### Connection Management

Parameters entered at SV+ when adding connection.

### Bandwidth Management

Parameters entered at SV+ when adding connection. Bandwidth performance monitored by viewing selected statistics at SV+ NMS.


### Statistics

Enabled and monitored via Cisco StrataView Plus.

# IGX Routing Hubs in a Tiered Network




With tiered networks, IGX nodes on the edge of the network are configured as interface shelves and are connected to IGX nodes configured as router hubs. The interface shelves allow the network to support additional voice, data and frame relay connections without adding additional routing nodes. An example of 3-segment voice and data connections via an IGX interface shelf and IGX routing hubs is shown in (Figure 13-3). An example of a frame relay connection via an IGX interface shelf and routing hubs is shown in (Figure 13-4).

**Figure 13-3 IGX Shelves and Routing Hubs, Voice and Data Connections**




The IGX voice card is the CVM or UVM. The IGX data cards are the LDM and HDM. The trunk card on both ends of the IGX feeder trunk is the BTM-E1, T3, or E3.

**Legend**

-  Depicts an IGX interface shelf
-  Depicts an IGX routing hub
-  Depicts an IGX routing node

S6414

Figure 13-4 IGX Shelves and Routing Hubs, Frame Relay Connections



S6415

## Tiered Network Implementation

The following applies to IGX routing hubs and interface shelves:

- An IGX routing hub supports up to 4 IGX interface shelves.
- An IGX interface shelf can have only one feeder trunk to the routing network.
- An IGX interface shelf is the only type of interface shelf that can connect to IGX routing hubs.
- No direct trunking between interface shelves is supported.
- No routing trunk is supported between the routing network and interface shelves.
- The feeder trunks between IGX hubs and IGX interface shelves are connected to a BTM-E1 backcard on each end of the trunk.
- Voice and data connection management to an IGX interface shelf is provided by Cisco StrataView Plus
- Telnet is supported to an interface shelf; the vt command is not.

- Remote printing by the interface shelf via a print command from the routing network is not supported.

The following applies to voice and data connections over IGX interface shelves:

- 3-segment connections are supported, that is: originating IGX interface shelf data or voice card to IGX routing hub, across IGX intermediate nodes, as applicable, to IGX routing hub, to terminating IGX interface shelf data or voice card.
- 2-segment connections are not supported, (IGX interface shelf voice or data card to routing hub).
- Routing through the middle segment of the three segment connection is done via IGX routing nodes using CBR mode and simple gateway over the IGX trunks.
- Connection statistics are supported at user endpoints only.
- Adaptive voice is not supported.

The following applies to Frame Relay connections over IGX interface shelves via an IGX hub.

- 3-segment connections are supported, that is: originating IGX interface shelf frame relay card to IGX routing hub, across IGX intermediate nodes, as applicable, to IGX routing hub, to terminating IGX interface shelf data or voice card.
- 2-segment connections are supported, (IGX interface shelf frame relay card to routing hub).
- Routing through the middle segment of the three segment connection is done via IGX routing nodes using ATFR mode and simple gateway over the IGX trunks.
- Connection statistics are supported at user endpoints only.

## General

Annex G, a bi-directional protocol, defined in Recommendation Q.2931, is used for monitoring the status of connections across a UNI interface. Tiered Networks use the Annex G protocol to pass connection status information between a Hub Node and attached Shelf.

### Definitions

|                     |                                                                                                                                                                                                                                                                   |
|---------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| IGX Routing Hub     | An IGX node in the routing network which has attached IGX interface shelves. Also referred to as a hub node or IGX hub.                                                                                                                                           |
| IGX Interface Shelf | A special configuration of an IGX switch that is connected as a shelf to an IGX routing hub. An IGX interface shelf is sometimes referred to as IGX A/F or feeder. The IGX interface shelf does not perform routing functions nor keep track of network topology. |
| Feeder Trunk        | Refers to a trunk which interconnects an IGX interface shelf with the routing network via an IGX routing hub. A feeder trunk is sometimes referred to as an interface shelf trunk.                                                                                |
| IGX/AF              | Another name for the IGX interface shelf                                                                                                                                                                                                                          |
| Routing Network     | The portion of the tiered network which performs automatic routing between connection endpoints.                                                                                                                                                                  |
| VPI                 | Virtual Path Identifier                                                                                                                                                                                                                                           |
| VCI                 | Virtual Connection Identifier                                                                                                                                                                                                                                     |

### Upgrades

Converting an IGX node to an interface shelf requires re-configuring connections on the node, as no upgrade path is provided in changing a routing node to an interface shelf.

Only IGX nodes are able to act hub nodes for IGX interface shelves for voice and data transport over the IGX tiered network. An IGX node, acting as a hub node, is not restricted from providing any other feature which is normally available on IGX nodes. An IGX hub supports up to 4 IGX interface shelves.

Connections within tiered networks consist of three distinct segments within each tier. A routing segment traverses the routing network, with an interface shelf segment at each end providing connectivity to the interface shelf end-point. Each of these segments are added, configured and deleted independently of the other segments. The Cisco StrataView Plus Connection Manager provides management of these individual segments as a single end-to-end connection.

Interface shelves are attached to the routing network via an IGX node using a BTM E1 trunk. The connection segments within the routing network are terminated on IGX feeder trunks.

### Co-locating Routing Hubs and Shelves

The feeder trunk between an interface shelf and the routing network is a single point of failure, therefore, the interface shelves should be co-located with their associated hub node. Card level redundancy is supported by the Y-Cable redundancy for the CVM, LDM, and HDM.

### Network Management

Communication between CPE devices and the routing network is provided in accordance with Annex G of Recommendation Q.2931. This is a bidirectional protocol for monitoring the status of connections across a UNI interface.



Communication includes the real time notification of the addition or deletion of a connection segment and the ability to pass the availability (active state) or unavailability (inactive state) of the connections crossing this interface.

A proprietary extension to the Annex G protocol is implemented which supports the exchange of node information between an interface shelf and the routing network. This information is used to support the IP Relay feature and the Robust Update feature used by network management.

Network Management access to the interface shelves is through the IP Relay mechanism supported by the SNMP and TFTP or by direct attachment to the interface shelf. The IP Relay mechanism relays traffic from the routing network to the attached interface shelves. No IP Relay support is provided from the interface shelves into the routing network.

IGX routing hubs are the source of the network clock for its associated feeder nodes. Feeders synchronize their time and date to match their routing hub.

Robust Object and Alarm Updates are sent to a network manager which has subscribed to the Robust Updates feature. Object Updates are generated whenever an interface shelf is added or removed from the hub node and when the interface shelf name or IP Address is modified on the interface shelf. Alarm Updates are generated whenever the alarm state of the interface shelf changes between Unreachable, Major, Minor and OK alarm states.

An interface shelf is displayed as a unique icon in the SV+ Network Management topology displays. The colors of the icon and connecting trunks indicate the alarm state of each. Channel statistics are supported by CVM, HDM, and LDM endpoints. Trunk Statistics are supported for the feeder trunk and are identical to the existing IGX trunk statistics.

## Preferred Routing

Preferred routing within the routing network can be used on all connections. Priority bumping is supported within the routing network, but not in the interface shelves. All other connection features such as conditioning, **rrtcon**, **upcon**, **dncon**, etc. are also supported.

## Local and Remote Loopbacks

Connection local and remote loopbacks are managed at the user interface of the voice or data endpoint Routing Node or interface shelf. The existing IGX voice and data port loopback features are supported on the IGX interface shelf.

## Testcon and Testdly

Tstcon is supported at the voice and data endpoints in a non-integrated fashion and is limited to a pass/fail loopback test. Fault isolation is not performed. Intermediate endpoints at the BTM cards do not support the tstcon feature. Tstdelay is also supported for the in a non-integrated fashion similar to that of the tstcon command.

## IGX Interface Shelf Description

The IGX interface shelf supports the termination of voice and data connection segments to a BTM. The IGX interface shelf connects to the routing network via a BTM and associated BMT-E1 back card on both the interface shelf and the IGX routing hub.

IGX interface shelves support the following network management features:

- Interval Statistics enable/disable/collection

- IP Relay
- Robust Object Updates
- Robust Alarm Updates
- Real-time Counters
- Event Logging
- Software/Firmware Downloads
- Configuration Save/Restore
- SNMP

## Configuration and Management

The interface shelves attached to each hub must have unique names. Each interface shelf must also be assigned a unique IP address.

An interface shelf communicates with a routing hub over a new type of NNI. It is similar to the existing Frame Relay NNI in purpose and function, and is based on the ATM LMI message set described by Recommendation 2931, Annex G. A routing hub and interface shelf use this NNI to maintain a control session with each other. Any change to the status of the feeder trunk affects this control session.

Feeder trunks are the communication path between the routing hub and the Feeder. These feeder trunks are supported by the BTM trunk card on both the IGX interface shelf and the IGX routing hub. Feeder trunks are upped using the “**uptrk**” command. Feeder trunks must be upped on both the routing hub and the interface shelf before it can be joined to the routing network.

An IGX node must be converted to an interface shelf by entering the appropriate command at the node. Once an IGX switch has been converted to an interface shelf, it can be joined to the IGX routing hub, by executing the **addshelf** command at the IGX routing hub. The **addshelf** command has the following syntax:

### Shelf Management

**addshelf** <trunk> <shelf\_type>

trunk                    slot.port

shelf\_type              I (IGX/AF)

**delshelf** <trunk> | <shelf\_name>    deletes interface shelf

**dsnode:**                Displays feeder trunk status. IGX routing hubs display the status of all attached IGX interface shelves. IGX interface shelves display a single status item, that of the attached IGX hub node.

## Alarm Management of Interface Shelf on the IGX Hub Node

**dspalms** The field, interface shelf alarms, shows a count of the number of interface shelves which are Unreachable, in Minor Alarm, or in Major Alarm. The nnn-A bit status failures for interface shelf connections are also shown.

## Alarm Management on the IGX Interface Shelf

**dspalms** The field, routing network Alarms, shows a count of major and minor alarms in the routing network. Feeder A-bit connection status reported by feeder NNI is shown in the “Connection A-Bit Alarms” field.

**dspnode:** Shows if the routing network is reachable and the attached IGX hub node.

## Port Management

Uses existing commands

## Connection Management

Parameters entered at Cisco StrataView Plus when adding connections.

## Bandwidth Management

Parameters entered at Cisco StrataView Plus when adding connection. Bandwidth performance monitored by viewing selected statistics at Cisco StrataView Plus NMS.

## Bandwidth Efficiency

Since voice traffic is time sensitive, and low-speed voice connections can result in SGW cells being sent with only a single packet placed in the cell in order to avoid excessive delay between cells. It may be necessary to use the **cnfcm** command on the interface shelves in order to configure the packet combining timeout rate for a particular application.

## Statistics

Enabled and monitored via Cisco StrataView Plus.

# User Interface Commands

Refer to the Command Reference manual for additional information on commands associated with tiered networks. The following is a list of most often used commands with IGX routing hubs and IGX interface shelves supporting voice and data connections.

## Shelf

**addshelf**

**delshelf**

**dspnode**

**dspalms**

**dsptrks**

## Data Connection Commands

**addcon**

**dspcon**

**dspcons**

## Data Channel Commands

**cnfchdfm**

**cnfcheia**

**cnfchdir**

**cnfdchtp**

**cnfdclk**

**cnfict**

## Voice Connection Commands

**addcon**

## Voice Channel Commands

**cnfchadv**

**cnfchutil**

**cnfchkdl**

**cnfcos**

**cnfechec**

**cnfchgn**

**cnfcond**

**cnfrcvsig**

**cnfvchtp**


**cnfxmtsig**

**cnfemb**

## Cisco StrataView Plus NMS

Interface shelf and feeder trunk information is reported to Cisco StrataView Plus by the routing hub and interface shelf. Cisco StrataView Plus can virtually connect to any node in the network via a TCP/IP connection. The Cisco StrataView Plus Connection Manager is used to add, delete, and monitor voice and data connections for tiered networks with IGX hubs. It is also used to add, delete and monitor frame relay connections for tiered networks with BPX hubs. A sample of the Connection Manager GUI is shown in Figure 13-5.

Figure 13-5 SV+ Connection Manager



NM47&4



# BPX SNMP Agent

---

This chapter introduces the functions of the Simple Network Management Protocol (SNMP) agent that is embedded in each BPX node. To benefit from this chapter, readers should have a general knowledge of SNMP, IP protocols, and MIBs.

The chapter contains the following:

- Introduction
- SNMP Overview
- SNMP Functions
- MIB II Support
- Cisco WAN Switching Proprietary MIB Structure

## Introduction

An SNMP agent is embedded in each BPX node. (This feature is an addition to and functionally different from the SNMP Proxy Agent that can be used by a non-SV+ workstation to provide access to a MIB on the SV+ workstation which contains data extracted from the SV+ Informix database.) The SNMP agent permits an SNMP manager to view and set certain network objects in Management Information Bases (MIBs) that are maintained in each BPX node within a managed network. The embedded SNMP agent supports the standard Internet MIB II, the ATM 3.1 UNI MIB, and a Cisco WAN Switching proprietary MIB. The Cisco WAN Switching proprietary MIB contains information necessary to control ports and connections on the switches in the network. The standard Internet MIB II contains MIB modules defined by the Internet Engineering Steering Group (IESG). SNMP support is available on both IPX and BPX switches.

The proprietary MIB is supplied on a tape for compilation into the user's SNMP manager.


## SNMP Overview

An SNMP manager manages the SNMP agents in each BPX node in a single domain. To gain access to network nodes, the SNMP manager is connected to one of the BPX nodes through its Ethernet port, which acts as a gateway for the SNMP manager to communicate with all the other BPX nodes in the domain.

In multiple networks, a separate SNMP manager must exist for each network that is being managed. Furthermore, nodes within a multi-network can be managed by multiple SNMP managers. Also, ATM connections that span multiple networks are supported in the SNMP MIB.

Figure 14-1 shows an SNMP manager and the nodes within a domain.

**Figure 14-1** SNMP Manager and Agents in a BPX Domain



Communication between the agents and the SNMP manager uses the standard UDP protocol encapsulated within IP protocol. The communication link between the SNMP manager and the directly attached BPX node uses the Ethernet interface of an BCC processor card. The SNMP manager can be either local or remote to the BPX node.

Figure 14-1 illustrates the SNMP manager's communication with the agents in the network. Each node in the domain must have a network IP address assigned by the **cnfnwip** command (see the *Cisco WAN Switching Command Reference* publication for details). The manager uses the network IP address to address an agent in the domain. The directly attached node (Node 4 in Figure 14-1) directs the SNMP message to the addressed BPX node. Responses from the agent go to the directly attached node then pass over the Ethernet link to the SNMP manager.

---

**Note** The LAN IP address of the directly attached node must be configured with the **cnflan** command.

---



## SNMP Functions

The SNMP protocol provides a basic query-response model for network management. The network manager has access to Get (Get-Next) and Set functions.

A Get request lets the manager read variables in the BPX switch. The request consists of a single variable or a list of variables. The BPX database subsequently returns the requested values.

The Get-Next request lets the manager obtain the successor to the given variable's object identifier. The returned object identifier can serve as input to another Get-Next request so the manager can lexicographically walk through the MIB.

A Set request lets the manager modify variables in the BPX switch. The request consists of either a single variable or a list of variables. The values supplied in the request modify the BPX database. The variables and their associated values in the request message are put into a response message and returned to the requesting management workstation. The format of the Set response message is the same as that of the Get response message.

SNMP requests from the manager have the same access level as non-privileged users. Non-privileged access can be read-only, read-write, or no access. To maintain access control, each Get and Set request is checked for the correct community string. The community string determines the access privileges that a management workstation has. A separate community string exists for Get requests and Set requests.

The node initializes the community strings to no access, so the user must set the strings to the appropriate values. The community strings can be set and displayed by the **cnfsnmp** and **dspsnmp** super-user commands, respectively (see the *Cisco WAN Switching Super-User Command Reference* publication for details).

Responses to Get, Get-Next, and Set requests are returned in a response packet along with a status field. The status field can be one of the following:

- noError (0) Successful operation.
- tooBig (1) The agent could not fit the results of an operation into a single SNMP message.
- noSuchName (2) The requested operation identified an unknown variable when attempting to modify a variable.
- badValue (3) Requested operation specified an incorrect syntax or value when attempting to modify a variable.
- readOnly (4) Requested operation attempted to modify a variable that, according to the community profile, may not be written. (No longer supported by Standards.)
- genErr (5) All other failure responses.

If an error occurs, the appropriate error code is encoded in ASN.1 format and inserted into the response packet.

---

**Note** In the sections that follow, user-specified command names are in lower case.

---

## Responses to Get (Get-Next) Requests

When an SNMP manager workstation sends an SNMP Get request packet to a BPX agent, it utilizes the IP protocol for addressing. The request packet can use either a LAN interface for a locally attached management workstation or a network interface for remote access. Each packet is in ASN.1 format, which is suitable for transmission via the UDP protocol. Once it arrives, the packet is decoded to a Protocol Data Unit (PDU). This PDU is the SNMP internal packet structure.

A PDU consists of one or more variables requested by the manager. The PDU's community string is validated for correct access permissions, then the requested variables are collected within an SNMP varbind list for processing.

For each variable in the request message, the agent calls a user-defined test function that makes sure the requested variable exists. If the test confirms the existence of the variable, the agent calls a user-defined get function to gain access to the BPX database for the specified variable. The get function is appropriate for the type of request (Get or Get-Next).

A get function can read either a single scalar value or a single column entry from the database row. The user-defined get-next function provides a way to read a table of unknown elements. The get-next function returns the lexicographically next variable in the table with respect to the next variable. This mechanism lets the manager sequentially retrieve the entire table.

The test and get functions result in a Get response packet. If an error occurs, the appropriate error code is encoded in ASN.1 format and placed in the packet. If no errors occur, the returned values are encoded and placed in the response packet. The response packet goes to the workstation that originated the Get request.

## ATM Set Requests

SNMP Set requests support the ATM functions in the following list. Refer to the *Cisco WAN Switching Command Reference* for command descriptions.

- Add ATM connection (**addcon**)
- Delete ATM connection (**delcon**)
- Up ATM connection (**upcon**)
- Down ATM connection (**dncon**)
- Modify ATM connection (**cnfrcon**, **cnfcos**, **cnfpref**, **cnfrcon**)
- Test ATM connections (**tstcon**, **tstdelay**)

SNMP Set requests can implement the following BPX commands on ATM ports:

- Up ATM port (**upfrport**)
- Down ATM port (**dnfrport**)
- Modify ATM port (**cnffrport**)

## Responses to Set Requests

When an SNMP manager workstation sends an SNMP Set request packet to a BPX agent, it utilizes the IP protocol for addressing. The request packet can use either a LAN interface for a locally attached management workstation or a network interface for remote access. Each packet has the ASN.1 format, which is suitable for transmission via the UDP protocol. Once it arrives, the packet is decoded to a Protocol Data Unit (PDU). This PDU is the SNMP internal packet structure.

Each variable in the varbind list is located, checked for visibility in the current MIB view, checked for write-access, and type-matched against the set request. A user-defined function is then called to validate the Set PDU. This validation mainly determines if the Set request packet follows the guidelines defined for the BPX switch. This function returns either good status or an error. The error indicates the PDU is bad and should be rejected. Processing continues with tests for accessibility and acceptability.

Each variable in the varbind list is tested for accessibility and acceptability. User-defined test functions associated with each variable are called to implement the tests. A failed test returns a specifier for the variable and a reason code. Any failed test results in a failed Set request. Upon successfully passing the test functions, the set request can proceed to set the requested variables on the specified switch. The SNMP agent calls a user-specified set function to implement the modifications.

Upon either a successful completion or an error, the Set request PDU is modified to become the response PDU. The response PDU also contains the values of the variables in the original Set request. This PDU is encoded into ASN.1 format and inserted into the response packet. The Set response packet goes to the workstation that generated the request.

## MIB II Support

The BPX SNMP agent supports the following groups in the Internet SNMP MIB II:

- ARP
- ICMP
- Interfaces
- IP
- SNMP
- System
- TCP
- UDP

## Cisco WAN Switching Proprietary MIB Structure

This section is an overview of the Cisco WAN Switching proprietary MIB. The proprietary MIB resides under the enterprises branch of the SNMP tree structure (1.3.6.1.4.1.StrataCom (351)). For detailed information on the structure and contents of the MIB, refer to the actual MIB that is included on the release tape. The MIB is in ASN.1 format.

The MIB provides network managers with BPX information on a per switch basis. This information in the MIB relates to ATM service. The SNMP agent MIB has two major branches of information. These are the Switch Service Objects and Switch Connections.

Each variable in the MIB also includes the following:

- An access level (read-only, read-write, or no access)
- A defined MIB view, which allows appropriate agents to have access to platform-specific information

### Switch Service Objects

The higher level Switch Services branch shows the available ATM services. This service information exists in a configuration table and a statistics table for each logical port on the switch. The configuration parameters for a logical port allow the manager to view and modify a specified available port. The statistics table gives the manager access to real-time counter statistics associated with a specified available port.

### Switch Connections

The Switch Connections branch supports per switch management of ATM connections. In this branch, the MIB defines the following:

- Connections—a general view of all available ATM connections on a switch
- Endpoints
- Bandwidth class
- Endpoint Statistics
- Endpoint mapping

The following is a list of the categories of connection information:

- Local description (e.g., domain.node.slot.port.vpi.vci, group id) (read-only)
- Remote description (e.g., domain.node.slot.port.vpi.vci) (read-only)
- Status of the connection (read-only)
- Failure reasons (read-only)
- Current route information (read-only)
- Preferred route information (read-write)
- Access to open space information (read-only)
- Pointer to endpoint-specific information (read-only)

The ATM endpoint-specific information (last item in the previous list) provides the mechanism for the manager to provision and configure ATM connections. The available endpoint-specific information is:

- Local description (e.g., domain.node.slot.port.vpi.vci) (read-write)
- Remote description (e.g., domain.node.slot.port.vpi.vci) (read-write)
- ATM applicable bandwidth parameters (read-write)
- Foresight enable status (read-write)
- Trunk avoid types (read-write)
- Connection priority (read-only)
- Foresight round-trip delay (read-only)

### Bandwidth Class

The bandwidth class information gives the manager a view of the available bandwidth classes that are configured on the switch. The manager can use a selected class as a template to create a ATM endpoint.

### Endpoint Statistics

The endpoint statistics are real-time counter statistics about a specific endpoint.

### Endpoint Mapping

The endpoint mapping information lets the manager have access to connection and endpoint-specific indices. The indices are associated with physical attributes of a connection (for example, *slot.port.vpi.vci*). The manager can use the indices returned to it to gain access to connection and/or endpoint-specific information.



# BPX Node Specifications

---

This appendix lists information for the BPX system specifications. (Refer to on-line documents for latest information).

## General

|                             |                                                                                                                                         |
|-----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| System Capacity:            | 1 shelf with 15 card slots.<br>Requires 1 or 2 dedicated slot(s) for BCC card.<br>Requires 1 dedicated slot for ASM card.               |
| Network Interface:          | T3, E3, OC3, and OC12.                                                                                                                  |
| Network Trunks:             | 32 per node max.                                                                                                                        |
| Network Interface Protocol: | ATM layer using 53-byte cell.                                                                                                           |
| Cell Switching:             | Crosspoint switch matrix, non-blocking.                                                                                                 |
| Switch Capacity:            | 9.6 Gbps or 19.2 Gbps (with BCC-4).                                                                                                     |
| Slot Rate:                  | 800 Mbps each, including overhead.                                                                                                      |
| Connection Rate:            | 20 million cell connections/sec. between slots.                                                                                         |
| Classes of Service:         | 32 queues per port, assignable.                                                                                                         |
| Clock Sources:              | Internal, free-running oscillator, Stratum 3.<br>Phase-locked to any appropriate network interface.<br>External input at T1 or E1 rate. |
| Clock Output:               | Single clock output at T1 or E1 rate for synchronizing co-located IPX node(s) or CPE.                                                   |
| Cabinet Size:               | 22.75 inches (57.8 cm) high.<br>19.0 inches (48.25 cm) wide.<br>27.0 inches (68.6 cm) deep.                                             |

|                        |                                                                                                                                                                                                                             |
|------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Weight, approx:        | 73 lb. (33.2 kg.) empty BPX shelf, w/fans but no PS.<br>6 lb. (2.7 kg.) each card.<br>18 lb. (8.2 kg.) empty AC Power Supply Tray.<br>16 lb. (7.3 kg.) each AC Power Supply.<br>2 lb. (0.9 kg.) each DC Power Entry module. |
| Clearance Requirement: | At least 30 inches front and rear clearance; nominal 12 inch side clearance.                                                                                                                                                |
| Power Source:          | AC system: 180 – 264 VAC, 47 to 63 Hz.<br>DC system: –42 to –56 VDC.                                                                                                                                                        |
| Power Requirements:    | AC BPX-15: 13 A at 180 VAC (2300 VA).<br>DC BPX-15: 40 A at –42 VDC (1680W).                                                                                                                                                |
| Input Power Connector: | AC: 3-conductor IEC receptacle. 8 feet (2.4 m.) power cord supplied.<br>DC: 3 Ring lug screw terminal connectors.                                                                                                           |
| Circuit Breakers:      | AC: 15 A on AC power supply assembly.<br>DC: 40A on power entry module.                                                                                                                                                     |
| Fuses:                 | Individual Backplane Card slot fuses, F1 through F3 for Fans 1 through 3, and F4 through F18 for card slots 1 through 15, 5A-120VAC rating.                                                                                 |
| Operating Environment: | Operating Conditions are listed in Table A-1.                                                                                                                                                                               |
| Shock:                 | Withstands 10G, 10 ms. at 1/2 sine wave.                                                                                                                                                                                    |
| Vibration:             | Withstands 1/4 G, 20–500 Hz.                                                                                                                                                                                                |
| Heat Transfer to Room: | Up to 7200 BTUs depending on node configuration.                                                                                                                                                                            |

**Table A-1 Ambient Temperature and Humidity Limits**

| Conditions                          | Limits                         |                      |
|-------------------------------------|--------------------------------|----------------------|
|                                     | Fahrenheit                     | Centigrade           |
| Operating Temperature               | +40 to +100 degrees            | +4.5 to +38 degrees  |
| Recommended                         | +68 to + 86 degrees            | +20 to +30 degrees   |
| Short-Term Temperature <sup>1</sup> | +35 to +120 degrees            | +1.7 to + 49 degrees |
| Operating Relative Humidity         | 20% to 55%<br>(non-condensing) |                      |
| Short-Term Relative Humidity        | 10% to 80%<br>non-condensing   |                      |

1. Room temperature refers to conditions at a location 5 feet above the floor and 15 inches in front of the equipment.



## ATM Trunk Interface (BXM-T3/E3 Cards)

| Characteristic                     | T3 (DS3)                                                                         | E3                      |
|------------------------------------|----------------------------------------------------------------------------------|-------------------------|
| Line Rate:                         | 44.736 Mbps +/- 20 ppm                                                           | 34.368 Mbps +/- 20 ppm  |
| Line Code:                         | B3ZS                                                                             | HDB3                    |
| Cell Transfer Rate:                | 96,000 cells per second (PLCP mode)<br>104268 cells per second (HEC/Direct mode) | 80,000 cells per second |
| Framing:                           | ANSI T1.107, T1.107a                                                             | ITU T G804, G.832       |
| Signal Level:                      | TA-TSY-000773 (PLCP)                                                             | ITU-T G.703             |
| Transmission Convergence Sublayer: | DS3 PLCP frame format<br>DS3 HEC mapped format                                   | G.832 E3 frame format   |

### T3 (DS3) and E3

|                                  |                                                   |
|----------------------------------|---------------------------------------------------|
| Port Interface, trunk mode,      |                                                   |
| -framing:                        | Framing for T3, C bit parity per ANSI T1.107/107A |
| -port alarm processing           | RDI (yellow alarm) and AIS                        |
| Port Interface, port (UNI) mode: |                                                   |
| ATM Layer Protocol:              | LMI, ILMI                                         |
| Port Alarm Processing:           | LOS, LOF                                          |
| Connector:                       | SMB                                               |

## ATM Trunk Interface (BXM-155 Cards)

|                 |               |         |
|-----------------|---------------|---------|
| Line Rate:      | 155.52 Mbps   |         |
| Line Code:      | NRZ           |         |
| Signal Level:   | Min dBm       | Max dBm |
| MMF LED TX      | -22           | -15     |
| MMF LED RX      | -34           | -10     |
| SMF IR TX       | -15           | -8      |
| SMF IR RX       | -34           | -10     |
| SMF LR TX       | -5            | 0       |
| SMF LR RX       | -34           | -10     |
| Framing Format: | STS-3c, STM-1 |         |
| Port Interface: | LMI, ILMI     |         |

## ATM Trunk Interface (BXM-155 Cards)

---

|                        |                                             |
|------------------------|---------------------------------------------|
| ATM Cell Rate:         | 353,208 cells/sec.                          |
| Jitter:                | ATM Forum UNI 3.1                           |
| ATM Layer Protocol:    | LMI, ILMI                                   |
| Port Alarm Processing: | LOS, LOF, LOP, Path AIS, Path Yellow        |
| Line Errors Counted:   |                                             |
| Connector:             | SC for MMF, FC-PC for SMF (IR) and SMF (LR) |
| Max. Cable Lengths:    | MMF ~2 KM<br>SMF IR ~20 KM<br>SMF LR ~40 KM |
| Indicators:            | Card status<br>Port status                  |

## ATM Trunk Interface (BXM-622 Cards)

|                        |                                      |         |
|------------------------|--------------------------------------|---------|
| Line Rate:             | 622.08 Mbps                          |         |
| Line Code:             | NRZ                                  |         |
| Signal Level:          | Min dBm                              | Max dBm |
| SMF IR TX              | -15                                  | -8      |
| SMF IR RX              | -28                                  | -8      |
| SMF LR TX              | -2                                   | +2      |
| SMF LR RX              | -28                                  | -8      |
| Framing Format:        | STS-12c, STM-4                       |         |
| Port Interface:        | LMI, ILMI                            |         |
| ATM Cell Rate:         | 1,412,830 cells/sec.                 |         |
| Jitter:                | ATM Forum UNI 3.1                    |         |
| ATM Layer Protocol:    | LMI, ILMI                            |         |
| Port Alarm Processing: | LOS, LOF, LOP, Path AIS, Path Yellow |         |
| Line Errors Counted:   |                                      |         |
| Connector:             | SMF-FC                               |         |
| Max. Cable Lengths:    | SMF IR ~20 KM                        |         |
|                        | SMF LR ~40 KM                        |         |
| Indicators:            | Card status                          |         |
|                        | Port status                          |         |

## ATM T3 Trunk Interface (BNI-T3, LM-3T3)

|                            |                                                                                                               |
|----------------------------|---------------------------------------------------------------------------------------------------------------|
| Line Rate:                 | 44.736 Mbps $\pm$ 20 ppm, asynchronous.                                                                       |
| Line Code:                 | B3ZS.                                                                                                         |
| Signal Level:              | DSX-3.                                                                                                        |
| Framing Format:            | C-bit parity is monitored. No other framing or control bits in the DS3 frame are either altered or monitored. |
| Protocol:                  | Physical Layer Convergence Protocol per AT&T Publication TA-TSY-000772 and 000773.                            |
| ATM Cell Rate:             | 96,000 cells/sec. Limited to 80,000 cells/sec. when interfacing with the IPX.                                 |
| Alarms Sent:               | Remote.                                                                                                       |
| Alarms Received:           | AIS.<br>Loss of Signal.<br>Remote.<br>Loss of Framing.                                                        |
| Line Errors Counted:       | BPV.<br>Parity Bit Errors.                                                                                    |
| Jitter:                    | Meets ACCUNET T45 specification (Pub 54014).                                                                  |
| Connector:                 | 75 ohm BNC.                                                                                                   |
| Recommended Cable Lengths: | 450 feet (150 m.) to a DS3 crossconnect.                                                                      |
| Indicators:                | Card status.<br>Port status.                                                                                  |

## ATM E3 Trunk Interface (BNI-E3, LM-3E3)

|                        |                                                                                                                                                                                                    |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Line Rate:             | 34.368 Mbps $\pm$ 20 ppm, asynchronous                                                                                                                                                             |
| Line Code:             | HDB3                                                                                                                                                                                               |
| Signal Level:          | CCITT G.703                                                                                                                                                                                        |
| Framing Format:        | CCITT G.804, G.832                                                                                                                                                                                 |
| Port Interface:        | 75 ohm unbalanced                                                                                                                                                                                  |
| Barrier:               | Fully barriered per EN 41003                                                                                                                                                                       |
| ATM Cell Rate:         | 80,000 cells/sec                                                                                                                                                                                   |
| Jitter:                | per CCITT G.823                                                                                                                                                                                    |
| ATM Layer Protocol:    | per CCITT I.361 with HEC                                                                                                                                                                           |
| Port Alarm Processing: | AIS<br>Loss of Signal<br>Remote Alarm Indication<br>Loss of Framing                                                                                                                                |
| Line Errors Counted:   | BPV<br>Parity Bit Errors                                                                                                                                                                           |
| Connector:             | 75 ohm BNC                                                                                                                                                                                         |
| Max. E3 Cable Lengths: | 100 meters. Cabling must not exceed -6 dB/1000 feet at E3 rates.<br>Cisco supplies cable with a maximum attenuation of 7 dB/1000 feet,<br>but the maximum cable length must not exceed 100 meters. |
| Indicators:            | Card status<br>Port status                                                                                                                                                                         |

## ATM OC3 Trunk Interface (BNI-OC3, LM-OC3)

|                        |                                                           |         |
|------------------------|-----------------------------------------------------------|---------|
| Line Rate:             | 155.52 Mbps                                               |         |
| Line Code:             | NRZ                                                       |         |
| Signal Level:          | Max                                                       | Min     |
| MMF TX                 | -8 dBm                                                    | -15 dBm |
| MMF RX                 | -8 dBm                                                    | -28 dBm |
| SMF LR TX              | 0 dBm                                                     | -5 dBm  |
| SMF LR RX              | -10 dBm                                                   | -34 dBm |
| Framing Format:        | STS-3c, STM1                                              |         |
| Port Interface:        | LMI, ILMI                                                 |         |
| ATM Cell Rate:         | 353,208 cells/sec.                                        |         |
| Jitter:                | < 0.1 UI p-p, < 0.01 UI rms                               |         |
| ATM Layer Protocol:    | LMI, ILMI                                                 |         |
| Port Alarm Processing: | LOS, LOF, LOP, Path AIS, Path Yellow                      |         |
| Line Errors Counted:   | Section BIP8, Line BIP24, Line FEBE, Path BIP8, Path FEBE |         |
| Connector:             | MMF SC<br>SMF FC/PC                                       |         |
| Max. Cable Lengths:    | MMF ~ 2 KM<br>KM SMF IR ~20<br>KM SMF LR ~40 KM           |         |
| Indicators:            | Card status<br>Port status                                |         |

## ATM Service Interface (BXM-T3/E3 Cards)

|                           |                                              |
|---------------------------|----------------------------------------------|
| Capacity:                 | 8 or 12 ports per card                       |
| Interface:                | DS3/T3/E3                                    |
| Line Rate:                | DS3 44.736 Mbs, E3 34.368 Mbps               |
| No. of channels per card: | 16,000                                       |
| No. of channels per node: |                                              |
| VPI Addressing Range:     | ATM UNI 3.1 compliant                        |
| VCI Addressing Range:     | ATM UNI 3.1 compliant                        |
| Queues:                   | 16 COS with 32 Virtual Interface (VI) queues |

## ATM Service Interface (BXM-155 Cards)

|                           |                                              |
|---------------------------|----------------------------------------------|
| Capacity:                 | 4 or 8 ports per card                        |
| Interface:                | OC-3c/STM-1                                  |
| Line Rate:                | 155.52.08 Mbps                               |
| No. of channels per card: | 16,000                                       |
| No. of channels per node: |                                              |
| VPI Addressing Range:     | ATM UNI 3.1 compliant                        |
| VCI Addressing Range:     | ATM UNI 3.1 compliant                        |
| Queues:                   | 16 COS with 32 Virtual Interface (VI) queues |

## ATM Service Interface (BXM-622 Cards)

|                           |                                              |
|---------------------------|----------------------------------------------|
| Capacity:                 | 2 ports per card                             |
| Interface:                | OC-12c/STM-4                                 |
| Line Rate:                | 622.08 Mbps                                  |
| No. of channels per card: | 16,000/32,000                                |
| No. of channels per node: |                                              |
| VPI Addressing Range:     | ATM UNI 3.1 compliant                        |
| VCI Addressing Range:     | ATM UNI 3.1 compliant                        |
| Queues:                   | 16 COS with 32 Virtual Interface (VI) queues |

## ATM Service Interface (ASI-1, LM-2T3)

|                           |                                                          |
|---------------------------|----------------------------------------------------------|
| Capacity:                 | 2 ports per card                                         |
| Interface:                | T3                                                       |
| Line Rate:                | 96,000 cells/sec.                                        |
| No. of channels per card: | 1000                                                     |
| No. of channels per node: | 1000 or 5000 (grouped)                                   |
| VPI Addressing Range:     | 0–255 (UNI), 0-1023 (NNI_7)                              |
| VCI Addressing Range:     | 1–4095                                                   |
| Queues:                   | 32, 16 per line (port) includes CBR, VBR, and ABR queues |

## ATM Service Interface (ASI-1, LM-2E3)

|                           |                                                          |
|---------------------------|----------------------------------------------------------|
| Capacity:                 | 2 ports per card                                         |
| Interface:                | E3                                                       |
| Line Rate:                | 80,000 cells/sec.                                        |
| No. of channels per card: | 1000                                                     |
| No. of channels per node: | 1000 or 5000 (grouped)                                   |
| VPI Addressing Range:     | 0–255 (UNI), 0-1023 (NNI_                                |
| VCI Addressing Range:     | 1–4095                                                   |
| Queues:                   | 32, 16 per line (port) includes CBR, VBR, and ABR queues |



## ATM Service Interface (ASI-2, LM-OC3)

|                           |                           |
|---------------------------|---------------------------|
| Capacity:                 | 2 ports per card          |
| Interface:                | OC3                       |
| Line Rate:                | 353,208 cells/sec.        |
| No. of channels per card: | 1000                      |
| No. of channels per node: | 1000 or 5000 (grouped)    |
| VPI Addressing Range:     | 0-255 (UNI), 0-1023 (NNI_ |
| VCI Addressing Range:     | 1-4095                    |
| Queues:                   |                           |



# BPX Switch Cabling Summary

---

This appendix provides details on the cabling required to install the BPX switch.

---

**Note** In all cable references, the transmit direction is from the BPX switch, receive is to the BPX switch.

---

## Trunk Cabling

Trunk cables connect the customer DSX-3 crossconnect point or T3-E3 Interface Module to the BPX switch at the LM-3T3 back card. Refer to Table B-1 for details.

**Table B-1      Trunk Cables**

| Cable Parameter | Description                                                                                                                                                                                                                                                                    |
|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Type:           | 75-ohm coax cable (RG-59 B/U for short runs, AT&T 734A for longer runs). Two per T3/E3 line (XMT and RCV).<br><br>For European shipment of the BXM-E3 cards, in order to meet CE mark transient test requirement (IEC1000-4-4), RG-17G double shielded SMB cable must be used. |
| Max. Length:    | 450 feet max. between the BPX switch and the DSX-3/E3 point.                                                                                                                                                                                                                   |
| Connector:      | Terminated in male BNC; Rx is receive from trunk, Tx is transmit to trunk.                                                                                                                                                                                                     |

## Power Cabling

Power connections are made to the AC Power Supply Shelf or the DC Power Entry Module at the rear of the BPX switch. Refer to Table B-2 and Table B-3. (next page) for acceptable cable and wire types.

## AC Powered Nodes

AC power cables may be provided by the customer or ordered from Cisco. Several standard cables are available (see Table B-2). AC cables with other plugs or different lengths may be special ordered. For users who wish to construct their own power cable, the cable must mate with an IEC320 16/20A male receptacle on rear of the AC Power Supply Assembly.

**Table B-2 AC Power Cables**

| Cable Parameter    | Description                                                                                                                                                                                   |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Cable:             | Provided with 8 feet (2.3 m.) of 3-conductor wire with plug.                                                                                                                                  |
| Plug: customer end | 20 A NEMA L620, 3-prong plug (domestic) or<br>13 A 250 Vac BS1363, 3-prong fused plug (UK, Ireland)<br>CEE 7/7 (Continental Europe)<br>AS3112 (Australia/New Zealand)<br>CEI23-16/VII (Italy) |

## DC Powered Nodes

DC wiring (Table B-3) is generally provided by the customer.

**Table B-3 DC Power Wiring**

| Cable Parameter | Description                                                                                                                                  |
|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| Wiring:         | Single conductor, 8 AWG recommended wire gauge, 75°C insulation rating, copper conductors only. Provision is provided for attaching conduit. |
| Connection:     | 90° ring lug for #10 screw terminal block.                                                                                                   |

## LM-BCC Cabling

This cabling connects data ports on the LM-BCC to StrataView Plus NMS computers, control terminals, and modems. It is also used for external clock inputs from a clock source. See *Appendix C, BPX Switch Peripherals*, for more details on peripherals that can be attached to these ports.

## Auxiliary and Control Port Cabling

The auxiliary and control ports are used to connect one of the nodes in the network to a control terminal, StrataView NMS workstation, or modem connections for remote alarm reporting or system monitoring. Refer to Table B-4 and Table B-5 for details on this cable.

**Table B-4 Auxiliary and Control Port Cabling**

| Cable Parameter    | Description                                                                                                                                                                  |
|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Interface:         | RS-232 DCE ports.                                                                                                                                                            |
| Suggested Cable:   | 24 AWG, 25-wire. A straight-through RS-232 cable is used for a terminal or printer connection. A null modem cable may be needed when interfacing with modems on either port. |
| Cable Connector:   | DB-25, subminiature, male. Table B-5 contains a list of the port pin assignments.                                                                                            |
| Max. Cable Length: | 50 feet (15 m.)                                                                                                                                                              |

**Table B-5 Auxiliary and Control Port Pin Assignments**

| Pin# | Name | Source | Description     |
|------|------|--------|-----------------|
| 1    | FG   | both   | Frame Ground    |
| 2    | TxD  | DTE    | Transmit Data   |
| 3    | RxD  | DCE    | Receive Data    |
| 4    | RTS  | DTE    | Request to Send |
| 5    | CTS  | DCE    | Clear to Send   |
| 6    | DSR  | DCE    | Data Set Ready  |
| 7    | SG   | both   | Signal Ground   |
| 8    | CD   | DCE    | Carrier Detect  |
| 20   | DTR  | DTE    | Data Term Ready |

## LAN Port Cabling

The LAN connection is used to connect one of the nodes in the network to a StrataView Plus NMS workstation. See Table B-6 and Table B-7 for details.

**Table B-6 LAN Port Cabling**

| Cable Parameter    | Description                                                                       |
|--------------------|-----------------------------------------------------------------------------------|
| Interface:         | Ethernet DCE port.                                                                |
| Suggested Cable:   | TBS                                                                               |
| Cable Connector:   | DB-15, subminiature, male. Table B-7 contains a list of the port pin assignments. |
| Max. Cable Length: | 50 feet (15 m.) max. to interface adapter.                                        |

**Table B-7 LAN Port Pin Assignments**

| Pin # | Name                 | Pin # | Name                 |
|-------|----------------------|-------|----------------------|
| 1     | Shield               | ---   | ---                  |
| 2     | Collision Presence + | 9     | Collision Presence - |
| 3     | XMT +                | 10    | XMT -                |
| 4     | Reserved             | 11    | Reserved             |
| 5     | RCV +                | 12    | RCV -                |
| 6     | Power return         | 13    | Power (+12V)         |
| 7     | Reserved             | 14    | Reserved             |
| 8     | Reserved             | 15    | Reserved             |

## Modem Cabling

Refer to *Appendix C, BPX Switch Peripherals*, for modem cabling information.

## External Clock Input Cabling

This cabling is for making external clock connections for use by the BCC-32, BCC-3, and BCC-4 backcards. The BCC-32 uses the BCC-bc backcard, and the BCC-3 and BCC-4 both use the BCC-3-bc backcard.

### T1 Clock Cabling

Table B-8 through Table B-11 lists T1 clock cabling details.

**Table B-8 External Clock Cabling**

| Cable Parameter    | Description                                                                                                         |
|--------------------|---------------------------------------------------------------------------------------------------------------------|
| Cable Type:        | 22 AWG, ABAM individually shielded twisted pair. Two pair per T1 line (1 transmit and 1 receive).                   |
| Cable Connector:   | Male DB-15 subminiature. See Table B-10 through Table B-11 for pinouts.                                             |
| Max. Cable Length: | 533 ft (162 m.) maximum between the BPX switch and the first repeater or CSU. Selection of cable length equalizers. |

**Table B-9 T1 Connection to XFER TMG on BCC-bc**

| Pin # | Description            |
|-------|------------------------|
| 1     | Transfer timing ring   |
| 2     | Transfer timing tip    |
| 3 & 4 | Transfer timing shield |

**Table B-10 T1 Connection to EXT TMG on BCC-bc**

| Pin # | Description         |
|-------|---------------------|
| 2     | Receive pair shield |
| 3     | Receive tip         |
| 11    | Receive Ring        |

**Table B-11 T1 Connection to EXT 1 or EXT 2 on BCC-3-bc**

| Pin # | Description            | Function                                             |
|-------|------------------------|------------------------------------------------------|
| 1     | Transmit tip           | Transmit T1 timing signal synchronized to the node   |
| 2     | Transmit pair shield   |                                                      |
| 3     | Receive tip            | Receive clock for synchronized clock source for node |
| 4     | Receive pair shield    |                                                      |
| 7     | Transfer timing tip    |                                                      |
| 8     | Transfer timing shield |                                                      |
| 9     | Transmit ring          |                                                      |
| 11    | Receive ring           |                                                      |
| 15    | Transfer timing ring   |                                                      |

## E1 Clock Cabling

Table B-12 through Table B-15 lists E1 clock cabling details.

**Table B-12 E1 Connector Pin Assignments for External Clock**

| Connector          | Description                                                                                                                                            |
|--------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| Cable Type:        | 75-ohm coax cable for unbalanced connection or 100–120-ohm twisted pair for balanced connection. Two cables/pairs (1 transmit, 1 receive) per E1 line. |
| Cable Connector:   | Two female BNC for unbalanced connection; male DB15 for balanced connection. See Table B-13 and Table B-15 for pinouts.                                |
| Max. Cable Length: | Approx. 100 meters maximum between the BPX switch and the first repeater or CSU. Equalizer for cable length.                                           |

**Table B-13 E1 Connection 75 Ohm to EXT TMG on BCC-bc or BCC-3-bc**

| Connector | Description           |
|-----------|-----------------------|
| BNC       | Receive E1 from trunk |

**Table B-14 E1 Connection 100/120 Ohm to EXT TMG on BCC-bc**

| Pin # | Description         |
|-------|---------------------|
| 2     | Receive pair shield |
| 3     | Receive tip         |
| 11    | Receive Ring        |

**Table B-15 E1 Connection 100/120 Ohm to EXT 1 or EXT 2 on BCC-3-bc**

| Pin # | Description            | Function                                             |
|-------|------------------------|------------------------------------------------------|
| 1     | Transmit tip           | Transmit T1 timing signal synchronized to the node   |
| 2     | Transmit pair shield   |                                                      |
| 3     | Receive tip            | Receive clock for synchronized clock source for node |
| 4     | Receive pair shield    |                                                      |
| 7     | Transfer timing tip    |                                                      |
| 8     | Transfer timing shield |                                                      |
| 9     | Transmit ring          |                                                      |
| 11    | Receive ring           |                                                      |
| 15    | Transfer timing ring   |                                                      |

## External Alarm Cabling

This cable (Table B-16) is for connecting network alarm outputs to the LM-ASM ALARM OUTPUT connector only. Table B-17 lists the pinouts for the network alarm outputs.

**Table B-16 External Alarm Cabling**

| Cable Parameter | Description                |
|-----------------|----------------------------|
| Interface:      | Dry-contact relay closure. |
| Wire:           | 24 AWG, shielded, 6-pair.  |
| Connector:      | DB-15, Subminiature, male  |

**Table B-17 Network Alarm Pin Assignments**

| Pin | Alarm         | Description     |
|-----|---------------|-----------------|
| 1   | Audible—Major | Normally open   |
| 2   |               | Common          |
| 9   |               | Normally closed |
| 4   | Visual—Major  | Normally open   |
| 5   |               | Common          |
| 12  |               | Normally closed |
| 7   | unused        | n.c.            |
| 8   | unused        | n.c.            |
| 3   | Audible—Minor | Normally open   |
| 11  |               | Common          |
| 10  |               | Normally closed |
| 6   | Visual—Minor  | Normally open   |
| 14  |               | Common          |
| 13  |               | Normally closed |
| 15  | unused        | n.c.            |

## Standard BPX Switch Cables

Table B-18 lists the various cables that may be ordered directly from Cisco. Cable lengths are specified as a suffix to the Cisco model number. For example 5610-50 indicates a 50 foot cable. Cables are generally available in standard lengths of 10 ft (3 m.), 25 ft (7.6 m.), 50 ft (15 m.), 75 ft (22.8 m.) and 100 ft (30 m.) Lengths of 101 ft. (30 m.) to 600 ft. (183 m.) are available on a special order.

When a cable is connectorized, the connector gender (male-female) will be indicated as well as the number of pins. For example RS-232/M25-M25 indicates a cable terminated with a male DB25 at both ends.



**Table B-18 Standard Cables Available from Cisco**

| Model#   | Description                   | Usage                                                               |
|----------|-------------------------------|---------------------------------------------------------------------|
| T3-E3-10 | 75 $\Omega$ coax/BNC-BNC, 10' | T3 or E3 trunk interface                                            |
| T3-E3-25 | 75 $\Omega$ coax/BNC-BNC, 25' |                                                                     |
| T3-E3-50 | 75 $\Omega$ coax/BNC-BNC, 50' |                                                                     |
| T3-E3-75 | 75 $\Omega$ coax/BNC-BNC, 75' |                                                                     |
| T3-E3-xx | length to be specified        |                                                                     |
| 5620     | RS-232/M25-F25                | Control port to control terminal, StrataView, or ext. window device |
| 5621     | RS-232/M25-M25 special        | Control or Aux. port to modem                                       |
| 5623     | RS-232/M25-M25                | Aux. port to ext. window device                                     |
| 5601     | Ground cable                  | DC                                                                  |
| 5670     | Molex-pigtail                 | DC                                                                  |
| 5671     | Spade lug-pigtail             | DC                                                                  |

## Redundancy “Y” Cable

The redundancy cables are a special “Y” cable available from Cisco. They are required for redundant trunk and data interfaces. Table B-19 lists the Y-cables used with various BPX switch back cards.

**Table B-19 Redundancy Y-Cables**

| Y - Cable        | Used On | Cisco P/N |
|------------------|---------|-----------|
| T3 trunk         | LM-3T3  | TBS       |
| E3 trunk         | LM-3E3  | TBS       |
| Aux./Cont. ports | LM-BCC  | TBS       |
| Ext. Clk. In     | LM-BCC  | TBS       |
| Ext. Clk. Out    | LM-BCC  | TBS       |



# BPX Switch Peripherals

---

This appendix provide details on BPX switch peripheral equipment, including printers and modems. The appendix includes the following sections:

- Network Management
- Printer
- Modems, Dial-In and Dial-Out

## Network Management

### Cisco StrataView Plus Terminal

A Cisco StrataView Plus workstation is recommended for managing a network containing IPX, IGX, and BPX switch. Refer to the *Cisco StrataView Plus Operation Manual* and *Cisco StrataView Plus Installation Manual* for setup instructions and specifications for the Cisco StrataView Plus NMS, which is required to provide network alarm, control, and statistics monitoring.

---

**Note** For network management, a Cisco StrataView Plus workstation is connected to the LAN port of one or more network nodes, typically BPX switches because of their processing power, to provide network management.

---

### Control Port, Local Control

A terminal (pc or workstation, including a Cisco StrataView Plus workstation) can be connected to the CONTROL port of a BPX switch for temporary or local control. This can be especially useful during installation, initial power-up, and configuration. Refer to Table C-1 for configuration data for the BPX CONTROL port.

**Table C-1 Control Port Parameters for Local Control (pc or workstation)**

| Parameter             | Setting                                                                                        |
|-----------------------|------------------------------------------------------------------------------------------------|
| BPX switch Port Used: | Serial CONTROL port, located on a BCC back card, is used to interface to a local terminal.     |
| Code:                 | Standard 7 or 8-bit ASCII; 1 or 2 stop-bits; even, odd or no parity.                           |
| Interface:            | RS-232 DCE.                                                                                    |
| Data Rate:            | All standard asynchronous data rates from 300 to 19200 bps, independently software-selectable. |
| Supported Terminals:  | Any terminal compatible with DEC VT-100.                                                       |
| Cable Required:       | Straight-through RS-232 cable.                                                                 |

## Printer

The standard maintenance printer that is currently being shipped with the BPX switch is the Okidata Model 184 dot matrix printer. This printer may be connected to any node. Refer to Table C-2 and Table C-3 for printer configuration requirements. Note that this is not the same as the printer that may be provided with the Cisco StrataView Plus NMS terminal but in addition to it.

**Table C-2 Auxiliary Port Parameters for OkiData 184 Printer**

| Parameter             | Setting                                                                                 |
|-----------------------|-----------------------------------------------------------------------------------------|
| BPX switch Port Used: | Serial AUXILIARY port, located on the LM-BCC card, is used for the maintenance printer. |
| Code:                 | Standard 8-bit ASCII; 8 data bits, 1 stop-bit, odd parity.                              |
| Interface:            | RS-232 DCE.                                                                             |
| Data Rate:            | 9600 baud.                                                                              |
| Supported Printer:    | Okidata 184.                                                                            |
| Cable Required:       | Straight-through RS-232 cable                                                           |

## DIP Switch Settings for Okidata 184

DIP Switch A is an 8-section DIP switch located on the printer's main circuit board. Access to the configuration switches is made by sliding back the switch cover at the top, rear of the printer case. Set Switch A as indicated in Table C-3.

**Table C-3 Switch A Settings—Okidata 184 Printer**

| Switch A | Setting | Description                 |
|----------|---------|-----------------------------|
| 1        | Off     | ASCII with non-slashed zero |
| 2        | Off     | ASCII with non-slashed zero |
| 3        | Off     | ASCII with non-slashed zero |
| 4        | Off     | 11-inch paper length        |
| 5        | On      | 11-inch paper length        |
| 6        | Off     | No Auto Line Feed.          |
| 7        | On      | 8-bit data.                 |
| 8        | Off     | Enables front panel.        |

The High Speed Serial Interface DIP Switch consists of two DIP switches, SW1 and SW2, located on a serial-board that is attached to the printer's main board. Set switches 1 and 2 as indicated in Table C-4 and Table C-5.

**Table C-4      Switch 1 Settings—Okidata 184 Printer**

| Switch 1 | Setting | Description          |
|----------|---------|----------------------|
| 1        | On      | Odd parity.          |
| 2        | On      | No parity.           |
| 3        | On      | 8 data bits.         |
| 4        | On      | Ready/busy protocol. |
| 5        | On      | Test select circuit. |
| 6        | On      | Print mode.          |
| 7        | On      | Busy line selection. |
| 8        | On      | DTR pin 2 enabled.   |

**Table C-5      Switch 2 Settings—Okidata 184 Printer**

| Switch 2 | Setting    | Description           |
|----------|------------|-----------------------|
| 1        | Off        | Transmission          |
| 2        | On         | Speed = 9600 baud.    |
| 3        | On         | Speed = 9600 baud.    |
| 4        | On         | DSR active.           |
| 5        | On         | Buffer = 32 bytes.    |
| 6        | On         | Timing = 200 ms.      |
| 7        | On         | Space after power on. |
| 8        | Don't care | Not used.             |

## Modems, Dial-In and Dial-Out

Customer service uses modems for diagnosing and correcting customer problems with installed BPX switches. The modem that is currently recommended for use with the BPX switch is the Codex Model V.34R.

A dial-in connection to a BPX switch RS-232 from customer service via a modem uses the CONTROL port of the BPX switch. A dial-out connection from a BPX switch via a modem to customer service uses the AUXILIARY port of the BPX switch. Refer to Table C-6 for interface requirements.

**Table C-6 Modem Interface Requirements**

| Parameter             | Requirement                                                                                                                                |
|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| BPX switch Port Used: | CONTROL port on BCC back card is used for auto-answer modem setup.<br>AUXILIARY port on a BCC back card is used for auto-dial modem setup. |
| Code:                 | Standard 8-bit ASCII, 1 stop-bit, no parity.                                                                                               |
| Interface:            | RS-232 DCE.                                                                                                                                |
| Cable to modem:       | Null modem cable: CONTROL or AUXILIARY port to modem (DCE to DCE)                                                                          |
| Phone Lines:          | Dedicated, dial-up business telephone line for Customer Service-to-BPX switch modem.                                                       |
| Data Rate:            | All standard asynchronous data rates from 300 to 19200 bps, independently software-selectable.                                             |
| Supported Modems:     | Motorola V.34R 28.8 baud modem with or without talk/data button.                                                                           |

## Motorola V.34R BPX Switch Dial-In Configuration

### BPX Switch Auto-Answer (Dial-In to BPX switch)

The following is a setup procedure that allows customer service to dial in to the customer's BPX switch to provide support and troubleshooting:

- Step 1** Using the **cnfterm** command, set the BPX CONTROL port speed to 9600 bps.
- Step 2** Using the **cnftermfunc** command, set the terminal type to VT100/StrataView.
- Step 3** To program the modem, temporarily attach a terminal to the modem using a straight through RS-232 cable (DTE to DCE). The modem EIA port will automatically match the 9600 bps setting of the terminal.
- Step 4** Enter the commands listed in Table C-7 to set up the modem for proper operation.

---

**Note** Consult the manual that is supplied with your modem for specific information concerning the modem configuration. Call customer service for latest modem configuration information.

---

- Step 5** Disconnect the terminal and the straight-through cable from the BPX CONTROL port.


**Step 6** Connect the modem to the BPX CONTROL port using a null-modem cables Figure C-1. A null modem cable is used, as the connection is essentially a DCE to DCE rather than a DTE to DCE connection.

**Step 7** Ask customer service to assist in testing the operation of the modem setup.

**Table C-7 V.34R Modem Configuration for Auto-Answer (Dial-in to BPX)**

| Step | Command | Function                                                                                                      |
|------|---------|---------------------------------------------------------------------------------------------------------------|
| 1.   | AT & F  | Reset to factory default.                                                                                     |
| 2    | ATL1    | Set modem loudness, modem speaker at low volume.                                                              |
| 3.   | ATS0=1  | Enables Auto-Answer Mode on modem (answer on first ring).                                                     |
| 4    | AT\N3   | Enables automatic MNP error correction.                                                                       |
| 5    | AT%C    | Disables data compression.                                                                                    |
| 6.   | AT\Q0   | Disables XON/XOFF flow control.                                                                               |
| 7.   | AT&S1   | Sets DSR to "normal".                                                                                         |
| 8.   | ATE0    | Disables local character echo. Modem will not echo what you type.                                             |
| 9.   | ATQ1    | Disables result codes. (Modem will appear "dead", will stop responding "OK" to commands.)                     |
| 10.  | AT&W    | Saves current configuration settings in non-volatile memory. (Writes and stores to configuration location 1.) |

**Figure C-1 Dial-Modem Cabling for Auto Answer (Dial-In to BPX)**



**Legend**

- FG - Frame Ground
- TXD - Transmit Data
- RXD - Receive Data
- RTS - Request To Send
- CTS - Clear To Send
- DSR - Data Set Ready
- DTR - Data Terminal Ready
- CD - Carrier Detect
- SG - Signal Ground

12138

### IPX Auto-Dial to Customer Service

The following is a setup procedure for the customer’s BPX to dial up customer service.

- Step 1** Using the **cnfterm** command, set the BPX AUXILIARY port speed to 9600 bps and enable XON/XOFF flow control.
- Step 2** Using the **cnftermfunc** command, select option 7, “Autodial Modem” and enter the customer service-designated Network ID, and the customer service modem phone number.
- Step 3** Attach a 9600 bps terminal to the modem using a straight-through cable. The modem EIA port will automatically match the 9600 bps setting of the terminal.
- Step 4** Enter the commands listed in either Table C-8 (V.34R modem without talk/data pushbutton) or Table C-9 (V.34R modem with talk/data pushbutton), to set up the modem for proper operation.

---

**Note** Consult the manual that is supplied with your modem for specific information concerning the modem configuration. Call customer service for latest modem configuration information.

---

- Step 5** Disconnect the terminal and the straight-through cable from the IPX CONTROL port.
- Step 6** Connect the modem to the IPX AUX port using a null modem cable Figure C-2.
- Step 7** Ask customer service to assist in testing the operation of the modem setup.

**Table C-8 V.34R Auto-Dial Configuration (dial-out to customer service)\***


| Step                                                                                                 | Command | Function                                       |
|------------------------------------------------------------------------------------------------------|---------|------------------------------------------------|
| <b>These configuration commands are for a V.34R modem that does not have a talk/data pushbutton.</b> |         |                                                |
| 1.                                                                                                   | AT&F    | Initializes factory defaults.                  |
| 2.                                                                                                   | ATL1    | Modem speaker at minimum volume.               |
| 3.                                                                                                   | AT*SM3  | Enables automatic MNP error correction.        |
| 4.                                                                                                   | AT*DC0  | Disables data compression.                     |
| 5.                                                                                                   | AT*SC1  | Enables DTE speed conversion                   |
| 6.                                                                                                   | AT*FL1  | Enables XON/XOFF flow control.                 |
| 7.                                                                                                   | AT*SII  | Enables 5-minute inactivity disconnect.        |
| 8.                                                                                                   | AT&C1   | DCD controlled by modem.                       |
| 9.                                                                                                   | AT&D2   | Modem disconnects when IPX toggles DTR.        |
| 10.                                                                                                  | AT&V    | Verify entries.                                |
| 11.                                                                                                  | AT&W    | Saves current settings to non-volatile memory. |



**Table C-9 V.34R with talk/data, Auto-Dial Configuration (dial-out to customer service)\***

| Step                                                                                       | Command | Function                                               |
|--------------------------------------------------------------------------------------------|---------|--------------------------------------------------------|
| <b>These configuration commands are for a V.34R modem that has a talk/data pushbutton.</b> |         |                                                        |
| 1.                                                                                         | AT&F    | Initializes factory defaults.                          |
| 2.                                                                                         | ATL1    | Modem speaker at minimum volume.                       |
| 3.                                                                                         | AT\N3   | To enable MNP error correction                         |
| 4.                                                                                         | AT%C    | To disable data compression                            |
| 5.                                                                                         | AT\J    | Enables DTE speed conversion                           |
| 6.                                                                                         | AT\Q1   | Enables flow control                                   |
| 7.                                                                                         | AT\T3   | Enables 3-minute inactivity timer                      |
| 8.                                                                                         | AT&C1   | DCD controlled by modem.                               |
| 9.                                                                                         | AT&D2   | Modem disconnects when IPX toggles DTR.                |
| 10.                                                                                        | AT&V    | Verify entries. ( <i>shows current configuration</i> ) |
| 11.                                                                                        | AT&W    | Saves current settings to non-volatile memory.         |

**Figure C-2 Dial Modem Cabling for Auto Dial (dial-out to customer service)**



Note: Cable must be connected in direction shown from node to modem because wiring is not pin-to-pin symmetrical.

**Legend**

- FG - Frame Ground
- TXD - Transmit Data
- RXD - Receive Data
- RTS - Request To Send
- CTS - Clear To Send
- DSR - Data Set Ready
- DTR - Data Terminal Ready
- CD - Carrier Detect
- SG - Signal Ground

12139



# AT3-6ME Interface Adapter


This appendix describes the AT3-6ME Interface Adapter, sometimes referred to as the T3-T2 Interface Adapter, that is used with the BPX switch to provide a 6 Mbps ATM network interface to T2 transmission facilities.

## Application

The AT3-6ME Interface Adapter is used with the BPX Broadband ATM Switch or the IPX Narrowband Switch in applications where it is required to interface a 6 Mbps T2 digital network facility to the 45 Mbps T3 ATM port on the BPX, IGX, or IPX node.

Applications include networks where T2 transmission facilities are available. Users with ATM networks who require somewhat more bandwidth than is provided by the T1 or E1 ATM network connections but do not need the full T3 bandwidth provided by the BPX ATM network ports can also benefit from using the AT3-6ME Interface Adapter. See Figure D-1 for a typical application.

**Figure D-1 Network Application**



## General Description

The AT3-6ME Interface Adapter is a bi-directional device which provides a conversion between transmission systems of different transmission rates, the North American T3 (44.736 Mbps) and the Japanese 6M (T2). It is used only in ATM networks. The adapter is transparent to both users and the network.

The T3 interface operates at 44.736 Mbps with the B-ISDN Physical Layer Convergence Protocol (PLCP) and meets the ATM Forum standards. The T2 interface operates at 6 Mbps according to the Japanese Nippon Telephone & Telegraph (NTT) User-Network Interface (UNI) specifications.

ATM cells from one interface are mapped to the other interface enabling users with ATM node equipment with North American T3 ATM ports to operate in a T2 network. The ATM cell throughput on a T2 digital trunk using this adapter is limited to 14,490 cells per second.

The cell transfer rate for T2 is greatly reduced from the T3 cell rate out of a T3 port on an IPX using the ATMT card or from a BPX port. It is very important to restrict the cell rate from the node when using a T2 trunk. Cell rate adaptation is done via software trunk configuration at the T3 ATM interface, where the non null cell throughput is limited to the T2 capacity. In the T2 to the T3 direction, the T3 ATM interface has more than enough capacity to accommodate the T2 cell rate.

The Interface Adapter can buffer a 70-cell burst at the T3 rate before the T2 interface will begin to drop cells. Cells will continue to be dropped until the T3 interface returns to a rate that complies with the bandwidth of the T2 interface.

All alarms and line errors are passed through the Interface Adapter unchanged. Any existing network management system has an instant view of the actual network transmission system. Errors at the ATM layer propagate through from one interface to the other, thus the end user has the complete knowledge and statistical information regarding the network status at all times. Therefore a special network management interface is not required.

Since the T3 interface is asynchronous and the T2 is synchronous, the AT3-6ME can be configured to carry the synchronization information through from one interface to the other. The synchronization is carried through the T3 interface using the PLCP-embedded 8 KHz. The T2 interface clock may be generated locally or it may be slaved to the public network.

## Equipment Description

The AT3-6ME is fully contained in a metallic housing designed to be mounted in a 19" equipment rack. It occupies only one rack mounting space and is powered from normal AC line powering. The power supply accommodates an input voltage over the range 90 to 240 VAC, 50 or 60 Hz.

## Interface Connectors

The interface connectors are located on the rear panel (see Table D-1 and Figure D-2). These connectors include:

- Two T3 BNC connectors, XMT and RCV.
- Two 6M BNC connectors, XMT and RCV.
- A single RS-232 male, subminiature 9-pin control terminal interface.
- AC input connector with integral fuse.

The control terminal is a standard RS-232 interface DTE interface. No hardware handshake is required for the interface. The diagnostic display comes up immediately. It operates at 9.6 Kbps with any ASCII terminal.

**Table D-1 Rear Panel Connectors**

| <b>Connector</b> | <b>Type</b> | <b>Description</b>                               |
|------------------|-------------|--------------------------------------------------|
| T3 RX            | BNC         | Receive T3 input from BPX, IGX, or IPX ATM port. |
| T3 TX            | BNC         | Transmit T3 output to BPX, IGX, or IPX ATM port. |
| T2 RX            | BNC         | Receive 6 MB input from T2 facility.             |
| T2 TX            | BNC         | Transmit 6 MB input to T2 facility.              |
| RS-232           | DB9         | Control terminal connection.                     |
| Primary Power    | IEC         | AC power input with fuse.                        |

## Front Panel Indicators

The front panel of the system provides LED indicators for the alarm status of the transmit and the receive T3 and the T2 interfaces (refer to Table D-2 and Figure D-2). Also on the front panel are indications for power and for operating status (Fail/Active).

The Overflow LED indicates that the cell rate coming from the T3 interface exceeds the bandwidth of the T2 facility and that the Interface Adapter buffer has overflowed.


**Table D-2 Front Panel Indicators**

| Indicator              | Color     | Description                                                                                                                                                    |
|------------------------|-----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| T3 Receive Status—AIS  | Green     | Alarm Indication signal detected on the RCV T3 line.                                                                                                           |
| T3 Receive Status—RAI  | Yellow    | Remote Alarm Indication signal detected on the receive T3 line.                                                                                                |
| T3 Receive Status—LOS  | Red       | Loss of receive T3 signal.                                                                                                                                     |
| T3 Receive—LOF         | Red       | Loss of frame on receive T3 signal.                                                                                                                            |
| T3 Transmit Status—AIS | Green     | Alarm Indication signal detected on the transmit T3 line.                                                                                                      |
| T3 Transmit Status—RAI | Yellow    | Remote Alarm Indication signal detected on the transmit T3 line.                                                                                               |
| T3 Transmit Status—LOS | Red       | Loss of transmit T3 signal.                                                                                                                                    |
| T2 Receive Status—AIS  | Green     | Alarm Indication signal detected on the RCV T2 line.                                                                                                           |
| T2 Receive Status—RAI  | Yellow    | Remote Alarm Indication signal detected on the receive T2 line.                                                                                                |
| T2 Receive Status—LOS  | Red       | Loss of receive T2 signal.                                                                                                                                     |
| T2 Receive—LOF         | Red       | Loss of frame on receive T2 signal.                                                                                                                            |
| T2 Transmit Status—AIS | Green     | Remote Alarm Indication signal detected on the transmit T2 line.                                                                                               |
| T2 Transmit Status—RAI | Yellow    | Loss of transmit T2 signal.                                                                                                                                    |
| T2 Transmit Status—LOS | Red       | Loss of frame on transmit signal.                                                                                                                              |
| Overflow               | Red       | T3 receive cell rate exceeds the T2 line capacity.                                                                                                             |
| FT2                    | Red       | Fractional T2 indication <u>for future use</u> .                                                                                                               |
| T3/T2 loop             | Red       | Indicates the unit is in loop back mode, external toward the T3 and T2 line interfaces.                                                                        |
| Active/Fail            | Green/Red | Upon power up the system will go through extensive self tests. If self-test passes, the Active/Fail LED will be green; if self-test fails the LED will be RED. |
| Power                  | Green     | Power ON indication.                                                                                                                                           |

## DIP Switches

The adapter has two front panel DIP switches, a two-position (SW-1), and a 12-position (SW-2) switch. SW-1 controls the configurations that may interrupt operation and should be done through a two-step operation. SW-2 enables all other configuration parameters.

Figure D-2 Front and Rear Panel Features



## Installation

Install the AT3-6ME in a rack adjacent to the BPX enclosure (allowing room for any AC Power Supply Assembly that may also need to be mounted) or in the IPX enclosure wherever there is space for the AT3-6ME adapter.

### System Connections

Two short BNC-BNC cables are required to connect the AT3-6ME to the BPX or IPX node.

- Step 1** For use with BPX switch, connect one cable between one of the three TX connectors on a selected BPX LM-3T3 card and the T3-RX connector on the AT3-6ME back panel. For IPX applications, connect to the TX connector on the ATMT back card.
- Step 2** Connect the other cable between the associated RX connector on the BPX LM-3T3 or ATMT card and the T3-TX connector on the AT3-6ME back panel.
- Step 3** Connect the cable coming from the 6 Mbps facility to the T2-RX connector on the AT3-6ME.
- Step 4** Connect the cable going to the 6 Mbps facility to the T2-TX connector on the AT3-6ME.
- Step 5** Connect the AC power cord to the IEC connector on the rear of the AT3-6ME.

### AT3-6ME Configuration

The adapter configuration is done via a set of DIP switches located on the front panel. There are two sets of switches, a 12-position switch and a two position switch. The two position switch enables the configuration change via the terminal and enable/disable the loop push button located in the front panel (to secure against accidental operation). Review both Table D-3 and Table D-4. Set the appropriate DIP switches with the power off.

**Table D-3      DIP Switch SW-1 Selection Guide**

| Switch | Position | Function                                        |
|--------|----------|-------------------------------------------------|
| 1      | Down     | Enable configuration via the TTY.               |
| 1      | Up       | Disable configuration via the TTY (default).    |
| 2      | Down     | Enable front panel loop push button.            |
| 2      | Up       | Disable front panel loop push button (default). |



**Table D-4**      **DIP Switch SW-2 Selection Guide**

| Switches   | Position   | Function                                                                          |
|------------|------------|-----------------------------------------------------------------------------------|
| 1          | Up         | Internal synchronization source for the T2 transmitter                            |
| 2          | Up         |                                                                                   |
| 1          | Up         | Slave T2 transmitter to T3 line                                                   |
| 2          | Down       |                                                                                   |
| 1          | Down       | Slave T2 transmitter to T2 receiver                                               |
| 2          | Down       |                                                                                   |
| 3          | Up         | Long length T3 cable                                                              |
| 4          | Up         |                                                                                   |
| 3          | Up         | Medium length T3 cable                                                            |
| 4          | Down       |                                                                                   |
| 3          | Down       | Short length T3 cable; system is co located to IPX/IGX/BPX <sup>1</sup> (default) |
| 4          | Down       |                                                                                   |
| 5, 6       | don't care | Unused                                                                            |
| 7          | Up         | ATM converter mode                                                                |
| 7          | Down       | Test Mode                                                                         |
| 8          | Up         | Enable BPV relay from T2 to T3                                                    |
| 8          | Down       | Disable PV relay from T2 to T3                                                    |
| 9          | Up         | Long length T2 cable                                                              |
| 9          | Down       | Short length T2 cable (default) <sup>1</sup>                                      |
| 10, 11, 12 | Don't care | Unused                                                                            |

1. T2 and T3 cable length should be set to "short" upon power-up for self-test.  
Upon LOS, defaults to "internal synchronization."

## BPX, IGX, or IPX Port Configuration

The trunk on the BPX, IGX, or IPX node must be reconfigured from Cisco StrataView Plus or a local control terminal.

- Step 1**    Telnet to the first node equipped with an AT3-6ME.
- Step 2**    Use the Configure Trunk (**cnftrk**) command to select T2 for the Tx Trunk Rate.
- Step 3**    Set the RCV Trunk Rate to 28980 cps.
- Step 4**    Repeat steps 1 through 3 for all other nodes using the AT3-6ME.

## Operation

The following paragraphs describe the various operating modes for the AT3-6ME. The unit is basically designed for unattended operation. Any failures in the unit or any line alarms or errors will be propagated.

### Power-Up Sequence

During the system power-up, the unit goes through a self test procedure. The Power LED turns green. The Active/ Fail LED stays off until the self test sequence is completed. At the end of the self test the loop LED comes on for about 5 seconds.

Through the self test, all LEDs light up. When the test is completed successfully the Active/Fail LED turns green. If the system fails self test, it will repeat the self-test twice more. If it continues to fail, the Active/Fail LED turns red.

### Normal Operation

In standard operation the AT3-6ME system relays ATM cells from the T2 6M to the T3 interface. To accommodate for the difference in the transmission rate, the AT3-6ME removes all null cells from the T3 interface. The T3 sources connected to the AT3-6ME must regulate their ATM Cell rate not to exceed the T2 6M cell rate. The AT3-6ME can absorb up to 70 cells in a single burst.

The AT3-6ME Interface Adapter can interface to any ATM UNI or NNI line at the T2 or T3 rate. The AT3-6ME Relays alarms and errors from one interface to the other. It relays the alarm and error conditions as indicated in Table D-5.

**Table D-5 Alarm Handling**

| <b>Alarms Passed Thru<br/>(both directions)</b> | <b>Errors Relayed Thru<br/>(both directions)</b> |
|-------------------------------------------------|--------------------------------------------------|
| AIS                                             | HEC Error—both directions.                       |
| RAI                                             | BPV (up to $10^{-5}$ rate)—6M to T3 only.        |
| LOS                                             |                                                  |
| LOF                                             |                                                  |

### Remote Loop Operation

The AT3-6ME has the capability of creating a remote loop on both the T3 and the T2 sides for test purposes. The loop can be activated by manually pressing a front-panel switch or through the control terminal. The loopbacks are through looping relays at the two interfaces and they operate simultaneously.

To activate the loop from the front panel, one must first enable the proper DIP switch on SW-1. Then press and hold the front panel push button for one second. This is to prevent accidental operation of the loop. Once the loop is set it can be removed by operating the loop switch a second time or it will automatically remove itself after one hour.

### Terminal Operation

The system is designed to operate without a terminal. There is a terminal interface designed for diagnostics and maintenance purpose only. The terminal interface is always active and continuously displays the user prompt. The terminal interface operating parameters are as follows:

|                       |          |
|-----------------------|----------|
| Electrical Interface: | RS232    |
| DTE/DCE:              | DCE      |
| Speed:                | 9.6 Kbps |
| Handshake:            | NON      |
| Connector:            | Male DB9 |

Upon power up, the system goes through power up diagnostics. The terminal displays the diagnostics sequence. Upon successful self test the unit is available for operation. The terminal will display the actual set up of the system represented by the DIP switches (see Table D-6). If the configuration was overwritten through the TTY, the terminal will display the actual set up that could be different then the dip switch setting.

**Table D-6**      **DIP Switch Settings**

| 1   | 2   | 3   | 4   | 5   | 6   | 7   | 8   | 9   | 10  | 11  | 12  | 1   | 2   |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 0/1 | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 |

## Commands

Commands are entered after the user prompt. Commands are available to display the various error counters and alarms associated with the T2 line and the T3 port interface, select the source of timing for the DSU, and to enable and remove the remote loop. Table D-7 lists available commands for use with the AT3-6ME terminal interface while Table D-8 indicates the display format.

**Table D-7**      **Command Summary**

| Command        | Parameters            | Meaning                                                                                                        |
|----------------|-----------------------|----------------------------------------------------------------------------------------------------------------|
| ?              |                       | Help Menu.                                                                                                     |
| dspstat        |                       | Display status.                                                                                                |
| dspstat clear  |                       | Clears the status display                                                                                      |
| Override dipsw | 0<br>1                | Disable TTY configuration entry.<br>Enable TTY configuration entry. Operates only when DIP switch 1-1 is down. |
| Sync source    | 0<br>1<br>2           | System is slaved to the 6M line.<br>System is slaved to the T3 line.<br>System runs of its internal clock.     |
| Remote loop    | No of seconds<br>stop | Enable remote loop back operation.<br>Cancel the loop back operation.                                          |

**Table D-8      Status Display**

| <b>Status</b>       | <b>T3<sup>1</sup></b> | <b>T2<sup>1</sup></b> |
|---------------------|-----------------------|-----------------------|
| BPV                 | NNN                   | NNN                   |
| Parity Errors       | NNN                   | X                     |
| Framing Errors      | NNN                   | NNN                   |
| PLCP Framing Errors | NNN                   | X                     |
| HEC Errors          | NNN                   | NNN                   |
| RX Cells            | NNN                   | NNN                   |
| TX Cells            | NNN                   | NNN                   |
| AIS                 | 1/0                   | 1/0                   |
| 1/0                 | 1/0                   | 1/0                   |
| LOF                 | 1/0                   | 1/0                   |
| Overflow            | X                     | 1/0                   |

1. X = not available

## Specifications

The following are the specifications for the AT3-6ME Interface Adapter:

### T3 interface

|                 |                                             |
|-----------------|---------------------------------------------|
| Line rate:      | 44.736 Mbps ±20 ppm                         |
| Framing format: | C-bit parity                                |
| Line code:      | B3ZS                                        |
| Physical layer: | PLCP format                                 |
| ATM layer:      | UNI per the ATM Forum UNI 3.0 specification |
| Cell Rate:      | Up to 96,000 cells/sec.                     |
| Connector:      | 75 ohm BNC                                  |

## T2 Interface

|                  |                                                                                                           |
|------------------|-----------------------------------------------------------------------------------------------------------|
| Line rate:       | 6.312 Mbps                                                                                                |
| Line code:       | B8ZS                                                                                                      |
| Synchronization: | Internal 6.312 Mbps $\pm$ 30 ppm or<br>Slave to the incoming 6 Mbps line or<br>Slave to the T3 PLCP frame |
| Framing format:  | ITU-T G.703                                                                                               |
| ATM Layer:       | Per NTT UNI specification dated 1993                                                                      |
| Queue:           | 75 cell FIFO                                                                                              |
| Cell Rate:       | Up to 14,490 cells/sec.                                                                                   |
| Connector:       | 75 ohm BNC                                                                                                |

## Power

|                        |                                        |
|------------------------|----------------------------------------|
| Input Power:           | 90 VAC to 250 VAC, 50/60 Hz            |
| Power consumption:     | 30 watts                               |
| Input Power Connector: | Universal power entry module with fuse |
| Fuse size:             | 1/2A 250 VAC                           |

## Mechanical

|                      |                              |
|----------------------|------------------------------|
| Rack Mounting Space: | 1 rack mount space, 19" rack |
| Size:                | 19" x 1.75" x 8.5"           |

## Terminal Interface

|            |          |
|------------|----------|
| Speed:     | 9.6 Kbps |
| Type:      | DTE      |
| Handshake: | NONE     |
| Connector: | DB9      |



# Glossary

---

## A

**A-bit (active bit)**

The bit in the frame relay frame header that indicates the status of the far end user device and the status of the PVC segment in the foreign network.

**A-law**

An analog to digital encoding scheme used to convert voice samples to an 8-bit data word used in CEPT E1 multiplex equipment. (See also  $\mu$ -law.)

**ABR (Available Bit Rate)**

ATM connection type for bursty traffic, such as data. Provides closed loop control of service rate that allows connections to use additional bandwidth when available. ABR may be used with ATM Traffic Management 4.0 standards VSVD flow congestion control, or with the proprietary ForeSight flow congestion control. (See also CBR and VBR.)

**ACO (Alarm Cut Off)**

A switch to turn off the audible alarm outputs from a node while leaving the visual alarm outputs unchanged.

**adaptive voice**

An optional feature of the IPX switch that disables VAD from connections using it whenever there is excess bandwidth available to allow the normal encoded voice to be carried on the packet line. (See also VAD.)

**ADPCM (Adaptive Differential Pulse Code Modulation)**

A compression method that samples voice 8,000 times per second, and uses the changes between samples as the basis for compression. Increases the capacity of a T1 line from 24 to 48 channels.

**ADTF (Allowed Cell Rate Decrease Factor)**

Time permitted between sending RM cells before the rate is decreased to ICR.

**AIT (ATM Interworking Trunk Card)**

The AIT front card provides an ATM trunk interface for the IPX switch. The AIT operates in conjunction with a backcard, AIT-T3 or AIT-E3.

**AIT-E3 (ATM Interworking Trunk E3 Interface Card)**

The AIT-E3 backcard provides an E3 interface for the AIT (IPX switch) or BTM (IGX switch) ATM trunk cards.

---

**AIT-T3 (ATM Interworking Trunk T3 Interface Card)**

The AIT-T3 backcard provides a T3 interface for the AIT (IPX switch) or BTM (IGX switch) ATM.

**alternate routing**

An automatic rerouting of a failed connection by a node to a new route through the network to maintain service.

**AMI (Alternate Mark Inversion)**

The line code used for T1 and E1 lines where the “1s” or “marks” on the line alternate between positive polarity and negative polarity.

**arbiter**

A BPX administration processor that polls each network port to control the data flow in and out of the crosspoint switch matrix.

**ARC (Alarm Relay Card)**

An alarm front card for the IPX switch.

**ARI (Alarm Relay Interface Card)**

An alarm interface back card for the IPX and IGX switches.

**ARM (Alarm Relay Module)**

An alarm front card for the IGX switch.

**ASM (Alarm/Status Monitor Cards)**

An alarm front card and back card set for the BPX switch.

**ATM (Asynchronous Transfer Mode)**

Data transmission that uses a very flexible method of carrying information, including voice, data, multimedia, and video between devices on a local or wide area network using 53-byte cells on virtual circuits. The 53 byte cell consists of data and a small header. (See also cell relay.)

**ATM Switched Virtual Circuits (SVCs)**

A member of the INS product family that uses ATM SVC Server Shelves and software to enhance a Cisco WAN switching network with ATM switched virtual circuits.

**ATM SVC Server Shelf**

An adjunct processor used in the INS ATM SVC application to enhance traditional Cisco WAN switching networks with ATM switched virtual circuits. The ATM SVC Server Shelf is co-located with and connected to a BPX switch.

**auxiliary port**

An RS-232 port on the front panel of the SCC card used for connecting a printer or an out-dial modem. This port is a one-way, outgoing port.

## B

**B3ZS (Bipolar with Three Zero Suppression)**

A protocol for T3 lines that converts a channel word with three consecutive zeros into a code which at the far end is converted back to three zeros.



---

**B8ZS (Bipolar with Eight Zero Suppression)**

A T1 line protocol that converts a channel word with eight consecutive zeros into a code which, at the far end, is converted back to eight zeros. Allows 64 Kbps clear channel operation while assuring the ones density required on the T1 line.

**bandwidth reservation**

An IPX software feature that allows circuits to automatically become active (or “upped”) at a specified time and date and downed at some later time and date. For circuits that do not need to be available 100% of the time.

**B channel**

In ISDN, a full-duplex, 64-kbps channel used to send user data. Also known as the bearer channel. Compare with D channel.

**BCC**

The control card for the BPX switch.

**BC-E1 (Backcard E1)**

E1 interface card used on IPX and IGX switches.

**BC-E3 (Backcard E3)**

E3 interface card used on IPX and IGX switches.

**BC-J1 (Backcard J1)**

J1 interface card used on IPX and IGX switches.

**BC-SR (Backcard Subrate)**

Subrate interface card used on IPX and IGX switches.

**BC-T1 (Backcard T1)**

T1 interface card used on IPX and IGX switches.

**BC-T3 (Backcard T3)**

T3 interface card used on IPX and IGX switches.

**BC-Y1 (Backcard Y1)**

Y1 interface card used on IPX and IGX switches.

**BDA (Bframe Destination Address)**

The address of the slot.port.channel for which the Bframe is destined. This address is part of the Bframe header and is only used across the switch fabric locally in the node.

**Bframe**

The BPX frame is the 64-byte format for messages used to encapsulate ATM cells which are sent across the switch fabric.

**bipolar violations**

Presence or absence of extra “1” bits on a T1 transmission facility caused by interference or a failing line repeater. These extra or missing bits interrupts one of the rules for bipolar pairs of a digital transmission line.

**BISDN (broadband ISDN)**

ITU-T communication standards designed to handle high-bandwidth applications. Compare with ISDN.

---

**BNI (BPX Network Interface Card)**

The front card used to network BPX switches together and to connect to AXIS shelves, and IPX and IGX nodes configured as shelves. Supports T-3, E-3, and OC3 trunks carrying ATM cells.

**BPX Switch**

A high-speed broadband, high-capacity ATM cell relay network switch from for private and public networks.

**BRI (Basic Rate Interface)**

ISDN interface composed of two B channels and one D channel for circuit-switched communication of voice, video, and data. Compare with PRI.

**bundled connections**

Frame relay connections grouping a number of ports into one permanent virtual circuit.

**BTM (Broadband Trunk Module)**

The BTM provides an ATM trunk interface for the IGX switch. The BTM operates in conjunction with a backcard, AIT-T3, or AIT-E3.

**BXM**

A series of BPX cards, BXM-T3/E3, BXM-155, or BXM-622 which can be configured for either trunk or line (service access) modes. These cards support ATM Traffic Management 4.0, including VSVD congestion flow control.

## C

**CAS (Channel Associated Signalling)**

A signalling mode in E1 transmission where the signalling bits for all 30 E1 channels are carried in timeslot 16. Timeslots 1 to 15 and 17 to 31 carry encoded voice bits only.

**CBR (Constant Bit Rate)**

ATM Connection type for constant bit rate traffic such as voice or synchronized data requiring a low variation in delay. (See also, VBR and ABR.)

**CCDV (Compliant Cell Delay Variation)**

A parameter utilized in defining ATM Constant Bit Rate service. The amount of delay that is acceptable between ATM cells for them to be accepted as compliant (usable).

**CCITT (Consultive Committee for International Telephone and Telegraph)**

An international telecommunications advisory committee established under the United Nations to recommend worldwide standards for data and voice communications.

**CCS (Common Channel Signalling)**

A carrier signalling mode in E1 transmission where signalling bits are not used. CCS typically separates user data from signalling information. A signalling channel is used to provide signalling for all other user data channels in the system.

**CDP (Channelized Data PAD)**

An IPX dual-purpose front card that can carry voice traffic, a combination of voice and data, or just data. The CVM card is used in conjunction with a BC-T1, BC-E1, or BC-J1 backcard.

**CDVT (Cell Delay Variation Tolerance)**

Controls time scale over which the PCR is policed.

---

**Cell**

A unit of data with a fixed number of bytes. For ATM the cell size is 53 bytes.

**cell relay**

A form of digital communications using fixed length cells consisting of data and a small header. IPX FastPacket was an early implementation of cell relay. The 53 byte ATM cell consists of data and a small header.

**CEPT**

CEPT is the European Conference of Posts and Telecommunications Administrations. This association is comprised of European Telecommunications service providers that participate in relevant areas of the work of CEN/CENELEC.

**CGA (Carrier Group Alarm)**

A major alarm condition for a T1 multiplexer or PABX that results in all channels being taken out of service.

**channel**

The logical end point for a connection.

**circuit line**

A T1 or E1 line that connects a user device, such as a PABX or channel bank to the IPX switch. Carries customer DS0 voice and data circuits. (See also line.)

**Cisco StrataView Plus**

A Unix-based workstation and software used as a network management system (NMS) for Cisco WAN switching networks. It is part of the StrataSphere group. Provides a graphical user interface for configuration, maintenance, administration of the network. Collects and displays network statistics.

**clear channel capability**

When all eight bits of a channel word in the T1 line signal are available for transmitting customer data with no restrictions on content. Also referred to as 64 Kbps clear channel.

**Cmax**

A frame relay connection parameter that specifies the number of packets allowed in the initial burst of data after which the data bandwidth is reduced to the connection's minimum specified bandwidth.

**CLLM**

Consolidated Link Layer Management. A protocol used to transmit ForeSight messages across the frame relay NNI port.

**CLP (Cell loss priority)**

Cell loss Priority. CLP Hi and CLP Lo thresholds are configurable.

**Complex Gateway**

Refers to interworking of a connection with respect to the IPX and IGX nodes. For example, in a Frame Relay to ATM interworking, the Frame Relay data is extracted from FastPackets and transformed to ATM cells with redundant overhead bits discarded.

**composite data rate**

The sum of the data rates for all circuits transmitting on the same synchronous or frame relay data card.

---

**control port**

An RS-232 port on the face plate of a back card for a controller card (BCC, NPC, NPM.) that may be used for connecting a control terminal. This port is bi-directional.

**COS (Class of Service)**

The priority assigned each user connection. Defines which circuits get rerouted first during a network failure.

**courtesy downing**

A software feature that is used to conserve network bandwidth by automatically “downing” a voice connection when the signalling status indicates an inactive (on-hook) circuit. The circuit is automatically “upped” when the circuit becomes active.

**CRC (Cyclical Redundancy Check)**

A method of error checking that detects errors in a block of data. Unlike parity checks, the CRC can detect multiple data errors within the block and thus equipment using a CRC error check can derive an error rate.

**crosspoint switch**

A two-dimensional data switch type that is arranged in a matrix of all input connections along one axis and all output connections along the other axis. Each input and output line has a switch point where the two axes intersect that can be enabled (switch closed) or disabled (switch open). The central matrix switch providing the switching matrix for traffic routing by the BPX switch.

**CSU (Channel Service Unit)**

A network protection unit that terminates any T1 span line connected to the carrier's central office, providing receive direction regeneration and maintenance loopback for the 1.544 Mbps signal.

## D

**D4-format**

A digital signal format with 24 eight-bit channels plus one synchronizing bit per T1 line. Channels are assigned in a straight, numeric sequence.

**DACS (Digital Access and Control System)**

Equipment, usually found in the telephone company central office, that is used to groom and retim the 24 channels in a DS1 signal. Individual DS0 channels can be cross-connected from one DS1 source and inserted in another DS1 source either with the same or with a different channel number.

**DAS Server Shelf**

The adjunct processor used in INS Dial-Up Frame Relay applications to provide frame relay dial-up and dial-backup circuits. The DAS Server Shelf is co-located with and connected to an IPX or IGX switch.

**DCE (Data Communications Equipment)**

As defined by the RS-232 standard, any device that transmits or receives information. Usually used with data terminal equipment (DTE, like a computer or network node).

**D channel**

A message-oriented ISDN signalling channel, typically carried in DS24 of a PRI on T1 facilities or TS16 of a PRI on E1 facilities. Compare to B channel.

---

**DDS (Digital Data Service)**

An AT&T dial-up data service offering for 2.4 to 56 Kbps over subscriber loop cable. Requires a Data Service Unit, DSU, at customer premise for interface to the DDS trunk.

**Device Code**

The first 8 bits of a FastPacket Address.

**DFM (Data Frame Multiplexing)**

An optional feature that saves data channel bandwidth by analyzing data channel content and suppressing repetitive data patterns.

**Dial Access Switching**

Another name for the INS Dial-Up Frame Relay application.

**Dial-Up Frame Relay**

An INS application that uses a DAS Server Shelf and software to enhance Cisco WAN switching networks with frame relay soft permanent virtual circuits (SPVCs) for dial-up dial-backup connections.

**DLCI (Data Link Connection Identifier)**

A field in a frame relay data packet that identifies the destination for the data.

**domain**

A grouping of nodes sharing common interests or attributes.

**domain name**

A unique name consisting of the letter "D" immediately followed by a number (1–8) delineated by a "." (period) from the node name (1–8 characters maximum). Example: D1.alpha.

**domain number**

A number from 1–8 assigned with the cnfdmn command. The number assigned is part of the domain name.

**DPNSS**

Digital Private Network Signalling System. A common-channel message-oriented signalling protocol commonly used by private branch exchanges (PBXes). The INS Voice Network Switching application supports DPNSS signalling.

**DS0 (Digital Signal 0)**

A 64 Kbps channel used to transmit encoded voice and/or data. There are 24 DS0 channels in a circuit T1 (DS1) line. DS0 data is transmitted using one or more DS0 circuits in a T1 or E1 circuit line.

**DS0A**

An extension of DS0 that defines the format for assembling various low-speed data circuits (1.2 to 19.6 Kbps) into a single 64 Kbps DS0 channel.

**DS1 (Digital Signal 1)**

A digital transmission standard that carries 24 individual channels in a bipolar, high-speed line signal at 1.544 Mbps. DS1 signal level is  $\pm 3V$ .

---

**DSI (Digital Speech Interpolation)**

An algorithm that analyzes DS0 voice bits for non-speech codes. Suppresses these bits to conserve packet line bandwidth and inserts a code to indicate to the far end that these bits have been removed. Similar to DFM for data channels. Also, referred to as VAD (Voice Activity Detection).

**DTE (Data Terminal Equipment)**

As defined by the RS-232 standard, any device that generates or utilizes information. (See also, DCE.)

**E****E1**

European transmission service at the rate of 2.048 Mbps.

**E3**

Transmission service at a rate of 34.368 Mbps.

**ECN (Explicit Congestion Notification)**

A frame relay feature to signal the onset of network congestion to external devices. Sets FECN and BECN bits in frame relay header to indicate forward and backward congestion.

**F****Fast EIA**

Same as interleaved EIA. Seven data circuit control leads in each direction are transmitted in alternating bytes with data. For fast control lead response to data being turned on and off but with a sacrifice in packet line bandwidth.

**FBTC (Frame Based Traffic Control)**

An AAL5 frame based traffic control that provides the possibility of discarding the whole frame, not just one compliant cell. This avoids wasting bandwidth by continuing to send the cells in a frame once a cell has been found to be non-compliant.

**FGCRA (Frame Based Generic Cell Rate Algorithm)**

An enhancement option to GCRA that allows an entire frame to be discarded if any of its cells are non-compliant, rather than transmitting a partial frame over the network.

**flat network**

A non-structured network, a network in which there are no junction nodes or domains.

**foreign network**

An adjacent network that is owned and managed by a different party than the one that owns the local network.

**ForeSight**

A proprietary optional feature that uses feedback techniques to dynamically allocate extra bandwidth to frame relay and ATM connections when the network bandwidth is available and not used by other connections. (See also VSVD.)

---

**frame forwarding**

A software feature allowing point-to-point frame relay type connection for various data applications that do not conform to the Frame Relay Interface Specification.

**FPC (FastPAD Back Card)**

The FPC is used with an FTC (IPX switch) or FTM (IGX switch) card. The FPC provides either a T1, E1, V.35, or X.21 interface.

**frame relay connection class**

A tag for a frame relay circuit which indicates the class of service to be provided for this connection. Parameters associated with a connection class include minimum information rate guaranteed, peak information rate expected, maximum network delay, etc.

**FRI (Frame Relay Interface Card)**

The backcard for an FRP (IPX switch) or FRM (IGX switch) card. The FRI provides V.35, X.21, T1, or E1 interfaces.

**FRP (Frame Relay PAD)**

An IPX frame relay front card that supports 1-4 data ports, and in single-port mode, operates up to 2.048 Mbps. The card is used in conjunction with FRI-V.35, X.21, T1, or E1 backcards.

**FRM (Frame Relay Module)**

An IGX frame relay front card that supports 1-4 data ports, and in single-port mode, operates up to 2.048 Mbps. The card is used in conjunction with FRI-V.35, X.21, T1, or E1 backcards.

**FRM-2 (Frame Relay Module)**

An IGX frame relay front card that provides an interface to the frame relay Port Concentrator Shelf (PCS). The card is used with the FRI-2-X.21 backcard which connects to the PCS.

**FRP-2 (Frame Relay Module)**

An IPX frame relay front card that provides an interface to the frame relay Port Concentrator Shelf (PCS). The card is used with the FRI-2-X.21 backcard which connects to the PCS.

**FRP-2 (Frame Relay Module)**

An IPX frame relay front card that provides an interface to the frame relay Port Concentrator Shelf (PCS). The card is used with the FRI-2-X.21 backcard which connects to the PCS.

**Frame Relay Service**

A packet interface data transmission protocol used for connecting widely-separated LANs. Characterized by long intervals of no data to be sent interspersed with bursts of large volumes of data; sometimes referred to as "bursty data".

**frame slip**

A T1 error condition caused by a timing problem between the network and the IPX switch. When this happens, the IPX switch inserts a blank DS1 frame or drops an idle DS1 frame so there is no loss of customer data.

**FRTT (Fixed Round Trip Time)**

The sum of the fixed and propagation delays from the source to a destination and back.

**Full Status Report**

A message sent across the NNI indicating the A-bit status of all connections routed across this NNI frame relay port.

---

**FTC (FastPAD Trunk Card)**

An IPX frame relay front card that provides an interface to a FastPAD. The FTC is used with an FPC backcard. that provides either a T1, E1, V.35, or X.21 interface.

**FTM (FastPAD Trunk Module)**

An IPX frame relay front card that provides an interface to a FastPAD.

**G****gateway**

A node that is configured to handle both T1 and E1 packet and circuit lines for direct interface international circuits. (See also Seamless International IPX Network.)

**GCRA (Generic Cell Rate Algorithm)**

GCRA is a “continuous leaky-bucket” process that monitors the cell depth in the input queue for each PVC to determine whether to admit a new cell to the network without setting the Cell Loss Priority bit.

**global addressing**

A frame relay addressing convention that uses the DLCI to identify a specific end device somewhere else in the frame relay network. In a global addressing scheme, the DLCI is a unique number for each port in the network.

**grouped connections**

Frame relay connections grouping a number of ports onto one permanent virtual circuit. Similar to bundled connections except the grouped connections do not have to be contiguous, nor do they all have to be added simultaneously.

**H****HDB3 (High Density Bipolar Three)**

A new line interface for E1, similar to B8ZS for T1, which eliminates patterns with eight or more consecutive zeros. Allows for 64 Kbps clear channel operation and still assure the ones density required on the E1 line.

**HDP (High Speed Data PAD)**

An IGX front card that supports one to four medium speed, synchronous data channels.

**I****IGX Switch**

A multi-service, multi-band ATM cell relay network switch for private and public networks.

**Intelligent Network Server (INS)**

INS is the broad name for a range of products that enhance traditional Cisco WAN switching networks. These products include Dial-Up Frame Relay, Voice Network Switching, and ATM Switched Virtual Circuits.

**interleaved EIA**

Same as “Fast EIA”.



---

**IPX Switch**

A narrowband cell relay network switch from for private and public networks.

**ISDN (Integrated Services Digital Network)**

A service provided by the telephone company or OCC that supports combined customer voice and data connections over the twisted pair subscriber loop. Requires special equipment at the customer premise and a connecting central office switch that is capable of providing ISDN.

**J****J1**

A. multiplexed 24-channel circuit line to a PBX conforming to the Japanese TTC-JJ-20 circuit standard. Similar to E1, it operates at 2.048 Mbps.

**junction node**

A node handling inter-networking of domains.

**junction trunk**

A packet line connecting junction nodes.

**L****LCON**

The logical connection used to represent an individual routing entity.

**LDM (Low Speed Data Module)**

An IGX data front card that supports up to 8 synchronous or asynchronous data ports. When used with an LDI4/DDS, an LDM can provide 56-Kbps Digital Data Service (DDS) interfaces to the IGX switch.

**LDP (Low Speed Data PAD)**

An IPX data front card that supports up to 8 synchronous or asynchronous data ports. When used with an LDI4/DDS, an LDP can provide 56-Kbps Digital Data Service (DDS) interfaces to the IPX switch.

**LEC (Lower Expansion Card)**

An expansion back card for the IPX 32 that connects upper shelf bus to lower shelf bus and the active NPC to standby NPC.

**line**

Connects a user device to a service interface, for example, a router to an ASI or AUSM card, a data line to a data card, a frame relay line to an FRP or a port concentrator, or a T1 or E1 line to a CDP card.

**link**

The network connection between two nodes.

**LMI (Local Management Interface)**

The protocol and procedures for control of IPX frame relay connections. Used for configuration, flow control, and maintenance of these connections.

---

**local addressing**

A frame relay addressing convention that uses the DLCI to identify the IPX frame relay port at the interface between the user device and the frame relay network. In local addressing, a particular DLCI is used only at the local FR connection. The DLCI may be reused at any other IPX node in the network.

**local alarm**

An IPX alarm indicating that the associated T1 line is down due to a local failure of its receive path.

**local bus**

An IPX utility bus (LB/0 or LB/1) located on the midplane, which provides the electrical connections between various front and back cards. For example, the front and back cards of the Low Speed Data PAD group (LDP and LDI) plug into this utility bus.

**logical port**

A frame relay circuit consisting of either 1, 6, 24 (T1,) or 31 (E1) contiguous DSO's on a T1 or E1 physical port.

## M

**major alarm**

A local or remote failure that is affecting operation of the network.

**MBS (Maximum Burst Size)**

Maximum number of cells which may burst at the PCR but still be compliant.

**MCR (Minimum Cell Rate)**

The minimum cell rate that is supported by an ATM connection for an ABR connection.

**MIR (Minimum Information Rate)**

The minimum information rate that is supported by a frame relay connection.

**minor alarm**

A local or remote failure that is not affecting operation of the network, but nonetheless should be investigated.

**MUXBUS**

A high-speed IPX backplane bus that carries data and timing between card slots for both circuit line and packet line data. Consists of the TDM bus carrying the data and the system clock bus that is used to synchronize all data flowing on and off the TDM bus.

## N

**n+1 redundancy**

A redundancy method in which a group of cards share the same standby redundant card.

**Network-to-Network Interface (NNI)**

The protocol at a frame relay port that serves as a bidirectional interface between a local Cisco WAN switching network and a separate and independent "other" network.

---

**node**

An IPX/IGX/BPX switch serving as a connection point to the network. At a node, connections from service lines are routed to trunks for transmission to other nodes in the network.

**NPC (Network Processor Card)**

Micro-processor based system controller front card that contains the software used to operate the IPX switch.

**NPM (Network Processor Module)**

Micro-processor based system controller front card that contains the software used to operate the IGX switch.

**Nrm**

Maximum number of cells a source may send for each forward RM cell, i.e., an RM cell must be sent for every Nrm-1 data cells.

**NTC (Network Trunk Card)**

IPX front card that coordinates fastpacket trunk traffic to another node via a number of backcards: T1, E1, Y1, and subrate (RS449, X.21, and V.35).

**NTM (Network Trunk Module)**

IGX front card that coordinates fastpacket trunk traffic to another node via a number of backcards: T1, E1, Y1, and subrate (RS449, X.21, and V.35).

**O****OC-3**

Standard optical transmission facility rate of 155.20 Mbps.

**OCC (Other Common Carrier)**

In the United States, reference to all the other telecommunications companies providing various transmission services other than AT&T.

**P****packet line**

Packet line referred to a line used to carry FastPackets between IPX nodes in a network. The term in these documents is replaced by the more general "trunk" which is defined as a physical link from node to node, node to shelf, or node to network. The trunk may be one that supports 24-byte FastPackets (packet trunk), or one that supports 53 byte ATM cells (cell trunk).

**packet switching**

A system that breaks data strings into small units (packets), then individually addresses and routes them through the network.

**PAD (Packet Assembler/Disassembler)**

A device that converts a serial data stream into discrete packets in the transmit direction and converts the received packets back into a serial data stream. Adds header information in the transmit packet to allow it to be routed to the proper destination.

---

**partially-interleaved EIA**

One control lead in each direction, generally RTS-CTS, is transmitted in same byte as seven data bits. For fast control lead response to data being turned on and off.

**PBX (private branch exchange)**

Digital or analog telephone switchboard, classified as customer premise equipment (CPE), used to connect private and public telephone networks.

**PCM (Pulse Code Modulation)**

The system for transmitting telephone signals digitally. Voice is sampled 8000 times per second and converted to an 8-bit digital word.

**PCR (Peak Cell Rate)**

The maximum rate for an ATM connection at which cells are allowed into the network.

**PCS (Port Concentrator Shelf)**

The PCS is an external shelf that expands the capacity of the FRP card. The PCS is used with the FRP-2 (IPX switch) or FRM-2 (IGX switch) card to 44 frame relay connections. The PCS connects to the FRI-2.X.21 backcard.

**PIR (Peak Information Rate)**

The peak level in bits per second allowed for a frame relay connection.

**PLCP (Physical Layer Convergence Protocol)**

A protocol defined for use with Switched Megabit Data Service. Used on DS3 ATM trunks in the BPX switch.

**PLPP (Physical Layer Protocol Processor)**

A custom VLSI processor used in the T3 ATM port interface of the BPX BNI card to handle the coding and decoding of the PLCP bit structure. Functions handled by the PLPP include header check sequence generation and checking, DS3 framing, and optional payload scrambling/descrambling.

**plesiochronous network**

A network where there is more than one source of network timing. The multiples sources must be operating at the same frequency but are not phase locked (synchronous) with each other.

**port**

Refers to a signal connection on a data back card that interfaces to a customer circuit or data device. The number of ports on a card ranges from 1 to 8 depending on the particular card type.

**PRI (Primary Rate Interface)**

An ISDN interface to primary rate access. Primary rate access consists of a single D channel for signalling and 23 (T1) or 30 (E1) B (bearer) channels for user data. A PRI is typically carried on T1 or E1 facilities.

**privilege level**

A level between 1 and 6 that is assigned to each IPX command. Each operator is assigned a privilege level by the system administrator. The operator may only access and execute commands equal to or lower than his or her own privilege level. Level 1 is the highest and level 6 is the lowest.

**PVCs**

Permanent Virtual Connections (circuits). Connections that are assigned but not connected until data is sent, thereby not using bandwidth when idle.

---

## Q

### **Q.921/Q.931**

ITU-T specifications for the ISDN user network interface (UNI) data link layer.

### **QSIG**

A common-channel message-oriented signalling protocol, defined by the European Telecommunications Standard Institute (ETSI), commonly used by private branch exchanges (PBXes). The INS Dynamic Network Switching application supports QSIG signalling to the Cisco WAN switching network.

### **queue**

A buffer that is used to temporarily hold data while it waits to be transmitted to the network or to the user.

## R

### **RIF (Rate increase factor)**

Controls the amount by which the cell transmission rate may increase upon receipt of an RM cell.

### **RDF (Rate decrease factor)**

Controls the amount by which the cell transmission rate may decrease upon receipt of an RM cell.

### **red alarm**

Another name for local alarm as the local alarm lamp on most digital transmission equipment is red in color.

### **remote alarm**

An IPX alarm indicating that the associated T1 line is down due to a receive line failure on another node. (See also yellow alarm.)

### **RPS (repetitive pattern suppression)**

Also called data frame multiplexing (DFM). An option for data circuits where repeating strings of data are replaced on the packet line by a single occurrence of the data string and a code that indicates to the far end how many repetitions of the string was being transmitted. Used to conserve network bandwidth.

### **robbed bit signaling**

A type of signaling used on T1 lines where the signaling bits for each channel are substituted for the least significant voice bit in each channel word during frames 6 and 12.

### **RS-232**

A physical and electrical interface standard for a low-speed, unbalanced, serial, data interface adopted by the EIA committee on data communications. Generally used for data circuits operating at data rates below 56 Kbps.

### **RS-422/423**

Another EIA standard electrical interface for serial data circuits operating at higher data rates than RS232. RS422 is a balanced interface; RS423 is unbalanced. Uses RS-449 for the physical interface (connector).

---

**RS-449**

The physical interface for the RS422 and R423 electrical interfaces. Contains the Processor Controller Card and the PCC utility bus, and provides system timing and control via the system bus.

**S****SAR (Segmentation and Reassembly)**

The process of breaking a dataframe containing data from a number of virtual paths or circuits apart so that the individual paths/circuits can be switched by reassembling the data into a new frame with a different sequence.

**SCC (System Clock Card)**

An IPX backcard that works in conjunction with the NPC. The SCC provides a centralized clock generation function and provides serial and LAN port interfaces.

**SCM (System Clock Module)**

An IGX backcard that works in conjunction with the NPM. The SCM provides a centralized clock generation function and provides serial and LAN port interfaces.

**SCR (Sustainable Cell Rate)**

Rate above which incoming cells are either tagged or discarded.

**SDP (Synchronous Data PAD)**

An IPX front card that supports one to four medium speed, synchronous data channels.

**SDI (Synchronous Data Interface)**

The back card for the SDP (IPX switch) or HDM (IGX switch) cards. The SDI is available with V.24, X.21, and V.35 interfaces.

**seamless international network**

An IPX network that is configured to carry traffic over international borders (E1-T1 or T1-E1)—see also gateway.

**Simple Gateway**

Refers to FastPacket to ATM interworking with respect to the IPX and IGX nodes. In the simple gateway mode, FastPackets are encapsulated in their entirety into cells. Compare with complex gateway.

**SIU (Serial Interface Unit)**

A set of circuits common to all BPX cards used for transmitting and receiving via the crosspoint switch.

**Soft PVC**

A PVC in the INS Dial-Up Frame Relay application that is dormant in the networks database until it is activated by a call into the network by a user.

**spanning tree**

An IPX network topology in which there is only one path available between any two sources in a frame relay multicast group. Spanning trees are required to prevent frames broadcast from a single source to multiple receptors from circulating endlessly around the network a result of frame relay circuits not having properly closed loops.

---

**speech detection**

Determining the presence or absence of speech for Digital Speech Interpolation. Performed in either the CDP card or VDP card in an IPX node.

**split clock**

A data clocking configuration where the timing for the transmit data is obtained from one source (e.g. user device) and the timing for the receive data is obtained from another source (e.g. IPX switch).

**Status Enquiry**

A message transmitted by a FR NNI port requesting an updated status from the attached foreign network. This message is used as a heartbeat to detect when a port has failed.

**StrataBus**

On the BPX switch, contains crosspoint wiring used to carry ATM trunk data between both the network interface and service interface modules and the crosspoint switch as well as providing control, clock, and communications.

**subrate data**

Multiple low-speed data circuits carried in a single DS0 timeslot.

**superrate data**

Single high-speed data circuit carried in multiple DS0 timeslots.

**SCR (Sustained Cell Rate)**

Long term limit on the rate a connection can sustain.

**SVC (switched virtual circuit)**

A virtual circuit that is dynamically established on demand and torn down when transmission is complete. SVCs do not need to reserve any network resources when they are not in use. Called a switched virtual connection in ATM terminology. Compare with PVC.

**system bus**

A two-part IPX data bus. One part carries system commands between the PCC and other IPX cards; the other carries time division multiplexed data.

**T****T1**

The standard US. multiplexed 24-channel voice/data digital span line. Operates at a data rate of 1.544 Mbps.

**T3**

Transmission service at DS3 rate of 44.736 Mbps.

**TBE (Transient Buffer Exposure)**

The negotiated number of cells that the network would prefer to limit the source to send during the start-up period.

**TDM (time division multiplexing)**

The process of combining several communication channels by dividing a channel into time increments and assigning each channel to a timeslot.

---

**timestamp**

A field in certain FastPacket formats that indicates the amount of time the packet has spent waiting in queues during the transmission between its source and destination nodes. Used to control the delay experienced by the packet.

**Trm**

An upper bound on the time between RM cells for an active source, i.e., RM cell must be sent at least once every Trm msec.

**trunk**

A physical link between two nodes. The trunk may be one that supports 24-byte FastPackets (packet trunk), or one that supports 53 byte ATM cells (cell trunk.)

**trunk conditioning**

A set of signalling and information bits that indicate a DS1 line failure.

**trunk queues**

The buffers in packet line cards (NTC, TXR) where the various FastPackets are queued up for transmission over the packet line(s). The buffers attempt to prioritize each packet so it experiences minimum delay.

## U

**μ-law**

An analog to digital encoding scheme used to convert voice samples to an 8-bit data word used in D3/D4 T1 multiplex equipment.

**UBR**

Unspecified Bit Rate.

**UNI (User to Network Interface)**

The user to network interface, used for ATM connection to CPE. Compare with NNI.

**UPC (Usage Parameter Control)**

A general procedure for controlling the rate of user data applied to an ATM network. There are a number of different algorithms for performing UPC. See also GCRA.

**USART (Universal Synchronous/Asynchronous Receiver Transmitter)**

A single-chip device used in certain applications that allows microprocessors to communicate with input/output (I/O) devices.

**User to Network Interface (UNI)**

The protocol at a frame relay port that passes information between the network and the user device attached to the port.

## V

**V.21**

A CCITT interface standard often used for data transmission over modems.



---

**V.35**

A data communications interface standard adopted by the CCITT. Often used for data circuits operating at 56 Kbps and above.

**VAD (Voice Activity Detection)**

Used to statistically compress voice by not sending packets in the absence of speech.

**VBR (Variable Bit Rate)**

Connection type for variable bit rate traffic such as bursty data. Compare with CBR and ABR.

**VC\_Q**

Frame relay buffer allocation parameter that specifies the maximum queue size reserved in the FRP card for the FR connection.

**virtual circuit**

A circuit that acts like it is an individual transmission path but is actually shared with other circuits over a single transmission path. Compare with PVCs.

**VNS**

The adjunct processor used in the INS Voice Network Switching application. The VNS is co-located with and connected to an IGX or IPX switch.

**Voice Network Switching**

An INS application used to provide voice or data switched virtual circuits over a Cisco WAN switching network for PBXes using either QSIG or DPNSS signalling.

**VSVD (Virtual Source/Virtual Destination)**

ATM Forum Traffic Management 4.0 method of providing congestion flow control for ABR connection types. Resource Management (RM) cells are used to convey management information between sources and destinations.

**vt (virtual terminal)**

An IPX control terminal that is the active control terminal at one node but is physically attached to another node.

## W

**WAN (Wide Area Network)**

A network of transmission circuits generally spanning a large region or territory for transmission of voice and data between widespread end users. An IGX/BPX network is an example of a WAN.

## X

**X.21**

A CCITT standard for data interfaces transmitting at rates up to approximately 2 Mbps.

**X.25**

A commonly-used standard that defines the protocol for low-speed data packet networks.

---

**XON/XOFF**

A simple communications protocol for controlling the flow of data from one device to another. An XON sent from a receiving device indicates it is ready to accept data and the transmitting device may begin to output data. An XOFF from the receiving device indicates that it can no longer store any more data and the transmitting device should temporarily cease transmitting.

**Y****Y-cable(s)**

A short adapter cable forming an electrical branch (thus the term Y) for connecting a single customer data or trunk connection to two identical back cards to provide hardware redundancy on the IGX switch.

**Y-cable redundancy**

A redundancy type used in the IPX switch when a 1:1 card redundancy is implemented using a split or Y-cable for the data connection between the user device and the primary and standby IGX interface card.

**Y1**

A digital trunk conforming to the Japanese “Y” circuit standard, for use as a packet line. Similar to T1, it operates at 1.544 Mbps.

**yellow alarm**

Another name for remote alarm as the remote alarm lamp on digital transmission equipment is always yellow in color.

**A**

- AAL 2-11
  - classes of traffic 2-11
- AAL5 Frame Base Traffic Control 7-9
- ABR 5-4
- ABR (Available Bit Rate) 7-3
- ABR and ATFST Connections 7-17
- ABR Connection Policing 7-35
- ABR STD 7-10
- AC Power
  - Supplies 2-4
- adaptation
  - FastPacket to ATM 2-14
- adaptation layers
  - and traffic classes 2-12
- addshelf command 8-11
- ADTF 7-10
- air intake grille 2-3
- AIT card 2-15
- Alarm/Status Monitor 3-12
- arbiter 3-3, 3-4
- ASI
  - features 5-3, 5-12
    - Line Module 5-8, 5-10
    - line statistics 5-14
- ASM (see Alarm/Status Monitor)
- ASM controls 3-13
- AT3-6M Interface Adapter xxvii, D-1
- ATM
  - cell headers 2-8
  - cell switching 3-1
- ATM adaptation layer 2-11
- ATM connections
  - definition 7-1
- ATM Forum Traffic Management 4.0 7-3
- ATM NIC 8-8
- audience, for this document xxv
- auto-dial modem C-6
- Auto-grooming 8-2
- AutoRoute 1-15, 1-19
  - Cost-based 1-21

**B**

- BAM 2-13
- BCC 3-1
  - Front Panel 3-6
- BCC backcard 3-8
- BCC-3-bc 3-8
- BCC-bc 3-8
- BNI clock modes 4-5
- BPX

- Cabling Summary B-1
- enclosure 2-1
- Features 1-3
- peripherals specifications xxvii, C-1
- shelf 2-1
- BPX Addressing Mode 2-13
- BPX Reference Manual xxviii
  - See Related documentation
- BPX Service Node 8-2
- Broadband Controller Card (BCC) 3-1, 3-2
- BXM 6-2
- BXM, ATM Connections 7-7
- BXM-15 7-1
- BXM-155 6-2
- BXM-622 6-2, 7-1
- BXM-T3/E3 6-2, 7-1

**C**

- CAM 2-13
- card
  - location 2-5
  - status 11-4
- card shelf configuration 2-5
- CBR 5-4, 5-12
- CBR (Constant Bit Rate) 7-3
- CBR Connections 7-13
- CBR Single Leaky Bucket 7-23
- CDVT(0+1) 7-9
- cell headers
  - ATM 2-8
- CI 7-4
- Circuit Emulation Service 7-13
- class of service 1-15
- classes of traffic
  - associated AAL Layers 2-11
- closed-loop 1-16, 7-5
- Cloud Addressing Mode 2-13
- CLP 7-9
- CLP Hi 7-10
- CLP Lo 7-10
- cnflan 3-11
- Command Reference Manual xxviii
  - See Related documentation
- Common Core 2-16
- congestion management 1-16, 7-5
- Connection Parameters 7-9
- Connections
  - configuring 5-4, 5-13
- conventions, documentation xxviii
- cooling fans 2-3, 3-12
- Cost-based route selection
  - Also see Cost-based AutoRoute 1-21
- crosspoint switch matrix 3-3

## D

DC Power  
  input 2-4  
  Power Entry Module 2-3, 11-9  
diagnostics 1-6, 1-24  
Dijkstra's Shortest Path Algorithm 1-21  
display card status 11-4  
DLCI 0 8-5  
DNS Installation and Operation manual  
  overview xxvi  
documentation  
  conventions xxviii

## E

e PNNI signali 8-5  
EFCI 7-10  
Egress from ASI 5-3  
ER 7-4  
ESP 8-1, 8-8  
  Application interfaces 8-9  
  redundant pairs 8-9  
  Y cables 8-10  
Ethernet LAN port 3-3  
Ethernet port 8-8  
explicit rate 7-4  
Extended Services Processor 8-1  
  See ESP

## F

FAIL lights 11-2  
fans 2-3  
FastPacket to ATM 2-14  
FBTC 7-9  
features 1-3  
ForeSight 1-16, 7-5  
FRF.4 8-4  
FRTT 7-10

## I

IBS 7-10  
ICR 7-10  
IGX Reference Manual xxviii  
  See Related documentation  
IISP 8-4, 8-6  
ILMI 8-5  
Ingress to ASI 5-3

Installation  
  ac power supply, redundant 11-12  
Interfaces  
  ESP 8-8  
Interim Inter-switch Protocol  
  See IISP  
Introduction 14-1  
IPX Reference Manual xxviii  
  See Related documentation

## L

LAN LED 3-8  
line module  
  for the ASM 3-15  
  for the BNI 4-8, 4-16  
LM-2T3 5-8, 5-10, 5-17  
LM-3E3 4-8  
LM-3T3 4-8  
LM-ASM (see Line Module Alarm/Status) 3-15  
Location of cards 2-5  
Loopbacks and Diagnostics 4-6  
low-speed data ports 3-3

## M

MBS 7-9  
MCR 7-9  
MIB II Support 14-5  
Modems  
  Auto-Answer at ISC C-4  
  Auto-Dial to ISC C-6  
  Codex 3220 C-4  
modems  
  cable C-5

## N

Network congestion 8-4  
Network Interface 1-17, 2-16  
Network Management 1-17  
Network Statistics 1-18  
network synchronization 1-18  
NI 7-4  
NN 8-4  
NNI 8-4  
  Signaling channel 8-6  
NNI header 2-8  
Node  
  alarms 1-24  
  availability factor 1-24

- redundancy options 1-24
- Synchronization 1-18
- non-blocking 3-4
- Nrm 7-10
- nrt-VBR (Non-Real Time Variable Bit Rate) 7-3

## O

- OptiClass 1-15, 1-19

## P

- PCR 7-9
- PEM (DC Power Entry Module) 11-9
- PEM (see DC Power Entry Module)
- physical description 2-1
- Physical Layer Convergence Protocol 4-3
- Physical Layer Protocol Processor 4-3
- PLCP (see Physical Layer Convergence Protocol) 4-3
- PLPP (see Physical Layer Protocol Processor) 4-5
- PLPP functions 4-5
- PNNI 8-1
  - for SPVCs 8-2
- Policing 7-9
- port queues 4-5
- Power
  - monitoring 3-12
- Power Supplies 2-16
- preventive maintenance 11-1
- Private Network to Network Interface 8-1

## R

- RDF 7-10
- Related documentation xxviii
  - IGX Installation Manual xxviii
  - IPX Installation Manual xxviii
- replacement
  - AC Power Supply 11-11
  - AC power supply 11-11
  - card slot fuse 11-14
  - DC Power Entry Module 11-9
  - fan assembly 11-13
  - front cards 11-5
  - line module 11-7
  - parts 11-5
  - temperature sensing unit 11-14
- Resource Management 7-4
- RIF 7-10
- RM 7-4
- RM cells 7-4

- Role Resolution protocol 8-9
- rt-VBR (Real-Time Variable Bit Rate) 7-3

## S

- SAM 2-13
- SC connector 8-8
- SCR 7-9
- self tests 3- 11-1
- self-tests 4-6
- self-tests, BCC 3-8
- Service Interface 2-16
- Service Interfaces 1-18
- Signaling 8-4
- signaling 8-5
- signalling VCCs 8-5
- Simple Addressing Mode 2-13
- Slots #7 and #8 3-2
- SNMP 8-9
- SNMP Functions 14-3
- SNMP Overview 14-1
- specifications
  - ATM E3 trunk interface A-7, A-8
  - ATM Service Interface, T3/E3 A-10, A-11
  - ATM T3 trunk interface A-6
  - BPX peripherals xxvii, C-1
  - system xxvii, A-1
- SPVC
  - auto-grooming 8-2
- SPVCs 8-2
- SrtaCom Proprietary MIB Structure 14-6
- Standard ABR 7-4
- statistics 5-5, 5-14
- STI header 2-8
- StrataBus backplane 3-17
- StrataView Plus NMS workstation 1-17
- StrataView Plus Operations Guide xxviii
- Stratum 3 system clocking 3-3
- SVC 8-1
- Switch Interface Module (SIM) 3-4
- Switched Megabit Data Service 4-3
- System software 1-19
- system specifications A-1

## T

- tag switching router
  - See TSR 9-16
- TBE 7-10
- Telnet 8-9
- temperature 1-24, 3-12
- Terminal port 8-8

- TFTP 8-9
- throttled 4-5
- Topolog 8-4
- Traffic 7-23
- traffic classes
  - and adaptation layers 2-12
- Traffic Policing 7-23
- Traffic Policing Definitions 7-8
- Trm 7-10
- troubleshooting the BPX 11-1
- TSR 9-16

## U

- UBR (Unspecified Bit Rate) 7-3
- UBR Connection Policing 7-35
- UBR Connections 7-22
- UNI 8-4
- UNI header 2-8
- User Service Interfaces 1-18

## V

- VBR 5-4, 5-12
- VBR and ATFR Connections 7-14
- VBR Dual-Leaky Bucket Policing 7-26
- VC Qdepth 7-10
- VCI 4-5, 5-4, 5-12
- VCI/VPI, description 2-11
- Virtual circuit connections (VCCs) 1-17
- Virtual Circuit Identifier 4-5
- virtual circuit identifier 2-10
- Virtual Path Identifier 4-5
- virtual path identifier 2-10
- virtual trunk 1-13
- Virtual Trunking 1-13
- VPI 4-5, 5-4, 5-12
- VPI 0 and VCI 1 8-5
- VPI 0 and VCI 18 8-5
- VPI 0 and VCI 5 8-5
- VSVD 7-9

**Feedback on the  
Cisco BPX 8600  
Series Reference,  
78-5391-01**

**Release 9.1,  
May 1998**

Thank you for taking the time to fill out this response card. Your input is important to us and helps us to provide you with better documentation.

If you have comments about this document, please complete this self-addressed response card and mail it to us.

We also encourage you to make copies of this blank response card to complete and send to us whenever you have comments about this document. You can mail copies of this card to:

Cisco Systems, Inc.  
Attn: Central  
Documentation Services  
170 West Tasman Drive  
San Jose, CA 95134-9883

You can also send us your comments by e-mail to [bug-doc@cisco.com](mailto:bug-doc@cisco.com), or fax your comments to us at (408) 527-8089.



## Documentation Response Card

### Feedback on the Cisco BPX 8600 Series Reference, Release 9.1, May 1998

Please respond to the following statements by checking a number from 1 to 5:

- 5 Strongly agree
- 4 Somewhat agree
- 3 Neutral
- 2 Somewhat disagree
- 1 Strongly disagree

Overall, I am satisfied with this document.

Strongly agree 5  4  3  2  1  Strongly disagree

This document is accurate and free of errors.

Strongly agree 5  4  3  2  1  Strongly disagree

I can find the information I need in this document.

Strongly agree 5  4  3  2  1  Strongly disagree

This document is complete and offers enough relevant information for me to do my job.

Strongly agree 5  4  3  2  1  Strongly disagree

This document is written at the correct level of complexity for the subject matter.

Strongly agree 5  4  3  2  1  Strongly disagree

This document is useful to me in doing my job.

Strongly agree 5  4  3  2  1  Strongly disagree

Would you like us to contact you? Yes  No

### Additional Feedback

---

---

---

---

---

---

---

---

### Mailing Information

Date

Company Name

Contact Name

Mailing Address

City  State/Province

Zip/Postal Code  Country

Phone (  )  Extension


Fax (  )  E-mail

**BUSINESS REPLY MAIL**

FIRST-CLASS MAIL PERMIT NO. 4631 SAN JOSE CA

POSTAGE WILL BE PAID BY ADDRESSEE

ATTN CENTRAL DOCUMENTATION SERVICES  
**CISCO SYSTEMS INC**  
170 WEST TASMAN DRIVE  
SAN JOSE CA 95134-9883



NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES

