

Repacking a Switch

This appendix provides repacking and shipping instructions for the Catalyst 2948G, 2948G-GE-TX, and 2980G switches if you need to return your switch to the factory.

To repack the switch using the original packaging material, follow these steps:

Note	The Catalyst 2948G switch is shown in Figure B-1. The repackaging procedure for the other switches is identical.
Place	the documentation and accessory kit in the box or poly bag provided.
Place	the documentation and accessory kit in the box or poly bag provided. the box or poly bag containing the documentation and accessory kit on packing material.
Place of the	the box or poly bag containing the documentation and accessory kit on

Figure B-1 Switch Packing Material

