



Preface

This preface explains the audience, purpose, and organization of the *Cisco 6260 Hardware Installation Guide*. It also defines the conventions that are used to present instructions and information.

Audience

The *Cisco 6260 Hardware Installation Guide* is intended for use by central office (CO) technicians and maintenance personnel who are responsible for installing, configuring, and maintaining the Cisco 6260 system. A familiarity with telco products and networking systems is recommended.

Purpose

The *Cisco 6260 Hardware Installation Guide* describes how to set up, install, and troubleshoot the Cisco 6260 system. After completing the installation procedures covered in this guide, refer to the appropriate related documents to provision your Cisco 6260 system. For additional information on related documentation, see the [“Related Documentation” section on page xv](#).

Organization

The *Cisco 6260 Hardware Installation Guide* is organized as follows:

- [Chapter 1, “Product Overview,”](#) provides an overview of the Cisco 6260 and describes the system hardware components.
- [Chapter 2, “Preparing for Installation,”](#) provides the requirements necessary to prepare for the installation of the Cisco 6260 system.
- [Chapter 3, “Installing a Cisco 6260 with a POTS Splitter Configuration,”](#) provides installation procedures for a Cisco 6260 system with a POTS splitter configuration.
- [Chapter 4, “Installing a Cisco 6260 Without a POTS Splitter Configuration,”](#) provides installation procedures for a Cisco 6260 system without a POTS splitter configuration.
- [Chapter 5, “Troubleshooting,”](#) provides troubleshooting procedures for hardware and software conditions in the Cisco 6260.
- [Chapter 6, “Upgrading and Maintaining the Cisco 6260 System,”](#) provides procedures for removing and installing system components, as well as information on maintaining the Cisco 6260 system.

- [Appendix A, “Technical Specifications,”](#) provides the technical specifications for the Cisco 6260 system.
- [Appendix B, “Port Mapping Specifications,”](#) provides cabling guidelines and port mapping tables for the Cisco 6260 system.
- [Appendix C, “Connector and Pinout Specifications,”](#) provides information about connectors and pinouts for the Cisco 6260 system.
- Glossary.
- Index.

Conventions

This publication uses the document conventions listed in this section.

Table 1 Font Conventions

Convention	Definition	Sample
Times bold	Text body font used for any argument, command, keyword, or punctuation that is part of a command that the user enters in text and command environments. Also used for names of some GUI elements.	This is similar to the UNIX route command.
<i>Times italic</i>	Text body font used for publication names and for emphasis.	See the <i>Cisco 6200 Series User Guide</i> for further details.
Courier	Font used for screen displays, prompts, and scripts.	Are you ready to continue? [Y]
Courier bold	Font used to indicate what the user enters in examples of command environments.	Login: root Password: < password >

Table 2 Command Syntax Conventions

Convention	Definition	Sample
Vertical bar ()	Separates alternative, mutually exclusive elements.	offset-list {in out} offset
Square brackets ([])	Indicate optional elements.	[no] offset-list {in out} offset
Braces ({ })	Indicate a required choice.	offset-list {in out} offset
Braces within square brackets ([{ }])	Indicate a required choice within an optional element.	[{letter\number}Enter]

Table 2 Command Syntax Conventions (continued)

Convention	Definition	Sample
Boldface	Indicates commands and keywords that are entered literally as shown	[no] offset-list {in out} offset
<i>Italics</i>	Indicate arguments for which you supply values. Note In contexts that do not allow italics, arguments are enclosed in angle brackets (< >).	offset-list {in out} offset

**Note**

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.

**Timesaver**

Means *the described action saves time*. You can save time by performing the action described in the paragraph.

**Tip**

Means *the following information will help you solve a problem*. The tip information might not be troubleshooting or even an action, but could be useful information, similar to a Timesaver.

**Caution**

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

**Warning**

Means *danger*. You are in a situation that could cause **bodily injury**. Before you work on any equipment, you must be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. To see translated versions of the warning, refer to the *Regulatory Compliance and Safety* document that accompanied the device.

Related Documentation

A complete list of all DSL product-related documentation is available on the World Wide Web at http://www.cisco.com/univercd/cc/td/doc/product/dsl_prod/index.htm.

Obtaining Documentation

The following sections provide sources for obtaining documentation from Cisco Systems.

World Wide Web

You can access the most current Cisco documentation on the World Wide Web at the following sites:

- <http://www.cisco.com>
- <http://www-china.cisco.com>
- <http://www-europe.cisco.com>

Documentation CD-ROM

Cisco documentation and additional literature are available in a CD-ROM package, which ships with your product. The Documentation CD-ROM is updated monthly and may be more current than printed documentation. The CD-ROM package is available as a single unit or through an annual subscription.

Ordering Documentation

Some Cisco documentation is available in the following ways:

- Registered Cisco Direct Customers can order Cisco Product documentation from the Networking Products MarketPlace:
http://www.cisco.com/cgi-bin/order/order_root.pl
- Registered Cisco.com users can order the Documentation CD-ROM through the online Subscription Store:
<http://www.cisco.com/go/subscription>
- Nonregistered CCO users can order documentation through a local account representative by calling Cisco corporate headquarters (California, USA) at 408 526-7208 or, in North America, by calling 800 553-NETS(6387).

Documentation Feedback

If you are reading Cisco product documentation on the World Wide Web, you can submit technical comments electronically. Click the **Feedback** link at the top of the Cisco documentation page. After you complete the form, click **Submit** to send it to Cisco.

You can e-mail your comments to bug-doc@cisco.com.

To submit your comments by mail, write to the following address:

Cisco Systems, Inc.
Document Resource Connection
170 West Tasman Drive
San Jose, CA 95134-9883

We appreciate your comments.

Obtaining Technical Assistance

Cisco provides Cisco.com as a starting point for all technical assistance. Customers and partners can obtain documentation, troubleshooting tips, and sample configurations from online tools. For Cisco.com registered users, additional troubleshooting tools are available from the TAC website.

Cisco.com

Cisco.com is the foundation of a suite of interactive, networked services that provides immediate, open access to Cisco information and resources at anytime, from anywhere in the world. This highly integrated Internet application is a powerful, easy-to-use tool for doing business with Cisco.

Cisco.com provides a broad range of features and services to help customers and partners streamline business processes and improve productivity. Through Cisco.com, you can find information about Cisco and our networking solutions, services, and programs. In addition, you can resolve technical issues with online technical support, download and test software packages, and order Cisco learning materials and merchandise. Valuable online skill assessment, training, and certification programs are also available.

Customers and partners can self-register on Cisco.com to obtain additional personalized information and services. Registered users can order products, check on the status of an order, access technical support, and view benefits specific to their relationships with Cisco.

To access Cisco.com, go to the following website:

<http://www.cisco.com>

Technical Assistance Center

The Cisco TAC website is available to all customers who need technical assistance with a Cisco product or technology that is under warranty or covered by a maintenance contract.

Contacting TAC by Using the Cisco TAC Website

If you have a priority level 3 (P3) or priority level 4 (P4) problem, contact TAC by going to the TAC website:

<http://www.cisco.com/tac>

P3 and P4 level problems are defined as follows:

- P3—Your network performance is degraded. Network functionality is noticeably impaired, but most business operations continue.
- P4—You need information or assistance on Cisco product capabilities, product installation, or basic product configuration.

In each of the above cases, use the Cisco TAC website to quickly find answers to your questions.

To register for Cisco.com, go to the following website:

<http://www.cisco.com/register/>

If you cannot resolve your technical issue by using the TAC online resources, Cisco.com registered users can open a case online by using the TAC Case Open tool at the following website:

<http://www.cisco.com/tac/caseopen>

Contacting TAC by Telephone

If you have a priority level 1 (P1) or priority level 2 (P2) problem, contact TAC by telephone and immediately open a case. To obtain a directory of toll-free numbers for your country, go to the following website:

<http://www.cisco.com/warp/public/687/Directory/DirTAC.shtml>

P1 and P2 level problems are defined as follows:

- P1—Your production network is down, causing a critical impact to business operations if service is not restored quickly. No workaround is available.
- P2—Your production network is severely degraded, affecting significant aspects of your business operations. No workaround is available.